

Roland®

GENERAL MIDI 2 XE V-LINK

***EXR-40 OR***  
***ORIENTAL INTERACTIVE ARRANGER***

Owner's Manual



For EU Countries

This product complies with the requirements of European Directive EMC 89/336/EEC.  
Dieses Produkt entspricht der europäischen Richtlinie EMC 89/336/EEC.  
Ce produit est conforme aux exigences de la directive européenne EMC 89/336/EEC.  
Questo prodotto è conforme alle esigenze della direttiva europea EMC 89/336/EEC.  
Este producto cumple con la directrice EMC 89/336/EEC de la CE.  
Dit product beantwoordt aan de richtlijn EMC 89/336/EEC van de Europese Unie.

For the USA

## FEDERAL COMMUNICATIONS COMMISSION RADIO FREQUENCY INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Unauthorized changes or modification to this system can void the users authority to operate this equipment.  
This equipment requires shielded interface cables in order to meet FCC class B Limit.

For Canada

## NOTICE

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

## AVIS

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

# Roland



## ***EXR-40 OR*** ***ORIENTAL INTERACTIVE ARRANGER***

### Owner's Manual

Thank you for choosing a Roland EXR-40 OR Interactive Arranger, a novel keyboard with a superior Roland sound source, an intuitive user interface, a USB port, V-LINK compatibility and a host of other useful functions.

To get the most out of the EXR-40 OR and to ensure many years of trouble-free service, we urge you to read through this Owner's Manual thoroughly.

To avoid confusion, let's agree to use the word "button" for all keys on the front panel, and use "key" only when referring to the EXR-40 OR's keyboard.

Before using this instrument, carefully read the "Important notes" (p. 7). They provide information concerning the proper operation of the EXR-40 OR. Be sure to keep this manual in a safe place for future reference.

# 1. Features

## Superior sound source

The EXR-40 OR's sounds are based on full-length (uncompressed) waveforms, which is unique in this price range. This produces vibrant, realistic sounds quite unlike anything you would expect from a budget-friendly arranger keyboard. The EXR-40 OR's tone generator is 64-voice polyphonic.

Combined with the new amplification system and Digital Bass Enhancer function, the EXR-40 OR sounds truly amazing, with a clear high end and a powerful low range.

## Lock functions





The EXR-40 OR is equipped with five buttons that allow you to filter various settings from the User Programs you recall. This allows for a more flexible and efficient use of your registrations, because settings you do not need in a given situation can be ignored.

## Flash memory and USB

The EXR-40 OR comes with 99 Music Styles in ROM (73 oriental, 26 western), 99 additional Music Styles and several Standard MIDI Files. The additional Styles and SMFs reside in the EXR-40 OR's Flash memory area, whose contents can be expanded and managed via a USB connection with your PC or Macintosh computer.

## New concept

The EXR-40 OR is 19-part multitimbral, with 3 parts that can be played via the keyboard (Main, Split and Dual). The Main part can be used to play melodies or for drumming, while the Split and Dual parts allow you to quickly add a second sound to your solo playing.

Furthermore, the EXR-40 OR provides a new selection routine for Music Styles, Tones, songs, and User Programs: the FAMILY   buttons can be used for selecting specific groups, while the SELECT   buttons allow you to choose a setting within the selected group.

## Excellent Arranger

The EXR-40 OR comes loaded with 198 Music Styles prepared by Roland's legendary Style foundry. As usual, several patterns are available (INTRO, ORIGINAL, VARIATION, FILL and ENDING), with additional options via the BAND ORCHESTRATOR buttons.

## 3 scale memories plus User Program-dependent scale settings

The EXR-40 OR is Roland's first arranger keyboard to provide 3 scale memories (for oriental tunings) and the possibility to save the currently used tuning settings in a User Program. That way, each of the 200 User Program memories could use a different tuning system.

## And much, much more...

A metronome and several educational functions are provided, while three digital effects processors (Reverb, Chorus and MFX) can be used to further enhance the already amazing sound quality.

The EXR-40 OR can play back GM, GM2, GS and XG song data, so that you can virtually use any Standard MIDI File available at your Roland dealer or on the Internet.

**Note:** The EXR-40 OR supports XG Light and therefore only provides the basic set of compatible functions.

The EXR-40 OR is also equipped with a floppy disk drive (2DD/2HD) for data management and importing Music Styles prepared for older Roland arranger instruments.

Have fun!

Microsoft and Windows are registered trademarks of Microsoft Corporation USA in the United States and other countries.

Apple and Macintosh are registered trademarks of Apple Computer Corporation USA in the United States and other countries.

Mac OS is a registered trademark of Apple Computer Corporation.

Other names of companies, products, or standards are the trademarks or registered trademarks of their respective owners.




# USING THE UNIT SAFELY

## INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

About ⚠ WARNING and ⚠ CAUTION Notices


<b>⚠ WARNING</b>	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.
<b>⚠ CAUTION</b>	Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly.  * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

About the Symbols


	The ⚠ symbol alerts the user to important instructions or warnings. The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger.
	The ⓧ symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled.
	The ● symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the power-cord plug must be unplugged from the outlet.

### ALWAYS OBSERVE THE FOLLOWING


**⚠ WARNING**

- Before using this instrument, make sure to read the instructions below, and the Owner's Manual. 



---


- Do not open or perform any internal modifications on the unit. 

---


- Do not attempt to repair the EXR-40 OR, or replace parts within it (except when this manual provides specific instructions directing you to do so). Refer all servicing to your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information" page. 

---


- Never use or store the EXR-40 OR in places that are:
  - Subject to temperature extremes (e.g., direct sunlight in an enclosed vehicle, near a heating duct, on top of heat-generating equipment); or are 
  - Damp (e.g., baths, washrooms, on wet floors); or are 
  - Humid; or are
  - Exposed to rain; or are
  - Dusty; or are
  - Subject to high levels of vibration.

- This unit should be used only with a rack or stand that is recommended by Roland. 


---


- Make sure you always have the unit placed in such a way that it is level and sure to remain stable. Never place it on stands that could wobble, or on inclined surfaces. 

---



- The instrument should only be connected to a power supply of the type described in the operating instructions, or as marked on the adapter supplied with the EXR-40 OR. 

**⚠ WARNING**


- Do not excessively twist or bend the adapter's power cord, nor place heavy objects on it. Doing so can damage the cord, producing severed elements and short circuits. Damaged cords are fire and shock hazards! 

- This instrument, either alone or in combination with an amplifier and headphones or speakers, may be capable of producing sound levels that could cause permanent hearing loss. Do not operate for a long period of time at a high volume level, or at a level that is uncomfortable. If you experience any hearing loss or ringing in the ears, you should immediately stop using the unit, and consult an audiologist. 


---


- Do not allow any objects (e.g., flammable material, coins, pins); or liquids of any kind (water, soft drinks, etc.) to penetrate the unit.   


---


- In households with small children, an adult should provide supervision until the child is capable of following all rules essential for the safe operation of the EXR-40 OR. 

---









- Protect the unit from strong impact. (Do not drop it!) 



- Do not force the EXR-40 OR's adapter to share an outlet with an unreasonable number of other devices. Be especially careful when using extension cords—the total power used by all devices you have connected to the extension cord's outlet must never exceed the power rating (watts/amperes) for the extension cord. Excessive loads can cause the insulation on the cord to heat up and eventually melt through. 

**! WARNING**

- Before using the EXR-40 OR in a foreign country, consult with your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information" page. 

**! CAUTION**

- The EXR-40 OR should be located so that its location or position does not interfere with its proper ventilation. 
- This unit for use only with Roland keyboard stand KS-12. Use with other stands is capable of resulting in instability causing possible injury. 
- Always grasp only the plug on the adapter when plugging into, or unplugging from, an outlet or this unit. 
- Try to prevent cords and cables from becoming entangled. Also, all cords and cables should be placed out of the reach of children. 
- Never climb on top of, nor place heavy objects on the unit. 
- Never handle the adapter's power cord or its plugs with wet hands when plugging into, or unplugging from, an outlet or this unit. 
- If you need to move the instrument, take note of the precautions listed below. Make sure to have a firm grip, to protect yourself from injury and the instrument from damage. 
  - Disconnect the adapter.
  - Disconnect all cords coming from external devices.
  - Remove the music stand.
- Before cleaning the unit, turn off the power and unplug the adapter from the outlet. 

- Whenever you suspect the possibility of lightning in your area, disconnect the adapter from the outlet. 
- Should you remove screws, make sure to put them in a safe place out of children's reach, so there is no chance of them being swallowed accidentally. 

# Contents

1. Features .....	2	More about ALL mode .....	24	V-LINK function .....	38
2. Important notes .....	7	Keyboard recording mode .....	24	V-LINK functions that the EXR-40 OR can control (and corresponding MIDI messages) .....	38
3. Panel descriptions .....	9	Single recording mode .....	24	12. Function menu .....	39
Front panel .....	9	Punch I/O .....	25	Editing parameters (general procedure) .....	39
Rear panel .....	11	8. Additional Music Style functions .....	26	KB SET parameters .....	39
4. First steps .....	12	One Touch .....	26	METRONOM parameters .....	41
Setting up .....	12	Using the Music Assistant .....	26	OCTAVE parameters .....	41
Demo songs .....	12	Melody Intelligence .....	27	VOLUME parameters .....	41
Playing back a Tone demo song .....	12	Changing the Melody Intelligence harmony type .....	27	ARR SET parameters .....	42
Playback of a Style demo song .....	12	PIANIST Mode .....	27	EFFECTS parameters .....	42
Leaving the Demo mode .....	12	Bass Inversion (Bass Inv) .....	28	KB SCALE parameters .....	43
Playing without accompaniment .....	13	More Music Style functions .....	28	MIDI parameters .....	43
Using the Main part .....	13	9. Using oriental tunings .....	29	UTILITY parameters .....	43
Using the Main and Split parts .....	13	Tuning individual notes a quarter tone down .....	29	13. Working with User Programs .....	44
Using the Main and Dual parts .....	14	Using other tuning values .....	29	Writing your settings to a User Program .....	44
Using the metronome .....	14	Saving and loading your tunings (SCALE MEMORY) .....	29	Notes about writing User Programs .....	44
5. Playing with accompaniment (Arranger) .....	15	10. Keyboard part functions .....	30	Selecting a User Program .....	44
Starting/using the Arranger .....	15	Selecting sounds for the Main, Split and Dual parts .....	30	Lock: filtering certain User Program settings .....	45
Changing the tempo .....	16	Selecting any of the available sounds .....	30	14. MIDI functions .....	46
Automatic playback start (Sync Start & Stop) .....	16	Using the USER TONES buttons .....	30	Channels .....	46
Stopping Arranger playback .....	16	Assigning another Tone to a USER TONES button .....	30	MIDI Function parameters .....	46
Selecting Music Styles .....	16	Drum sounds and sound effects ("SFX") .....	31	15. Data management .....	48
Using the Band Orchestrator function .....	17	Drum Sets .....	31	Working with the Flash memory .....	48
Balance .....	18	Sound effects ("SFX") .....	31	Saving songs to a Flash memory .....	48
6. Playing back songs .....	19	Transpose .....	32	Archiving User Programs in the Flash area .....	48
Basic song playback .....	19	Global transpose function ("GLB") .....	32	Saving Styles to a Flash memory .....	49
Additional playback functions .....	20	Octave settings .....	33	Loading a User Program set from the Flash memory .....	49
Selecting Song mode .....	20	Other Keyboard part functions .....	33	Removing songs from the Flash memory .....	49
Fast Forward, Rewind, and Reset .....	20	11. Performance functions and effects .....	34	Removing Styles from the Flash memory .....	50
Loop playback (Repeat) .....	21	Performance functions .....	34	Removing a User Program set from the Flash memory .....	50
Live performance with song backing (Minus One) .....	21	Keyboard Touch (velocity sensitivity) .....	34	Archiving data using a computer (USB) .....	51
Changing the track assignments .....	22	Pitch Bend and Modulation .....	34	Disk functions .....	52
7. Recording your music .....	23	Footswitch .....	34	Loading User Programs from disk .....	52
Basic song recording .....	23	Using effects .....	35	Loading songs from disk .....	53
Listening to your song .....	23	Using the multi-effects processor (MFX) .....	35	Loading Music Styles from disk .....	53
Other recording functions .....	24	Reverb .....	36	Saving files to disk .....	53
About the recording modes .....	24	Chorus .....	37	Deleting files on disk .....	54

Format .....	55
16. Using the outputs and an optional footswitch.....	56
17. Miscellaneous .....	57
Functions for educational purposes .....	57
Deactivating or activating the Demo function.....	57
Deactivating or activating the Arranger .....	57
Deactivating or activating the Arranger and Demo functions.....	57
Initializing your EXR-40 OR (Factory) .....	57
18. Specifications .....	58
Thanks .....	58
19. Lists .....	117
Tones selectable via the front panel .....	117
Drum Kits .....	120
Music Styles .....	125
Chord Intelligence ("Md1" setting) .....	126
MIDI Implementation Chart .....	128



## 2. Important notes

In addition to the items listed under "Using the unit safely" (p. 3), please read and observe the following:

### Power supply

- Do not use this instrument on the same power circuit with any device that will generate line noise (such as an electric motor or variable lighting system).
- Before connecting the EXR-40 OR to other devices, turn off the power to all units. This will help prevent malfunctions and/or damage to speakers or other devices.

### Placement

- Using the EXR-40 OR near power amplifiers (or other equipment containing large power transformers) may induce hum. To alleviate the problem, change the orientation of this instrument or move it further away from the source of interference.
- This instrument may interfere with radio and television reception. Do not use it in the vicinity of such receivers.
- Observe the following when using the unit's floppy disk drive. For further details, refer to "Before using floppy disks (handling the floppy disk drive)".
  - Do not place the unit near devices that produce a strong magnetic field (e.g., loudspeakers).
  - Install the EXR-40 OR on a solid, level surface.
  - Do not move the unit or subject it to vibration while the drive is operating.
- Do not expose the EXR-40 OR to direct sunlight, place it near devices that radiate heat, leave it inside an enclosed vehicle, or otherwise subject it to temperature extremes. Excessive heat can deform or discolor the instrument.
- To avoid possible breakdown, do not use the unit in a wet area, such as an area exposed to rain or other moisture.
- Do not allow objects to remain on top of the EXR-40 OR. This can be the cause of malfunction.

### Maintenance

- For everyday cleaning wipe the EXR-40 OR with a soft, dry cloth or one that has been slightly dampened with water. To remove stubborn dirt, use a mild, non-abrasive detergent. Afterwards, be sure to wipe the instrument thoroughly with a soft, dry cloth.
- Never use benzene, thinner, alcohol or solvents of any kind, to avoid the possibility of discoloration and/or deformation.

### Repairs and data

- Please be aware that all data contained in the instrument's memory may be lost when it is sent for repairs. In certain cases (such as when circuitry related to memory itself is out of order), we regret that it may not be possible to restore the data. Roland assumes no liability concerning such loss of data.

### Additional precautions

- Please be aware that the memory contents can be irretrievably lost as a result of a malfunction, or the improper operation of the instrument.
- Use a reasonable amount of care when using the instrument's buttons, other controls, and jacks/connectors. Rough handling can lead to malfunctions.
- Never strike or apply strong pressure to the display.
- When connecting/disconnecting cables, grasp the connector itself—never pull on the cable. This way you will avoid causing shorts, or damage to the cable's internal elements.
- A small amount of heat will radiate from the instrument during normal operation. This is perfectly normal.
- To avoid disturbing your neighbors, try to keep the instrument's volume at reasonable levels. You may prefer to use headphones, so you do not need to be concerned about those around you (especially late at night).
- When you need to transport the instrument, package it in the box (including padding) that it came in. Otherwise, you will need to use equivalent packaging materials, or a flightcase.
- Use only a recommended footswitch (DP-2, DP-6, sold separately). By connecting any other footswitch, you risk causing malfunction and/or damage to the EXR-40 OR.


- When the EXR-40 OR is used at excessive volumes, the protection system of its power amplifier stage may come on and mute the speakers. In that case, reduce the volume setting and wait a few seconds.

### Before using floppy disks (handling the floppy disk drive)

- Install the unit on a solid, level surface in an area free from vibration. If the unit must be installed at an angle, be sure the installation does not exceed the permissible range: upward, 2°; downward, 18°.
- Avoid using the EXR-40 OR immediately after it has been moved to a location with a level of humidity that is greatly different than its former location. Rapid changes in the environment can cause condensation to form inside the drive, which will adversely affect the operation of the drive and/or damage floppy disks. When the EXR-40 OR has been moved, allow it to become accustomed to the new environment (allow a few hours) before operating it.
- To insert a disk, push it gently but firmly into the drive—it will click into place. To remove a disk, press the EJECT button firmly. Do not use excessive force to remove a disk which is lodged in the drive.
- Never attempt to remove a floppy disk from the drive while the drive is operating (the indicator is lit); damage could result to both the disk and the drive.
- Remove any disk from the drive before switching the instrument on or off.
- To prevent damage to the disk drive's heads, always try to hold the floppy disk in a level position (not tilted in any direction) while inserting it into the drive. Push it in firmly, but gently. Never use excessive force.
- To avoid the risk of malfunction and/or damage, insert only floppy disks into the disk drive. Never insert any other type of disk. Avoid getting paper clips, coins, or any other foreign objects inside the drive.

## Handling floppy disks

- Floppy disks contain a plastic disk with a thin magnetic coating. Microscopic precision is required to enable storage of large amounts of data on such a small surface area. To preserve their integrity, please observe the following when handling floppy disks:
  - Never touch the magnetic medium inside the disk.
  - Do not use or store floppy disks in dirty or dusty areas.
  - Do not subject floppy disks to temperature extremes (e.g., direct sunlight in an enclosed vehicle). Recommended temperature range: 10°~50°C (50°~122°F).
  - Do not expose floppy disks to strong magnetic fields, such as those generated by loudspeakers.
  - Floppy disks have a "WRITE" tab which can protect the disk from accidental erasure. It is recommended that the tab be kept in the PROTECT position, and moved to the WRITE position only when you wish to write new data onto the disk.



- Do not use this unit for purposes that could infringe on a copyright held by a third party. Roland assumes no responsibility whatsoever with regard to any infringements of third-party copyrights arising through your use of this unit.


- Disks containing important performance data for this instrument should always be locked (have their write protect tab slid to the PROTECT position) before you insert them into the drive of another instrument.
- The identification label should be firmly affixed to the disk. If the label comes loose while the disk is in the drive, it may be difficult to remove the disk.
- Put the disk back into its case for storage.

## Liability and copyright

- Should data contained and stored on a floppy disk be lost, it is unfortunately impossible to restore them. Roland Europe S.p.a. assumes no liability concerning such loss of data.
- Unauthorized recording, distribution, sale, lending, public performance, broadcasting, or the like in whole or in part, of a work (musical composition, video, broadcast, public performance, or the like) whose copyright is held by a third party is prohibited by law.

## 3. Panel descriptions

### Front panel



#### ① SCALE MEMORY buttons

These three buttons allow you to save and recall the tuning settings carried out with the ORIENTAL SCALE buttons. When the EXR-40 OR is shipped, these memories already contain useful settings (that will be recalled whenever you initialize your EXR-40 OR).


**Note:** The settings of the ORIENTAL SCALE buttons are also saved to a User Program, so that you can use these three memories for more "general" settings.

#### ② ORIENTAL SCALE buttons

These buttons allow you to change the tuning of each note of the scale. By default, pressing one of these buttons will lower the corresponding notes in all octaves by a quarter tone (-50 cents). Other tunings can also be selected and saved to one of the three scale memories (see above) or a User Program.

#### ③ POWER ON button

Press this button to switch the EXR-40 OR on and off.



#### ④ BENDER/MODULATION lever

By performing left/right movements, you can bend your solo notes down (left) or up (right). Press this lever towards the rear of the instrument to add modulation (usually vibrato) to the notes you are playing.

#### ⑤ PHONES 1/2 sockets

This is where you can connect two pairs of optional headphones (Roland RH-25, RH-50 or RH-120). By doing so, you switch off the EXR-40 OR's speakers.

#### ⑥ VOLUME knob

Use this knob to set the global volume of your EXR-40 OR.

#### ⑦ BALANCE [ACCOMP] [KEYBOARD] buttons

Use the BALANCE buttons to change the volume of the corresponding section (accompaniment/song, or the parts you play on the keyboard).

#### ⑧ KEYBOARD TOUCH button

Press this button to switch the keyboard's velocity sensitivity on or off. When it is switched off, you can specify the fixed velocity value that should be used for all notes you play.

#### ⑨ METRONOME button

This button allows you switch the metronome on and off. Holding it for more than one second calls up a FUNCTION parameter you can set.

#### ⑩ MELODY INTELLIGENCE button

This button allows you to switch the Melody Intelligence function on/off. This function adds a harmony part to your melody playing. See p. 27. Holding it for more than one second calls up a FUNCTION parameter you can set for selecting the harmony type.

#### ⑪ USB button

This button allows you to select the function of the USB port should perform: (i) mass storage (archiving and retrieving settings to/from a computer) or (ii) USB/MIDI (whereby the USB port has the same function as the MIDI IN and MIDI OUT connectors). See pages 46 and 51 for details. Press it together with [ONE TOUCH] to select the EXR-40 OR's demo function (see p. 12).

**12 ONE TOUCH button**

Press this button to select the desired One Touch settings. One Touch memories contain a number of settings that complement the currently selected Music Style. There are two One Touch memories per Music Style. See p. 26.

**13 V-LINK button**

Press this button to take advantage of the EXR-40 OR's V-LINK functionality for controlling video material via certain performance functions and the right-most keys on the EXR-40 OR's keyboard. By using V-LINK-compatible video equipment, visual effects can be easily linked to, and made part of the expressive elements of a performance. By connecting the EXR-40 OR to an optional Edirol DV-7PR or V-4, you can switch images in synchronization with music, or use the EXR-40 OR's performance functions or right-most keys to switch clips, control playback speed, etc.

During song and Music Style playback, this button flashes to indicate the tempo and beats (BEAT function).

**14 KEYBOARD CONTROL section**

Press the **SPLIT** button to play different sounds with your left and right hands. Press the **DUAL** button to play two sounds simultaneously.

Use the **TRANPOSE** button to transpose the keyboard (see p. 32).

**15 BAND ORCHESTRATOR section**

Press one of these buttons to choose the desired orchestration for the selected Music Style. See page 17.

**16 ARRANGER & SONG -CONTROLS section**

**TAP TEMPO** button: Press this button at least twice to set the Arranger's or Recorder's playback tempo.

**SYNC START/STOP** button: This button performs two functions: In Arranger mode (while using the automatic accompaniment), it allows you to switch the SYNC START and SYNC STOP function on and off.

In Song mode, it can be used to specify the beginning ("A") and end ("B") of the passage that should be repeated.

The remaining buttons in this section allow you to control Arranger or Recorder playback. See pages 15 and 19.

**17 LOCK section**

The buttons in this section allow you to filter (ignore) certain settings that are usually recalled when you select a User Program. This allows for a more flexible use of your registrations. See page 45.

When the Minus One function is on, these buttons allow you to quickly mute several Standard MIDI File parts (these mute functions are not available while you are using the Arranger function).

**18 KEYBOARD MODE section**

These two buttons allow you to quickly configure the EXR-40 OR for use with **(ARRANGER BAND)** or without **(PIANO/SOLO)** automatic accompaniment. At power-on, the EXR-40 OR selects the PIANO SOLO mode.

Press them simultaneously to activate the PIANO MODE, which allows you to use the EXR-40 OR's Arranger (automatic accompaniment) without splitting the keyboard (see p. 27).

**19 MUSIC ASSISTANT button**

This button allows you to work with pre-programmed registrations (additional User Programs). See p. 26.

**20 SONG button**

This button allows you to select the EXR-40 OR's Song mode and to specify that the **INTRO**, **ORIGINAL**, etc., buttons should be used to operate the on-board Recorder.

**21 STYLE button**

Press this button if you want to select Music Styles. By activating this button, you also specify that the **INTRO**, **ORIGINAL**, etc., buttons are used for selecting a Style Division, while the numeric buttons can be used to select the desired Style memory.

**22 TONE button**

Press this button if you want to use the **FAMILY** and numeric buttons for assigning a sound ("Tone") or Drum Set to the Main, Split or Dual part. See p. 30.

**23 DATA ENTRY buttons**

**FAMILY** and **SELECT** buttons: The **FAMILY** and **SELECT** buttons are used to select Tones, Styles, Music Assistant memories, Songs, and Function parameters. The **FAMILY** buttons allow you to select a group. You can press them, hold them, or press one while holding the other to change the scrolling speed.

The **SELECT** buttons allow you to choose items within the selected group or family. You can press them, hold them, or press one while holding the other to change the scrolling speed. After selecting the last item of the currently selected group, pressing again takes you to the first entry of the following group. Conversely, pressing again after selecting the first entry of a group takes you to the last entry of the preceding group.

**Numeric key pad:** These buttons allow you to enter numbers (for Tone, Style, Music Assistant memory, song, track selection), values and characters (for entering names).

The **TEMPO/DATA** buttons allow you to set the arranger or Song tempo and the value of the selected **FUNCTION** parameter.

**24 FUNCTION button**

This button provides access to the **FUNCTION** menu. You can use the **FAMILY** and **SELECT** buttons to select the desired function.

**25 DISK button**

Press this button to access the Disk functions. They are used for loading data from floppy, saving data to disk, and managing floppy disks. See p. 52.

**Note:** You can also save and load data via USB.

**26 USER PROGRAM/WRITE button**

Press this button whenever you want to select a User Program (a set of registrations). Press and hold it to save the current panel and parameter settings to a User Program. See page 44.


**27 USER TONES section**

These buttons allow you to select the "best" sound of the indicated family (i.e. the "best" piano, organ, guitar/bass, etc. sound). After pressing one of these buttons, you can use **FAMILY** and **SELECT** buttons to select other families and other Tones within the active family. (At a later stage, these can be recalled by "double-clicking" these buttons.) You can also assign your favorite sounds to these buttons. See "Using the USER TONES buttons" (p. 30) for details.

**28 Disk drive, in the middle below the keyboard (not pictured)**

This is where you insert floppy disks with Standard MIDI Files or Music Styles you may already own. The drive accepts 2DD (720k) and 2HD (1.44MB) floppy disks.

## Rear panel



### ① OUTPUT R, L/MONO sockets

These sockets allow you to connect the EXR-40 OR to your HiFi amplifier, a mixer, a cassette deck, a keyboard amplifier, etc. If the external amplifier is mono, be sure to connect it to the OUTPUT L/MONO socket.

### ② DC IN socket

This is where you need to connect the supplied adapter (PSB-4U).

**Note:** Be sure to only use the adapter supplied with your EXR-40 OR. Other adapters may damage your Interactive Arranger.

### ③ Cord hook

After connecting the adapter cable, wind it around the cord hook to the socket's right to prevent accidental power failures.

### ④ FOOTSWITCH socket

This is where you can connect an optional DP-2, DP-6, or BOSS FS-5U footswitch that allows you to hold ("sustain") the notes you play with your right hand. It can also be used for controlling other parameters (see "FSW° (Footswitch Assign)" (p. 40)).

### ⑤ MIDI OUT/IN sockets

Connect the MIDI OUT socket to the MIDI IN jack of your computer (or MIDI instrument) to transfer MIDI data from the EXR-40 OR to the computer or external MIDI instrument. Connect the MIDI IN socket of the EXR-40 OR to the computer's MIDI OUT jack to receive data from the computer.

**Note:** The EXR-40 OR can also transmit/receive MIDI data via its USB port. To do so, you need to install the appropriate USB drivers from the supplied CD-ROM.

### ⑥ USB port


The USB port can be used for transmitting/receiving MIDI messages or for archiving purposes with a computer.

## 4. First steps


### Setting up

The first thing you need to do is connect the supplied PSB-4U adapter to a suitable wall outlet.

- (1) Unpack the EXR-40 OR and place it on a stable surface.
- (2) Connect the small end of the adapter cable to the EXR-40 OR's DC IN jack, and the other end to a suitable wall outlet.
- (3) Press the **POWER ON** button to switch on the EXR-40 OR.



- (4) Use the **VOLUME** knob to set the EXR-40 OR's output volume.




**Note:** When the EXR-40 OR is used at excessive volumes, the protection system of its power amplifier stage may come on and mute the speakers. In that case, reduce the volume setting and wait a few seconds.

- (5) Press **POWER ON** again to switch the EXR-40 OR back off again.  
If you wish to connect the EXR-40 OR to a keyboard or HiFi amplifier, do so before performing step (3) and switch on the amp before performing step (4).

### Demo songs

Your EXR-40 OR comes with 1 song demo, 8 Tone demos, and various Style demos.

- The **song demo** illustrates the possibilities of the EXR-40 OR as a whole.
  - **Tone demos** show off the EXR-40 OR's amazing sound quality.
  - **Style demos** give you an impression of the quality of the on-board Music Styles.
- (1) Hold down the **USB** button while pressing **ONE TOUCH**.




DemoSong 1, 120 001

- (2) If necessary, use the **VOLUME** knob to change the playback volume.
- (3) Press **START/STOP** to stop playback.

### Playing back a Tone demo song

- (1) Press the **TONE** button.




Playback of the Tone demo song starts automatically.

You can now press **START/STOP** to stop playback of the currently selected Tone song. If you press this button again, the next Tone demo song will be played back.

- (2) Press **START/STOP** to stop Tone demo song playback.

### Playback of a Style demo song

- (1) Press the **STYLE** button.



DemStyle 1, 146

Playback of the Style demo song starts automatically. You can now press **START/STOP** to stop playback of the currently selected Style demo song. If you press this button again, the next Style demo song will be played back.

- (2) Press **START/STOP** to stop Style demo song playback.

### Leaving the Demo mode

- (1) Hold down the **USB** button while pressing **ONE TOUCH** to leave the Demo mode.

## Playing without accompaniment

When you switch on the EXR-40 OR, it selects the PIANO SOLO mode. This means that you can use the EXR-40 OR like a digital piano, or a synthesizer.


The accompaniment function (called "Arranger") and **ONE TOUCH** button are not available in PIANO SOLO mode, while only the Main part is active.

The EXR-40 OR provides three parts for your live playing (and many more for Arranger backing and Song playback):

Main	As its name suggests, this is the most important part. As long as the Split part is off, the Main part is assigned to the entire keyboard.
Split	When you switch on this part, it is assigned to the left half of the keyboard, while the Main part can be played with your right hand.
Dual	This part can be added to the Main part and is also assigned to the entire keyboard. This allows you to play two sounds simultaneously.

### Using the Main part


- (1) To activate the Main part and assign it to the entire keyboard, press the **PIANO SOLO** button.




The **ARRANGER** icon disappears, the Arranger stops (if it was playing), and the EXR-40 OR automatically selects a piano sound for you.

- (2) Play a few notes on the keyboard.

- (3) If necessary, select another sound by pressing one of the 8 USER TONES buttons. See p. 30 for details.



- (4) If necessary, you can hold down the **TONE** button and use **BALANCE ACCOMP** (softer) or **KEYBOARD** (louder) to change the Main part's volume.




**Note:** Unlike previous Roland arranger instruments, the EXR-40 OR no longer distinguishes between "melodic" parts and a Manual Drums part. You can therefore also play a Drum Set with the Main part.

**Note:** You can also press the **START/STOP** button to add a rhythm accompaniment to your playing. This is based on the currently selected Music Style. See p. 16 for how to select a different one.

**Note:** See p. 15 and "Automatic playback start (Sync Start & Stop)" (p. 16) for other ways to start Music Style playback (the drums, that is).


### Using the Main and Split parts

- (1) If you wish to play different sounds with your left and right hands, press the **SPLIT** button.




The **SPLIT** icon appears and the EXR-40 OR now automatically selects a sound for the Split part that complements the sound assigned to the Main part.

- (2) Play a few notes on the keyboard. At first, the keyboard is split at the G3 (note number "55"). If necessary, you can select a different split point. See "KeySplit\* (Split point)" (p. 40).



To change the balance between the Main and Split sounds, proceed as follows:

- (3) Hold down the **SPLIT** button and use **BALANCE ACCOMP** (decrease) or **KEYBOARD** (increase) to change the Split part's volume.



- (4) To assign another sound to the Split part, hold down the **SPLIT** button and proceed like for the Main part (page 13).


Alternatively, press and hold one of the eight USER TONES buttons (Main part) while pressing another USER TONES button (Split part).

**Note:** You cannot assign Drum Sets to the Split part.

**Note:** You can also add a monophonic bass part ("Auto Bass") to the Split part. See "Auto Bass\*: status and volume" (p. 41).

### Using the Main and Dual parts

- (1) To play two sounds simultaneously, press the **[DUAL]** button.



The **[DUAL]** icon appears and the EXR-40 OR now automatically selects a sound for the Dual part that complements the sound assigned to the Main part.

You can also activate the Dual mode by holding down one of the eight USER TONES buttons while pressing another. The first USER TONES button's sound is then assigned to the Main part, while the second sound is assigned to the Dual part.


- (2) Play a few notes on the keyboard.  
To change the balance between the Main and Dual sounds, proceed as follows:
- (3) Hold down the **[DUAL]** button and use **BALANCE [ACCOMP]** (decrease) or **[KEYBOARD]** (increase) to change the Dual part's volume.
- (4) To assign another sound to the Dual part, hold down the **[DUAL]** button and proceed like for the Main part (page 13).

**Note:** You cannot assign Drum Sets to the Dual part.

### Using the metronome

You can switch on the metronome when practising a new song.

- (1) Press the **[METRONOME]** button.



The **[M]** icon appears in the display and you hear the metronome sound.

- (2) Press and hold **[METRONOME]** to select the **Metro TS** function.
- (3) Use the **[ ] [ ]** buttons to set another time signature. The possibilities are: 1/4~9/4, 1/8~9/8.
- (4) Press another "big" button in the DATA ENTRY section to leave this function.
- (5) Press the **[METRONOME]** button again to switch the metronome off.




## 5. Playing with accompaniment (Arranger)

Let us now take advantage of the EXR-40 OR's accompaniment function. This function is called "Arranger".


### Starting/using the Arranger

- (1) Press the **ARRANGER BAND** button.



The **ARRANGER** icon appears in the display and the keyboard is split into two halves. The keys you press in the left half are used to specify the key of the accompaniment. The **right half** of the keyboard allows you to play a **tune** to the accompaniment.

- (2) Press the **START/STOP** button to start Arranger playback.




The **V-LINK** button now flashes to indicate the tempo and beats (BEAT function).

**Note:** If the **ARRANGER** icon is displayed, playing in the left half of the keyboard while the Arranger is stopped, will sound a stereo string sound (to which you can add a monophonic bass sound, see "Auto Bass\*: status and volume" (p. 41)). The left half of the keyboard is thus not muted (like on previous Roland arranger instruments). This "EP Chord" function can be switched off, however (page 42).


- (3) Play a chord (or just one note) with your left hand.



- (4) Play another chord (or note) to change the Arranger's key.  
 (5) To quickly return to the beginning of the accompaniment pattern (RE-START function), press the **REC** button while the accompaniment is running.




- (6) Press the following buttons to use other patterns of the currently selected Music Style:



Button	Function
INTRO	Selects an introduction. Press this button before activating <b>START/STOP</b> .
ORIGINAL	Simple accompaniment version.
FILL	Transition ("Fill In") to VARIATION or ORIGINAL.
VARIATION	Slightly more complex accompaniment version.
ENDING	Phrase that indicates the end of the song. Use this button instead of <b>START/STOP</b> to stop playback.


These buttons select Music Style "patterns". The icon corresponding to the button you press appears in the display. Also, the ARRANGER chord field in the display indicates the name of the chord you played last. This chord is used by the accompaniment.



As soon as you feel comfortable with the Arranger, you should try to play a melody with your right hand while using your left for specifying Arranger chords.

## Changing the tempo

- (7) Use the TEMPO/DATA buttons to decrease ([-]) or increase ([+]) the tempo (if necessary).




To return to the Music Style's default tempo, simultaneously press [-] and [+].

You can also press the [TAP TEMPO] button several times at the desired tempo.



## Automatic playback start (Sync Start & Stop)

Press [SYNC START/STOP] (the [SYNC START] icon appears). "Sync Start" means that the Arranger starts playing back the selected Music Style as you play a note or a chord with your left hand (to the left of the split point).



In PIANIST mode, Arranger playback will start when you press any note.

The EXR-40 OR also provides a SYNC STOP option: quickly press [SYNC START/STOP] twice ("double-click") so that the [SYNC START] icon starts to flash. This will cause the Arranger to

stop as soon as you release all keys in the chord recognition area. This is great for songs where you need breaks (i.e. one or several beats of silence).

**Note:** The behavior of the SYNC STOP function can be changed (see p. 42) by pressing and holding the [SYNC START/STOP] button.

## Stopping Arranger playback

- (8) Press [START/STOP] again to stop playback. You can also press [ENDING]. In that case, you first hear an ending phrase. When it is finished, Arranger playback stops automatically. Alternatively, you can press the [SYNC START/STOP] button twice in succession to activate the SYNC STOP function. If you then release all keys in the left half of the keyboard, playback stops at the same time.

## Selecting Music Styles

The EXR-40 OR provides three memory areas for Music Styles: **USER STL:** (Memory 000) This is where a Music Style loaded from the Flash memory or floppy disk (MSA, MSD and MSE series, optional) is temporarily stored. The data in this RAM memory are erased when you switch off the EXR-40 OR.

**LAIKA** (001~028), **PARADISI** (029~054), **ARABIKA** (055~075), **WESTERN** (076~099): These are the Style families in the EXR-40 OR's internal ROM memory. These Styles cannot be erased (but you can modify them in realtime using the Band Orchestrator function, see page 17).

**FLASH:** (Memories 101~199) This is a Flash area inside the EXR-40 OR that already contains 81 Styles when the EXR-40 OR is shipped. You can expand the number of Styles in this area by copying more Styles from your computer (via USB) or by saving the Styles loaded from disk. There are 99 Flash memory slots in all, but the actual number of Styles you can save there depends on the data size of the Styles.


**DISK:** (Memories 201~...) This area refers to a floppy disk you inserted into the EXR-40 OR's drive. The number of available Styles depends on the floppy disk, of course. The Style you select is transferred to the EXR-40 OR's USER STL memory (see above), which is why it takes a little longer before you can use it. (You could, however, save it to a Flash memory, see p. 48.)

- (1) Press the [ARRANGER BAND] button. Check whether the [ARRANGER] and a [INTRO] [ORIGINAL] [FILL] [VARIATION] [ENDING] icon are displayed.
- (2) Press the [STYLE] button.



- (3) If you want to use a style on floppy disk, insert the disk into the drive.

- (4) Use FAMILY  $\leftarrow$   $\rightarrow$  to select the memory area that contains the desired Music Style (see above).




The FAMILY buttons allow you to jump to the desired "family" (which also include the Flash and USER STL areas).

The display now shows the name of the selected family.

MALFOUF TEMPO  $\text{♩} = 73$

FLASH TEMPO  $\text{♩} = 132$

- (5) Use SELECT  $\leftarrow$   $\rightarrow$  to specify the desired Style within the selected group.



The first press of SELECT  $\rightarrow$  (or  $\leftarrow$ ) shows the name of the first Music Style within the selected group. It is already selected, so if you need the first Style, there is actually no need to press SELECT  $\rightarrow$ . You must use SELECT  $\leftarrow$  or  $\rightarrow$ , however, to select another Style within the same group. You can also use the numeric buttons to select Styles. See also "Working with the FAMILY, SELECT and numeric buttons" (p. 20).

After selecting memory 101 (Flash) or 201 (first disk memory), the display shows a flashing YES message.

**Note:** If you forgot to insert a floppy disk into the drive, the display shows "No Disk" when you attempt to select the "disk family".

- (6) If necessary, confirm your selection by pressing the  $\boxed{+/\text{YES}}$  button.

The display briefly shows "LOADING" (only after selecting a Style from the inserted floppy disk).

If you selected a Music Style on floppy disk, the **DISK** icon now flashes, and the EXR-40 OR automatically selects the USER STL memory that now contains the Music Style you loaded from floppy disk.


If you press  $\boxed{+/\text{YES}}$  during Arranger playback, the new Style is used at the next downbeat (1st beat of the next measure). Otherwise, the EXR-40 OR displays its name and uses that Style when you press  $\boxed{\text{START/STOP}}$ .

**Note:** See page 49 for how to save the Music Style in the USER STL memory to the Flash memory.

## Using the Band Orchestrator function

The Band Orchestrator function allows you to vary the accompaniment patterns played by the Arranger. You can leave out parts, thin out the drum part, etc. - in real-time (i.e. while you are playing).


- Press the  $\boxed{\text{ARRANGER BAND}}$  button to select the Arranger mode.
- Select the Music Style you wish to use for playing (or use the one that is currently selected).  
See page 16.
- Press one of the following buttons to select the desired level of musical "complexity" (the corresponding icon is displayed):



Obviously, these buttons should be used during Arranger playback.

<b>DRUM &amp; BASS</b>	The simplest accompaniment that only contains the drum and bass lines.
<b>COMBO</b>	Accompaniment pattern with only a few instruments (i.e. a band).
<b>FULL BAND</b>	Accompaniment pattern with a lush arrangement (several melodic instrument lines).

The corresponding icon appears in the display (only one of them can be displayed at any one time).



**Note:** Immediately after switching on the EXR-40 OR, the Orchestrator selects the "FULL BAND" level.


**Note:** The effect of these three levels also depends on whether the [VARIATION] or [ORIGINAL] button was pressed. In effect, the combination of the [ORIGINAL]/[VARIATION] and [DRUM & BASS]/[COMBO]/[FULL BAND] buttons provides 6 accompaniment patterns per Music Style (3 x 2).

The last selection you make can be saved to a User Program. See p. 44.

## Balance

The BALANCE [◀▶] buttons allow you to change the volume balance between the Arranger (or Song) parts and the Keyboard parts (the ones you can play yourself).

- (1) Press BALANCE [ACCOMP] if the Arranger (or Song parts) are too soft.




A 10 Balance <sup>TEMPO</sup> ♩ 80

- (2) Press BALANCE [KEYBOARD] if you think your solo playing should be louder.  
By holding down [SPLIT] (or [DUAL]) while pressing these buttons, you can modify the volume of those Keyboard parts.

**Note:** See p. 41 for setting the volume of individual parts.


## 6. Playing back songs

The EXR-40 OR allows you to play back commercially available music data files (called Standard MIDI Files) or your own songs you saved to disk or to the EXR-40 OR's Flash memory. Your own songs are saved as Standard MIDI Format 0 files and can also be played back using any other SMF compatible sequencer (or software).



### Basic song playback


- (1) Press the **SONG** button (it lights) to switch to Song mode.



This is necessary because, otherwise, pressing the **START/STOP** button will start Arranger playback. So be sure to check whether the **SONG** button lights and whether the **ARRANGER** and **INTRO ORIGINAL FILL VARIATION ENDING** icons are no longer displayed. Only then will the **ARRANGER & SONG CONTROLS** buttons allow you to control song playback (see above).


- (2) If you want to play back a song from floppy disk, insert the disk into the drive (front right).

- (3) Use **FAMILY** to select the memory area that contains the song you wish to play back.



The EXR-40 OR provides three memory areas for songs:  
**USER:SONG:** (Memory 000) This where the song data you record are temporarily stored. The data in this RAM memory are erased when you switch off the EXR-40 OR.  
**FLASH:** (Memories 101~199) This is the Flash area inside the EXR-40 OR that already contains several songs when the EXR-40 OR is shipped. You can expand the number of songs in this area by copying more songs from your computer (via USB). There are 99 Flash memory slots in all, but the actual number of songs you can save there depends on the data size of the songs.  
**DISK:** (Memories 201~...) This area refers to a floppy disk you insert into the EXR-40 OR's drive. The number of available songs depends on the floppy disk, of course.

- (4) Use **SELECT** or the numeric buttons to specify the desired song within the selected group.



This is only necessary for the Flash memory or a floppy disk (there is only one **USER:SONG** memory).

The first press of **SELECT** (or ) shows the name of the first song within the selected group. It is already selected, so if you need the first song, there is actually no need to press **SELECT** . You must use **SELECT** or , however, to select another song within the same group. After selecting memory 101 (the first Flash memory), the display looks as follows.

101 SongName TEMPO

You can also use numeric buttons to select songs.

### Working with the FAMILY, SELECT and numeric buttons

You can press FAMILY or either repeatedly (brief presses) to go back or advance, or hold down or to quickly select another family. The fastest way to scroll through the available families is by holding down while pressing (go backwards), or by holding down while pressing (advance). The same methods are available for the SELECT buttons. As a reminder: the FAMILY buttons are used for selecting groups, while the SELECT buttons allow you to select items within a group.

If you prefer to use the **numeric buttons**, enter three figures (e.g. "001" for entry "1"). If you only enter two figures (or only one), the EXR-40 OR takes slightly longer to accept your entry.


**Note:** If the number you enter lies beyond the last available entry, the EXR-40 OR does not change.

**Note:** Enter "000" (or "0") to select the USER:SONG memory.

After selecting memory 101 (Flash) or 201 (first disk memory), the display shows a flashing YES message. You can ignore this if you like, and proceed with the next step (or you can press and then proceed).

**Note:** If you forgot to insert a floppy disk into the drive, the display shows "No Disk" when you attempt to select a file on disk.

- After making sure that the correct song has been selected, you can press (now called ) to load it and immediately start playback.



The button now flashes to indicate the tempo and beats (BEAT function).

You can already select a new song while the current one is still playing back. If you want to listen to it before the current song is finished, stop playback by pressing

, then press that button again. Otherwise, wait until the current song is finished, then press the button to start playback of the new song.

**Note:** Please bear in mind that starting playback of the selected song on disk will erase the song in the USER:SONG memory. Be sure to save it to disk before proceeding (see p. 53).

- You can change the song tempo with the buttons or .

Doing so, however, means that the tempo will still change if the song you are playing back contains tempo change messages. Furthermore, every time you jump back to the beginning or another position of the song using , , or , the programmed song tempo is reset.

**Note:** In Song mode, the EXR-40 OR automatically selects the PIANO SOLO keyboard mode. If you like, you can play along with the song (and even use the Split or Dual part).

**Note:** In certain cases, the display may show the message XG Light or GM2 rather than a Tone name. Such a message means that the EXR-40 OR is using a Tone that cannot be selected via the front panel. There are 798 such "hidden" Tones whose sole purpose is to ensure XG/GM2 playback compatibility.


## Additional playback functions

The , , etc. buttons have two functions: one in Style mode (printed above the buttons), and another one in Song mode (printed below the buttons).


### Selecting Song mode

The ARRANGER & SONG CONTROLS buttons have two functions: they can be used for selecting Music Style patterns (when the icon is displayed), or for Song navigation (when the button lights).

To select the Song mode (and the SONG CONTROL functions), you need to press the button. Only then will the following functions be available.



### Fast Forward, Rewind, and Reset



- To **fast forward** (jump to a measure later in the song), press .
- To **rewind** (return to a measure that lies before the current position), press . The measure indication in the upper right corner of the display will help you locate the measure you need.
- Press (Reset) to jump back to the **first measure** of the song. You need to stop playback before using the .


**Note:** In certain cases, and may not be available. This is only the case for very large songs, however.

**Note:** By pressing , or , you also recall the song's pre-programmed tempo value.


### Loop playback (Repeat)

Another clever feature of the EXR-40 OR's Recorder is that you can program playback loops. You can do so during playback or while the Recorder is stopped.

- (1) Press **MARKER A-B** where you want the loop to begin (the **MARKER A-B** icon appears in the bottom right corner of the display).



- (2) Fast forward to the measure where you want the loop to end and press **MARKER A-B** again (the **MARKER A-B** icon appears). You can also program loops on the fly. Remember, however, that the Recorder always memorizes the beginning (down-beat) of the next measure.
- (3) If the icon isn't already displayed, press the **REPEAT A-B** button to activate the loop you have just programmed.



This button allows you to switch the EXR-40 OR's Repeat function on and off.

- (4) To play back the loop, press the **START/STOP** button (now called ).

The Recorder jumps to measure "A" and starts playing. At the end of measure "B", the Recorder immediately jumps back to the beginning of measure "A" and continues playing back the passage.

If necessary, repeat steps (1) and (2) to set other marker positions.


**Note:** The playback tempo is reset every time the Recorder reaches the "A" measure.

**Note:** In certain cases, the Marker function may not be available. This only happens with very large songs, however.

### Live performance with song backing (Minus One)

Your EXR-40 OR allows you to mute parts you wish to play yourself or don't need in a given situation. This is called "Minus One" playback.


- (1) Press the **SONG** button if it doesn't light. You can now select a Song, if you like (see p. 19).
- (2) Press the **MINUS ONE** button (the "Minus One" message appears in the display).



The 5 LOCK buttons light to indicate that all tracks will be played back.

- (3) Press one of the LOCK buttons to switch off the corresponding track(s). The assigned track icon flashes.

(Example: if you switch off the **DRUMS** button, the **DRUMS** icon starts flashing.)



When a button lights, the corresponding track(s) is/are audible (i.e. not muted). You can also mute several tracks by switching off the corresponding LOCK buttons.

The **MINUS ONE** icon appears and the selected part is muted.

**Note:** The Main part does not automatically adopt the Tone and related settings of the melody part.

If you like, you can also mute several parts.

**What are tracks?**  
 The term "track" is used only for your convenience. We borrowed it from tape recorders that allow for recording several musical parts by the same person (one part after the other).  
 In the case of the EXR-40 OR, the term is only used to indicate that we are dealing with separate musical parts. Here indeed (like with computer-based sequencers) what really counts are the MIDI channels.

Songs you record with the EXR-40 OR, and the Standard MIDI Files you play back can consist of up to 16 tracks (i.e. MIDI channels). In many instances, only certain tracks are used, but the following are almost certainly present in every Standard MIDI File:

- Track 2: bass
- Track 4: melody
- Track 10: drums

The LOCK buttons allow you to mute the following tracks:  
**RIGHT**—Refers to track "4" of the selected Standard MIDI File. Music data for educational purposes (especially piano music) use this track for the right-hand part. Mute this track

to play the right hand yourself while listening to the left-hand part of the Standard MIDI File. The EXR-40 OR contains an excellent stereo piano Tone you could use.

**LEFT**—Refers to track "3" of the selected Standard MIDI File. Music data for educational purposes (especially piano music) use this track for the left-hand part. See also above.

**OTHERS**—Mutes all tracks that cannot be muted with the remaining LOCK buttons, more specifically: 1, 3, 6~9, 12~16.

**BASS**—Mutes track "2", which is assigned to the bass part of a Standard MIDI File.

**DRUMS**—Mutes track "10", which is assigned to the drum part of a Standard MIDI File.

**Note:** You also switch off several buttons simultaneously.

- (4) Press **◀** and **▶** to start playback.
- (5) Press **▶/■** again to stop playback.
- (6) Press **MINUS ONE** again (or one of the "big" DATA ENTRY buttons) to switch the function of the same name back off again.

**Note:** The Minus One setting can be saved along with the selected song. See page 48.

### Changing the track assignments

If the song files you are using do not conform to the GM system (and therefore do not correspond to the RIGHT, LEFT, BASS or DRUM assignments of the Minus One function), you can proceed as follows to assign other tracks (MIDI channels) to the LOCK **RIGHT**, **LEFT**, **BASS** and **DRUMS** buttons:

- (1) Press the **MINUS ONE** button to activate the function of the same name.
- (2) Press and hold the **RIGHT**, **LEFT**, **BASS** or **DRUM** button.
- (3) While holding that button, use the **[-]**/**[+]** buttons to assign the desired MIDI channel to the button you are holding. Example: To assign MIDI channel "10" to the **RIGHT** button, press DATA ENTRY **[+]** until the display looks as follows:

VALUE  
10 RIGHT

- (4) Press **MINUS ONE** again (or one of the "big" DATA ENTRY buttons) to switch the function of the same name back off again.

**Note:** The Minus One setting can be saved along with the selected song. See page 48.




## 7. Recording your music

Your EXR-40 OR contains a 16-track Recorder you can use for recording your own songs.

### Basic song recording


Let us first look at the most straight-forward way of recording your renditions with Arranger backing.

- Press the **ARRANGER BAND** button.




The **ARRANGER** icon appears. You can now use your left hand for transposing the Arranger's key in realtime.

- Press the **STYLE** button and select a Music Style (or select a Music Assistant memory).
- Select the desired Arranger division by pressing **INTRO**, **ORIGINAL** or **VARIATION**.
- Press the **START/STOP** button.
- Use **TAP TEMPO** or the **[ ] +** buttons to set desired tempo.
- Press **START/STOP** again to stop Arranger playback.
- Assign the desired Tone to the right half of the keyboard. Press **TONE** and use the FAMILY & SELECT **[ ] [ ]** buttons, the numeric buttons or the buttons in the USER TONES section. See also page 30.
- Press the **REC** button.



The display should look as shown above (if it doesn't, use the FAMILY **[ ] [ ]** buttons ("REC MODE") to select REC ALL): (The **RECORD** and **1~16** icons flash.) You are now in ALL mode, which means that everything you and the EXR-40 OR's Arranger play will be recorded.




**Note:** If you select "REC ALL" with the FAMILY buttons, the song in the EXR-40 OR's USER:SONG memory is erased. You may want to save the current song first (see p. 48). If you only pressed **REC**, the EXR-40 OR selects the Single mode if the USER:SONG memory already contains data. See page 24 for details about that mode.

- Start recording in one of the following ways:
  - Press the **START/STOP** button to start Arranger playback with the selected Division. The **V-LINK** button now flashes to indicate the tempo and beats (BEAT function).
 


**Note:** If you start recording without the Arranger and want to bring it in at a later stage, it would be a good idea to switch on the metronome by pressing the **METRONOME** button.
  - Activate the **SYNC START** function and press one or several keys to the left of the Split point.
 

**Note:** It is also possible to record in PIANO SOLO mode (after pressing the button of the same name). In that case, you should definitely use the metronome. The song's time signature can be set with the **METROTS** function. See page 14.
- Stop recording in one of the following ways:

- Press **START/STOP**.



- Press the **ENDING** button to start the Ending phrase. As soon as it ends, Arranger playback and song recording stop.



### Listening to your song

- Press the **SONG** button.
- Press **START/STOP** to start playback.
- Press **START/STOP** once again to stop playback.
- Press **[ ]** to return to the beginning of the song.

## Other recording functions

The EXR-40 OR's 16-track Recorder can be used in several ways. Let us therefore have a look at the other recording modes.

### About the recording modes

#### ● Modes

The EXR-40 OR provides two modes for recording new music, and two for adding parts or correcting passages of existing music:

#### Recording a new song

**ALL** In this mode, you can record everything you and the EXR-40 OR can play simultaneously:

- Arranger (accompaniment).
- Keyboard parts (Main and Split or Dual).

**Keyboard** In this mode, you can record using the Keyboard parts. The track can be freely selected.

- Main and Split or Dual

#### Adding parts to an existing song

**Single** In this mode you can record onto one track at a time. The track can be freely selected.

**Punch I/O** This mode allows you to re-record a short section of an otherwise perfect part.

**Note:** Each time you select ALL or Keyboard mode, the data in the USER:SONG memory are erased.

#### ● Recorder memory

The EXR-40 OR provides one "live" song memory, which can contain one song at a time. After completing a song, you should save it (see p. 53).

To keep you from accidentally erasing the song in the EXR-40 OR's internal memory, the EXR-40 OR automatically selects **Single** after your first recording. Bear in mind that **selecting "ALL" or "Keyboard" will erase the song in the USER:SONG memory.** Do not select "ALL" or "Keyboard" for adding parts to an existing song – use "Single" or "Punch I/O" instead.


Conversely, you cannot select "Single" or "Punch I/O" if the USER:SONG memory doesn't yet contain data.

And finally: playing back a Standard MIDI File erases the song in the EXR-40 OR's memory. In return, the SMF data will be available (and can be supplemented with your own renditions in "Single" or "Punch I/O" mode).

### More about ALL mode

In addition to what you learned on p. 23, here are a few considerations:

After pressing the **REC** button, the 16 track and **RECORD** icons start flashing, signalling that all 16 tracks are available for recording.



Here is what the tracks correspond to (after recording a song with Arranger backing):

- |                  |                                |
|------------------|--------------------------------|
| 1) Accomp 1      | 9) Accomp 6                    |
| 2) Arranger bass | 10) Arranger drums             |
| 3) Accomp 2      | 11) → Split*                   |
| 4) → Main        | 12) → Auto Bass* (see p. 41)   |
| 5) Accomp 3      | 13)                            |
| 6) → Dual*       | 14)                            |
| 7) Accomp 4      | 15) Melody Intell. (see p. 27) |
| 8) Accomp 5      | 16) (→ Main**)                 |

(\*) Only one of these can be used alongside the Main part.

(\*\*) If you assign a Drum Set to the Main part. In that case, track 4 is not used.

For your convenience, the Keyboard parts are flagged with a "→" symbol in the above graphic.

Parts you do not hear during recording are not recorded. The track icons 1~16 thus do not show you what *will* be recorded, but rather what *can* be recorded.


### Keyboard recording mode

In Keyboard mode, you can record the Keyboard parts. The Arranger is not available. Essentially, this mode allows you to record either one layered part using up to two sounds (Main +

Dual) or two parts (Split to the left, Main to the right). If you select a Drum Set for the Main part, you can only record a drum part.

**Note:** When you select the Keyboard mode, song data in the EXR-40 OR's internal memory will be overwritten by your new recording.

- (1) Press the **REC** button.
- (2) Press FAMILY **◀▶** to make the display look as follows:



The **RECORD** icon and track icons flash.

- (3) To create a split, press the **SPLIT** button.
- (4) Activate the metronome (if necessary), and set the desired tempo with the **TAP TEMPO** button or **[-] [+]**.

You can also record without metronome if you like.

**Note:** If you assign a Drum Set to the Main part, your drum performance is recorded onto track 16.

### Single recording mode

This mode is only available if the EXR-40 OR's song memory already contains data. When you press **REC**, the **RECORD** icon and the icon of the first empty track flash. You could therefore record a new part straight away. (If all tracks already contain data, Track 1 will be selected.)

You can, however, also substitute an already recorded part with a new version.

- (1) Press the **REC** button.
- (2) Press FAMILY **◀▶** to select "Single".
- (3) Use the SELECT **◀▶** or numeric buttons to select the track you wish to record to.  
You can only select one track at a time (hence the name "Single"). If you select a track that already contains data, your new version will overwrite the existing one.
- (4) If necessary, assign the desired Tone to the part you are about to record (see p. 30).

If you select track **10**, you can select Drum Sets rather than Tones. Track 10 is reserved for drum parts.

**Note:** If you use the Single recording mode for adding parts to a Standard MIDI File recorded with another instrument or sequencer, track 16 (or any other track defined as "second drum track") may also use a Drum Set that can be changed.


**Note:** Even though the Main part can be used for recording all tracks in Single mode, the MFX only applies to track/MIDI channel 4.

- (5) Press **START/STOP** to start recording. After a two-measure count-in (see p. 41), you will hear all parts that have already been recorded. Start playing (and recording) your new part.
- (6) Press **START/STOP** to stop recording.
- (7) Return to step (3) to record additional parts.


### Punch I/O

In this mode, you can re-record part of a track (the second chorus, for example). The important aspect of this mode is that newly recorded material does not erase the material before or after the passage you redo.

Original track




This passage is redone




By contrast, in Single mode, the entire track you record is replaced by your new material. (So if you don't play anything during recording, the entire track will be empty afterwards.) Like the Single mode, Punch I/O can only be selected if the EXR-40 OR's memory already contains song data.

- (1) Press the **REC** button.
- (2) Press **FAMILY** to make the display look as follows:



The flashing track icon (only one) depends on the first track that already contains data. In the above example, track 1 contains data, which is why its icon flashes.

- (3) Use the **SELECT** or numeric buttons to select the track you wish to record to.




You can only select one track at a time.

- (4) Press **START/STOP** to start playback of the (old) song data. The **RECORD** icon and the icon of the selected track flash.
- (5) When the Recorder reaches the measure where you wish to start recording, press **REC** again. The **RECORD** icon now lights steadily.
- (6) Play the passage you want to redo.
- (7) Press **REC** again to deactivate recording. Song playback still continues, so...
- (8) Press **START/STOP** to stop playback.
- (9) Press **START/STOP** to listen to the new version. If you are not satisfied, return to step (3) above. Return to step (3) to correct another track.


### Using a footswitch for punching in/out

You can also use an optional footswitch for starting and stopping recording. Doing so has the advantage that you can use both hands for playing (or the left hand for Pitch Bend/Modulation effects and the right for playing the melody.)

- Connect an optional DP-2, DP-6, or BOSS FS-5U footswitch to the FOOTSWITCH socket on the EXR-40 OR's rear panel.
- Press the **FUNCTION** button (it must light).



- Use **FAMILY** to select "KB SET". The EXR-40 OR's Function parameters are divided into 9 logical "families". For the following, we need to select the group that contains the global keyboard settings.
- Use **SELECT** to select the "FSW" parameter.



**Note:** See also "Working with the FAMILY, SELECT and numeric buttons" (p. 20).

- Use the **+** buttons to select "Punch I/O".
- Press **SONG** to return to the recording function.
- Continue with step (1) under "Punch I/O". In steps (5) and (7), press the footswitch (rather than the **REC** button).

## 8. Additional Music Style functions

Apart from the basic Music Style functions covered on page 15 and following, your EXR-40 OR also provides the following functions. Most of the following functions are only available after pressing the **ARRANGER BAND** button (the **ARRANGER** icon must be displayed).


### One Touch

The One Touch function automates quite a few tasks:

- The Arranger selects the preset Style tempo.
- Suitable Reverb and Chorus settings.
- The EXR-40 OR selects sounds for the Main, Split and Dual parts that are suitable for the selected Style.

There are 2 One Touch memories per Style with different settings for the above parameters. Here is how to select one:

- (1) Select the desired Music Style (see p. 16).
- (2) Press the **ONE TOUCH** button.



The number field in the upper left corner reads "OT", followed by the number of the selected One Touch memory.



If the DATA ENTRY **TONE** button lights, the display now shows a Tone name ("Piano 2" in the example above).

- (3) Press the **ONE TOUCH** button again if you need "OT2". One Touch needs to be activated again every time you select a new Music Style.

**Note:** One Touch is also available for USB and disk Styles, but it is less meaningful.


### Using the Music Assistant

Another practical function for quickly making the right settings for a song you want to play is to take advantage of the EXR-40 OR's novel MUSIC ASSISTANT function. It prepares everything for working with the Arranger (Style, Tones, effects, etc.). The Music Assistant is not available for song playback.

The following parameters are changed automatically when you select a Music Assistant memory:


- Music Style
- Tempo
- Sounds for the Main, Split and Dual parts
- Effect settings
- Band Orchestrator
- Keyboard Touch

- (1) Press the **MUSIC ASSISTANT** button.



It lights and the display shows the name of the last Music Assistant setting you selected (or of the first Music Assistant memory).

- (2) Use **FAMILY** **◀▶** to select the "family" (i.e. genre) that contains the desired Music Assistant settings.



The following families are available: Arabic, Greek and World.

- (3) Use **SELECT** **◀▶** to specify the desired Music Assistant memory within the selected family. The first press of **SELECT** **▶** (or **◀**) shows the name of the first Music Assistant setting within the selected group. It is already selected, so if you need the first setting, there is actually no need to press **SELECT** **▶**. You must use **SELECT** **◀** or **▶**, however, to select another Music Assistant setting within the same group. You can also use the numeric buttons. See also "Working with the FAMILY, SELECT and numeric buttons" (p. 20).



**Note:** If necessary, you can now change the settings you do not like (e.g. select another sound for the Main part, etc.) and then save your new version to a User Program (see p. 44).

## Melody Intelligence

The Melody Intelligence function adds a second voice (harmony notes) to the melodies you play with your right hand. In fact, the Melody Intelligence function uses both halves of the keyboard to determine which notes to play:

- It looks at the melody notes in the right half; and...
- It analyzes the chords you play in the left half to see which notes it must add to your melody.

Press the **MELODY INTELLIGENCE** button so that the corresponding icon appears in the display.



## Changing the Melody Intelligence harmony type

The EXR-40 OR contains 18 different voicings (harmony types) for the MELODY INTELLIGENCE function. These voicings specify the number of harmony notes and the way in which they are added to your melody.

To select a different harmony type, press and hold the **MELODY INTELLIGENCE** button until the "MI" message appears in the upper left corner of the display. Then use the **◀▶** buttons to select the desired voicing. The available types are:

1 Duet	6 Block	11 Gospel	16 WltzOrg
2 Organ	7 BigBand	12 Romance	17 OctvTpe1
3 Combo	8 Country	13 Latin	18 OctvTpe2
4 Strings	9 Traditnl	14 CntrGuit	
5 Choir	10 Broadway	15 CntrBald	

Note: The **MELODY INTELLIGENCE** setting can be saved to a User Program memory.

## PIANIST Mode


In PIANO mode, the Main part is assigned to the entire keyboard. Though the EXR-40 OR initially assigns a piano sound to the Main part, you can select any other one and save your setting to a User Program.

The main difference between PIANO SOLO and PIANIST mode is that the Arranger's melodic parts are available here, which is not the case in PIANO SOLO mode.

But there is no split for chord recognition (you may remember that the EXR-40 OR's keyboard is split when you switch on the **ARRANGER BAND** button): the Arranger decodes every chord you play – no matter where you play it. Causing the Arranger to play another chord requires that you play at least a triad (i.e. the three notes that make up a chord). Feel free to play more than three chord notes but remember that two notes won't cause the Arranger to play another chord.

When you use an optional sustain pedal, all notes you play simultaneously are recognized as a chord – irrespective of whether you play them with your left or right hand.

- (1) Simultaneously press the **ARRANGER BAND** and **PIANO SOLO** buttons (both buttons light). The display briefly shows "PianoMod" and the **ARRANGER** icon flashes.




- (2) Press **STYLE** and use the **SELECT** **◀▶** buttons to select a Music Style. See also p. 16.
- (3) Press **STONE** and use **FAMILY** **◀▶** and **SELECT** **◀▶** (or the **USER TONES** buttons) to assign a different sound to the Main part.  
You can also add the DUAL part (page 14). Even the SPLIT part could be used, yet chord recognition remains active for the entire keyboard.
- (4) Press **ARRANGER BAND** or **PIANO SOLO** to leave PIANIST mode.

## Bass Inversion (Bass Inv)


Use this function to change the way in which the Arranger reads the chords you play.

When this function is off (default), the Acc Bass part plays the root of the chords that feed the Arranger. If you play a "C" (or C chord), the bass sounds a "C"; if you play an A minor chord (or if you press "A" and the "C" to its right), the bass sounds an A, etc. By activating Bass Inversion, you can specify the note played by the A. Bass part (the lowest note of your chords). Switch on Bass Inversion for songs that rely on bass rather than on chord patterns (for example C - C/B - C/B $\flat$ , etc.).

- (1) Press the **FUNCTION** button.





- (2) Use **FAMILY** to select "ARR. SET".



The EXR-40 OR's Function parameters are divided into 9 logical "families". As the Bass Inversion parameter is an Arranger function, you need to select the Arranger settings (hence ARR. SET).

- (3) Use **SELECT** to select the "Bass Inv" parameter.



- (4) Press the **+** button to select "ON" for "VALUE".  
**Note:** See also "Working with the FAMILY, SELECT and numeric buttons" (p. 20).
- (5) Press another "big" button in the DATA ENTRY section to leave this function.  
**Note:** This setting can be saved to a User Program (see p. 44).

## More Music Style functions

Here are yet other functions related to Music Styles. These can be set via the **FUNCTION** menu, or are covered elsewhere:


- Balance between the Keyboard parts and the Music Style parts (see p. 18)
- Volume of certain Music Style parts (see p. 41)
- Arranger split point (see p. 40)
- Hold function for the Arranger notes (see p. 42).

## 9. Using oriental tunings

Your EXR-40 OR allows you to change the tuning of the keys, which then applies to all notes of the same name. Here's an example: If you press the ORIENTAL SCALE [B $\flat$ ] button (indicator lights), that note's tuning is lowered by a quarter tone (-50 cents). This setting applies to all B-flat keys on the keyboard.

### Tuning individual notes a quarter tone down

- Press an ORIENTAL SCALE button to tune the corresponding notes a quarter tone down (the button must light).




- If you also want to tune down other notes, press the corresponding button(s).  
If you pressed the wrong button (indicator lights), press it again so that its indicator goes dark again. The pitch of the corresponding notes returns to normal.

### Using other tuning values

Pressing an ORIENTAL SCALE button toggles between the western tuning of the corresponding notes and a setting that is a quarter tone below western tuning (-50 cents).

However, you can also select other tuning values.

- Press and hold the ORIENTAL SCALE button of the note whose tuning you wish to change until the display reads  $\frac{5}{4}c \downarrow 1 \text{ E}$ , followed by the note name.  
You can also select this page and parameter via the Function menu. See page 43.
- Use the DATA ENTRY [+/-] buttons to modify the tuning of the selected note.




Setting range: -64~63 cents.

**Note:** To return to the default value, press [+] and [-] simultaneously.

### Saving and loading your tunings (SCALE MEMORY)


After setting the desired tunings, you can save them to one of the three Scale Memories and recall them whenever you need them. Here's what you need to do:

- Tune the notes to your liking (see above).
- Press and hold the SCALE MEMORY button ([1]~[3]) that corresponds to the memory where you wish to save your tuning settings.



- Wait until all three SCALE MEMORY indicators briefly light, and release the button you pressed.  
If necessary, you can select another, scale memory by briefly pressing the SCALE MEMORY button assigned to the settings you wish to use.  
To return to the western tuning, press the SCALE MEMORY button in question again so that its indicator goes dark, and/or switch off all ORIENTAL SCALE buttons whose indicators light.  
In the second case, the SCALE MEMORY indicator of the last memory you selected starts flashing to signal that the current ORIENTAL SCALE settings no longer correspond to the ones contained in the currently selected memory.  
The ORIENTAL SCALE settings are also saved to a User Program and therefore do not need to be saved to one of the SCALE MEMORY areas. Whenever you select a User Program

whose scale settings differ from the ones of the last memory you selected, the corresponding button ([1]~[3]) starts flashing.



**Note:** When shipped, the EXR-40 OR already contains frequently used Scale Memory settings (see above).

**Note:** See also "Sel Mode" (p. 43) for deciding which sections should be affected by the Scale Tune settings.

## 10. Keyboard part functions


### Selecting sounds for the Main, Split and Dual parts

The EXR-40 OR contains about 524 melodic sounds you can use for playing melodies (others are more like sound effects). Those sounds need to be assigned to a Keyboard part, of which there are three: Main, Split and Dual (see also p. 13).

### Selecting any of the available sounds

Unlike previous arranger-type instruments, the EXR-40 OR no longer works with banks, numbers and variations: all available sounds can be selected via the same streamlined procedure.


- (1) Press the DATA ENTRY **TONE** button (it must light).



- (2) To assign another sound to the Split or Dual part, hold down the **SPLIT** or **DUAL** button while performing the following steps.

**Note:** Now skip to step (5) if you prefer to enter the Tone number using the numeric key pad (0~9). That is indeed the only way to select any available Tone.

- (3) Use **FAMILY**  $\leftarrow \rightarrow$  to select the desired Tone family.



See below for the available families. By selecting another family, you immediately jump to the first sound of that group.

- PIANO (001-011)
- E.PIANO (012-026)
- KEYBOARD (027-033)
- CHR PERC (034-063)
- ORGAN (064-097)
- ACCORDN (098-111)
- GUITAR (112-129)
- E.GUITAR (130-163)
- BASS (164-217)
- STRINGS (218-263)
- VOCAL (264-275)
- SAX (276-287)
- WIND (288-301)
- AC BRASS (302-329)
- SYNBRASS (330-343)
- SYNLEAD (344-380)
- POLY SYN (381-391)
- PAD (392-426)
- ETHNIC (427-499)
- PERCUSSION (500-524)
- SFX (525-566)
- DRUM KIT (567-592)

**Note:** See page 117 for a list of the available sounds.

- (4) Use **SELECT**  $\leftarrow \rightarrow$  to specify a sound within the selected family.

The first press of **SELECT**  $\rightarrow$  (or  $\leftarrow$ ) shows the name of the first Tone within the selected group. It is already selected, so if you need the first sound, there is actually no need to press **SELECT**  $\rightarrow$ . You must use **SELECT**  $\leftarrow$  or  $\rightarrow$ , however, to select another Tone within the same group.


- (5) Use the numeric buttons 0~9 to select other sounds within the current family that are skipped by the **SELECT** buttons.

**Note:** This setting can be saved to a User Program (see p. 44).

You can also use the numeric buttons. See also "Working with the FAMILY, SELECT and numeric buttons" (p. 20) and replace "song" with "sound" in the explanations.

### Using the USER TONES buttons

The USER TONES buttons allow you to select 8 melodic sounds or Drum Sets directly (without using **TONE**, the FAMILY, SELECT and/or numeric buttons). At first, these buttons recall sounds assigned to them at the factory (but you can change that).



These buttons are assigned to our "favorite" sounds for the indicated categories, thus allowing you to quickly select "a piano", "a string sound", etc. The assignments to these buttons can be changed.

**Note:** The **TONE DRUMS** button is only available for the Main part.

### Assigning another Tone to a USER TONES button

To assign another sound to one of the 8 USER TONES buttons:

- (1) Select the sound you want to assign using the procedure described above.
- (2) Press and hold the desired USER TONES button. The display briefly shows the message "Tone: i z e d". You can assign whichever sound (or Drum Set) you like to any of the USER TONES buttons and select it by pressing that button once.

**Note:** The assignments can be saved to a User Program (see p. 44). This allows to work with up to 1600 different assignments (because there are 200 User Programs).


To select the sound, which has been assigned to a USER TONES button at the factory, press the corresponding button twice in rapid succession ("double-click").



## Drum sounds and sound effects ("SFX")

### Drum Sets

The last 25 "sounds" (567~592) are so-called "Drum Sets". When you select such a Kit, each key is assigned to a different sound. With the left-most key, you can play a bass drum sound (also called "kick"). The white key next to it triggers a snare drum sound, etc. Try it out by pressing several keys, either in succession or simultaneously.



Drum Sets are collections of over 90 sounds, each assigned to a different key.

**Note:** Drum Sets can only be assigned to the Main part (so neither to the Split, nor the Dual part).

**Note:** One Kit (592) is actually a sound effects (SFX) kit that cannot be used for "drumming" but rather for triggering various sound effects.

**Note:** This setting can be saved to a User Program (see p. 44).

### Sound effects ("SFX")

The EXR-40 OR also contains individual sound effects (like "Train", "Kitty", "HrseGillp", etc.) and individual drum and percussion sounds (500~566) that are assigned to the entire range of the part you select them for (Main, Split or Dual).

Note that those sounds do not work like the Drum Sets: only one sound is assigned to the keyboard – and can be played melodically (though "Train" melodies are probably "interesting" at best).

It might therefore be a good idea to proceed as follows:


- (1) Press the **[SPLIT]** button.
- (2) Decide whether you want to play the sound effect or percussion sound with your left or right hand.

If you want to use your left hand, assign a sound between "500" and "566" to the Split part. To play the effect with your right hand, assign it to the Main part.

- (3) Change the split point (page 40) in such a way that only a few keys are assigned to the percussion sound/sound effect ("C6" for right-hand effect playing, "C3" for left-hand effect playing).

- (4) To obtain a meaningful effect, you may also have to change the **MAIN Oct.** or **SPLIT Oct.** setting (page 41).

If you assign a sound effect/percussion sound to the Split part, the key ranges could be set as shown below.




## Transpose

The Transpose function changes the pitch of the notes and chords you play. Instead of figuring out what other keys you need to press to accommodate the singer or an instrumentalist, you can set the required Transpose value and go on playing the song the way you practised it, while sounding in a different key.


There are two transpose functions: one ("USRTrnsp") whose setting can be saved to a User Program, and a second one ("GLBTrnsp") that applies to all sections and whose setting is added to (or subtracted from) the "USR Transp") value. Its setting is never saved.

Let us begin with the "USRTrnsp" function, which is assigned to the **TRANPOSE** button:


- (1) Press the **TRANPOSE** button.



The display now looks as follows:



- (2) Use the **[+]** and/or numeric buttons (**[0~9]**) to set the desired transposition interval.




The setting range is -12~12 semitones. A "semitone" is one step between a white and a black key (or two adjacent white keys, i.e. between "E"/"F" and "B"/"C").

Press **[+]** or **[-]** repeatedly to transpose the keyboard up or down. You can also directly enter the desired interval by pressing the corresponding numeric key.

To transpose the keyboard down, hold down **[-]** while pressing **[0~9]** (in that case, you can transpose the pitch down by up to 9 semitones)

Here's an example: to hear an "E" each time you play a "C", select "4". All other notes will be shifted by the same amount, so that you end up sounding in E major when you actually play in C major, etc.



The corresponding value and the **TRANPOSE** icon appear in the display.

- (3) To switch the Transpose function back off, repeat steps (1) and (2), this time entering the value "0" (no transposition).

**Note:** This setting can be saved to a User Program (see p. 44).

**Note:** There is also a function that allows you to specify which section(s) the Transpose function should apply to. See "Trans-Mod\*" (p. 40).

- (4) Press another "big" button in the DATA ENTRY section to leave this function.

## Global transpose function ("GLB")

There is also a "master transpose control" that alters the pitch of all sections of the EXR-40 OR. Its value is added to the current transposition interval until you reset it to "0" or until you switch off your EXR-40 OR.

- (1) Press the **TRANPOSE** button.  
The display now shows the "USR Trnsp" message.
- (2) Press the **SELECT** button once to select the following parameter:



- (3) Use the **[+]** and/or numeric buttons (**[0~9]**) to set the desired transposition interval.

The setting range is -6~0~5 semitones. This setting is added to (or subtracted from) the "USRTrnsp" value of all sections and all User Programs.

Press **[+]** or **[-]** repeatedly to transpose the keyboard up or down. You can also directly enter the desired interval by pressing the corresponding numeric key.

To transpose the keyboard down, hold down **[-]** while pressing **[0~9]** (in that case, you can transpose the pitch down by up to 6 semitones).

As soon as you select a value other than "0", the **TRANPOSE** icon starts flashing to signal that the EXR-40 OR is applying global transposition to all sections.

- (4) To switch the global transposition back off, repeat step (3), this time entering the value "0" (no transposition). The **TRANPOSE** icon stops flashing (and disappears if the "USRTrnsp" function is off).


**Note:** This setting is not saved to a User Program and will be cancelled when you switch off the EXR-40 OR.

- (5) Press another "big" button in the DATA ENTRY section to leave this function.

## Octave settings

The EXR-40 OR allows you to transpose the Keyboard parts (Main, Split, Dual) up or down by 4 octaves.

To change the octave transposition of a part, hold down **[TONE]** (Main part), **[SPLIT]** (Split part) or **[DUAL]** (Dual part), while pressing **[-]** (down) or **[+]** (up).



## Other Keyboard part functions

Here are yet other functions related to the Keyboard parts. These can be set via the **FUNCTION** menu, or are covered elsewhere:

- Keyboard velocity (see p. 34)
- Master Tune (see p. 39)
- Volume of the Keyboard parts (see p. 41)
- Intelligence function for the Split part (see p. 40)
- Hold function for the Split part (see p. 40).

## 11. Performance functions and effects

### Performance functions


#### Keyboard Touch (velocity sensitivity)

The EXR-40 OR is velocity sensitive, which means that the volume and brightness of the Main, Split and Dual notes depend on the force/speed with which you strike the keys.

All acoustic instruments (piano, violin, flute, drums, etc.) are velocity sensitive. The harder you play, the louder and brighter the resulting notes will be, which creates a perfectly natural effect. (That explains why the KEYBOARD TOUCH function is on when you power on the EXR-40 OR.)

If the EXR-40 OR is your first musical instrument ever, you may feel distracted by the volume and timbre variations of the notes you play.

- (1) If the **KEY TOUCH** icon is not displayed, press the **KEYBOARD TOUCH** button to activate the EXR-40 OR's velocity sensitivity.



- (2) Press the button again to switch the KEYBOARD TOUCH function off, if you don't need it.
- (3) To set a fixed velocity value, press and hold the **KEYBOARD TOUCH** button until the "KbdTouch" message is displayed.

VALUE  
127 KbdTouch

- (4) Use the numeric buttons and/or  $\square +$  to set the velocity value that should be used for all notes you play (1~127).


"1" is very low (usually inaudible), while "127" corresponds to maximum striking force (loud, bright notes). The value is only used when the **KEY TOUCH** icon is not displayed (otherwise, all notes use the velocity values that correspond to the force with which you strike the keys).

- (5) Press another "big" button in the DATA ENTRY section to leave this function.  
**Note:** Some sounds use "velocity switching". This means that by hitting the keys harder and softer, you alternate between two sounds. So only switch off this parameter if doing so makes you feel more comfortable.  
**Note:** This setting can be saved to a User Program (see p. 44).  
**Note:** Keyboard Touch applies to all parts you can play yourself (the "Keyboard parts"): Main, Split, and Dual.

#### Pitch Bend and Modulation

The BENDER/MODULATION lever to the left of the keyboard can be used to add two kinds of effects to the Keyboard-part notes. You can even use these effects simultaneously if you like.

- (1) Press the lever towards the rear of the EXR-40 OR to add a vibrato effect ("wobble") to the notes you are playing.



The Modulation axis can also be used for switching between the slow and fast Rotary speeds (if the "Rotary" effect is assigned to the MFX).

- (2) Turn the lever to the left to temporarily lower the pitch of the notes you are playing. Turn it to the right to raise the pitch of your notes.

- (3) In either case, you can release the lever if you no longer need the effect.

**Note:** If necessary, you can change the Pitch Bend interval. See "PB Range" (Pitch Bend Range)" (p. 40).

**Note:** Modulation is not available when the MFX type="Rotary". In that case, the modulation axis of the lever is used for switching between the fast and slow speeds.

#### Footswitch

The EXR-40 OR's FOOTSWITCH socket (rear panel) allows you to connect optional DP-2, DP-6, or BOSS FS-5U footswitch.

The footswitch can be used for sustaining the notes you are playing (default), as Soft or Sostenuato pedal, to change the Rotary effect speed (MFX), and more. See "FSW" (Footswitch Assign)" (p. 40) and "Using the outputs and an optional footswitch" (p. 56).

To use it for holding the notes you are playing, proceed as follows:

- (1) Connect a DP-2, DP-6, or BOSS FS-5U footswitch to the FOOTSWITCH jack.
- (2) Play a note with your right hand.
- (3) Press the footswitch.
- (4) Release the key.  
The note(s) you played keep on sounding after you release the corresponding keys.
- (5) To stop the note(s) from sounding, release the footswitch.


## Using effects

The EXR-40 OR contains digital Reverb and Chorus effects processors. You can switch them on/off and select other types. You can also set the Send level (the amount of reverb or chorus) to be applied to the various Keyboard parts. Please bear in mind that the chorus effect cannot be combined with the MFX (so you need to choose between chorus or MFX for the Main part).

### Using the multi-effects processor (MFX)

The multi-effects (MFX) processor can be used for processing the Main part. It can generate various effects (47), some of which are combinations of two effects, while the Reverb and Chorus processors only generate effects that are somehow related to ambiance (REV) or modulation (CHR).

- (1) Press the **FUNCTION** button (it must light).



- (2) Use **FAMILY** to select "EFFECTS".  
The EXR-40 OR's function parameters are divided into 9 logical "families". For the following, we need to select the effects group.
- (3) Use **SELECT** to select the "MFX" parameter.



**Note:** See also "Working with the FAMILY, SELECT and numeric buttons" (p. 20).

The "□+□" message means that the MFX is not being used.

- (4) To switch on the MFX, select one of the remaining 47 types using the buttons.  
**Off:** The MFX is off.

**Enhancer:** An Enhancer controls the overtone structure of the high frequencies, adding sparkle and tightness to the sound.

**Overdrv1~4:** Overdrive creates a soft distortion similar to that produced by tube amplifiers. Several types of overdrive are available: (1) Small combo amp, (2) Combo amp, (3) Large double-stack amp (2 cabinets), (4) Large double-stack amp (3 cabinets).

**Distort1~4:** This effect produces a more intense distortion than Overdrive. The numbers refer to different kinds of distortion.

**Phaser:** Adds a phase-shifted sound to the original sound, producing a twisting modulation that creates spaciousness and depth.

**AutoWah:** The Auto Wah cyclically controls a filter to create cyclic change in timbre.

**Rotary:** Simulates the sound of a classic rotary speaker. This effect is most suitable for electric organ. If you select this type, you can use the MODULATION axis of the BENDER/MODULATION lever for switching between the slow and fast modulation speeds: press the lever towards the back of the EXR-40 OR to alternate between slow and fast undulations.

**StFlangr:** This is a stereo Flanger. It produces a metallic resonance that rises and falls like a jet airplane taking off or landing.

**SpFlangr:** A Step Flanger is a Flanger effect with clearly noticeable steps rather than continuous pitch changes.

**Compress:** A compressor reduces signal peaks and boosts low levels, smoothing out unevenness in volume.

**Limiter:** A limiter prevents the volume from exceeding a certain level without boosting low levels.

**HexaCho:** Hexa Chorus uses six layers of chorused sound to give richness and spatial spread to the sound.

**Trem Cho:** Tremolo Chorus is a chorus effect with added Tremolo (cyclic modulation of the volume).

**StChorus:** This is a stereo chorus.

**Space-D:** A multiple Chorus that gives no impression of modulation, but produces a transparent Chorus effect (the perfect "stereo maker").

**StDelay:** Delay is an effect that allows you repeat the input signal, thus creating echoes (repetition).

**Mod Dly:** This effect adds modulation to the delayed sound, producing an effect similar to a Flanger.

**3Tap Dly:** The Triple Tap Delay produces three delay sounds; center, left and right.

**4Tap Dly:** Delay with four repetition lines.

**TmCtrDly:** This effect controls the delay time in realtime.

**Reverb:** A nice Reverb effect.

**GteRevNr:** Gate Reverb is a special type of Reverb in which the reverberant sound is suddenly cut off (and does not gradually decrease).

**GteRevRv:** A gated Reverb effect that sounds "backwards".

**GteRevS1:** The reverberant sound moves from right to left.

**GteRevS2:** The reverberant sound moves from left to right.

**2PtchShf:** A Pitch Shifter changes the pitch of the original sound. This 2-voice effect has two pitch shifters, and adds two transposed copies to the original sound.

**FbPtchShf:** Pitch Shifter with several echoes.

**OD►Chors:** This effect connects an Overdrive and a Chorus in series. ("Series" means that the first effect is also processed by the second.)

**OD►Flgr:** This effect connects an Overdrive and a Flanger in series.

**OD►Delay:** This effect connects an Overdrive and a Delay in series.

**DS►Chors:** This effect connects distortion and a Chorus in series.

**DS►Flgr:** This effect connects distortion and a Flanger in series.

**DS►Delay:** This effect connects distortion and a Delay in series.

**EH►Chors:** This effect connects an Enhancer and a Chorus in series.

**EH►Flgr:** This effect connects an Enhancer and a Flanger in series.

**EH►Delay:** This effect connects an Enhancer and a Delay in series.

**Cho►Dly:** This effect connects a Chorus and a Delay in series.

**FL►Delay:** This effect connects a Flanger and a Delay in series.

**Cho►Flgr:** This effect connects a Chorus and a Flanger in series.

**Cho/Dly:** This effect connects a Chorus and a Delay in parallel. ("Parallel" means that the input signal is processed by two effects that do not interact.)

**FL/Delay:** This effect connects a Flanger and a Delay in parallel.

**Cho/Flgr:** This effect connects a Chorus and a Flanger in parallel.

**Note:** This setting can be saved to a User Program (see p. 44).

**Note:** By default, MFX type selection is linked to Tone selection for the Main part. This can be switched off, however, see "Tone MFX" (p. 42). Note that this does not apply to all Tones.

- (5) While selecting an MFX type, play a few notes on the keyboard to audition the effect.
- (6) Press another "big" button in the DATA ENTRY section to leave this function.

**Note:** If the MFX is on, the Main part is no longer processed by the Chorus effect. But the MFX also contains Chorus algorithms (either in isolation or in combination with other effects).

### Reverb

*Reverb is an effect that gives you the impression of playing in a concert hall, a room or another acoustic environment that reflects the sounds that are being produced.*


When you switch on the EXR-40 OR, all three Keyboard parts (Main, Dual, Split) as well as the Arranger and Song parts are processed by the internal Reverb effect.

If you don't need that, you can either switch off the Reverb processor (in which case none of the EXR-40 OR's 19 parts are processed) or prevent just one Keyboard part from being processed. You cannot change the amount of reverb that is added to the Arranger or pre-recorded Song parts.

#### ● Switching the Reverb on/off

Use the following procedure if you want no reverb at all (for none of the EXR-40 OR's parts), or to select another Reverb type.

- (1) Press the **FUNCTION** button (it must light).



- (2) Use **FAMILY**  $\leftarrow \rightarrow$  to select "EFFECTS".  
The EXR-40 OR's function parameters are divided into 9 logical "families". For the following, we need to select the effects group.
- (3) Use **SELECT**  $\leftarrow \rightarrow$  to select the "REV" parameter.



**Note:** See also "Working with the FAMILY, SELECT and numeric buttons" (p. 20).

- (4) Use the  $\square \oplus$  buttons to select "Off" if you don't need the Reverb processor. Otherwise, select one of the eight available types:

Type	Explanation
Room 1~3	These types simulate the Reverb characteristics of a room. The higher the number (1, 2, or 3), the "bigger" the room becomes.
Hall 1, 2	These types simulate the Reverb of a small (1) or large (2) concert hall and thus sound far "bigger" than the Room types above.
Plate	Digital simulation of a metal plate that is sometimes used for creating Reverb effects. Works well for percussive sounds.
Delay	A Delay effect (no Reverb). Works a lot like an echo effect and thus repeats the sounds.
Pan Delay	This is a stereo version of the preceding Delay effect. It creates repetitions that alternate between the left and right channels.

- (5) Play a few notes on the keyboard to audition the effect.

#### ● Changing the amount of reverb processing for the Keyboard parts

To change the reverb depth (i.e. how much reverb is added to a part), proceed as follows:


- (6) If the **FUNCTION** button still lights, use **SELECT**  $\leftarrow \rightarrow$  to select one of the following parameters.

VALUE 100	Rev MAIN	Reverb depth of the Main part.
VALUE 100	Rev DUAL	Reverb depth of the Dual part.
VALUE 100	Rev SPLIT	Reverb depth of the Split part.

(If **FUNCTION** doesn't light, first perform steps (1) and (2) above.)

- (7) Use  $\square \oplus$  to select "0" if you don't want the selected Keyboard part to be processed by the reverb effect. Otherwise, set the desired value.

If you selected an MFX type (see p. 35), the **Rev MAIN** parameter no longer affects the Main part directly, but rather the MFX signal.



"Rev Main= 100" then means: Reverb depth of the processed Main signal coming out of the MFX. This can be used for a variety of interesting applications: Distortion (MFX) + Reverb (REV), Rotary (MFX) + Plate (REV), etc.

- (8) Play a few notes on the keyboard to audition the effect. Do not forget to activate the Split or Dual part if you wish to audition its Reverb depth.  
Note: This setting can be saved to a User Program (see p. 44).
- (9) Press another "big" button in the DATA ENTRY section to leave this function.

### Chorus

*Chorus broadens the spatial image of the sound and creates a stereo impression. You can choose from 8 types.*


When you switch on the EXR-40 OR, none of the Keyboard parts (Main, Dual, Split) are processed by the internal chorus effect. Note also that the Chorus effect **doesn't affect the Main part** if the MFX is set to anything but "Off".

If you don't need Chorus, you can either switch off the Chorus processor (in which case none of the EXR-40 OR's 19 parts are processed) or prevent just one Keyboard part from being processed. You cannot change the amount of Chorus that is added to the Arranger or pre-recorded Song parts.

#### ● Switching the Chorus effect on/off

Use the following procedure if you want no Chorus at all (for none of the EXR-40 OR's parts), or to select another Chorus type.

- (1) Press the **FUNCTION** button (it must light).



- (2) Use **FAMILY** to select "EFFECTS".
- (3) Use **SELECT** to select the "CHR" parameter:



Note: See also "Working with the FAMILY, SELECT and numeric buttons" (p. 20).

- (4) Use the **[-]** buttons to select "Off" if you don't need the Chorus processor. Otherwise, select one of the eight available types (see the list below).


Chorus 1	Chorus 4	S-Delay
Chorus 2	FB Chorus	SDelayFb
Chorus 3	Flanger	

- (5) Play a few notes on the keyboard to audition the effect.

#### ● Changing the amount of Chorus processing for the Keyboard parts

To change the Chorus depth (i.e. how much Chorus is added to a part), proceed as follows:

- (6) If the **FUNCTION** button still lights, use **SELECT** to select one of the following parameters.





(\*) Though this parameter is displayed even when MFX is set to something else than "Off", the Main part is not processed by the Chorus effect.

(If **FUNCTION** doesn't light, first perform steps (1) and (2) above.)

- (7) Use **[+]** to select "0" if you don't want the selected Keyboard part to be processed by the Chorus effect. Otherwise, set the desired value.

If you selected an MFX type (see p. 35), the **Chr MAIN** parameter has no effect (even though it is displayed).



- (8) Play a few notes on the keyboard to audition the effect. Do not forget to activate the Split or Dual part if you wish to audition its Chorus depth.

Note: This setting can be saved to a User Program (see p. 44).

- (9) Press another "big" button in the DATA ENTRY section to leave this function.

## V-LINK function


V-LINK is a function that provides for the integration of music and visual material. By using V-LINK-compatible video devices (i.e. an Edirol DV-7PR), visual effects can be easily linked to, and made part of the expressive elements of a performance.

By using the EXR-40 OR with an Edirol DV-7PR, you can:

- Use the EXR-40 OR's keyboard (highest octave) to switch images (clips). Press and hold a key for longer transition ("fade"). Briefly press a key for fast transitions.
- The numeric buttons [0]~[9] are used for switching palettes (only if the [USER PROGRAM] button lights).
- Use the BENDER axis of the BENDER/MODULATION lever to change the playback speed of the picture material or to select a different color.
- Use the LOCK buttons to change the effect (VFX1~4).

V-Link signals can be transmitted via MIDI OUT.

- (1) Connect the EXR-40 OR's MIDI OUT socket to the MIDI IN socket of the external video processor (or to a UM-1 interface).



- (2) Press the [V-LINK] button (it lights blue).



- (3) Use the BENDER, the assigned buttons or "V-LINK" keys (highest octave) to manipulate the video pictures in sync with your music (see below).
- (4) Press [V-LINK] again to switch off this function (the button goes dark).

### V-LINK functions that the EXR-40 OR can control (and corresponding MIDI messages)

The EXR-40 OR provides the following functions for controlling V-LINK compatible video equipment.

- **Keyboard:** Clip 1~8 → Program Change: 00H~08H  
Press the keys in the highest octave to switch clips.
- **Keyboard velocity:** Dissolve Time → CC23  
The velocity of the keys in the highest octave controls the speed of transition between images.
- **[1]~[0] buttons** (if the [USER PROGRAM] button lights): Palette 1~10 → CC00 (Bank Select)/00H~09H  
While the [V-LINK] button lights, press buttons [1]~[0] to switch palettes 1~10. (The numeric buttons also perform their "normal" functions.)
- **BENDER axis of the BENDER/MODULATION lever:** Playback Speed → Pitch Bend  
Moving the lever toward the right will speed up playback, and moving it toward the left will slow down playback. At the center position, playback speed will be normal.
- **MODULATION axis of the BENDER/MODULATION lever:** Clip color → CC24 (Color CB), CC25 (Color CR)  
Press the lever towards the rear of the EXR-40 OR to change the color. There are five steps that can be selected by pressing the lever several times: green, violet, blue, red, original clip color.
- **LOCK buttons:** VFX1~4, None (ACOUSTIC= None, POP= V-FX 1, ROCK= V-FX 2, DANCE= V-F1h)

- X 3, ETHNIC= V-FX 4)

Use these buttons to change the video effects. This function is not available if the receiving video processor is already set to "Off".

**Note:** VFX2 is not supported by the DV-7.

**Note:** All V-LINK messages are transmitted on MIDI channels 13 and 14.




## 12. Function menu

The EXR-40 OR's Function mode contains more advanced settings you may not need every day. They allow you to fine-tune your instrument's response. It would therefore be a good idea to familiarize yourself with these parameters. Most settings ("\*\*") can be written to a User Program (see p. 44). Other parameters ("\*") are saved to the Flash memory when you leave the Function mode.


### Editing parameters (general procedure)

You can edit the EXR-40 OR's Function parameters via the display. Here is a general outline of the procedure for all parameters discussed below:

- (1) Press **FUNCTION**.




- (2) Use **FAMILY** to select the Function group that contains the desired parameter:



- **KB SET:** KbdTouch, MstrTune, USRTnsp, GLB Trnsp, TransMod, PB Range, KeySplit, SpltHold, SpltInt, FSW, Port Main, Port Dual, Mode Main, Mode Dual
- **METRONOM:** Mtro TS, MetroVol, Count-In
- **OCTAVE:** MAIN Oct, DUAL Oct, SPLT Oct
- **VOLUME:** Main Vol, Dual Vol, SplitVol, Auto Bass, AccDrums, AccBass, Accomp1~Accomp6, Song1~Song16
- **ARR SET:** ArrChord, Arr Hold, EP Chord, Bass Inv, MI (Melody Intelligence), InEnCHRD, Sync Stop

- **EFFECTS:** REV (Reverb), CHR (Chorus), MFX, Tone MFX, Rev MAIN, Chr MAIN, Pan MAIN, Rev DUAL, Chr DUAL, Pan DUAL, RevSPLIT, ChrSPLIT, PanSPLIT
- **KB SCALE:** Scale C/C#/D/Eb/E/F/F#/G/Ab/A/Bb/B, Scale Mode
- **MIDI:** Local, MidiTxRx, Sync Rx, Style PC, LyricsTx, NTARx14, PitchBnd, Modulatr, ProgChng, Velo Rx, Clock Tx, StartStp, SongPosP
- **UTILITY:** LockInit, InitFLASH, Resume
- **WriteSNG** (see p. 48)
- **WriteSTL** (see p. 49)
- **RemoveSNG** (see p. 49)
- **Remove STL** (see p. 50)
- **WriteUPG** (see p. 49)
- **ReadUPG** (see p. 49)
- **RemovUPG** (see p. 50)

- (3) Use **SELECT** to select the parameter you wish to edit (see below).



**Note:** In FUNCTION mode, **SELECT** do not allow you to jump from one family to the next.

The "VALUE" message and a setting appear to signal that you can change ("edit") the selected parameter.

- (4) Use the **DATA ENTRY** or numeric buttons (only for values) to modify the setting of the selected parameter.  
**Note:** See also page 20.

**Note:** To return to the default value of the currently selected parameter, press and simultaneously.

- (5) Use **FAMILY** to select another Function parameter.  
(6) Continue with step (3).  
(7) Press another "big" button in the DATA ENTRY section to leave this function.

### KB SET parameters

#### ■ Kbd Touch\*

(1~127, Default setting: 110) Use this parameter to set the EXR-40 OR's fixed velocity value that will be used when the **KEY TOUCH** icon is not displayed. See p. 34.

**Note:** This parameter can also be selected by pressing and holding **KEYBOARD TOUCH**.

#### ■ MstrTune\* (Master Tune)

(427.4~452.6, Default setting: 440.0) This parameter allows you to change the EXR-40 OR's overall tuning, which may be necessary when you accompany a singer, an acoustic instrument, or when you play to a recording on CD or cassette.

#### ■ USRTnsp\*

(-12~12, Default setting: 0) Use this parameter to transpose the EXR-40 OR in semitones. If you're not sure what transposition is, see p. 32. This parameter can also be selected by pressing the **TRANSPOSE** button.

#### ■ GLBTrnsp

(-6~5, Default setting: 0) Use this parameter to temporarily transpose the EXR-40 OR in semitones. If you're not sure what transposition is, see (see p. 32). This parameter can also be selected by pressing the **TRANSPOSE** button and pressing **SELECT** once.

■ **TransMod\***

(Default setting: Int+Song) This parameter allows you to specify which parts should be affected by the Transpose setting:

**Int:** The Keyboard and Arranger parts will be transposed. Notes received via MIDI, however, will be played without change.

**Song:** Only the Song parts will be transposed. This is only meaningful when you play back a Standard MIDI File or one of your own songs with the EXR-40 OR's Recorder.

**MIDI:** Only the notes received via MIDI will be transposed.

**Int+Sng, Int+MIDI, Sng+MIDI, All:** These are combinations of the above. *Int* could be useful to transpose only the Keyboard parts so that you can play to a Recorder song in "your" key but sound in the song's key.

■ **PB Range° (Pitch Bend Range)**

(0~24, Default setting: 2) This parameter allows you to set the interval that will be used when you push the BENDER/MODULATION lever fully to the left or to the right (Pitch Bend effect). You can set this parameter in semitone steps, with a maximum of 24 semitones (2 octaves), the default value being "2", which should be OK in most situations.

**Note:** Pitch Bend is only available for the Main, Dual and Split parts. See also p. 34.

■ **KeySplit\* (Split point)**

(48~84, Default setting: 60) Use this parameter to set the split point for the Arranger mode and the Split part. The note you set here is the lowest note you can play with the Main part. The number refers to a note. "60" corresponds to the note "C4".

**Note:** You can also select this parameter by pressing and holding the **ARRANGER BAND** button.

■ **SpltHold\* (Hold function for the Split part)**

(On/Off, Default setting: Off) The SpltHold function memorizes the chords you play while the Split part is on and holds the corresponding notes until you play another chord.

■ **SpltInt\* (Split Chord Intelligence)**

(On/Off, Default setting: Off) When you activate the **SPLIT** button, the EXR-40 OR's Split Chord Intelligence function allows you to play major chords by pressing just one key, minor chords by pressing two keys, and more complex chords by pressing three keys. This system thus follows Arranger control, which is why it would be a good idea to select "On" whenever you are using the Split part while the **ARRANGER** icon is displayed.

■ **FSW° (Footswitch Assign)**



(Default setting: Sustain) After connecting an optional DP-2, DP-6, or BOSS FS-5U to the FOOTSWITCH socket on the rear panel, you can use this parameter for assigning a function to the footswitch.

**Sustain:** Also called "Hold" or "Damper", this function allows you to use the footswitch to hold the notes you play on the keyboard in much the same way as on an acoustic piano.

**Sostenut:** In this case, the footswitch functions as Sostenuto pedal (another pedal found on grand and digital pianos that allows you to sustain only those notes you played at the time you pressed the pedal).

**Note:** This function only applies to the Keyboard parts.

**Soft:** In this case, the footswitch functions as Soft pedal (a pedal found on grand and digital pianos that reduces the volume).

**Note:** This function only applies to the Keyboard parts.

**Rotary S/F:** Allows you to select the slow or fast speed of the Rotary effect. This only works, if the "Rotary" type is assigned to the MFX (see p. 35).

**UsrPrgUp:** Selects the next User Program (i.e. "10" if "9" is currently active).

**UsrPrgDw:** Selects the previous User Program (i.e. "1" if "10" is currently active).

**Start/Stop:** Starts and stops Arranger or Song playback. Same function as the **START/STOP** button.

**Bass Inv:** Switches the Bass Inversion function on and off (see p. 28).

**Punch I/O:** The footswitch can be used to activate and switch off punch in/out recording (see p. 25).

■ **Port Main**

(Off, 1~127, Default setting: Off) Portamento is an effect that produces gradual pitch changes between the notes you play. The higher the value, the longer it takes before the pitch of the newly played note is reached.

This parameter allows you to set two parameters simultaneously for the Main part (there is a second parameter for the Dual part): the Portamento switch and the Portamento time. When you select a value between "1" and "127", the Portamento switch is automatically set to "on" (127).

■ **Port Dual**

(Off, 1~127, Default setting: Off) This parameter allows you to set two parameters simultaneously for the Dual part: the Portamento switch and the Portamento time. See above for an explanation.

■ **Mode Main**



(Mon/Pol, Default setting: Pol) This parameter allows you to specify whether the Main part can be played polyphonically ("Pol") or monophonically ("Mon"). "Polyphonic" means that you can play chords, while "monophonic" means that you can only play one note at a time. This may be useful for violin, woodwind and similar sounds, because the acoustic instrument in question cannot (or usually doesn't) play chords. If you press two keys after selecting "Mon", only the note of the last key you pressed sounds (nobody actually presses two keys at exactly the same time).

■ **Mode Dual**

(Mon/Pol, Default setting: Pol) This parameter allows you to specify whether the Dual part can be played polyphonically ("Pol") or monophonically ("Mon"). See also above.

## METRONOM parameters

### ■ Metro TS° (metronome time signature)

(1/4~9/4, 1/8~9/8, Default setting: 4/4) This parameter allows you to set the metronome's time signature (number of beats per bar). Please bear in mind that this setting changes whenever you select a Music Style with a different time signature. See also p. 14 for how to use the metronome. This parameter can also be selected by holding down the **[METRONOME]** button.

### ■ Metro Vol° (metronome volume)

(0~127, Default setting: 100) Use this parameter whenever you think the metronome is too loud/soft with respect to the music. The default value is usually an appropriate setting.

### ■ Count-In

(On/Off, Default setting: Off) This parameter allows you to switch the count-in function for punch-in and normal recording (see p. 25) on or off. When on, the metronome will count down two measures (8 beats for a song with a 4/4 time signature).

## OCTAVE parameters

### ■ MAIN Oct°, DUAL Oct°, SPLIT Oct° (octave transposition)

(-4~0~4, Default setting: 0) These three parameters allow you to shift the octave of the part in question (Main, Split, or Dual) up or down by up to four octaves. This can be useful for Techno/Dance songs where you need a piano sound that plays in two different octaves.

To achieve this, assign two different (or the same) piano sounds to Main and Dual, activate the **[DUAL]** button, and set DUAL Octv to "-1" (or "1").

**Note:** When a Drum Set is assigned to the Main part, the pitch of the drum/percussion sounds is not transposed. Instead, the keys are assigned to other drum/percussion sounds ("shifted"). Example: after setting "MAIN Oct" to "-1", the bass drum can be played with the C3 key (rather than the C2), while other sounds are available to the left of the C3.

## VOLUME parameters

### ■ Main Vol°, Dual Vol°, SpltVol°: volume



(0~127, Default setting: 127 Main/110 Dual/100 Split) These three parameters allow you to set the volume of the Main, Dual, and Split parts respectively. Please note that the settings you make here have no effect if you used BALANCE **[ACCOMP]** to set the maximum volume for the Arranger/Song parts.

**Note:** The volume of the Dual part can also be set by holding down **[DUAL]** while pressing **[ACCOMP]** or **[KEYBOARD]**. The same is true of the Split part, except that you need to press and hold **[SPLIT]**.

### ■ Auto Bass°: status and volume

(OFF, 0~127, Default setting: OFF) Whenever the Split part is active, this parameter allows you to set the volume of the Auto Bass part (in which case the Auto Bass part is switched on). This part sounds monophonic bass notes based on the chords you play. If the Bass Inversion function (see p. 28) is off, the Auto Bass part sounds the root notes (fundamentals) of the chords you play with your left hand (using the Split part).

The Auto Bass part can also be added to the EP Chord part (see below), and then follows the same rules as that part. The Auto Bass' volume and status can be set independently for "Split use" and "EP Chord use".

In either case, select **OFF** if you don't need the Auto Bass part.

### ■ AccDrums°, AccBass°, Accomp1°~Accomp6°: volume

(0~127, Default setting: 100 AccDrums/100 AccBass/100 Accomp1~6) These three parameters allow you to set the volume of three Music Style sections: the drums, the bass and the Accomp parts (1~6). You can use these parameters if you think the original "mix" of the selected Music Style is not quite right.

### ■ Song1~Song16: volume

(-64~0~63) These volume parameters apply to the respective tracks of the song you are currently playing back. In most cases, you may want to change the volume of track 4 (melody), 2 (bass) or 10 (drums). Finding another track (1, 5~9, 11~16) that's too loud or too soft may take some time, because their usage is more or less free. Be aware, however, that not all Standard MIDI Files use all 16 tracks that are available (so that changing the volume of track 16 may produce no audible change at all, for example).

These are relative parameters: the value you set here is subtracted from (negative values) or added to (positive values) the song parts' volume. Note that the upper limit (defined by the MIDI standard) is "127". It may thus be impossible to increase the volume of a track (because it already uses "127"). Select "0" if you like a track's volume the way it is.

Be aware that the changes you make here **must be saved along with the song data**. They are not written to a User Program. See pages 48 and 53 for how to save songs.

## ARR SET parameters

## ■ ChordInt\* (Arranger Chord intelligence)

(Md1, Md2, Off, Default setting: Md1) This parameter allows you to select the chord intelligence system to be used by the EXR-40 OR: the Roland system ("Md1", which makes more sense from an educational point of view, see page 126), or the "Md2" system, which can be used in the following way:

Major chords	Press the key that corresponds to the chord's fundamental.
Minor chords	Fundamental + any black key to the left of the fundamental.
Seventh chords	Fundamental + any white key to the left of the fundamental.
Minor seventh chords	Fundamental + any black key to the left + any white key to the left.

In either case, pressing just a few keys is therefore enough for obtaining full chords. If you are used to playing full chords, you can switch this function off.


## ■ ArrHold\* (Arranger Hold)

(On/Off, Default setting: On) The Arranger Hold function memorizes the chords you play with your left hand and keeps playing the corresponding notes until you play another chord.


If you switch off ArrHold, the melodic Arranger parts (A.Bass, Accomp) stop playing as soon as you release the key(s) in the left half of the keyboard, leaving you only with the drum accompaniment.

For your convenience, this function is switched on every time you power on the EXR-40 OR.

## ■ EP Chord\* (left-hand St. Strings + bass)

(On/Off, Default setting: On) The EP Chord function (for "Educational Purposes") activates a stereo string sound and monophonic bass (if Auto Bass is set to "on") whenever (a) the  icon is displayed and (b) the Arranger is stopped.

This allows you to play chords (and a bass line) with your left hand in Arranger mode – without using the EXR-40 OR's accompaniment function.


If you select "Off", however, the left half of the keyboard will be muted when conditions (a) and (b) are met and if the  icon is not displayed.

## ■ Bass Inv\*



(On/Off) Use this parameter to change the way in which the Arranger reads the chords you play. See p. 28.

## ■ MI\* (Melody Intelligence harmony type)

(Default setting: Traditnl) This parameter allows you to select the desired harmony type for the Melody Intelligence function.

**Note:** This parameter can also be selected by pressing and holding the  button. See p. 27.


## ■ InEnCHRD\* (Intro/Ending chord recognition)

(On/Off, Default setting: Off) This parameter allows you to block chord recognition during playback of the Intro or Ending pattern of the selected Music Style in PIANIST mode. Unlike the "normal" patterns (Original, Variation), Intro and Ending patterns usually contain chord changes. If you select "", chord recognition is active during Intro/Ending playback, so that the accompaniment may jump from one key to another. To avoid this, select ".

## ■ Sync Stop\* (system used for automatic stops)

(Int/Nor, Default setting: Nor) This parameter allows you to specify how the SYNC STOP function (see p. 16) should work. Select "Nor" if you want the Arranger to stop as soon as you release all keys in the chord recognition area (left side in ARRANGER mode, entire keyboard in PIANIST mode). When you play another chord, Arranger playback resumes from the beginning of the selected Style pattern.

If you select "Int", switch on the SYNC STOP (see p. 16) function and then release all keys in the chord recognition area, the Arranger stops on the next downbeat – and all notes that are on at that time keep sounding (only if the "ArrHold" function is on). When you play another chord, Arranger playback resumes from the point it had reached when you released all keys in the chord recognition area.

**Note:** This parameter can also be selected by pressing and holding the  button.

## EFFECTS parameters

## ■ Rev\* (Reverb Type)

(Default setting: Hall 2) Use this parameter to select the kind of Reverb that best suits your musical purposes, or to switch the Reverb processor "Off". See p. 36.

## ■ Chr\* (Chorus Type)

(Default setting: Chorus 3) This parameter allows you to specify the type of Chorus effect, or to switch the Chorus processor "Off". See p. 37.

## ■ MFX\* (MFX type)

(Default setting: Rotary) This parameter allows you to select the desired MFX type and to switch the MFX processor off. See p. 35 for details about the MFX. Selecting "Off" means that the MFX is off.

**Note:** MFX type selection can also be linked to Tone selection for the Main part.

## ■ Tone MFX\*

(On/Off, Default setting: On) This parameter allows you to link the selection of an MFX type to the Tone you assign to the Main part. That way, a Distortion/Overdrive effect will be selected for a rock guitar sound, Rotary for an organ, etc.

## ■ Rev MAIN\*

(0~127, Default setting: 100) This parameter allows you to set the Reverb Send Level for the Main part (i.e. how much Reverb should be added to the Main notes). Select "0" if the Main part may not be processed by this effect.

## ■ Chr MAIN\*

(0~127, Default setting: 0) This parameter allows you to set the Chorus Send Level for the Main part (i.e. how much Chorus should be added to the Main notes). If you want this part to be processed by the Chorus effect, you need to select a value different from "0". This parameter is only used when the MFX parameter is set to "Off".

## ■ Pan MAIN\*

(Rnd, R63~0~L63, Default setting: 0) This parameter allows you to set the stereo position of the Main part (i.e. its placement between the left and right speakers). "Rnd" means that the stereo position changes randomly for each note you play. Values starting with "L" correspond to the left speaker. "0" refers to the center, and values starting with "R" correspond to the right speaker.

### ■ Rev DUAL\*

(0~127, Default setting: 100) This parameter allows you to set the Reverb Send Level for Dual part (i.e. how much Reverb should be added to the Dual notes). Select "0" if the Dual part may not be processed by this effect.

### ■ Chr DUAL\*

(0~127, Default setting: 0) This parameter allows you to set the Chorus Send Level for the Dual part (i.e. how much Chorus should be added to the Dual notes). If you want this part to be processed by the Chorus effect, you need to select a value different from "0".

### ■ Pan DUAL\*

(Rnd, R63~0~L63, Default setting: 0) This parameter allows you to set the stereo position of the Dual part (i.e. its placement between the left and right speakers). "Rnd" means that the stereo position changes randomly for each note you play. Values starting with "L" correspond to the left speaker. "0" refers to the center, and values starting with "R" correspond to the right speaker.

### ■ Rev SPLIT\*

(0~127, Default setting: 100) This parameter allows you to set the Reverb Send Level for the Split part. Select "0" if the Split part may not be processed by this effect.

### ■ Chr SPLIT\*

(0~127, Default setting: 0) This parameter allows you to set the Chorus Send Level for the Split part. If you want this part to be processed by the Chorus effect, you need to select a value different from "0".

### ■ Pan SPLIT\*

(Rnd, R63~0~L63, Default setting: 0) This parameter allows you to set the stereo position of the Split part (i.e. its placement between the left and right speakers). "Rnd" means that the stereo position changes randomly for each note you play. Values starting with "L" correspond to the left speaker. "0" refers to the center, and values starting with "R" correspond to the right speaker.

## KB SCALE parameters

### ■ Scale C\*~Scale B\* (Scale Tune)

(-64~63, Default setting: 0 for all notes) These parameters allow you to stray away from the usual semitone-interval scale (used in western music) by changing the pitch of the notes so as to accommodate other musical cultures or tuning methods (oriental, baroque music, etc.). These settings are assigned to the ORIENTAL SCALE buttons.

As you will notice, you can change the pitch of every note of one octave (C, C#, D, Eb, E...). The settings you make here apply to all notes of the same name (i.e. to every "C", every "C#", etc.). Most of the time, you will probably select the value "50" or "-50" as they correspond exactly to half a semitone up or down (quarter tone). Other settings may also be interesting, though.

### ■ Scl Mode\*

(MN, ALL, Default setting: MN) This parameter allows you to specify which parts the Scale settings (see above) should apply to: only the Main part ("MN") or all parts ("ALL"). In some cases, choosing "ALL" may produce a more satisfactory result.

## MIDI parameters

See page 46.

## UTILITY parameters

### ■ Locknit

(On/Off, Default setting: On) This function allows you to protect the EXR-40 OR's Flash area from accidentally initializing it (see the next parameter). Select "Off" only before using the "InitFLSH" parameter. For safety reasons, this parameter is reset to "On" when you switch off the EXR-40 OR.

If you want to initialize the Flash area without first selecting this FUNCTION parameter, hold down the **KEYBOARD TOUCH** button while switching the EXR-40 OR on. The display then briefly shows the "UHLCK:FLS" message.

### ■ InitFLSH (Flash initialization)

This function initializes (formats) the EXR-40 OR's Flash memory, which is only necessary if the data in the Flash memory become unreadable.

**Note:** Executing this function erases all Standard MIDI Files and Music Styles in the EXR-40 OR's Flash area.

Press **YES/+** in response to the flashing **YES** message. The "SURE?" message appears and the **YES** message starts flashing. Press **YES/+** to initialize the Flash area (or **NO/-** if you changed your mind).

After showing the "Complete" message, the EXR-40 OR leaves this function.

### ■ Resume

Select this function to recall the EXR-40 OR's factory Function settings.

**Note:** Resume does not reset the MIDI parameters of the FUNCTION mode (see p. 46).

Press **YES/+** in response to the flashing **YES** message. After showing the "Complete" message, the EXR-40 OR leaves this function.

**Note:** There is no "Sure?" question that gives you time to think. Only press **YES/+** if you are certain you want to recall ALL factory Function settings.

## 13. Working with User Programs

The EXR-40 OR is equipped with 200 User Program memories that allow you to store almost all settings (or registrations) you make on the front panel and via the Function menu (see p. 39).

**Note:** MIDI settings (see p. 46) are not saved to a User Program because the EXR-40 OR memorizes them automatically.

### Writing your settings to a User Program


It is a good idea to write your settings frequently, even if you still need to do some editing afterwards. Those intermediary saves allow you to return to the previous stage whenever you do not like your last modifications.

- (1) Press and hold the **USER PROGRAM/WRITE** button.



The EXR-40 OR now displays "-Write?".

- (2) Enter the number of the memory where you wish to save your settings using the numeric buttons **0~9**.



The "YES" message starts flashing.

- (3) Press **YES/+** to confirm the number.
- (4) Now use the numeric buttons **0~9** to name your User Program.

The available characters are:

```

_ ! # $ % & ' - @ ^ `
0 1 2 3 4 5 6 7 8 9
A B C D E F G H I J K L M
N O P Q R S T U V W X Y Z
    
```

**Note:** Each time you press another numeric button (for entering characters), the cursor advances automatically to the next position. This works like a mobile phone.

- (5) Press the **YES/+** button to save your settings to the selected memory. (Press **NO/-** if you don't want to save them after all.)  
The display now responds with the "Complete" message.

### Notes about writing User Programs

#### Leaving the User Program environment

Press any other "big" DATA ENTRY button to leave the User Program environment.

#### Meaning of the flashing number

At some stage, you may notice that the User Program number flashes.

It means that the last User Program you selected is still in effect but that the current settings no longer correspond to the ones in that memory. Such changes may include the status of the Reverb or Chorus effect, a changed volume value, etc.

Before selecting another User Program or switching off the EXR-40 OR, you should therefore write these settings to the same (or a different) User Program if you want to keep them. Otherwise, you lose these changes.

#### Mode selection

The mode (Arranger, p. 15, Piano Solo, p. 13, Pianist, p. 27) is also memorized when you write a User Program.

### User Programs and the USER STL memory


The last Music Style you selected before writing a User Program is also memorized. This even applies to the USER STL memory that may contain a Style loaded from floppy disk or the Flash memory (see p. 19).

The 200 User Programs can be saved the Flash memory (see p. 48) or a floppy disk as a set (see p. 53).

### Selecting a User Program

Though the User Program memory you specified above is already selected, there will be times when you need to select another memory. In that case, here is what you need to do:

- (1) Briefly press **USER PROGRAM/WRITE** (it lights). Do not hold this button down because doing so will start the Write procedure (see above).



The display now shows the number of the User Program you selected last, or "1" if you have not yet selected a User Program since switching on the EXR-40 OR.

The flashing number indicates that the EXR-40 OR is still using the last manual changes you may have made before selecting the User Program function. It only means "this is the last memory you selected".

None of its settings are being used for the time being. By pressing another "big" button in the DATA ENTRY section, you can leave the User Program mode without changing your manual settings. This may be important to remember if

you were about to write your settings and accidentally pressed the wrong button (or didn't press it long enough).

To actually select a User Program...

- (2) Use the numeric buttons [0]~[9] to select the memory (00~199).  
The settings of the selected User Program will be recalled.  
**Note:** You can also use the FAMILY and SELECT [◀] [▶] buttons to select User Programs.  
**Note:** As soon as you modify any setting (on the front panel or in the Function menu), the User Program number starts flashing.
- (3) Press any other "big" button in the DATA ENTRY section to leave this mode.


## Lock: filtering certain User Program settings

Your EXR-40 OR provides five LOCK buttons with two functions each that allow you to filter certain settings of the User Programs you recall.

These filters (or "locks") will help you use your User Program settings more efficiently, because you can leave out settings that may be fine for one song (the one you prepared the User Program for) but not for another.

Here is an example: suppose you saved a User Program for song "A" with the Main part's "Mode" function set to "Mon". All other settings are just perfect for song "B". Without the LOCK parameter, you would have to use a second User Program (where the "Main Mode" parameter is set to "Pol"). On the EXR-40 OR, however, you just need to switch on the [MONO/PORT] button to be able to use User Program originally prepared for song "A".

- (1) Press the LOCK button that corresponds to the settings you want to ignore.



Each button has two functions. Press it either once (it lights) or twice in rapid succession (it flashes) to activate the desired filter:

Button	Function
STYLE (x1)	The Music Style does not change when you select a different User Program.
STYLE (x2)	The Music Style and BAND ORCHESTRATOR setting remain as they are.
TONE (x1)	The Main and Dual parts do not select the sounds stored in the User Program you select.
TONE (x2)	The Main and Dual parts as well as the USER TONES assignments remain unchanged.*

Button	Function
TEMPO (x1)	The current tempo value remains unchanged.
TEMPO (x2)	The current tempo value and the status of the SYNC START function remain as they are.
TRANSPOSE (x1)	The "USRTrnsp" setting remains as it is.
TRANSPOSE (x2)	The "USRTrnsp" setting and the status of the ORIENTAL SCALE buttons remain unchanged.
MONO/PORT (x1)	The "Mode" and "Port" settings of the Main part (see p. 40) remain unchanged.
MONO/PORT (x2)	The "Mode" and "Port" settings of the Main and Dual parts (see p. 40) remain unchanged.

(\* The assignments of the USER TONES buttons (see p. 30) are also saved to a User Program.


You can also activate several buttons at once.

- (2) Select the User Program whose registration (with the exception of the unnecessary settings) settings you want to use.
- (3) Switch the LOCK buttons off again before recalling yet another User Program if you need all of its settings.  
**Note:** The status of the LOCK buttons is not saved to a User Program.

## 14. MIDI functions

MIDI is short for "Musical Instrument Digital Interface". The word refers to many things, the most obvious being a connector type that is used by musical instruments and other devices to exchange messages relating to the act of making music.

Each time you play on the EXR-40 OR's keyboard or start the Arranger (or Song), your instrument transmits MIDI data to its MIDI OUT. If you connect the MIDI OUT socket to the MIDI IN socket of another instrument, that instrument may play the same notes as one of the EXR-40 OR's parts, select sounds, etc. MIDI is a universal standard, which means that musical data can be sent to and received by instruments of different types and manufacturers. Furthermore, MIDI allows you to connect your EXR-40 OR to a computer or hardware sequencer. Connect your EXR-40 OR as shown below.



**Note:** All EXR-40 OR parts are set to receive MIDI messages. If they do not seem to respond to the messages you send from the external controller, you should check whether the external controller's MIDI OUT is connected to the MIDI IN of your EXR-40 OR.

The EXR-40 OR's transmit and receive channels of all parts have been set in keeping with a tacit Roland standard and are therefore shared by all recent EM, E, G, and RA series instruments. You cannot change them. They also correspond to the track assignments of the 16-track Recorder:

- |                 |                               |
|-----------------|-------------------------------|
| 1 Accomp 1      | 9 Accomp 6                    |
| 2 Arranger bass | 10 Arranger drums             |
| 3 Accomp 2      | 11 → Split                    |
| 4 → Main        | 12 → Auto Bass                |
| 5 Accomp 3      | 13 V-Link                     |
| 6 → Dual        | 14 V-Link                     |
| 7 Accomp 4      | 15 Melody Intell. (see p. 27) |
| 8 Accomp 5      | 16 (→ Main*)                  |

(\*) If you assign a Drum Set to the Main part.

### MIDI Function parameters

See "Editing parameters (general procedure)" (p. 39) for how to select and set these Function parameters (they belong to the "MIDI" family).


**Note:** With the exception of "Local", all MIDI parameter settings are saved as soon as you leave the Function mode.

#### ■ Local

(On/Off, Default setting: On) The Local parameter allows you to establish or remove the connection between the EXR-40 OR's keyboard/Recorder and the internal tone generator.

When set to "ON" (default), playing on the EXR-40 OR's keyboard or playing back a Recorder song will cause the corresponding notes to sound. If you select "OFF", the correspond-

ing MIDI messages are no longer sent to the internal tone generator – but they are still transmitted to the MIDI OUT or USB port and hence to external MIDI instruments.



**Note:** The setting of this parameter is not memorized when you switch off the EXR-40 OR.

#### ■ MIDI TxRx\* (MIDI transmission and reception)

This parameter allows you to specify which EXR-40 OR parts should transmit and receive MIDI messages:

Option	Meaning
ALL	All parts.
KBD	Only the Keyboard parts (see → in the table above).
STL	Only the Arranger parts (AccDrums~Accomp 6).
SNG	Only the Song parts (1~16).
OFF	None of the EXR-40 OR's parts transmits/receives MIDI messages.

#### ■ Sync Rx\* (MIDI synchronization)

Use this parameter to specify how the EXR-40 OR should be synchronized (as slave) to an external MIDI sequencer, computer, drum machine, etc.

"Synchronization" is a learned term for the fact that one device (or function) is set to start and stop at the same time as another device (or function), and to run at the same tempo (BPM).<sup>o</sup>

### Channels

MIDI can simultaneously transmit and receive messages on 16 channels, so that up to 16 instruments can be controlled. Nowadays, most instruments –like your EXR-40 OR– are multitimbral, which means that they can play several musical parts with different sounds.



Please note that synchronization is only possible when you connect the external device's MIDI OUT socket to the EXR-40 OR's MIDI IN socket (though you can also work the other way around; in that case, see the sequencer's manual for details).

- 
- Off In this case, the EXR-40 OR is not synchronized with other MIDI devices. It is thus impossible to start/stop it via MIDI.
- 
- On Arranger playback and Song recording/playback are synchronized if the EXR-40 OR receives MIDI Start and Stop messages followed by MIDI Clock signals. If the EXR-40 OR receives only a Start message, it will wait a moment to see if there are also MIDI Clock messages coming. If there are, it will synchronize to them. If there are no MIDI Clock messages, it will follow its own tempo. In either case, you can stop playback or recording with a MIDI Stop message.
- 

#### ■ Style PC° (Style Select TxRx Channel)

(OFF, 1~16, Default setting: 10) As its name implies, the Style Select channel is used to receive and transmit program changes that cause the EXR-40 OR or the external instrument to select another Music Style.

#### ■ Lyrics Tx° (Transmit Lyrics messages)

(On/Off, Default setting: Off) The EXR-40 OR can transmit Lyrics messages contained in Format 0 Standard MIDI Files you play back. It cannot display them, but it allows you to transmit them to a device capable of displaying Lyrics messages (such as the Roland LVC-1). This filter allows you to enable (On) or disable (Off) the transmission of Lyrics data.

#### ■ NTA Rx14° (Note-to-Arranger reception on/off)

(On/Off, Default setting: On) *NTA* is short for "Note-to-Arranger", or the notes you play in the left half of the keyboard to feed the Arranger with chord information. These notes can also be received via MIDI (from an accordion, a digital piano, an organ, for example). If you want to use the Arranger without playing on the EXR-40 OR's keyboard, you must transmit these notes on MIDI channel 14 (from your computer or external MIDI instrument to the EXR-40 OR) and select "On" here:

NTA notes can only be received (they are not transmitted). The notes you play on the EXR-40 OR's keyboard are indeed transmitted to the Arranger, from there to the Arranger parts, and used to play the accompaniment in the right key. Since all Music Style notes are transmitted via MIDI, there is no need to send the NTA notes separately.

#### ■ PitchBnd° (Pitch Bend)

(On/Off, Default setting: On) This filter allows you to enable (On) or disable (Off) the transmission and reception of Pitch Bend messages. These messages are used to temporarily increase or decrease the pitch of the Keyboard-part notes (Main, Dual, Split).

#### ■ Modulatn° (Modulation)

(On/Off, Default setting: On) This filter allows you to enable (On) or disable (Off) the transmission and reception of Modulation messages. These messages are used to add vibrato to the notes you play (control change CC01).

#### ■ ProgChng° (Program Change)

(On/Off, Default setting: On) This filter allows you to enable (On) or disable (Off) the transmission and reception of Program Change messages. These messages are used to select Tones, Styles, or User Programs.

#### ■ Velo Rx° (Receive Velocity)

(On, 1~127, Default setting: On) This filter allows you to enable (On) or disable the reception of velocity messages. This only applies to note messages *received* via MIDI. Choose the velocity value to be substituted for the actual values the EXR-40 OR receives (1~127), or select "On" to use the velocity values as is.

#### ■ Clock Tx° (synchronization)

(On/Off, Default setting: On) This parameter allows you to determine whether (On) or not (Off) the Arranger and Recorder send MIDI Clock messages when you start them. These messages are necessary for synchronizing external MIDI instruments/sequencers/software to the EXR-40 OR.

#### ■ StartStp° (Start/Stop/Continue)

(On/Off, Default setting: On) This option allows you to specify whether or not the Arranger and Recorder send Start/Stop/Continue messages when you start or stop them. Select "Off" when you wish to control the tone generator of a MIDI organ, etc., without starting or stopping its automatic accompaniment.

#### ■ Song PosP° (Song Position Pointer)

(On/Off, Default setting: On) The EXR-40 OR's Recorder also sends and receives Song Position Pointer messages that indicate the exact location of the notes that are being played back. Select "OFF" if you don't want the Recorder to send or receive these messages.

## 15. Data management


### Working with the Flash memory

Let us first have a look at the remaining Function parameters. They allow you to save newly recorded songs and Styles loaded from a floppy disk to the EXR-40 OR's Flash memory, and to remove such files.

#### Saving songs to a Flash memory

Songs you record or edit with the EXR-40 OR's Recorder can be saved to its Flash memory or floppy disk. See page 53 for how to save them to floppy and page 19 for how to select songs in the Flash memory.

- (1) Press **[FUNCTION]**.



- (2) Use **FAMILY** to select the "WriteSNG" parameter. Wait until the display looks as shown below, then proceed with the following step.

Wrl SONG 001-YES TEMPO


The EXR-40 OR automatically selects a Flash memory that doesn't yet contain data. (The first character, "S", flashes.)

**Note:** If no vacant Flash memory remains or if the memory capacity is exhausted, the display shows the "Mem Full" message when you select this function. In that case, it will be impossible to save your song. You can, however, delete another song ("Remove") and repeat step (2) and following.

**Note:** The "No Song" message means that there are no song data that could be saved.

- (3) If necessary, use the **SELECT** buttons to move the cursor to another character position (that character flashes).

- (4) Use the numeric buttons to assign a character to that position.



The available characters are:

\_ ! # \$ % & ' - @ ^ `  
 0 1 2 3 4 5 6 7 8 9  
 A B C D E F G H I J K L M  
 N O P Q R S T U V W X Y Z

**Note:** Each time you press another numeric button (for entering characters), the cursor advances automatically to the next position. This works like a mobile phone.

- (5) Repeat steps (3) and (4) to assign the desired characters to the remaining positions.
- (6) After entering the name, press the **[YES/+]** button to save the song to the EXR-40 OR's Flash memory. The display now counts down:

71 Writing

At the end of the saving operation, the display briefly shows the "Complete" message.

**Note:** Press **[NO/-]** if you do not wish to save the song after all.

- (7) Press another "big" button in the DATA ENTRY section to leave this function.

#### Archiving User Programs in the Flash area

This function allows you to save the contents of the internal User Programs (all 200 of them) to the Flash area. User Programs are always archived as a set.

Use this function if all 200 User Programs contain settings you don't want to overwrite (by saving other registrations) or lose (in the unlikely event of a memory failure). There is also a function that allows you to load archived User Programs (page 49).

**Note:** The User Program set data also contain the TONE button assignments (page 30).

- (1) Press **[FUNCTION]**.
- (2) Use **FAMILY** to select the "WriteUSPG" parameter. Wait until the display looks as follows, then proceed with the next step:

Wrl USPR\_000-YES TEMPO

Though you could save the file with the current default name ("USPR\_000"), a proper name will help you identify the file at all times. We therefore suggest you take the time to specify a meaningful name.

The first character of the default name ("UserPrg") flashes.

**Note:** If the memory capacity is exhausted, the display shows the "Mem Full" message when you select this function. In that case, it will be impossible to archive the User Program set. You can, however, delete another set ("Remove") and repeat steps (2) and following.

- (3) If necessary, use the **SELECT** buttons to move the cursor to another character position (that character flashes).
- (4) Use the numeric buttons to assign a character to that position.

The available characters are:

```

_ ! # $ % & ' - @ ^ `
0 1 2 3 4 5 6 7 8 9
A B C D E F G H I J K L M
N O P Q R S T U V W X Y Z

```

- (5) Repeat steps (3) and (4) to assign the desired characters to the remaining positions.  
**Note:** Each time you press another numeric button (for entering characters), the cursor advances automatically to the next position. This works like a mobile phone.
- (6) After entering the name, press the **[YES/+]** button to save the User Program set to the EXR-40 OR's Flash memory. The display first shows the "Writing" message. At the end of the saving operation, the display briefly shows the "Complete" message.  
**Note:** Press **[NO/-]** if you do not wish to archive the User Program Set after all.
- (7) Press another "big" button in the DATA ENTRY section to leave this function.

### Saving Styles to a Flash memory

Music Styles you load from floppy disk (and which are copied to the USER STL memory at that time) can be saved to a Flash memory.

- (1) Press **[FUNCTION]**.
- (2) Use **FAMILY** **[<|>]** to select the "WriteSTL" parameter. Wait until the display looks as follows, then proceed with the next step:

```

Wrl  TANGO  TEMPO  J-YES

```

The EXR-40 OR automatically selects a Flash destination memory that doesn't yet contain data. (The first character flashes.)

**Note:** If no vacant Flash memory remains or if the memory capacity is exhausted, the display shows the "Mem Full" message when you select this function. In that case, it will be impossible to save the Music Style. You can, however, delete another Style ("Remove") and repeat step (2) and following.  
**Note:** The "No Style" message means that there are no Style data that could be saved.

- (3) If necessary, use the **SELECT** **[<|>]** buttons to move the cursor to another character position (that character flashes).
- (4) Use the numeric buttons to assign a character to that position.

The available characters are:

```

_ ! # $ % & ' - @ ^ `
0 1 2 3 4 5 6 7 8 9
A B C D E F G H I J K L M
N O P Q R S T U V W X Y Z

```

- (5) Repeat steps (3) and (4) to assign the desired characters to the remaining positions.  
**Note:** Each time you press another numeric button (for entering characters), the cursor advances automatically to the next position. This works like a mobile phone.
- (6) After entering the name, press the **[YES/+]** button to save the Style to the EXR-40 OR's Flash memory. The display now counts down:

71 Writing

At the end of the saving operation, the display briefly shows the "Complete" message.

**Note:** Press **[NO/-]** if you do not wish to save the Music Style after all.

- (7) Press another "big" button in the DATA ENTRY section to leave this function.

### Loading a User Program set from the Flash memory

This "ReadUPG" function allows you to transfer a set of 200 User Programs (i.e. for all memories) to the EXR-40 OR's internal memory. This will overwrite the User Programs that currently reside in the internal memories. You cannot load individual User Programs from an archived set.

**Note:** If you wish to use the User Programs in the internal memory at a later stage, first archive them (page 48) or save them to disk before proceeding. See p. 53.


- (1) Press **[FUNCTION]**.
- (2) Use **FAMILY** **[<|>]** to select the "ReadUPG" parameter.
- (3) Wait until the display shows the name of the first User Program set, then proceed with the following step.

- (4) Use the **SELECT** **[<|>]** buttons to select the set you wish to load.
- (5) Press the **[YES/+]** button.  
The display now shows the "SURE?" message, while YES starts flashing.
- (6) Press the **[YES/+]** button again to load the User Program set (or **[NO/-]** if you do not want to load it after all). While the data are being loaded, the display shows the "Reading" message. Once the file has been loaded, the display briefly shows the "Complete" message.
- (7) Press another "big" button in the DATA ENTRY section to leave this function.


### Removing songs from the Flash memory

Songs you no longer need can be deleted (which is called "Remove" here) to make room for new songs.

- (1) Press **[FUNCTION]**.




- (2) Use **FAMILY** **[<|>]** to select the "REMOVING" parameter.



Wait until the display shows the name of the first song in memory (101), then proceed with the following step.

**Note:** The "No Song" message means that there are no song data that could be deleted.

- (3) Use the SELECT ◀▶ buttons to select the song you wish to delete.



- (4) Press the YES/+ button.  
The display now shows the "SURE?" message, while YES starts flashing.
- (5) Press the YES/+ button again to delete the song (or NO/- if you do not want to delete it after all).  
The display now shows the following message:

## Removing

Once the file has been deleted, the display briefly shows the "Complete" message.

- (6) Press another "big" button in the DATA ENTRY section to leave this function.

## Removing Styles from the Flash memory

Styles you no longer need can be deleted (which is called "Remove" here) to make room for new Styles.

- (1) Press FUNCTION.
- (2) Use FAMILY ◀▶ to select the "RemoveSTL" parameter. Wait until the display shows the name of the first Style memory (101), then proceed with the following step.  
**Note:** The "No Style" message means that there are no Music Style data that could be deleted.
- (3) Use the SELECT ◀▶ buttons to select the Music Style you wish to delete.
- (4) Press the YES/+ button.  
The display now shows the "SURE?" message, while YES starts flashing.
- (5) Press the YES/+ button again to delete the Style (or NO/- if you do not want to delete it after all).  
The display now shows the following message:

## Removing

Once the file has been deleted, the display briefly shows the "Complete" message.


- (6) Press another "big" button in the DATA ENTRY section to leave this function.

## Removing a User Program set from the Flash memory


The "RemoveUPG" function allows you to erase User Program sets from the EXR-40 OR's Flash memory. This may be necessary to make room for new files (e.g. when the "Memory Full" message appears). Be careful, though, to only delete files you are absolutely (positively) sure you will never need again. Once a file has been deleted, it is gone forever.

**Note:** As a rule, you should first make a backup copy of your disk on your computer. After all, most files really only become indispensable once they are no longer available...

- (1) Press FUNCTION.



- (2) Use FAMILY ◀▶ to select the "RemoveUPG" parameter. Wait until the display shows the name of the first User Program set, then proceed with the following step.  
**Note:** The "No Files" message means that there are no set data that could be deleted.
- (3) Use the SELECT ◀▶ buttons to select the User Program set you wish to delete.



- (4) Press the YES/+ button.  
The display now shows the "SURE?" message, while YES starts flashing.
- (5) Press the YES/+ button again to delete the User Program (or NO/- if you do not want to delete it after all).

The display now shows the following message:


## Removing

Once the file has been deleted, the display briefly shows the "Complete" message.


- Press another "big" button in the DATA ENTRY section to leave this function.

## Archiving data using a computer (USB)

The EXR-40 OR's USB port can be used for two purposes: (a) for transmitting/receiving MIDI data or (b) for exchanging files with a computer.

As long as the  icon is not displayed, the USB port transmits and receives MIDI data (the MIDI IN and OUT sockets are bypassed if you connect a USB cable to this port).

If the icon is displayed, however, your EXR-40 OR will appear as an external drive on your PC's or Mac's desktop:



The drive letter ("F:" in the above illustration) depends on the number of drives recognized by Windows (and is of no importance for MacOS).

**Note:** USB communication (i.e. for MIDI applications) is possible between the EXR-40 OR and Windows Me/XP or later (for Windows users), or between the EXR-40 OR and Mac OS 9.0.4 or later (for Macintosh users). This requires that you install the appropriate drivers from the supplied CD-ROM.


Data transfer, on the other hand, is possible with Windows 2000/Me/XP or later/Mac OS 9.0.4 or later. If you encounter problems with your system, please contact your nearest Roland service center for details.

Once recognized, you can copy files to the "Song", "UserPrg" or "Style" folder by dragging and dropping them using the usual routines. The "Style", "UserPrg" and "Song" folders cannot be deleted and must not be renamed. You can empty them by dragging all files they contain to the trash, though.

**Proceed as follows** (Windows XP):


- Restart your PC.
- Switch on your EXR-40 OR.


- Press the EXR-40 OR's **[USB]** button.



The display shows the error message "No Cable" to signal that USB communication is impossible.

- Connect the EXR-40 OR's USB port to a free USB port of your computer using the supplied cable.



The  icon appears and the display shows "PC <-> EXR".

If you prefer to use another cable, choose one with the correct USB jack types: a "square" one ("type B") for the EXR-40 OR and probably a "flat" one (type "A") for your computer.

**Note:** If you do not connect a USB cable within 15 seconds, the EXR-40 OR returns to its normal mode.

**Note:** Never switch off the EXR-40 OR while the "Writing" message is displayed, because doing so would damage all data in the EXR-40 OR's Flash area. (See "InitFLSH (Flash initialization)" (p. 43) if you need to repair the Flash area after an erroneous operation.)

**Note:** The "Wait... Connection Proceeding" message may appear when you press the **[USB]** button. This only happens after using the USB port for MIDI communication. It means that Windows XP is reconfiguring the USB port for data transfer use. This may take a while, so please be patient.


**Proceed as follows** (other operating systems):

- Switch on your Mac or PC if it isn't on already.
- Switch on your EXR-40 OR if it isn't on already.
- Press the EXR-40 OR's **[USB]** button.

The display shows the error message "No Cable" to signal that USB communication is impossible.

**Note:** If you do not connect a USB cable within 15 seconds, the EXR-40 OR returns to its normal mode.

- (4) Connect the EXR-40 OR's USB port to a free USB port of your computer using the supplied cable.


The  icon appears and the display shows "PC->EXR".

If you prefer to use another cable, choose one with the correct USB jack types: a "square" one ("type B") for the EXR-40 OR and probably a "flat" one (type "A") for your computer).

**Note:** Do not connect the EXR-40 OR to a USB hub. Always connect it directly to your computer.

**Note:** Never switch off the EXR-40 OR while the "Warning" message is displayed, because doing so would damage all data in the EXR-40 OR's Flash area. (See "InitFLASH (Flash initialization)" (p. 43) if you need to repair the Flash area after an erroneous operation.)

#### For all operating systems:

**Note:** If you press the  button without connecting the USB cable, the display shows the error message "No Cable" to signal that USB communication is impossible. Connect a cable to cause this message to disappear.

- (5) Open the "My Computer" window (Windows) and check whether your computer has found an "EXR\_DRV" (or just "Removable Disk").
- (6) Open that drive by double-clicking on its icon.
- (7) Open either the "Style", "UserPrg" or "Song" folder. This depends on whether you want to delete/rename/add Music Styles or Standard MIDI Files.
- (8) Do one of the following:
- Copy the desired Music Styles from the "Style" folder to your computer's hard disk using drag & drop.
  - Copy the desired songs from the "Song" folder to your computer's hard disk using drag & drop.
  - Copy the desired User Program sets from the "UserPrg" folder to your computer's hard disk using drag & drop.
  - Copy the desired Music Styles from your computer's hard disk to the "Style" folder using drag & drop. (See also the explanation below step (10).)


- Copy the desired songs from your computer's hard disk to the "Song" folder using drag & drop.
  - Copy the desired User Program sets from your computer's hard disk to the "UserPrg" folder using drag & drop.
  - Rename the desired files in the "Style", "UserPrg" or "Song" folder.
  - Delete the files you no longer need.
- Note:** While the "PC->EXR" message is displayed, all of the EXR-40 OR's buttons and keys are blocked.

- (9) To disconnect the EXR-40 OR from your computer:




- **Macintosh:** Drag the "EXR\_DRV" (or "Removable Disk") icon to the trash.  
-OR-
- **Windows:** Click on the removal icon on the task bar. Wait until a drop-down menu appears and select the entry that says something to the effect of "Stop USB disk EXR\_DRV". You should now see a window that says something to the effect of "The USB device XX can now be safely removed from the system". Click on the [OK] button.

-THEN-

- Disconnect the USB cable from your computer and the EXR-40 OR.

- (10) Press the  button again.

The display shows the "Sure?" message.

- (11) Press  (the  icon disappears).  
(Press  to remain in USB mode.)

If you copied Music Styles from your computer to the Flash area, the display now shows "Wait... Converting Styles" to indicate that files with the extension ".STL" are converted to the EXR-40 OR's Music Style format (".STH").


Note that this conversion is only necessary for Music Styles in the EXR-40 OR's Flash area that do not yet have the ".STH" extension.

**Note:** This operation adds a few bytes to every converted Music Style. In rare circumstances (when the Flash area is nearly full), this may lead to the impossibility to convert all Styles that still have the extension ".STL". The EXR-40 OR then displays the "MemFull" message to signal that the conversion was aborted before reaching the last ".STL" file. All Styles up to that point have been converted, though, and can be used.

## Disk functions

The EXR-40 OR's Disk functions allow you to save the Recorder Song in the USER SONG memory to disk, to save and load your files to and from disk, to delete files on a floppy disk, and to format disks.

Though you can use 2DD or 2HD floppies, 2HD disks have twice the capacity of 2DD disks, so use 2HDs whenever you can.


Whenever the disk drive writes data to or reads data from disk, the Disk icon () flashes in the display. Do not remove the floppy disk while this icon is displayed as that may damage both the disk drive and the disk (so that it becomes unreadable).


### Loading User Programs from disk


This load function is called LOAD USER. It allows you to transfer a set of 200 User Programs (i.e. for all memories) to the EXR-40 OR's internal memory. This will overwrite the User Programs that currently reside in the internal memories.



**Note:** If you wish to use the User Programs in the internal memory at a later stage, first save them to disk before proceeding. See p. 53.


**Note:** The User Program set data also contain the TONE button assignments (page 30). After loading a User Program set, the eight TONE buttons may therefore select other sounds than before.

- (1) Insert a disk into the drive.
- (2) Press  to select the Disk mode.




The "LOAD USER" function is already selected, so there is nothing else you need to do. (Otherwise, use FAMILY  to select this parameter.)

- (3) Use SELECT   to select the User Program Set you wish to load.



The YES message next to it starts flashing.

- (4) Press the YES/+ button to load the selected file.



**Note:** Press NO/- if you do not want to load the selected file after all.

If you pressed YES/+, the display now shows the message "Loading". Once the data have been loaded, the "Complete" message briefly appears.





- (5) Press another "big" button in the DATA ENTRY section to leave this function.

#### Possible error messages

No Disk	You forgot to insert a floppy disk into the drive.
No Files	The disk you inserted contains no User Program data.
NoFormat	The floppy disk is either not formatted or uses a format the EXR-40 OR doesn't recognize. Press YES/+ to format it now ( <i>careful: this will erase all data on disk</i> ).
Disk Err	The disk is probably damaged and cannot be used.
File Err	The file you selected is damaged and cannot be loaded.

#### Loading songs from disk

LOAD SNG allows you to load a song on floppy disk into the EXR-40 OR's User memory.





- Insert a disk into the drive.
- Press DISK to select the Disk mode.
- Select the "LOAD SNG" function using FAMILY  .
- Use SELECT   to select the song you wish to load. The YES message next to it starts flashing.
- Press the YES/+ button to load the selected file.  
**Note:** Press NO/- if you do not want to load the selected file after all.

If you pressed YES/+, the display now shows the message "Loading". Once the data have been loaded, the "Complete" message briefly appears.

- Press another "big" button in the DATA ENTRY section to leave this function.  
**Note:** See also "Possible error messages" above.

#### Loading Music Styles from disk

LOAD St.1 allows you to load a Music Style on floppy disk into the EXR-40 OR's User memory.

- Insert a disk into the drive.
- Press DISK to select the Disk mode.
- Select the "LOAD St.1" function using FAMILY  .
- Use SELECT   to select the Music Style you wish to load.  
The YES message next to it starts flashing.
- Press the YES/+ button to load the selected file.  
**Note:** Press NO/- if you do not want to load the selected file after all.

If you pressed YES/+, the display now shows the message "Loading". Once the data have been loaded, the "Complete" message briefly appears.

- Press another "big" button in the DATA ENTRY section to leave this function.  
**Note:** See also "Possible error messages" (p. 53).





#### Saving files to disk

The EXR-40 OR provides the following Save functions:

**SAVE UPR:** Use this function to save the contents of the internal User Program memories (all 200 of them) to a floppy disk.


**Note:** The User Program set data also contain the USER TONES button assignments (page 30).

**SAVE SNG:** This allows you to save the song in the USER:SONG memory to a floppy disk. A song saved to disk becomes a Standard MIDI File.

- Insert a disk into the drive.  
Every floppy contains a square tab that allows you to "close" a little window. With the tab in that position, you can save data to the disk. Do not forget to write-enable the disk by closing this little window prior to inserting the floppy disk.
- Press DISK and use SELECT   to select "SAVE UPR" or "SAVE SNG".
- If necessary, use the SELECT   buttons to move the cursor to another character position (that character flashes).

**Note:** Each time you press another numeric button (for entering characters), the cursor advances automatically to the next position.

- (4) Use the numeric buttons to assign a character to that position.



The available characters are:

```


_ ! # $ % & ' - @ ^ `
0 1 2 3 4 5 6 7 8 9
A B C D E F G H I J K L M
N O P Q R S T U V W X Y Z
    
```

- (5) Repeat steps (3) and (4) to assign the desired characters to the remaining positions.

Though you could save the file with the current default name ("SONG\_001", or "USPR\_000"), a proper name will help you identify the file at all times. We therefore suggest you take the time to specify a meaningful name.

**Note:** If you select "SPACE" (0 button), the display will insert a "\_". That's because MS-DOS® does not allow you to use spaces.

- (6) After entering the name, press the **[YES/+]** button to save the data to floppy disk.



The display now counts down ("Saving").

71 Saving

At the end of the saving operation, the display briefly shows the "Complete" message.

**Note:** If the message "Protect" appears, you forgot to switch off the disk's Write protection. Press the EJECT button of the disk drive, remove the floppy and close the tab, insert the disk again and press **[YES/+]**.

**Note:** Press **[NO/-]** if you do not want to save the selected file after all.

- (7) Press another "big" button in the DATA ENTRY section to leave this function.

#### Possible error messages

No Disk	You forgot to insert a floppy disk into the drive.
Protect	See above.
Disk Full	The remaining disk capacity does not allow to save your data to this disk.
NoFormat	The floppy disk is either not formatted or uses a format the EXR-40 OR doesn't recognize. Press <b>[YES/+]</b> to format it now ( <i>careful</i> : this will erase all data on disk).
Disk Err	The disk is probably damaged and cannot be used.
OverWrt?	The name you assigned to the data already exists on the floppy disk you inserted. If you press <b>[YES/+]</b> to continue, the file on disk will be overwritten (and the corresponding data will be erased). Either insert another floppy disk, or press <b>[DISK]</b> and enter another name for the data you want to save.

#### Deleting files on disk

The Delete functions allow you to erase files from the inserted floppy disk. This may be necessary to make room for new files (e.g. when the "Disk Full" message appears). Be careful, though, to only delete files you are absolutely (positively) sure you will never need again. Once a file has been deleted, it is gone forever.

**Note:** As a rule, you should first make a backup copy of your disk on your computer. After all, most files really only become indispensable once they are no longer available...

**DEL UPR:** Use this function to delete a User Program Set from disk. Be aware that by doing so, you actually erase 200 User Program settings.

**DEL SNG:** This allows you to delete a song file on disk.

- (1) Insert the disk with the file you want to delete into the drive.
- (2) Press **[DISK]** to select the Disk mode.
- (3) Use **FAMILY** (left/right arrows) to select "DEL UPR" or "DEL SNG".
- (4) Use **SELECT** (left/right arrows) to select the file you wish to delete (example: "USPR\_005"). The YES message starts flashing.
- (5) Press the **[YES/+]** button.  
To be on the safe side, the EXR-40 OR now asks you whether you really want to delete the file ("Sure?").
- (6) Press **[YES/+]** to delete the file, or **[NO/-]** to abort the operation.  
If you pressed **[YES/+]**, the display now shows the message "Deleting". Once the data have been deleted, the "Complete" message briefly appears.
- (7) Press another "big" button in the DATA ENTRY section to leave this function.



### Possible error messages

No Disk	You forgot to insert a floppy disk into the drive.
Protect	You forgot to switch off the disk's Write protection. Press the EJECT button of the disk drive, remove the floppy and close the tab, insert the disk again and press <b>YES/+</b> .
NoFormat	The floppy disk is either not formatted or uses a format the EXR-40 OR doesn't recognize. Press <b>YES/+</b> to format it now ( <i>careful</i> : this will erase all data on disk).
Disk Err	The disk is probably damaged and cannot be used.
No Files	The disk contains no files of the selected type. Insert another disk.

### Format

Before being able to save files to a disk, you need to prepare a floppy disk. This is called "formatting". If the floppy you are about to use is IBM PC formatted, there is no need to format it, though disk access is faster with disks formatted on the EXR-40 OR. Otherwise proceed as follows:

- (1) Insert a disk into the drive.  
Every floppy contains a square tab that allows you to "close" a little window. With the tab in that position, you can format the disk. Do not forget to write-enable the disk by closing this little window prior to inserting the floppy disk.
- (2) Press **DISK** to select the Disk mode.
- (3) Use FAMILY **◀▶** to select "FORMAT". The "Sure?" message appears and the **YES** message starts flashing.
- (4) Press **YES/+** to format the disk.  
**Note:** If you do not want to format your floppy, press **NO/-**.  
**Note:** By formatting a disk, you **erase all files it contains**. It would be a good idea to first check what it contains (e.g. on your PC).

The value to the left of the "Formating" message now counts from "1" to "100" while the disk icon flashes to indicate that the disk is being accessed. When the disk is formatted, the message "Complete" is briefly displayed.


## 16. Using the outputs and an optional footswitch

If you like, you can also record your performance (or a Recorder songs) to cassette, MD, etc. To this end, you need to connect the EXR-40 OR's OUTPUT sockets to the external device's REC IN jacks.

Use a standard 1/4" phone cable for doing so. Another use for these outputs is to connect the EXR-40 OR to your HiFi or keyboard amplifier (such as the Roland KC-550/350/150). Using a HiFi amplifier requires the use of an adapter plug (RCA/phono → 1/4" jack). If you like, you can also purchase two Roland PJ-1M cables.

**Note:** By connecting the OUTPUT jacks, you do not switch off the EXR-40 OR's amplification system.

You can connect an optional DP-2, DP-6, or BOSS FS-5U foot switch to the FOOTSWITCH jack in order to hold the notes even after releasing the keys, or to perform other functions (see p. 40).



## 17. Miscellaneous

### Functions for educational purposes

The EXR-40 OR provides two functions that may come in handy for music teachers or for those who use the EXR-40 OR in class:

#### Deactivating or activating the Demo function

The EXR-40 OR's Demo function can be switched off so that pressing **[USB]+[ONE TOUCH]** will have no effect at all. This may be useful in situations where the EXR-40 OR is used in class. Here is how to deactivate the Demo function:

- (1) Switch off the EXR-40 OR.
- (2) Hold down the **[USB]**, **[ONE TOUCH]** and **[ACOUSTIC]** buttons while switching the EXR-40 OR back on again. The display briefly shows "DISABLED".

This setting is remembered, so that next time you want to listen to a demo song, you have to repeat the above procedure.

#### Deactivating or activating the Arranger

Use the following procedure to ensure that the Arranger cannot be started or stopped:

- (1) Switch off the EXR-40 OR.
- (2) Hold down the **[ACOUSTIC]** and **[ARRANGER BAND]** buttons while you switch the EXR-40 OR back on again. The display briefly shows "DISABLED". It is now impossible to start/stop the Arranger using the **[START/STOP]** button.

Repeat the above procedure when you want to use the Arranger again.

#### Deactivating or activating the Arranger and Demo functions

A third "educational" option is to switch off both the Demo and the Arranger functions in one go:

- (1) Switch off the EXR-40 OR.
- (2) Hold down the **[ACOUSTIC]** and **[START/STOP]** buttons while you switch the EXR-40 OR back on again. The display briefly shows "DISABLED". It is now impossible to start/stop the Arranger or demo song playback. Repeat the above procedure when you want to use the Arranger and Demo function again.

### Initializing your EXR-40 OR (Factory)

After working extensively with your EXR-40 OR, you may want to recall the original factory settings. Note that the Recorder song will be empty and that the User Programs contain the factory settings after initializing your EXR-40 OR.

Here is how to initialize your EXR-40 OR:

- (1) Power off your EXR-40 OR.
- (2) Hold down the **[USER PROGRAM/WRITE]** button while turning your EXR-40 OR back on again. The message "FACTORY" informs you that the EXR-40 OR has been initialized.

**Note:** This does not affect the data in the EXR-40 OR's Flash memory. See page 43 for how to initialize that area.

## 18. Specifications

EXR-40 OR Interactive Arranger

**Keyboard:** 61 keys, velocity sensitive

**Sound source:** PCM samples

**Max polyphony:** 64 voices

**Tones:** 592 panel sounds (542 XG compatible voices/256 GM2 compatible sounds)

**Drum Sets:** 26 Drum Sets (11 XG compatible + 9 GM2 compatible)

**Multitimbral parts:** 19

**Compatibility:** GM2, GS, XG Lite

**Display type:** New large backlit custom display

**Panel controls:** VOLUME knob, ACCOMP/KEYBOARD BALANCE buttons, TEMPO/DATA buttons, BENDER/MODULATION lever, FAMILY buttons, SELECT buttons, numeric buttons [0]~[9], 8 assignable TONE buttons, 12 ORIENTAL SCALE buttons, 3 SCALE MEMORY buttons

**Music Styles:** 198 Styles in Flash memory (99 factory + 99 changeable)

**One Touch:** 2 x 99

**Orchestrator:** 3 levels: Drum&Bass, Combo, Full Band

**LOCK functions (setting filters x10):** STYLE, TONE, TEMPO, TRANSPOSE, MONO/PORTAMENTO

**Songs:** Realtime SMF player

16-track Recorder: 4 easy modes (ALL, Keyboard, Single, Punch In/Out)

**Flash Memory:** For Music Styles, User Program sets and songs

**User Programs:** 200

**LOCK functions:** (Setting filters x10) STYLE, TONE, TEMPO, TRANSPOSE, MONO/PORT

**Effects:** Reverb: 8 types, Chorus: 8 types, Multi-FX: 47 types

**Data storage:** FDD 3.5" 2HD/2DD (Styles, Songs/SMF, User Programs), File save & load from PC via USB (Styles, Songs, User Programs)

**Metronome:** Time Signature setting (1/4~9/4, 1/8~9/8), Volume setting

**Other functions:** 3 easy modes: Piano/Solo, Arranger/Band, Pianist, Music Assistant: 126 settings, Split (2 Tones: Split [L] + Main [R]), Dual (2 Tones: Main + Dual), Melody Intelligence: 18 types, Octave (-4~4), User Transpose (-12~12)/Glbl Transpose (-6~5), V-Link  
System updates: Yes

**Connections:** USB: MIDI communication and file transfer, MIDI IN, OUT

**Outputs:** L/Mono, Right (1/4" phone jacks), Phones 1/2, DC IN (adapter)

**Others:** Output Power: 10W+10W with "Digital Bass Enhancer", Stereo Speakers: x ø13cm, Bass Reflex

**Power supply:** 12V/3.5A

**Dimensions:** 1020 x 355 x 132 mm

**Weight:** 8kg

**Supplied accessories:** Owner's Manual, PSB-4U adapter, music rest, USB cable, CD-ROM with USB driver files

**Note:** Specifications are subject to change without prior notice.

### Thanks

Roland Corporation wishes to express gratitude and thanks to all persons who have been involved in the preparation of the Oriental Drum Sets, Oriental Music Styles and Demo Songs for the EXR-40 OR Interactive Arranger.

Special thanks go to:

**Mr. Emmanuel G. Chnarakis**

for his important and valuable co-operation and enthusiasm for the development of the EXR-40 OR

**Mr. Abdallah George and Mr. Cherif Cotta**

for their precious advice and support

**Mr. Mohamed Raheem**

for authorizing Roland Corporation to use his famous composition "Leh Bey Dari" as demo song in the EXR-40 OR





# 19. Lists

## Tones selectable via the front panel

Tone no.	PC	CC00	CC32	Name	Family	Tone no.	PC	CC00	CC32	Name	Family	Tone no.	PC	CC00	CC32	Name	Family
1	1	8	2	StPiano1	PIANO	82	17	1	2	Organ101	ORGAN	163	121	6	2	PickScrp	E.GUITAR
2	1	16	2	EuropeanPf	PIANO	83	17	7	2	DtndOr1	ORGAN	164	33	0	2	AcstcBss	BASS
3	4	0	2	Piano 2	PIANO	84	17	8	2	TrmOrgn	ORGAN	165	33	1	2	Ac.Bass1	BASS
4	4	0	2	Honkytnk	PIANO	85	17	9	2	Organ109	ORGAN	166	34	0	2	FngdrBss	BASS
5	1	0	2	Piano 1	PIANO	86	17	17	2	60sOrgn2	ORGAN	167	34	2	2	JazzBass	BASS
6	7	3	0	StPiano2	PIANO	87	17	18	2	60sOrgn3	ORGAN	168	34	3	2	FngdrBss3	BASS
7	3	0	2	Piano 3	PIANO	88	17	31	2	PopOrgn	ORGAN	169	35	0	2	PckdBass	BASS
8	3	1	2	MIDI EP1	PIANO	89	17	32	2	RockOrgn	ORGAN	170	36	0	2	FrtLbSb	BASS
9	3	2	2	MIDI EP2	PIANO	90	17	33	2	Even Bar	ORGAN	171	37	0	2	SlpBass1	BASS
10	3	8	2	StPiano3	PIANO	91	17	40	2	OrganBss	ORGAN	172	39	0	2	SynBass1	BASS
11	4	8	2	OldUpgrt	PIANO	92	18	1	2	Organ201	ORGAN	173	39	16	2	ResoSMBs	BASS
12	5	0	2	E.Piano1	E.PIANO	93	18	8	2	ChorsOr2	ORGAN	174	39	22	2	Sqr Bass	BASS
13	5	8	2	StSortEP	E.PIANO	94	18	10	2	Dtnd Or2	ORGAN	175	33	2	2	Ac.Bass2	BASS
14	5	47	2	Pro EP 3	E.PIANO	95	18	32	2	PerOrg2	ORGAN	176	33	3	2	Ac.Bass3	BASS
15	5	48	2	Wurlly	E.PIANO	96	20	16	2	ChrchOr3	ORGAN	177	34	1	2	FngdrBss2	BASS
16	6	10	2	EPLegend	E.PIANO	97	21	16	2	PuffOrgn	ORGAN	178	34	4	2	FngdrBss4	BASS
17	6	24	2	HardFMPEP	E.PIANO	98	21	16	2	AccrdnC1	ACCORDN	180	35	3	2	Pckd Bss2	BASS
18	6	32	2	EP Phase	E.PIANO	99	83	112	2	AccrdnC2	ACCORDN	181	35	8	2	Mt PckBss	BASS
19	5	16	2	FM+SA EP	E.PIANO	100	83	114	2	Accrdn3L	ACCORDN	182	36	1	2	FrtLbBss3	BASS
20	5	24	2	60sEPno	E.PIANO	101	83	115	2	Accrdn4L	ACCORDN	183	36	2	2	FrtLbBss4	BASS
21	5	25	2	Hard EP	E.PIANO	102	83	116	2	Accrdn1	ACCORDN	184	36	3	2	FrtLbBss5	BASS
22	5	26	2	MellowEP	E.PIANO	103	85	116	2	Accrdn2	ACCORDN	185	36	4	2	SnFrtrLs	BASS
23	6	0	2	E.Piano2	E.PIANO	104	86	116	2	JVAccord	ACCORDN	186	36	5	2	MrsSmooth	BASS
24	6	8	2	Dtnd EP2	E.PIANO	105	22	0	2	AccrdnFr	ACCORDN	187	36	8	2	FrtLbSss	BASS
25	6	16	2	St.FM EP	E.PIANO	106	22	8	2	AccrdnIt	ACCORDN	188	36	8	2	FrtLbSss	BASS
26	100	5	2	Nylon+EP	E.PIANO	107	24	0	2	Bandtheon	ACCORDN	189	37	8	2	ResoSlap	BASS
27	7	24	2	Harpst	E.PIANO	108	23	0	2	Harmonic	ACCORDN	190	38	0	2	SynBss101	BASS
28	7	16	2	StHarpst	KEYBOARD	109	23	0	2	Harmonic2	ACCORDN	191	39	1	2	JunoBass	BASS
29	8	0	2	Clav.	KEYBOARD	110	22	16	2	JV-Acc1	ACCORDN	192	39	2	2	106Bass	BASS
30	8	8	2	CompClav	KEYBOARD	111	22	17	2	JV-Acc2	ACCORDN	193	39	3	2	AcidBass	BASS
31	7	0	2	HarpSchtr	KEYBOARD	112	25	0	2	NylonStl	GUITAR	194	39	8	2	TeknBass	BASS
32	7	8	2	Clpd Hps	KEYBOARD	113	25	24	2	Velohrmx	GUITAR	195	39	9	2	ClavBss	BASS
33	8	39	2	PulsClav	KEYBOARD	114	26	9	2	Nyln+Stl	GUITAR	196	39	10	2	Hammer	BASS
34	9	0	2	Celesta	CHR PERC	115	25	49	2	Regnt Gt	GUITAR	197	39	19	2	PopSynBss	BASS
35	11	0	2	MusicBox	CHR PERC	116	25	49	2	FlnmcoGt	GUITAR	198	39	20	2	LghtSnbS	BASS
36	12	0	2	VibraPhn	CHR PERC	117	26	8	2	StStrGt	GUITAR	199	39	21	2	FatTBssS	BASS
37	13	0	2	Marimba	CHR PERC	118	26	8	2	12-strGt	GUITAR	200	39	23	2	SynBss2	BASS
38	14	0	2	Xylophone	CHR PERC	119	26	16	2	Mandolin	GUITAR	201	39	24	2	ModBss	BASS
39	15	0	2	TubIBell	CHR PERC	120	25	8	2	Ukulele	GUITAR	202	39	25	2	Seq Bass	BASS
40	99	2	2	StCvyst	CHR PERC	121	25	16	2	NylonGto	GUITAR	203	40	0	2	BeefMBs	BASS
41	99	4	2	LoudGlock	CHR PERC	122	25	16	2	NylonGto	GUITAR	204	40	1	2	XWr Bass	BASS
42	99	16	2	ChriBell	CHR PERC	123	26	32	2	NylonG2	GUITAR	205	40	2	2	RubrBss	BASS
43	113	0	2	TnkIBell	CHR PERC	124	26	33	2	SteelG2	GUITAR	206	40	3	2	SH101Bss1	BASS
44	0	2	2	Gicknspi	CHR PERC	125	32	0	2	StHBody	GUITAR	207	40	8	2	SH101Bss2	BASS
45	12	1	2	HardVibe	CHR PERC	126	32	16	2	AcGHrmx	GUITAR	208	40	9	2	MldBass	BASS
46	12	8	2	StVlbrap	CHR PERC	127	100	0	2	Atmspher	GUITAR	209	40	16	2	DetunBss	BASS
47	13	8	2	StMarimb	CHR PERC	128	100	0	2	NylnHarp	GUITAR	210	40	17	2	Str Slap	BASS
48	13	16	2	Barafon	CHR PERC	129	121	0	2	GfFrtnoz	GUITAR	211	40	18	2	BassSlid	BASS
49	13	17	2	Barafon2	CHR PERC	130	27	0	2	Jazz Gt.	E.GUITAR	212	40	19	2	StringOct	STRINGS
50	13	24	2	Log drum	CHR PERC	131	27	8	2	PedalSl	E.GUITAR	213	40	20	2	StStrngs	STRINGS
51	15	8	2	ChrchBell	CHR PERC	132	28	4	2	CleanGt2	E.GUITAR	214	40	21	2	StSlwStr	STRINGS
52	15	9	2	Carillon	CHR PERC	133	28	4	2	JCClnGt	E.GUITAR	215	40	29	2	LegtoStr	STRINGS
53	99	0	2	Crystal	CHR PERC	134	28	23	2	MidTneGT	E.GUITAR	216	121	2	2	SuspnsStr	STRINGS
54	99	1	2	SynMailt	CHR PERC	135	29	0	2	Muted Gt	E.GUITAR	217	121	5	2	PzccStr	STRINGS
55	99	3	2	RfdGlock	CHR PERC	136	30	0	2	OvrndvGt	E.GUITAR	218	11	116	2	StrngOct	STRINGS
56	99	5	2	GicknChm	CHR PERC	137	31	0	2	Dist. Gt	E.GUITAR	219	49	16	2	StStrngs	STRINGS
57	99	6	2	ChriBells	CHR PERC	138	31	16	2	Power Gt	E.GUITAR	220	50	10	2	StSlwStr	STRINGS
58	99	7	2	XmasBell	CHR PERC	139	27	1	2	CleanGt.	E.GUITAR	221	50	8	2	LegtoStr	STRINGS
59	99	8	2	VbrBells	CHR PERC	140	27	2	2	OpenGt2	E.GUITAR	222	51	0	2	SuspnsStr	STRINGS
60	99	9	2	DigiBell	CHR PERC	141	28	0	2	ChorusGt1	E.GUITAR	223	45	9	2	PzccStr	STRINGS
61	99	17	2	AirBells	CHR PERC	142	28	8	2	ChorusGt2	E.GUITAR	224	46	0	2	StrngOct	STRINGS
62	99	18	2	BellHarp	CHR PERC	143	28	8	2	ChorusGt1	E.GUITAR	225	46	116	2	StStrngs	STRINGS
63	99	19	2	Gamelimb	CHR PERC	144	28	48	2	CleanGt3	E.GUITAR	226	41	116	2	StSlwStr	STRINGS
64	17	116	2	OROrgn1	ORGAN	145	29	1	2	Mt DstBss	E.GUITAR	227	41	0	2	Violin	STRINGS
65	21	116	2	OROrgn2	ORGAN	146	29	8	2	Funk Pop	E.GUITAR	228	41	8	2	SlwVioln	STRINGS
66	17	0	2	Organ 2	ORGAN	147	29	16	2	Funk Gt2	E.GUITAR	229	42	0	2	Viola	STRINGS
67	17	0	2	Organ 1	ORGAN	148	29	24	2	Jazz Man	E.GUITAR	230	43	0	2	Cello	STRINGS
68	17	10	2	R&Borgan	ORGAN	149	30	4	2	Gt Pinch	E.GUITAR	231	44	0	2	Contrbss	STRINGS
69	17	34	2	CoolOrgn	ORGAN	150	31	1	2	Dist.Gt2	E.GUITAR	232	56	10	2	DoubIHIt	STRINGS
70	17	16	2	60sOrgn1	ORGAN	151	31	2	2	Dazed Gt	E.GUITAR	233	41	1	2	Violin2	STRINGS
71	17	24	2	ChseOrgn	ORGAN	152	31	8	2	Fdbck Gt	E.GUITAR	234	41	9	2	SlVioln2	STRINGS
72	18	9	2	PercOrg1	ORGAN	153	31	9	2	FdbckGt2	E.GUITAR	235	42	1	2	Cello2	STRINGS
73	19	0	2	Organ 3	ORGAN	154	31	17	2	PowerGt2	E.GUITAR	237	45	0	2	Trem Str	STRINGS
74	19	8	2	RotyOrg	ORGAN	155	31	18	2	5th Dist	E.GUITAR	238	45	8	2	SlwTrmol	STRINGS
75	19	14	2	RotyOr5	ORGAN	156	31	24	2	RockRhyt	E.GUITAR	239	49	0	2	String2	STRINGS
76	19	26	2	RotyOrF	ORGAN	157	31	25	2	RockRhy2	E.GUITAR	240	49	1	2	Orchstr2	STRINGS
77	20	0	2	ChrchOr1	ORGAN	158	31	26	2	DstRtmGT	E.GUITAR	241	49	8	2	Orchstr1	STRINGS
78	20	8	2	ChrchOr2	ORGAN	159	32	8	2	GfFdbck	E.GUITAR	242	49	9	2	Orchstr2	STRINGS
79	20	24	2	OrgnFle	ORGAN	160	121	1	2	GTCNOz2	E.GUITAR	243	49	10	2	TremOrch	STRINGS
80	20	32	2	TrmFlute	ORGAN	161	121	3	2	GTCNOz1	E.GUITAR	244	49	8	2	Orchstr1	STRINGS
81	21	0	2	ReedOrgn	ORGAN	162	121	4	2	DstCutnz	E.GUITAR	245	49	10	2	TremOrch	STRINGS

Roland EXR-40 OR

Tone no.	PC	CC00	CC32	Name	Family	Tone no.	PC	CC00	CC32	Name	Family	Tone no.	PC	CC00	CC32	Name	Family
244	49	11	2	ChoirStr	STRINGS	333	64	17	2	VeloBrss2	SYNBASS	422	103	2	2	Echo Pan	PAD
245	49	24	2	VeloStr	STRINGS	334	63	1	2	PolyBrss	SYNBASS	423	103	3	2	EchoPan2	PAD
246	49	40	2	60String	STRINGS	335	63	3	2	SYBrass	SYNBASS	424	103	4	2	BigPannr	PAD
247	50	0	2	SlwString	STRINGS	336	63	4	2	JunoBrss	SYNBASS	425	103	6	2	WtrPiano	PAD
248	50	1	2	SlwStrn2	STRINGS	337	63	8	2	SynBrss3	SYNBASS	426	104	1	2	StrThme2	PAD
249	50	9	2	WarmStrn	STRINGS	338	63	9	2	OuakBrss	SYNBASS	427	106	17	2	JV-Bouz1	ETHNIC
250	51	1	2	OBStrings	STRINGS	339	63	18	2	OctvBr	SYNBASS	428	106	18	2	JV-Bouz2	ETHNIC
251	51	8	2	SynStrn1	STRINGS	340	64	0	2	SynBrss2	SYNBASS	429	106	19	2	JV-Bouz3	ETHNIC
252	51	8	2	70s Str1	STRINGS	341	64	1	2	SoftBrss	SYNBASS	430	106	20	2	JV-Bouz4	ETHNIC
253	51	9	2	70s Str2	STRINGS	342	64	8	2	SynBrss4	SYNBASS	431	106	21	2	BouzBag1	ETHNIC
254	52	0	2	SynStrn2	STRINGS	343	64	16	2	VeloBrss1	SYNBASS	432	106	22	2	BouzBag2	ETHNIC
255	52	1	2	SynStrn3	STRINGS	344	82	4	2	Big Lead	SYN LEAD	433	106	116	2	Bouzouki	ETHNIC
256	56	0	2	Orch Hit	STRINGS	345	81	0	2	Sqr Wave	SYN LEAD	434	107	116	2	BzktTrm	ETHNIC
257	56	1	2	Bass Hit	STRINGS	346	81	3	2	MellowFM	SYN LEAD	435	108	116	2	BzktTrVm	ETHNIC
258	56	2	2	6th Hgt	STRINGS	347	81	4	2	CC Solo	SYN LEAD	436	16	0	2	Santur	ETHNIC
259	56	3	2	Euro Hit	STRINGS	348	81	17	2	260 Sync	SYN LEAD	437	47	0	2	Harp	ETHNIC
260	56	4	2	TechHit	STRINGS	349	82	0	2	Saw Wave	SYN LEAD	438	76	8	2	Kawala	ETHNIC
261	56	8	2	ImpctHit	STRINGS	350	82	2	2	PulseSaw	SYN LEAD	439	100	116	2	Kawala2	ETHNIC
262	56	9	2	PhlyHit	STRINGS	351	82	6	2	GR-300	SYN LEAD	440	101	116	2	Kawala1	ETHNIC
263	56	16	2	LoFrave	STRINGS	352	82	16	2	WaspySyn	SYN LEAD	441	102	116	2	KawlaOct	ETHNIC
264	53	8	2	St.Choir	VOCAL	353	82	46	2	SegncdSw	SYN LEAD	442	103	116	2	KwIOctVm	ETHNIC
265	54	40	2	Humming	VOCAL	354	83	0	2	SnCallpe	SYN LEAD	443	111	116	2	Rababa	ETHNIC
266	54	0	2	VoiceOoh	VOCAL	355	83	2	2	PurPantld	SYN LEAD	444	118	116	2	Nay	ETHNIC
267	55	0	2	SynVox	VOCAL	356	85	0	2	Charang	SYN LEAD	445	119	116	2	NayOct	ETHNIC
268	86	0	2	Solo Vox	VOCAL	357	85	1	2	WireLead	SYN LEAD	446	120	116	2	NayOctVm	ETHNIC
269	53	0	2	ChoirAah	VOCAL	358	85	8	2	DistLead	SYN LEAD	447	122	116	2	Mizmar	ETHNIC
270	53	9	2	MelloChr	VOCAL	359	81	1	2	Square	SYN LEAD	448	123	116	2	MizmrOct	ETHNIC
271	53	32	2	ChraAhs2	VOCAL	360	81	5	2	HollowMin	SYN LEAD	449	124	116	2	MizmrTrv	ETHNIC
272	55	19	2	SynVoice	VOCAL	361	81	6	2	Shmoog	SYN LEAD	450	126	116	2	MizmarDu	ETHNIC
273	55	19	2	AnaVoice	VOCAL	362	81	6	2	LMsquare	SYN LEAD	451	127	116	2	Arghool	ETHNIC
274	100	3	2	Harpvox	VOCAL	363	81	8	2	SineWave	SYN LEAD	452	78	0	2	Shakuhch	ETHNIC
275	100	4	2	HllwRels	VOCAL	364	81	16	2	DistSqr	SYN LEAD	453	105	0	2	Sitar	ETHNIC
276	66	116	2	OrienSax	SAX	365	82	1	2	P5 Saw	SYN LEAD	454	106	0	2	Banjo	ETHNIC
277	67	8	2	BlwTenor	SAX	366	82	3	2	FelmeGR	SYN LEAD	455	106	8	2	Rabab	ETHNIC
278	67	7	2	BrthTnr	SAX	367	82	5	2	VeloLead	SYN LEAD	456	106	24	2	Oud	ETHNIC
279	65	0	2	SoprnSax	SAX	368	82	7	2	LA Saw	SYN LEAD	457	110	116	2	Oud1Trem	ETHNIC
280	66	0	2	Alto Sax	SAX	369	82	8	2	Dr. Solo	SYN LEAD	458	112	116	2	Oud1	ETHNIC
281	67	0	2	TenoSax	SAX	370	82	9	2	Saw Wave2	SYN LEAD	459	113	116	2	Oud2	ETHNIC
282	68	0	2	BarnSax	SAX	371	82	10	2	Saw	SYN LEAD	460	114	116	2	Oud2Trem	ETHNIC
283	65	8	2	SoprSax2	SAX	372	82	36	2	NatLead	SYN LEAD	461	115	116	2	Oud1TrVm	ETHNIC
284	66	1	2	AltoSax2	SAX	373	83	1	2	VentSyn	SYN LEAD	462	116	116	2	Oud2TrVm	ETHNIC
285	66	8	2	HyprAlto	SAX	374	84	0	2	Chfrld	SYN LEAD	463	117	116	2	OudOct	ETHNIC
286	67	1	2	TennSax2	SAX	375	87	0	2	5thSawWv	SYN LEAD	464	107	0	2	Shamisen	ETHNIC
287	67	9	2	SprTenor	SAX	376	87	1	2	Bghvtes	SYN LEAD	465	108	0	2	Koto	ETHNIC
288	74	48	2	FluteVib	WIND	377	88	0	2	Bss&Lead	SYN LEAD	466	108	16	2	Kanoon	ETHNIC
289	73	0	2	Piccolo	WIND	378	88	1	2	Big&Raw	SYN LEAD	467	87	115	2	Kncoun3St	ETHNIC
290	69	0	2	Oboe	WIND	379	88	2	2	Fat&Pkly	SYN LEAD	468	87	116	2	KanounSt	ETHNIC
291	71	0	2	Bassoon	WIND	380	88	7	2	DiylLead	SYN LEAD	469	93	115	2	Kanoun3	ETHNIC
292	72	1	2	Clarinet	WIND	381	91	0	2	PolySyn	POLY SYN	470	93	116	2	Kn1TrVm	ETHNIC
293	76	0	2	PanFlute	WIND	382	91	1	2	80sPlySn	POLY SYN	471	94	116	2	Kn2TrVm	ETHNIC
294	79	0	2	Whistle	WIND	383	97	0	2	Ice Rain	POLY SYN	472	95	115	2	Kanoun3	ETHNIC
295	70	0	2	EnglHorn	WIND	384	100	1	2	WarmAtms	POLY SYN	473	95	116	2	Kanoun1	ETHNIC
296	72	0	2	JzClint	WIND	385	101	0	2	Brightns	POLY SYN	474	96	116	2	Kanoun2	ETHNIC
297	72	8	2	BsClarnt	WIND	386	89	0	2	Fantasia	POLY SYN	475	97	116	2	KanounTr	ETHNIC
298	74	0	2	Recorder	WIND	387	89	1	2	Fantasia2	POLY SYN	476	99	115	2	Kanoun3Oc	ETHNIC
299	75	0	2	BotlBlw	WIND	388	97	2	2	HarmRain	POLY SYN	477	99	116	2	KncounOct	ETHNIC
300	77	0	2	Ocarina	WIND	389	97	8	2	Africnwd	POLY SYN	478	110	0	2	Bagpipe	ETHNIC
301	87	0	2	Trumpet	AC BRASS	390	97	8	2	ClavPad	POLY SYN	479	111	0	2	Fiddle	ETHNIC
302	57	8	2	FlghHorn	AC BRASS	391	98	8	2	Rave	POLY SYN	480	112	1	2	Shanal 2	ETHNIC
303	58	0	2	Trombone	AC BRASS	392	90	0	2	Warm Pad	PAD	481	16	1	2	Santur 2	ETHNIC
304	58	0	2	Tuba	AC BRASS	393	90	3	2	ThckPpad	PAD	482	16	8	2	Cimbalom	ETHNIC
305	60	0	2	MtdTrmp	AC BRASS	394	90	4	2	RortyStr	PAD	483	47	24	2	Yang Qin	ETHNIC
306	60	0	2	FrcchHrns	AC BRASS	395	90	4	2	Soft Pad	PAD	484	105	1	2	Sitar 2	ETHNIC
307	61	0	2	Brass 1	AC BRASS	396	92	0	2	SpvVoice	PAD	485	105	2	2	DnsStar	ETHNIC
308	42	116	2	Brass 2	AC BRASS	397	92	1	2	Heavenl	PAD	486	105	8	2	Tambra	ETHNIC
309	62	0	2	Brass 3	AC BRASS	398	92	3	2	Itopia	PAD	487	105	16	2	Tamboura	ETHNIC
310	62	16	2	BrssFall	AC BRASS	399	94	1	2	Tine Pad	PAD	488	106	1	2	MtdBanjo	ETHNIC
311	62	24	2	TwnTrmpt	AC BRASS	400	94	2	2	PannrPad	PAD	489	106	16	2	Gopichnt	ETHNIC
312	62	26	2	Trombn5c	AC BRASS	401	96	0	2	SweepPad	PAD	490	107	1	2	Tsugaru	ETHNIC
313	57	1	2	Trumpet2	AC BRASS	402	96	1	2	PolarPad	PAD	491	108	8	2	Taishokt	ETHNIC
314	57	2	2	Trumpet3	AC BRASS	403	96	9	2	Shwimmer	PAD	492	109	0	2	Kalimba	ETHNIC
315	57	3	2	DrkTrmpt	AC BRASS	404	98	0	2	SndtTrack	PAD	493	112	0	2	Shanal	ETHNIC
316	57	24	2	BrightTp	AC BRASS	405	100	6	2	AmbntPad	PAD	494	112	8	2	Pungi	ETHNIC
317	57	25	2	Warm Tp	AC BRASS	406	102	1	2	Goblnsn	PAD	495	112	16	2	Hichrki	ETHNIC
318	58	1	2	Trombn2	AC BRASS	407	103	5	2	ResoPnrr	PAD	496	113	8	2	Bonang	ETHNIC
319	58	2	2	Trombn3	AC BRASS	408	104	0	2	StarThme	PAD	497	113	9	2	Gender	ETHNIC
320	58	4	2	BrightTb	AC BRASS	409	90	2	2	Horn Pad	PAD	498	113	10	2	GaminGng	ETHNIC
321	59	1	2	Tuba 2	AC BRASS	410	93	5	2	Sine Pad	PAD	499	113	11	2	StGameln	ETHNIC
322	60	2	2	MtTrmpt2	AC BRASS	411	93	0	2	BowdGls	PAD	500	48	0	2	Timpani	PRCSION
323	61	1	2	Fr.Horn2	AC BRASS	412	94	0	2	MetalPad	PAD	501	115	0	2	StDrums	PRCSION
324	61	8	2	FHorns1	AC BRASS	413	95	0	2	Halo Pad	PAD	502	116	8	2	Cstncts	PRCSION
325	61	16	2	HornOrch	AC BRASS	414	96	8	2	Converge	PAD	503	117	0	2	Taiko	PRCSION
326	62	1	2	Brass 2	AC BRASS	415	96	10	2	CelstIPd	PAD	504	113	16	2	RAMACybl	PRCSION
327	62	8	2	Brass 3	AC BRASS	416	98	1	2	Ancestrl	PAD	505	114	0	2	Agogo	PRCSION
328	62	25	2	TwinBons	AC BRASS	417	98	2	2	Prologue	PAD	506	114	8	2	Atarigan	PRCSION
329	62	27	2	TmbrnSc2	AC BRASS	418	102	0	2	Gobln	PAD	507	116	0	2	Woodbck	PRCSION
330	63	0	2	SynBrss1	SYNBASS	419	102	2	2	S0sScf1	PAD	508	117	8	2	ConcrBD	PRCSION
331	63	5	2	JmpBrass	SYNBASS	420	103	0	2	EchDrops	PAD	509	117	9	2	CncrBDMt	PRCSION
332	63	16	2	Oct5nBr	SYNBASS	421	103	1	2	EthoBell	PAD	510	118	0	2	MeloTom1	PRCSION



Tone no.	PC	CC00	CC32	Name	Family
511	118	1	2	Real Tom	PRCSSION
512	118	8	2	MeloTom2	PRCSSION
513	118	9	2	Rock Tom	PRCSSION
514	119	0	2	SyntDrum	PRCSSION
515	119	8	2	808 Tom	PRCSSION
516	119	9	2	ElecPerc	PRCSSION
517	120	0	2	Rev Cym	PRCSSION
518	120	1	2	Rev Cym2	PRCSSION
519	120	8	2	Rev Snr1	PRCSSION
520	120	9	2	RevSnr 2	PRCSSION
521	120	16	2	RevKick1	PRCSSION
522	120	17	2	RevComBD	PRCSSION
523	120	24	2	RevTom 1	PRCSSION
524	120	25	2	RevTom 2	PRCSSION
525	123	2	2	Thunder	SFX
526	123	3	2	Wind	SFX
527	124	0	2	Bird	SFX
528	124	2	2	HrseGllp	SFX
529	124	3	2	Bird 2	SFX
530	125	1	2	Telphn 2	SFX
531	126	0	2	Helicptr	SFX
532	126	1	2	CarEngine	SFX
533	126	3	2	Car-Pass	SFX
534	126	5	2	Siren	SFX
535	126	6	2	Train	SFX
536	127	0	2	Applause	SFX
537	127	1	2	Laughing	SFX
538	127	2	2	Screaming	SFX
539	128	3	2	Xplosion	SFX
540	122	0	2	BritNoise	SFX
541	122	1	2	FKClick	SFX
542	123	0	2	Seashore	SFX
543	123	1	2	Rain	SFX
544	123	4	2	Stream	SFX
545	123	5	2	Bubble	SFX
546	124	1	2	Dog	SFX
547	124	4	2	Kitty	SFX
548	124	5	2	Growl	SFX
549	125	0	2	Telphn 1	SFX
550	125	2	2	DoorCrk	SFX
551	125	3	2	Door	SFX
552	125	4	2	Scratch	SFX
553	125	5	2	WndChims	SFX
554	125	7	2	Scratch2	SFX
555	126	2	2	Car-Stop	SFX
556	126	4	2	CarCrash	SFX
557	126	7	2	Jetplane	SFX
558	126	8	2	Starship	SFX
559	126	9	2	BurstNs	SFX
560	127	3	2	Punch	SFX
561	127	4	2	HeartBt	SFX
562	127	5	2	Footstps	SFX
563	127	6	2	Applaus2	SFX
564	128	0	2	Gun Shot	SFX
565	128	1	2	MachnGun	SFX
566	128	2	2	Laserqun	SFX
567	1	0	2	STNDARD1	DRUMS*
568	2	0	2	STNDARD2	DRUMS*
569	9	0	2	ROOM	DRUMS*
570	10	0	2	Hip Hop	DRUMS*
571	11	0	2	Drum'Bss	DRUMS*
572	12	0	2	TechHous	DRUMS*
573	14	0	2	R&B	DRUMS*
574	17	0	2	POWER	DRUMS*
575	26	0	2	TR808909	DRUMS*
576	27	0	2	DANCE	DRUMS*
577	31	0	2	NewTR909	DRUMS*
578	33	0	2	Jazz Kit	DRUMS*
579	41	0	2	BRUSH	DRUMS*
580	49	0	2	ORCHSTRA	DRUMS*
581	50	0	2	ETHNIC	DRUMS*
582	117	0	4	E-40	DRUMS*
583	117	0	1	Orient 1	DRUMS*
584	117	0	2	Orient 2	DRUMS*
585	117	0	3	Orient 3	DRUMS*
586	118	0	4	OrMix 1	DRUMS*
587	119	0	4	OrMix 2	DRUMS*
588	3	0	2	STNDARD3	DRUMS*
589	25	0	2	ELECTRNC	DRUMS*
590	34	0	2	JAZZ	DRUMS*
591	51	0	2	KICK&SNR	DRUMS*
592	57	0	2	SFX	DRUMS*

(\*) See below for details.





PC 50 (CG2 Z)  
ETHNIC

(C7)	96		(Catsaa Down)
	97		Claves
	98		Woodblock
	99		Woodblock
	100		.....
	101	002	.....
	103	104	.....
	105	106	.....
	107		.....
	108	009	.....
	110		.....
	112	111	.....
	113		.....
	114		.....
	115	116	.....
	117		.....
	119	118	.....
	120		.....
	121		.....
	122	123	.....
	124		.....
	125		.....
	126		.....
	127		.....
	128		.....
	129		.....
	130		.....
	131		.....
	132		.....
	133		.....
	134		.....
	135		.....
	136		.....
	137		.....
	138		.....
	139		.....
	140		.....
	141		.....
	142		.....
	143		.....
	144		.....
	145		.....
	146		.....
	147		.....
	148		.....
	149		.....
	150		.....
	151		.....
	152		.....
	153		.....
	154		.....
	155		.....
	156		.....
	157		.....
	158		.....
	159		.....
	160		.....
	161		.....
	162		.....
	163		.....
	164		.....
	165		.....
	166		.....
	167		.....
	168		.....
	169		.....
	170		.....
	171		.....
	172		.....
	173		.....
	174		.....
	175		.....
	176		.....
	177		.....
	178		.....
	179		.....
	180		.....
	181		.....
	182		.....
	183		.....
	184		.....
	185		.....
	186		.....
	187		.....
	188		.....
	189		.....
	190		.....
	191		.....
	192		.....
	193		.....
	194		.....
	195		.....
	196		.....
	197		.....
	198		.....
	199		.....
	200		.....
	201		.....
	202		.....
	203		.....
	204		.....
	205		.....
	206		.....
	207		.....
	208		.....
	209		.....
	210		.....
	211		.....
	212		.....
	213		.....
	214		.....
	215		.....
	216		.....
	217		.....
	218		.....
	219		.....
	220		.....
	221		.....
	222		.....
	223		.....
	224		.....
	225		.....
	226		.....
	227		.....
	228		.....
	229		.....
	230		.....
	231		.....
	232		.....
	233		.....
	234		.....
	235		.....
	236		.....
	237		.....
	238		.....
	239		.....
	240		.....
	241		.....
	242		.....
	243		.....
	244		.....
	245		.....
	246		.....
	247		.....
	248		.....
	249		.....
	250		.....
	251		.....
	252		.....
	253		.....
	254		.....
	255		.....
	256		.....
	257		.....
	258		.....
	259		.....
	260		.....
	261		.....
	262		.....
	263		.....
	264		.....
	265		.....
	266		.....
	267		.....
	268		.....
	269		.....
	270		.....
	271		.....
	272		.....
	273		.....
	274		.....
	275		.....
	276		.....
	277		.....
	278		.....
	279		.....
	280		.....
	281		.....
	282		.....
	283		.....
	284		.....
	285		.....
	286		.....
	287		.....
	288		.....
	289		.....
	290		.....
	291		.....
	292		.....
	293		.....
	294		.....
	295		.....
	296		.....
	297		.....
	298		.....
	299		.....
	300		.....
	301		.....
	302		.....
	303		.....
	304		.....
	305		.....
	306		.....
	307		.....
	308		.....
	309		.....
	310		.....
	311		.....
	312		.....
	313		.....
	314		.....
	315		.....
	316		.....
	317		.....
	318		.....
	319		.....
	320		.....
	321		.....
	322		.....
	323		.....
	324		.....
	325		.....
	326		.....
	327		.....
	328		.....
	329		.....
	330		.....
	331		.....
	332		.....
	333		.....
	334		.....
	335		.....
	336		.....
	337		.....
	338		.....
	339		.....
	340		.....
	341		.....
	342		.....
	343		.....
	344		.....
	345		.....
	346		.....
	347		.....
	348		.....
	349		.....
	350		.....
	351		.....
	352		.....
	353		.....
	354		.....
	355		.....
	356		.....
	357		.....
	358		.....
	359		.....
	360		.....
	361		.....
	362		.....
	363		.....
	364		.....
	365		.....
	366		.....
	367		.....
	368		.....
	369		.....
	370		.....
	371		.....
	372		.....
	373		.....
	374		.....
	375		.....
	376		.....
	377		.....
	378		.....
	379		.....
	380		.....
	381		.....
	382		.....
	383		.....
	384		.....
	385		.....
	386		.....
	387		.....
	388		.....
	389		.....
	390		.....
	391		.....
	392		.....
	393		.....
	394		.....
	395		.....
	396		.....
	397		.....
	398		.....
	399		.....
	400		.....
	401		.....
	402		.....
	403		.....
	404		.....
	405		.....
	406		.....
	407		.....
	408		.....
	409		.....
	410		.....
	411		.....
	412		.....
	413		.....
	414		.....
	415		.....
	416		.....
	417		.....
	418		.....
	419		.....
	420		.....
	421		.....
	422		.....
	423		.....
	424		.....
	425		.....
	426		.....
	427		.....
	428		.....
	429		.....
	430		.....
	431		.....
	432		.....
	433		.....
	434		.....
	435		.....
	436		.....
	437		.....
	438		.....
	439		.....
	440		.....
	441		.....
	442		.....
	443		.....
	444		.....
	445		.....
	446		.....
	447		.....
	448		.....
	449		.....
	450		.....
	451		.....
	452		.....
	453		.....
	454		.....
	455		.....
	456		.....
	457		.....
	458		.....
	459		.....
	460		.....
	461		.....
	462		.....
	463		.....
	464		.....
	465		.....
	466		.....
	467		.....
	468		.....
	469		.....
	470		.....
	471		.....
	472		.....
	473		.....
	474		.....
	475		.....
	476		.....
	477		.....
	478		.....
	479		.....
	480		.....
	481		.....
	482		.....
	483		.....
	484		.....
	485		.....
	486		.....
	487		.....
	488		.....
	489		.....
	490		.....
	491		.....
	492		.....
	493		.....
	494		.....
	495		.....
	496		.....
	497		.....
	498		.....
	499		.....
	500		.....

ORIENTAL	PC 117 (CC32: 1) E-40 MODIFIED	PC 117 (CC32: 1) ORIENT 1	PC 118 (CC32: 2) ORIENT 2	PC 117 (CC32: 3) ORIENT 3	PC 118 (CC32: 4) OR MIX 1	PC 119 (CC32: 4) OR MIX 2
C-1						
1					HighLife B/O	Tempari
2					Rek 2 Rim 2	Tempari
3					Rek 2 Rim 1	Share Pagi
4					Rek 2 Tak 1	Concert 5r
5					Rek 2 Tak 2	Concert 5r
6					Rek 2 Tak 1	Jingle Bell
7					Table Ge	Bell Tree
8					Table Na	Bar Chimes
9					Table Te	Wedako
10					Table Tun	Small Gong
11					Djembe rim	Gamelan Gong
12					Popak 35	Udo Tong
13					Popak 36	82ZBDRum2
14					Popak 37 1	Side Stick
15					Popak 38 1	82ZShare
16					Popak 39 1	Hand Clap
17					Popak 40 1	82ZShare2
18					Popak 41 1	Real Tom 6
19					Popak 42	82ZShare
20					Popak 43	Real Tom 6
21					Popak 44	Real Tom 6
22					Popak 45	Real Tom 4
23					Popak 46	82ZShareH8
24					Popak 47	Real Tom 4
25					Popak 48	Real Tom 1
26					Popak 49	Crash B
27					Popak 50	Real Tom 1
28					Popak 51	Real Tom 1
29					Popak 52	Real Tom 1
30					Popak 53	Real Tom 1
31					Popak 54	Real Tom 1
32					Popak 55	Real Tom 1
33					Popak 56	Real Tom 1
34					Popak 57	Real Tom 1
35					Popak 58	Real Tom 1
36					Popak 59	Real Tom 1
37					Popak 60	Real Tom 1
38					Popak 61	Real Tom 1
39					Popak 62	Real Tom 1
40					Popak 63	Real Tom 1
41					Popak 64	Real Tom 1
42					Popak 65	Real Tom 1
43					Popak 66	Real Tom 1
44					Popak 67	Real Tom 1
45					Popak 68	Real Tom 1
46					Popak 69	Real Tom 1
47					Popak 70	Real Tom 1
48					Popak 71	Real Tom 1
49					Popak 72	Real Tom 1
50					Popak 73	Real Tom 1
51					Popak 74	Real Tom 1
52					Popak 75	Real Tom 1
53					Popak 76	Real Tom 1
54					Popak 77	Real Tom 1
55					Popak 78	Real Tom 1
56					Popak 79	Real Tom 1
57					Popak 80	Real Tom 1
58					Popak 81	Real Tom 1
59					Popak 82	Real Tom 1
60					Popak 83	Real Tom 1
61					Popak 84	Real Tom 1
62					Popak 85	Real Tom 1
63					Popak 86	Real Tom 1
64					Popak 87	Real Tom 1
65					Popak 88	Real Tom 1
66					Popak 89	Real Tom 1
67					Popak 90	Real Tom 1
68					Popak 91	Real Tom 1
69					Popak 92	Real Tom 1
70					Popak 93	Real Tom 1
71					Popak 94	Real Tom 1
72					Popak 95	Real Tom 1
73					Popak 96	Real Tom 1
74					Popak 97	Real Tom 1
75					Popak 98	Real Tom 1
76					Popak 99	Real Tom 1
77					Popak 100	Real Tom 1
78					Popak 101	Real Tom 1
79					Popak 102	Real Tom 1
80					Popak 103	Real Tom 1
81					Popak 104	Real Tom 1
82					Popak 105	Real Tom 1
83					Popak 106	Real Tom 1
84					Popak 107	Real Tom 1
85					Popak 108	Real Tom 1
86					Popak 109	Real Tom 1
87					Popak 110	Real Tom 1
88					Popak 111	Real Tom 1
89					Popak 112	Real Tom 1
90					Popak 113	Real Tom 1
91					Popak 114	Real Tom 1
92					Popak 115	Real Tom 1
93					Popak 116	Real Tom 1
94					Popak 117	Real Tom 1
95					Popak 118	Real Tom 1
96					Popak 119	Real Tom 1
97					Popak 120	Real Tom 1

	PC: 116 [CC32: 1] E-40 MODIFIED	PC: 116 [CC32: 2] ORIENTAL PERC. 1	PC: 116 [CC32: 3] ORIENTAL PERC. 2	PC: 116 [CC32: 4] ORIENTAL 3	PC: 116 [CC32: 4] ORIENTAL MIX 1	PC: 116 [CC32: 4] ORIENTAL MIX 2
(C7) 96	Hand Clap 2 Mono (E-40)	Zaghrouta 2 End	Zaghrouta 2 End	Mazhar Dom	Do's Rim 2	Sagat Mid
97	...	...	...	Mazhar Tak	Do's Dom st.	TablaNurDom1
98	...	...	...	Mazhar Sak	TablaNurDom	Sagat Hi
99	...	...	...	Mazhar Brass	Do's Sak st.	TablaNurTak1
100	...	...	...	Sagat Mid	TablaNurRim	Sagat Sak
101	...	...	...	Sagat Hi	TablaNurTak	Hager 1
102	...	...	...	Sagat Closed	TablaNurSak	Zir 1
103	...	...	...	Sagat Sak	BassSlideFX	Nakrazhan 1
104	...	...	...	Do's Tak	BassSlideFX	ZaghroutaSim
105	...	...	...	Do's Dom	ZaghroutaSim2	Nakrazhan 2
106	...	...	...	Do's Sak	Zir 1	ZahmoutaEd1
107	...	...	...	Do's Rim 1	ZaghroutaEd2	ZaghroutaSim2
108	...	...	...	Do's Rim 2	NewHiBongo	ZaghroutaEd2
109	...	...	...	Do's Dom st.	NewLoBongo	TR-707 BD
110	...	...	...	TablaNurDom	NewCongaSlp	TR-909 BD2
111	...	...	...	Do's Sak st.	NewCongaSlp	Mix Kick
112	...	...	...	TablaNurRim	NewLoConga	82Rm8Drum1
113	...	...	...	TablaNurTak	NewTmbHh	8255Snare1
114	...	...	...	TablaNurSak	NewTmbLo	8255Snare1
115	...	...	...	BassSlideFX	Hager 1	House SD
116	...	...	...	BassSlideFX	Hager 1	Rev Snare
117	...	...	...	ZaghroutaSim2	Jingle Bell	
118	...	...	...	Zir 1	Bell Tree	
119	...	...	...	ZaghroutaEd2	Bongo High	
120	...	...	...	NewHiBongo	Bongo Lo	
121	...	...	...	NewLoBongo	Mute H Conga	
122	...	...	...	NewCongaSlp	Conga H Opn	
123	...	...	...	NewLoConga	Conga Lo Opn	
124	...	...	...	NewHiBongo	High Tmbale	
125	...	...	...	NewTmbLo	Low Tmbale	
126	...	...	...	Hager 1	Agogo	
127	...	...	...			



# Chord Intelligence ("Md1" setting)

C	C#	D	E $\flat$	E	F
CM7	C#M7	DM7	E $\flat$ M7	EM7	FM7
C7	C#7	D7	E $\flat$ 7	E7	F7
Cm	C#m	Dm	E $\flat$ m	Em	Fm
Cm7	C#m7	Dm7	E $\flat$ m7	Em7	Fm7
CmM7	C#mM7	DmM7	E $\flat$ mM7	EmM7	FmM7
Cdim	C#dim	Ddim	E $\flat$ dim	Edim	Fdim
Cm7 (b5)	C#m7 (b5)	Dm7 (b5)	E $\flat$ m7 (b5)	Em7 (b5)	Fm7 (b5)
Caug	C#aug	Daug	E $\flat$ aug	Eaug	Faug
Csus4	C#sus4	Dsus4	E $\flat$ sus4	Esus4	Fsus4
C7sus4	C#7sus4	D7sus4	E $\flat$ 7sus4	E7sus4	F7sus4

\*= Keys you need to press to hear this chord.  
 ●= Constituent notes of this chord.



F#	G	A <sup>b</sup>	A	B <sup>b</sup>	B
F#M7	GM7	A <sup>b</sup> M7	AM7	B <sup>b</sup> M7	BM7
F#7	G7	A <sup>b</sup> 7	A7	B <sup>b</sup> 7	B7
F#m	Gm	A <sup>b</sup> m	Am	B <sup>b</sup> m	Bm
F#m7	Gm7	A <sup>b</sup> m7	Am7	B <sup>b</sup> m7	Bm7
F#mM7	GmM7	A <sup>b</sup> mM7	AmM7	B <sup>b</sup> mM7	BmM7
F#dim	Gdim	A <sup>b</sup> dim	Adim	B <sup>b</sup> dim	Bdim
F#m7 (b5)	Gm7 (b5)	A <sup>b</sup> m7 (b5)	Am7 (b5)	B <sup>b</sup> m7 (b5)	Bm7 (b5)
F#aug	Gaug	A <sup>b</sup> aug	Aaug	B <sup>b</sup> aug	Baug
F#sus4	Gsus4	A <sup>b</sup> sus4	Asus4	B <sup>b</sup> sus4	Bsus4
F#7sus4	G7sus4	A <sup>b</sup> 7sus4	A7sus4	B <sup>b</sup> 7sus4	B7sus4

★ = Keys you need to press to hear this chord.  
 ● = Constituent notes of this chord.

# MIDI Implementation Chart

[Interactive Arranger]

Model: EXR-40 OR

Date: May 2005

, Version: 1.01

Function...	Transmitted	Recognized	Remarks
Basic Channel	1~16 1~16, Off	1~16 1~16, Off	32 Parts 2 Logical Parts
Mode	Mode 3 Mode 3, 4 (M=1) *****	Mode 3 Mode 3, 4 (M=1)	*2
Note Number	0~127 *****	0~127 0~127	
Velocity	Note ON Note OFF	O X	
After Touch	Key's Ch's	O O	
Pitch Bend	O	O	*1
Control Change	0,32	O	*1
	1	O	*1
	5	O	*1
	6, 38	O	
	7	O	
	10	O	
	11	O	
	22, 23, 24, 25	O	
	64	O	
	65	X	
	66	O	
	67	O	
	84	X	
	91	O	
	93	O	
	98, 99	O	
	100, 101	O	
Program Change	O *****	O 0~127	*1 Program Number 1~128
System Exclusive	O	O	
System Common	Song Position Pointer Song Sel Tune	O X X X	
System Real Time	Clock Commands	O O	
Aux Messages	All Sounds Off Reset All Controllers Local On/Off All Notes Off Active Sense Reset	X X O X O O X	O (120, 126, 127) O (121) O O (123-125) O X
Notes			

\*1 O X is selectable  
\*2 Recognized as M=1 even if M≠1

Mode 1: OMNI ON, POLY  
Mode 3: OMNI OFF, POLY

Mode 2: OMNI ON, MONO  
Mode 4: OMNI OFF, MONO

O: Yes  
X: No

# Information

When you need repair service, call your nearest Roland Service Center or authorized Roland distributor in your country as shown below.

## AFRICA

**PHILIPPINES**  
G.A. Yurpango & Co. Inc.  
339 Gil J. Payat Avenue  
Makati, Metro Manila 1200,  
PHILIPPINES  
TEL: (02) 899 9801

**SINGAPORE**  
ARD E1 Coll, Helopolis,  
Caro 11341, EGYPT  
TEL: 20-2-417-1828

**REUNION**  
Maison FO - YAM Mareel  
25 Rue Jules Hermaun,  
Chaudron - 8779 97 491  
Ste. Clothilde Cedex,  
REUNION ISLAND  
TEL: (0262) 218-429

**SOUTH AFRICA**  
That Other Music Shop (PTY) Ltd.  
11 Melie St., Braamfontein,  
Johannesburg,  
SOUTH AFRICA  
TEL: (011) 403 1234  
FAX: (011) 403 1234

**PAUL BOLINMER (PTY) LTD.**  
17 Weckmiller Centre,  
Main Road, Clarendon 7708  
SOUTH AFRICA  
TEL: (021) 674 4030

## ASIA

**CHINA**  
Roland Shanghai Electronics  
Co., Ltd.  
5F, No. 150 Pingliang Road  
Shanghai 200090, CHINA  
TEL: (021) 5580-0880

**Roland Shanghai Electronics  
Co., Ltd.**  
BEIJING OFFICE)  
10F, No. 18 3-section, Minxuanli  
Chaoyang District Beijing  
100011 CHINA  
TEL: (010) 6426-8050

**Roland Shanghai Electronics  
Co., Ltd.**  
(GUANGZHOU OFFICE)  
2/F, No. 30 Shi You Nan Er Jie  
Yi Xiang, Wu Yang Xin Cheng,  
Guangzhou 510600, CHINA  
TEL: (020) 8736-0428

**HONG KONG**  
Tom Lee Music Co., Ltd.  
Service Division  
22-32 Pan Shan Street, Tsuen  
Wan, New Territories,  
HONG KONG  
TEL: 2415 0911

**Parsons Music Ltd.**  
8th Floor, Railway Plaza, 39  
Chatham Road South, T.S.T.,  
Kowloon, HONG KONG  
TEL: 2333 1863

**INDIA**  
Bevera Digital (India) Pvt. Ltd.  
409 Nirmala Kerdra  
Meharaj Park Compound  
Off: Dr. Eshwar Innes Road,  
Mumbai-400011, INDIA  
TEL: (022) 2493 9651

**INDONESIA**  
PT Citra Intikama  
Jl. Cideng Timur No. 151-150  
Jakarta Pusat  
INDONESIA  
TEL: (021) 6324170

**KOREA**  
Cosmos Corporation  
146-19, Sechoo-Dong,  
Sechoo Ku, Seoul, KOREA  
TEL: (02) 3486-8855

**MALAYSIA**  
Roland Asia Pacific Sdn. Bhd.  
45-1, Block C2, Jalan PUI 1/39,  
Dataran Prima, 47300 Puchong,  
Jaya, Selangor, MALAYSIA  
TEL: (03) 7865-3263

**COSTA RICA**  
JUAN Bausbach Instrumentos  
Musicales  
Ave. 1, Calle 11, Apartado 10237,  
San Jose, COSTA RICA  
TEL: 258-0211

**CURACAO**  
Zelandia Music Center Inc.  
Oranweg 30  
Curacao, Neherland Antilles  
TEL: (305) 6926866

**DOMINICAN REPUBLIC**  
Instrumentos Fernando Giraldez  
Calle Proyecto Central No. 3  
En La Esperilla  
Santo Domingo,  
Dominican Republic  
TEL: (809) 683 0305

**ECUADOR**  
Mas Musica  
Rumbaca 822 y Zaruma  
Guayaquil - Ecuador  
TEL: (593)-42302364

**EL SALVADOR**  
OMNI MUSIC  
75 Avenida Norte y Final  
Alameda Juan Pablo II,  
Edificio No. 4010 San Salvador,  
EL SALVADOR  
TEL: 262-0788

**GUATEMALA**  
Casa Instrumental  
Calleza Roosevelt 34-01 zona 11  
Ciudad de Guatemala  
TEL: (502) 596-2988

**HONDURAS**  
Anaacen Pajaro Azul S.A. de C.V.  
BO Paz, Barahona  
San Pedro Sula, Honduras  
TEL: (504) 553-2029

**MARTINIQUE**  
Musique & Son  
Z.L.Les Mangle  
97232 Le Lamanin  
Martinique F.W.I.  
TEL: 596 596 426860

**MEXICO**  
Casa Veerkamp S.A. de C.V.  
Av. Tolosa No. 323, Col. Olivar  
de los Padres 01790 Mexico  
D.F. MEXICO  
TEL: (55) 5668-6689

**NICARAGUA**  
Musicales Nicaraguas  
Banabach Instrumentos  
Alameda D'Este, Calle Principal  
de la farmacia Sucre y Avenida  
Cuadro al Lago 0505  
Managua, Nicaragua  
TEL: (505) 277-2597

**PANAMA**  
SUPRO MUNDIAL S.A.  
Boulevard Andrews, Albrook,  
Panama City, REP. DE  
PANAMA  
TEL: 315-0101

**PARAGUAY**  
Distribuidora De  
Instrumentos Musicales  
J.E. Olear y ESQ. Manduvira  
Asuncion PARAGUAY  
TEL: (595) 21 492147

**PERU**  
Audiomet  
Distribuciones Musicales SAC  
Juan Manning 530  
Miraflores  
Lima - Peru  
TEL: (51) 4461388

**TRINIDAD**  
AMR Ltd  
Ground Floor  
Maritime Plaza  
Barratara Trinidad W.I.  
TEL: (686) 638 6385

**URUGUAY**  
Todo Musica S.A.  
Francisco Acuna de Figueroa  
1771  
C.P.: 11 800  
Montevideo, URUGUAY  
TEL: (02) 924-2335

**VENEZUELA**  
Instrumentos Musicales  
Allegro C.A.  
Av. Las Industrias e/ Guitar  
import  
#7 zona Industrial de Turumo  
Caracas, Venezuela  
TEL: (212) 244-1122

## EUROPE

**AUSTRIA**  
Roland Elektronische  
Musikinstrumente HmbH.  
Austrian Office  
Eduard-Rodem-Gasse 8,  
A-6020 Innsbruck, AUSTRIA  
TEL: 262-44 260

**BELGIUM/FRANCE/  
HOLLAND/  
LUXEMBOURG**  
Roland Central Europe N.V.  
Huisstraat 3, 16260 Oevel  
(Westvlebe) BELGIUM  
TEL: (013) 575811

**CZECH REP.**  
K-AUDIO  
Kardovska 626  
CZ-198 00 Praha 9,  
CZECH REP.  
TEL: (2) 666 10529

**DENMARK**  
Roland Scandinavia A/S  
Nordhavnsvej 7, Postbox 880,  
DK-2100 Copenhagen  
TEL: 3916 0210

**FINLAND**  
Roland Scandinavia As, Filial  
Finland  
Etanontie 5  
FIN-01510 Vantaa, FINLAND  
TEL: (09) 68 24 020

**GERMANY**  
Roland Elektronische  
Musikinstrumente HmbH.  
Oststrasse 96, 22844  
Norderstedt, GERMANY  
TEL: (040) 52 60990

**GREECE**  
STOLLAS S.A.  
Music Sound Light  
155, New National Road  
Patras, 26442, GREECE  
TEL: 2610 435400

**HUNGARY**  
Roland East Europe Ltd.  
Warehouse Area DEPKO 7183  
HUNGARY  
TEL: (23) 511011

**IRELAND**  
Roland Ireland  
C2 Calmount Park, Calmount  
Avenue, Dublin 12  
Republic of IRELAND  
TEL: (01) 4294444

**ITALY**  
Roland Italy S. p. A.  
Viale delle Industrie 8,  
20020 Arese, Milano, ITALY  
TEL: (02) 937-78300

**NORWAY**  
Roland Scandinavia Avd.  
Kontor Norge  
Lilleakerveien 2 Postboks 95  
Lilleaker N-0216 Oslo  
NORWAY  
TEL: 2273 0074

**POLAND**  
MK MUSIC SP.Z.O.O.  
Ul. Gibraltarska 4,  
PL-03664 Warszawa POLAND  
5857  
TEL: (02) 679 44 19

**PORTUGAL**  
Roland Iberia, S.L.  
Portugal Office  
Cais das Pedras, 8/9-1 Dto  
4050-465, Porto, PORTUGAL  
TEL: 22 648 00 60

**ROMANIA**  
FBS LINES  
Piata Libertatii 1,  
535000 Clougheni,  
ROMANIA  
TEL: (266) 364 609

**RUSSIA**  
MuzTeK  
3-Bogatyrskaya Str. 1, 1-1  
107 564 Moscow, RUSSIA  
TEL: (095) 169 5043

**SPAIN**  
Roland Iberia, S.L.  
Paseo Garcia Faria, 33-35  
08005 Barcelona SPAIN  
TEL: 93 493 91 00

**SWEDEN**  
Roland Scandinavia A/S  
SWEDISH SALES OFFICE  
Danvik Center 28, 2 tr.  
S-131 30 Nacka SWEDEN  
TEL: (08) 702 00 20

**SWITZERLAND**  
Roland (Switzerland) AG  
Landstrasse 5 Postfach,  
CH-1452 Itingen,  
SWITZERLAND  
TEL: (061) 927-8383

**UKRAINE**  
TIC-TAC  
Mira Str. 19/108  
P.O. Box 180  
295-000 Mukachevo,  
UKRAINE  
TEL: (03131) 414-40

**UNITED KINGDOM**  
Roland (U.K.) Ltd.  
Atlantic Close, Swansea  
Enterprise Park, SWANSEA  
SA7 9FL,  
UNITED KINGDOM  
TEL: (01792) 702701

**BAHRAIN**  
Moon Stores  
No. 16, Bldg. Al Bahrain Avenue,  
P.O. Box 247 Manama 304,  
State of BAHRAIN  
TEL: 17 211 005

**CYPRUS**  
Bades, Sound Equipment Ltd.  
17 D. Agorou Street, Nicosia,  
CYPRUS  
TEL: (022) 66-9426

**IRAN**  
MOCO INC.  
No.1 Nike St., Dr-Sharyati Ave.,  
Robeyrye Centre, Mirداماد  
Tehran, IRAN  
TEL: (021) 285-4169

**ISRAEL**  
Hilithi P. Greenspoon & Sons  
Ltd.  
8 Refziy Halyahya Hashmya St.  
Tel-Aviv-Yafa ISRAEL  
TEL: (03) 6823666

**KUWAIT**  
EASA HUSAIN AL-YOUSIFI  
& SONS CO.  
Abdullah Salem Street,  
Sabit, KUWAIT  
TEL: 2447-6399

**LEBANON**  
Chahine S.A.L.  
Gerje Zeidan St., Chahine  
Bldg., Achrafieh, P.O.Box: 16-  
5857  
Beirut, LEBANON  
TEL: (01) 20-1441

**OMAN**  
TALENTZ CENTRE L.L.C.  
P.O. BOX 37 MUSCAT,  
POSTAL CODE 113  
TEL: 931-3705

**QATAR**  
Al Emadi Co. (Badie Studio &  
Stores)  
P.O. Box 62, Doha, QATAR  
TEL: 4423-554

**SAUDI ARABIA**  
aDawlah Universal  
Electronics APL  
Corniche Road, Aldossary  
Bldg., 1st Floor, AlKhobar,  
SAUDI ARABIA  
P.O.Box 2154, AlKhobar 31952  
SAUDI ARABIA  
TEL: (03) 898 2081

**SYRIA**  
Technical Light & Sound  
Center  
Rawda, Abdul Qader Jazari St.  
Bldg. No. 21, P.O. BOX 13530,  
Damascus, SYRIA  
TEL: (011) 223-5384

**TURKEY**  
Ant Musik Aletleri Ihlalat Ve  
Ihracat Ltd Sti  
Strashevler Caddesi  
Strashevler Pasaji No74/20  
Taksim - Istanbul, TURKEY  
TEL: (0212) 2449624

**U.A.E.**  
Zak Electronics & Musical  
Instruments Co. L.L.C.  
Zabeel Road, Al Sherouk Bldg.,  
No. P4, Grand Floor, Dubai,  
U.A.E.  
TEL: (04) 3360715

**NORTH AMERICA**  
**CANADA**  
Roland Canada Music Ltd.  
(Head Office)  
5480 Parkwood Way  
Richmond B. C. V6V 2M4  
CANADA  
TEL: (604) 270 6626

**Roland Canada Music Ltd.**  
(Toronto Office)  
170 Admiral Boulevard  
Mississauga On L5T 2N6  
CANADA  
TEL: (905) 362 9707

**U. S. A.**  
Roland Corporation U.S.  
5100 S. Eastern Avenue  
Los Angeles, CA 90040-2938,  
U. S. A.  
TEL: (323) 890 3700

## SONGS contained in the EXR-40 OR

Title	File Name	Composer	Copyright	Artist / Remarks
Leh Bey Dari	LehBeyDa.mid	Mohamed Raheem	©2005 Roland Europe	Mohamed Raheem
Amazing Grace	AmazingG.mid	Traditional	©2005 Roland Europe	Traditional
My Bonnie	MyBonnie.mid	Traditional	©2005 Roland Europe	Traditional
Babel's Blunder	Babel.mid	John Maul	©1993 Roland Corporation	John Maul
Late Night Chopin	Chopin.mid	John Maul	©2003 Roland Corporation	John Maul
O Tannenbaum	OTannenb.mid	Traditional	©1991 Roland Corporation	Traditional
Pathétique	ZE1_Path.mid *	Ludwig Van Beethoven	©1994 Roland Corporation	Education Song
Liebesträume	ZE2_Lieb.mid *	Franz Liszt	©1993 Roland Corporation	Education Song
Sonata Mozart	ZE3_Sona.mid *	Wolfgang Mozart	©1994 Roland Corporation	Education Song
Gymnopédie	ZE4_Gymn.mid *	Erik Satie	©1993 Roland Corporation	Education Song
Arabesque	ZE5_Arab.mid *	Claude Debussy	©1996 Roland Corporation	Education Song

\* Songs whose file name starts with "ZE" are for educational purposes. The Right or Left hand track can be muted separately using the Minus-One function.

**MUSIC ASSISTANT**

**FUNCTIONS**

**ARABIC**

- 001 3amI3ant
- 002 3eni
- 003 7'adoka
- 004 AbdIKadr
- 005 Adeyt3am
- 006 AhYaLail
- 007 AishHytk
- 008 AlaDa3on
- 009 AlbiDali
- 010 AlimAlIh
- 011 AllaHay
- 012 Allalla
- 013 AlLekaa2
- 014 AnaAlbi
- 015 ArredaWn
- 016 Ayoub
- 017 Az Alaya
- 018 BaladHab
- 019 Be3aad
- 020 Btwannes
- 021 Dalloaa
- 022 DareElAy
- 023 EkoroDof
- 024 El Talla
- 025 El Zaal
- 026 ElAlmAla
- 027 ElElYaSa
- 028 ElKheil
- 029 ElLelaKe
- 030 ElSharyM
- 031 Etala3Fy
- 032 FatmaK
- 033 HabibAlb
- 034 HabibiWl
- 035 HabiEnta
- 036 Hanadi
- 037 HayatAlb
- 038 HbHayati
- 039 Keda3eni
- 040 KedOzala
- 041 KolMaolo
- 042 LailRa3d

- 043 LamaBada
- 044 LanA3ish
- 045 LaTsdgon
- 046 Law3ala
- 047 LelaElAb
- 048 LmmaBada
- 049 MaArwaak
- 050 MoshHaul
- 051 MryalaKh
- 052 Mwashah
- 053 Nadet
- 054 NenaGnen
- 055 OITaniKe
- 056 RahH Fin
- 057 Romeo
- 058 SafinMar
- 059 SalSa
- 060 SamraYaS
- 061 ShaghalO
- 062 ShatEskn
- 063 TabatWeN
- 064 Takaseem
- 065 Tal3aSal
- 066 Tasawar
- 067 TikiTa
- 068 Tol Omry
- 069 WeHeya3a
- 070 Ya Lela
- 071 YaGhddar
- 072 YaLelaDn
- 073 YaMagnon
- 074 YaMaSawa
- 075 Yanasini
- 076 ZabeyFel
- 077 ZayElHaw

**GREEK**

- 078 Amartolh
- 079 Annoula
- 080 AporoMmn
- 081 DariDari
- 082 Ela Mou
- 083 Perasmna
- 084 SouToPa1
- 085 Staxth

**WORLD**

- 086 AmPatrol
- 087 Bamboeo
- 088 CalIMePl
- 089 CareWhis
- 090 Child
- 091 Crocodil
- 092 Desafina
- 093 Do-Re-Mi
- 094 Everybdy
- 095 FnkyCity
- 096 G Ipanem
- 097 GreatFir
- 098 HrtSoul
- 099 IAlwyluv
- 100 Imaginin
- 101 In Mood
- 102 IsSheLov
- 103 Jealous
- 104 Johnny B
- 105 JoyWorld
- 106 KnckHeav
- 107 LaCumpar
- 108 LaPalom
- 109 Lola
- 110 LtsTwist
- 111 Mas Nada
- 112 My Heart
- 113 No Woman
- 114 No Worry
- 115 O Sole M
- 116 Old Good
- 117 One Note
- 118 Pop&Corn
- 119 Pretty W
- 120 Quando
- 121 Radetzky
- 122 Sailyng
- 123 Scandal
- 124 Sensitiv
- 125 Tico
- 126 White Ch

**KEYBOARD SET**

- Keyboard Touch
- Master Tune
- USR Transpose
- GLB Transpose
- Transpose Mode
- Pitch Bend Range
- Key Split
- Split Hold
- Split Intelligence
- Footswitch Assign
- Portamento Main
- Portamento Dual
- Mode Main
- Mode Dual

**METRONOME**

- Metronome Time Sign.
- Metronome Volume
- Count-In

**OCTAVE**

- Main Octave
- Dual Octave
- Split Octave

**VOLUME**

- Main Volume

**Dual Volume**

- Split Volume
- Auto Bass
- Accomp Drums
- Accomp Bass
- Accomp 1-6
- Song 1-16
- ARRANGER SET**
- Chord Intelligence
- Arranger Hold
- EP Chord
- Bass Inversion
- Melody Intelligence
- Intro/Ending Chord
- Sync Stop

**EFFECTS**

- Reverb
- Chorus
- MFx
- Tone MFx
- Reverb Main
- Chorus Main
- Panpot Main
- Reverb Dual
- Chorus Dual
- Panpot Dual

**Reverb Split**

- Chorus Split
- Panpot Split

**KEYBOARD SCALE**

- Scale C
- Scale C#
- Scale D
- Scale Eb
- Scale E
- Scale F
- Scale F#
- Scale G
- Scale Ab
- Scale A
- Scale Bb
- Scale B
- Scale Mode

**MIDI**

- Local
- MIDI Tx Rx
- Sync Rx
- Style PC
- Lyrics Tx
- NTA Rx 14
- Pitch Bend
- Modulation
- Program Change
- Velocity Rx
- Clock Tx
- Start/Stop
- Song Position Pointer

**UTILITY**

- Lock Init
- Initialize Flash
- Resume
- WRITE Song**
- WRITE Style**
- REMOVE Song**
- REMOVE Style**
- WRITE User Program**
- READ User Program**
- REMOVE User Program**

**QUICK JUMP BUTTONS**

FUNCTION	Press and hold
Keyboard Touch	KEYBOARD TOUCH
Key Split	ARRANGER BAND
Metronome Time Signature	METRONOME
Melody Intelligence	MELODY INTELLIGENCE
Dual Tone Selection	DUAL+TONE
Split Tone Selection	SPLIT+ TONE
Memorizing Favourite Tone	TONE 1- 8
Sync Stop function	SYNC START/STOP
Changing Scale Tune settings	ORIENTAL SCALE C-B
	<b>Press</b>
Main Octave	TONE + TEMPO/DATA
Dual Octave	DUAL + TEMPO/DATA
Split Octave	SPLIT + TEMPO/DATA
Main Volume	TONE + BALANCE
Dual Volume	DUAL + BALANCE
Split Volume	SPLIT + BALANCE



# USING THE UNIT SAFELY

INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

## **WARNING**




**Connect only the designated AC adaptor, as specified within the Owner's Manual.**  
**The use of any other AC adaptor could cause fire, electric shock, or injury to persons.**



Immediately turn the power off, remove the AC adaptor from the outlet, and request servicing by your dealer or qualified Roland service personnel when you notice an abnormality—for example, you see smoke coming from the device, notice an odd smell, or hear a strange sound.



### About **WARNING** Notice and the Symbols

 <b>WARNING</b>	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.
	The symbol at left, it means that the printed instructions must be followed exactly.
	The symbol at left, it means that the types of danger explained potentially exist.

**Roland®**

**K6018580**

---

UPC

K6018580



10981

**Roland®**