



ATTENTION: RISQUE DE CHOC ELECTRIQUE NE PAS OUVRIR

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK,
DO NOT REMOVE COVER (OR BACK).
NO USER-SERVICEABLE PARTS INSIDE.
REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS.

IMPORTANT SAFETY INSTRUCTIONS SAVE THESE INSTRUCTIONS

WARNING - When using electric products, basic precautions should always be followed, including the following:

- 1. Read these instructions.
- 2. Keep these instructions.
- Heed all warnings.
- 4. Follow all instructions.
- Do not use this apparatus near water.
- Clean only with a damp cloth.
- Do not block any of the ventilation openings. Install in accordance with the manufacturers instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. When the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- 12. Never use with a cart, stand, tripod, bracket, or table except as specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



- 13. Unplug this apparatus during lightning storms or when unused for long periods of time.
- 14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

For the U.K.-

IMPORTANT: THE WIRES IN THIS MAINS LEAD ARE COLOURED IN ACCORDANCE WITH THE FOLLOWING CODE.

BLUE: NEUTRAL BROWN: LIVE

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is coloured BLUE must be connected to the terminal which is marked with the letter N or coloured BLACK. The wire which is coloured BROWN must be connected to the terminal which is marked with the letter L or coloured RED. Under no circumstances must either of the above wires be connected to the earth terminal of a three pin plug.

Roland









/A-76

V-ARRANGER KEYBOARD 128-VOICE POLYPHONY

Owner's Manual

Thank you, and congratulations on your choice of the Roland VA-76 V-Arranger Keyboard.

The VA-76 is the 76-key (weighted synthesizer action), professional version of the widely acclaimed VA-7. VariPhrase, brandnew and strikingly realistic sounds and Drum Sets, all-new Music Styles, an animated touch screen, an Audio In connector with separate effects, 2 programmable "Pad" buttons, a programmable Lyrics function, 4 assignable outputs - and a sober, intuitive user interface are just the most exciting new features.

To get the most out of the VA-76 and to ensure many years of trouble-free service, we urge you to read through this Owner's Manual thoroughly.

- · To avoid confusion, let's agree to use the word "button" for all keys on the front panel, and only use "key" when referring to the VA-76's keyboard. Also, in order to avoid mixups between the "real" buttons on the front panel and the "software buttons" on the touch screen, we shall use the word "field" for the on-screen buttons.
- · The contents of the illustrations appearing in this manual may differ slightly from what you see when you start using your instrument.

Before using this instrument, carefully read the sections entitled, "Using the unit safely", and "Important notes". These sections provide important information concerning the proper operation of the VA-76. Be sure to keep this manual in a safe place for future reference.

Iomega® is a registered trademark. Zip™ is a trademark of Iomega Corporation. All other trademarks in this manual are the property of the respective companies.

USING THE UNIT SAFELY

INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

About A WARNING and A CAUTION Notices

Used for instructions intended to alert the user to the risk of death or severe **⚠WARNING** injury should the unit be used improperly. Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used

⚠ CAUTION

improperly. * Material damage refers to damage or

other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

About the Symbols

The \triangle symbol alerts the user to important instructions or warnings. The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger.

The Symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled

The symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the powercord plug must be unplugged from the outlet.

ALWAYS OBSERVE THE FOLLOWING

riangle Warning

· Before using this instrument, make sure to read the instructions below, and the Owner's Manual.



· Do not open (or modify in any way) the instrument, and avoid damaging the supplied power cable.



· Do not attempt to repair the instrument, or replace parts within it. Refer all servicing to your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information" page.



· Never use or store the unit in places that are:



Subject to temperature extremes (e.g., direct sunlight in an enclosed vehicle, near a heating duct, on top of heat-generating equipment); or are



Damp (e.g., baths, washrooms, on wet floors); or ате



- Humid; or are
- Exposed to rain; or are
- Dusty: or are
- Subject to high levels of vibration.
- Make sure the line voltage at the installation matches the input voltage specified on the name plate.




· Avoid damaging the power cord. Do not bend it excessively, step on it, place heavy objects on it, etc. A damaged cord can easily become a shock or fire hazard.



 This instrument may be capable of producing sound levels that could cause permanent hearing loss. Do not operate for a long period of time at a high volume level, or at a level that is uncomfortable. If you experience any hearing loss or ringing in the ears, you should immediately stop using the instrument and consult an audiologist.

⚠WARNING







 Immediately turn the power off, remove the power cable from the outlet, and request servicing by your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information" page when:



- The power cord has been damaged; or
- Objects have fallen into, or liquid has been spilled onto the instrument; or
- The instrument has been exposed to rain (or otherwise has become wet); or
- The instrument does not appear to operate normally or exhibits a marked change in performance.
- · In households with small children, an adult should provide supervision until the child is capable of following all the rules essential for the safe operation of the unit.



Protect the instrument from strong impact. Do not drop it!



· Do not force the instrument to share an outlet with an unreasonable number of other devices. Be especially careful when using extension cords-the total power used by all devices you have connected to the extension cord's outlet must never exceed the power rating (watts/ amperes) for the extension cord. Excessive loads can cause the insulation on the cord to heat up and eventually melt through.



Before using the instrument in a foreign country, consult with your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information" page.



A CAUTION

 The instrument and the power cord should be located so their position does not interfere with their proper ventilation.



 Always grasp only the plug or the body of the power cord when plugging into, or unplugging from, an outlet or this instrument.



 Whenever the instrument is to remain unused for an extended period of time, disconnect the power cord.



 Try to prevent cords and cables from becoming entangled. Also, all cords and cables should be placed so they are out of the reach of children.



• Never climb on top of, nor place heavy objects on the instrument.



 Never handle the power cord with wet hands when plugging into, or unplugging from, an outlet or this unit.



A CAUTION

 Before cleaning the unit, turn off the power and unplug the power cord from the outlet.



 Whenever you suspect the possibility of lightning in your area, disconnect the power cord from the outlet.



Features

VariPhrase processor

The VA-76 features a new breakthrough in sampling technology that allows for "elastic" processing and MIDI data-like manipulation of sampled audio phrases. You can now combine Arranger playback (accompaniments) with realtime triggering of sampled phrases so as to (re)create vocals, "acoustic" solo parts, etc., while giving the impression that the part in question is being sung or played to the VA-76's Music Styles. Thanks to its exceptional quality, the VariPhrase processor allows you to play the samples in ROM or your own sampled phrases polyphonically with little or no artifacts so typical of conventional samplers. For the first time ever, this is achieved based on single samples rather than time-consuming and intricate multisampling techniques. Furthermore, you can assign the VariPhrase part to the desired keyboard zone.

VariPhrase provides for automatic synchronization (without sonic alterations) of sampled material with the Arranger or Song Composer. It also allows you to divide longer phrases (e.g. an entire verse or chorus) into individual syllables and to play these one after the other — in perfect sync with the Arranger or Song tempo. The effect is truly stunning — and there is more. See page 29 for a first impression.

76-key velocity-sensitive keyboard with channel Aftertouch

The VA-76's keyboard is a delight to play. Capable of generating channel Aftertouch messages, it allows you to control the volume, timbre, and Arranger functions in an intuitive way.

D-Beam and Ribbon Controllers

The VA-76 also boasts the acclaimed D-Beam Controller* for intuitive Tone and Arranger control via movements over an invisible beam of infrared light. There is also a Ribbon Controller that can be used for controlling the same or complementary functions. And, of course, the BENDER/MODULATION lever and Aftertouch control are there, too.

New sound source

The VA-76 comes with a 128-voice polyphonic sound source with 3,646 instrument sounds and 116 Drum Sets that cover everything from incredibly realistic acoustic instruments to cooking Techno sounds. Never before has an electronic instrument produced such true-to-life instrument and drum sounds, including subtle tonal changes and all the "noises" associated with acoustic instruments (scraping for guitar sounds, resonance for drum sounds, etc.).

Effects galore

In addition to the indispensable digital Chorus, Reverb, Delay and 2-band Equalizer, the VA-76 also features a multi-effector with a stunning 89 effects and combinations (called "algorithms").

Customizable even without using the User Programs

The VA-76 is among the first Roland instrument that allows you to select your favorite sounds using five convenient SUPER TONES buttons on the front panel. The preset assignments for these buttons can be changed.

Furthermore, the One Touch Program functionality already available on previous models has been expanded to include four memories per Music Style – including the Disk Link Styles – and the possibility to assign your favorite settings to these memories.

Of course, the VA-76 also sports 128 User Programs where you can save your own panel registrations.

On-board Zip™ drive and floppy disk drive

The VA-76 engineers also thought you might appreciate a 100MB Zip drive for data storage and therefore wrote operating software that provides direct access to data on a Zip disk. Of course, the VA-76 also provides a convenient database function.

128 User Programs

Apart from allowing you to customize existing Styles quickly, the User Programs are also used to save all panel settings. If you need more than 128 memories, you can save the contents of the User Programs to Zip or floppy disk and load them whenever necessary. If you do not wish to program Styles, or if you are too busy to delve into this matter, you can personalize existing Styles by modifying the instrument assignments to any given Arranger part (bass, drums, chord backing, etc.), and then save these changes to one of the 128 User Programs in RAM.

128 High-definition Music Styles, plus 559 Music Styles on the supplied Zip The VA-76 comes loaded with an impressive 128 high-definition Music Styles covering every musical genre you need. Each Style comprises four versions (Basic, Advanced, Original, and Variation), two Intros, two Endings, four orchestrations, and various other elements that actually add up to far more than 128 accompaniments.

64 "Disk Link" memories allow you to assign Music Styles on Zip or floppy disk (VA-76) to the front-panel buttons for quick recall.

And if this impressive offer still isn't enough, the supplied Zip disk provides 559 additional Music Styles to choose from.

Of course, the VA-76 also allows you to program your own Music Styles (called *User Styles*). They even provide a nifty function that allows you to convert carefully selected sections of a Standard MIDI File into a Style.

Virtual Band for interactive registration

The Virtual Band button provides access to a step-by-step help function that asks you a few questions and then configures the VA-76 according to your answers. Registering an arranger keyboard has never been easier.

16-track sequencer

The VA-76 comes with a 16-track sequencer with a host of edit functions.

Three trigger modes

The Music Styles of your VA-76 can be triggered in one of three modes: Standard, Intelligent or Piano Style. In Standard mode, the Arranger's chord recognition works the way you would expect an intelligent keyboard to operate.

In *Intelligent* mode, you do not have to play complete chords in order to hear them. Pressing one, two, or three keys will produce even the most complex chords you can think of. The *Piano Style* mode, finally, is provided for those with a "pianistic" background even though it can be used for playing any sound, i.e. not just piano.

Intuitive user interface

The large touch screen keeps you posted about the status of the VA-76 and allows you to almost all functions by touching the on-screen fields.

Lyrics display

The VA-76 displays Standard MIDI File (SMF) lyrics and can also transmit Lyrics data to an optional LVC-1 Lyrics Converter. This should help you remember the words of every song you wish to sing. The VA-76 also boasts a function that allows you to edit Lyrics data. Furthermore, the VA-76 also features an Audio Input that can be used for sampling phrases as well as for connecting a microphone. Two dedicated effects (Chorus and Reverb) are provided for processing your vocals.

Unpacking your VA-76

Your VA-76 comes with the following items. Please check the contents of the cardboard box and report any problems to the Roland dealer you purchased the VA-76 from.

- · This Owner's Manual.
- A Zip disk with useful supplementary files (see the booklet included with the Zip disk for its contents).
- · A metal music stand.
- · A power cable.

Useful options

FC-7 Foot Controller

The FC-7 Foot Controller allows you to perform various Style selection functions (Fill In To Original/To Variation, Start/Stop, etc.) by foot. Connect it to the FC7 PEDAL socket at the back of your VA-76. The functions performed by the FC-7's foot switches is programmable.

Note: The FC-7 cannot be used as MIDI pedal board because it transmits pulses rather than MIDI messages. Do not try to connect it to the MIDI IN jack of your VA-76, or any other instrument.

EV-5 or BOSS FV-300L expression pedal

An optional EV-5 or BOSS FV-300L expression pedal can be used to perform various tasks, such as master volume changes.

DP-2, DP-6, or FS-5U Foot Switch

You will probably need two DP-2 (DP-6 or Boss FS-5U) footswitches. One should be connected to the SUSTAIN FOOTSWITCH socket to function as Hold pedal.

A second DP-2 (DP-6 or Boss FS-5U) can be used to perform various selectable tasks. The FOOT SWITCH assignment can be saved to a User Program along with all other settings.

MSA, MSD, and MSE series Style Disks The MSA, MSD, and MSE series Music Style disks contain new Styles. The MSE Music Style series was specially developed for the VA-76, G-1000, EM-2000, G-800, G-600, E-96, and RA-800. The MSE series Styles take advantage of the VA-76's new sounds. You will have no trouble reading MSA and MSD series Style disks on your VA-76 (upward compatibility).

RH series headphones

A pair of Roland RH series headphones (RH-25 or RH-50) can be connected to the PHONES socket.

Compatibility note

Though Music Styles for previous Roland arranger instruments can be used with the VA-76, Performance Memories (G-1000) or User Programs (EM-2000) are not compatible. You can, however, share User Programs, Styles, etc. with VA-7, VA-5, and VA-3 users. Furthermore, the VA-7's VariPhrases are fully compatible with the VA-76 (and vice versa).

General MIDI 2

Note: Only the VA-76's Song Composer is fully GM2 compatible.

Important notes

In addition to the items listed under "USING THE UNIT SAFELY" (see page 4), please read and observe the following:

Power supply

- Do not use this instrument on the same power circuit with any device that will generate line noise (such as an electric motor or variable lighting system).
- Before connecting the VA-76 to other devices, turn off the power to all units. This will help prevent malfunctions and/or damage to speakers or other devices.

Placement

- Using the VA-76 near power amplifiers (or other equipment containing large power transformers) may induce hum. To alleviate the problem, change the orientation of this instrument; or move it farther away from the source of interference.
- This instrument may interfere with radio and television reception. Do not use it in the vicinity of such receivers.
- Do not expose the VA-76 to direct sunlight, place it near devices that radiate heat, leave it inside an enclosed vehicle, or otherwise subject it to temperature extremes.
 Excessive heat can deform or discolor the instrument.

Maintenance

- For everyday cleaning wipe the VA-76 with a soft, dry cloth or one that has been slightly dampened with water.
 To remove stubborn dirt, use a mild, non-abrasive detergent. Afterwards, be sure to wipe the instrument thoroughly with a soft, dry cloth.
- Never use benzene, thinners, alcohol or solvents of any kind, to avoid the possibility of discoloration and/or deformation.

Repairs and data

Please be aware that all data contained in the instrument's memory may be lost when it is sent for repairs.
 Important data should always be saved to Zip or floppy disk. In certain cases (such as when circuitry related to memory itself is out of order), we regret that it may not be possible to restore the data. Roland assumes no liability concerning such loss of data.

Additional precautions

- Please be aware that the memory contents can be irretrievably lost as a result of a malfunction, or the improper operation of the instrument. To protect yourself against the risk of losing important data, we recommend that you periodically save a backup copy of important data in the instrument's memory.
- Use a reasonable amount of care when using the instrument's buttons, other controls, and jacks/connectors.
 Rough handling can lead to malfunctions.
- · Never strike or apply strong pressure to the display.
- When connecting/disconnecting all cables, grasp the connector itself—never pull on the cable. This way you will avoid causing shorts, or damage to the cable's internal elements.
- A small amount of heat will radiate from the instrument during normal operation. This is perfectly normal.

- To avoid disturbing your neighbors, try to keep the volume at reasonable levels. You may prefer to use headphones, so you do not need to be concerned about those around you (especially late at night).
- When you need to transport the instrument, package it in the box (including padding) that it came in. Otherwise, you will need to use equivalent packaging materials, or a flightcase.

Handling Zip disks


- When inserting the Zip disk, hold it horizontally and gently push it downward into the drive until it snaps into place. If the mechanism fails to load the disk completely, gently push the Zip disk downward.
- To remove a Zip disk, use the ZIP Eject function (see page 62). Never force the Zip disk into or out of the drive.
- Store the Zip disk in its protective case when it is not in
- Avoid exposing the Zip disk to direct sunlight, high temperature, moisture, and magnetic fields.
- Never insert a floppy disk into the Zip drive, and never try to clean the drive with a 3,5" head cleaning diskette.

About the touch screen

 Wipe off stains on the touch screen using ethanol, but do not allow the ethanol to soak into the joint of the upper fume and the bottom glass, for it may otherwise cause peeling or malfunction. Do not use organic solvents or detergents other than ethyl alcohol (ethanol).

Handling floppy disks

- Floppy disks contain a plastic disk with a thin magnetic coating. Microscopic precision is required to enable storage of large amounts of data on such a small surface area.
 To preserve their integrity, please observe the following when handling floppy disks:
- · Never touch the magnetic medium inside the disk.
- · Do not use or store floppy disks in dirty or dusty areas.
- Do not subject floppy disks to temperature extremes (e.g., direct sunlight in an enclosed vehicle). Recommended temperature range: 10 to 50° C (50 to 122° F).
- Do not expose floppy disks to strong magnetic fields, such as those generated by loudspeakers.
- Floppy disks have a "write protect" tab which can protect
 the disk from accidental erasure. It is recommended that
 the tab be kept in the PROTECT position, and moved to
 the WRITE position only when you wish to write new
 data onto the disk.



- Disks containing important performance data for this instrument should always be locked (have their write protect tab slid to the PROTECT position) before you insert them into the drive of another instrument.
- The identification label should be firmly affixed to the disk. If the label comes loose while the disk is in the drive, it may be difficult to remove the disk.
- Put the disk back into its case for storage.

Contents

1. Panel descriptions	4.6 Arranger/Music Style clinic
1.1 Front panel14	Selecting Music Styles59
1.2 Rear panel	Orchestrator and Morphing62
1.2 Near parier	4.7 Song Composer clinic
2. Setting up and demo songs19	Recording your music65
2.1 Audio connections	Redoing the melody (2nd Trk)
2.2 Listening to the demo songs	Saving your song to disk
Z.E Listening to the demo songstriff	5. More about the VariPhrase part69
3. Scratching the surface22	-
3.1 The general idea	5.1 Playing with the User memories
-	Loading VariPhrases, VariPhrase Sets or audio files69
3.2 Easy Routing: quick registration22	Selecting a User memory
3.3 The Master page24	5.2 Sampling your own phrases
3.4 Using the VA-76's Arranger25	Phrase Edit: touching up the audio material
3.5 Adding a melody to the accompaniment27	Encoding the phrase
Changing the tempo27	5.3 Phrase Parameters
Balance: if the melody is too soft or too loud27	Pitch
Selecting sounds for the right hand	Amplitude
Using VariPhrases	Phrase Ctrl78
3.6 Listening to Standard MIDI Files	Pan
Minus One playback	Portamento
4. VA-76 clinics 34	5.4 Global VariPhrase functions
	Playback81
4.1 Keyboard Mode clinic	Trigger81
Arranger and Piano modes	Mode 82
Other	5.5 Controller functions for the VariPhrase part 82
4.2 Tone clinic	5.6 Truly "global" VariPhrase parameters
Selecting Tones for the Keyboard parts	Style Linked (Phrase Select)83
Choosing your own Tone favorites (Customize	Sync Settings
Preferred Tone)40	C. A. June and March and most from tions
Selecting different Tone Maps41	6. Advanced Keyboard part functions85
Drumming on the keyboard	6.1 Upper1 functions
4.3 VariPhrase clinic45	More about the Super Tones85
Switching on the VariPhrase part	6.2 Upper2 functions
Selecting other phrases for playing	Upper 2 Split
Combining/splitting a VariPhrase with another Keyboard part	'Dynamic' second split point: UP2 to Left
"Playing" with the VariPhrases	Portamento (Upper 1-2 Portam)
Adding realtime expression	6.3 LWR Hold
Realtime VariPhrase control via the display 49	
Adding effects to the VariPhrase part 50	6.4 Velocity sensitivity
4.4 Expression clinic51	6.5 Scale Tuning92
D Beam Controller51	7 Mars shout the Arranger OF
Ribbon controller (Touch control)52	7. More about the Arranger95
Aftertouch52	7.1 Arranger and Music Styles95
Pitch Bend/Modulation52	Starting a Music Style95
Transposition	Stopping a Music Style95
Octave	Sync (Options)
FC-7 Foot Controller	7.2 Selecting other Style divisions
Sustain Footswitch (Hold)55	Major, minor, seventh
Foot Switch55	Using Aftertouch to select Arranger patterns97
Expression (Foot Pedal)55	Style Morphing (part 2)98
Master Tune	7.3 Melody Intelligence99
Metronome56	
4.5 Using live vocals57	


7.4 One Touch	10.2 Song List: searching songs on disk (Find) Play & Search: finding Songs by playing a few notes .	13
Programming your own Tone selections (Memorize) .100	10.3 Song playback functions	
7.5 More refined Arranger settings101	Lyrics function	134
ARR(anger) Hold101	Fast Forward, Rewind, and Reset	135
Chord recognition area101	Loop playback (Markers)	135
Arranger Chord Mode102	Changing the song tempo	135
Bass Inversion	Soloing and muting parts	135
Dynamic Arranger103	Song/Keyboard-part balance	136
7.6 Arranger Options104	Transpose	
(Arranger) Tempo104	10.4 Song Chains	137
Chord Family Assign, Alteratn	Compiling or editing a Song Chain	
Intro& Ending Alteration	Playing back a Song Chain	
	Chain Mode	139
7.7 Selecting Tones for the Arranger parts	Deleting a Song Chain	
7.8 Working with Styles on Disk	10.5 Song Options	139
Programming your own Disk Link assignments 108	P&S Input	140
Find: locating Styles on a Zip disk	11 Song Composer (16-track atc.)	4 4 4
Rename (Style Options) 110 Style Delete 111	11. Song Composer (16-track, etc.)	
Style Delete	11.1 16-track Sequencer	141
8. Mixer, effects and editing	General considerations	
	Example 1: Recording a track	
8.1 Structure of the Mixer pages	Example 2: Recording a song from scratch	145
8.2 Volume and pan	11.2 Editing 16-track songs	
Global Volume	Easy editing and useful functions	
Muting parts114 Keybrd Mixer (volume of the Keyboard parts)114	In-depth editing of a 16-track song.	
Style Mixer (volume of the Arranger parts)	Utility: other useful functions	152
PanPot (stereo position)	11.3 Style Converter	
More locks	11.4 Edit Lyrics	
8.3 Output Assign115	'Utility' functions for Edit Lyrics	
8.4 Effects and Equalizer	11.5 Header Post Edit	
Applying Reverb, Chorus, or Delay to a part	11.3 Header Fost Luit	. 101
Effects settings117	12. Programming User Styles	163
Delay types & Parameters119	12.1 Concept	
Equalizer119	Selecting the User Style Composer	
8.5 Insertion effect (M-FX)120	12.2 Recording User Styles from scratch	
Using the insertion effect	Selecting the track, the Mode, the Type and the	. 100
Selecting an M-FX type123	Division	165
8.6 VariPhrase and Audio In effects	Record mode	
8.7 Sound Palette: editing Keyboard part parameters . 125	Specifying the key	
	Quantize	.166
9. Registrations – User Programs 127	Tone selection	. 167
9.1 Writing your settings to a User Program	Time signature	. 167
9.2 Selecting User Programs128	Length: specifying the pattern length	.167
Free Panel	Tempo	.169
Selecting a User Program (Group, Bank, Number) 128	Recording Audition your pattern and then keep or redo?	160
Selecting User Programs using the [DOWN][UP]	Saving your Style to disk	170
buttons129	Programming other parts and divisions	.170
Selectively loading User Program settings (User	Muting parts while recording others	.170
Program Cancel Options)129	Remarks	.171
9.3 Automatic functions for User Programs	Copying entire Styles using Load (all tracks)	.172
Song & MIDI (Set) Link	12.3 Copying existing Styles	. 172
User Program selection at power-on131	Copying individual Style tracks	.172
10. Song Composer (the basics)	Editing on the fly by recording	
	12.4 Editing User Styles	. 174
10.1 A few remarks about recording songs	Edit functions that are not part of the User Style	
Formatting a disk132	Edit mode	. 176


12.5 User Style Edit mode	177
Erase	
Delete	178
Insert	
Transpose	
Velocity	
Quantize	
Shift	
12.6 User Style Micro mode	
Change	
Insert	
Move Mix	
Copy Mix	184
12.7 User Style Utility	
Change	
Сору	
• •	
13. Miscellaneous	.186
13.1 Choosing performance functions (Controllers)	. 186
D Beam	186
Pitch Bender	
Modulation	
Touch Control (Ribbon)	
AftertouchSustain Switch (CC64)	
Foot Switch	
Foot Pedal (Expression).	
13.2 FC-7 & Pad parameters	
FC-7 Foot Controller	
PAD buttons	
13.3 Global parameters (for the entire VA-76)	
Tone Recall	
Factory Resume	
Virtual Band Autorun	196
4.4 . 0.6175.1	
14. MIDI	
14.1 MIDI in general	
MIDI messages used by the VA-76	
About MIDI implementation charts	
14.2 Preparations for using the MIDI functions	
Transmitting MIDI data (TX)	
The how-to's	
14.3 Keyboard MIDI, Style MIDI, Song MIDI	
14.4 Utilities MIDI	
MIDI Sync RX/TX	
Style TX Sync	. 203
Song TX Sync	
Style	
NTA: Note-to-Arranger	
MIDI parameters (Param)	
14.5 MIDI Sets	

15. Disk functions)9
15.1 Autoload	09
15.2 Disk Load (loading data from disk)	09
Load Style/copy Style	09
Load User Prg2	
Load MIDI Set	
Load Phrase	
15.3 Disk Save (saving data to disk) 2	
15.4 Delete	13
15.5 Disk Utility	13
Format2	13
Copy functions	
Rename	16
16. Specifications	18
-	18
-	
17. M-FX Types & controllable parameters	19
17. M-FX Types & controllable parameters	19 22
17. M-FX Types & controllable parameters	19 22 22
17. M-FX Types & controllable parameters .2 18. Reference .2 18.1 Tones .2 18.2 Drum Sets .2	19 22 22 33
17. M-FX Types & controllable parameters .2 18. Reference .2 18.1 Tones .2 18.2 Drum Sets .2 18.3 Internal Music Styles .2	19 22 22 33 51
18. Reference .2. 18.1 Tones .2. 18.2 Drum Sets .2.	19 22 22 33 51

1. Panel descriptions

1.1 Front panel





1 D BEAM CONTROLLER section

Use the [ON/OFF] button to switch the D Beam Controller on (the button lights) or off (button dark). By holding down the [ON/OFF] button for more than a second, you call up the display page where you can select the parameter to be controlled via the D Beam. (These parameters can also be selected by pressing the [CONTROLLERS] button.)

Note: The D Beam technology has been licensed from Interactive Light, Inc.

Move your hand or body over the two "eyes" to control the volume, filter setting, modulation depth, etc., of the currently active Keyboard parts.

② VOLUME knob

Use this knob to set the VA-76's global output volume (all sections) both in the speakers and the headphones you may have connected. The setting of this knob also determines the volume of the signals sent to the outputs.

(3) M-FX knob and ON/OFF button

The [M-FX] knob allows you to control one multieffects parameter in realtime. The [ON/OFF] button is used to switch the multi-effects on or off. Press and hold it to call up a display page where you can set the M-FX parameters. Please note that this only affects the parts that have been assigned to the multi-effects.

(4) BALANCE knob

This knob allows you to set the balance between the Arranger parts ("ACCOMP") and the solo sounds ("KEYBOARD").

(5) MELODY INTELL button

Press this button (so that it lights) to add an automatic counter-melody (second and third voice) to your solos or melodies. Press and hold this button to call up a page where you can select the harmony type.

(6) CONTROLLERS button

This button provides access to a display page where you can define the functions of the VA-76's standard and optional realtime controls. These include the D Beam Controller as well as an optional footswitch and expression pedal, and three sliders for controlling VariPhrase playback.

(7) EFFECTS button

Press this button to call up the display page where you can set all effects parameters. The VA-76 provides two sets of effects: a group of four that are accessible to most parts, and a group of two that are reserved for the VariPhrase processor and the Audio In part.

® ONE TOUCH button

This button has two functions: when pressed in isolation, it takes you to the display page where you can select/program so-called One-Touch memories for the currently selected Music Style (see page 29).

By holding it down while pressing the USER PROGRAM [DOWN] or [UP] button, you transpose the VA-76 in semitone steps.

SYNC button

Press this button to activate one (or two) SYNC function(s). By default, SYNC START is selected. Hold this button down to call up a display page where you can select another SYNC option.

(10) KEYBOARD MODE section


These three buttons are used to specify whether the keyboard will be split or whether one sound can be played using the entire keyboard. Press the [OTHER] button if you want to use other configurations than "Arranger left/melody right" (ARRANGER) or "one sound for the entire keyboard" (PIANO).


[OTHER] also provides access to other keyboardrelated functions, such as transposition, the Octave function, and parameters for fine-tuning Arranger response.

(1) USER PROGRAM [DOWN]/[UP] buttons

These buttons allow you to select the previous (DOWN) or next (UP) User Program. User Programs are registration memories.

Press either or both of them while holding down the [ONE TOUCH] button (see page 14) to transpose the VA-76 in semitone steps, or to return to the 'no transposition' (0 semitones) setting.





(12) Display

This is a so-called touch screen that allows you to select functions, parameter values, etc., simply by touching the corresponding fields. Please note that the bulk of the VA-76's functions can only be selected via the display.

(3) ORCHESTRATOR button

This button allows you to call up a display page where you can select another orchestration for the currently selected Music Style and/or take advantage of the Style Morphing feature. See page 62 for details.

(14) VIRTUAL BAND button

Press this button if you wish to listen to the VA-76's demo songs, or take advantage of a very powerful feature that allows you to configure the VA-76 simply by answering a few questions. This is called "Easy Routing" and is available in 6 languages.

(15) DISK indicator

This indicator lights when the VA-76 reads or writes data from/to disk (Zip or floppy).

(16) SONG COMPOSER button

Press this button if you want to play back, or record and edit your music with the VA-76's digital recording function called "Song Composer".


17) FUNCTION MENU button

This button allows you to access the VA-76's function menu where you can find all functions you probably only need sporadically.

Note: The FUNCTION MENU page also contains a PANEL INFO field. Press this field to get at-a-glance information about the special functions assigned to the frontpanel buttons.

(18) Arranger control buttons

Use these buttons to select the desired Music Style pattern, and to start/stop Music Style playback.



(19) VariPhrase section

These buttons provide access to the revolutionary VariPhrase function of your VA-76.

20 SUPER TONES buttons

Use these buttons to select one of the five so-called "Super Tones". These are sounds for the Upper 1 part you may want to use more often than others. There are two sets of five that can both be edited: the FACTORY and the USER group. You can thus prepare 10 favorite Tones. See page 40 for details.

21) DATA button

When this button lights (which is sometimes the case every time you select an adjustable parameter), you can press it to call up an on-screen 10-key pad. Use this pad for entering the desired parameter value.

2 TEMPO/TAP button

If the [DATA] button lights, press this button (so that it lights) whenever you need to change the Style or Song tempo. Then use the [TEMPO/DATA] dial to set the desired value. Press and hold this button to have access to various tempo options. You can also press it rhythmically to enter the tempo like musicians do: by tapping it.

23 STYLE, TONE and USER PROGRAM buttons

These buttons allow you to specify the function of the BANK and NUMBER buttons. They are color-coded for easy identification: [STYLE]= green, [TONE]= red, [USER PROGRAM]= orange. These colors are reflected by the active BANK/NUMBER buttons.

24 TEMPO/DATA dial

The function of this dial depends on the status of the [TEMPO/TAP] and [DATA] buttons. If the [TEMPO/TAP] button lights, the dial can be used to set the desired tempo. If the [DATA] button lights, the dial can be used for setting the value of the currently selected parameter.

25 PART button


Hold down this button while pressing a NUMBER button to specify a Keyboard part for Tone selection and to call up the Part Sclect page (where the specified part is already selected). The assignments are as follows:

PART + NUMBER [1]	Upper 1
PART + NUMBER [2]	Upper 2
PART + NUMBER [3]	Manual Drums
PART + NUMBER [4]	
PART + NUMBER [5]	Melody Intelligence
PART + NUMBER [6]	Lower1
PART + NUMBER [7]	Lower2
PART + NUMBER [8]	Manual Bass

Press and hold it for a second (all GROUP/BANK/ STYLE/TONE/USER PROGRAM indicators except the NUMBER button of the currently selected part go off). Then release it to select the PART SELECT page.

26 GROUP, BANK, NUMBER buttons

This section allows you to select the desired Music Style, Tone, or User Program memory.



② Floppy disk drive

This is where you can insert 2DD or 2HD floppy disks for external storage of your Music Styles, User Programs, Composer Songs, and MIDI Sets. Press the eject button to remove the disk from the drive. Note: Do not remove the floppy disk while the DISK indicator on the front panel lights or flashes. Doing so may indeed damage both the floppy disk and the drive's head.

28 BENDER/MODULATION lever

When pushed towards the back of the VA-76, this lever will add modulation to the notes of the Keyboard parts you are playing at that time. Move it to the left or right to temporarily lower or increase the pitch of the Keyboard part notes you are playing.

2 Zip drive

The Zip drive can be used to save and playback Composer Songs, and to save or load User Styles, User Programs, MIDI Sets, VariPhrases, etc.

Note: To prevent damaging your Zip disk (it can hold up to 100MB worth of precious data), you cannot remove it manually.

30 Ribbon controller

Slide your finger on the ribbon or press a given position in order to modify the value of the parameter that is being controlled. You can select the parameter to be controlled.

(31) PAD buttons

These two buttons are meant for assigning the desired functions you wish to have direct access to. The assignments are part of the parameter settings that can be saved to a User Program, so that redefining the functions of these buttons is a matter of selecting another User Program.


(32) KEYBOARD PARTS buttons

These buttons allow you to switch the desired Keyboard parts (the one you can play yourself) and and off.

33 PHONES socket

The VA-76 comes with a headphone socket. Be sure to connect high-quality headphones to this socket (Roland RH-25 or RH-50, optional).

1.2 Rear panel



1 POWER ON button

Press this button to switch the VA-76 on and off.

(2) AC socket

This is where you need to connect the supplied power cord. Be sure to only use a wall outlet that delivers the correct voltage.


③ LCD CONTRAST knob

Use this knob to set the contrast when you are having problems reading what is written on the display.

Note: The LCD may take some time to warm up. That is why you may have to change the contrast several times after powering on.

(4) FC7 PEDAL socket

This is where you connect an optional FC-7 footswitch unit that allows you to start, stop, and select Style divisions by foot. The functions of this foot switch unit are programmable (and apply to all User Programs).



(5) SUSTAIN FOOTSWITCH socket

Connect an optional DP-2, DP-6, or BOSS FS-5U footswitch to this socket to sustain the notes of the Keyboard parts even after releasing the key(s) you pressed.

(6) FOOT SWITCH socket


Connecting an optional DP-2, DP-6, or FS-5U to this socket allows you to control an assignable function by foot.

7 FOOT PEDAL socket

Connect an optional EV-5 or BOSS FV-300L expression pedal to this socket to control the volume of one or several parts or another parameter by foot.

(8) MIDI connectors

These sockets allow you to use your VA-76 along with other MIDI instruments.



(9) METRONOME LEVEL knob and OUT socket


The VA-76'sa metronome signals can be transmitted to the METRONOME OUT socket. You can connect headphones (Roland RH-25 or RH-50) to this socket. This is useful for a drummer, for example (as "Click Track"). Use the METRONOME LEVEL knob to set the metronome volume in the headphones.

(10) VARIPHRASE section

LEVEL knob: This knob allows you to fine-tune the VariPhrase processor's input sensitivity. Always select a setting where no distortion is audible.

GAIN switch: Set this switch according to the signal source you have connected to the INPUT jack: Select "MIC" after connecting a microphone, and "LINE" if you connect a CD or MD player, etc.

INPUT socket: This mono 1/4" phone socket is where you need to connect the signal source you wish to "capture" (another word for "sampling"). Unless you buy or solder a special cable, you can only connect one output of your CD player, etc., to this socket. A microphone, on the other hand, can be connected straight away. For CD or MD players you may need to purchase an adapter plug or cable with a 1/4" phone jack



on one side, and an RCA/phono jack on the other. Alternatively, you can use an optional PJ-1M cable available at your Roland dealer.

(1) OUTPUT 2 L/R sockets

When you first switch on the VA-76, these audio outputs are not used (all signals are sent to the OUTPUT I sockets). You can, however, assign any desired signal to these sockets xx.

(2) OUTPUT 1 R, L/MONO sockets

These sockets allow you to connect the VA-76 to a mixing console, PA system, or audio recorder. We recommend you always use both sockets so as to transmit the VA-76's audio signals in stereo.

2. Setting up and demo songs


2.1 Audio connections

The VA-76 does not contain an internal amplification system. You will either have to use stereo headphones or connect the VA-76 to a keyboard or other type of amplifier and speaker system. You could also connect it to a PA system, power amplifiers, etc.

OUTPUT 1 sockets— Connect these sockets to the inputs of a mixing console, stage box, HiFi or power amplifier, etc. You can also connect them to the inputs of a cassette deck, etc. to make an audio recording of your playing.

OUTPUT 2 sockets— Use these sockets whenever you wish to amplify certain parts of your VA-76 without the internal effects. Using these sockets can be useful for multi-track recordings involving your VA-76.

PHONES— The PHONES socket is located at the front right. You can connect one pair of headphones. For optimum sound quality, be sure to use Roland RH-25 or RH-50 headphones.




2.2 Listening to the demo songs

Your VA-76 comes with a number of demonstration songs that give you an accurate impression of what you can do with your V-Arranger Keyboard. Here is how to listen to the demo songs:

Note: All demosongs © 2001 by Roland Europe in collaboration with Luigi Bruti and Roberto Lanciotti. All rights

- 1. Unpack the VA-76 and place it on a stable surface.
- 2. Connect the supplied power cord to the VA-76's AC socket, and the other end to a suitable wall outlet.

3. Set the [VOLUME] knob to the MIN position.



4. Press the [POWER ON] button next to the AC socket on the rear panel.

Once the internal circuit tests have been completed, the display looks as follows:



This page will be displayed automatically whenever you leave the VA-76 unattended for more than five minutes.

Note: You can prevent the VA-76 from automatically selecting this display page at start-up, or from returning to it at power-on. See page 195 for details.

Note: If you want to select this page at a later stage (after playing the VA-76), press the [VIRTUAL BAND] button. If you like, you can press a language field. That way, all demo song messages will be displayed in your language (if supported).

Note: Depending on the country where you bought the VA-76, other language options than the above may be available

5. Press the [DEMO] field. The display now looks as follows:



Note: If you selected another language, the question is displayed in that language. All other functions are the same, however.

- 6. Slightly increase the setting of the [VOLUME] knob. You may have to adjust it once demo song playback is up and running.
- 7. Insert the supplied Zip disk into the drive.

The demo songs do not reside in the VA-76's internal memory but on the supplied Zip. If you do not insert that disk before proceeding, the following message is displayed:



8. Press a "DEMO" field to select the demo songs you want to listen to:

ALL DEMO— The VA-76 plays back all of the following demo songs.

TONE DEMO— The VA-76 plays back the demonstration songs that illustrate the variety and realism of its sounds.

STYLE DEMO— The VA-76 plays back the demo songs that illustrate the quality of its automatic accompaniments (called "Music Styles").

VariPhrase DEMO— Press this field to listen to the exciting possibilities of the VA-76's VariPhrase processor.

What happens now depends on the selected demo option:





- Playback starts automatically. If you don't want to wait until the end of the current song, press [SKIP NEXT
 ▶]. This takes you to the beginning of the next demo song.
- Press the [STOP ■] field to stop demo song playback.
- You can continue playback from the beginning of the current or next song (after pressing the [SKIP NEXT ►►] field) by pressing [PLAY ►].
- Press the [←BACK] field to return to the demo song selection page.
- Press [EXIT] to leave the Virtual Band mode and to jump to the Master page (see page 24).

if you selected. FONE DEMO:



 Demo playback starts automatically. But you can press a Tone family field ("Piano", "CPerc", etc.) to select another demo song that features the Tones of that family

The abbreviations on the above display page reflect the names of the BANK buttons on the front panel (right side). Some demo songs feature several Tones.

Note: You can select another Tone demo while demo playback of the current Tone demo is still running.

- Press the [STOP ■] field to stop demo song playback.
 Press [PLAY ▶] to start it again.
- Press the [*BACK] field to return to the demo song selection page.

Press [EXIT] to leave the Virtual Band mode and to jump to the Master page (see page 24).

it you selected STYLEDEMONES TO A STREET



- Demo playback starts automatically. But you can press a Style name field ("Rock", "Dance", etc.) to start the demonstration of another Music Style.
 "Music Styles" are the VA-76 accompaniment patterns. These can be transposed and varied in realtime.
- Press the [STOP ■] field to stop demo song playback.
 Press [PLAY ▶] to start it again.
- Press the [BACK] field to return to the demo song selection page.
- Press [EXIT] to leave the Virtual Band mode and to jump to the Master page (see page 24).

It you selected VariPhrase DEMO:




- Playback starts automatically. Press the [STOP ■] field to stop demo song playback. Press [PLAY ▶] to start it again.
- Press [EXIT] to leave the Virtual Band mode and to jump to the Master page (see page 24).
 - 9. Press [◆BACK] to return to the demo selection page, and again to return to the first Virtual Band page.

3. Scratching the surface

3.1 The general idea

Your VA-76 is two instruments in one: one half provides the backing for the melody you play in the other half.



There are two main sections you can use for playing live. (The third section, the Song Composer, can also be used for live applications, but is mainly intended for recording and playing back your music.)

1 Keyboard parts:

This section consists of parts you need to play via the keyboard, hence the name "Keyboard". The VA-76 provides eight Keyboard parts, six of which can be used simultaneously: Upper 1/2, VariPhrase, Lower 1 & 2, and Manual Bass (called M.Bass or just MBS). The seventh part, Manual Drums (called M.Drums or MDR), can only be played in isolation, i.e. you cannot combine it with Upper1/2 or the VariPhrase part, though you can assign it to only the right half of the keyboard and use it along with Lower1/2 (that can be played in the left half). See page 42 for details. The eighth part, "MInt", is what computer buffs would call a "cross-platform part": it belongs to the Keyboard section but it is in part controlled by the Arranger. See "Melody Intelligence" on page 99.

(2) Arranger/Style section:

The Arranger is your backing band. It plays an accompaniment (called *Music Style*) recorded by Roland, third-party suppliers, friends/colleagues, or yourself. In a way, the Arranger works like a drum machine because it uses accompaniment patterns.

Unlike a drum machine, however, you can easily select the desired pattern while you play. So you do not need to program the order in which you intend to use the patterns. Furthermore, the Arranger not only provides a rhythm section but also chords, guitar and synthesizer riffs, and so on. The accompaniment can be transposed in realtime. All you have to do is play a different chord (usually with your left hand).

You can add vocals to your music using the Vari-Phrase function (see page 29) or by singing live (see page 57).

3.2 Easy Routing: quick registration

The Virtual Band page is the first page that is displayed after switching on the VA-76:



You already know what the [DEMO] field is for. Let us therefore have a look at the VA-76's Easy Routing function. It allows you to tell your V-Arranger Keyboard how to behave simply by answering a series of interactive questions.

1. If the above Virtual Band page is not displayed, either switch your VA-76 off and back on again, or press the [VIRTUAL BAND] button.

Note: You can prevent the VA-76 from automatically selecting this display page at start-up, or from returning to it at power-on. See page 195 for details.

2. Choose your language by pressing the appropriate field

If your language is supported, it would be a good idea to select it, as that will further simplify the interactive selection process.

Note: This language selection is stored and will be used again next time you switch on the VA-76.

3. Press the [EASY ROUTING] field. The display now looks as follows:



Given the number of options and the "easy" character of this interactive function, describing every possibility would confuse you and make the Easy Routing function look extremely intricate. Here is how it is structured:

 Specify whether you want to play with ([In a BAND]) or without accompaniment ([As a SOLOIST]). This is important for the remaining questions and answers.

If you press the [As a SOLOIST] field, there are two options:

- ORGANIST means that you can play two different sounds with your left and right hands (the keyboard is split). Despite the name, you can also select other combinations, such as a synthesizer sound for the left hand and a saxophone sound for the right.
- PIANIST means that one sound will be assigned to all keys. Again, you'll be offered a wider choice than just piano sounds.

Note: After selecting the "As a SOLOIST" option, you can still use the Arranger's drum patterns for rhythm backing simply by pressing the [START/STOP] button.

Note: Once you are more familiar with the VA-76, you will realize that this specifies the Keyboard Mode (see page 34).

If you pressed [In a HAND];

The keyboard will be split into a left section for Arranger control and a right section for playing a live melody to the accompaniment.

- You then need to specify how many instruments the accompaniment should contain: Drums, Drm&Bass (drums & bass), Combo (small band), or Big Band (which can also be an orchestra).
 - Note: Once you are more familiar with the VA-76, you will realize that this selects the Orchestrator version (see page 62).
- You are then given three options for the kind of music you want to play: ROMANTIC, BALL ROOM, or HEAVY. Again, these should be taken as generic terms, for ROMANTIC also includes musical genres like HipHop, for example.
- Finally, you can choose an automatic accompaniment ("Music Style") and select a sound for your right hand. There are eight Tone suggestions for every Style for you to choose from.

Other steps and tips:

- The [←BACK] field takes you back to the previous display page. Press it whenever you wish to change a previous selection.
- If the [FINISH] field is displayed, you can press it to confirm your settings and use them right away.
- Press [EXIT] to jump to the Master page (see page 24).
 If you pressed this field by accident, you can return to the Virtual Band page by pressing the [VIRTUAL BAND] button below the display.

- Note: If you press [EXIT], the selected settings will not be used. You need to press [FINISH] to confirm your choices.
- If one or both arrows (← and →) are displayed in "solid", you can call up additional options by pressing the arrow field in question.
- The symbol refers to the VariPhrase function.
 This is a very sophisticated sampler that allows you to play back audio phrases in sync with the Arranger tempo, and at the correct pitch.


4. Start playing on the VA-76.

You probably want to try out the VA-76 straight away without first reading the following pages. Just remember the following:

- You can start and stop Arranger playback (automatic accompaniments) by pressing the [START/STOP] button.
- In some cases, the melodic accompaniment (bass, chords, etc.) may not be audible. This is due to the settings you have selected. Later on in this manual, we will show you how to change these settings.
 Note: Though the VA-76 contains a lot more parameters for fine-tuning the Arranger's behavior, you could already decide to write the current settings to a User Program (see page 127). That way, you can return to them time and again without having to use the Easy Routing function.

3.3 The Master page

Whenever you leave the DEMO or EASY ROUTING mode by pressing [EXIT] or [FINISH], the display looks more or less as follows:



- Press this field if you want to select another Music Style (see page 59).
- ② Press this field if you want to select other Tones (sounds) (see page 37).
- ③ Press this field if you want to select a User Program (see page 128).
- 4) The metronome field allows you to switch the metronome on/off.
- ⑤ Press this field to call up the Mixer functions (see page 112).

Let us agree to call this the *Master page*. There are, in fact, two Master pages: one for Arranger playback, and another for the Song Composer. The difference between these two will be explained later on in this manual.

Note: If you switched off the automatic jump to the Virtual Band mode (see page 195), the Master page appears immediately after switching on the VA-76.

The number of items displayed on the Master page varies. Here is what it can look like in some situations:




That way, you know exactly which functions are currently active.

Which button does what? (Panel Info)

There may be situations where you don't remember exactly what you need to do in order to select a given function. The VA-76 provides a display page where you can check the (usually) "second" function of certain buttons. Note that not all button functions are explained on that page, so you still need to read the rest of this manual...

Here is how to select the Panel Info function:


1. Press the [FUNCTION MENU] button.



The display now looks as follows:



2. Press the [(i) Panel Info] field.



This page provides an overview of the display pages or functions that can be selected by holding down a given button, by pressing it when it lights, by pressing it twice in succession, or when pressed in combination with other buttons. Try to remember that it exists, and how to select it, because it may come in handy.

3. Press [EXIT] to return to the Master page. You can also press [←BACK] to return to the Function Menu, if you like, but that is not what we need here.

3.4 Using the VA-76's Arranger


The Arranger is an interactive "playback sequencer" that provides the accompaniments. These accompaniments are called "Music Styles", because they provide an 8-track backing for a given musical genre (Rock, Pop, Dance, Waltz, etc.).

The Arranger is interactive because it allows you to transpose the melodic accompaniment parts (bass, piano, guitar, etc.) simply by playing chords. In most instances, you will probably do so with your left hand. Each Music Style comprises several patterns so that you can vary the accompaniment by starting with an introduction, using a simple accompaniment for the verses, a more elaborate one for the choruses, and by ending your songs with an "Ending" pattern.

Let us first look at the most important aspects for operating the Arranger:


- 1. Switch on the VA-76 and use the Easy Routing function (see page 22) to select a "In a BAND" registration with a "Combo" or "Big Band" option.

 Of course, you can also register the VA-76 manually. But using the Easy Routing function is probably quicker.
- 2. If the [SYNC] button lights (which is probably the case), press it to switch it off.



The [ARRANGER] button must light.

- 3. Set the [VOLUME] knob to a reasonable level (e.g. about "1/4").
- 4. Check whether the Keyboard Mode [ARRANGER] button lights, and press it if it doesn't.
- 5. Play a chord in the left half of the keyboard (to the left of the C key below the USER PROGRAM [UP] button), then press the [START/STOP] button.




The [START/STOP] button lights, and the Arranger starts playing the accompaniment of the selected Music Style. The accompaniment pattern ("Music Style") is sounded in the key that corresponds to the

chord you played. The name of the chord you are playing is displayed below the name of the currently selected Music Style:



- **6.** Play another chord in the left half of the keyboard. The same pattern is now played in that key. In fact, you don't even have to play full chords:
- For major chords, playing just the root note is enough (e.g. "C" for C major, "A" for A major, etc.)
- For *minor* chords, playing the root note and the third key to its right will do.
- For seventh chords, playing the root and the second key to its left is enough.





Only the key that corresponds to the chord's name.


Root note + third key to the right.



Note: The function that takes care of this easy fingering is called "Intelligent" (see page 102). See also page 252 for a list of other chords that can be played using this system (augmented, diminished, etc.).

What you hear now is the "ORIGINAL" pattern (the [ORIGINAL] button lights). This is the simple accompaniment of the selected Music Style. Let's listen to the accompaniment your could use for your choruses:

7. Press the [VARIATION] button.



As soon as the ORIGINAL pattern is finished, the [VARIATION] button lights steadily, and the Arranger plays a different accompaniment called VARIATION.


Note: There are four more patterns for the ORIGINAL and VARIATION levels. See "Orchestrator" on page 62 for how to select them.

Professional transitions: Fill

So far, we have only used the ORIGINAL and VARIA-TION patterns. ORIGINAL is great for verses, while VARIATION could be used for choruses. Switching between these two is a matter of pressing the [ORIGI-NAL] and [VARIATION] buttons. Yet, that will produce instant changes of the accompaniment, while "real" musicians tend to "announce" new song parts by means of roll in the drums, or slightly different accompaniment notes.

The VA-76 allows you to make such "announcements" in the following way:

- 1. Start playback of the ORIGINAL pattern (see above).
- 2. Play a chord in the left half of the keyboard.
- 3. Press the [FILL] button.



What happens now, depends on when you press the [FILL] button:

- If you press it on any beat before the last one of the current bar, the Arranger plays a Fill-In pattern that lasts *until the end of the current bar*. It then changes to the VARIATION pattern.
- If you press it on the last beat of the current bar, the Fill-In will start on the next downbeat and last an entire bar, after which the Arranger automatically selects the VARIATION pattern.
 - The [FILL] button can also be used for transitions from the VARIATION pattern to the ORIGINAL accompaniment. All you need to do is press it while the [VARIATION] button lights.
- If you press the [FILL] button twice in succession, you select the fill that usually leads to the "other" pattern, but here once again selects the previously selected pattern. This is also called "Fill In To Previous", which can also be assigned to the Aftertouch (see page 98).

 Note: The length of a Fill-In can be halved. See page 97.


Intro & Ending

Now that we've got the transitions covered, you may start wondering how to create more professional intros for your songs – and indeed how to end them in style. That is what the [INTRO] and [ENDING] buttons are for.

While the VARIATION and ORIGINAL patterns (as well as their ORCHESTRATOR versions) keep repeating the same accompaniment until you select another one, or until you stop Arranger playback, Fill-Ins (see above), Intros, and Endings are played only once.

Once the *Intro* pattern is finished, the Arranger automatically proceeds with the ORIGINAL or VARIA-TION pattern (depending on which of these two buttons flashes). At the end of the *Ending* pattern, however, the Arranger stops.

- 1. Stop Arranger playback by pressing the [START/STOP] button (it goes dark).
- 2. Play a chord in the left half of the keyboard to select the key of the Intro pattern.
- 3. Press the [INTRO] button.



4. Press the [START/STOP] button to start Arranger playback.

The Arranger plays the introduction of the currently selected Music Style.

Note: Avoid playing chords while the Intro is running. Most Intro patterns indeed contain chord changes, so that playing different chords may lead to highly annoying results.

5. Press the [ORIGINAL] or [VARIATION] button while the Intro is still running.

The button in question starts flashing to signal that the corresponding pattern is ready to take over once the Intro is finished.

6. Wait until the ORIGINAL or VARIATION pattern is playing, then press the [ENDING] button.

At the end of the current pattern cycle, the Arranger will start playing the Ending pattern and then stop.

Note: Here again, it would be wiser not to play chords during playback of the Ending phrase.


Note: See "Arranger/Music Style clinic" on page 59 for other Arranger functions.

Note: You can also select patterns via the Aftertouch. See page 96.

3.5 Adding a melody to the accompaniment

If you set up the VA-76 using the Easy Routing function, you not only select a Music Style but also a sound for your right hand. Let's add a live melody to the accompaniment.

- 1. Press the [ORIGINAL] or [VARIATION] button and play a chord in the left half of the keyboard. It doesn't matter which of these two patterns you select as long as it keeps playing all the time. Also note that you could play only one note in the left half, because the Intelligent function is currently on.
- 2. Press the [START/STOP] button to start Arranger playback.




- 3. Play a melody in the right half of the keyboard.
- 4. While doing so, try to play the chords (or notes) that match the melody you are playing.

Note: There is no need to hold down the chord notes all the time, because the Arranger does this automatically. Briefly pressing the appropriate left-hand notes is thus enough. The function that takes care of this is called "ARR Hold" (see page 101).

Changing the tempo

If the Arranger is too fast (or too slow), here is how to change the Music Style tempo:

1. If the [TEMPO/TAP] button does not light, press it.



2. Use the [TEMPO/DATA] dial to set the desired tempo value.


The new tempo is displayed in the upper right corner of the display:



You can also press the [TEMPO/TAP] button several times in the rhythm of the desired tempo. This is called the *Tap Tempo* function. It sets the tempo based on the speed at which you press the button.

To quickly return to the default tempo, do the following:

3. Press and hold the [TEMPO/TAP] button. The display now looks as follows:




- **4.** On this page, press the [Default Tempo] field. See page 104 for the remaining tempo options.
- 5. Press [EXIT] to return to the Master page.

Balance: if the melody is too soft or too

You may find that the melody sound is too soft, or too loud, with respect to the Music Style accompaniment. In that case...

Use the [BALANCE] knob to correct the volume balance between the accompaniment and your solo playing.



Turn it towards the left (ACCOMP) if you can't hear the accompaniment. Turn it towards the right if the melody is too soft.

Selecting sounds for the right hand.

Suppose you like the sound for the right hand but think that it is not really suited for the currently selected Music Style. Here are two easy ways of assigning a different sound to the right hand.

Let's agree to use the word "Tones" for the VA-76's sounds.

Note: In the following, we'll assume that the Arranger is still active (the [ARRANGER] button should light).

Note: There is also the "classic" way of selecting Tones that we'll skip here. See page 37 for details.

Super Tones

One of the VA-76's user-friendly functions is the possibility to "earmark" 5 (Factory) + 5 (User) Tones and to select them almost instantly. Here is how this works:

- 1. Stop Arranger playback by pressing the [START/STOP] button (it goes dark).
- 2. Press a SUPER TONES [1]~[5] button.



This selects the Tone that is currently assigned to the button you pressed (see the display page below). This Tone is selected for the Upperl part.

Note: See "What are 'parts'?" on page 35 for more information about Upper1. For now, it is enough to know that Upper1 is the part that is assigned to the right half of the keyboard (unless you selected the VariPhrase).

The display now looks as follows:



The above illustration shows the Factory Tones that can be assigned to the SUPER TONES [1] button.

There are two assignment sets: "FACTORY" and "USER". See page 85 for details. "Factory" only means that the number of possible options is restricted to 40 Tones (rather than 3,646).

- 3. Play a few notes in the right half of the keyboard.
- 4. If you like, you can try out a different sound by pressing another field (e.g. "Vibraphone w").

There is a second set called USER to which you can assign one of the 3,646 Tones to each SUPER TONES button. See page 85.

5. You may want to press the [START/STOP] button to find out whether the newly selected Tone is better suited for the Music Style.

Just for your reference: if you hold down a SUPER TONES button, the following display page appears:



In that case, press the [EXIT] field as we do not need this function here. See page 85 for details.

6. Press another SUPER TONES button.

Again, there are 8 possibilities, one of which is already selected. Press another displayed field to change the assignment for the active SUPER TONES button.

Note: The [CUSTOMIZE] field allows you to store a new assignment (after pressing another instrument field on the display). The Tone in question will then be selected next time you press the corresponding SUPER TONES button.


7. Stop Arranger playback by pressing the [START/STOP] button (it goes dark).

One Touch


Another way of selecting a suitable Tone for the righthand part while working with the Arranger is by using the ONE TOUCH feature. In fact, One Touch does a lot more than selecting a Tone for Upper1. See page 99 for details.

Note: One Touch is intended for quick registration of the Upper1 and Upper2 parts when used in conjunction with the Arranger. If you press the [ONE TOUCH] button while the Arranger is not available, the selection page appears. If you then select a One Touch memory, the Keyboard Mode [ARRANGER] button lights. This means that the Arranger has been switched on.

1. Press the [ONE TOUCH] button.



The display now changes to:



The important thing to note, however, is that there are four One Touch memories per Music Style (for the 128 ROM Styles, the 64 Disk Link memories and the Disk User memory).

2. Press one of the big $[1]\sim[4]$ fields to select the corresponding One Touch memory.

If you press the third field, the display looks as follows:



Note: If the Arranger suddenly starts playing, first press the [START/STOP] button and then the [SYNC] button. One Touch indeed activates the SYNC function.

3. Press the [OFF] field if you no longer need the One Touch setting.

If you do not press the [OFF] field, the [ONE TOUCH] button keeps lighting to signal that you are still using a One Touch program.

4. Press [EXIT] to return to the Master page.

Using VariPhrases

The VariPhrase function is a revolutionary Roland technology that allows you to manipulate audio data (samples) in an incredibly flexible way.

Once the audio data have been sampled and encoded, they can be played like any of the "regular" sounds (the ones we have been using so far), while they have the advantage that you can use vocal phrases, etc., that sound perfect in any key, and at any tempo. VariPhrase is thus ideal for adding seemingly live vocals or solos to the VA-76's accompaniments.

Six phrases have been preprogrammed for each of the 128 internal Music Styles. You can also sample or import your own audio material and use it with any Music Style you see fit. See "More about the Vari-Phrase part" on page 69.

Here's how to use the pre-programmed VariPhrases: Note: Feel free to ignore steps $(1)\sim(5)$ if you don't want to select another Music Style (for that's what these steps are all

1. Press the [VIRTUAL BAND] button to select the following display page:




- 2. Press the [EASY ROUTING] field.
- 3. Press the [In A BAND] field.
- 4. Make all necessary selections.
- 5. On the "Select a solo instrument for your right hand" page select any sound you like.

We're not going to use it here, so pick any sound you

6. Check whether the Keyboard Mode [ARRANGER] button lights, and press it if it doesn't.

Press the VARIPHRASE [MELODIC] button (so that it lights).



The display briefly shows the following page where you could select another phrase. But please ignore it here. It will disappear after a few seconds.




The VariPhrase part is switched on, while the Upper1 part is automatically switched off. You can check this by pressing the Keyboard Mode [OTHER] button: the field should be displayed in white, while [UP1] should be blue. Press [EXIT] to return to the Master page.

Note: See "What are 'parts'?" on page 35 for details about UP1, UP2, etc.

(Note that, after switching on the VariPhrase part, you can add the Upper1 and other Keyboard parts. Be sure to first activate the part, then switch on UP1, etc.)

- 8. Play a few notes in the right half of the keyboard. Start by playing one note at the time, then try chords. Amazing isn't it? But the realism of the sounds you hear is not even half the story:
- **9.** Use the [TEMPO/DATA] dial to change the tempo. You can also press [TEMPO/TAP] several times (Tap Tempo function).
- 10. Again play a few notes in the right half of the keyboard and change the tempo while doing so. The audio follows your every tempo move – and keeps sounding just perfect! The phrase continues but is transposed halfway trough.

11. Select the Original or Variation pattern (see page 25), play a chord in the left half of the keyboard, and press the [START/STOP] button to start Arranger playback.



- 12. Again change the tempo while the Arranger is running, and play a few VariPhrase notes.
- 13. Now try out the two remaining preset phrases by pressing first the [BACKGROUND] and then the [RHYTHMIC] button.

The difference between BACKGROUND, MELODIC, and RHYTHMIC phrases lies in their use: Background phrases are perfect for backing vocal effects, Melodic phrases can replace a vocalist, and Rhythmic phrases could be seen as "melodic raps".

Note: See page 45 for some examples of the VariPhrases assigned to the Music Styles. Please note that not all VariPhrases start on the first beat. These are indicated in bold type in the list.

Of course there is a lot more you can do, so be sure to read the "VariPhrase clinic" on page 45.

Note: In SPLIT mode (see page 36), you can decide whether to play the VariPhrase part via the left or right half of the keyboard.

Note: You can also sing yourself by connecting a microphone to the VARIPHRASE [INPUT] socket. See "Using live vocals" on page 57.


3.6 Listening to Standard MIDI Files

Standard MIDI Files are sequences almost any sequencer can read. Though you can use your VA-76 as "playback machine" of such Standard MIDI Files, it is also possible to mute the melody part and to play it yourself.

1. Insert the supplied Zip^{TM} disk into the appropriate drive (the one below the keyboard).

Note: While Zip disks are too large for the floppy drive, be careful never to insert a floppy disk into the Zip drive as that may damage the drive or its heads.

- 2. If necessary, press the [START/STOP] button to stop Arranger playback.
- 3. Press the [SONG COMPOSER] button.



The display now looks as follows:



(There may be a different name or no name at all in the upper white field on your VA-76.)

4. Press the [Song List] field.



Wait for the Zip (or floppy) drive to read what is on the disk.

5. If the [ZIP] field is not displayed in white, press it.

6. Use the [←][→] fields to select the next or previous group of four songs if the one you want to listen to is not displayed.

You can also use the [TEMPO/DATA] dial for doing so

7. Press a song field to select the song you want to listen to.

The RAM information field is still empty.



That is because the selected song has not yet been loaded into the VA-76's RAM memory and thus cannot be played back straight away.

8. Press the [Load] field.

This time, the name of the selected song is displayed in the RAM information field.

- 9. Press the [PLAY ▶] field to start playback. If you like, you can now play along to this Standard MIDI File. The Arranger, however, cannot be used while the Song Composer is running.
- 10. Press the [STOP | ◄] field to stop playback. If you like, you can press the [♣Back] field to return to the initial Song Composer page:



You can then use [◀◀ BWD] and [FFW ▶▶] to rewind to an earlier measure or fast forward to a later one. See "Song Composer clinic" on page 65, for details.

You could also press the [EXIT] field to return to the Master page, though that would not be practical.

 During Song Composer playback the Master page looks as follows:



Pressing the [Song] field takes you back to the display page where you can select another song. However, on the Master page you cannot control Song Composer playback (Start, Stop, REW, FFW, etc.).

 If Song Composer playback is stopped, selecting the Master page would switch off the Song Composer mode and take you back to Arranger mode where you can use the automatic accompaniment function.

Minus One playback

Your VA-76 allows you to mute any given part of the song you are currently playing back. You could use this feature to mute the solo part on disk so that you can play it yourself. This is called *Minus One playback* (because one part of the original song is muted).

You can solo whichever part you like, and even mute several parts simultaneously.

All Keyboard parts remain active. In other words, you are free to use the Upper1/2, VariPhrase, Lower1/2, and M.Bass parts in whichever split or layer combination (see page 35) you like. The MDR part is also available but selecting this part means that other Keyboard parts are temporarily deactivated.


Note: Whenever you start playing back a new song or return to the beginning of the current song (by pressing the [STOP $\blacksquare | \blacktriangleleft |$ field), all Keyboard parts, except Upper1, are be switched off and the VA-76 selects the Whole Keyboard mode. This is not the case however, if you select a User Program memory.

Note: When playing back one of your songs in which you used the VariPhrase part and one of your own phrases (User memory), you must load the phrase(s) in question before you start playback. See page 69.

1. Insert the supplied Zip^{TM} disk into the appropriate drive (the one below the keyboard).

You can also use any other Zip or floppy disk, of course. It must contain a Standard MIDI File, though.

- 2. If necessary, press the [START/STOP] button to stop Arranger playback.
- 3. Press the [SONG COMPOSER] button.




4. See steps $(4)\sim(8)$ above for how to select the desired song on disk.

It would be a good idea to start playback and to stop it after a few measures.

Note: If the field in the upper left corner on the Master page reads [Song], you can press it to jump to the page where you can select a Standard MIDI File. 5. On the Song Composer page, press the [Minus One] field.



The display now looks as follows:



The numbers 1~16 represent the tracks of the selected Standard MIDI File. Standard MIDI Files can contain up to 16 different parts that each receive on a different MIDI channel.

The [ON]/[OFF] fields next to the numbers indicate whether the tracks in question will be played back or not. No field means that the track in question contains no data.

6. Press the [ON] field next to track/channel [4]. In most Standard MIDI Files, the melody part is assigned to track/channel 4. Pressing this field (to make it read [OFF]) is thus a good guess. This channel corresponds to the VA-76's UP1 part.

Note: The on/off status of the tracks can be written to a User Program (see page 127).

- 7. Select a Tone for the Upper1 (UP1) part.
- See "Super Tones" on page 28 or "Selecting Tones for the Keyboard parts" on page 37. There is a function that allows you to link Tone selection for the Upper1 part to the parameter settings of the selected song so that your melody will sound exactly like the original part. See below.
- 8. Press the [STOP | ◄] field twice to return to the beginning of the song.
- 9. Press the [PLAY ▶] field to start playback, and play along to the Standard MIDI File.

Feel free to use the performance functions (see page 51). If necessary, use the [TEMPO/DATA] dial or the [TEMPO/TAP] button to change the tempo.

- 10. Press the [STOP | ◄] field to stop playback.
- 11. Press the [←Back] field to return to the Song Composer page.

12. Press [EXIT] to return to the Master page. The Master page now looks different, because the field in the upper left corner is called [Song]. See page 31.




13. Press the Keyboard Mode [ARRANGER] button if you once again want to use the Arranger.

UP1 linked to Song


Here is a function that may come in handy when playing back Standard MIDI Files with the melody part muted (something we call "Minus One") so that you can play it yourself. See page 32 for details about Minus One performances.

Linking the Upper1 part to the Song Composer means that it will use the same Tone as the original melody part (on track 4) of the Standard MIDI File/song. Pitch Bend, Modulation, and other performance effects will also be muted.

- 1. Press the Keyboard Mode [OTHER] button.
- 2. On the display page that appears now, press the [KEYBOARD MODE] field in the upper right corner (if it is not displayed in white).



Press the [Options] field. The display now looks as follows:



3. Press the UP1 Linked to Song [OFF] field to make it read [ON].

The Upper1 part is now linked to track 4 of the Standard MIDI File you are playing back. In some cases, this may mean that the sound changes somewhere in the middle of the song – but at least it does so in perfect sync with the accompaniment so that you don't have to worry about it.

Note: The default setting for this parameter is "ON".

- 4. Press [EXIT] to return to the Master page.
- 5. Press [SONG COMPOSER] to return to the song page.

4. VA-76 clinics

In this chapter, we will have a closer look at some of the VA-76's functions. While "Scratching the surface" on page 22 only showed you what to expect and how to obtain instant gratification, this chapter is already a little more technical. But again, not all parameters and functions will be covered here so as not to overwhelm you. So be sure to also read the rest of this manual. Note: The alphabetic index at the end of this manual may prove invaluable for locating the desired information at a later stage.


4.1 Keyboard Mode clinic

The KEYBOARD MODE setting is the singlemost important parameter of your VA-76 because it determines which parts (or Tones) and sections are available. Though the Easy Routing function (see page 22) sets these parameters automatically based on your answers, you should familiarize yourself with the KEYBOARD MODE concept.

Arranger and Piano modes

The VA-76 has two major keyboard modes: ARRANGER and PIANO. These can be selected using the [ARRANGER] and [PIANO] buttons.

In many instances, pressing [ARRANGER] or [PIANO] provides a nice starting point for further fine-tuning. Select ARRANGER when you need the automatic accompaniment function and wish to activate its chord recognition in the left half (see page 102 for details). Select PIANO to switch off the Arranger's chord recognition.



Note: Pressing either button not only selects the desired Keyboard Mode but also sets a series of other parameters. In some cases, the parts you may have been using up to that point are suddenly muted. Another important aspect is that the split point (see below) will be set to "C4" when you press [ARRANGER].

In ARRANGER mode, the keyboard is split into two halves. The *left* half is used for playing chords that the Arranger uses for transposing the Music Style patterns in realtime. The *right* half, on the other hand, can be used for adding a live melody to the Arranger's auto-

matic accompaniment. This melody can be played using the Upper1 (UP1) part. Feel free to add other parts for creating richer sounds. See page 36.



Arranger control

Upper1

The settings affected by the KEYBOARD MODE [ARRANGER] button are:

Split mode with the split point at the C4.

Only the UP1 part is active in the right half of the keyboard (see "What are 'parts'?" below for an explanation of this concept).

Arranger Chord= Left (see page 102).

Intelligent chord recognition (see page 101).

This means that one button (here (ARRANGER)) allows you to prepare the main parameters for working with the automatic accompaniment (called "Arranger").

In **PIANO mode**, the Upper1 part is assigned to the entire keyboard.



Upper 1 (UP1) using the A11 St.AcPiano 1 Tone

Later on, you will discover that this way of using the keyboard is also called *Whole*, and that you do not need to work with a piano sound.

The settings affected by the KEYBOARD MODE [PIANO] button are:

Whole mode with only UP1 active.

The 11 St.AcPiano 1 Tone is assigned to UP1.

Arranger Chord= Off (see page 102).

This means that the Arranger cannot be transposed in realtime while the [PIANO] button lights. You could, however, use the Arranger's drum accompaniment for rhythmic backing. Press the [START/STOP] button to start and stop it.

Note: There is a Global Parameter that allows you to block the selection of the piano Tone for UP1 and go on using the Tone that is currently assigned to the Upper1 part. See page 195.

Split point in Arranger mode

When the [ARRANGER] button lights, the keyboard is split in two halves. The split point is located at a C key. This key is called the "C4":




There may be situations where the automatically assigned range is not what you need. In that case, you can change the split point:


1. Press the Keyboard Mode [ARRANGER] button (so that it lights).

This switches on the Arranger and splits the keyboard.

2. Press the Keyboard Mode [OTHER] button.



The display now looks more or less as follows:



If this page is not displayed, press the [SPLIT] field so that it is displayed in white.

3. Use the [←][←] fields to the left and right of the displayed keyboard to select the new split point. The setting range is F1~F#7.

Note: Your settings can be written to a User Program and recalled at a later stage. See page 127.

Other

As soon as you change any of the Other parameters, the [ARRANGER] or [PIANO] button goes dark (if it was on). This is done to signal that the current settings no longer correspond to the preset settings of the Arranger or Piano mode.

As stated above, the Keyboard Mode [ARRANGER] and [PIANO] buttons select the Arranger or Piano mode and also make a number of preset settings. In most instances, these settings work just fine. There are, however, other possibilities that allow you to use the VA-76 in an even more flexible way. Before looking at them we'd like to clarify the following:

What are 'parts'?

The VA-76 allows you to use several sounds simultaneously. Some of these sounds can be played in real-time. These are the *Keyboard parts*. Other parts are played by the Arranger/Music Styles and are called *Style parts*. And finally, there are the *Song parts* that are controlled by the Song Composer function.

Below please find an explanation of the Keyboard parts. (See page 107 for the Style parts.)


- UP1 (Upper1): Though there are only slight differences between Upper1 and Upper2, Upper1 is normally the main solo part (and switched on automatically in Piano mode).
- UP2: The Upper2 part can be used as additional solo part to be layered with the Upper1 part, or as an alternative melody sound. Except when the UP2 Split function is activated (see page 86), it is perfectly possible to switch on Upper2 while Upper1 is off.
- **(VariPhrase)**: This part triggers the VariPhrase function (see page 29).
- MEL Int (Melody Intelligence): This part is triggered by the Arranger and plays automatic harmonies. You cannot play it yourself. You can choose from among 18 harmony types (see page 99).
- LW1: The Lower1 part allows you to play chords with your left hand. Use it whenever you want to add live chords, such as strings, to your right-hand melody.
- LW2: The Lower2 part is to Lower1 what Upper2 is to Upper1, i.e. it allows you to add a second sound to the notes you play with your left hand, or to alternate between two sounds.
- MBS: The Manual Bass part can supply a semi-automatic bass part to your left-hand notes. It is only available in SPLIT mode (see below). If activated while the Lower parts are off, it is no longer triggered automatically, in which case you can also play chords.
- MDR: The Manual Drums part is somewhat different from the other Keyboard parts in that you can only select Drum Sets for this part. It does not allow you to play melodies because every key is assigned to a different sound. Select this part whenever you feel like drumming on the keyboard. See page 42.

Using the WHOLE Keyboard Mode

Whole means that all keys trigger the same part(s). There is thus no split. You can assign up to five parts to the entire keyboard: LW1, LW2, UP2, UP1, and the part. The MDR part cannot be layered with (added to) the other parts. Also note that when you switch on the part, all other parts (except UP2) will be deactivated. You can, however, add UP1, LW1, and LW2 to the VariPhrase part once it has been switched on.

- 1. Press the Keyboard Mode [OTHER] button.
- 2. Press the [KEYBOARD MODE] field in the upper right corner (so that it is displayed in white).

The display now looks as follows (the [KEYBOARD MODE] field must be white):



3. If the [WHOLE] field is not displayed in white, press it to make the display look like in the above illustration.

In the central part of this page, you can switch on all Keyboard parts you need, and switch off those you don't need.


Switching parts on and off

4. Press the fields of the parts (LW2, LW1, etc.) you want to play via the keyboard and switch off the parts you do not need.

Active parts are displayed in white fields (and their button lights, see below), while switched-off parts are displayed in blue.

Be aware, however, that activating the [MDR] or field means that [IW1], [LW2], and [UP1] (as well as [MDR] or []) will be switched off. After activating the VariPhrase part, you can, however, add the UP1, UP2, LW1, and LW2 parts if you like.

Yet another way of switching keyboard parts on and off is by using the KEYBOARD PARTS buttons to the right of the BANK/NUMBER section:



If a part is on, its button lights (Upper2 in the above illustration).

Note: The [M.BASS] button can only be activated in SPLIT mode.


Note: If none of the part fields is displayed in white (and if non of the KEYBOARD PARTS buttons lights), the notes you play on the keyboard will not be audible. (It would, however, be possible to go on controlling the Arranger.)

By the way: selecting WHOLE does not mean that the Arranger is automatically switched off, or can no longer be used. See "Arranger Chord Mode" on page 102 for details.

Note: Your settings can be written to a User Program and recalled at a later stage. See page 127.

Using the SPLIT Keyboard Mode


Split means that the keyboard is divided into two halves (at the C4 mentioned above). You can use the VariPhrase (), LW1, LW2, and MBS parts in the left half, and the UP1 and UP2 parts in the right. (It is also possible to use an additional split between UP1 and UP2, see "Upper 2 Split" on page 86.)



Alternatively, you can use the MDR part in the right half and drum to the chords you play with the LW parts. Yet another option would be to use the Vari-Phrase () part in the right half and LW1 and/or LW2 (with or without the MBS part) in the left. Note that it is also possible to assign the VariPhrase part to the left half of the keyboard.

Here's how to activate the SPLIT keyboard mode:

- 1. Press the Keyboard Mode [OTHER] button.
- 2. Press the [KEYBOARD MODE] field in the upper right corner (so that it is displayed in white). The display now looks as follows (the [KEYBOARD MODE] field must be white):



If the [SPLIT] field is not displayed in white, press it to make the display look like in the above illustration.

In the central part of this page, you can switch on all Keyboard parts you need, and switch off those you don't need.

Note the line that separates the ALMI, LW2, and MBS parts from the UP1, UP2, MDR, and ALMI parts. Unlike previous Roland arranger instruments, the VA-76 allows you to play chords (and add an automatic bass part) with your left hand, while drumming with your right. In the past, the MDR (or M. Drums) part used to be automatically assigned to the entire keyboard, which is still possible (in WHOLE mode) but not mandatory.

Note: See "Drumming on the keyboard" on page 42 for more information about the MDR part.

4. Press the fields of the parts (LW2, LW1, etc.) you want to play via the keyboard and switch off the parts you do not need.

Active parts are displayed in white fields (and their button lights, see below), while switched-off parts are displayed in blue.

5. If necessary, change the split point. See "Split point in Arranger mode" on page 35.

This split point indeed applies both to the chord recognition area of the Arranger and the SPLIT keyboard mode.

Note: If you like, you can activate a Hold function for the LW1/2 parts. That way, briefly pressing the notes to be played by the LW1/2 parts is enough. The Arranger has a similar function (called ARR Hold). See also "LWR Hold" on page 90.

Note: If none of the part fields is displayed in white (and if non of the KEYBOARD PARTS buttons lights), the notes you play on the keyboard will not be audible. (It would, however, be possible to go on controlling the Arranger.)

Note: Your settings can be written to a User Program and recalled at a later stage. See page 127.

4.2 Tone clinic

Selecting Tones for the Keyboard parts

On page 28 we already mentioned the SUPER TONES buttons that can be used for selecting one of 40 Tones for the UP1 part, and the One Touch function that prepares 4 different Tones for both the UP1 and UP2 parts. See also "One Touch" on page 99.


Let us now have a look at the "classic" way of selecting Tones. This selection method is available for all Keyboard parts.

In fact, there are two possibilities that can be used indiscriminately at any stage, except for selecting a Variation (only via the display). For the sake of clarity, however, we shall treat them as separate items.

Tone selection via the front panel

Note: All button actions are also reflected by the display. See "Tone selection via the display" on page 39 for the information that appears on-screen.

1. Tell the VA-76 that you wish to select a Tone (sound): press the [TONE] button.




The VA-76 uses a nifty color coding system. As soon as you press the [TONE] button, its indicator as well as the BANK and NUMBER buttons of the currently selected Tone light in red. The color for Music Style selection (see page 59) is green, while orange is used for selecting User Programs.

The display now looks as follows:




The name next to the [A]/[B] fields tells you which Keyboard part is currently active for Tone selection:



Note: The numbers in the upper right corner of the display indicate the MIDI address of the selected Tone ("Organ 1").

2. Specify the part for which you want to select another Tone:

Hold down the [PART] button and press one of the NUMBER buttons.



If you only press the [PART] button, all GROUP and BANK indicators go off, while the NUMBER indicator that corresponds to the currently selected part lights. If you then release it, the part select page appears on the display. See also page 39.

Note: The VariPhrase part (2) cannot be selected here. Use the [BACKGROUND], [MELODIC], [RHYTHMIC], and [USER] buttons for choosing the desired VariPhrase. See the "VariPhrase clinic" on page 45.


3. Press the [GROUP] button to select the group that contains the desired Tone (A or B, the corresponding indicator lights).

The above display contains eight Bank selection fields that tell you more about the contents of the Tone banks in the selected Group.

Note: See also the Tone lists starting on page 222 for the address of the desired Tone.

When you select a GROUP, the VA-76 automatically activates the BANK that was active in the previous group. Here is an example: if the Upper1 part currently uses the "A31 Organ 1" Tone, selecting group B means that bank 3 (SYN LEAD) is automatically suggested (but you still hear the organ).

Another way of deciding which group you need is by looking at the BANK buttons on the front panel. The banks of group A are printed above the BANK buttons, and the banks of group B appear below the BANK buttons:



4. Press a BANK [1]~[8] button (so that it lights) to select a Tone bank within the active group.

Each Tone group (A and B) contains eight banks. Here are two examples:

- a) for a solo synthesizer sound, select GROUP B and BANK 3 (SYN LEAD);
- b) for a trumpet sound, select GROUP A and BANK 8.
- 5. Press a NUMBER [1] ~[8] button to select a Tone within the active bank.

Only now will the new Tone be loaded. You could take advantage of this system to prepare the group and bank with your left hand, while continuing to play the melody with your right hand. Then, all you need to do is press the desired NUMBER button just before the beat where you wish the new Tone to take effect.

6. Play a few notes on the keyboard to check whether you like the Tone you have just selected.

In many instances, the VA-76 does not select the requested Tone but an even better one (our "favorite" for that particular Tone family). That is because there is yet another Tone category called "Variation".

Let us briefly summarize the various Tone categories:

Tone category	Meaning		
Group [Example: B]	The highest level that specifies which 8 Tone banks are available.		
Bank [Example: B3–]	The second level whose contents depend on the selected group. Each bank contains 8 Tones (numbers).		
Number [Example: B38]	A memory within the selected bank. This specifies the desired Tone.		
Variation [Example: B38 <2>]	An alternative sound for the selected Tone/ number that is either directly or indirectly related to the same Tone family.		

7. If necessary, select another Variation. This is only possible via the display. See step (8) under "Tone selection via the display" on page 39.

The number of Variations depends on the selected Tone number. There may be as many as 30. It is also possible to select "no Variation". This is the Tone proper, referred to as *Capital* (it is displayed without a number between < >).

Note: It is possible to change the "preset" Variation (or Capital) that is recalled when you select a Tone. You can take advantage of this when you don't agree with our "favorite" selection. See "Choosing your own Tone favorites (Customize Preferred Tone)" on page 40.

Note: Apart from the Variations, there are also Tone Maps. See page 41 for details. The Tone selection display behaves as follows:

a) If you only select a number (using the BANK/NUMBPR pad), the Tone selection page is not displayed:


b) If you press a BANK button, the Tone selection display waits until you have specified a NUMBER, after which it disappears

c) If you press the [TONE] button (or [Tone] field) and then select a Tone; the Tone selection display does not disappear automatically. In that case, you need to press [EXII].

Tone selection via the display

Let us now look at how to use the display for selecting Tones. For details about the terms used in this paragraph, see "Tone selection via the front panel" on page 37.

1. Press the [Tone] field in the display.




The display now looks as follows:



If you look at the BANK/NUMBER buttons, you will notice that they now light in red.

The name next to the [A]/[B] fields tells you which Keyboard part is currently active for Tone selection:



Note: The numbers in the upper right corner of the display indicate the MIDI address of the selected Tone ("Organ 1").

2. Press the [Part] field in the lower left corner of the display.



Alternatively, you can hold down the [PART] button for about one second, and then release it. This will also take you to the following display page.

The display now looks as follows. The currently selected part (the one whose name appears inside the arrow on the Master page, see above) is highlighted:



3. Press the field of the Keyboard part you wish to select (UP1, UP2, etc. – left column).

That field is now displayed white-on-blue.

Note: The VariPhrase part () cannot be selected here.
Use the [BACKGROUND], [MELODIC], [RHYTHMIC],
and [USER] buttons for choosing the desired VariPhrase.
See the "VariPhrase clinic" on page 45.

Note: If this page is not displayed, press the [Keyboard] field. It must be displayed in white.

If you select the MEL Int (M Int) part, the display looks somewhat different:



The lock allows you to override the preset settings. See page 99 for details. It is also displayed for the Arranger parts.

Note: You can also use the [PART] button and the NUM-BER pad for selecting the desired part (see page 38).

4. Press the [Tone] field to return to the Tone selection page.

Now we're back on the following display page:



"favorite" Tone.

- 5. Press the [A] or [B] field to select the desired Tone group.
- 6. Press one of the following fields to select a bank within that group:

Use these fields to select a Tone Bank:



7. Press a Tone field to select a Tone (number). Again, the VA-76 may actually load another Tone than the one you selected. We believe that Tone is even better than the one you set out to recall. If you disagree, see "Choosing your own Tone favorites (Customize Preferred Tone)" for how to change that particular

If the Tone name is followed by a number in angled brackets < >, a Variation Tone has been selected. If there are no angled brackets, the Capital has been selected.

8. Press the [Variations] field to call up the following display page:



The field of the currently selected Variation is highlighted.

There are 28 Variations for the A31 Tone (watch the numbers inside the selection fields).

- a) Press another Variation field on this page to select that Variation.
- b) If none of the Variations on offer corresponds to what you have in mind, press the upward arrow (to select the page that contains Variations 1~9 (if that is possible).

You will have guessed that the downward arrow (usually allows you to select the next page – unless it is grayed out, as is the case here.

c) To use the "main" Tone (Capital), press the Variation field on the first page that has no small number (the topmost field in the left column on the first Variation page). The angled brackets <> next to the Tone address disappear.

Note: Just for your reference: the term "Variation" refers to Tones here, and has nothing to do with the [VARIATION] button on the front panel, or the Music Style pattern of the same name.

9. Press the [←Back] field to select another Tone (if none of the Variations fits the bill).

10. Press the [EXIT] field to return to the Master page.

Choosing your own Tone favorites (Customize Preferred Tone)


As stated earlier, selecting a Tone via the display or the BANK/NUMBER buttons very often means that the VA-76 uses an even better sound than the one you requested— or so the Roland engineers think.

You may not agree with the automatic substitutions and grow weary of always having to select correct Variation you do actually mean when you select the address in question (group, bank number).

Here is how to substitute your "favorites" for Roland's preselections. Note that this can be programmed for all 128 Tone addresses (A11~A88, B11~B88). Here, we shall only show you how to do it for one Tone. Note: These selections are stored automatically. So be sure to either select the Variation you do actually like as favorite, or change the setting back to the previous version before continuing.


1. See "Tone selection via the front panel" on page 37 and "Tone selection via the display" on page 39 for how to select the desired Tone.

For this example, select Tone A31, so that the display looks as follows:



The Organ 1 Tone is automatically selected. Suppose you prefer Variation <8> Trem Organ and want that to be selected when you enter the "A31" address.

2. Press the [Variations] field to call up the following display page:




(Press the [♣] field to select the page with Variations 10~19 or 20~28.)

3. Press the [8 Trem Organ] field to select that Variation.

Note: Press the Variation field without a number ("Organ I" in our example) to preset the Capital Tone as "Preferred Tone".

4. Press the [Customize] field to store this Variation as your new favorite.

The display responds with:



This means that your selection has been stored. After a brief interval, the display returns to the Group/Bank/Number page.

- 5. Repeat this operation for all other Tone addresses you wish to assign a different preferred Tone to.
- **6.** Press the [EXIT] field to return to the Master page. Note: These "Preferred Tone" settings will be saved to disk whenever you use the Save User Program Set function. See page 211 for details.

Selecting different Tone Maps

As you know, the VA-76 comes with 3,646 Tones, which is an impressive number, especially when it comes to selecting a Tone.

That is why there are not only groups (A, B), banks (1~8), numbers (1~8), and Variations (varying number), but also "Tone Maps".

Tone Maps emulate the behavior of a given tone generator. By selecting Tone Map "1", for example, you tell the VA-76 to use the SC-55 Tones rather than the brand-new Tones especially developed for this V-Arranger Keyboard.

Note: This Tone Map system can also be used for editing Standard MIDI Files. See "Change" on page 152.

There are four Tone Maps that correspond to the following instrument models:

Tone Map	Correspondence
1	The Tones found on the E-86 and SC-55 Sound Canvas.
2	The Tones found on the G-800, RA-800, and the SC-88 Sound Canvas.
3	The Tones found on the G-1000, EM-2000 and SC-88 Pro Sound Canvas.
4	New Tones especially developed for the VA-76, VA-7, VA-5 and VA-3; some of them can also be found on the SC-8850.

- Tone Maps 1~3 ensure perfect compatibility with older Music Styles and Standard MIDI Files. Besides, these Maps contain some "classic" sounds you wouldn't want to miss.
- Tone Map 4 (the brand-new sounds) contains 1,616 new Tones with the best material ever released by Roland.


Here's how to select the desired Tone Map:

1. On the Tone selection page, press the [Map] field.



Press to open the Map selection page

The display now looks as follows:



The "CC32" messages refer to a MIDI control change that allows you to select the Maps from an external MIDI sequencer or any other MIDI instrument capable of sending these messages.

This information is also important for you when you browse through the Tone Lists on page 222 in search of a given Tone. Always look at what it says behind the "CC32=". That number (1~4) tells you which Tone Map to select.

2. Press the [Tone Map] field you wish to select. This means that all Tones you select from now on belong to that Tone Map until you change this setting again.

Here's how you can tell which Tone Map is currently being used:

Map information



This information is also displayed on other pages (mark the "Map" field). Here is another example:




Note: Tones without a "Map" indication belong to Map 4 (the new VA-76 sounds).

A word about the new Tones

All new VA-76 Tones (Map 4) are fantastic, of course, but some of them are truly amazing. In the Tone List on page 222 (and on the display pages), look out for Tones that start with a "V" (for "virtual").

Select them and try playing at different velocities (strengths) to discover the rich nuances that can be obtained. There is a trumpet Tone, for example ("V Trumpet", A81, Variation 13) that allows you to alternate between a muted and a "full blown" trumpet simply by hitting the keys softer or harder. Various guitar Tones provide a hammering-on/bending sounds when you strike the keys as hard as you can. And there's more.


On top of that, transposing the keyboard to the lowest octave sometimes provides access to some typical noises (scraping over the strings, hitting the body of an acoustic guitar, etc.). See page 54 for how to select the lowest octave. Though these "beautiful noises" are probably too far away for live use, consider throwing them in when recording your own songs. Your sequences will sound even better!



Drumming on the keyboard


The MDR (M. Drums) part allows you to drum on the keyboard. As stated above, this part is available in both SPLIT and WHOLE modes. When used in SPLIT Keyboard Mode, it is assigned to the right half of the keyboard (which means that the notes pictured below are masked until you select another Octave for the MDR part).

The MDR part differs from the other Keyboard parts in that it assigns different sounds to every key. If you select the WHOLE mode and press the C2 (second C from the left), you trigger a bass drum sound. Press the D2 key (the D to the right of the C2) to trigger a snare drum sound, and so on. Consequently, you won't be able to play melodies. Consider the following illustration:




Here's how to activate the MDR part:

1. Press the Keyboard Mode [OTHER] button.




The display now changes to:



This page means that the WHOLE Keyboard Mode is currently selected (see page 35). If you don't see this page, press the [KEYBOARD MODE] field in the upper right corner.

2. Press the [SPLIT] or the [WHOLE] field, depending on whether you wish to assign the MDR part to the entire keyboard (WHOLE), or just the right half (SPLIT).

If you press [SPLIT], the display now looks more or less as follows:



SPLIT would be a good choice if you wanted to control the Arranger with your left hand, while adding a percussion solo with your right.

If you work in SPLIT mode and need to play the Kick, Snare, HiHat, etc. sounds (assigned to the keys that cannot be triggered by the MDR part), consider using the Octave function (see page 54).

3. Press the [MDR] field.

All part fields (WHOLE mode), or all part fields to the right of the dividing line (SPLIT) turn blue (and the KEYBOARD PARTS buttons go dark), while the [MDR] field turns white. That is because you cannot use both the MDR part and UP1, UP2, etc. This wouldn't make sense: playing a drum part often means that you have to play semitone intervals (e.g. C4 → C#4, etc.), while playing a melody would lead to surprising percussion or drum lines if the MDR was also on.

4. Play a few notes on the keyboard to try out the drum sounds.

You may also want to try out the following:

Roll


The Roll function allows you to play perfect drum rolls whose tempo is synchronized with the Arranger or a Composer Song.

1. On the above display page (in SPLIT or WHOLE mode), press the [Options] field.

If you lost the above display page, first press the [OTHER] button on the front panel.

2. Press the [MDrums Roll] field (left column, central field).

The display now looks as follows:



3. Press the indicated [ON/OFF] field so that it reads "ON" and is displayed in white.

4. Again play a note.

The drum sound will now be played as a roll. Rolls are always played in time with the tempo displayed on the Master page. Try this out by changing the tempo using the [TEMPO/DATA] dial.

Using the Modulation lever (press the lever away from you), you can modify the volume of the drum roll. Try this out now.

Setting the Roll resolution (speed)

You can specify the number of notes per beat for the Roll function.

5. Press another note value field than the one that is currently active.

There are six options that have the following meaning:

Symbol	Meaning
1/16	Sixteenth notes.
1/32	Thirty-second notes (half the duration of 1/16 notes).
t	Triplet (three notes in the space of 2).
s	Swing (syncopated notes, where the second note of a pair drags a little).

The default value is "1/32". Selecting shorter values may result in machine-gun type rolls at high tempo values. Always specify the resolution after setting the Style or Song tempo, or change it to a more usable value if your setting turns out to be too optimistic to produce natural rolls.

6. Press [EXIT] to return to the Master page.

Selecting Drum Sets for the MDR part

The MDR part may already be a remarkable function by itself. But things really become interesting when we tell you that the VA-76 comes with 116 different Drum Sets to choose from.


There are Drum Sets for just about any musical genre you can think of – and usually, you can even choose among several alternatives. See page 233 for a list of the available Drum Sets. While looking at that list, remember that every note plays a different drum sound.

The notes have two "addresses" (see also the chapter about MIDI): a note number $(0\sim127)$, and a note name $(C\sim1\sim69)$. The sounds that can be triggered in WHOLE mode without transposing the keyboard are E0 $(16)\sim66$ (91). Lower and higher notes require that you transpose the MDR part using the Octave function (see page 54).

The readily available drum sounds are indicated by means of greyed keys in the list for easy identification. Remember, however, that in SPLIT mode, only the notes C3 (48)~G6 (91) are available – unless you change the split point (see page 35).

1. See "Selecting Tones for the Keyboard parts" on page 37 for the basic operation.

Remember that you can either work via the display or with the BANK/NUMBER pad after pressing the [TONE] button. The display should look as follows:



2. Select the MDR part:

- Either hold down the [PART] button while pressing NUMBER [3];—or—
- Press the [Part] field on the above page, and then press the [MDR] field. (Then press the [Tone] field to return to the above page.)
- 3. Select the desired Drum Set (here you only need to select a bank and a number).



See "Tone selection via the front panel" on page 37 and "Tone selection via the display" on page 39.

Be sure to try out at least the Drum Sets whose names start with a "V". The V-VoxDrum Set (Tone Map 4, 88) is especially interesting for voice percussion. If you take a close look at the table below, you will recognize that they follow a pattern: bank "1" of all Maps contains generally usable Drum Sets, bank "2" Drum Sets with effects (ambience, special Dance noises), bank "3" rock kits, etc.

Note: The Drum Sets labelled CC32= 122 (General MIDI 2) and CC32= 119 (XG) cannot be selected via the front panel. You need to play back a Standard MIDI File using the Composer, or transmit these CC32 values to the VA-76 via MIDI

Tone Map 4	74 KICK&SNARE 2	71 ORCHESTRA	41 ELECTRONIC
11 STANDARD 1	75 ASIA	72 ETHNIC	42 TR-808
12 STANDARD 2	76 CYMBAL&CLAP	73 KICK & SNARE	51 JAZZ
13 STANDARD L/R	77 GAMELAN 1	75 ASIA	61 BRUSH
14 V-Pop15t	78 GAMELAN 2	76 CYMBAL&CLAP	71 ORCHESTRA
15 V-R&B	81 SFX	81 SFX	81 SFX
16 V-Fiesta	82 RHYTHM FX	82 RHYTHM FX	88 CM-64/32L
21 ROOM	83 RHYTHM FX 2	83 RHYTHM FX 2	
22 HIP HOP	E X3 MHTYHR P8	128 CM-64/32L	CC32= 122
23 JUNGLE	85 SFX 2		(General MIDI 2)
24 TECHNO	87 CYM&CLAPS 2	Tone Map 2	1 GM2
25 ROOM L/R	88 V-VoxDrum	11 STANDARD 1	9 GM2 ROOM
26 HOUSE	128 CM-64/32L	12 STANDARD 2	17 GM2 POWER
31 POWER		21 ROOM	25 GM2 ELECTRIC
32 V-Rock1St	Tone Map 3	31 POWER	26 GM2 ANALOG
33 V-Rock25t	11 STANDARD 1	41 ELECTRONIC	33 CM2 JAZZ
41 ELECTRONIC	12 STANDARD 2	42 TR-808/909	41 GM2 BRUSH
42 TR-808	13 STANDARD 3	43 DANCE	49 GM2
43 DANCE	21 ROOM	51 JAZZ	57 GM2 SFX
44 CR-78	22 Hip-Hop	61 BRUSH	
45 TR-606	23 JUNGLE	71 ORCHESTRA	CC32= 119 (XG)
46 TR-707	24 TECHNO	72 ETHNIC	1 standard kit XG
47 TR-909	31 POWER	73 KICK&SNARE	2 standrd kit2 XG
51 JAZZ	41 ELECTRONIC	74 E-40 Modified	9 room kit XG
52 JAZZ L/R	42 TR-808	81 SFX	17 rock kit XG
61 BRUSH	43 DANCE	82 RHYTHM FX	25 electro kit XG
62 BRUSH 2	44 CR-78	128 CM-64/32L	26 analog kit ZG
63 BRUSH 2 L/R	45 TR-606		33 jazz kit XG
64 V-JazzBrush	46 TR-707	Tone Map 1	41 brush kit XG
71 ORCHESTRA	47 TR-909	11 STANDARD	49 classic kit XG
72 ETHNIC	51 JAZZ	21 ROOM	121 SFX 1 kit XG
73 KICK & SNARE	61 BRUSH	31 POWER	122 SFX 2 kit XG


▶ Numbers indicated as "123" are MIDI Program Change numbers

Note: As you see, the Sets are divided over several Tone Maps. See also page 41.

Note: There are no Variation Drum Sets, which is why the [Variations] field is not displayed when the MDR part is selected.


4.3 VariPhrase clinic

The revolutionary VariPhrase function allows you to play vocals or other sampled phrases via the keyboard - at any pitch, and at any tempo. 48 of those phrases reside in the VA-76's ROM memory. They are divided over two groups (A & B), with 3 banks per group, and 8 memories per bank (1~8).



Switching on the VariPhrase part

Switching on the VariPhrase part () is simple: press a bank button (Background, Melodic, Rhythmic) and you're there.



You will notice that one of the number buttons lights. If you press a bank button while the Arranger can be used (i.e. as long as you do not playback a Composer song/Standard MIDI File), the VA-76 automatically selects a phrase for you. Six of these selections have been prepared for each Music Style in ROM. The VariPhrase part allows you to play four notes

simultaneously.

Here are three examples of the phrases that have been prepared for Music Styles A11, A12, and A13:

A11 LightRk1			A13 LightRk3		
Background	A1-4	Uaah uuh F	Background	A1-8	Na,nanana F
Melodic	A2-3	Ooh, Baby M	Melodic	A2-6	
Rhythmic	A3-4	DoYeahDat M	Rhythmic	A3-4	DoYeahDat M
Background2	B1-5	Yeah,ah M	Background2	81-5	Yeah,ah M
Background3	82-6	Wow,wow F	Background3	B2-6	Wow,wow F
Rhythmic2	B3-8	Keep on F	Rhythmic2	B3-8	Keep on F
A12 LightRk2					
Background	A1-8	Na,nanana F			
Melodic	A2-7	HoneyiNed M			
Rhythmic	A3-4	DoYeahDat M			
Background2	81-7	Eh,eh,eeh F			
Background3	B2-6	Wow,wow F			


B3-8 Keep on F

Rhythmic2

See page 59 for how to select Music Styles.

Let us now look at another way of switching on the VariPhrase part. Though you do not need this procedure for activating the VariPhrase part, it will help you add the Upper1 part to the phrase if you so wish.

1. Press the Keyboard Mode [OTHER] button. The display now looks as follows:



2. Press the VariPhrase field (2) so that it is displayed in white.

You will notice that the [UP1] (or LW1) field turns blue if it was white. That is because every time you switch on the VariPhrase part, the UP1 (or LW1) part is switched off. You can, however, activate UP1 and/or UP2 (or LW1) after switching on the VariPhrase part, while it is also possible to add the LW1, LW2, and MBS


Note: The VariPhrase part is available both in WHOLE and SPLIT modes. In SPLIT mode, it can also be assigned to the left half of the keyboard, which is useful for BACK-GROUND and RHYTHMIC phrases (see page 35 for details about the WHOLE and SPLIT modes).

- 3. If you also need the Upperl part, press the [UP1] field.
- 4. Press [EXIT] to return to the Master page.

Selecting other phrases for playing

Selecting other phrases is a matter of using the following buttons:

 Press [GROUP] to select group A or B. The indicator of the selected group lights.



· Press [BACKGROUND], [MELODIC], or [RHYTH-MIC] to select a bank. Depending on the group you select, these banks are called:

Group A	Group B			
Background	Background 2			
Melodic	Background 3			
Rhythmic	Rhythmic 2			

The bank names tell you something about the kind of situations for which the phrases were originally intended. The *Melodic* phrases can be used for playing solo lines, while the *Rhythmic* and *Background* phrases are probably more convincing for spicing up your music with the odd vocal accent. But there is no need to use the phrases in this way. A Rhythmic phrase might work equally well as solo line.

Use the number buttons ([1]~[8]) to select a memory
of the active bank.

As always, the buttons you press light. In the case of the [GROUP] button, however, the "A" or "B" indicator lights.

Note: You can switch off the VariPhrase part by pressing the bank button that lights. This will once again switch on the UP1 (or LW1) part. You could use this for alternating between instrumental and vocal parts.

Below please find a list of all internal VariPhrases. It also contains the MIDI addresses of these phrases (Program Change and CC00/CC32 Bank Select) that you may not need here, but they may come in handy at a later stage. The VariPhrase part receives on MIDI channel 13. See page 197 for details about MIDI.

One last thing: you can ignore the first number ("1-", for example) as this corresponds to the bank button you pressed (1= Background, 2= Melodic, 3= Rhythmic).

GBN PC CC00 CC32 Phrase Name

GBN	PC	CC00	CC32	Phrase	Name
BACI	(GRO	UND 2			

BACKGRO	IND			DAG	KGRC	HUD		#2012##################################
A1-1 001	096	096	Uaah uaah M	B1-1		096	096	Hah,ha,ha M
A1-2 002	096	096	Uaah uaah F	B1-2		096	096	Hah,ha,ha M
A1-3 003	096	096	Uaah uuh M	B1-3		096	096	Ahi,ai,ai M
A1-4 004	096	096	Ugah uuh F	B1-4		096	096	Ahi,ai,ai F
A1-5 005	096	096	Uah Uah U M	B1-5		096	096	Yeah,ah M
A1-6 006	096	096	Uah Uah U F	B1-6		096	096	Yeah,ah F
A1-7 007	096	096	Uahua Uah F	B1-7		096	096	Eh,eh,eeh F
A1-8 008	096	096	Na,nanana F		032	096	096	Sha la la F
10516016-95998	on with a	NEW TARREST	DOMESTIC CONTROL OF STREET	As transport of	18/20/2005	orene con no	Laboration Consu	Ananyanan amana amana ana an
MELODIC	11194	151	AF18KA	BAC	KGRO	JND 3		
A2-1 009	096	096	Baby, Baby M	82-1	033	096	096	Humaah,hu M
A2-2 010	096	096	Your Love M	82-2	034	096	096	Humaah,hu F
A2-3 011	096	096	Ooh, Baby M	B2-3	035	096	096	TuruTuruh M
A2-4 012	096	096	Com'on M	82-4	036	096	096	TuruTuruh F
A2-5 013	096	096	SetMeFree M	B2-5	037	096	096	Wow,wow M
A2-6 014	096	096	OohDarlin M	B2-6	038	096	096	Wow,wow F
A2-7 015	096	096	HoneylNed M	B2-7	039	096	096	BlaimBlai M
A2-8 016	096	096	HoneylNed F	82-8	040	096	096	BlaimBlai F
May are and to obscious		A2003443		#EST	es chicaconi	304.地面的	erer er	Harrison of the
RHYTHMIC				BHT	THMIC			
A3-1 017 A3-2 018	096	096	Dot,do,do M	83-1		096	096	Tutu tah M
A3-2 018 A3-3 019	096	096	Tururu,Tu M	B3-2		096	096	Tutu tah F
	096	096	DoidiDatt M	B3-3	043	096	096	Lero,lero M
	096	096	DoYeanDat M	B3-4	044	096	096	Lero, lero F
	096	096	Dabut, Dab M	B3-5	045	096	096	EihlOlele M
A3-6 022	096	096	Dabada,Da M	B3-6	046	096	096	EihlOlele F
A3-7 023	096	096	Taratta,T M	B3-7	047	096	096	Ma,ma,mma F
A3-8 024	096	096	ShuShuDo F	B3-8	048	096	096	Keep on F

The VariPhrases in *Bold-Italic* do not start on the first beat. You thus have to play them with a different timing, such as on the second beat of a bar, etc.

Note: Though they sound just fine by themselves, using the VariPhrases in combination with the Arranger is an even more rewarding experience. See page 29 for how to do that.

Combining/splitting a VariPhrase with another Keyboard part

It is also possible to add either or both Upper parts (UP1 and UP2) to your VariPhrase playing, which allows you to double the vocals with a piano, trumpet, organ, etc. part, or to add a chord backing to your left-hand VariPhrase part.

The important thing to remember is that you need to switch on UP1 or LW1 after activating the VariPhrase part, for the VariPhrase part at first cancels the UP1 or LW1 part. You can however, write your VariPhrase layers to a User Program. See page 127.


"Playing" with the VariPhrases

There is a lot more you can do with the on-board (and your own User) phrases than we have seen so far. Let us have a look at a few examples.

Key Assign

The Key Assign parameter allows you specify whether or not you can play chords with the VariPhrase part (). Why would you want to do that?

Selecting *Mono* means that the VariPhrase part only sounds one note you play with your right hand, even though you may be playing two-voice lines or even chords. In a layer combination, the VariPhrase part would thus allow you to combine a chordal part (Upperl or Lowerl) with a solo vocal line. Here's an example: Suppose you switch on the VariPhrase and Upperl parts. Here's what happens when you play chords in the right half (in SPLIT mode):




Note: The exact notes sounded by the VariPhrase part depend on which chord note you strike last. The above result may require some practice.

Mono can be used very effectively: if you press one key to start the selected VariPhrase and then add a second key, the phrase is transposed up or down – but continues. With the "Honey, I need you" phrase, for instance, you could press a C for playing "Honey", then add the E to the right of the C just before "I". This would transpose the pitch of the "I" to E. If you then release the C (but not the E), while playing a G, the rest of the phrase ("need you") will be played in G. In other words: the phrase runs from start to finish but changes its pitch whenever you press another key. (If you select *Poly*, the "I" and "need you" would be played using two voices. *Poly* allows you to play chords.)

Here's how to select the Mono mode:

1. Press the Mode [MONO/POLY] button to make it light.




If the indicator doesn't light, the POLY mode is selected. Here, we need the MONO mode.

- 2. Switch on the Upper1 part (see page 45) and select the SPLIT Keyboard mode (see page 36).
- 3. Play a few chords with your right hand and listen to what happens.

Here are two other ways of selecting the MONO mode:

- a) Press and hold the Mode [MONO/POLY] button.
- b) Proceed as follows:
- · Press the [FUNCTION MENU] button.
- On the Function Menu page, press the [VariPhrase] field.
- · On the VariPhrase page, press the [Global] field.
- On the Goldbal Parameters page, press the [Key Assign] field.

The display now looks as follows:



- 4. Press the [Mono] field.
- 5. Press [EXIT] to return to the Master page.

Trigger

Yet another way of changing VariPhrase playback is to select how the selected phrase behaves once you have started it, and how it will be stopped. The VA-76 provides three options you will find on the "Trigger" page.


1. Activate the VariPhrase part (see page 45) and switch off all other parts (see page 36).

2. Select a VariPhrase.

The following may not be what you think is necessary, but it shows you just how user-friendly the VA-76 is. We will indeed take advantage of the jump functions


mentioned under "Which button does what? (Panel Info)" on page 24 for calling up a page that cannot be selected directly. (If you want to select the Trigger parameters "the hard way", see step (b) above.)

3. Press and hold the Mode [STEP/SYNC] field. This calls up the following display page:



This is not the page we need, but the one we do need is only one press away:

4. Press the [Trigger] field.



Now look at the three icons in the right section. They already tell you how a running phrase will be stopped:

Gate— This means that the phrase will play for as long as you hold a key down. When you release it, the phrase stops. (Depending on the *Mode* setting, see page 82, holding the key down for a long time may mean that the selected phrase is repeated.)

Trigger— Press a key once to start playback of the phrase. Release the key and press it again to stop playback. This is similar to using a casette deck: you press the Play button to start playback, and the Stop button to stop it. Here, of course, the key acts as Play and Stop button.

Drum— This setting means that pressing a key will start playback of the selected phrase and that you cannot stop it: it will go on sounding until it is finished. The phrase is not looped, however. This setting is particularly useful for (rap) phrases you want to start at given intervals without worrying about stopping them.

Note: Selecting this Trigger mode means that the phrases cannot be looped (because there would be no way of stopping them).

5. Press [EXIT] to return to the Master page.

Note: See also page 77 for additional VariPhrase parameters.


Adding realtime expression

Things you ought to know about VariPhrase


The VariPhrase technology allows you to change the pitch of a phrase (by playing melodies) while the speed (tempo) and character/timbre are kept constant. On the other hand, you are free to change the tempo without affecting the pitch/timbre of a phrase.

This is remarkable for two reasons:

a) Usually, the pitch of recorded/sampled material can be changed only by playing the data at a higher or slower speed, so that the tempo changes. (Conversely, changing the tempo also means that the pitch changes.) Consider the following illustration.



On a sampler, playing higher notes will speed up the phrase, so that a J = 120 rhythm suddenly changes to e.g. J = 144, which would make the material useless for live performances. Besides, traditional samplers do not allow you to lock a phrase's tempo to the tempo of a sequencer (or Arranger), while VariPhrase does.



b) Sampled or recorded audio consists of frequency clusters that describe the kind of sound, its timbre, etc. We'll spare you the details... Such clusters also contain certain frequencies that make a sound (e.g. your voice) recognizable. No matter how hard you try to imitate someone else's voice, you will always produce frequency clusters that will betray you. Such frequency clusters (partials) are called the formant. Changing the pitch of recorded/sampled audio material means that the formant is also transposed. And that's precisely why a piano sample of the note "A4" sounds like a cheap electronic piano when you use it for the note "D5" (the D further to the right). Why? Because the speed is different (see above), and -more importantly-because the "typical piano frequencies" are shifted to a different range.

VariPhrase analyses the frequency content of your audio material and is therefore capable of (a) keeping the formant constant, or (b) deliberately changing the formant, so that you can modify the character of a phrase to an extent that it almost sounds as though you had changed a woman's voice into a man's, or vice versa

The VA-76's controllers can be used to modify these – and other– aspects. Here's how:

D Beam controller

- 1. Press the D Beam Controller [ON/OFF] button (button must light) to activate the D Beam Controller
- 2. Select a phrase with a man's face (for "male voice"). See the table on page 46.
- 3. Activate the VariPhrase part.
- 4. Move your hand over the "eyes" while playing something.

The function currently assigned to the D Beam Controller is called "Cut & Reso Up and A Formant Up". (Cut& Reso is for the VA-76's Keyboard parts, while Formant Up is for the VariPhrase part.)

The male voice you selected in step (2) changes drastically as you move your hand closer to the D Beam's eyes.

Other controllers

Of course, you can also use the remaining controllers: the Ribbon, the BENDER/MODULATION lever, Aftertouch, the Foot Switch and the Foot Pedal. Based on what you will learn on page 55 and following, you should be able to try them out now. See page 186 for how to assign other functions to these controllers. The important thing to remember is that only the parameters marked with a will influence the VariPhrase part.

Please bear in mind that the formant is only one aspect that can be influenced in this way. The others are: Pitch, Time (speed), and sometimes Level (volume).


Yet other parameters affect the VariPhrase indirectly or change its behavior. They allow you to use a controller to increase or decrease the influence of an LFO (an oscillator used for modulation effects that result in vibrato, WahWah, etc.) on various VariPhrase parameters.

Realtime VariPhrase control via the display


There may be times where you don't feel like using any of the controllers mentioned above – or where they have been assigned other functions you do not want to change.

In that case, consider using three on-screen sliders in the touch screen for adding some mild (or wild) changes to the currently selected VariPhrase:


- 1. Activate the VariPhrase part (see page 45) and switch off all other parts (see page 36).
- 2. Press the [CONTROLLERS] button.



The display now looks more or less as follows:



3. Press the [VariPhrase] field. The display changes to:




4. Use the on-screen sliders to modify the pitch, the speed (Time), and/or the formant of the currently selected VariPhrase.

Positive values (+) mean that you increase the basic Pitch, Time, or Formant settings, while negative values (-) mean that you decrease that value. You can thus influence these parameters in either direction.

If you press the field of the slider's name (Pitch, Time, Formant) so that it is displayed in white ("Formant" in the above illustration), you can also use the [TEMPO/DATA] dial or the Numeric Entry pad for setting the desired value.

Note: Enter the value "0" (or return the slider to its central position) to once again use the normal Pitch, Time, or Formant value.



Note: The last settings (slider positions) you make here will be written to a User Program (see page 127). Be sure to select the values you really do want to change, or else set these values back to 0 before writing your settings to a User Program.

Adding effects to the VariPhrase part


Though already amazingly flexible by itself, the Vari-Phrase part can even be enhanced using two dedicated effects. These Reverb and Chorus effects operate independently from the "main" Reverb and Chorus effects. In many instances, the Reverb effect is already switched on but let's go through the motions. Note: The VariPhrase part's assignment to the OUTPUT 1 sockets cannot be changed. This means that the following effects are always available. (The other parts can also be assigned to the OUTPUT 2 sockets, in which case they are no longer processed by the internal effects.)

Reverb and Chorus depth


1. Activate the VariPhrase part (see page 45) and switch off all other parts (see page 36).

Note: The following affects the VariPhrase part – not just the currently selected phrase. Thus, if you select another phrase at a later stage, it will use the effects settings you make here.


2. Press the [EFFECTS] button.



3. On the display page that appears now, press the [Keybrd Mixer] field.



The display now looks as follows:




- 4. Press the [Reverb] field if it is not displayed in white.
- 5. Move the leftmost slider (☑) while playing on the keyboard and listen to how the sound changes.

 Note: If the VariPhrase part is not displayed, press the [←] field several times.

Let us now add some Chorus to the VariPhrase part.

6. Press the [Chorus] field in the left column. The display now changes to:



7. Again use the leftmost slider to increase or decrease the Chorus depth while playing a few notes on the keyboard.

Note: See page 124 for how to select another Reverb and/or Chorus type.


Single Part/Palette

Suppose you are finalizing a new song. All settings are ready (Music Style, tempo, Keyboard part Tones, etc.). The only thing that's missing are the effects settings that sound just right for the VariPhrase part. On the pages shown so far, you always see the Reverb/Chorus depth settings of other parts as well.

That may not always be to your liking, because you wish to concentrate on the VariPhrase (or any other) part. In that case, proceed as follows:

1. On any of the above pages, press the [Single Part] field.

The display now changes to:



2. Use the [♠][♣] fields to select this page if the name in the upper left corner does not read "€2". You can now press the [Reverb] or [Chorus] field and use the slider in the right column to change the Reverb or Chorus depth.

Note: You can also use the [TEMPO/DATA] dial and the Numeric Pad page (see page 49).

3. Press the [Palette] field to return to the "mixer" pages of steps (3) and (6).

[Single Part] and [Palette] are also available for the other effects and parts.


4.4 Expression clinic

Allow us to introduce the VA-76's performance functions. Also called *Controllers*, they allow you to add expression to your playing, which is a very important aspect for simulating glissando's, bendings, and other changes to the timbre that will make your melodies even more convincing.


Note: See page 91 for details about the VA-76's velocity sensitivity and related possibilities.

D Beam Controller

The D Beam Controller is no doubt the most exciting and spectacular performance function of your VA-76. You can use it to modify various aspects of your V-Arranger Keyboard, such as bending the notes, intensify their vibrato, change the filter frequency (to make the sound brighter or mellower), and even to play arpeggios or chords.



The D Beam Controller has two sensors that detect motion (such as your hand or body movements) in front of it. These "sensed" positions are translated into M1DI messages that can be assigned to a variety of parameters. See page 186.



1. Press the D Beam Controller [ON/OFF] button (button must light) to activate the D Beam Controller.

2. Activate the UP1 part.


The easiest way to do so is by pressing the Keyboard Mode [ARRANGER] or [PIANO] button. See also page 34.

Note that the D Beam Controller also applies to the other Keyboard and the VariPhrase parts, while it also allows you to control certain Arranger functions. Here, however, we'll keep things simple by showing you how it influences the UP1 part.

3. Move your hand over the "eyes" while playing something.

Listen to how the UP1 sound becomes brighter and mellower as you move your hand up or down. Furthermore, the sound becomes more synthesizer-like. That is because the "Cut & Reso Up and Formant Up" function is assigned, which means that you can change the filter setting. (If you activate the VariPhrase part, this function allows you to change the characteristics of the selected phrase by turning it into a man's or woman's voice, see page 48.)


4. If you no longer need the D Beam Controller, press its [ON/OFF] button again (indicator goes dark).



Note: The values generated by the D Beam Controller can be recorded by the Composer and are transmitted to the VA-76's MIDI OUT port.

Ribbon controller (Touch control)

The Ribbon/Touch controller is a performance function that was already available on vintage analogue synthesizers, the Roland JP-8000, and the EM-20. We included it because we figured that you might like to influence one of the VA-76's parameters by sliding a finger over the ribbon located below the BENDER/MODULATION lever for a more natural "feel" of the temporary change you'd like to produce.



1. Activate the UPI part.

The easiest way to do so is by pressing the Keyboard Mode [ARRANGER] or [PIANO] button. See also page 34.

Note that the Ribbon/Touch controller also applies to the other Keyboard and the VariPhrase parts, while it also allows you to control certain Arranger functions. Here, however, we'll keep things simple by showing you how it influences the UP1 part.

2. Slide your finger from left to right while playing something, then release it again.

Listen to how the UP1 sound becomes brighter and mellower as you slide your finger to the right or left. That is because the "Cut & Reso Up and Formant Up" function is assigned. (If you activate the VariPhrase part, this function allows you to change the characteristics of the selected phrase by turning it into a man's or woman's voice.) At first, the Ribbon controller's function is the same as that of the D Beam Controller, but you can change that (see page 186).

Note that it is also possible to directly press the position you think corresponds to the desired parameter value for "stepped" changes. You thus do not need to slide your finger to the left and right all the time.

The Ribbon controller always works from left (0) to right (maximum value). That is why most assignable parameters are labelled "Up" or "Down". Moving your finger to the far right will thus increase (Up) or reduce (Down) the value of the parameter being controlled. Once you release the Ribbon, the value of the parameter being controlled returns to the "no change" position.

Note: The values generated by the Ribbon controller can be recorded by the Composer and are transmitted to the VA-76's MIDI OUT port.

Aftertouch


The VA-76 is equipped with an Aftertouch-sensitive keyboard. Like most instruments supporting Aftertouch, it generates channel Aftertouch messages, which means that one Aftertouch value will be transmitted by each MIDI channel (or part).

Aftertouch is generated when you press a key even further down after playing a note. The effect obtained is usually similar to the one you can achieve with the BENDER/MODULATION lever: you can change the pitch, modify the volume, intensify the modulation, etc.

In the VA-76's case, however, you can also control the Arranger and even the VariPhrase part.

Aftertouch data can only be received by the following parts: Upper 1/2 and Lower 1/2, the VariPhrase part, and the Arranger.

Pitch Bend/Modulation



Turn the BENDER/MODULATION lever towards the right to bend the notes you are playing upwards, or to the left to lower the pitch. Release the lever to return to the standard pitch. The Pitch Bend function can also be used for controlling various VariPhrase aspects (pitch, formant, level, tempo).


Push the lever away from you to add vibrato to the notes you are playing (Modulation). Release the lever to remove the vibrato. See page 188 for how to set the Pitch Bend interval.

Transposition

If you are used to playing a song in a particular key, the Transpose function will help you go on playing in that key while sounding in another one. That way, you can accompany a singer or instrument without changing your fingering.

Hold down the [ONE TOUCH] button while pressing User Program [DOWN] or [UP].

Press [DOWN] to lower the pitch in semitone steps (a C to B, an E to E, etc.).




Note: Transposition applies to all parts except the MDR (Manual Drums) and ADR (Accompaniment Drums) parts.

To transpose from the key of C to G, hold down [ONE TOUCH] and press User Program [UP] seven times (or User Program [DOWN] five times).

Be sure to return to the original setting (no transposition) by pressing the "opposite" User Program button ([DOWN] or [UP]) the same number of times as the one ([UP] or [DOWN]) you pressed first.

The transposition is indicated on the Master page:




The "C4" actually refers to a semitone increase of the pitch, so that you hear a "C sharp" every time you play a C. This also means that rather than the A you press, you will hear "A sharp" (or "B flat"). The above setting corresponds to pressing User Program [UP] once while holding down the [ONE TOUCH] button.

Note: This setting is also reflected on the Transpose display page (see below).

Setting the transposition interval via the display

If you prefer to set the transposition interval via the touch screen with a nice graphic, way, here is how to.

- 1. Press the Keyboard Mode [OTHER] button. What you see now, depends on the currently selected keyboard mode. The things to look out for here are the [ARRANGER CHORD] and [KEYBOARD MODE] fields in the upper left and right corners.
- 2. Press the [KEYBOARD MODE] field in the upper right corner (so that it is displayed in white).
- 3. Press the [Transpose] field.



4. In the display, press the key that corresponds to the note you would like to hear every time you play a C. Note: Selecting "0" means that the transposition is off. This is the only way to activate or switch off this function. Your setting can, however, be written to a User Program (see

page 127).
See below for details about the Transpose Mode options. You can activate all three simultaneously, if you like.

Note: The MDR and ADR parts are never transposed. Every key (note) of the MDR/ADR parts is assigned to a different percussion sound. It is thus in your best interest to leave the Manual and Accompaniment Drums parts alone.

Selecting the sections to be transposed

The three fields below the keyboard allow you to specify which parts should be affected by the Transpose setting:

Internal—The Keyboard and Arranger parts will be transposed. Notes received via MIDI, however, will be played without change.

Song—Only the Song parts will be transposed. This is only meaningful when you play back a Standard MIDI File or one of your own songs with the VA-76's Song Composer.

MIDI "IN"— Only the notes received via MIDI IN will be transposed. In a way, this is the same as the Rx Shift parameter in MIDI mode (see page 201).

Though it is perfectly possible to switch on all three options, you can never switch off all three of them. At least one of them must be on. *Internal* could be useful to transpose only the Keyboard parts so that you can play to a Composer song in "your" key but sound in the song's key.


5. Press [←BACK] to return to the previous display page, or [EXIT] to return to the Master page.

Octave

The Octave function is another useful parameter that allows you to change the pitch of the selected part in octave steps (12 semitones).

You could take advantage of this function for solo parts where you need the UP1 and UP2 parts to trigger the same Tone, while UP2 plays one octave above or below UP1. Another use for this function is to provide access to the "noises" of the VA-76's new "V" Tones so as to be able to trigger the scraping, knocking, etc.

This probably only works when you use a Keyboard part (UP1, UP2, LW1, or LW2) in WHOLE Keyboard Mode (see page 35). Working in SPLIT mode indeed means that you can only play the notes up to a certain point (the split point). For the "noises", you need to select the setting "-3". Note that this also means that you need to play the "real" notes at the right end of the keyboard, because the entire part/Tone is transposed down.



This parameter also comes in handy when you wish to trigger Drum Set sounds (using the MDR part) that are not accessible via the keyboard in its normal state. Remember that there are 76 keys, while some Drum Sets provide drum/percussion sounds for all 128 notes supported by the MIDI standard.

- 1. Press the Keyboard Mode [OTHER] button.
- 2. Press the [KEYBOARD MODE] field in the upper right corner (so that it is displayed in white).

3. Press the [Octave] field.




4. Press the field that corresponds to the Keyboard part you wish to transpose in octave steps (UP1, UP2, etc.).

As you see, the display also indicates the current Octave settings for all Keyboard parts.

- 5. Now press the field that corresponds to the desired Octave setting.
- "-" values mean "down/lower". Example: "-3" means that the part in question is transposed three octaves down. All other values (except "0") mean "up/higher".
- 6. Press [◆BACK] to return to the previous display page, or [EXIT] to return to the Master page.

PAD buttons



The PAD buttons [1] and [2] allow you to quickly access a function you would normally have to select via the display (which may involve several presses). At first, PAD [1] is used to immediately return to the beginning of the current Style pattern (useful when you are out of sync with a singer or other musician and want to "re-synchronize" the accompaniment with the singer/soloist). PAD [2], on the other hand, allows you to switch the Bass Inversion function on and off (see page 102).

Holding [1] or [2] down for more than a second takes you to a display page where you can assign other functions to these buttons (see page 194). The PAD functions can be written to a User Program.

FC-7 Foot Controller

The VA-76 allows you to connect an optional FC-7 Foot Controller to the FC7 PEDAL socket.





At first, the switches of this controller are assigned Arranger control functions. You can, however, assign other functions to these switches. See page 193 for details.

Note: The FC-7 assignments apply to the VA-76 and are not written to individual User Programs. Selecting another User Program is therefore not enough to reconfigure the FC-7.

Sustain Footswitch (Hold)

The Hold function can be used for the following parts in isolation or in combination: Upper 1/2, Lower 1/2, and M.Bass, on condition that you select the WHOLE keyboard mode. In SPLIT mode, the sustain pedal's Hold function only works for the right-most part. When Upper 1 and 2 are layered, the Hold effect will work for both of them. In UP2 Split (see page 86) and UP2-to-Left modes, the Hold only applies to the Upper1 part.

Note: Do not forget to connect an optional DP-2, DP-6, or BOSS FS-5U footswitch to the SUSTAIN FOOTSWITCH socket.

Foot Switch

An optional DP-2, DP-6, or BOSS FS-5U footswitch connected to the FOOT SWITCH socket can be used to perform various functions. If you do not change the factory setting, this footswitch allows you to start and stop Arranger playback.

The footswitch assignment can be saved to a User Program. See page 191 for how to assign the desired function to the footswitch.

Expression (Foot Pedal)


controlled using this pedal.)

An optional EV-5 or BOSS FV-300L expression pedal connected to the FOOT PEDAL socket allows you to control the volume of all parts by foot. You can reverse the expression pedal's effect and specify that certain parts are not to be controlled by the expression pedal. Furthermore, you can use this pedal for controlling M-FX parameters, in which case the expression function is no longer available for other Keyboard parts. (The Formant of the selected VariPhrase can also be


Master Tune

This is not really a performance function, but it allows you to tune your VA-76 to acoustic instruments that cannot be tuned.

1. Press the [FUNCTION MENU] button.



The display now looks as follows:



2. Press the [Global Parameter] field.



If this page is not displayed, press the [Keyboard] field so that it is displayed in white.

3. Play the A below the [ENDING] button while using the [♠][♣] fields to set the desired tuning. The default value is "440.0". You can return to this value by pressing the [Default] field.

Alternatively, you can press the [Value] field and set the desired value using the [TEMPO/DATA] dial.

4. Press the [EXIT] field to return to the Master page. Press the [←Back] field to return to the Function Menu if you need to set other functions.

Scale Tuning


Another useful function is called Scale Tuning. This allows you to use oriental, asian, and other scales in much the same way as on an oriental keyboard (EM-50 OR, etc.). See page 92 for details.

Metronome

The VA-76 is equipped with three metronomes: one for Style playback, one for Song Composer recording/playback, and one for User Style Composer programming.

If you wish to hear a metronome during Style playback, here is what you need to do:

1. On the Master page, press the metronome field (so that it turns white).




- 2. Start Arranger playback, and you will hear the metronome.
- 3. Press the metronome field again to switch off the metronome.


Metronome Output

The VA-76 also allows you to select how the metronome is played back:


1. Press the [CONTROLLERS] button.



This selects a display page with controller options. The exact look of that page is of little importance, for you need to press the [Metronome] field at the bottom of the screen, which is available on all pages:



The display now looks as follows:



If it doesn't, press the [Style] field (it must be displayed in white).

2. Select one of the following options:

Int—The metronome signal is played by the Drum Set currently assigned to the MDR part (see page 44) and thus transmitted to the OUTPUT 1 & 2 and PHONES socket.

Midi—The metronome signal is sent to the VA-76's MIDI OUT port and can be played by an external module. This module must receive on MIDI channel 16. The safest would be to assign MIDI channel 16 to part 10 of a multitimbral module. That way, its Drum Set is triggered by the metronome. (The MDR part transmits on MIDI channel 16.)

EXT— The metronome signal is sent to the VA-76's METRONOME OUT socket (rear panel). You can connect headphones to this socket and set the metronome's volume using the LEVEL knob. This option may be useful as "click track" for a drummer.

ALL—The metronome is played by the VA-76's MDR part and transmitted to MIDI OUT, the OUTPUT 1 & 2 sockets as well as the METRONOME OUT socket.

Metronome Mode

Yet another option on the above display page is to specify *when* the metronome should be sounded:

Always— The metronome even counts when Arranger playback is stopped. Press this field if you want to hear the metronome at all times (which is probably only useful when practising a new song).

Play— Press this field (so that it is displayed in white) if the metronome should only be sounded while the Arranger is playing back a Music Style pattern (Intro, Original, etc.).

Count-In

This parameter allows you to switch the Count-In function on or off. When on, the metronome will count in the specified number of measures (bars) before the Arranger starts playing.

Note: This count-in is also available when you are using the Sync Start function. In that case, playing a chord means that the Arranger only starts after 1 or 2 measures.

- 1. See "Metronome Output" for how to select the display page with the metronome options.
- 2. Select an option in the *Count-In* section: OFF— The count-in function is off.

1Bar, 2Bar— Whenever you start Arranger playback, the metronome counts in 1 or 2 bars before the selected Music Style pattern starts playing.

Note: The Count-In function can be used independently of the metronome. There is thus no need to activate the metronome in order to hear the count-in.

3. Press the [EXIT] field to return to the Master page.


4.5 Using live vocals

The VA-76 also provides a special part you can use when you want to sing to the music you play on the VA-76. You can also use this part for other audio signals, but please bear in mind that the Audio In part is more.


The audio signal received by the Audio In part is transmitted to the OUTPUT 1 and PHONES sockets.

- 1. Set the [VOLUME] knob to the "MIN" position.
- 2. Connect a microphone to the VariPhrase INPUT socket.

Please use a dynamic microphone. Two models are available from Roland: the DR-10 and the DR-20.




- 3. Set the [LEVEL] knob to the "MIN" position and the [GAIN] switch to "MIC".
- 4. Press the [EFFECTS] button.




5. On the display page that appears now, press the [Keybrd Mixer] field.

The display now contains a page similar to the following:



It doesn't really matter which effet is currently selected. Just make sure the [Keybrd Mixer] field is displayed in white.

6. Press the [→] field several times until the following page is displayed:



7. Set the [Volume] slider to "0", and press the [ON/OFF] field below this slider to select "OFF" (if necessary).

Let us now set the input sensitivity of the VariPhrase [INPUT] socket.

8. Sing into the microphone and gradually increase the VariPhrase [LEVEL] setting (rear panel). Set it so that the INPUT OVER indicator in the VariPhrase section does not light even when you sing at the top of your voice.



This indicator should not light.

Note: At this point, you won't hear your voice because the Audio In part is off.

9. Locate the microphone in such a way that it cannot pick up the signal from the external speakers.

Failure to do so will result in a nasty howling tone also known as feedback. This should be avoided at all costs.

- 10. Press the [OFF] field below the [Volume] slider to make it read [ON].
- 11. Set the VA-76's [VOLUME] knob to a comfortable listening level (about halfway for the time being).
- 12. Gradually increase the setting of the on-screen [Volume] slider while singing or talking into the microphone.

You should now be able to hear your voice.

- 13. You can also add Reverb and Chorus to your voice:
- Press the [ON/OFF] field between the [Chorus] and [Reverb] sliders to make it read "ON". This field can also be used for muting the effects when you need to make an announcement and don't want it to sound like you are in a church, etc.

Note: This function can also be controlled via the assignable footswitch (see page 192).

 Use the [Chorus] and [Reverb] sliders for setting the desired Chorus/Reverb depth. See page 124 for details about these effects.


14. To quickly switch on/off the Audio In part, press the [ON] (or [OFF]) field below the on-screen [Volume] slider.

Note: While the above on-screen settings can be written into a User Program, the settings of the [GAIN] switch and [LEVEL] knob on the rear panel cannot. You may want to write them down for future reference.

- 15. Now try singing and playing together. If your voice is too soft, increase the setting of the [Volume] slider in the display.
- 16. Press [EXIT] to return to the Master page.

Single Part

By pressing the [Single Part] field on the above display page, you select a page where the above parameters are displayed in the following manner. Choose whichever is more convenient for you.



4.6 Arranger/Music Style clinic

Before telling you more about the Music Styles, we'd like to explain the difference between Music Styles and the Arranger. The Arranger is in fact the function (or sequencer) that plays the accompaniments you select. These accompaniments are always related to a given musical genre (or "style"), and are therefore called *Music Styles*. As the VA-76's accompaniments are a lot more than just one pattern that goes on playing until you stop it, the Music Styles comprise several patterns (or divisions).

The Arranger is interactive in two respects: you can tell it in what key it should sound by playing chords; and you can also tell it what kind of of accompaniment it should play by selecting other divisions via the front panel or the touch screen. The Arranger (the "hardware") would be nothing without the Music Styles (the "software"), while the Music Styles would become repetitive after a while without the various divisions.


Selecting Music Styles

Like for Tone selection, there are two possibilities that can be used indiscriminately: you can work the traditional way (using the buttons), or via the display – or mix these two approaches as you see fit.

Style selection via the front panel

Note: All button actions are also reflected by the display. See "Style selection via the display" on page 60 for the information that appears on-screen.

1. Tell the VA-76 that you wish to select a Music Style: press the [STYLE] button (so that it lights).



As soon as you press the [STYLE] button, it lights in green, as well as the BANK and NUMBER buttons of the currently selected Music Style. (The color for Tone selection is red, while orange is used for selecting User Programs.)


The display now looks as follows:




The name next to the [A]/[B]/[C] fields tells you which Music Style is currently selected.

Note: The numbers in the upper right corner of the display indicate the MIDI address of the currently selected Music Style ("B15 ScatSwing").

2. Press the [GROUP] button to select the group that contains the desired Music Style.



There are three Music Style groups with 64 memories each (for a total of 192 Styles):



A & B— These two groups refer to the Music Styles in ROM.

C— This group represents the Disk Link group. These are memories that can be selected in the same way as the ROM memories, even though they load Music Styles directly from Zip or floppy disk.

Note: See also the Music Style list starting on page 251 for the names and addresses of the Music Styles.

When you select a GROUP, the VA-76 automatically activates the BANK that was active in the previous group. Here is an example: if you are currently working with the *B15 ScatSwing* Style, selecting group A means that bank 5 is automatically selected.

- 3. Press a BANK [1]~[8] button (so that it lights) to select a Style bank within the active group. Each Style group contains eight banks.
- **4.** Press a NUMBER [1]~[8] button to select a Style within the active bank.


Only now will the new Music Style be selected. You could take advantage of this system to prepare the group and bank with your left hand, while continuing to play the melody with your right hand. Then, all you

need to do is press the desired NUMBER button just before the beat where you wish the new Music Style to take effect.

Style selection via the display

Let us now look at how to use the display for selecting Styles.

1. Press the [Style] field in the display.



The display now looks as follows:



If you look at the BANK/NUMBER buttons, you will notice that they now light in green.

- 2. Press the [A], [B], or [C] field to select the desired Music Style group.
- 3. Press one of the following fields to select a bank within that group:

Use these fields for selecting a Music Style bank:




4. Press a Style field to select a Music Style (number). While you're at it, you may want to prepare the desired Orchestrator "version" so as to be all set for the next song you want to play. In that case, press the [Orchestrator] field and see page 62 for what to do next.

Working with the Disk Link memories

The VA-76 provides 64 memories (8 banks x 8 numbers) that refer to Music Styles on a Zip or floppy disk. Though these memories behave exactly like the memories of groups A and B (that provide access to the 128 internal Music Styles), they only "work" if the disk in question has been inserted into the drive. Thanks to the VA-76's powerful software, loading a Disk Link Style is as swift as working with internal Styles.

The Music Style referenced by the Disk Link memory you select is automatically loaded from disk and copied to the Disk User memory (see also page 61). This is a RAM memory whose contents are erased when you switch off the VA-76, and overwritten when you select another Disk Link memory (or use the Disk User function).

Here's in a nutshell what happens when you select a Disk Link memory. (Even though the drawing may suggest that this takes quite some time, the VA-76 performs these steps in a split second.)



After unpacking the VA-76, these memories already contain links to 64 Music Styles on the supplied Zip disk. You can also program your own references to other Music Styles on disk (see page 108). You could even "mix" references to a Zip and a floppy disk.

The Disk Link memories are assigned to group C. You can use either of the above procedures for selecting them ("Style selection via the front panel", "Style

selection via the display"). Just be sure to select group C. Here's what the display looks like when group C has been selected:



Even for Music Styles on Zip/floppy, the VA-76 thus displays their names. In fact, it's the names that are important for finding the Styles on a disk. If you change the name of a Music Style that is referenced by one of the Disk Link memories (see page 110), the VA-76 can no longer find it. Conversely, if you have two Zip disks (for example) that both contain a Music Style called "Reggae1", even inserting the "wrong" Zip disk would recall a "Reggae1" Style – but it might be the wrong one (and quite a few other Disk Link memories might not recall any Style at all, because the other names only exist on the "other" disk). Note: See page 62 for the meaning of the [Orchestrator] field.

Do not forget to insert the required Zip and/or floppy disk into the VA-76's drive. Failure to do so may lead to the following message being displayed:



If the Zip drive currently contains another disk, press the [ZIP Eject] field to eject that Zip disk. Then insert the disk that contains the referenced Music Style.

Note: If you do not wish to use the Music Style after all, press [EXIT]. In that case, the VA-76 will go on using the last Music Style it did find.

In the case of a Music Style on floppy disk, the message about a missing Music Style would be:



In that case, press the Eject button on the floppy drive, insert the correct floppy disk, and press the [RETRY] field.

Note: If you do not wish to use the Music Style after all, press [EXIT]. In that case, the VA-76 will go on using the last Music Style it did find.

Disk User

You can also load one Music Style directly into the VA-76's Disk User memory and use it as if it were a 193rd Music Style. You could take advantage of this function whenever none of the 64 Disk Link memories refer to the Music Style you need for playing a given song.

Note: The Music Style in this memory is only available until you switch off the VA-76 or load another Style. Be aware that selecting a Disk Link Style will also overwrite the last Disk User Style you selected.

Note: Unlike the Disk Link memories, the reference to the selected Music Style is not remembered (and therefore not "fixed").

- 1. Insert the Zip or floppy disk with the desired Music Style into the (appropriate) drive.
- 2. On the Music Style selection page (see above), press the [Disk User] field.



The display now looks as follows:



- 3. Press the [FLOPPY] or [ZIP] field to specify whether you want to load a Music Style from a Zip or a floppy disk.
- 4. Press the field that contains the name of the Music Style you want to load.

If the desired Music Style is not displayed, use | → | | → | to select another group of 4 Styles.

You can also use the [TEMPO/DATA] dial for selecting other pages with different Music Styles on the inserted disk.

Note: The VA-76 contains a powerful search engine for quickly locating the desired Music Style on a Zip disk (see page 109). See page 110 for the [Options] field.

Note: Press the [EXIT] field if you do not want to use a Style on disk after all.

6. Press the [LOAD] field to copy the data of the selected Music Style to the VA-76's Disk User memory.

The display page does not change. This was done to allow you... to select another Music Style on Zip or floppy disk. Repeat the above procedure. As soon as you press the [LOAD] field, the name of the newly selected Style will appear in the "User" field in the upper left corner. When the pattern of the currently selected Music Style is finished, the VA-76 switches to the newly selected Style on disk.

7. Start playing with the newly selected Style.

The selection of the Disk User Style will be written to a User Program (see page 127). The User Program in question, however, refers to the memory address – not its contents. Next time you recall such a User Program, the VA-76 will therefore use the Style that resides in the Disk User memory at that time.

If, at that time, you haven't loaded a User Style, the VA-76 will go on using the last Disk Link Style you selected. That is because the Disk User memory also acts as buffer for the Music Styles referenced by the Disk Link memories. If you haven't selected any Disk Link Style since switching on the VA-76, it will go on using the last ROM Style.

8. Press [EXIT] to return to the Master page. The "User" message to the right of the [Style] field alerts you to the fact that you are currently using a Disk User Style.

Ejecting the Zip disk OK, so you've inserted the Zip disk, and now press the eject button on the drive because you want to insert another Zip disk But the Zip disk won't come out of the drive. This was done as a safety precaution because the VA-76, may still nesse to assess the Zip for certain operations. Making it "difficial" that you no longer want to use the current Zip disk is thus the only way to remove the Zip disk. (A floppy disk, on the other hand, can be ejected simply by pressing the eject button on the drive.) 1. Press the [FUNCTION-MENIO] button. 2. Press the [Floppy/ZIP Disk] field. 3. On the page that appears now, press the [Utillity] field. Use of the drive of the control of the co

Orchestrator and Morphing

press the eject button on the drive.


The VA-76's Music Styles are far more versatile than we have seen so far. For one, you can vary the repeating accompaniment patterns (Basic, Advanced, Original and Variation). And you can also mix the parts of two Music Styles so as to create new Music Styles on the fly (Morphing).

The Zip disk is ejected - so you don't even have to

5. Press [FOX 12] to session to the Master page.

Orchestrator

The Original and Variation patterns are the two "basic" Music Style patterns that can be selected by pressing the corresponding buttons on the front panel:



(Note that only one of them can be active.) Whereas [ORIGINAL] selects the simpler version of the repeating ("looped") accompaniment, [VARIATION] calls up a more "stuffed" version.

With the ORCHESTRATOR function, you can further refine and vary the Original and Variation patterns played by the Arranger. This is like orchestrating the accompaniment in realtime, because you can leave out parts, thin out the drum part, or even select a totally different accompaniment.

There are four options for both Original and Variation, while the selected Orchestrator option also affects the Intro and Ending patterns.


1. Activate the VA-76's Arranger and start playback of the [ORIGINAL] or [VARIATION] pattern. See "Using the VA-76's Arranger" on page 25.

2. Do one of the following:


- Press the [Style] field on the Master page (as though you wanted to select a Music Style).
- On the page that appears next, press the [Orchestrator/Morphing] field.

-OR-

· Press the [ORCHESTRATOR] button.



In either case, the display now looks as follows:



3. Press an Orchestrator field to select the desired "orchestration".

As you see, there are four fields. ② corresponds to the *Basic* level found on previous Roland arranger keyboards. ① provides a slightly more sober version of the Basic pattern. ④ corresponds to the *Advanced* level on older Roland models, while ③ is a slightly simpler version.

With these fields, you can thus vary your accompaniments at will so as to make them sound really professional.

Levels ② and ④ can also be selected by pressing either [ORIGINAL] or [VARIATION] twice in succession. There are indeed two Basic and Variation patterns: one for the Original and a second for the Variation level.

Note: The last version you select will be written to a User Program (see page 127), so be sure to prepare the one you want to start with next time you select that User Program. Note: The Music Styles on the supplied Zip disk also contain suitable Orchestrator versions. Other Music Styles you can load with the VA-76, however, may not provide the same flexibility.

Morphing

The Morphing function allows you to create a mix of two Music Styles by using certain accompaniment parts from one Style, and other parts from another Style.

The mixable parts are: Drums, Bass, and Accomp. The latter includes all melodic parts (for a maximum of six) except for the bass. These may be piano, guitar, brass, etc. lines. Morphing allows you to create combinations like the following:

1st Style	2nd Style
Drums	Bass, Accomp
Bass	Drums, Accomp
Accomp	Drums, Bass

Of course, you can also use just one part of the "2nd Style" and two of the "1st Style". It is not possible, however, to switch on two identical parts (i.e. the Bass parts of the "1st Style" and the "2nd Style"). Nor can you switch off e.g. the drums altogether (neither "1st Style", nor "2nd Style"). See page 114 for how to do that.


On the other hand, it is perfectly possible to combine the drums of a waltz with the bass and accompaniment parts of a 16-beat Style, for example. Using two Styles with different time signatures is absolutely no problem. Be aware, though, that the result of your morphing may not be usable in a real-life situation.

If you do use two Styles with different time signatures, the "1st Style" determines the time signature of your morphed Style. In other words: if your "1st Style" is a waltz, the morphed result will use the 3/4 time signature.

The possibilities are endless, because you can not only use the internal Music Styles (groups A and B) but also Styles on Zip or floppy disk (via the Disk Link or Disk User function).

Let us morph (i.e. create) a new Music Style now to see how it works:

1. See steps (1) and (2) above.



The "1st Style" is the one you (or the Virtual Band) selected last, while the "2nd Style" is prepared automatically. What you hear now is the "1st Style" (all three fields in the left column are white).

Note: See below for how to select other Music Styles for the Morphing function.

- 2. Press the [Drum] field in the right column.

 The [Drum] field in the left column turns blue, while the one in the right column turns white. You are now using the drum part of the "2nd Style" with the Bass and Accompaniment of the "1st Style".
- 3. Press the [Bass] field in the right column. This switches off the Bass line of the "1st Style", while the Bass line of the "2nd Style" is activated.
- 4. Try out other combinations.
- 5. Press [START/STOP] to stop Arranger playback.

Let us now select other Music Styles for the "1st Style" and the "2nd Style".

6. Press the [1st Style] field in the display.



This page should look familiar. It allows you to select a Music Style.

7. Assign a Music Style to the "1st Style" memory. Remember that it is also possible to use the BANK/ NUMBER buttons. See "Selecting Music Styles" on page 59 and "Style Morphing (part 2)" on page 98 for operation details.

8. Press the [2nd Style] field.



Again a familiar display page. Note, however, that the [C] and [Disk User] fields are no longer there. While the "1st Style" can be taken from the ROM memory (groups A and B) or a Zip/floppy disk (group C or Disk User), the "2nd Style" must be a ROM Style. That is why you can only select group A or B.

9. Assign a Music Style to the "2nd Style" memory.

10. Press the [←Back] field to return to the Orchestrator/Morphing page, and start morphing again.

Note: Your "2nd Style" will also be stored when you write your settings to a User Program (see page 127). You thus do not have to perform the selection process every time you want to morph.

4.7 Song Composer clinic

On page 31 we already showed you how to play back a Standard MIDI File on Zip or floppy disk. Here we'll record a song using the Arranger as accompaniment.

Recording your music

You can record your music as "Songs" that can be saved to Zip or floppy disk.

Note: Your singing using the Audio In part (see page 57) is not recorded. If you use User VariPhrases during your recordings, do not forget to load them before starting playback of one of your own songs.

Though the following series of steps may seem rather long to perform, you could skip the ones you do not need, while you may want to perform other actions for certain steps. Here, we will take advantage of all "automatic" functions the VA-76 contains with occasional hints for alternatives.

Note: See also "A few remarks about recording songs" on page 132.

- 1. Press the [VIRTUAL BAND] button.
- 2. Press the [EASY ROUTING] field, followed by the [In a BAND] field.
- 3. Now follow the on-screen instructions to select a Music Style and a Tone for your right hand.
- 4. After selecting the "solo instrument", press the [FINISH] field.

Here are other settings you could select:


- See page 59 for selecting another Music Style and page 25 for selecting the pattern you want to start with.
- Press [ORIGINAL] or [VARIATION] if you want to start without the introduction. Use the Orchestrator for selecting another Intro or Original/Variation version (see page 62).

If you need more than the Upper1 part, select additional Keyboard parts (see page 34). It is also possible to use the VariPhrase part for recording and to work with a second (see page 86) or a dynamic split (see page 88).

Note: Rather than performing the above steps, you could recall a User Program with the desired settings (see page 128).

- 5. Press the [START/STOP] button and listen to the tempo. If it is too fast, change it now (see page 27).
- **6.** Press [START/STOP] again to stop playback. This tempo will be used every time you start playback of this song. You can, however change it temporarily during playback, or edit it later (see page 161).

7. Press the [SONG COMPOSER] button.



The display now looks as follows:



See page 132 and following for an explanation of the various fields.

8. Press the [REC ●] field (so that it is displayed in white).

If you like, you can press the [SYNC] button (so that it lights). In that case, you can skip the next step.

9. Press the [START/STOP] button.

Arranger playback and recording start.

Note: You can also start recording by pressing the

[PLAY ▶] field, in which case the Song Composer starts without the Arranger. Press the [START/STOP] button to add the Arranger at a later stage.

10. Play the Arranger chords with your left hand, and the melody with your right.

If you think that playing the chords for the Arranger and the melody simultaneously is too difficult, leave the melody for later (see "Redoing the melody (2nd Trk)") and only play the chords used for transposing the Arranger in realtime. This is similar to working with the Chord Sequencer on previous models. On the VA-76 however, recording the chord changes for the Arranger is part of one integrated, seamless process. Note: You can also use the VA-76's performance functions for your melody playing. See "Expression clinic" on page 51.

- 11. To stop recording, do one of the following:
- Press the [ENDING] button. The Arranger will play the Ending. When it is finished, Arranger playback and Song Composer recording stop.
- Press the [START/STOP] button. This will stop Arranger playback, while recording goes on. This allows you to improvize without accompaniment. (You will also need to perform the following step.)
- Press the [STOP ■] ◀] field to stop recording.

Listening to your song

You probably want to listen to your song now. If you like it, be sure to save it to Zip or floppy disk (see "Saving your song to disk").

- 1. Press the [STOP | ◄] field twice.
 This returns the Song Composer to the beginning of your new song.
- 2. Press the [PLAY ▶] field to start playback.



Playback of your freshly recorded song starts.

3. Press [STOP ■ | ■] again to stop playback, and again to return to beginning of the song.

If you made a mistake in the Arranger chords and would like to record that part again, go back to step (8) above. Make sure that the [2nd Trk] field is not displayed in white (press it if it is), and start again.


Note: This will also erase your melody, so be sure to play it again — or leave it for later (see "Redoing the melody (2nd Trk)").

Redoing the melody (2nd Trk)

Note: 2nd Trk is only available for newly recorded songs. You cannot use it for adding a new melody to a song loaded from Zip or floppy disk. You can, however, use the 16-track sequencer for doing so. See page 141.

Note: Please be aware that 2nd Trk will erase all Keyboard parts, even if you only play the Upper1 part again.

The 2nd Trk function allows you to redo part of your recording. The previous melody version is erased in the process, while the Arranger parts are left untouched. You cannot use 2nd Trk for adding notes to the melody, or for adding additional lines using other Keyboard parts.




Note: From now on, the VA-76's Song Composer takes control over the tone generator. This means that the Arranger can no longer be started/stopped or otherwise controlled. You can, however, use all Keyboard parts (in SPLIT or WHOLE mode).

Note: You could record the melody using the Upper1 and 2 parts or the VariPhrase part. Even the "Keyboard Mode" WHOLE or SPLIT modes, as well as UP2 to Left (see page 88) and UP2 Split (see page 86) are available.

1. Press the [STOP ■ | ◄] field to return to the beginning of the song.


The measure indication above the [PLAY ▶] field must read "1.1".

2. Select a Tone for the new melody part: See "Super Tones" on page 28 or "Selecting Tones for the Keyboard parts" on page 37.



- 3. Press the [REC ●] field (so that it is displayed in white).
- 4. Press the [2nd Trk] field.

This means "redo the melody but leave the Arranger parts unchanged". The relevant part of the display now looks as follows:



5. If you're ready, press the [PLAY ▶] field to start recording.

Remember that this time, there is no keyboard split (but you could select it), so that you could also play with you left hand. This is ideal for recording piano parts, for example.

- **6.** At the end of the song, press the [STOP |] field to stop recording.
- 7. Listen to your song (see page 66).

If you like it, save it to disk, if you're still not happy with your melody, go back to "Redoing the melody (2nd Trk)" on page 66.

Note: See page 147 if you want to change just single notes or other aspects of your song (which is called "editing").

Saving your song to disk

A Composer song you save to disk becomes a Standard MIDI File that can be played back with the VA-76, but also with any other SMF-compatible sequencer.

Be aware that, once a song has been saved to disk, the 2nd Trk option can no longer be used for redoing the melody. You can, however, use the 16-track sequencer for achieving exactly the same effect.

There are two ways of saving new or edited songs:

- a) Via the [FUNCTION MENU] button and the Disk menu (you will have to press the [Save] field).
- **b)** By leaving the Song Composer page. Here, we will show you how to save your song simply by returning to the Master page.
- 1. On the Song Composer page, press the [EXIT] field. The display now responds with:




2. Press the [YES] field.



3. Insert a Zip or floppy disk into the appropriate drive, and press the [FLOPPY] or [ZIP] field to select the drive you want to save your song to.

Note: Do not use the supplied Zip disk for saving your own data. Use a new disk for your own data.



Note: If you want to save the song under its current name, or the name assigned by default (Song_001), you can skip steps $(4)\sim(7)$.

4. Press the [Name] field, because you need to give your brand-new song a name.



Alphanumeric keypad

In fact, you even need to give your song two names: a *Song Name*, and a *File Name*. See page 109 for the difference.

- 5. Press the [Song Name] field.
- 6. Enter the name:
- Move the cursor to the desired position using [←] and [→].
- Enter the character for that position using the alphanumeric keypad. In many instances, you will have to press the desired field several times to select the desired character.
- Use the [A/a] field to alternate between captitals and small letters.
- Press the [Delete] field to delete the character indicated by the cursor ("_"). Press [Space] to insert a space. Press [Insert] to insert a character at the current position. All characters behind this position move one position further to the right.
 - 7. Press the [File Name] field and enter the file name. See page 109 for details. Here, you can only enter 8 characters. All characters will be capitals.
 - **8.** Press the [EXECUTE] field to save your song. The display tells you that the data are being saved, after which it returns to the *Save Disk* page.

5. More about the VariPhrase part

5.1 Playing with the User memories

Loading VariPhrases, VariPhrase Sets or audio files

As stated earlier, you can also use your own VariPhrases, or load up to 16 phrases from the supplied Zip disk. (The Zip disk contains 62 User VariPhrases and 7 Phrase Sets.)

This allows you to expand the "repertoire" of your virtual vocalist. You can also sample your own phrases, save them to Zip and then load them again. It is even possible to load phrases created on a Roland VP-9000, .WAV and AIFF files. These data must reside on an MS-DOS formatted floppy or Zip disk. Careful: the VA-76 cannot read 250MB Zip disks.

Note: The contents of the User memories are erased when you switch off the VA-76. After sampling your own phrases, do not forget to save them to disk.

Note: You can also load —and even sample—new VariPhrases while the Arranger/Recorder is playing back. Loading is so smooth that you can take advantage of this any time you need new User phrases.

1. Insert the supplied (or another 100MB) Zip disk into the Zip drive.

This disk (if it is not the supplied one) must contain at least one .WAV/AIFF file or VariPhrase. You could also load VariPhrases from floppy disk. (You could even save VariPhrases to floppy disk, but be aware that the capacity of a floppy is rather limited.)

2. Press the [FUNCTION MENU] button.

3. In the Function Menu, press the [Disk] field.




4. Press the [FLOPPY] or [ZIP] field in the upper right corner.

This depends on whether the desired phrase resides on a floppy or Zip disk.

5. Press the [A Phrase] field in the left column.

The display now looks as follows:



Now decide whether you wish to load just one Vari-Phrase (Single Phrase), a set of 16 VariPhrases (Phrase Set), or a .WAV/AIFF file (Other Sample Format).

If you press [Single Phrase]

The display now looks more or less as follows:



- a) Use the [←][←] fields to step through groups of eight VariPhrases on the selected disk (Zip or floppy).
- **b)** Press the field that corresponds to the VariPhrase you want to load (so that it is displayed in white).
- c) Use the [↑][↓] fields to select the VariPhrase User memory that should contain the selected VariPhrase. Here, the memories are numbered A1, A2, A3,...B7, B8.
- d) Press [EXECUTE]. The display now informs you that the selected VariPhrase is being loaded, after which the above page is once again displayed. You could now load additional VariPhrases.

If the selected User memory already contains a phrase, there will be a warning.



Press the [YES] field if it is OK to overwrite the phrase in the selected User memory. Press the [NO] field to return to the Disk Load page. Press [←Back] to return to the previous page and select another memory.

If you press [Phrase Set]

The display now looks more or less as follows:




Here, you can load 16 VariPhrases in one go (so-called Phrase Sets), which means that the phrases in the VA-76's User area will be overwritten.

- a) If necessary, use the [←][→] fields to select the page that contains the desired Phrase Set.
- b) Press the field that corresponds to the name of the Phrase Set you wish to load.
- c) Press [EXECUTE]. The Phrase Set is loaded.

If you select [Other Sample Format]

This option allows you to load .WAV or AIFF files from Zip or floppy disk. These files must reside in the root directory of the Zip/floppy disk. If they reside in a sub-directory, the VA-76 cannot not find them. Furthermore, the disk in question must be MS-DOS formatted. Mac OS-format disks are not supported.

The display now looks more or less as follows:




- a) Use the $[\leftarrow][\rightarrow]$ arrows to step through groups of eight .WAV/AIFF files on the selected disk (Zip or floppy).
- b) Press the field that corresponds to the audio file you want to load. The icon in the left column tells you whether that is a .WAV or an AIFF file.

Note: .WAV and AIFF files are audio files you can play back as such (at a fixed pitch). If you want to use them as VariPhrases, you need to encode and possibly edit them. See page 74 and following.

6. Press [EXIT] to return to the Master page.

Selecting a User memory

To use the VariPhrase(s) or audio file(s) you have just loaded, press the VariPhrase [USER] button and use the [GROUP] & [1]~[8] buttons to select the group (A or B) and the memory that contains the desired User phrase.



As soon as the [USER] and a number button in the VariPhrase pad light, the VariPhrase part is switched on. To switch the VariPhrase part off, again press the [USER] button so that it goes dark. Remember that switching on the VariPhrase part will deactivate the Upperl part. You must switch it on manually if you wish to add it to the VariPhrase part.

5.2 Sampling your own phrases

You can also sample your own audio phrases and turn them into fully functional and interactive VariPhrases.

1. Connect a signal source to the VariPhrase [INPUT] socket on the rear panel.

Use a dynamic microphone, or a cassette deck, MD player, etc.

2. Set the [GAIN] switch to match the kind of audio signal you wish to sample.

If you connect a microphone (Roland DR-10 or DR-20), set this switch to MIC. If you connect a cassette deck, etc., set it to LINE.




- 3. Talk or sing into the microphone or start playback of the external signal source.
- 4. Watch the INPUT OVER indicator while gradually increasing the setting of the VariPhrase [LEVEL] knob on the rear panel.

The INPUT OVER indicator must never light.

5. Select a Music Style that uses the time signature of the material you want to sample.

You only need to do this if you intend to use the metronome while recording (see below). 6. Press the SAMPLING [CAPTURE] button.



The display now looks more or less as follows:



- 7. Press the [A] or [B] field to select the desired User Phrase group.
- 8. Press a Phrase memory field (so that it is displayed in white).
- 9. Press the [Capture] field.

Try to select a field that reads NO PHRASE. Memories of that name indeed contain no data.

If all memories are occupied by previously loaded phrases, press a field that contains a phrase you no longer need, then press the [Delete] field. The display responds with:



Press [YES] to erase the selected User memory. Press [Back] to return to the previous page and select another memory. Press [NO] to abort the sampling process.

The display now looks more or less as follows:



10. Enter a name for the phrase you are about to cre-

See page 68.

11. Press the [EXECUTE] field.

The display now looks more or less as follows:



Check the Capturing Free Area field.
If the value is less than "4's", it would be a good idea to delete a User phrase you have already saved to disk (see page 76) to free up sampling memory. Most audio phrases indeed require about four sec onds. Cabe remaining time is ess than this value your sample may be stopped prematurely, which means that you won't be able to record the entire audio phrase.

- a) Press: tie (Barde) feld twice
- h) On the display page that appears now (Plirase Source), press the field of a User phrase you no longer need so that it is displayed in white.

 Note, Be careful not to select the memory you have just selected for sampling, for that won't help you recover any memory capacity, because that memory is still empty,
- c) Press the [Delete] field to dispose of that phras
- d) Press the [Capture] field again.

About the phrase RAM memory.

The total duration available for all 16 User Vari-Phrase memories is ±54 seconds. The required capacity is allocated intelligently. If you work with long phrases, however, you may not be able to take advantage of all 16 memory locations.

Here is an example, if User phrase A1 is 30 seconds long, while A2 uses 14 seconds, and A3 10 seconds, you've already used up the available 54 seconds, so that memories A4-B8 are of no use to you.

12. Press the [TEMPO/TAP] button at the desired tempo, or set the tempo value using the [TEMPO/ DATA] dial.

You can also specify the tempo value of the phrase at a later stage (see page 75). But if you do it here, you won't have to worry about the tempo at a later stage. Besides, setting the correct tempo also allows you to take advantage of the metronome.

13. (Optional) Press the Metronome [OFF] field to activate the metronome.

Note: The time signature cannot be changed here. That explains why we suggested selecting a Music Style with the correct time signature before calling up the Capture function.

14. Press the [START/STOP] button and start singing or playback of the external audio source.

Note: The Reverb or Chorus effect you may hear while recording is not sampled. It may help you make your performance sound more "convincing" though. See page 58 for how to switch it off.

Note: For optimum results, try to sing all notes at the same pitch. If that is impossible, consider using the Robot function (see page 82) but bear in mind that this may affect the sound quality.

15. Press [START/STOP] again to stop sampling. The display now indicates the length of your sample (*Current Capturing Area*) and how much time you have left for other samples (*Capturing Free Area*).

16. Press the [Preview] field to listen to your sample.



You can also play on the keyboard to audition your sample. The audio material will be looped and repeated until you release the [Preview] field or the key you pressed. (If you're not happy with your sample, press [Capture Retry] and start again.)

Here, we will assume that you are happy with your recording. What you have now, is a rough audio sample that needs some cleaning up and a special processing step that is called *Encode*. It is this encoding operation that transforms an audio file (a regular sample) into a VariPhrase whose tempo remains the same regardless of the pitch at which you are playing back the sample, and whose formant, etc. can be changed in a creative and –above all– controlled way.

Note: If you save this audio file to disk before doing the touching up, it will also be saved as an encoded phrase. But it would be relatively useless, so please bear with us.


Phrase Edit: touching up the audio material

Note: The following settings need to be finalized by pressing the [EXECUTE] field. This "encodes" the phrase and "burns" these settings into the wave information.

There are a number of additional steps you need to perform before your audio material behaves like the internal VariPhrases and the ones on the supplied Zip disk.


Truncate

17. Press the [Edit] field.



Truncate allows you to shorten the phrase. This may be necessary if the beginning of the phrase contains a blank (or noise) you do not need when performing with the phrase, while the end is a little long for a perfect loop.

Consider the following illustration:




The above audio phrase runs from the "Start" till the "End" position. The grayed areas denote noise or blanks you don't need because they delay the onset of the future phrase (Start), while also making a smooth loop impossible (End). These areas need to be disposed of.

This means you need to move the *Edit Start* address to a position just before "I", while the *Edit End* address must be shifted to a position just after "you".

Another use for Truncate is to shorten a phrase by disposing of the parts you don't need. Here's an example: suppose it turns out that "I wanna be" is all you need. In that case, set the *Edit Start* address like in the preceding example, and move the *Edit End* address to the position immediately before "phrased".


- 18. Press the [Truncate] field in the upper left corner so that it is displayed in white.
- 19. Press the [Edit Start] field so that it is displayed in white
- 20. Use the [TEMPO/DATA] dial to change the *Edit Start* point.

Press a key on the keyboard (or the [Preview] field) to play back the audio material, and adjust the Edit Start position so that the phrase starts at the desired position whenever you press a key on the keyboard (or the [Preview] field).



Note: It would be a good idea to work with headphones at this stage, switch off the external amplifier, and set a rather high volume. If you listen very carefully, you will notice that a properly pronounced "I" starts with a slight pressure. Don't discard that. Likewise, be careful no to create too short a "you". A good indicator for both addresses is to listen to the phrase in a loop (by holding down the [Preview] field or the key you pressed). If the rhythm "fits", your Edit Start and End points are perfect.

- 21. Press the [Edit End] field.
- 22. Use the [TEMPO/DATA] dial to select a different Edit End point.



If you are sure the sample sounds alright with the new Start and End positions, you can finalize its new size by erasing the audio information before the Edit Start and after the Edit End position.

23. Press the [EXECUTE] field to truncate the sample. The animated clock tells you that the audio data are being edited.

Normalize

Another thing you may want to do before going on, is maximize the level of the phrase you have just sampled. This sometimes improves the dynamics of your audio data, while it certainly increases the level. This may come in handy if the recording level was a little low, so that the phrase is a bit too soft.

Note: See also "Amplitude" on page 78 for how to change the volume of a phrase at a later stage.

Normalize boosts the level of the audio data in such a way that the volume is maximized, while distortion is avoided.



1. On the *Phrase Edit* page (see above), press the [Normalize] field in the upper right corner. The display now looks more or less as follows:



2. Use the [♠][♣] fields to set the desired Normalize percentage.

In most instances, "97%" is probably a good choice. Do not select a higher value because that may lead to distortion

Note: Be aware that if the audio data contain noise, that noise will also be amplified.

3. Press [EXECUTE] to change the level of the selected phrase.

Encoding the phrase

So far, we have been working with audio data that you could already save to disk (see page 76). That, however, would not allow you to use this phrase in sync with the Arranger tempo. That is because the audio file hasn't been turned into a VariPhrase yet. The function that allows you to do so is called *Encode*. And again, there are a few parameters you can set to optimize the audio data for "intelligent" VariPhrase applications that sound just as impressive as the phrases prepared by Roland.

- 1. Press the [FUNCTION MENU] button.
- 2. In the menu that is displayed now, press the [VariPhrase] field.

The display now looks as follows:



Note: You can also select this page by pressing and holding a VariPhrase bank button ([BACKGROUND], [MELODIC], [RHYTHMIC], or [USER]) and by pressing the [←Back] field on the display page that is displayed then.

3. Press the [Encode] field.



Use the [Preview] function or the keyboard to listen to the current state of the phrase. If you press [Step] (so that it is displayed in white), you can step through the various "chunks". Note that even though the Event Sense parameter allows you to change the way in which the phrase is chopped up, you cannot "preview" the result of your setting. [Preview] reflects the current (executed) state of the phrase – without the value changes entered on this page but not yet executed. You can, however, correct this setting if it does not yield the expected result.

Note: Some parameters on this page are related to one another, while others are separate items. That is why some parameters will be described together.

Original Key

Original Key allows you to ensure that your VariPhrase will be played back at the right pitch (so that you hear a C when you press a C key). Here's an example: suppose you sampled a phrase in the key of A (major or minor) that actually starts with an A. Right now, the VA-76 doesn't know the phrase is in A. That is why the phrase will be played back in A whenever you press the [Preview] field or the C4 (the C more or less in the middle of the keyboard). If you then press the D4, the phrase will be played back in B, etc.

This is no good for melodic applications and would do away with the advantages of the VariPhrase technology. You therefore need to change the Original Key parameter so that the phrase is played back in A when you press an A key on the keyboard. Consider the illustration:





After setting the correct Original Key: the phrase is played in A when you press an A (and in C when you press a C).

Note: The "Key" parameter of the User Style Composer (see page 166) has a similar function. But while "Key" is used for MIDI data, "Original Key" bears on audio data.

- 1. Press the Keyboard Mode [OTHER] button and the [KEYBOARD MODE] field (it must be displayed in white).
- 2. Press the [UP1] field to switch on the Upper1 part. Now, when you play on the keyboard, you will hear both the VariPhrase and the Upper1 part. This will allow you to set the correct Original Key value.

 Note: You will notice that the tempo of the phrase does not change, while the pitch does.
- 3. Press the [EXIT] field to return to the *Phrase Edit* page.
- 4. Press the [Original Key] field.
- 5. Press the $[\uparrow] [\downarrow]$ arrows while playing the same note repeatedly (C-1~G9).
- 6. When the pitch of your phrase corresponds to that of the Upperl note (in any octave), stop pressing $[\uparrow]$ or $[\downarrow]$.
- 7. Press the [EXECUTE] field, or go on to the next parameter.

Note: See page 78 if your phrase is still flat or sharp. You can also use this parameter for causing the phrase to change octaves. Here's an example: if the sampled phrase is in A, selecting "A4" may yield the correct pitch, while the phrase is actually too low. To "transpose" it one octave up (when you press the same key on the keyboard), you would have to select "A3" as Original Key.

Specifying the phrase's tempo: Time Signature, Measure, Beat, Tempo

If you decided not to use the metronome while recording your sample (which also means that you did not set the tempo), the VA-76 is still unaware of the phrase's tempo. Yet that is important for the correct synchronization of the phrase with the Arranger/Song tempo.

Note: Be sure to select the Phrase you want to edit on the Phrase Source page (see page 71).

Note: Before using Method 1, it would be a good idea to cut the phrase to the part you really need. See "Truncate" on page 72.

There are two approaches for specifying the tempo:

① Method 1: specify the length of the sample and have the VariPhrase function calculate the tempo



- Use the *Time Signature* fields to specify the time signature of the phrase. Press the field before the "/" and enter the number of beats per measure (for a 6/8 measure, enter "6"). Use the [TEMPO/DATA] dial. Press the field behind the "/" and enter the note value of the beats (for a 6/8 measure, enter "8").
- Press the [Measure] field and specify the length of the phrase in measures. For a phrase that is 2 measures and 3 beats long, enter "2".
- Press the [Beat] field and specify the number of additional beats. If your phrase is 2 measures and 3 beats long, you need to set Beat to "3".
- Press the [Calculate] field to have the VA-76 calculate the tempo (BPM).


What you do here, is in fact ask the VA-76 a question: "if I tell you that the present audio phrase is two (Measure) 4/4 (Time Signature) measures and three beats (Beat) long, what is its tempo value (BPM)?" The result is displayed in the [New] field.

- ② Method 2: entering the tempo value right away

 If you know the tempo value of the audio phrase you

 have just someled you can prove the [New] field and
 - have just sampled, you can press the [New] field and enter the value using the [TEMPO/DATA] dial.

 8. Press the [EXECUTE] field, or go on to the next




After encoding the data, the display returns to the VariPhrase Source page.

Event Sense

This parameter is important for the Step function (see page 81). It allows you to set the VariPhrase processor's sensitivity to sudden volume drops. The (slightly more) silent passages are considered the end of a step. As soon as the volume of the audio phrase rises again, the audio data that follow will be considered a new step. As the term "Step" already indicates, this function allows you to chop up an audio phrase into smaller units that you can play one after the other. In our example on page 72, this would allow you to play a melody using the following syllables: "I-wan-na-be-phrased-by-you" (rather than "I wanna be phrased by you" in one go). This is in fact one of the most creative uses of the VariPhrase processor.

Event Sense allows you to specify how sensitive the processor should be to silences between two audio events. Here's an example:

These could be individual steps



If the Playback parameter (see page 81) is set to *STEP*, the sample will play to the next event each time you press a key.

The higher the *Event Sense* value you set, the more steps will be generated.


9. Press the [Event Sense] field and enter the desired value (0~127) with the [TEMPO/DATA] dial.

Note: If you set this parameter to a high value, a large number of steps may be detected. If you encode in such a state, the intervals between the steps may be too short and therefore musically useless.

10. Press the [EXECUTE] field to encode the phrase. This finalizes all of the above settings (New Tempo, Original Key, and Event Sense) and turns your audio phrase into a fully functional VariPhrase.

11. Play a few notes on the keyboard to try out the phrase. If necessary, correct any of the above parameters, and press [EXECUTE] again.

Note: If you change a setting after pressing [EXECUTE], you must encode the phrase again (by pressing [EXECUTE] yet again).



Saving your VariPhrase

Now that you have created your first phrase, there is one important step before you can take a break or start "playing" with it: you must save it to disk. It will indeed be erased as soon as you switch off the VA-76.

- 1. If you followed our steps above, press the [←Back] field to return to the VariPhrase menu.
- 2. On the VariPhrase menu page, press the [Capture] field.



You can also press the [Save] field. (Otherwise, press the [FUNCTION MENU] button, the [Disk] field, the [A Phrase] field, [Single Phrase], select the Save page, and press [Proceed].)

3. Press [Save].



If you have already saved a previous version of this phrase to disk, and wish to overwrite the older version, you can skip to step (7).

4. Insert a Zip disk into the Zip drive and press the [ZIP] field.

Though you could also use a floppy disk (and press [FLOPPY]), we strongly recommend to work with Zip disks. After all, a floppy may be just enough for one phrase (if that), while a Zip disk allows you to build your own libraries.

Note: Do not use the Zip disk that came with your VA-76, As a rule, you should not save any of your own data to the supplied Zip disk.

Note: You may have to format the Zip disk (see page 132).

5. Press the [Name] field.



6. Enter the name of your new VariPhrase. See page 68.

Note: Note that what you are entering here is the "File Name" for the VariPhrase. This can only be 8 characters long, and is used for identification purposes by the VA-76.

7. Press the [EXECUTE] field.

The animated clock indicates that the data are being saved to disk, after which a "Complete" message is displayed.

8. Press [EXIT] to return to the VariPhrase menu (if that is where you came from).

Note: You can also save all 16 User phrases as a so-called Phrase Set. See page 212. It is even possible to have the VA-76 load such a Set automatically when you switch it on, See page 209.

5.3 Phrase Parameters

As you know, there are some parameters you usually set immediately after sampling an audio phrase and before saving it to disk. "Executing" those changes transforms such a phrase into a VariPhrase (a process we call "encoding"). VariPhrases are the audio "tracks" you can use in combination with the Arranger/Song Composer. Their main feature is that, while their pitch usually changes as expected, the tempo remains the same for all notes — and is synchronized to the Arranger/Song Composer.


Even though the following parameters also modify the selected phrase, you can reverse those changes by selecting other settings. (By contrast, a "truncated" phrase cannot be restored to its original length.) Be aware, though, that these changes need to be saved to disk if you want them to take effect each time you load such a phrase. Also note that these parameters are only available for User phrases – not for the phrases in ROM.

- 1. Select the phrase to be edited by pressing [GROUP], [USER] and a number button [1]~[8].
- 2. Press the [FUNCTION MENU] button.
- 3. Press the [VariPhrase] field.
- 4. Press the [Select Phrase] field.

You can also select the Phrase Parameter page by holding the [USER] button and pressing [Phrase Parameter] on the page that appears then:




The display now looks more or less as follows:



The following parameters can be set by touching the corresponding field and by using the [TEMPO/DATA] dial.

Pitch

Press the [Pitch] field to select the following page.




Coarse Tune

(-24~+24) This parameter is similar to the Original Key parameter on the *Edit* page (see page 74). The main use for this parameter will probably be to transpose a phrase in octave steps depending on which keys you use for playing it.

This may greatly enhance the realism of the audio phrases you use. Being able to play a phrase at any pitch indeed means two things:

- the VariPhrase processor has to adapt the tempo of each note that is different from the Original Key.
- while changing the pitch in realtime, the processor also shifts the Formant to avoid the dreaded "chipmunk" effect (see also page 48). These shifts are usually very good, so that you may not even notice that the phrase is being played way above or below the pitch of the original audio signal.

As a rule, however, you should use this parameter for ensuring that the original pitch of the audio phrase falls within the keyboard range where you'll be most likely to play the phrase. This will further improve the sound quality.



Note: You could also select other values to create fifths intervals with respect to the Upper1/Upper2 (or Lower1/Lower2) part(s).

Fine Tune


(-50-50) This parameter allows you to tune the Vari-Phrase if it turns out that it is slightly sharp or flat. Just in case you have already worked with a sampler: this parameter is not meant for tempo-matching purposes: it merely corrects the tuning of your phrase. Like for guitar tuners, this value refers to cents, which is a very fine unit (1 cent= 1/100th of a semitone).

The best way to check the tuning of the phrase is by switching on the UP1 part so that you hear both the VariPhrase and the Upperl parts:

- Press the Keyboard Mode [OTHER] button and the [KEYBOARD MODE] field (it must be displayed in white).
- Press the [UP1] field to switch on the Upper1 part.
 Alternatively, you can press the KEYBOARD PARTS
 [UPPER 1] button on the front panel.

Amplitude

After selecting the Phrase Parameters page and the phrase to be edited (see page 77), press the [Amplitude] field.



The parameters on this page allow you to change the volume of the selected phrase.

Phrase Gain

(-12dB~24dB) Press this field and use the [TEMPO/DATA] dial to change the volume of the selected phrase. Negative values mean that the phrase will be softer, while positive values allow you to "amplify" the phrase's volume (which is why this parameter is called "Gain"). You could use it to ensure that all phrases you want to use in a given song have the same volume. Note: If a phrase contains noise or clicks, these will also be amplified.

Fade In/Out

The Fade In parameter works a lot like the Attack parameter of the remaining Keyboard parts (see page 126): it allows you to create an automatic swelling effect, whereby the phrase, once launched, starts at a volume of 0 and then gradually reaches its maximum volume. The setting range is 0.00~2.00 seconds. If you don't want the phrase to have a slow attack, select "0.00".

Note: This parameter does not allow you to create a more "snappy" attack for a phrase with a rather laid back beginning.

Note: Avoid choosing too high a value, for that may mean that you'll never hear the phrase (e.g. if it's less than two seconds long).


The Fade Out parameter (0.00~6.00 seconds) allows you to cause the phrase to gradually become softer when it stops sounding. Once the Fade Out time is completed, the phrase's volume will be 0. Again, be careful not to set too high a value.

Phrase Ctrl

The parameters on this page allow you to stray away from the "clever" concept of the VariPhrase technology. As you know, the pitch, tempo and formant are adapted in realtime to yield the *expected pitch* at a *stable tempo* (same tempo for all notes, which can, however, be changed by the Arranger/Song Composer). The *formant*, too, is adapted so as to yield a natural result for any note at any pitch. See also "Things you ought to know about VariPhrase" on page 48.

The Pitch Keyfollow parameter is usually set to "+100", which means that the pitch increases by a semitone between two keys (e.g. C4 and C#4), which corresponds to the normal behavior of a keyboard instrument. If you want the tempo and/or formant to change according to the notes you play on the keyboard, this page will allow you to do so. Here's an example: if you set the Time Keyfollow parameter to "+30", the phrase will be played back at a faster tempo as you play higher notes (and at a slower tempo as you play lower notes). The same value for Formant Keyfollow means that the phrase's character changes from something slightly "male" to a more "female" sound.

After selecting the Phrase Parameters page and the phrase to be edited (see page 77), press the [Phrase Ctrl] field.



Pitch Keyfollow

(-200~+200) This allows you to specify how the pitch should change as you play on the keyboard. "+100" is the normal setting. All other settings mean that you can no longer play meaningful melodies. Such settings may be great for rap or other rhythmic phrases you created yourself.

Time Keyfollow

(-200~+200) This parameter allows you to vary the tempo as you play higher or lower notes (with the Original Key setting as origin, where the phrase will run in sync with the Arranger/Song Composer). "0" is the usual setting. Negative values (–) mean that the tempo decreases as you play higher notes (while it increases when you play lower notes), and positive values (+) mean the opposite.

Formant Keyfollow


(Depth: -200~+200) This parameter allows you to vary the formant as you play higher or lower notes (with the Original Key setting as origin, where the phrase's character corresponds to the sampled timbre). "0" is the usual setting. Negative values (-) mean that the character becomes darker (more like a male voice) as you play higher notes (lower notes will gradually transform the character into something that reminds you of a female voice).

Curve—(1~8) This parameter allows you to set the curve for the formant changes. The higher the value, the more outspoken the formant changes will be as you play higher or lower notes. (Selecting "1" means that the Keyfollow effect is hardly noticeable.)

Pan

This parameter allows you to specify the position of the selected phrase between the left and right speakers. All three parameters are dynamic in nature, so that every phrase note will be located elsewhere in the stereo sound field.

After selecting the Phrase Parameters page and the phrase to be edited (see page 77), press the [Pan] field.



Random Pan

(-64-63) Use this when you want the pan of the sound to change randomly each time you play a key. Higher settings will produce a greater amount of change between left and right.

Alternate

(-64~63) Use this setting when you want the pan of the sound to alternate between the left and right speakers each time you press a key. Higher settings will produce a greater amount of change. L or R settings will reverse the order in which the pan will alternate between left and right.

(Pan) Keyfollow

Specifies how the phrase's stereo position will be affected by the key that you play. With positive (+) settings, playing keys higher than the original pitch (see page 77) will move the pan toward the right. With negative (-) settings, playing keys higher than the original pitch will move the pan toward the left. Larger values will produce greater changes.


Values: -100, -70, -50, -40, -30, -20, -10, 0, +10, +20, +30, +40, +50, +70, +100

Portamento

Note: The Formant Sw and Time Sw parameters only "work" if Formant Keyfollow and Time Keyfollow are not set to "O". See "Phrase Ctrl" above.

Portamento is an effect which smoothly changes the pitch from the first-played key to the next-played key. Applying portamento will produce an effect similar to the slide performance technique of a violinist. Portamento can also be applied when Key Assign is polyphonic (POLY). See page 89 for details about Portamento.

After selecting the Phrase Parameters page and the phrase to be edited (see page 77), press the [Portamento] field.



Master Sw (Portamento master switch)

Allows you to specify whether the Portamento effect will be applied (ON) or not (OFF).

Formant Sw

When Formant Keyfollow is set to a value other than "0", the Formant Sw parameter specifies whether differences in formant between the first-played key and the second-played key will be changed smoothly (ON) or not (OFF).

Note: This function is only available when the Master Sw is set to "ON".

Time Sw

When Time Keyfollow (see page 79) is set to a value other than "0," the *Time Sw* setting specifies whether differences in the playback speed between the first-played key will be smoothly changed to the playback speed of the second-played key (ON), or whether it will change abruptly (OFF).

Note: This function is only available when the Master Sw is set to "ON".

Mode

This parameter allows you to specify when the Portamento effect should be applied:

NORMAL -- Portamento is used for all notes.

LEGATO— Portamento will be applied only when you play legato (i.e., when you press the next key before releasing the previous key).

Type (portamento type)

This allows you to decide how the Portamento effect should work:


RATE—The time of the pitch change depends on the interval between the first and the second key you press. For small intervals, the change will take longer, while it will become progressively faster as you play wider intervals. (Here, the *Time* value is adapted to the interval so as to avoid excessively long glides.)

TIME— The *Time* value (see below) will always be used, no matter how big or small the interval between two notes played in succession.


Start

When another key is pressed while the Portamento effect is already executing the transition to the previously played note, a new transition will be started (to the newly played note). Start allows you to specify the pitch at which the new transition should begin.

PITCH— When another key is pressed while the pitch is moving, the new transition starts from the pitch that had been reached at that moment.



NOTE—Portamento will begin from the pitch where the current change would have ended if you hadn't pressed another key before the transition was complete.



Time (portamento time)

(0~127) Allows you to specify how long it takes before the pitch of the newly played note is reached. The higher the value, the longer the transition.


5. Press the [EXIT] field if you want to do something else now.

5.4 Global VariPhrase functions

The following parameters are *Global* parameters. This means that they apply to the VariPhrase *part* itself—not just the phrase that is currently selected. They can, however, be written to a User Program (see page 127), so that up to 128 different parameter combinations are possible (because there are 128 User Programs).

These parameters allow you to specify how the VariPhrases should be played back.

- 1. Press the [FUNCTION MENU] button.
- 2. Press the [VariPhrase] field.
- 3. On the page that appears now, press the [Global] field.



4. Press a field in the left column to select the parameters you wish to set.

Key Assign

See page 46.

Playback

The VA-76's VariPhrases can be played back in three ways. Let's try out the three possibilities by means of an example:


- **a)** Press the Keyboard Mode [ARRANGER] button (so that it lights).
- **b)** Press the VariPhrase [MELODIC] button, followed by the [8] button.

(Also make sure that the [GROUP] A indicator lights. This means that the phrase "A *Melodic* (a) HoneyINed" has been selected.)

If the VariPhrase selection page has disappeared, simply press the [8] button again to check the assignment.

- c) Play a C note in the right half of the keyboard.
- **d)** Keep holding this note, while also playing a G to the right of the C.

e) Press and hold the MODE [SYNC] button. The display now looks as follows:



(If you already performed steps (1) and (3) above, you only need to select a VariPhrase and press the [Playback] field.)

What you hear now, is the VariPhrase singing a C. As soon as you play the G, the VariPhrase goes on playing, but adds the G to the C. That is because the [Time Sync] function is currently selected. Whenever you select this setting, the Loop function is automatically switched on.

If you press the [Retrigger] field and once again start with the C, to which you add the G, the G note once again starts the phrase from the beginning, while the loop started with the C note goes on at its own timing. (Mind you, both phrases run at the correct tempo—they just don't do so together.)

Now press the [Step] field, and press the C key. What you hear now, is the first "step" of the VariPhrase that goes on repeating "Honey". These repetitions are due to the fact that the Trigger parameter (see page 47) is currently set to *Gate*, while the *Mode Loop* parameter (see page 82) is switched on. (It's up to you to decide whether or not the individual steps should be looped.)

The important thing to note is that you need to press the C again – or another key– to hear the second step of this phrase ("I need you"). Try this out now. "Step" literally means that at every note you play the phrase advances by one step.

Note: You can also alternate between the Time Sync and Step settings by pressing the Mode [STEP/SYNC] button in the VariPhrase pad. If the button lights, "Step" is selected. If the button is dark, the phrase will be played back in [Time Sync] mode.

Trigger

See page 47. If this is set to [Trigger] and you loose track of which key you played, the sample may continue sounding. In that case, try to locate the key you used for starting the prase and press it again.

Mode

- 1. Press the [FUNCTION MENU] button.
- 2. Press the [VariPhrase] field.
- 3. On the page that appears now, press the [Global] field.
- 4. Press the [Mode] field in the left column.



Loop

If you want the Phrase to play back as a loop (i.e. to be repeated over and over), turn this ON. In the case of a stepped phrase (see page 81), this means that the current step will be looped for as long as you hold down the key(s) you pressed. If you then press another key after releasing the previous one(s), the next step will be played in a loop.

You could also use this parameter for overriding the automatic activation of the Loop function whenever the Mode [STEP/SYNC] button in the VariPhrase pad on the front panel is switched off. This selects the Time Sync mode (see page 81) — and that, in turn, switches on this Loop function, which may not always be to your liking.

Note: If Trigger is set to [Drum] (see page 47), the LOOP setting is ignored.

Note: The VA-76's VariPhrases are always looped between the Edit Start and End positions. If the rhythm of a User phrase is odd, modify the Edit Start and/or Edit End position(s) until it is just right. See page 72. Bear in mind, though, that your phrase has to be encoded (EXECUTE) again before these new positions become meaningful. Also, do not forget to save your User phrase to disk after changing its Edit Start and End positions (see page 76).

T. Quantize

This parameter allows you to ensure that the Vari-Phrases can only be started at rhythmically meaningful positions so that they always make musical sense. Press the [OFF] field to make it read [ON] if you wish to take advantage of the quantization.

Robot

Imagine you are using a phrase with lyrics that are just right for a new song, while the melody isn't. As you know by now the melody of a sampled phrase can change even though you press only one key (which is about the same as the chords of the Intro or Ending

pattern of a Music Style). The phrases in ROM contain no such pitch shifts, which is why they sound just right in any key and at any pitch.

Your User phrases, however, may contain entire verses of a song. What do you do then? Of course, you could sample the vocal line yourself at the correct melody, but maybe that wouldn't provide quite the same "feel". You could also switch on the Robot function. This will "equalize" all melodic shifts of the phrase, so that all syllables are played back at the same pitch. When combined with the Step parameter (see page 81), this "equalized" phrase allows you to "build" an entirely new vocal line based on the syllables of the phrase.



Note that this is meant as a "special effect" similar to that obtained with a Vocoder (an effect that gives the impression that a synthesizer, guitar, etc. can talk). Note: Even slight changes in pitch (grace notes, etc.) will be equalized so that the result may sound slightly more mechanical. But then again, that's what a robot is all about...

Note: For optimum results, be sure to play only notes close to the Original Key note (see page 74).

5.5 Controller functions for the VariPhrase part

As shown on page 49, you can change the pitch, formant and tempo of the currently selected VariPhrase using the three on-screen sliders on the Controllers/ VariPhrase page. We also mentioned the possibility to use the remaining performance functions, some of which are built-in, while others are optional.

The following functions would already be worth the purchase of an optional DP-2, DP-6, or BOSS FS-5U footswitch, because they allow you to do something truly amazing. There are also some convenient Hold functions you may want to use at times (see page 192), while you can also use the built-in controllers (Pitch Bend/Modulation, Ribbon, etc.).

Legto Lock

By assigning this function to the optional footswitch, you can cause a phrase to go on running even when you play no note at all. Play a note, press the footswitch and then release the key, only to press it again a little later. You will notice that the phrase now sounds from its "logical position" (i.e. the one it would have reached if you had held the key down). This technique is an intelligent "audible/muted" switch for the

selected phrase and similar to a noise gate in a recording studio, with the additional advantage that you can specify the pitch of the "audible bits".

Gray areas: this is where you press a key. Only these fragments will be audible.

Wan-na bee phrased by you


This is where you press the footswitch

This is where you release the foot-

Pause

Another remarkable footswitch function allows you to "freeze" the audio data at the point where you press the footswitch. It is called [Pause]. Here is an example:

switch



Selecting the foot switch function

Selecting the foot switch function is as easy as most other settings on the VA-76:

- 1. Press the [CONTROLLERS] button.
- 2. On the page that appears now, press the [Foot]
- 3. Press the [Foot Switch] field in the left column.
- 4. Press the [→] field several times to select the following display page:




- 5. Press the [Legto Lock] or [Pause] field.
- 6. Press [EXIT] to return to the Master page.

5.6 Truly "global" VariPhrase parameters

The parameters discussed above apply to all VariPhrases you may use for a given song. But they can be saved to a User Program (see page 127). This means that you can reconfigure them simply by selecting another User Program (which allows for multiple simultaneous parameter changes).

The VA-76 also contains a number of Global Vari-Phrase parameters that apply to the entire instrument and cannot be changed simply by selecting another User Program. The following Global parameters also affect the way in which your VariPhrases are played back:

1. Press the [FUNCTION MENU] button.



- 2. Press the [Global Parameter] field.
- 3. On the page that appears now, press the [Vari-Phrase] field.

The display now looks as follows:



Style Linked (Phrase Select)

Let us begin with this parameter. If you press the [ON/OFF] field so that it reads [ON], selecting a Music Style also prepares the VariPhrases assigned to that Style for easy recall via the VariPhrase [BACK-GROUND], [MELODIC], [RHYTHMIC] (and [GROUP]) buttons.

You may remember that there are six assignments for each of the 128 Music Styles in ROM. In certain situations, this automatic "reshuffle" may not be convenient. In that case, press the [ON] field to make it read [OFF].

☑ Sync Settings

The following parameters may turn out to be very useful indeed. As you know, all VariPhrases (ROM and User) are automatically synchronized to the Arranger/Song Composer tempo. At extremely high or low values, however, the phrases may still be OK for "special effects" but probably no longer for serious musical applications. That is why you can set two tempo limits for automatic changes below or above the specified tempo value:

Double Speed On (BPM Lower Than)

Use this parameter for specifying whether ([ON] or [OFF]) the VariPhrase tempo should be doubled once the tempo is lower than the value you specify here, and if so, what should be the lower tempo limit. The default value is "75". So every time you select a lower tempo value, the current VariPhrase will be played at twice its original speed – provided the [ON/OFF] field next to it reads [ON].

Here's how to set the tempo value:

- · Press the [Double Speed On...] field.
- Use the [↑] [↑] to set the desired lower tempo limit.
 Press the [Default] field to return to the factory setting (75).
- Press the [ON/OFF] field next to [Double Speed On...] to make it read [ON]. The tempo doubling function is now active.

Half Speed On (BPM Higher Than)

This parameter is the upper tempo limit. Whenever you set a higher tempo than the value specified for this parameter, the current VariPhrase will be played back at half its original speed (tempo). See above for how to set this parameter.

Sync Adjust

Here's a parameter that allows you to use VariPhrases in 4/4 time for Music Styles in 6/8. When the [ON/OFF] field reads [ON], the VA-76 will see to it that phrases in 4/4 time also "work" with Music Styles in 3/4 or 6/8. Note that VariPhrases designed for Music Styles in 6/8 or 3/4 time may not work with Music Styles in 4/4. In some cases, however, switching off Sync Adjust might just do the trick.

4. Press [EXIT] to return to the Master page.

6. Advanced Keyboard part functions

6.1 Upper1 functions

More about the Super Tones

The SUPER TONES buttons are intended to help you select a Tone for the Upperl (or UP1) part without bothering to use the [Tones] field on the Master page or the BANK/NUMBER buttons. They cannot be used for the other parts.

Whenever you press a SUPER TONES button, a page similar to the following appears:




The white field indicates the Tone that is currently assigned to the SUPER TONES button you pressed. By pressing another field, you can override this setting. But that is only temporary and cannot be written to a User Program.

You can, however, select another option by pressing the appropriate field and then press the [Customize] field. The display then responds with:



You can repeat this for the remaining SUPER TONES buttons.

As you see, there are 8 possibilities for each SUPER TONES button, for a total of 40 Tones selected by the Roland engineers. Here's a list that may come in handy for almost instant location of the desired Tone for the Upper1 part:



This is the Factory set with fixed options for all five SUPER TONES buttons. Although you are free to select another option for a button, you cannot change the options themselves. There are eight possibilities per SUPER TONES button, and that's it.

There is, however, a User set with five additional SUPER TONES memories. At first, the assignments to these buttons is as shown in the illustration below.

Here is how to access the User set:

1. Press and hold any SUPER TONES button. The display now looks as follows:



You can also select this page by pressing the [FUNC-TION MENU] button followed by the [Super Tones] field on the *Function Menu*.

- 2. Press the [USER] field so that it is displayed in
- 3. Press [EXIT] to return to the Master page.
- **4.** Use the SUPER TONES buttons for selecting one of the five User assignments.

Memorize Super Tones: programming other assignments for the buttons

As stated earlier, you are free to assign any five of the VA-76's 3,646 Tones to the User set memories for the SUPER TONES buttons.

- 1. Select a Tone for the Upper1 part. See page 37.
- **2.** Press the [FUNCTION MENU] button. The display now looks as follows:



- 3. Press the [Super Tones] field.
- 4. Press the [User] field.
- 5. On the page that appears now, press the [Memorize] field.

The display now looks as follows:



As you see, the name of the Tone selected for Upper1 appears above the five button icons. If you do not agree with the current selection, you can use the BANK/NUMBER buttons and/or the [TEMPO/DATA] dial for selecting another Tone. It might be a good idea to work with the [GROUP], BANK and NUMBER buttons for selecting the Tone address (e.g. B51), while using the [TEMPO/DATA] dial to specify the desired Variation Tone (e.g. <12>).


Note: This does not allow you to change Tone Maps (see page 41), so preparing the Upper! Tone before selecting the above page is definitely a better choice. That is also why we didn't tell you to press and hold a SUPER TONES button: doing so would already select a Tone – and probably not the one you want.

6. Press a numbered field (that corresponds to the desired SUPER TONES button).

This field is now displayed in white.

7. Press the [EXECUTE] field to save your choice.

The display now responds with:



As soon as this message disappears, the display returns to the Factory/User page.

8. Press [EXIT] to return to the Master page. You could now try out the new assignment to check if it works. Press the SUPER TONES button whose Tone you changed.

UP1 Linked to Song


See page 33.

6.2 Upper2 functions

Upper 2 Split

On page 36, you learned how to split the keyboard into a left half with the LW1, LW2, and possibly also the MBS part, and a right half with the UP1, UP2 or the VariPhrase/MDR part. You can program an additional split between the UP1 and the UP2 parts, which is great for playing question-and-answer types of melody lines with a brass sound for Upper2, for example, and a clarinet or flute for Upper1. If you like, you can even add the VariPhrase part to the UP1 part – or use it instead of the UP1 part (see "Splitting Upper2 and the VariPhrase part" on page 88).

The possibilities are as follows:




The default split point is located at the G5 (lowest note of the Upper1 part).

Note: This function is only available in SPLIT Keyboard Mode. You cannot use it in WHOLE mode.


In effect, the VA-76 allows you to play at least three sounds assigned to three separate keyboard areas. On top of that, you can select the Arranger's chord recognition area, i.e. the notes that feed the Arranger (see page 101).

Here is how to activate the UP2 Split function:

1. Press the Keyboard Mode [OTHER] button.



The display now looks more or less as follows:



- 2. If the display does not look like in the above illustration, press the [KEYBOARD MODE] field in the upper right corner, and the [SPLIT] field. Both must be displayed in white.
- 3. Press the [UP2 Split] field.



This field is now displayed in white and the keyboard is split at the G5, with the UP1 part to the right, and the UP2 part to the left of this second split point.

See page 37 for how to assign the desired Tone to the Upper2 part.

Note: UP2 Split only works if the Upper1 (UP1) part is active. It is impossible to program an Upper split without using the Upper1 (or VariPhrase) part. Once UP1 has been switched on (automatically or manually), you can, however, switch it off. Furthermore, the UP2 part will be switched on as soon as you press the [UP2 Split] field.

If you don't agree with this split point (G5), you can change it to any note between the F#1 and G7 (but never to the left of the main split point):



Possible range for UP2 Split

This clever system helps you to avoid that the UP2 Split zone "covers" either the LW/Arranger or the UP1 zone. There will thus always be room for the zones to the left and right of the UP2 zone.

4. Press the [Options] field.



The display now looks more or less as follows:



5. Press the [Upper2 Functions] field to select the following display page:



As you see, the [UP2 Split] on this page already lights. If you no longer needed this function, you could use this field to switch it back off again. But that is not what we want to do here.

- 6. Use the [+][+] fields to the left and right of the keyboard for selecting the new split point.
- 7. Press [EXIT] to return to the Master page. Note: If you are satisfied with your split point, you should save it to a User Program (see p. 127).


The UP2 Split function can be cancelled in two ways:

- Press the [UP2 Split] field again so that it turns blue (either on this page, or on the opening display page when the [KEYBOARD MODE] and [SPLIT] fields are displayed in white).
- After pressing the Keyboard Mode [OTHER] button, press the [WHOLE] field to switch off the SPLIT mode.

Splitting Upper2 and the VariPhrase part

Once you have completed the above and set the UP2 Split point to your liking, you can switch off the UP1 part and use the VariPhrase part a instead so as to use a PCM (sampled) Tone for UP2 and a VariPhrase in the rightmost keyboard zone. It is even possible to add the VariPhrase part to the UP1 part.

- 1. Activate the UP2 Split function and set the desired UP2 Split point (see page 86).
- 2. Do not press the [EXIT] field to return to the Master page, but press [←Back] instead to jump to the following page:



You can also select this page by pressing the Keyboard Mode [OTHER] button. Furthermore, you can activate the VariPhrase part (and switch off UP1) simply by pressing a VariPhrase bank button.

3. Press the si field to switch on the VariPhrase part (this field must be displayed in white).

The keyboard is now split into three zones, with the VariPhrase part assigned to the rightmost zone.

Note: If you switch off the UP2 part while the [UP2 Split] field is displayed in white, the split is temporarily cancelled, so that UP1 (or the VariPhrase part) can be played all the way to the main split point.

4. Press [EXIT] to return to the Master page.

'Dynamic' second split point: UP2 to Left

While the UP2 Split function provides a static split between UP2 to the left and UP1 and/or the Vari-Phrase part to the right, there is a second way of playing two distinct melody parts in the right half of the keyboard, whereby the highest note is sounded by the Upper 1 (and/or VariPhrase) part, while the lower notes are sounded by Upper2. This is still a split, but it can be shifted dynamically as you play in the right half of the keyboard.


Here is an example. If you play the following notes to the right of the main split point, while [UP2 to Left] is switched on...



...the Upper1 part sounds the grayed notes, while the Upper2 part sounds the lower notes. Of course, you can also hold the top note (UP1 and/or VariPhrase) and play a melody to the left of it (UP2).

You could further refine this by transposing the UP2 part one octave up using the Octave function (see page 54) and by reducing the Upper1 part's volume using the Mixer. Of course, you can also turn this system around, and play the "second voice" on top (E-G-C), and the melody below. If you play three-note chords, the Upper2 part sounds two notes, while the Upper1 part sounds the highest notes.

1. Press the Keyboard Mode [OTHER] button.



2. If the display does not look like in the above illustration, press the [KEYBOARD MODE] field in the upper right corner, and the [SPLIT] field.

Note: This function is only available in SPLIT Keyboard Mode. You cannot use it in WHOLE mode.

- 3. Press the [UP2 to Left] field to switch on this dynamic split function.
- 4. Press [EXIT] to return to the Master page.

Note: Of course, UP2 Split and UP2 To Left are mutually exclusive. Selecting one means that the other is automatically switched off.

Note: There is also a footswitch function that allows you to alternate between Upper1 and Upper2 without splitting them. See "Kbd Exc UP1/UP2" on page 192.

Note: This function can also be switched on and off using a PAD button. See page 194.

Tuning Upper2: Coarse and Fine

The Upper2 part can be used as full-fledged solo or melody sound or to "fatten" the sound of Upper1. Note that the latter only works when you layer Upper2 and Upper1. By layering we mean that every time you press a key in the right half of the keyboard (in SPLIT Keyboard mode, page 36) or anywhere on the keyboard (WHOLE mode), you trigger two Tones: the one assigned to Upper1 part and the one assigned to Upper2. To layer the Upper1 and Upper2 parts, you need to switch them both on. See "Keyboard Mode clinic" on page 34.


The following parameters allow you to transpose (Coarse) or to detune (Fine) the Upper2 part relative to the Upper1 part. Though this is also possible when

the Upper2 and Upper1 parts are split (*UP2 Split* or *UP2 To Left*), detuning or shifting the UP2 part would not be very meaningful.

You could use **Coarse** to program an interval of a fifth (7 semitones) for Upper2, which is especially effective for brass sounds and guitar power chords. Do not forget to activate both the Upper1 and Upper2 parts when you want to take advantage of the Upper2 Coarse and Fine parameters. If only the Upper2 part is active, the solos you play either sound off or flat.

The Fine parameter works well when you assign the same or similar Tones to Upperl and Upper2. In those cases, Fine creates a kind of natural Chorus effect that you could enhance by panning Upperl to the left and Upper2 to the right (or vice versa, see page 114).

1. Press the Keyboard Mode [OTHER] button. The display now looks more or less as follows:



- 2. If the [KEYBOARD MODE] field in the upper right corner is not displayed in white, press it.
- 3. Press the [Options] field.
- 4. Press the [Upper2 Functions] field to select the following display page:




- 5. Press the [Coarse] field if you want to change Upper2's pitch in semitone steps.
 That field is displayed in white.
- 6. Use the [TEMPO/DATA] dial or the [DATA] button/Numeric Entry field to enter the desired value. "—" means that Upper2 is transposed down, while "+" means that Upper2's pitch is shifted up. A very popular setting for UP1/UP2 layers is "+12" for Upper2, so that it sounds one octave above Upper1.
- 7. Press the [Fine] field if you want to change Upper2's pitch in small steps (Cents). That field is displayed in white.

- 8. Use the [TEMPO/DATA] dial or the [DATA] button/Numeric Entry field to enter the desired value. Note: As stated earlier, (de)tuning Upper2 only makes sense when you layer the Upper2 part with the Upper1 part.
- 9. Press [EXIT] to return to the Master page.

Portamento (Upper 1-2 Portam)

Here are two functions that may come in handy for even more impressive solos involving the Upper parts. Let us first select the display page and have a look at how it is structured:


- 1. Press the Keyboard Mode [OTHER] button.
- 2. Press the [KEYBOARD MODE] field in the upper right corner.
- 3. Press the [Options] field and the [Upper 1-2 Portam] field.




The display is split into two sections: one for the UP1 and a second for the UP2 part. The arrows in the middle (↑ ♦) and the [Default] field always apply to the currently selected [Portam. Time] field (i.e. the one that is displayed in white).

Portam Time

Portamento is a function that produces smoother transitions between the notes you play:





Portamento time> 0 - Smooth pitch changes

Instead of jumping in semitone steps (as you would expect), the pitch glides from one note to the next whenever the Portamento time is higher than 0. The higher the value you set, the slower the glide. This effect is particularly useful for synthesizer or gypsy violin parts.

- 4. Press the [Portam Time] field of the Upper1 (UP1) or Upper2 (UP2) part to select it.
- 5. Set the desired value using the:
- "Value" arrows (↑ ♦),
- the [TEMPO/DATA] dial, or the
- [DATA] button/Numeric Entry pad (see page 49).
- Press the [Default] field to reset the Portam Time parameters of the UP1 or UP2 part back to "0". It does not change the Portamento Mode settings, however.

Portamento Mode: Mono/Poly

The VA-76 also allows you to set the Upper1 and Upper2 parts to mono(phonic) mode. *Mono* means that you can only play one note at a time. You could select the Mono mode to play a trumpet or woodwind part in a more natural way. *Poly*, on the other hand, means that you can play chords using the selected part.

- 6. Press the [Mono] or [Poly] field of the Upper part whose setting you want to change.
- 7. Press [EXIT] to jump to the Master page (see page 24).

6.3 LWR Hold


The VA-76 is an instrument that allows you to change many settings in realtime. Because you can trigger the Lower 1/2 parts and the Arranger simultaneously, selecting another Music Style pattern usually means that you have to lift your left hand from the keyboard. If the LWR Hold function is not active in SPLIT mode, the Lower (LW) parts stop sounding as soon as you release all keys in the left area.

If you press the [LWR Hold] field, however (so that is its displayed in white), the notes of the Lower parts go on sounding until you play other notes in the left keyboard area. It is probably a good idea to leave LWR Hold on at all times.

If both the Lower and M.Bass parts are active, the LWR Hold function sustains both the Lower and M.Bass notes.

Here's how to switch the LWR Hold function on and off:

1. Press the Keyboard Mode [OTHER] button. The display now looks more or less as follows:



- 2. If the display does not look like in the above illustration, press the [KEYBOARD MODE] field in the upper right corner, and the [SPLIT] field.

 Note: The LWR Hold function is only available in SPLIT
- 3. Switch on at least one LW part (its field must be displayed in white).
- 4. Press the [LWR Hold] field so that it is displayed in white.

Note: This field allows you to toggle between the "Lower Hold" setting you make on the Options page and "Hold Off".


5. Play a short note in the left half of the keyboard, and release the key.

This note goes on sounding until you press another note or chord in the left half of the keyboard.

Assigning the Lower Hold function

As the VA-76 provides two Lower parts (LW1 and LW2), there is also a parameter that allows you to select whether the LWR Hold function should apply only to the LW1 or LW2, or the both Lower (LW) parts:

- 1. On the above display page, press the [Options] field.
- 2. On the page that appears now, press the [Lower Hold] field.



3. Press the desired "Lower On/Off" fields to make your selection.

If you select [Lower 1 Hold On] and [Lower 2 Hold On], the [LWR Hold] field on the previous display page allows you to toggle between LW 1 & 2 Hold "On" and "Off".

Note: It is also possible to obtain a similar effect by assigning the LW1 and LW2 parts to the Sustain pedal or the assignable footswitch (see page 186).

4. Press [EXIT] to return to the Master page.

6.4 Velocity sensitivity

Of course, the VA-76's keyboard is also velocity sensitive. This allows you to control the timbre and volume of the Keyboard parts by varying the force with which you strike the keys. See page 103 for how to control the Arranger via the velocity.

- 1. Press the Keyboard Mode [OTHER] button.
- 2. If the display does not look like in the above illustration, press the [KEYBOARD MODE] field in the upper right corner, and the [SPLIT] field.
- 3. On the page that appears now, press the [Keyboard Velocty] field.



4. Press a part field in the center of this page to select the Keyboard part whose velocity behavior you wish to change (Upper1, Upper2, etc.).

Note: See page 99 for details about the MEL Int part.

Key Touch

The [Key Touch] field allows you to specify a velocity curve for the selected Keyboard part:

High—Select this setting for maximum expressiveness: even small variations of the force with which you strike a key produce audible changes. The trade-off is, however, that you have to strike the keys forcefully to achieve the maximum volume. (This is the default setting.)

Medium— Medium velocity sensitivity. The part still responds to velocity changes, but the maximum volume can be obtained easier than with *High*.

Low— Select this setting if you are used to playing on an electronic organ or if you do not want velocity changes to bring about major volume changes.

5. Press the [Key Touch] field, and use the on-screen slider at the right (or the [TEMPO/DATA] dial) to select the desired velocity curve.

Velocity switching (Min and Max)

You can also specify the smallest (Min) and highest (Max) velocity values with which you can trigger the selected part. This is probably only useful when applied to the Upperl and Upper2 parts, or the Upperl and VariPhrase parts. Do not change these values if you have no intention of using a "complementary" part because, otherwise, you may start wondering why the LW1 part, for instance, only sounds at high or low velocity values.

Min and Max can be used effectively for switching between two Tones simply by striking the keys harder or softer. Doing so allows you to alternate between two sounds. Remember, though that some "V" Tones already have this function built-in (see page 42). Using such Tones for velocity switching applications is thus unnecessary. But feel free to experiment. Some unique effects could be obtained when using Min and Max for the Upper1 and VariPhrase parts.

Consider the following example:

Part	Min	Max	Tone
Upper1	1	114	A81 <14> V Romantic Trp. (Tone Map 4)
Upper2	115	127	A81 <17> V Tp Mar/Shk (Tone Map 4)

Both parts must be on. The above settings allow you to trigger the "normal" trumpet sound with velocity values between 1 and 114 (low to relatively high velocity), while velocity values above 115 only trigger the slightly more "lyrical" trumpet (a Tone, by the way, that contains already a built-in velocity switch for additional flexibility). Try this out: it sounds spectacularly real.

Another example involving the Upper1 and Vari-Phrase parts could be:

Part	Min	Max	Tone
Upper1	1	127	A76 <27> Humming (Map 4)
Vari- Phrase	90	127	A-Melodic-6 OohDarlin M

Here, the Upper1 part sounds all notes at any velocity value, while the VariPhrase part is added only when you strike the keys rather forcefully. This could be used for accents. Of course, there are countless other possibilities, such as using Min= 90/Max= 127 for the MEL Int part (see page 99), so that the automatic harmonies are only added when you really want to hear them.

Note: See page 37 for how to select Tones for the Keyboard parts, and page 45 for how to select a VariPhrase.


6. Press [EXIT] to return to the Master page.

6.5 Scale Tuning

Another useful function is called Scale Tuning. It allows you to use oriental, asian, and other scales in much the same way as on an oriental keyboard (EM-50 OR, etc.).

The VA-76 contains three memories where you can store your favorite tunings. The contents of these memories can be saved to disk along with the User Program Set (see page 211) – i.e. these are three global memories.

- 1. Press the Keyboard Mode [OTHER] button.
- 2. If the [KEYBOARD MODE] field in the upper right corner is not displayed in white, press it.
- 3. Press the [Scale Tuning] field.



4. Press the [Upper Parts] or [All Parts] field.

All Parts means that all VA-76 parts will be affected by the Scale Tune setting. This also includes the Vari-Phrase and Arranger Parts. Upper Parts, on the other hand, means that only Upper1 and Upper2 will use the selected scale. There is also an off position (when both fields are blue).


Note: The [Upper Parts] function can also be switched on and off using an optional footswitch (see page 191).

5. Press a [Mem 1]~[Mem 3] field to select a Scale Tuning memory.

This will change the pitch of the following notes ("-50" means that the note in question is tuned a quarter tone down):

Mem 1	Mem 2	Mem 3
E (-50)	E (-50)	C# (-50)
B (-50)	A (-50)	F# (-50)

The pitch of the other notes is left unchanged. The keys corresponding to the notes whose pitch is changed are displayed in white for easy identification. Here is an example:



You will notice that every note can be selected only once. That is because the value you specify (using Pitch EDIT, see below) applies to all notes of the same name. In other words, if you change the tuning of the C, that value will be added to or subtracted from all Cs (C1, C2, C3, etc.). The on-screen keys are used as "on/ off switches".

If you now returned to the Master page, you would notice that the VA-76 alerts you to the fact that the Scale Tuning function has been switched on:



But let us not return to the Master page just yet.

Changing the pitch of other notes

Changing the pitch of other notes than the ones already highlighted is a matter of pressing the desired on-screen key in question. And defeating the pitch change of a key displayed in white is as easy as pressing that key again (it will once again be displayed in blue).

Press all white on-screen keys (or the [Mem] field that is displayed in white) to switch the Scale Tuning function off again.


Note: See also "Customizing the pitch changes (Pitch EDIT)" if you need to change the tuning of a given note to something else than "-50".

Storing your new scale

Suppose you just switched on several on-screen keys, while the ones that were originally on are now off. If you think you'll need that scale in the future, you should save – or "Memorize" – it:

- 1. Program the scale you wish to save by switching the desired notes on or off (see above).
- 2. Press the [Memorize] field in the upper right corner of the display.

The display now looks as follows:



3. Press a [Mem 1]~[Mem 3] field to save your settings in the corresponding Scale Tuning memory.

The display now responds with the following message and then returns to the Scale Tuning page.




Customizing the pitch changes (Pitch EDIT)

At first, pressing an on-screen key so that it is displayed in white means that its pitch is lowered by 50 cents (1/4 tone, or "-50"). Though this system allows you to use the desired arabic tuning, there may be situations where you actually want to raise the pitch of a note, or select a different tuning:

1. On the Scale Tuning page (see above), press the [Pitch EDIT] field.

The display now looks as follows:



Here again, the white keys inform you about the notes whose pitch is actually being affected.

- 2. Press the value field (or the on-screen key) of the note/key whose pitch you want to change. That field is displayed in white. As stated earlier, the pitch of all notes is at first set to "-50" (one quarter tone down). You can however, select any value between "-64" (slightly lower than a quarter tone down) and "63" (slightly higher than a quarter tone up).
- 3. Use the [TEMPO/DATA] dial or the [DATA] button/Numeric Entry field to set the desired pitch. These Pitch EDIT values only apply to the Scale Tuning memory where you save your settings (see "Storing your new scale"). Values other than "-50" or "+50" sound flat at best and are probably not really useful.
- 4. Repeat steps (2) and (3) for the other notes whose pitch you want to change.

Note: This pitch is only used when the corresponding onscreen key is displayed in white. Do not forget to switch it on. Also, you need to press the [Upper Parts] or [ALL Parts] field (both can indeed be switched off).

5. Press the [←Back] field to return to the Scale Tuning page, or the [EXIT] field to jump to the Master page.

Any changes to the standard tuning of the notes will be indicated by means of the "Scale Tuning ON" message on the Master page (see also page 93).

7. More about the Arranger

7.1 Arranger and Music Styles

Think of the Arranger's Music Styles as your backing band. Your VA-76 is indeed capable of playing several "versions" of a given accompaniment. All you need to do is make up your mind about the kind of music you want to play and to select a Music Style that complements it. You can choose how many bars there are to each song part and how the melody and/or solo should be accompanied.

Arranger parts

Each accompaniment (or Music Style) can consist of up to eight parts:

A. Drums (or ADR): Accompaniment Drums. This part takes care of the rhythm. It triggers the drum and percussion sounds of the Drum Set assigned to the ADR part.

A. Bass (or ABS): Accompaniment Bass. This part plays the bass line of the Music Style you selected.


Ac1~Ac6: These are the melodic accompaniment parts. Depending on the Music Style you selected, only a few of them actually play something, which can be anything from a piano line, a guitar line, an organ line to a synth pad line. Not all Accompaniment parts play chords.

The ABS and Ac parts rely on the chord or note information you play in the *chord recognition* area (see page 101), i.e. the keyboard zone you assign to the Arranger.

Starting a Music Style

Music Styles can be started in several ways:

- 1. Press the Keyboard Mode [ARRANGER] button.
- **2.** Press the [START/STOP] button (so that it lights) to start the Arranger right away.



If you start the Arranger without playing a chord in the chord recognition area, you will only hear the drums of the selected Music Style. In most cases, however, the VA-76 has already memorized a chord, so that you will hear the full accompaniment.

OR:

3. Stop playback of the current Style (see below), press the [INTRO] button (so that it lights) and then the [START/STOP] button to start Style playback with a musical introduction.

The length of the Intro depends on the Style you selected. At the end of the Intro, the Arranger starts playing the Music Style division you select while the Intro is being played. In other words, you can select whichever Type (Orchestrator Basic and Advanced) and Division (Original, Variation) you like to be played upon completion of the Intro.

∩R•

4. Press the [SYNC] button (if it currently controls the Start function, see below) and play a chord (or just one note in Intelligent mode, see page 102). The Arranger starts as soon as you play a note in the chord recognition area (see page 101).

Note: Do not play chord changes while the Intro is running. Unlike the "normal" patterns (Original, Variation), Intro patterns usually contain chord changes. Chord recognition is not deactivated during Intro playback, so that the beginning of a song may jump from one key to another.

Note: You can also start and stop the Arranger with the D Beam Controller (see page 187).

Stopping a Music Style

There are three ways to stop Style playback:

- 1. Press [START/STOP] to stop playback right away.
- 2. Press [ENDING] (so that it lights) to activate the Ending function. The Ending (or coda) pattern will start at the beginning of the next measure (next downbeat).

Note: Do not play chord changes while the Ending is running. Unlike the "normal" accompaniments (Original, Variation), Ending patterns usually contain chord changes. Chord recognition is not deactivated during Intro or Ending playback, so that the ending of a song may jump from one key to another.

OR

3. Press [SYNC] and release all keys in the chord recognition area of the keyboard. The accompaniment stops immediately.

There is no need to restart Style playback manually if you also activate Sync Start (see below). Sync Stop is only available if you activate it. See "Sync (Options)".


Sync (Options)

If you've never used an arranger keyboard before, the status of the [SYNC] button is the single most important function to look out for after switching on your instrument. After all, if it is on without you knowing it, playing just one note on the keyboard may cause the Arranger to start even though you don't want it to. Once you get to know the VA-76 a little better, you will appreciate this function, and you may want to take advantage of its Sync functions. Sync Start means that the Arranger starts as soon as you play a note or chord in the chord recognition area of the keyboard. (If the Keyboard Mode [ARRANGER] button lights, this area is the left half of the keyboard. See page 101 for details.)

The VA-76 also provides a **Sync Stop** option. This will cause the Arranger to stop playback as soon as you release all keys in the chord recognition area. This is great for songs where you need breaks (i.e. one or several beats of silence).

And finally, you can choose to activate both Sync Start and Sync Stop.


Whenever you configure the VA-76 via the Virtual Band function or by pressing the Keyboard Mode [ARRANGER] button, the [SYNC] button lights.



This means that the currently selected Sync Option has been switched on. As long as you do not select another Sync Option, this will be Sync Start.

Here's how to set another Sync option. This setting can be written to a User Program (see page 127).

1. Press and hold the [SYNC] button until the following page appears:



- 2. Press the Sync field that corresponds to the desired Sync function(s).
- **3.** Press [EXIT] to return to the Master page. You can now use the [SYNC] button to switch the selected Sync function off (button dark) and on (button lights).


Note: Whenever you use One Touch or Virtual Band to configure the VA-76, Sync Start will be selected.

Note: See also page 100 for how to prevent the VA-76 from reverting to Sync Start and switching on the [SYNC] button when you take advantage of the One Touch memories.

7.2 Selecting other Style divisions

As stated above, you can "professionalize" your performance with the Arranger by selecting different accompaniment patterns. Let us agree to use the word *Division* for any Music Style pattern the VA-76 can play. We'll need that term for programming User Styles.

Here's a quick overview of how the VA-76's Music Styles (and the ones on Zip/floppy disk) are structured:



Press the [ORIGINAL] button to select the "normal" accompaniment. ORIGINAL ① is the simplest of the four possible accompaniment patterns, while VARIATION ④ is the most complex. ② ("Basic") and ④ ("Advanced") can also be selected by pressing [ORIGINAL] or [VARIATION] twice in rapid succession. The combination of ORIGINAL and VARIATION with the four ORCHESTRATOR options already provides a total of eight accompaniments per Music Style (multiplied by three, see the next paragraph).

As you see, you can use the [FILL] button to go from ORIGINAL to VARIATION, and back. In the first case, you will hear the Fill-In To Variation pattern. When going back from VARIATION to ORIGINAL, the Arranger will play the Fill-In To Original pattern.

Note that you don't have to use the [FILL] button: you can also switch divisions by pressing [VARIATION] or [ORIGINAL].

Note: See also "Using the VA-76's Arranger" on page 25.

Note: You can also press [INTRO] in the middle of a performance. In that case, the indicator will flash until the end of the current bar and then light on the next downbeat to indicate that the Arranger is playing the introductory pattern.

Tip: The Intro is "renewable", i.e. you can press the [INTRO] button again while the Intro is playing. Doing so on the fourth beat of the first Intro bar, for instance, will retrigger the beginning of the Intro in the second bar.

Fill In Half Bar

Certain pop songs in 4/4 contain bars that only last two beats. The usual place for such a bar is between the first and the second verse. Another favorite position for "halved" bars is at the end of a chorus or the bridge. Your VA-76 allows you to faithfully reproduce these "anomalies". Set the Fill-In Half Bar function to [ON]. This does not change Style playback right away. Only when you press the [FILL] button will the Half Bar function be active and play half the number of beats of the fill you selected.

- 1. On the page that appears when you press the Keyboard Mode [OTHER] button, press the [ARRANGER CHORD] field if it is not displayed in white.
- 2. Press the [Options] field.
- 3. Press the [Intro Ending Fill In] field in the left column.

The display now looks more or less as follows:



- 4. Press the [ON] field so that it is displayed in white.
- 5. Start Arranger playback and press the [FILL] button.

Notice how the Fill In is shortened.

- **6.** Press the Fill In Half Bar [OFF] field to return to the normal length of the Fill-In patterns.
- 7. Press [EXIT] to return to the Master page.

Major, minor, seventh

This is an "invisible" Style division function of your VA-76. In time you will notice that the Intro and Ending patterns of a Music Style change according to the chord you play. There are three possibilities:

Major (M): Calls up the first (major chord) accompaniment level.

Minor (m): Calls up the second accompaniment level. **Seventh** (7): By playing a seventh chord, you activate yet another accompaniment level. Try this out by first playing a major and then a seventh chord.

In other words, the number of certain divisions (such as the Intros and Endings) is in fact multiplied by

Note: The VA-76 is equipped with a function that allows you to freely assign various chord types (7/5, dim etc.) to one of these levels (see page 105).

Using Aftertouch to select Arranger patterns

Another way of switching between Types, Divisions, and Fills is to use Aftertouch. Obviously, only one of the following options can be selected because multipurpose assignments like for the Keyboard parts (see page 189) would send the Arranger haywire.

Note: Selecting "Arranger" does not cancel the Aftertouch settings you may have made for the Keyboard parts.

Here is how to activate the switching function for the Arranger:

- 1. Press the [CONTROLLERS] button.
- 2. On the page that appears now, press the [Aftertouch] field so that it is displayed in white.
- 3. Use the [↑] [↑] fields to select Arranger. In the case of the Keyboard parts, these fields are used to select the part whose Aftertouch you want to program (see page 189). Here, however, we want to specify an Aftertouch function for the Arranger, which is why we need to select Arranger. The display now looks more or less as follows:



Note the [ON/OFF] switch. You must press it to make it read [ON] if you do want to use the Aftertouch for selecting divisions. If you prefer not to use the Aftertouch, press this switch again to make it read [OFF].

- 4. If necessary, press the [→] field to select the second page with Arranger functions.
- 5. Press the field that corresponds to the switching function you want the Arranger to perform.

Bsc/Adv— Switches between the Basic (②) and Advanced (④) levels. These two patterns are available via the VA-76's Orchestrator function.

Or/Var— Switches between Original and Variation and thus duplicates the functions of the [ORIGINAL] and [VARIATION] buttons on the front panel.

FO/FV— Triggers the Fill-In To Original the first time around, and the Fill-In To Variation the second time. This duplicates the function of the [FILL] button that leads you from the Original to the Variation pattern by playing one Fill-In, and from the Variation to the Original pattern by playing another Fill-In.

Fill To Previous— This also starts a Fill-In but does not switch to the Variation pattern (if the Original pattern is currently selected), and vice versa.

Intro, Ending—Same function as the [INTRO] or [ENDING] button. If Arranger playback is stopped, using the Aftertouch will select the Intro. If used during Arranger playback, the Aftertouch will select the Ending.

Note: Even Aftertouch messages generated outside the chord recognition area (see below) will trigger the selected switching function.

6. Press [EXIT] to return to the Master page.

Style Morphing (part 2)

On page 63, we showed you how to morph using two internal Styles. Morphing with one internal Style and a Style on disk is just as easy:

1. Select the following display page:



- Press the [Style] field on the Master page (as though you wanted to select a Music Style). On the page that appears next, press the [Orchestrator] field.
- Or press the [ORCHESTRATOR] button. You can only assign a Style on Zip or floppy to the 1st Style.
- 2. Insert a Zip or floppy disk into the (appropriate) drive.
- 3. Press the [1st Style] field.
- 4. On the page that appears now, press the [Disk User] field in the lower left corner of the display.

The display now looks more or less as follows:




The rest is exactly the same as selecting a Disk User Style:

- 5. Press the [FLOPPY] or [ZIP] field to specify whether you want to load a Music Style from a Zip or a floppy disk.
- 6. Press the field that contains the name of the Music Style you want to load.
- 7. If the desired Music Style is not displayed, use [←][→] to select another group of 4 Styles.
- 8. Press the [LOAD] field to copy the data of the selected Music Style to the VA-76's Disk User memory.
- 9. Start morphing with the Style in the Disk User memory (1st Style) and the internal Style (2nd Style).
- 10. Press [EXIT] to return to the Master page.

7.3 Melody Intelligence

The Arranger of your VA-76 can not only play chords but also add a counter-melody to your melodies based on the chords you play in the chord recognition area (see page 101). This counter-melody will be played by the Melody Intelligence part (MEL INT) and added to the Upper1 part. You can assign whichever Tone you like to the MEL INT part. Furthermore, there are 18 harmony types to choose from.

1. Press the [MELODY INTELL] button (so that it lights).



This adds a harmony to the notes you play. Do not forget to switch on the Upperl part (see page 36).

2. To select another harmony type, press and hold the [MELODY INTELL] button until the following page appears:



3. Press the field of the desired harmony type.

Selecting a Harmony Type also means that the VA-76 automatically assigns a suitable Tone to the MEL INT (and sometimes even to the Upper1) part (e.g. a trumpet sound for *Big Band*, etc.). You can, however, override this automatic setting (see "Selecting Tones for the Keyboard parts" on page 37) and save your own sound choice to a User Program.

Note: On the Keyboard Tone selection page, you will notice a lock when you select the MEL INT part. It allows you to specify whether or not selecting another harmony type should automatically change the Tones of the MEL INT part. See also "About the lock" on page 107. If the lock is open, your own Tone selections for MEL INT are no longer overridden by the Tone selection contained in the "Melody Intelligence Types".

Note: For "Traditional", "Latin", "CntryBallad", "OctaveType1", and "OctaveType2", only the Upper1 part is used. All other Melody Intelligence Types, however, use both the Upper1 and the MI part.

4. Press [EXIT] to return to the Master page.

5. Press the [MELODY INTELL] button once again to switch this function off again.

7.4 One Touch

You may find yourself using the One Touch function at regular intervals because it automates quite a few tasks. Press the [ONE TOUCH] button to select the following display page:



If the [OFF] field lights, the One Touch function is not yet active. You still need to select one of the four memories by pressing one of the large fields. The One Touch function makes a number of automatic settings for you:

- Keyboard Mode [ARRANGER]. This corresponds to
 pressing the button of the same name, and means that
 the keyboard is split into two halves, with Arranger
 control in the left, and Upper1 control in the right. (If
 Upper2 is already on, it will not be switched off,
 though.)
- · The Music Style's default tempo is selected.
- The [SYNC] button is assigned the Start function and switched on (see also "Sync (Options)" on page 96).
- The VA-76 makes suitable settings for the Upper1 and Upper2 parts. These comprise Tone selection and appropriate Reverb, Chorus, and Delay settings.
- If Arranger playback is currently stopped, the [INTRO] button is switched on, so that playing a chord in the chord recognition area of the keyboard will start Music Style playback with the Intro of the selected Style.

There are four One Touch memories for all internal Music Styles (A11~B88), all Disk Link Styles (C11~C88), and the Disk User memory.

Note: If a One Touch memory is selected when you recall a User Program, the One Touch function is switched off.

If you select a One Touch memory while another one is already active

In that case, the VA-76 selects the Tones and Reverb/ Chorus/Delay settings of that One Touch memory.

It may also switch on one of the following functions if you switched them off after selecting the first One Touch memory:

- · Sync Start
- [INTRO] (if Arranger playback is currently stopped).
 Just for your information, the selection of a One
 Touch memory is also indicated on the Master page.
 Look out for the "OT" symbol.




Ignoring certain One Touch settings (Cancel Options)

Now imagine that you have grown accustomed to using the One Touch memories, because they are similar to (though less comprehensive than) the User Programs. What if, for a given song, you want to use the Tone and effects settings for the Upper1 and Upper2 parts without returning to the Music Style's preset tempo (because you are playing a medley)?

In that case, you can take advantage of the One Touch Cancel options. They act as filters for the functions supported by the One Touch facility.

1. While on the One Touch page, press the [Cancel Options] field.

The display now looks as follows:



2. Press the field corresponding to the settings that should *not* be loaded when you select another One Touch memory or Music Style.

If a field is displayed in white, the corresponding settings are no longer loaded:


Suitable Tempo— The preset tempo of the selected Music Style.

KBD Mode— The current Keyboard Mode settings. You may have selected another chord recognition area (the entire keyboard, for example). If this field lights, the chord recognition area is not set back to the left half of the keyboard.

Sync Start— If this field is on, the function of the [SYNC] button (see page 96) does not change. So if you selected "Sync Stop", this would not be reset to "Sync Start". Also, if the [SYNC] button is currently dark, selecting another One Touch memory or Music Style does not switch it back on.

Intro— This option means that the [INTRO] button is not automatically switched on when you select a One Touch memory or Music Style while Arranger playback is stopped.

If one of the cancel functions has been activated, the [Cancel Options] field on the One Touch page contains a tick (\checkmark) :



Note: The One Touch function will be switched off whenever you select a User Program.

Programming your own Tone selections (Memorize)

The VA-76 also allows you to memorize your own favorite Tones for the Upper1 and Upper2 parts in case none of the four One Touch memories provide the sounds you need.

Given the careful preparation of these selections, customizing the Tone assignments may not be necessary for the internal Music Styles. Yet they may come in handy for Disk Link and Disk User Styles (see pages 60 and 61) for which there are no "presets".

These customized One Touch settings are stored in a special memory area inside the VA-76. Though they are not part of the User Program parameters (because User Programs and the One Touch facility are mutually exclusive), they will be saved to disk whenever you use the Save User Program Set function (see page 211).

- 1. If necessary, switch off the One Touch memory that is currently on:
- Press the [ONE TOUCH] button to select the following display page:



- Press the [OFF] field so that it is displayed in white.
 The One Touch field (1~4) that was on, will go dark.
 - 2. Select the Music Style you want to program a Tone assignment for.

You can do so manually or by taking advantage of the Virtual Band function.

- 3. Switch the Upper1 part on and all other Keyboard parts off (see page 36).
- **4.** Select a Tone for the Upper1 part (see page 37). You could also press a SUPER TONES button.
- 5. Switch the Upper1 part off and the Upper2 part on.
- 6. Select a Tone for the Upper2 part.
- 7. Press the [MEMORIZE] field.



8. Press the 1~4 field that should contain your new Tone assignments for the Upper1 and Upper2 parts. The display now shows the following message:




9. Press the [EXIT] field to return to the Master page.

7.5 More refined Arranger settings

ARR(anger) Hold

The ARR Hold function is very similar to "LWR Hold" on page 90: It sustains the notes you play in the chord recognition area until you play other notes. At first, this function is switched on, so that you can briefly play the chord for a given bar and release all keys in the chord recognition area. If [ARR Hold] is displayed in blue, the melodic accompaniment (bass and other parts) stop as soon as you release all keys in the chord recognition area, so that only the drums keep playing. You should try this out now — but you'll probably stick to the on status of this field, because that frees up your "chord hand" for other things (such as using the D Beam controller, Pitch Bend lever, etc.).

1. Press the Keyboard Mode [OTHER] button.



- 2. Press the [ARR Hold] field to switch the Arranger Hold function off (blue), or on (white).
- 3. Press [EXIT] to return to the Master page.
 As soon as you play another chord, the accompaniment changes, but as long as you don't, the melodic accompaniment keeps playing the previously specified chord.

Chord recognition area


As stated on page 34, telling the VA-76 that you wish to use the Arranger is a matter of pressing the Keyboard Mode [ARRANGER] button. That, however, means that the key of the Music Style patterns can only be controlled by playing chords in the left half of the keyboard. You can also tell it to scan another part of the keyboard for usable chords. Though Left is probably the mode you will usually use, you could select Right to have the Arranger scan the right half of the keyboard. Note that it is possible to select Whole so that you can feed the Arranger anywhere on the keyboard. If you don't want the Arranger to scan your chords, choose Off.

Note: Off can also be assigned to an optional footswitch (see page 191).

The range of the Left or Right keyboard area depends on the current setting of the main split point (see "Split point in Arranger mode" on page 35). The split point you set for the Keyboard parts will also be used by the Arranger to determine the upper (Left) or lower (Right) limit of the chord recognition area.

- 1. Press the Keyboard Mode [OTHER] button.
- 2. Press the [ARRANGER CHORD] field in the upper left corner of the display (so that it is displayed in white).

The display now looks more or less as follows:



- 3. Press the [LEFT], [WHOLE], [RIGHT] or [OFF] field in the center to select the chord recognition area. Your choice is reflected by the keyboard below the central display section, so you can't go wrong.
- 4. Press [EXIT] to return to the Master page.

 Note: Every time you press the Keyboard Mode
 [ARRANGER] button, the [LEFT] setting is selected.

 Note: You can also use an optional footswitch for selecting
 [OFF] (see page 191).

Arranger Chord Mode

Another important choice is how you want to transmit note information to the Arranger so that it plays the Music Style in the right key.

- 1. Press the Keyboard Mode [OTHER] button.
- 2. Press the [ARRANGER CHORD] field in the upper left corner of the display (so that it is displayed in white).
- 3. Press the [Standard], [PianoStyle], or [Intelligent] field.

Standard— This is the normal chord recognition mode. In Standard mode, the melodic accompaniment plays the chords you play in the chord recognition area of the keyboard. If you play only one note in that area, the accompaniment plays only that note, i.e. it assumes that you deliberately chose to omit the third and the fifth of your "chord".

To have the Music Style sound a major, minor or seventh chord, you can suffice to play three notes, by the way. Other, more complex, chords require that you press four keys.

Piano Style—Piano Style means that you can play on your VA-76 as you would on a piano. In this mode, it is probably a good idea to press the Keyboard Mode [PIANO] button (or to switch off all Keyboard parts except Upper1).

The Piano Style mode works as follows: the Arranger decodes every chord you play – no matter where you play it. Causing the Arranger to play another chord requires that you play at least a triad (i.e. the three notes that make up a chord). You are free to play more than three chord notes but remember that two notes won't cause the Arranger to play another chord. Do not forget to select a chord recognition area (see above), because pressing Keyboard Mode [PIANO] selects "OFF". "WHOLE" would be a good choice here.

Intelligent— Select Intelligent when you want the Arranger to supply the missing notes of the chord you want to play. See page 252 for a chart of intelligent chords and the way to play them. The VA-76 can handle virtually any chord you can think of – and playing them requires no more than three (for minor and seventh chords only two, and for major chords only one) finger(s)! This is probably the mode you will select most of the time.

4. Press [EXIT] to return to the Master page.

Note: The choice you make here also affects the "Arpeg" and "Chord" options of the D Beam Controller. See "Arpeg 1/2/3 Octv" on page 187.


Bass Inversion

The Bass Inversion function allows you to change the way the Arranger reads the chords you play.

If the field is not displayed in white, the Accompaniment Bass part (ABS) plays the root of the chords that feed the Arranger, while the chords of the Accompaniment 1~6 parts are voiced in such a way as to avoid semitone intervals (for complex chords) that wouldn't sound very nice.

Bass Inversion gives you more artistic license because you specify the notes played by the ABS part. Switch on Bass Inversion for songs that rely on bass rather than on chord patterns (for example $C - C/B - C/B_b$, etc.).

1. Press the Keyboard Mode [OTHER] button.




- 2. Press the [Bass Inv] field to switch the Bass Inversion function on (white) or off (blue).
- 3. Press [EXIT] to return to the Master page.

 Note: By default, this function is also assigned to the PAD
 [2] button, which may be more convenient to use for quick toggles.

Dynamic Arranger

The Dynamic Arranger function allows you to control the volume of the Arranger parts via the way you strike the keys in the chord recognition area (velocity). If the selected Style uses a "V" Drum Set, this function also influences the timbre of the drum sounds in a far more natural way than before.

1. Press the Keyboard Mode [OTHER] button.



- 2. On the page that appears now, press the [Dynamic] field to switch the Dynamic Arranger function on (white) or off (blue).
- 3. To return to the Master page, press [EXIT].
- "Dynamic" only becomes meaningful if you also specify how the various Arranger parts should respond to your velocity. There are eight Arranger parts: A Drum (the drums), A Bass (the bass), and Accomp 1~6 (the melodic accompaniment parts).
- 4. On the page that appears when you press the Keyboard Mode [OTHER] button, press the [ARRANGER CHORD] field if it is not displayed in white.
- 5. Press the [Dynamic Arr EDIT] field. The display now looks more or less as follows:



- **6.** Select the Arranger part whose velocity sensitivity you wish to change by pressing its field.
- 7. Specify the velocity sensitivity value with the [TEMPO/DATA] dial or using the [DATA] button/ Numeric Pad facility.

You can specify positive and negative sensitivity values. Positive values mean that the volume of the part in question increases when you strike the chord recognition area keys harder, while negative values mean that the volume of the selected Arranger part increases as your velocity becomes softer.

You could use extreme positive/negative ACCOMP pairs (i.e. "127" and "-127") to alternate between those two lines simply by varying your velocity. One part would then only be audible when you strike the keys softly, while the other would only be audible at high velocity values.

Subtler settings (i.e. 20 and -20 for a pair) can also be effective, of course. Set the value to "0" for those parts whose volume should not be affected by your velocity values


You could use the [Dynamic] field on this page to switch this function on or off. By default, it is switched off.

8. Press [EXIT] to return to the Master page.
You can also press the [←Back] field if you still need to make other Arranger settings.

7.6 Arranger Options

- 1. On the page that appears when you press the Keyboard Mode [OTHER] button, press the [ARRANGER CHORD] field if it is not displayed in white.
- 2. Press the [Options] field.

The display now looks more or less as follows:



You can also select this particular page by pressing and holding the [TEMPO/TAP] button.

(Arranger) Tempo

3. Press the [Tempo] field so that it is displayed in white.

Fill Ritardando

The Fill Ritardando function is suitable for ballads. It causes the next fill (To Original, To Variation) to slow down ("ritardando"). Try using this function now:

4. Start Arranger playback and press the [OFF] field below the Fill Ritardando message (so that it reads [ON]). Then press the [FILL] button on the front panel.

The tempo slows down while the Fill is being played. At the end of the fill, the Style returns to the previously set tempo (this is called "a tempo").

- 5. Press the Fill Ritardando value field (next to the [OFF/ON] field).
- 6. Use the [TEMPO/DATA] dial or the [DATA] button (Numeric Entry) to enter the desired tempo change value (5~92%).


The higher the value, the more dramatic the tempo change.

BPM

Before telling you what this parameter is for, let us briefly summarize everything that has already been said about the tempo:

 Every Music Style has a preset tempo that is recalled whenever you select that Style, or when you take advantage of the One Touch function (see page 99).
 The One Touch function, however, allows you to filter the tempo setting (by activating [Suitable Tempo], which means that the preset tempo is no longer loaded automatically).

- On the other hand, you are free to change a Music Style's tempo any time. See "Changing the tempo" on page 27. That value can be written to a User Program and will then be set every time you select that User Program.
- The Style (and also Composer Song) tempo is displayed on the Master page (upper right corner), but also by the four tempo indicators above the [DATA] and [TEMPO/TAP] buttons. The first indicator flashes red to indicate the downbeat (the beginning) of a new bar.



For time signatures like 6/8, etc. the fourth indicator flashes repeatedly to supply the "missing" beats.

[Auto] and [Lock] allow you to specify what happens when you select another Style:

BPM field that lights	If Arranger playback is stopped when you select another Style	If the Arranger is running when you select another Style	
[Auto]	The Arranger loads the preset tempo of the new Style	The new Style is played	
[Lock]	The preset tempo of the new Style is not loaded. Instead, the Style will be played at the current tempo.	back at the tempo of the previous Style.	
(none)	The Style's preset tempo is loaded.		

To switch off both tempo options, press the [Auto] or [Lock] field that is currently displayed in white.

RIT and ACC

The [RIT] and [ACC] fields allow you to speed up or slow down the Arranger tempo. The field you press will be displayed in white, and change to blue again as soon as the ritardando (RIT) or accelerando (ACC) is completed. After pressing the [RIT] (slow down) or [ACC] (speed up) field, you can use the "opposite" field ([ACC] or [RIT]) to return to the initial tempo value. This will gradually turn the tempo change back. To immediately return to the Style's default tempo, press the [Default] field.

The two **Tempo Change** parameters allow you to set the degree (ratio) to which the tempo changes when you press the [RIT] or [ACC] field.



Press the first field (Rit/Acc) and use the [TEMPO/DATA] dial or the [DATA] button/Numeric Entry pad to select the ratio by which the tempo should increase/decrease.

Next, press the [CPT] field and enter the number of clocks required for executing the requested tempo change. "480" corresponds to one 4/4 measure. Enter the value "120" if the tempo change should be executed in one beat.


Chord Family Assign, Alteratn

On page 97, we told you about three complete sets of Style divisions: one for major, one for minor, and one for seventh chords. If you listen very carefully to the internal Styles of your VA-76, you will notice that the accompaniment for minor chords sometimes differs from that for major and seventh chords. That is because these accompaniments can be programmed separately.

The Chord Family Assign function allows you to specify which pattern (major, minor or seventh) should be used for the chords you play. For instance, if you want the Arranger to use the minor accompaniment for "6" chords, you should use the Chord Family Assign function to assign the "6" chord family (for instance C6, A6 etc.) to the minor accompaniment level.


- 1. On the page that appears when you press the Keyboard Mode [OTHER] button, press the [ARRANGER CHORD] field if it is not displayed in white.
- 2. Press the [Options] field.
- 3. Press the [Chord Family Assign] field in the left column.

The display now looks more or less as follows:




- 4. Press the Keyboard Mode [ARRANGER] button (this is only necessary if it doesn't light).
- 5. Play a chord in the left half of the keyboard.

The name of that chord now appears to the right of the "Chord" field.



6. While still holding those keys, press the [CAP-TURE] field.

The display now contains two arrows that are displayed below the [Family] field. Use [♠][♣] to select the Chord division (pattern) you want to hear every time you play your "Sus" chord (for example). Select "Maj", "min", or "7th".



Note: You cannot select "Maj" in this particular case, because Sus chords are already assigned to the "Maj" family. You could assign them to the "7th" divisions, however.

Note the [DELETE] field. This means that you can delete this assignment and program a new one if you

- 7. Press the Chord [♣] field to select memory 2. Repeat the above steps to program other Chord Family assignments. You can use [♠] to return to memory 1, and change the assignment, or delete it.
- 8. Press [EXIT] to return to the Master page. You can also press the [←Back] field if you still need to make other Arranger settings... such as the following, which is related to the Chord Family Assign function.

Intro& Ending Alteration

Now suppose you like the accompaniment you assigned your chord to (e.g. the "7th" pattern), but think that the Intro and Ending sound odd when you start a song with that chord ("Csus4" for instance). Consider the following example: you assigned the C4 chord to the major family and the Intro of the Style you are using contains the following progression:


 $C \rightarrow Am \rightarrow F \rightarrow G$

Starting the Intro with the C4 chord memorized would transform this progression into the following: $C4 \rightarrow Am6 \rightarrow F \rightarrow G7$

The outcome is not really predictable. That is precisely why you can turn the Alteration function off. Doing so allows you to memorize the C4 chord but have the Intro or Ending play the normal progression (e.g. C, Am, F, G), and cause the Arranger to switch to the C4 chord when the Intro/Ending is finished.

- 1. On the page that appears when you press the Keyboard Mode [OTHER] button, press the [ARRANGER CHORD] field if it is not displayed in white.
- 2. Press the [Options] field.
- 3. Press the [Intro Ending Fill In] field in the left col-

The display now looks more or less as follows:



Press the [OFF] field if you don't want the Intro and Ending patterns to be affected by the "special" (unusual) chords you play. Press the [ON] field if your "special" chords should also be reflected by the Intro and Ending patterns.

4. Press [EXIT] to return to the Master page. You could also stay on this page for the following function:

Musical Style playback: Wrap

The Wrap function is used to specify how the bass line and accompaniment parts should be played. If the bass, for instance, is programmed to play ascending scales, some notes may be too high or too low to sound natural in a given situation. Though perfectly possible for the built-in tone generator, playing the scales the way they were programmed affects the quality of your accompaniment.

So far, you may not have noticed the difference because the default setting for the Wrap function is "ON", meaning that all parts are played in their natural range. The Wrap function transposes all accompaniment notes that are too low (for piccolo etc. sounds) or too high (for bass sounds, etc.) one octave up or down. The Wrap point is preset for each Tone and cannot be changed.

The Accomp Wrap parameter allows you to activate or cut the Wrap function. In most cases, *ON* is probably a sensible setting.

- 1. On the page that appears when you press the Keyboard Mode [OTHER] button, press the [ARRANGER CHORD] field if it is not displayed in white.
- 2. Press the [Options] field.
- 3. Press the [Accomp Wrap] field in the left column. The display now looks more or less as follows:



4. Press the field of the Arranger part whose Wrap setting you wish to change.

That field is displayed in white.

- 5. Use the [TEMPO/DATA] dial to select "ON" or "OFF".
- ON—All notes played by the selected part will sound in a "natural" range for the selected Tone, i.e. neither too low nor too high.
- OFF— All notes of the selected part will be played the way they were programmed. Select "OFF" if the chord progression you are playing requires ascending or descending lines or consistent chord voicings (such as when the User Style function is used for sequencing). Note: The A Drum part cannot be selected because it doesn't contain melodies, so that the Wrap function wouldn't make sense.
- 6. Press [EXIT] to return to the Master page.

7.7 Selecting Tones for the Arranger parts

You can select other Tones for the Arranger parts of the currently selected Music Style. Assigning another Drum Set to the A. Drums part, for instance, may already dramatically change the Music Style's character. Likewise, replacing the acoustic piano by an electric one is an easy way of adapting a preset Music Style to your specific needs.

Tone selection for the Arranger parts is very similar to the procedure for the Keyboard parts. If in doubt, please see "Selecting Tones for the Keyboard parts" on page 37.

1. On the Master page, press the [Tone] field. You can also press the [TONE] button in the BANK/NUM-BER section.

The display now looks more or less as follows:



2. Press the [Part] field to select the following page:



3. Press the [Style Part] field to select the following page:



4. Press one of the part fields [ADR]~[AC6] to select the part you wish to assign another Tone to.
[ADR] refers to the Accompaniment Drums part,
[ABS] to the Accompaniment Bass part, and [AC1]~
[AC6] to the melodic accompaniment parts.

5. Use the BANK/NUMBER buttons to select a Tone for the active Arranger part (the one that is displayed in white).

Alternatively, you can also press the [Tone] field and work via the display. See also "Selecting different Tone Maps" on page 41 if you can't seem to find the Tone you need in the current Map. See the Tone Lists on page 222 for locating the desired Tone.

About the lock 6

It is up to you to decide whether the VA-76 should remember which Tones you assigned to the Arranger parts. If you do not modify the setting of the lock, you will notice that, after a while, the Music Style returns to the original, preset, Tones.

Thanks to the lock, however, you can ensure that the preset Tone selection will be overridden by your own choices

Lock closed — The Tone assignment contained in the Music Style will be recalled at the beginning of a loop. This may be after 2, 4, or even 8 measures. (There are also locks for the volume, Reverb, Chorus, etc. parameters.)

Lock open — The Arranger part in question does not change at the beginning of the loop. Selecting this option is probably wiser when you are planning to write your settings to a User Program (see page 127) and recall them at a later stage. Otherwise, you might just as well not bother with selecting other Tones for the Arranger parts.

This is an intelligent function: as soon as you select another Tone (or Drum Set), the lock is automatically opened.

Note: See also "More locks" on page 115.

6. Press [EXIT] to return to the Master page.

7.8 Working with Styles on Disk

Programming your own Disk Link assignments


The VA-76 comes with 64 preprogrammed assignments to Music Styles on the supplied Zip disk. The Zip disk, however, contains a lot more Music Styles (559 in all), while you may in time also use other Styles on different Zip or floppy disks.

If such disks contain Music Styles you want to be able to select at the press of three buttons (without using the Disk User memory), here is how to program an assignment.

Note: If you take advantage of this, it would be wiser to have all Disk Link memories refer to the same disk. This can be one floppy and one Zip disk (but try to avoid two different Zip disks). That way, you do not have to change disks while playing, which is rather cumbersome in the case of a Zip disk.

1. Press the [STYLE] button or the [Style] field on the Master page.

The display now looks more or less as follows:



- 2. Insert a Zip or floppy disk into the (appropriate) drive.
- 3. Press the [Disk User] field.



4. Press the [FLOPPY] or [ZIP] field in the upper right corner.

This is necessary to specify whether you want to link a Style on floppy or on Zip disk. You need to do this before pressing the [Options] field.

- 5. Press the [Options] field.
- 6. Press the [Disk Link] field.

The display now looks more or less as follows:



7. Use the $[\uparrow] [\downarrow]$ fields to select the Disk Link memory you wish to assign a new Style to.

Select C21, for example. The memories are numbered from 1~8. This explains why the next Disk Link memory after "C18" is "C21" ("9" and ""0" are not used).

Note: This will overwrite the current assignment of the C21 memory. You may want to write it down before proceeding, so as to be able to restore the factory setting.

8. Press the field of the Style you want to assign to this memory.

If necessary, use the [★][★] fields or the [TEMPO/DATA] dial to select another group of four Styles.

Note: If you can't seem to find the Style you wish to assign, and if you know it exists on the selected disk, check the "Find" field. It should read "(ALL)". On the other hand, you can also use the Find functions for locating the desired Music Style before selecting the Disk Link page. See page 133 for details about the Find functions.

9. Press the [EXECUTE] field.

The VA-76 now briefly confirms that your selection has been registered and then returns to this page. You could now program other assignments if you wanted to.

10. Press the [←Back] field to return to the previous page and, at the first occasion, press [EXIT] to return to the Master page.

Note: Disk Link assignments are stored internally but they are not part of the User Programs. Thus, you can "only" program 64 links in all (rather than 64 per User Program). Note: Disk Link settings are saved to a global memory whose contents are saved together with all User Program Set data (page 211). When you transfer such a Set back to the VA-76 using the "All" option of the User Program Set Load function, the internal Disk Link settings will be replaced by the settings you load. Be sure to save your settings to disk before loading an entire User Program Set. Use "Save User Program Set" on page 211 for saving the settings.

Find: locating Styles on a Zip disk

Working with Music Styles on Zip or floppy disk is convenient and fast, as you know by now.

The Zip disk supplied with the VA-76, however, contains 559 Music Styles. That is why there is also a powerful Find function for quickly locating the Style you need. Here is how to use this Find function:

1. Press the [STYLE] button or the [Style] field on the Master page.

2. Press the [Disk User] field.

(This procedure is the same as the one for using Disk User Styles.) The display now looks more or less as follows:



there are four columns.

[Style Name] — Tills is the internal name of each Maisin Style? This name appears on the Master page, the 'Music Style selection page, etc.' It is issually the interningful? name; it is is not seed.

[Genre! — Tells you more about the musical genre! (Walta, Fulk, Lain, etc.)

[File Name! — This is the name the Music Style has on disk and by which has YA for cognizes it fills "address"). If you change this name of a Music Style the Disk Link function not longer finds the Style. The nator manor of these solumns are supplied by a special file on the Zip disk that is called Database. Gwenthat florpy disks cannot contain such a Database disk only the 'Style Name' and independent of the Style Name' are available; while the kind function is not supported. You can supply the shore failure and in the Styles unthe supplied Zip disk (though the latter is probably not avery good tica).

Note: Muse Styles you man from floppy disk and then save to Zip are not automatically mounted to include this Database information. You need to program it yourself, See 'Rename (Style Opnors)' on page 110.

Here are the available Database entries for Music Styles and Songs:




3. Press the [Style Name], [Country], [Genre], or [File Name] field, depending on the entry you want to base your search on.

To locate all Styles for a given genre (e.g. Standard), press the [Genre] field.

4. Press the [FIND] field.

The display now looks more or less as follows:



- 5. Select the way in which the VA-76 should search the Zip disk for the desired information:
- Press the [GO To...] field if the VA-76 should search
 for all entries that start with the characters you enter
 ("BEA", for example). Note that by "entry", we mean
 the [Style Name], [File Name], etc. you selected on the
 previous page or here. Files that match the specified
 criteria will be displayed at the top of the display.
- Press the [Find Only] field to have the VA-76 search the selected column for files that contain the supplied information. (This would allow you to also locate a file called Raggabeat if you entered "BEA".)
- The four fields below the [GO To...] and [Find Only] fields allow you to specify the entry that should be searched. The one that is displayed in white ([Style Name] in the above illustration) is the active field.
 - 6. Use the keypad for entering the information to look out for. Use the $[\leftarrow][\rightarrow]$ fields to move the cursor to the next/preceding position.

See also page 68. Use the [Delete] field to erase any character you don't want the VA-76 to look for. Such "forgotten" characters can seriously affect the search result.

Note: It would be a good idea to enter at least 2 characters, possibly even 3 so as to narrow down your search to a "workable" size.

7. Press the [EXECUTE] field and look at the "Find:" field above the [Orchestrator] field.

If it says "0 of 559", the VA-76 was unable to find a file that contains the desired information. In all other cases, the field will read "XX of 559", which means "found XX Style Name, Country, Genre, or File Name entries that match the characters you entered."

8. Use the [←][←] fields or the [TEMPO/DATA] dial to call up the desired Music Style and press its field to select it.

If all columns are blank (because the Find function was unable to find Music Styles that match the search criteria), press the [Style Name], [Country], [Genre] or [File Name] field. All Styles on disk will now be sorted alphabetically according to the selected column. Here is an example: if you press the [Genre] field, the Music Styles will be sorted in the alphabetical order of the Genre column.

Note: Pressing an entry field on the database page will cancel the Find results you may have obtained previously with the [GO To...] or [Find Only] option.

Let us now have a look at how to supply the information the Database will be able to find. This is only possible for Zip disks and only necessary for files that do not contain the desired information, or no information at all.

Rename (Style Options)

Note: The Rename and Delete options are also available for floppy disks. In the case of "Rename", however, you can only change the [File Name] and [Style Name].

The ZIP Style Options page contains three options: [Rename], [Delete], and [Disk Link]. You already know what the Disk Link function is for (see page 108). Here, we will have a look at the [Rename] function. As stated above, it allows you to change (or supply) the information for the various Database entries.

It is an "Option", which means that you probably won't use it every day. If you do use it, be aware of the following: the VA-76 remembers the File Name of the referenced Music Styles for the Disk Link facility. If you change the File Name (not the Style Name), the VA-76 no longer finds it when you select the Disk Link memory in question. We therefore recommend you never change the File Name.

- 1. Press the [STYLE] button or the [Style] field on the Master page.
- 2. Press the [Disk User] field.
- 3. Press the [ZIP] field to select the Zip drive. Though you could also press the [FLOPPY] field, you would then be left with only the [Style Name] and [File Name] to change. Renaming these two may be useful at times, but it is usually very dangerous. It would be wiser to use Rename only for changing or supplying the [Country] or [Genre] information.

4. Press the [Options] field.



- 5. Select the Style you want to rename by touching it. If necessary, use the [←][→] fields or the [TEMPO/DATA] dial to locate it.
- 6. Press the [Rename] field to call up the following page:



As you see, the four entry fields [Style Name], [Country], [Genre], and [File Name] are once again displayed.

Note: If this is not the case, you forgot to select the Zip drive earlier.

- 7. Touch the field for which you wish to supply or change the information.
- 8. Use the keypad to enter the desired name. See also page 68.

Note: Except for the Style Name entry that allows for 16 characters, you can only enter 8 characters.

9. Press the [EXECUTE] field.

The new information is saved to the Zip disk while the following animation is displayed:



The display now returns to the Style Options page.

Style Delete

It is also possible to delete a Style from floppy or Zip disk. You should use this as sparsely as possible – and never for the supplied Zip or floppy disk. Once a Style is gone, there is indeed no way to restore it. So please be careful and try to forget this function even exists

- 1. Press the [STYLE] button or the [Style] field on the Master page.
- 2. Press the [Disk User] field.
- 3. Press the [ZIP] field to select the Zip drive.
- 4. Press the [Options] field.
- 5. Select the Music Style you want to delete.
 Use [←][→] fields or the [TEMPO/DATA] to call up the Style's name, then press its field (so that it is displayed in white).
- **6.** Press the [Delete] field to call up the following page:



- 7. Carefully look at the Style name that is displayed here and check whether this is the correct one. If this is the wrong Style, press [+ Back] to return to the Style Options page and select the correct one.
- **8**. Press the [YES] field to go ahead and delete the Style.

Press [NO] if you selected this function by accident. If you press [YES], the Style is deleted, after which the display confirms the operation and returns to the ZIP Style Options or FDD Style Options page.




9. Press [EXIT] to return to the Master page.

8. Mixer, effects and editing

The VA-76 also allows you to set the volume, the stereo position and the amount of effect the parts should use. Of course, you can also program the effects themselves. All of these parameters can be found on the Mixer pages.

There are *three ways* to select the VA-76's Mixer. The first is the most straightforward one, the others require some additional operations.

a) Press the [Mixer] field on the Master page.



- b) Press the [EFFECTS] button, followed by the [Keybrd Mixer], [Style Mixer], or [Global Volume] field.
- c) Press and hold the M-FX [ON/OFF] button, followed by the [Keybrd Mixer], [Style Mixer], or [Global Volume] field.

8.1 Structure of the Mixer pages

The main pages are structured in a very logical way: The [Keybrd Mixer] field provides access to the VA-76's Keyboard parts: VariPhrase, Upper1, Upper2, Lower1, Lower2, M.Bass, MEL INT, M.Drums and the Audio In part.

The [Style Mixer] field allows you to set various parameters of the Arranger (or "Style") parts: A.Drums, A.Bass, Accomp 1~6.

The [Global Volume] field allows you to set the volume of several part groups in one go. On a mixing console, these sliders would be called the bus faders.


In fact, the Mixer is very similar to a mixing console, because you can not only set the volume of the above parts, but also their stereo position (PanPot) and the amount of effect they should use. In other words: this is where you can "mix" the parts so as to create a convincing sound image.

For your convenience, you can do the mixing according to two approaches:

(1) Via sliders on so-called palette pages

In this case, you can edit the selected parameter (volume, pan, effect send) for several parts at once. If the desired part is not displayed, use the [←][→] fields to select another group of Keyboard or Style parts. A typical palette page looks like this:

Means that you are on a palette page



[Single Part] and [PALETTE] are only available on the pages you select via these fields

Press the [Palette] field (if available) so select the palette page. (If the [Single Part] field in the upper left corner is displayed, you are on a palette page.)

On such palette pages, you need to proceed as follows:

- 1. Select one of the VA-76's Mixer pages (see a-c).
- Select the Mixer group that contains the part whose settings you want to change by pressing the [Keybrd Mixer] or [Style Mixer] field.
- If the part you want to change is not displayed, use the [←][→] fields to call up another group of four parts/sliders.
- 4. Select the desired parameter by pressing the [Delay], [Chorus], [Reverb], [PanPot] or [Volume] field.


Note: The Delay effect is not available for the A.Drums, M.Drums, VariPhrase, and Audio In parts.

- 5. Edit the selected parameter for one or several parts in one of the following ways:
- a) Use the on-screen sliders -or-
- b) Press the name field (above the sliders) of the part whose setting you wish to change and use the [TEMPO/DATA] dial, or the [DATA] button/Numeric Entry pad (see page 49).

(2) Use a Single Part page

Single Part pages contain all available Mixer parameters for the currently selected part. A typical Single Part page looks like this:

Means that you are on a Single Part page




Here, you need to proceed as follows:

- 1. Select one of the VA-76's Mixer pages (see a~c on page 112).
- 2. Select the Mixer group that contains the part whose settings you want to change by pressing the [Keybrd Mixer] or [Style Mixer] field.
- 3. If the [Single Part] field is displayed in the upper left corner, press it.
- 4. Use the [♠][♣] fields to select the desired part.
- 5. Select the desired parameter by pressing the [Delay], [Chorus], [Reverb], [PanPot] or [Volume] field.
- **6.** Edit the selected parameter in one of the following ways:
- a) Use the slider to the right of the parameters -or-
- b) Press the field of the parameter whose setting you wish to change and use the [TEMPO/DATA] dial, or the [DATA] button/Numeric Entry pad (see page 49). Note: The Equalizer and Insertion M-FX parameters can only be set on Single Part pages.

About the Audio In part

The Audio In part has a special place among the "Keyboard parts". That's because it is not really a Keyboard part: it allows you to mix your live vocals with the music played by the VA-76.


This explains why it has two pages to itself (a Single Part and a Palette page). Choose whichever is more convenient for you. See page 58 for details.



8.2 Volume and pan

Global Volume

- 1. Press the [Mixer] field in the display.
- 2. If necessary, press the [Global Volume] field:



Note: We strongly recommend that you first assign the Tones you need to the parts you intend to play because the character of the sounds you use affects the balance. Thus, a trumpet sound will be perceived louder than a flute because the former contains more harmonics (overtones).

The sliders on this page are group sliders that allow you to set the volume of several parts at once:

Drum— Refers to the volume of the ADrums (ADR) and MDrums parts (MDR). With this slider, you thus affect the volume of two parts.

Bass— Refers to the A Bass (Music Style bass) and the MBS (Manual Bass) parts.

Accomp—Refers to the AC1~AC6 parts of the Arranger. These are the melodic accompaniment parts.

Lower- Refers to the LW1 and LW2 parts.

Upper— Refers to the UP1, UP2, VariPhrase, Audio In, and MEL INT parts.

As the name implies, you could use this page for global changes to the volume.

3. Press the name of the VA-76 part section whose volume you wish to change.

In the above illustration, the Upper slider (group) has been selected.

- 4. Set the desired volume in one of the following ways:
- · Using the on-screen slider;
- · With the [TEMPO/DATA] dial;
- By pressing the [DATA] button and using the Numeric Pad (see page 49).



Note: The relative balance of two grouped parts is only maintained as long as you do not decrease (or increase) the volume once one of the faders on the other pages has reached the value "0" (or "127"). If you increase the volume of a group beyond the point where one of its members has reached "127", only the volume of the part(s) whose volume hasn't yet reached "127" will change. The same is true when you decrease the volume of a grouped pair after one part has reached the value "0". There is no way to restore the relative balance that was in effect before you destroyed it.

Note that obtaining the right balance is not always a matter of increasing the volume of one section. In many instances decreasing the volume of the part or section that is too loud with respect to the others, is more effective.

Muting parts


On the above page (as well as on the Keybrd Mixer and Style Mixer pages) you can press the [ON/OFF] fields below the sliders (Palette) or part name (Single Part) to mute the selected group (or part). The [ON] prompt then changes to [OFF].

Note: See below for the remaining functions on the Mixer pages.

5. Press [EXIT] to return to the Master page.

Keybrd Mixer (volume of the Keyboard parts)

After selecting a Mixer page (see page 112), press the [Keybrd Mixer] field. The display now looks as follows:




Here you can set the volume of the individual Keyboard parts. If this page is not displayed, press the [PALETTE] field in the middle of the display.

The parts whose volume you can change here are: VariPhrase, M Drums, Upper 2, Upper 1, M Bass, Lower2, Lower1, MEL INT, and Audio In (see page 57).

- 1. Use the [♣][♣] fields to select the page that contains the Keyboard part whose volume you want to change or that you wish to switch off.
- 2. If the [Volume] field is not displayed in white, press it. Otherwise, you'll change another parameter setting.

Style Mixer (volume of the Arranger parts)

After selecting a Mixer page (see page 112), press the [Style Mixer] field. The display now looks as follows:



Here, you can set the volume and on/off status of the Arranger parts.


- 1. Use the [♣] fields to select the page that contains the Arranger/Style part whose volume you want to change or that you wish to switch off.
- 2. If the [Volume] field is not displayed in white, press it. Otherwise, you'll change another parameter setting.

PanPot (stereo position)

The VA-76 allows you to specify the PanPot setting (stereo position) of every part individually. One sensible way of using the PanPot parameter could be to move the Upper1 part to the left output, while the Upper2 part is moved to the right output. If you then layer Upper1 and Upper2 (by activating [UP1] and [UP2] on the page you select with the [OTHER] button), the Upper1 sound will come from the left speaker, while that of the Upper2 part will come from the right speaker.

Here is how to specify the PanPot setting of a part:

- 1. Select a Mixer page (see page 112).
- 2. Select the part group (Keyboard or Style) by pressing either [Keybrd Mixer] or [Style Mixer].
- Select the Single Part or Palette page.
 On the Palette page, use the [←][→] fields if the desired part is not displayed.
- If you chose to work with the Single Part page, select
 the part whose setting you wish to change by pressing
 [†] or [†].




4. Set a value between 1 and 63 to move the part further to the left, or 65~127 to move the part further to the right.

Note that you can also select *Rnd* (Random), which means that the part will alternate between the left and right channels in a random way.

Note: The percussion sounds of the M.Drums and A.Drums parts are already panned in stereo. Changing the PanPot setting for these parts means that the entire stereo distribution will be shifted to the left or right.

More locks

You may have noticed the locks on the [Style Mixer] Single Part page:



They allow you to choose whether the Chorus (Send), Reverb (Send), and PanPot settings for the Arranger/ Style parts will be used or not.

On the Single Part page, press the Auto/Man] field.

Man—The settings remain in effect until you change them again, until you select another User Program, or another Style. (Man is short for Manual).

Auto— In this case, the Arranger parts will use the settings contained in the Music Style patterns you select. Music Styles not only contain notes (i.e. the drum, bass and accompaniment parts) but also a series of settings that specify how the parts are to be played back. These settings include Program Change messages, PanPot, volume, etc.

Music Styles are accompaniment patterns that are repeated every so often (usually after four bars). The non-note information is located at the beginning of a pattern, so that, if you select *Auto*, the Mixer settings of the Arranger parts will be reset as soon as the pattern restarts from bar 1 – or every time you select another division (Original, Variation, Fill, etc.).


If you do not want your changes to be overwritten by the information contained in a Music Style, select Man.

Note: These locks are managed intelligently: as soon as you modify one of the above parameters for an Arranger/Style part, the lock is opened automatically (because the VA-76 assumes that you actually want to use the settings you make).

Note: The lock settings have no effect on the reception of MIDI messages via MIDI IN. However, the VA-76 is also equipped with MIDI filters that allow you to suppress the reception of certain MIDI messages.

8.3 Output Assign

The VA-76 is equipped with four outputs grouped into two pairs: OUTPUT 1 and OUTPUT 2.



The OUTPUT 1 sockets are considered the main connectors, which is why all parts are assigned to them by default. In some cases, such as when using the VA-76 for multitrack recording or if a given part should be processed using an external effects device, you may want to take advantage of the OUTPUT 2 sockets. The parts assigned to the OUTPUT 2 sockets are no longer processed by the VA-76's effects (or Equalizer), nor controlled by the [VOLUME] knob on the front panel.

Except for the VariPhrase and Audio In parts, all of the VA-76's parts can be freely assigned to the desired OUTPUT socket(s).

That is: the Keyboard parts...



...the Arranger ("Style") parts...



... and the Recorder ("Song") parts.




Here is how to assign a part to the desired output:

1. Press the [FUNCTION MENU] button.



2. Press the [Output Assign] field in the bottom row.



- 3. Depending on the group the desired part belongs to, press the [Keyboard Parts], [Style Parts] or [Song Parts] field so that it is displayed in white.
- In the above example, the Keyboard Parts section has been selected.
- 4. Press the field assigned to the desired part so that it is displayed in white.
- 5. Use the [TEMPO/DATA] dial or the [DATA] button/Numeric Entry to select the desired OUTPUT socket(s):
- 1L/R— The part is connected to the OUTPUT 1 sockets. Its stereo position can be controlled using the Pan-Pot parameter. Such a part can also be processed by the VA-76's internal effects.
- **2L/R** The part is connected to the OUTPUT 2 [L] and [R] sockets. Its stereo position can be set using the PanPot parameter.
- **2L** The part is connected to the OUTPUT 2 [L] socket.
- 2R— The part is connected to the OUTPUT 2 [R] socket. Choosing "2L" for one part and "2R" for another thus allows you to process two VA-76 parts separately using external effects.

Note: If you select a "2" option, the part's volume can no longer be controlled using the [VOLUME] knob, nor can such a part be connected to the internal effects.

6. Press [EXIT] to return to the Master page.

Note: The Output Assign settings are written to a User Program, thus providing even greater flexibility.

8.4 Effects and Equalizer

The VA-76 is equipped with three programmable effects (Reverb, Chorus, and Delay), a multi-effector (called *Insertion M-FX*) and a parametric two-band equalizer.

Note: Any changes to the effects programs apply to all parts, as there is only one Reverb, one Chorus, one Delay, and one Equalizer (EQ). What can be specified for every part individually, though, is the amount of effect to be applied (effect depth/send).

Note: The M-FX is only available for the Keyboard parts, while the Delay is not available for the M.Drums or A.Drums part.


Note: The VariPhrase and Audio In parts use separate Reverb and Chorus effects.

Note: Parts assigned to an OUTPUT 2 socket cannot be processed using the internal effects.

Applying Reverb, Chorus, or Delay to a part

1. On the selected Mixer page (see page 112) select the part group ([Keybrd] or [Style]) and the part whose effect send setting you wish to change.


Do not forget to press the [Keybrd Mixer] or [Style Mixer] field to gain access to the desired part. The effect send settings specify the part level for the signal that is fed to the Reverb, Chorus, and Delay effect respectively. Setting high Reverb, Chorus, and Delay values means that you effectively increase the effect level.



As you see, one Palette page of the Keyboard Mixer level looks a little different. That is because neither the VariPhrase nor the M.Drums part can be processed with the Delay effect.

- 2. Press the [Delay] field and modify the Delay send level.
- 3. Press the [Chorus] field and modify the Chorus send level.

4. Press the [Reverb] field and modify the Reverb send level.



Note: The Reverb, Delay and Chorus send levels cannot be set for Keyboard parts you assign to the M-FX effect (see page 122). The M-FX effect, however, has the same send parameters (see page 123).

Effects settings

Three of the VA-76's effects can be edited and thus tailored to your needs. The settings you perform here apply to all parts that use the effect in question. Especially for the Reverb and Chorus effects, it is therefore wise to work with universally usable settings. Try to consider these two as "general" effects that will be used by several parts at once.

The Delay effect, on the other hand, is probably only useful when applied to one part (because too many repeated sounds clutter up the sound image).


Note: The VariPhrase and Audio In parts use separate effects. See page 124.

- 1. Select the effects parameters you wish to edit:
- a) Select a Mixer page (see page 112) and press the [Effect] field.




---or---

b) Press the [EFFECTS] button.



The display now looks more or less as follows:




- 2. Press the field that is assigned to the effect you wish to edit (left column).
- 3. Press a field in the center of the display to select an effect type.

The number of types depends on the selected effect.

4. Use the [Level] slider in the right part of the display for setting the output level of the effect processor itself.

This parameter allows you to set the volume of the selected effects processor. The connection is as follows:



The [Level] sliders therefore allow you to change the balance between the selected effect on the one hand and the mix of the Keyboard and Style/Arranger parts plus the remaining effects on the other hand.

Note: This slider duplicates the function of the "Level" parameter found on the Parameters page (see page 118, for example).

5. Press the [Macro] field to recall the preset parameters for the selected effects type (Room1, Room 2, Room 3, etc. on the above page).

This recalls suitable preset values for all effects parameters (Pre-LPF~RevPre DlyT in the case of the Reverb effect). The difference between *Macro* and *Character* (see below) is that the former does what its name implies: it calls up a program Macro that includes Character selection and Parameters settings for the selected effect.

Note: "Character" is only available for the Reverb effect.

Note: Do not press [Macro] after making your own settings on one of the Parameters pages for that would reset all your changes to the factory settings.

6. Press the [Param] field to jump to the Parameters page of the selected effect.

7. On that page, press the field of the parameter you want to edit and change its value with the slider, the [TEMPO/DATA] dial, or the [DATA] button/Numeric Entry pad.

Reverb types & Parameters

This is where you can edit the Reverb effects processor.



Room1, Room2, Room3	These Reverbs simulate the reverberation of a room. They provide a well-defined spacious reverberation.
Hali1, Hali2	These Reverbs simulate the reverberation of a concert hall with a deeper reverberation than the Room Reverbs.
Plate	This effect type simulates a plate Reverb (a stu- dio device using a metal plate to simulate natu- ral Reverb).
Delay	This is a conventional Delay that produces echo effects.
Pan Delay	This is a special Delay in which the delayed sounds move left and right. It is effective when you are listening in stereo.

Seeing that Delay usually only works for one part, use the dedicated Delay processor for echo effects. That way, the Reverb effect can be used to "deepen" the sound field.

Character (0~7)— Character only specifies the Reverb type you need. It does not load preset values for the Pre-LPF~RevPreDlyT parameters. Selecting another Character thus does not reset the other Parameter values to their factory settings. A Macro, on the other hand, calls up a Reverb type and suitable settings for that effect.

Pre-LPF (0~7)— A low-pass filter can be applied to the Tone signal sent to the Reverb to cut the high frequency range before it is processed by the Reverb. Higher values will cut more of the high frequencies, resulting in a more mellow Reverberation. Note that this parameter only applies to the signal that is sent to the Reverb effect. If you want to cut high frequencies of the direct Tone signals, use the Equalizer instead (see page 119).


Level (0~127)— This parameter sets the volume of the Reverb effect (or the Master AUX Return signal if you are used to thinking in mixing console terms). Higher values result in louder reverberation.

Time (0~127)— This parameter sets the time over which the reverberation will continue. Higher values result in longer reverberation.

Delay Fb (0~127)— This parameter is only available when you select Character "6 Delay", or "7 Panning Delay". It sets the way in which Delays repeat. Higher values result in more repeats.

PreDlyT (0ms~127ms)— This parameter sets the time interval between the original ("dry") signal and the onset of the selected Reverb effect. Higher values result in a longer pre-Delay time, simulating a larger Reverberant space.

Chorus types & Parameters



Chorus broadens the spatial image of the sound, adding richness. You can choose from 8 types of Chorus.

Chorus 1~4	These are conventional Chorus effects that add spaciousness and depth to the sound. This is a Chorus with a Flanger-like effect and a soft sound.		
Fb Chorus			
Flanger	This is an effect sounding somewhat like a jet air- plane taking off and landing.		
S Delay	This is a Delay with a short Delay time.		
S Delay FB	This is a short Delay with many repeats.		

Seeing that Delay usually only works for one part, use the dedicated Delay for echo effects. That way, the Chorus effect can be used to fatten the stereo image.

Pre-LPF (0~7)—A low-pass filter can be applied to the sound sent to the Chorus to cut the high frequency range. Higher values will cut more of the high frequencies, resulting in a more mellow Chorus sound.

Level (0~127)— This parameter sets the overall volume of the Chorus effect. If only one Tone contains too much Chorus, reduce its Chorus Send value (see page 116) rather than this Level value.

Feedback (0~127)— This parameter sets the level at which the Chorus sound is re-input (fed back) into the Chorus. By using Feedback, a denser Chorus sound can be created. Higher values result in a greater feedback level.

Delay (0~127)— This parameter sets the Delay time of the Chorus effect. Higher values will cause greater deviation in pitch of the Chorus sound.

Rate (0~127)— This parameter sets the speed (frequency) at which the Chorus sound is modulated. Higher values result in faster modulation.


Depth (0~127)— This parameter sets the depth at which the Chorus sound is modulated. Higher values result in deeper modulation.

Cho▶ Reverb (0~127)— This parameter sets the amount of Chorus sound that will be sent to the Reverb. Higher values result in more sound being sent. The value "127" effectively allows you to connect the Chorus and Reverb effects in series (Chorus before Reverb). If you do not wish the Chorus signal to be processed by the Reverb effect, set this value to "0".

Cho▶ Dly (0~127)— This parameter sets the amount of Chorus sound that will be sent to the Delay. Higher values result in more sound being sent. The value "127" effectively allows you to connect the Chorus and Delay effects in series (Chorus before Delay). If you do not wish the Chorus signal to be processed by the Delay effect, set this value to "0".

Note: Press the [Default Value] field to recall the factory setting for the currently active (white) parameter. Press the &Back field if you want to select another Macro.

Delay types & Parameters



A Delay creates echoes. It is also possible to give depth and width to a sound by adding a short Delay to the original sound (a technique often used for rock-'n'-roll songs and in Karaoke bars). You can choose from among 10 types of Delay.

Delay 1~3	These are conventional Delays. 1, 2 and 3 have progressively longer Delay times.		
Delay 4	This is a Delay with a rather short Delay time (a kind of "slap back" effect).		
Pan Dlay 1~3	The Delay sound moves between left and right. This is effective when listening in stereo. 1, 2 and 3 have progressively longer Delay times.		
Pan Diay 4	This is a rather short Delay with the Delayed sound moving between left and right. It is effective when listening in stereo (kind of stereo "slapback" effect).		
Dly To Rev	Reverb is added to the Delay sound which moves between left and right. It is effective when listening in stereo.		
PanRpeat	The Delay sound moves between left and right channels, but the pan position is different from the effects listed above. It is effective when listening in stereo.		

Pre-LPF (0~7)—A low-pass filter can be applied to the sound coming into the Delay to cut the high frequency range. Higher values will cut more of the high frequencies, resulting in a more mellow Delay sound.

Time C (0.1ms~1.0s)— The Delay effect of the VA-76 allows you to set three Delay times: center (C), left (L), and right (R). Time C sets the Delay time of the Delay located at the center.

TRatioL/R (4%~500%)— This parameter sets the delay time of the left- or right-channel Delay line as a percentage of the central Delay. The value "100%" means that the left or right Delay repeats at the same speed as the center Delay.

Level C/L/R (0~127)— These parameters set the volume of the central, left, and right Delays. Higher values result in a louder Delay.


Level (0~127)— This parameter sets the overall volume of the three Delays (center, left and right). Higher values result in a louder overall Delay.

Feedback (-64~ 0 ~+63)— This parameter specifies the number of times the Delay will repeat. With a value of "0", the Delay will not repeat. With higher values there will be more repeats. With negative (-) values, the center Delay will be fed back with inverted phase. Negative values are effective with short Delay times

Dly ► Rev (0~127)— This parameter sets the amount of Delay sound that is sent to the Reverb. Higher values mean that the Reverb portion will be more prominent in the Delay signal. Be careful not to overdo this effect because it tends to blur the sound image.

Note: Press the [Default Value] field to recall the factory setting for the currently active (white) parameter. Press the [►Back] field if you want to select another Macro.

Equalizer



This equalizer works the same way as the Treble and Bass knobs on an amplifier. It allows you to boost or cut the high and/or low frequencies of the Tones. By boost we mean that the volume of a certain frequency band is increased, while cut means that the volume is decreased. The Low and High frequencies to be boosted or cut are selectable.

1. Select a Mixer page (see page 112), press the [Effect] field, and the [Equalizer] field (left column).


- 2. Press the Low Gain [400Hz] or [200Hz] field to select the low frequency to be boosted or cut.
- 3. Press the Low Gain value field and use the slider (right), the [TEMPO/DATA] dial, or the [DATA] button/Numeric Entry pad to enter a positive (boost) or negative value (cut) for the Low Gain parameter (-12~+12dB).
- 4. Press the *High Gain* [6kHz] or [3kHz] field to select the high frequency to be boosted or cut.
- 5. Press the High Gain value field and use the slider (right), the [TEMPO/DATA] dial, or the [DATA] button/Numeric Entry pad to enter a positive (boost) or negative value (cut) for the *High Gain* parameter (-12~+12dB).

Choosing the parts to be processed by the equalizer

When you power on the VA-76, all parts are set to be processed by the equalizer, so that you can use the equalizer as master tone control that modifies the bass and treble response of your instrument.

An equalizer is usually only effective when used to correct the frequency response of one sound that is in the way of other sounds. Therefore, you now need to switch the equalizer off for all parts that don't require tone correction.

- 1. Select a Mixer page (see page 112).
- 2. Select the Mixer group that contains the part whose settings you want to change by pressing the [Keybrd Mixer] or [Style Mixer] field.
- 3. Press the [Single Part] field.
- 4. Use the [♠][♣] fields to select the desired part.
- 5. Press the Equalizer [ON/OFF] field to make it read [OFF] (blue) if you don't want the part in question to be processed by the equalizer.



8.5 Insertion effect (M-FX)

Using the insertion effect


Your VA-76 contains a multi-effect that can be assigned to the Keyboard parts (if they are assigned to the OUTPUT 1 sockets, see page 115). You can select one type and decide which Keyboard part(s) should use the effect. As applying this effect to one or several Keyboard parts also changes the way in which the Keyboard part(s) can take advantage of the remaining effects (Reverb, Chorus, Delay, and Equalizer), this effect is called an *insertion effect* (because it is inserted into the signal path). See page 123 for details.

The [M-FX] knob on the front panel allows you to control one parameter of the insertion effect in real-time, and thus to add even more expression to the parts you play.

1. Press the [ON/OFF] button (so that it lights) to switch the insertion effect on or off (the button goes dark).

Doing so also changes the way in which the affected Keyboard part(s) is processed by the other effects.

2. Use the [M-FX] knob to control the assigned parameter while playing.



This assignment is preset and cannot be changed. Bear in mind, though that it varies according to the currently selected M-FX effect. It always influences the parameter for which realtime control really makes sense.

Realtime control via the display

If one effects parameter is not enough for the sound changes you want to achieve, you can select the following display page where two M-FX parameters can be controlled (one of which is also assigned to the [M-FX] knob). For your convenience, the names of these parameters are also displayed so that you know exactly what you are doing.

Note: The parameters assigned to the [M-FX] knob are also indicated by a "e" in the table starting on page 219.

Let's have a look at how you can modify the two effects parameters and add even more expression to your music:


1. If the UP1 part is currently off, press the Keyboard Mode [OTHER] button followed by the [KEYBOARD MODE] field and switch it on (see page 36).

2. Press and hold the M-FX [ON/OFF] button to jump to the following display page:



This page may look vaguely familiar (especially the left column). There are indeed other ways of selecting this page: via the [Mixer] field on the Master page, or via the [EFFECTS] button (see page 112). But you then need to press a few other fields before reaching this page, so pressing and holding M-FX [ON/OFF] is definitely faster.

- 3. Check whether the M-FX [ON/OFF] button lights.
- 4. Press the [Param] field to jump to the following page:



5. Depending on the kind of parameters that can be controlled, use the two fields in the left half of the display (called Slow and Fast for the "13 Rotary" effect) or the two M-Value sliders for realtime changes. The parameters being controlled depend on the currently selected M-FX effect. See page 219 for details. Here is an example: If you select the "15 SpFlangr" type, the controllable parameters are Feedback (M-Value 1) and Step Rate (M-Value 2). You could also press the [M-Value 1] or [M-Value 2] field and use the [TEMPO/DATA] dial or the [DATA] button/Numeric Entry pad. Press the [Default Value] field to recall the factory setting for the currently active (white) parameter.

Note: The current settings will also be written to a User Program (along with all the other panel and parameter settings)

Note: One M-Value parameter can be assigned to an optional Expression pedal. See page 193 for details. This allows you to control the "other" parameter (the one not assigned to the [M-FX] knob) by foot.

Note: In the case of the Rotary effect, you can also toggle between the "Slow" and "Fast" settings using an optional FC-7 foot controller or a PAD button. See pages 193 and 194.


M-FX Selection Mode: automatic Tone link for Upper1

The Upper1 part is considered to be the most important part. The VA-76 therefore automatically loads the M-FX type that is linked to the Tone you assigned to the Upper1 part. A good example of this is the selection of the 13 Rotary type for organ Tones. The status of the M-FX is also memorized and may thus change.

Though this is usually very convenient, there may be times when you wish to remain in control yourself. In that case, proceed as follows:

- 1. Press and hold the M-FX [ON/OFF] button.
- 2. On the page that appears now, press the [M-FX Sel Mode] field.


The display now looks more or less as follows:



- 3. Do one of the following:
- a) Press the [Auto] field if the VA-76 should choose a suitable M-FX type for you.
- **b)** Press the [Manual] field if you do not want the M-FX to change automatically.


Note that it is perfectly possible to activate [Auto], to select a different M-FX type by hand, and to save that setting to a User Program (see page 127).

Below please find the factory assignments (to program change numbers, which means that they apply to all CC00 and CC32 banks that are linked to these program change numbers):



Assigning the M-FX to a Keyboard part

You may have noticed the Insertion M-FX [ON/OFF] field on the Single Part pages of the Keyboard parts (see page 113). Here is an example:




Press it (so that it reads [ON]) to assign the currently selected Keyboard part to the M-FX.


Note: This effect is not available for the Arranger/Style parts, nor for the VariPhrase or Audio In parts.

By the way: the M-FX is also called *Insertion* effect because this processor is located between the Keyboard parts and the other effects.


For a Keyboard part that is not assigned to the M-FX, the connection between this part and the other effects/ OUTPUT 1 sockets is as follows:



When a Keyboard part is assigned to the Insertion M-FX, that part is no longer directly connected to the Outputs or the other effects:



This is also reflected in the display:



Notice how the [Delay], [Chorus], and [Reverb] fields are displayed in gray. That is because they no longer influence the signal of the Keyboard part in question. And careful: if the M-FX [ON/OFF] button does not light, any Keyboard part assigned to the M-FX will not be audible.

There is only one M-FX, so all Keyboard parts assigned to it will use the same type. If the M-FX effect is processed by the Reverb, Chorus, and Delay effects (see page 123), the assigned Keyboard parts also use the same Reverb/Chorus/Delay & EQ settings.

Note: Keyboard parts assigned to either or both OUTPUT 2 sockets cannot be processed using the M-FX.

Selecting an M-FX type

Let us now have a look at how to select a different type (effect) for the M-FX processor. Each type you select is loaded with suitable preset settings that cannot be edited on the VA-76 itself. You can, however, modify two parameters per type via the [M-FX] knob on the front panel and the two sliders on the M-FX Parameters page (see page 121). See page 219 for a description of the types and the controllable parameters.

1. Press and hold the M-FX [ON/OFF] button to jump to the following display page:



If another field in the left column is displayed in white, press the [M-FX] field.

- 2. If necessary, use the [♣][♣] fields to select another set of 15 types.
- 3. Press the field that corresponds to the M-FX type you need.

You may want to set the M-FX to Manual mode to avoid accidental changes when you select another Tone for the Upperl part. See page 121.

M-FX Send: processing the M-FX with the other effects

As you know, Keyboard parts that you assign to the M-FX lose the Reverb, Chorus, and Delay Send capabilities, while their [Equalizer] field also becomes inactive.


You could, however, set these parameters for the M-FX itself, in which case, the signal is processed as follows:

- a) The signals of all Keyboard parts assigned to the M-FX are combined and transmitted to the M-FX.
- b) The M-FX processes these signals.
- c) By setting the parameters below, you can process the output signal of the M-FX with the Reverb, Chorus, and Delay effects, and also route it through the Equalizer.

You probably know how to do the above, so we'll leave you to it. (If not, see pages 116 and 119.) Here's how to select these parameters:

- 1. On the above display page, press the [Param] field.
- 2. On the page that appears now, press the [→] field.

The display now looks more or less as follows:




- 3. Use the sliders, the [TEMPO/DATA] dial, or the [DATA] button/Numeric Entry pad (see page 49) to set the desired send values.
- 4. Press the [Default Value] field to reset all three sliders to their factory setting ("40", "0", "0").
- 5. Use the [Equalizer] field to divert the M-FX signal to the EQ (white) or directly to the speakers and outputs (blue).

8.6 VariPhrase and Audio In effects

The VariPhrase and Audio In parts are two separate entities, which is why they do not share the same effects processors as the Keyboard and Arranger/Style parts. The advantage is that your "virtual" (Vari-Phrase) and "actual" (Audio In) vocals can be processed with just the right effect settings, regardless of how you set the "other" effects processors.

Consequently: even though a slider appears side by side with the [M.Drums], [Upper2] and [Upper1] sliders (see the illustration), and even though you can set the Reverb Send and Chorus Send levels along with those of the other Keyboard parts, their settings bear in fact on different processors.



See page 57 for the Send sliders of the Audio In part.

Here's how to select the desired Reverb and Chorus effects for the VariPhrase and Audio In parts. There are no parameters you can set. The Audio In part provides an [ON/OFF] field for quickly activating and switching off both effects. This can also be done with a footswitch, see page 192, or an optional FC-7. The latter also applies to the VariPhrase part.

- 1. Select a Mixer page (see page 112).
- 2. Press the [EFFECT] field.
- 3. Press the [Reverb] or the [Chorus] field, depending on whether you wish to select another effect type for the Reverb or the Chorus effect.
- 4. Select an effect type by pressing the desired field:

VariPhrase/Audio In Reverb types:

Room 1~3, Hall 1~3— See page 118.

Garage— Simulates the Reverb of a relatively small, but "live" space (with many reflections).

Plate— Simulates the Reverb of a mechanic device (a metal plate) that was very popular a few years ago for simulating Reverb. Digital simulations of these characteristics are still widely used for vocals.

No Linear— A deliberately "unnatural" Reverb effect that may be just what you need in a given situation.

VariPhrase/Audio In Chorus types

Chorus 1~4— See page 118. The difference between these four lies in the speed of the undulations and the depth of the effect.

Fb Chorus— This Chorus effect is already reminiscent of a Flanger and creates a soft sound.

Flanger— This effect is similar to the sound evolution of a jet plane taking off and landing.

Short Delay, Fb Delay— See "S Delay" and "S Delay FB" on page 118.

8.7 Sound Palette: editing Keyboard part parameters

Your VA-76 allows you to edit certain parameters that affect the way a Keyboard part sounds when you play it. These parameters will help you "modify" the parts by adjusting their brilliance, their modulation speed (Vibrato Rate), and so on.


Please bear in mind that the parameters discussed in this chapter only apply to the following Keyboard parts: Upper1, Upper2, Lower1, M.Bass (you must select one of these to ensure that the [Sound Palette] field is displayed). (The VariPhrase part provides its own editable parameters, see page 77 and following.) Assigning another Tone to a Keyboard part does not reset the part parameters discussed below. In other words, if you modify the envelope of the piano sound assigned to the Upper1 part, you might be inclined to think that you have changed the envelope of the piano Tone and that selecting another Tone for Upper1 will load other envelope settings. Though that is partly correct, the part parameter settings are added to the settings of the Tone you assign to a part.

Parts are in fact containers in which you can "put" a Tone and whose sound can be modified using the parameters described below.

Note: All Part parameters are relative parameters whose values are added to or subtracted from the preset Tone parameter values. That is why you can specify both positive ("more") and negative ("less") values.

- 1. Press the [TONE] button in the BANK/NUMBER section, or the [Tone] field on the Master page.
- 2. On the page that appears now, press the [Part] field in the lower left corner.

Note: Rather than performing steps (1) and (2), you could also press the [PART] button in the BANK/NUMBER section.




3. Press the [Sound Palette] field.



- 4. In the left column, press the field of the Keyboard part you wish to edit.
- 5. To quickly reset the selected parameter, press the [Reset] field.
- 6. To edit one of the displayed parameters, press its field and use the slider, the [TEMPO/DATA] dial, or the [DATA] button/Numeric Entry pad (see page 49).
- 7. Use the [←][→] fields to select the remaining Sound Palette parameters.

Here are the Part parameters you can edit:

Modulation (Vibrato)



Vibrato is an effect created by modulating the pitch. Applying vibrato makes the sound more expressive. Pitch modulation adds a pleasant "wobble" to the notes you play. Use the following three parameters if you think the part in question has too much (or could use a little more) vibrato.

Note: Some "V" Tones contain natural (sampled) vibrato whose depth or speed cannot be changed.


Vibrato Rate [-64~63]— This parameter adjusts the speed of the pitch modulation. Positive (+) settings make the preset pitch modulation faster, and negative (-) settings make it slower.

Vibrato Depth [-64~63]— This parameter adjusts the intensity of the pitch modulation. Positive (+) settings mean that the "wobble" becomes more prominent, while negative (-) settings make it shallower.

Vibrato Delay [-64~63]— This parameter adjusts the time required for the vibrato effect to begin. Positive (+) settings increase the time before vibrato will begin, and negative settings shorten the time.


Note: There are additional modulation parameters that can be controlled via the Aftertouch (see page 189). Use them for WahWah (TVF modulation) or tremolo (amplitude modulation).

Timbre (TVF)



By modifying the filter settings, you can control the timbre (tone) of the sound. The VA-76 uses Low-Pass Filters (LPF) that allow only frequencies below the specified frequency to pass. The frequency where the filter starts "cutting off" harmonics (or overtones) is called the Cutoff Frequency. By modifying the setting of the Cutoff Frequency you can make the sound brighter or darker. The Cutoff Frequency can change over time, controlled by the "envelope". By adjusting the filter and envelope settings, you can create sounds that have movement and expression.

TVF Cutoff [-64~63]— Positive Cutoff settings mean that more overtones will be allowed to pass, so that the sound becomes brighter. The further this value is set in the negative direction, the fewer overtones will be allowed to pass, and the sound will become softer (darker).



Note: For some sounds, positive (+) Cutoff settings will cause no noticeable change because the preprogrammed Cutoff parameter is already set to its maximum value.

TVF Resonance [-64-63]— This is a parameter one invariably associates with a synthesizer. When the Resonance value is increased, the overtones in the area of the cutoff frequency will be emphasized, creating a sound with a strong character.


Note: For some sounds, negative (-) settings of Resonance may produce no noticeable change because the Resonance is already set to the minimum value.

Envelope



The volume of an instrument changes with time, from the moment the note begins to sound to when it disappears. This change can be indicated on a graph as shown below. The envelope shape is unique to each instrument, and is an important element in how we distinguish the sounds we hear. The envelopes of musical instrument sounds can change depending on how the instrument is played. For example if a trumpet is played sharply and strongly, the attack will be quick and the sound will be sharp. But if a trumpet is played lightly and softly, the attack will be softer. In order to adjust the attack of a sound, you can modify the Attack Time of the envelope. By modifying the values of the envelope you can simulate the characteristics of many different instruments.

The envelope parameters affect both the volume (or amplitude) and the filter. If the cutoff frequency has been lowered, it will rise as the envelope rises, and will fall as the envelope falls.



Env Attack [-64~63]— This parameter adjusts the onset of the sound. Negative values speed up the attack, so that the sound becomes more aggressive.

Env Decay [-64 ~63]— This parameter adjusts the time over which the sound will fall from the highest point of the attack down to the sustain level.

Note: Percussive sounds usually have a sustain level of 0.

Piano and guitar sounds are in this category. Holding the

keys for a long time will thus have little effect on the dura-

tion of the notes you are playing.

Env Release [-64~63]— This parameter adjusts the time over which the sound will decay after the note is released until it is no longer heard. The cutoff frequency will also fall according to this setting.

9. Registrations - User Programs

The VA-76 is equipped with 128 User Programs that allow you to store almost all settings (or registrations) you make on the front panel. Before taking a closer look at these User Programs, there is one thing we have to point out. All settings relating to MIDI must be written to a MIDI Set (see page 207).

MIDI settings are not saved to a User Program. The reason for this is simple: You probably need a lot more memories for your songs than you do for your MIDI gear. Writing the MIDI settings to a User Program would slow down the loading process.

Note: It is perfectly possible to link a MIDI Set to a User Program, so that the User Program in question also recalls the linked MIDI Set (see page 131).

For the Disk Link and the Disk User memories, your VA-76 also memorizes the name. If, at the time you recall such a User Program, that Style is not accessible, the display will respond with:



(There is a similar message for Styles on floppy disk.) Press [ZIP Eject] to eject the current Zip disk (or the eject button on the floppy disk drive), and insert the proper disk. If you are sure you don't have the disk with you, press the [EXIT] field. In that case, the VA-76 will go on using the last Style you selected.

A similar system applies to Songs. A User Program can indeed be programmed to automatically prepare the desired song, so that all you have to do is press [PLAY ▶] to start playback. Here's what happens if you insert the wrong disk (Zip or floppy):



See above for what to do then.

9.1 Writing your settings to a User Program

It is a good idea to save your settings frequently even if you still need to do some touching up afterwards. Those intermediary saves allow you to return to the previous stage whenever you do not like your last modifications. Try to use the User Programs as "recall buffers" to be able to return to the previously edited settings, discarding only the latest modifications.

Save your settings after...

- ...setting the VariPhrase parameters;
- · ...changing the parts' Output Assign settings;
- · ...defining the functions of the PAD buttons;
- · ...selecting Tones for the Keyboard parts;
- ...selecting a Style, the first division, and after setting the tempo;
- · ...assigning other Tones to the Arranger parts;
- ...editing the Mixer settings.
 In short, every time you like the settings you just made. That way, subsequent modifications can be undone by loading the "provisional" User Program settings you do not want to lose.
- 1. Press the [Usr Prg] field on the Master page. The display now looks more or less as follows:



2. Press the [MEMORIZE] field.



3. Use the [A]/[B] and numeric fields to select the group, the bank and the memory number where you wish to write your settings.



One final step before writing your settings to a User Program is to assign a name to your settings. You only have to do this the first time you write (or "memorize") new settings to a User Program. On the other hand, you can also name your User Program at a later stage and then write it again under the same address. If you do it now, you do not have to worry about renaming your User Program.

Use a name that somehow summarizes the memory's contents. The name of the song you will use these settings for is probably the most explicit name you can think of.

4. See page 68 for how to enter the desired name. It is perfectly possible to program several User Programs for one song. Selecting a User Program is a lot faster than calling up one of the VA-76's functions, modifying the settings, etc., while playing. You could program one User Program for the first part of a song, another one for the bridge, and a third one for the closing section. Doing so allows you to "play" with the effect settings of the Keyboard and/or Arranger parts, or the VariPhrase part, for example.

5. Press the [EXECUTE] field.

The display confirms that the settings have been written to the selected memory and returns to the page of step (1) on page 127.

9.2 Selecting User Programs


Free Panel

For Song Composer playback, or whenever you want to start anew, you should always select the factory-set *FreePanel* User Program that contains the default settings of your VA-76.

The Free Panel settings can be changed and selected any time, i.e. even after selecting a "regular" User Program.

The Free Panel memory can be selected in two ways:

a) Simultaneously press User Program [DOWN] and [UP]; —or—



b) Press the [USER PROGRAM] button followed by the [Free Panel] field on the display page that appears then.


Note: Free Panel is read-only. You cannot write data to this memory.

Note: Unless you specified a User Program for the Startup function (see page 131), you can also load the Free Panel settings by powering off your VA-76 and turning it back on again.

Selecting a User Program (Group, Bank, Number)

Selecting User Programs works exactly like selecting Tones: you can work with the BANK/NUMBER section (after pressing [USER PROGRAM]), via the display, or both. See pages 37 and 39 for details.

Instead of pressing the [USER PROGRAM] button, you can also press the [Usr Prg] field on the Master page.



There are two groups (A and B), with eight banks and eight memories each. You can select the group (A or B) and the bank (1~8) a little ahead of the song part where you want the new settings to take effect. Only when you specify the User Program *number* will the corresponding settings be loaded.

The name of the selected User Program is displayed on the Master page:




The asterisk (*) only appears when you change a parameter setting after loading a User Program. This is to alert you to the fact that the current settings no longer correspond to the ones you recalled. If you like them better than the original settings, you must write them again. See page 127.

Note: You do not need to load all User Program settings. See "Selectively loading User Program settings (User Program Cancel Options)".

Selecting User Programs using the [DOWN][UP] buttons

The following method is especially useful if you programmed two or more User Programs for a song or if the User Program sequence corresponds exactly to the song sequence you are about to play (i.e. settings of the first song or song part in memory All, settings of the second song or song part in Al2, etc.). Pressing [DOWN] or [UP] immediately selects the following or preceding User Program.



[UP]— Selects the following User Program (for example A13 if you selected A12 before pressing this button).

[DOWN]— Selects the preceding User Program (for example A11 if you selected A12 before pressing this button).

Note: If you press [UP] after selecting A88, your VA-76 will call up B11. Likewise, if you press [DOWN] after selecting B11, your VA-76 will call up A88, and so on.


User Programs can also be selected using the footswitch connected to the FOOT SWITCH socket on the rear panel. See "UsrPrg Up" and "UsrPrgDown" on page 191 for details.

Selectively loading User Program settings (User Program Cancel Options)

The VA-76 is equipped with several options that allow you to keep certain settings of the previous User Program while selecting another User Program. You could use this to quickly assign other Tones to the Keyboard and/or Arranger parts without loading the Style parameters contained in the new User Program, for example.

Let's have a look at the possibilities. The desired Cancel Option can be set via the display:

- 1. Press the [USER PROGRAM] button or the [Usr Prg] field in the display.
- 2. If you need a different User Program, select it, otherwise...



3. ...press the [Cancel Options] field.
The display now looks more or less as follows:



4. Press the field that corresponds to the settings you do *not* want to recall.

To ignore the Tone selection data of a new User Program, press the [Tone] field so that it is displayed in white.

Style & Song—Press this field if the settings related to the Arranger (Style and Division) or the Song (see "Linking a Song to a User Program" on page 130) should no longer be loaded.

Tones—Press this field to ignore Tone selection for the Keyboard parts when a different User Program is recalled.

KBD Mode— Press this field to ignore the Keyboard Mode (Whole/Split) and Arranger Chord settings (Standard/Piano Style, Left/Right, etc.).

Transpose— Press this field to ignore the Transpose (value and mode) contained in every User Program.

Tempo— Press this field if the tempo setting contained in every User Program should be ignored.

MIDI Set—Press this field if the linked MIDI Set (see page 131) should not be recalled. This allows you to use a User Program, that you originally programmed for a given MIDI setup, even with a different MIDI setup. The current MIDI channels, filter settings, etc., (see page 201) will thus not change.

Pressing one of the above fields without selecting a User Program afterwards has no effect. Only when you select another User Program will the selected data filter (because that is what the User Program Cancel Options are) start working.

To once again load all settings of the new User Program, press the Cancel fields that are displayed in white (so that they turn blue again).

If one of the Cancel options has been activated, the [Cancel Options] field on the User Program selection page contains a tick (✓):



9.3 Automatic functions for User Programs


Song & MIDI (Set) Link

Song & MIDI (Set) Link are two functions that allow you to:

a) link a Song to every User Program, so that by recalling the User Program, you also prepare the song in question. Songs reside on disk, which means that the disk must be inserted. Otherwise, this system won't work. All you need to do then, is hit the Song Composer [PLAY ▶] field to start playback of that song.

b) link a MIDI Set to every User Program. See page 207 for details about MIDI Sets. They contain all MIDI settings for all sections and parts of your VA-76. By linking a MIDI Set to a User Program, you could thus completely reconfigure not only the VA-76 itself, but also the way in which it (a) can control external MIDI instruments and (b) can be controlled from other MIDI instruments.

- 1. Press the [USER PROGRAM] button or the [Usr Prg] field in the display.
- 2. On the display page that appears now, press the [Song & MIDI Link] field:



The display now looks more or less as follows:



Linking a Song to a User Program

- 3. Insert a Zip or floppy disk into the (appropriate)
- 4. Press the [→Song List] field to jump to the display page where you can select a song.



See page 31. You can select a Song from Zip or floppy. Bear in mind that the Song data are not loaded into the User Program memory. You will have to insert the Zip or floppy in question into the drive before recalling this User Program. (Otherwise, an error message is displayed. See page 127.)

5. Press the Song [Link OFF] field to make it read [Link ON] if the selected Song should be prepared every time you select this User Program.

Note: Do not forget to write your User Program after changing these settings (see page 127).

Note: If the desired Song is not loaded, check the Cancel Options (see page 129). The message in question might be filtered.

Linking a MIDI Set to a User Program

MIDI Sets are "User programs for MIDI parameters". There are eight such memories (see page 207). If you regularly use the VA-76 in different MIDI environments (studio, live, band), preparing three MIDI Sets and linking them to the User Programs you usually use in the studio, on stage, etc., can be a time saver. In other situations, such a link could be **dangerous**, because it would reconfigure the VA-76's MIDI parameters without you actually knowing it.

- 6. Press a MIDI Set [1]~[8] field to select the desired MIDI Set.
- 7. Press the MIDI Set [Link OFF] field to make it read [Link ON] if the selected MIDI Set should be recalled every time you select this User Program.

Note: Do not forget to write your User Program after changing these settings (see page 127).

8. Press the [+ Back] field and the [EXIT] field to return to the Master page.

User Program selection at power-on

Whenever you switch on the VA-76, it automatically selects User Program 00 Free Panel (see page 128). But maybe you prefer to be "operational" right away (without using the Virtual Band function). In that case, tell the VA-76 which User Program it should recall whenever you switch it on:

- 1. Press the [FUNCTION MENU] button.
- 2. Press the [Global Parameter] field on the Function Menu.
- 3. Press the [Startup] field in the bottom row of the display.



- 4. Press the [Startup User Program] field so that it is displayed in white.
- 5. Use $[\, \updownarrow \,] [\, \updownarrow \,]$ or the [TEMPO/DATA] dial, to select the User Program to be recalled.

If you don't want a User Program to be recalled, select "Off".

6. Press [EXIT] to return to the Master page.

10. Song Composer (the basics)

The Song Composer of your VA-76 is a Standard MIDI File player/recorder with the additional advantage that is can double as 16-track sequencer whenever you want it to.

The VA-76's Composer reads GM/GM2/GS compatible Standard MIDI files.

Note: You may be confused by the words "Song" and "Standard MIDI File" we use in this chapter. There is absolutely no difference because the VA-76's songs are saved to disk as Standard MIDI Files.

Note: The Chord Sequencer on previous Roland models has been replaced by an even more userfriendly recording function (2nd Trk). See page 66.

10.1 A few remarks about recording songs

This section only contains a few hints about recording your own songs. See the "Song Composer clinic" on page 65 for hands-on information.

Formatting a disk

Songs that you record are first stored in the VA-76's Song RAM memory. When you press the [EXIT] field while a Song Composer page is displayed, however, you will be prompted to save it to disk. That is why you should to prepare a floppy or Zip disk. If you prefer to use a floppy disk, choose a reliable 2HD (high density) disk.

Though the VA-76 can also read MS-DOS-formatted disks, it would be a good idea to format all disks you intend to use with the VA-76. This is especially true of Zip disks: during formatting, the VA-76 indeed also creates a number of folders where your various files will be stored. An MS-DOS-formatted Zip disk does not contain these folders, which might create problems

Note: Be careful never to format the Zip disk supplied with your VA-76. It would be a pity to lose all the precious material it contains.

- 1. Insert a Zip or floppy disk into the (appropriate)
- 2. Press the [FUNCTION MENU] button.
- 3. On the display page that appears now, press the [Disk] field.
- 4. Press the [Utility] field in the bottom row.

The display now looks more or less as follows:



5. On the display page that appears now, press the [Format] field.



- 6. Press the field that corresponds to the disk type you wish to format (Zip or floppy).
- 7. Press the field that corresponds to the type of formatting you want to use:

Quick—Choose this option to "initialize" new (usually MS-DOS formatted) disks. This is a lot quicker than the *Full* option.

Full— This option is only necessary for disks you used on platforms with a different data and formatting structure.

The display now responds with:




(In the case of a floppy disk, the "ZIP" will read "Floppy", of course.)

8. Press the [YES] field to format your disk. Press [NO] to return to the previous display page without formatting.

Note: If necessary, see page 62 for how to eject the Zip disk.

If you press [YES], the display shows an animated clock to indicate that the disk is being formatted.



You can exit this display page without interrupting the formatting process by pressing the [EXIT] field. That allows you to do something else while the VA-76 is formatting.

Before recording

Though you can record without using the Arranger, that is probably not what you want to do. Here are a few things you should do before starting to record:

- 1. Stop Arranger playback.
- 2. Assign the desired Tones to the Keyboard parts you want to use for recording. Select the desired Vari-Phrase if you wish to use it for recording.

Note: The notes played with the VariPhrase part will sound different on other SMF-compatible instruments because the VariPhrase processor does not conform to the GM/GM-2/GS format. As long as you only want to play back your songs using the VA-76 (or a VA-7), nothing should stop your from taking advantage of the VariPhrase part.

- 3. Select the desired Keyboard Mode (see page 34).
- 4. Select the desired Arranger Chord mode (see page 102).
- 5. Select the Style, the division etc. you want to use.
- 6. Prepare the desired Orchestrator and Morphing settings (see page 62).

There are at least three other ways of configuring the VA-76:

- a) Use the Virtual Band function (see page 22).
- b) Select the User Program that contains all the settings you need for the song you are about to record (see page 128).
- c) Select a Style while the One Touch function (see page 29) is on.
- 7. See page 65 for what to do now.

10.2 Song List: searching songs on disk (Find)

Like the Arranger, the Song Composer provides a clever system for locating the desired song on a Zip disk. The display pages for floppy disks look similar, but they neither provide the [Author] and [Genre] fields, nor the Find functions.

The Song List Find function is very similar to the Find function for Music Styles. See "Find: locating Styles on a Zip disk" on page 109. One item has a different name, though, because that makes more sense: Author replaces the "Country" entry of the Music Style Find function. Apart from that, the Song List function should feel familiar. The "Author" can refer to the artist who made the song famous, or to the composer (who might be a different person, as you know).

- 1. Press the [SONG COMPOSER] button.
- 2. On the display page that appears now, press the [Song List] field.



3. See page 109 for the main operational steps.

Play & Search: finding Songs by playing a few notes

The Play & Search function (or P&S) is like a very gifted assistant. You can ask your VA-76 something like the following: "what's the name of the song that goes like this..." (and then you play the main theme). Here is how to use this exciting function:


Note: This function is only available for Zip disks, so be sure to press the [ZIP] field (next to [LOAD] and [FLOPPY]).

1. On the Zip Song Options page (see above), press the [Find] field.

There are now three options: [GO To...], [Find Only], and [Play & Search].

2. Press the [Play & Search] field.

The display now looks more or less as follows:



3. Play the notes of the Song you want the VA-76 to find.

The key and rhythm are of little importance. (You must get the intervals right, though!) The note boxes will display a quarter note for every note you played. Five "note boxes" thus mean that you played five notes.

- 4. If you make a mistake, proceed as follows to correct it:
- Press the [Delete Last Note] field if you only wish to correct the last note.
- Press [Reset] to erase all notes you have played so far.
 Then play the notes again.
- 5. Press the [SEARCH] field to launch the search for Songs that match the melody you played.

The display returns to the ZIP list page (see step (2) above). This time, only the names of the songs that contain the excerpt you played will appear in the List window. That's why the counter may display something like "12 of 301".

6. Press the field of the Song you need, and then press the [LOAD] field.



7. Press [←Back] to return to the main Song Composer page and start playback of your song. Please be aware that Play & Search is not supported by just any song. In fact, the P&S information is not "standard" Standard MIDI (and therefore not part of the files themselves). It belongs to the Database information to be found on a VA-76 Zip disk.

Songs for which there is Play & Search information are flagged with a note symbol $(\ \)$ to the left of their names on the Song List page.

Note: You can also program this information for Songs for which it is not yet available. See "P&S Input" on page 140.

10.3 Song playback functions

Playing back a standard MIDI File requires that you insert a disk containing song files into the corresponding drive and that you select the desired song. See "Listening to Standard MIDI Files" on page 31 for details.

Song playback transforms the VA-76 into a GM2/GS sound module, thereby deactivating the Arranger section of your instrument. Leaving this mode is a matter of pressing the [EXIT] field.

The Keyboard parts remain active in Composer mode, and you can mute or solo any part of the song you are playing back. That way, you can also use Standard MIDI Files as backing tracks.



Before starting playback of songs for which there is no User Program, simultaneously press User Program [DOWN] and [UP] to select the factory User Program (Free Panel). The Free Panel memory contains the default settings for all parts and is the only guarantee that the songs on disk will sound exactly the way the recording artist wanted them to.

On the other hand, the VA-76 also allows you to modify the way in which Standard MIDI Files are played back (see "Header Post Edit" on page 161). You can thus "customize" Standard MIDI File playback.

Note: The VA-76 allows you to program Song Chains (or "Song Sets" on previous models). See "Song Chains" on page 137 for details.

Note: Songs on floppy or Zip can be linked to a User Program, so that selecting such a User Program automatically prepares the desired song. All you have to do then is start playback. See "Song & MIDI (Set) Link" on page 130.

Lyrics function

This function was provided to allow you to read the lyrics of the song the Composer is playing back in a karaoke fashion: the words to sing will be highlighted at the right time. Note that this function is only available for Standard MIDI Files that contain lyrics. Ask your dealer for details.

1. Insert a Zip or floppy disk into the appropriate drive and select the Standard MIDI File with lyrics data that you wish to play back.

Note: The Standard MIDI Files on the supplied Zip disk contain no Lyrics data.

- 2. Press the [SONG COMPOSER] button.
- 3. On the display page that appears now, press the [Lyrics] field.

The display now looks more or less as follows:



4. Press the [PLAY ▶] field to start Song playback. The lyrics are now displayed on screen:



5. Press the [STOP ■ | ◄] field to stop playback, or the [←Back] field to return to the main Song Composer page.

Note: You can also program and edit lyrics yourself. See page 157.

Fast Forward, Rewind, and Reset

To fast forward or rewind within the current song, first press the [PLAY ▶] and then [FFW ▶▶] to fast forward, or [◀◀ BWD] to rewind. Pressing [FFW ▶▶] takes you to the next measure of the current song, while [◀◀ BWD] takes you to the measure before the current one. You can hold down either field to accelerate the fast forward or rewind process. The measure indication in the display will help you locate the measure you need.

Press the [STOP ■ | ◄] field once more after stopping Song playback to return to the first measure of the song (Reset).

Loop playback (Markers)

Another clever feature of the Song Composer is that you can program playback loops. You can do so during playback or while the Song Composer is stopped.

- 1. Select a Song Composer page where the [A:] and [B:] fields are displayed.
- 2. Press [A:] where you want the loop to begin (that field is displayed in white).



3. Fast forward to the measure where you want the loop to end and press [B:] (this field is also displayed in white).



You can also program loops on the fly. Remember, however, that the Composer always memorizes the beginning (downbeat) of the next measure.

4. To activate the loop you have just programmed, press the field.

At the end of the B measure, the Song Composer immediately jumps back to the beginning of measure A.

- 5. To stop playback, press the [STOP | ◄] field.
- 6. Press the field again to deactivate the loop.

Changing the song tempo

You can change the (programmed) song tempo with the [TEMPO/DATA] dial or the [TEMPO/TAP] button (by tapping the desired rhythm). Such changes are only temporary, however, and will be overridden by tempo change messages contained in the song data. Furthermore, every time you jump back to the beginning of the song using [STOP ■] ◄], the preset song tempo will be recalled.

Note: You can edit the tempo using "Header Post Edit" on page 161.

Soloing and muting parts

Before muting a part for Minus One performances, you have to know which part (MIDI channel/track) plays the notes you do not want to hear. Unfortunately, the Standard MIDI File format, specific though it may about certain aspects, still leaves a considerable amount of liberty for programmers. Finding the part you want to mute is not always easy, though the VA-76 can help you find it.

Note: See also "Tracks and MIDI channels" on page 141.


Soloing parts

To find out which part is assigned to which MIDI channel, you can use the Solo function. This function mutes all other parts except the current one. Once one part has been soloed, you can add other parts and so switch on all Song parts one after the other. You could use this facility for Dance/House "mixing" by first switching on the bass, then the drums, etc., simply by adding these tracks to the parts already soloed. The Loop function (see above) might come in handy for such DJ applications. Here is how to solo one or several parts:

1. Load a Standard MIDI File.

2. On the Song Composer page (see above), press the [Minus One] field.

The display now looks more or less as follows:



The [1]~[16] entries refers to the 16 MIDI channels of the currently selected Standard MIDI File. The [ON] and [OFF] switches are only displayed for tracks that contain data. Careful, though: when you start playback of a newly loaded song, the [ON]/[OFF] indications are not always reliable. So please first start playback of the first 15 measures, reset ([STOP ■] ◄]) and then solo the part(s) you need. This also possible during playback.

- 3. Press the [Solo] field (so that it is displayed in white). At first, this will solo track 4.
- 4. Now press the [OFF] field of the part you want to listen to in isolation (so that it reads [ON]). To "un-solo" track 4, press its [ON] field, so that it reads [OFF]

It also possible to solo several tracks, which means that you only hear the track/MIDI channels whose [ON/OFF] field reads [ON].

5. Press the [Solo] field again to switch off the solo function.

Note: The Solo settings are never written to a User Program. Use the mute facility for switching off the tracks that should be switched off when you select the User Program in question.

Muting tracks/MIDI channels

On this page (and while the [Solo] field is displayed in blue) you can also *mute* tracks/MIDI channels. Muted Song parts do not sound during playback. This is thus the opposite of the Solo function: here, you need to select the tracks/MIDI channels you *don't* want to

- 1. Select the above display page (see "Soloing parts").
- 2. Press the [ON] field of the track you wish to mute so that it reads [OFF].

Again, you can mute several tracks simultaneously. By muting 15 tracks/MIDI channels, you effectively do the same as when you press the [Solo] field and select the track you wish to solo (except that you would then have to press 15 [ON] fields, which is not very convenient).

Note: The Solo status takes precedence over the Mute status. To mute a soloed part, you must turn off the Solo function.

3. Press the [←Back] field to return to the Song Composer page, or go on to the next section.

Note: The Mute settings can be written to a User Program (see page 127) so be sure to only mute the tracks you do not want to be active every time you select the User Program in auestion.


Note: See also "Header Post Edit" on page 161 for some interesting parameters you can change and save along with the song itself, as well as "In-depth editing of a 16-track song" on page 148.

Using the metronome

See page 66.

Song/Keyboard-part balance


Use the [BALANCE] knob on the front panel to modify the volume balance between the Standard MIDI File and the Keyboard parts. Turn it to the left to increase the Standard MIDI File's volume (ACCOMP), and to the right to increase the Keyboard part volume (KEYBOARD).



Transpose

Of course, it is also possible to take advantage of the VA-76's Transpose function, which may be convenient if you are used to playing a given song in another key than the one used by the selected Standard MIDI File. There are two methods for setting the transposition:

① Hold down the [ONE TOUCH] button while repeatedly pressing the User Program [DOWN] or [UP] button.



Repeat this operation with the "opposite" button (e.g. [DOWN] if you pressed [UP] above) to return to standard pitch. See also page 53.


Note: Transposition applies to all parts except the MDR (Manual Drums) and track/MIDI channel 10 (plus any additional track that may use a Drum Set rather than a Tone).

2 Proceed as follows:

a) Press the [SONG COMPOSER] button. The display now looks more or less as follows:



b) Press the [Transpose] field. The display now looks more or less as follows:



c) Set the desired transposition interval (see page 53).

d) Select the desired transposition mode (see page 53). To transpose both the Keyboard parts and the song tracks, switch on the [Internal] and [Song] fields.

The transposition interval and mode are displayed as follows on the Song Composer page:



10.4 Song Chains

Song Chains (called "Song Sets" on previous Roland models) are another useful feature for performing artists because they allow you to take a break without leaving the audience without music. Song Chains are in fact sequences that specify the order in which the Standard MIDI Files on a given disk are to be played back.


Song Chains can either produce continuous playback of up to 99 songs on disk (floppy, Zip) or be programmed to stop at the end of each song, which means that you have to start playback of next song manually.

Compiling or editing a Song Chain

1. Insert the Zip or floppy disk that contains the songs you wish to combine to a Chain into the (appropriate) drive.

Note: Do not use commercial Standard MIDI File floppy disks or the supplied Zip or floppy disk. Also, Song Chains can only refer to song files that reside on the same disk. You may want to use a Copy function before proceeding (see page 214).

- 2. Press the [SONG COMPOSER] button.
- 3. Press the [Song Chain] field.



4. Press the [ZIP] or [FLOPPY] field to select the drive that contains the songs you want to "chain". If you want to edit an existing Song Chain, select it here by pressing the corresponding field. Use [↑][↓] if the name of the desired Song Chain is not displayed.


5. Press the [Edit] field.



(The display on your VA-76 may look slightly different.)

6. Press the [New] field to create a new Song Chain. Ignore this step if you want to edit (change) an existing Song Chain (the one you selected above).

The display now looks as follows:



7. Press the first list field (the one that reads "End") and [Song List].



8. Use the [TEMPO/DATA] dial to select a song on disk that is to be played first (assigned to Position 1).

9. Press the [CAPTURE] field.

The "End" entry now becomes Position "2", while Position "1" contains the name of the selected Standard MIDI File.



In the case of a Zip disk, you could also press the [Song List] field and use the Find function to narrow down the search.

- 10. Press the Position "2" field so that it is displayed in white.
- 11. Repeat steps (7)~(10) to compile your Song

End is the last entry. Any song after the End marker will not be included in your Song Chain.

12. Press the [Cancel] field to delete the currently selected Position.

This is the Position that is displayed in white. You cannot delete the "End" position.

If you are editing a Song Chain, you can use the $[\ \ \]$ $[\ \ \ \]$ fields to browse through the available steps.

13. Press the [Save] field to save your Song Chain. Your Song Chain will be saved under the first available number. You cannot name your Song Chain.

After saving the Song Chain to disk, the display returns to the Song Chain page.

14. Press the [◆Back] field to return to the Song Composer page (see above).

Your new (or edited) Chain is already selected and can be played back.

Playing back a Song Chain

To play back a Song Chain, proceed as follows:

1. See steps (1)~(4) on page 137.



2. Press the field of the Song Chain you wish to play

Use the $[\uparrow] [\downarrow]$ fields if the desired Chain is not displayed in one of the 8 fields.

3. If you do not want to play back the entire Chain, use the m or m field to select the position where playback should start.

You can use these fields during playback or after pressing [STOP ■] ◀] to jump to the next or previous step.

4. Press the [PLAY ▶] field to start playback of your Song Chain.

The songs of the selected Song Chain are played back one after the other.

5. Press the [STOP ■ | ◀] field to stop playback.

Chain Mode

The Chain Mode allows you to specify how the selected Song Chain should be played back. This is typically a function you set after selecting the desired Song Chain but before starting playback.

Press the [Auto] field if playback of the next song in Chain is to start automatically when the current song is finished.

Press the [Manual] field if you wish to be in control of when playback of the next song should start. This means that playback stops automatically at the end of the current song. To start the next song, you need to press the [PLAY] field.

Note that it is perfectly possible to change this setting during Song Chain playback. If you start out with [Auto], you'll have plenty of time for a drink during a break. At the end of your break, you could press the [Manual] field and wait until playback of the currently selected song is finished. Then press [STOP | | | | | and go on entertaining your audience!

Deleting a Song Chain

Deleting a Song Chain is a matter of pressing the [Delete] field on the Song Chain page after selecting the Song Chain you no longer need. A deleted Song Chain cannot be restored (you will have to program it again).



10.5 Song Options

As for the Style Find function, there also a number of utilities for renaming or deleting Standard MIDI Files on Zip or floppy disks. They work more or less the same as the Style Options. See therefore page 110 and following.

Here's how to select them:

- 1. Press the [SONG COMPOSER] button.
- 2. On the display page that appears now, press the [Song List] field.



- 3. On this display page, press the [FLOPPY] or [ZIP] field.
- **4.** Press the [Options] field.

 If you pressed the [ZIP] field, the displ

If you pressed the [ZIP] field, the display now looks more or less as follows:



If you pressed the [FLOPPY] field, the display now looks as follows:




- **5.** Press the [Rename] or [Delete] field. Bear in mind that there is no "Country" entry for songs. This entry is called "Author".
- **6.** See page 110 for how to rename or delete a song. Note: Songs referenced by a User Program (see page 130) can no longer be loaded automatically if you change the [File Name] or if you delete them.

Note: If you rename or delete a song that is referenced by a Song Chain (see page 138), the Position in question will be empty. The VA-76 will skip such empty Positions during playback of the Chain in question. (Be aware that this may shorten your break when you use the VA-76 for gigs.)

P&S Input

This option allows you to program the theme that by which to find the Song using the Play & Search function (see page 133). It is only available for Zip disks.

- 1. Press the [SONG COMPOSER] button.
- 2. Press the [Song List] field, followed by the [ZIP] field.
- 3. Select the song for which you want to program a theme.
- 4. Press the [Options] field.
- 5. Press the [P&S Input] field.



6. Play the notes of the most characteristic theme (the one you'll be most likely to play when using Play & Search for locating this song).

The key and rhythm are of little importance. (You must get the intervals right, though!) The note boxes will display a quarter note for every note you played. Five "note boxes" thus mean that you played five notes.

- 7. If you make a mistake, proceed as follows to correct it:
- a) Press the [Delete Last Note] field if you only wish to correct the last note.
- **b)** Press [**Reset**] to erase all notes you have played so far.

Then play the notes again.

8. Press the [EXECUTE] field to save this information to Zip disk.

Songs for which there is Play & Search information are flagged with a note symbol $(\ \ \ \)$ to the left of their names on the Song List page.

Note: The Play & Search function is Database information that is not part of the songs themselves. It resides in a different area on the Zip disk.


11. Song Composer (16-track, etc.)

11.1 16-track Sequencer

The Song Composer of your VA-76 is linked to a 16-track sequencer with full-fledged editing functions that allows you to refine your recordings in great detail.

Selecting the 16-track sequencer

1. Press the [SONG COMPOSER] button.



The display now looks as follows:



2. Press the [16 Tracks Sequencer] field to select 16-track sequencer. The display may now look like this:



General considerations

The 16-track sequencer can be used to record sequentially onto 16 tracks (one track after the other). Since the 16-track sequencer and the Song Composer share the same RAM memory, you can lay down your first tracks using the Song Composer (with or without Arranger), and then select the 16-track sequencer to add new tracks or change existing ones. The Song Composer indeed allows for simultaneous multitrack recording, which is not possible with the 16-track Sequencer where you can only record one track at a time, and where the Arranger is not available.

Tracks and MIDI channels

Tracks are assigned to MIDI channels on a 1:1 basis (i.e. Track 1= MIDI channel 1,... Track 12= MIDI channel 12, etc.). Since the Keyboard parts have been assigned to the MIDI channels in such a way as to allow for easy Minus-One playing using the Song Composer (see page 31), you should take a minute to study the table below.

Obviously, if you record a song with Arranger backing, the respective parts (ADR, ABS, etc.) are recorded onto the tracks that are assigned to their MIDI channels.

Tract (SMFauro)	igini (y-76 p	are:
	dame!	Song Composer	Arranger
10 (Drums)	10	M.Drums*	A.Drums
1 (Piano)	1	-	Accomp 1
2 (Bass)	2	M.Bass*	A. Bass
3 (Chords)	3		Accomp 2
4 (Solo/Melody)	4	Upper1	Upper1
5 (Not specified)	5	_	Accomp 3
6 (Counter-melody)	6	Upper2	Upper2
7 (Not specified)	7	_	Accomp 4
8 (Not specified)	8		Accomp 5
9 (Not specified)	9	_	Accomp 6
11 (Not specified)	11	Lower1	Lower1
12 (Not specified)	12		M.Bass*
13 (Not specified)	13	VariPhrase	VariPhrase
14 (Not specified)	14	Lower2	Lower2
15 (Not Specified)	15	MEL Int	MEL Int
16 (Not specified)	16		M. Drums*

(*) The MIDI channel of these parts depends on whether you are working with the Arranger (see page 65) or the Song Composer.

There is yet another track, called M, that is used for recording the time signature, the tempo, as well as general SysEx messages.

As you see, there are two Keyboard parts (M. Bass, M. Drums) whose MIDI channel (and track) assignments depend on whether you use the Song Composer for recording a song with Arranger or not. If you are used to working according to a given system, you could use Exchange to transfer the data to the desired tracks after recording them. See page 154 for details.

Example 1: Recording a track

Here's how to add a track to a song in the VA-76's Song RAM memory. This is only meaningful after recording a song using the Song Composer or after playing back a song on disk. See page 145 for how to start a new song.

Note: Though the following may seem confusing at first, you will find very quickly that the 16-track Sequencer uses a very logical structure. Please bear with us and perform all indicated steps to get a feel for how the 16-track Sequencer "ticks". Besides, what you learn here will also come in handy for recording your own Music Styles.

Note: See also "Easy editing and useful functions" on page 147 for some additional functions that are not covered here.

- 1. Press the [SONG COMPOSER] button and the [16 Tracks Sequencer] field.
- 2. If the following page is not displayed, press the [Rec] field in the bottom row of the display.



- 3. Press the [Master] field in the upper left corner. Field ① in the upper right corner informs you about the current measure and the time signature. You can use [◀◀ BWD] and [FFW ▶▶] to jump to another measure, or [STOP |◀] to return to the beginning of the song. Field ② shows which tracks contain data and are active. No switch (neither [ON] nor [OFF]) means that the track in question doesn't yet contain data.
- 4. Press the big [Track] field more or less in the middle and use the [TEMPO/DATA] dial to select the track you wish to record.



The name of the selected track appears in the [Track] field and is indicated by a white box (in the above example, track 1 has been selected).

Note: Select track 13 to record using the VariPhrase part. But be careful: You cannot work with the VariPhrase part if it has not been assigned to the song. You need to initialize the Song RAM memory and activate the VariPhrase part for Composer use, or initialize track 13. See page 146.

Selecting the (Recording) Mode and the first measure



5. Press the [Mode] field and use the [TEMPO/DATA] dial to specify how the new data should be recorded. Select Erase if a track contains data you wish to replace with new data. This erases all data of the selected track from the place where you start recording until the end. (Erase is selected by default for empty tracks.)

Select Merge to add new notes to the ones already recorded on the selected track. This recording mode is particularly useful for recording the rhythm track (10) because you can first record the bass and snare drums, then add a few tom hits here and there, and record the HiHat, for example.

Punch In/Out allows you to re-record part of a track. Select this mode to replace a phrase you do not like with a new version. Doing so has the advantage that only the area where you punch in and out will be overwritten. See also page 144.

Setting the Metronome and the Quantize, Octave values (Options)

- 6. Press the [ON/OFF] field to switch the metronome "ON" (or "OFF" if you don't need it). If you also wish to specify when the metronome should sound, proceed as follows:
- a) Press the [Options] field:



The display now looks more or less as follows:



- **b)** Press the Metronome [Mode] field. This takes you to a familiar display page. See page 66 for details.
- c) Select the desired Metronome Mode and press [+Back] to return to the above page.

Theifollowing two parameters can be set by pressing the corresponding field and by using the LTEMPO/TAP dial and the [DATA] button/Numeric Entry pad (see page 49).


7. Press the [Octave] field.

This is only necessary if you want your notes to be sounded and recorded in a different octave than the one you use for playing. This can be useful for recording a part which is just a little too low (or too high) and therefore does not "fit" into 61-note range covered by the keyboard.


Another creative use for this parameter is for recording the "noises" of the "V" Tones mentioned on page 42: select a track that already contains data, set Octave to "-4", select the *Merge* Mode (see above), and start recording (see below) for adding your scrapes, knocks, etc.

8. Press the [Quantize] field and set the desired resolution.

Quantize corrects the timing of your notes by shifting them to the nearest grid mark. Use the [TEMPO/DATA] dial to specify the number of grid marks per measure (i.e., the Quantize resolution). Here is an example:



The setting range is: 1/8, 1/8t, 1/16, 1/16t, 1/32, 1/32t, 1/64t, and Off. As this Quantize function changes the way in which your notes are recorded, you may want to select Off here. The 16-track sequencer has a second Quantize function that you can use more selectively (i.e., for notes that are definitely late/early). See page 151.



Selecting a Tone or Drum Set

The following parameter allows you to assign a Tone (normal track) or Drum Set (track 10 or the 2nd Drum Track) for the selected track, or to modify/ replace existing setting.

9. Press the [Tone] field in the upper left corner.



The display now looks more or less as follows:



For all tracks except track 10 (and another track that also uses a Drum Set), the field to look out for is called *Current Tone*. For track 10 (and any other drum track), this parameter is called *Current Drum Set*.

Note: Use the VariPhrase pad to assign a phrase to the VariPhrase part.

10. Press the [Current Tone/Current Drum Set] field and use the BANK/NUMBER pad to select the desired Tone/Drum Set.

Note: See "Using two drum tracks (2nd Drum Track)" on page 145 for how to select a second drum track.

11. If necessary, press the [REC] field so that it is displayed in white.

In Merge mode (see page 142), you can specify whether or not to record the settings made on this page by switching the [REC] field on (white) or off (blue). In Erase and Punch In/Out modes, it is automatically switched on ([REC] is displayed in white).

12. Play a few notes on the keyboard to check whether you like the selected Tone or Drum Set.

Volume (Level)

13. Press the [Mixer] field in the left column.



The display now looks more or less as follows:



- 14. Press the [Level] field in the left column so that it is displayed in white.
- **15.** If necessary, use the [VOLUME] slider for setting the desired volume.

You can also touch it and use the [TEMPO/DATA] dial or the [DATA] button/Numeric Entry pad for entering the value. (You can also leave this for later.)

16. If necessary, press the VOLUME [REC] field so that it is displayed in white.

These fields (like the two remaining ones on this page) follow the same system as Tone/Drum Set selection above.

17. Play a few notes on the keyboard to check whether you like your settings.


Note: See also "Mixer: Changing the volume, adding effects" on page 147.

Want some effects?

18. Press the [Effect] field.



The display now looks more or less as follows:



19. Use these three sliders to specify the selected track's Send level for the Reverb, Chorus and Delay effects.

These sliders set the volume of the track signal that is sent to the effect, and consequently how much effect should be added to the track. See page 116 for how to set the effects (type, parameters). Those "overall" effect settings are part of the general SysEx settings of the "M" track and must be set before recording the first track.

Note: The Delay effect is not available for drum tracks (10, and any other track that uses a Drum Set) or track 13 (assigned to the VariPhrase part), while the M-FX is not supported at all.

Use the [REC] fields to specify whether or not these settings should be recorded.

- 20. Play a few notes on the keyboard to check whether you like your settings.
- 21. Use the [FFW ▶▶] or [◀◀ BWD] field to select the measure where you want to start recording. For Punch In/Out recording, select a measure that lies a little before the place where you wish to punch in.

Recording in Erase or Merge mode

Press the [REC ●] and [PLAY ▶] fields. After a 1-measure count-in, recording will begin.

Recording in Punch In/Out mode

 To record in Punch In/Out mode, first press the [REC ●] field (it starts flashing). Next, press [PLAY ▶] to start playback.

As soon as the VA-76 reaches the point where you want to punch in, press [REC ●] to start *recording*. (The [REC ●] field is now displayed steadily.) You could also use a footswitch for doing so. See "Punch I/O" on page 191.

22. To stop recording, press [STOP ■] <].

During Punch In/Out recording, you could also press [REC ●] or the footswitch. In that case, recording is deactivated, while playback continues.

Saving your song

The 16-track sequencer uses a special portion of the VA-76's RAM memory where all editing takes place. To ensure that you do not forget to save your song after recording and/or editing it, you are given the opportunity to do so upon leaving the Song Composer page (by pressing [EXIT]):



Note: The Song RAM memory is erased when you switch off your VA-76.

1. Press [YES] to save your changes (and the entire song). This will take you to the following display page:



If you don't want to wait until the above warning ("Song has been changed...") is displayed automatically, proceed as follows. Using this "manual" Save function has the advantage that you can save your song whenever you are happy with your latest recording or edits. Bear in mind that a power failure is all it takes to lose your song. Don't wait until it is too late...

- a) Press the [Save] field in the bottom row.
- b) Press the [Name] field.
- c) On the display page that appears now, press the [Save] field in the bottom line.
- 2. See page 67 for details about saving your song.

Example 2: Recording a song from scratch

Let us now record a Song from scratch using the 16-track sequencer.

1. Press the [SONG COMPOSER] button and the [16 Tracks Sequencer] field.

Let us suppose that you already played back a Song. That means that the VA-76's Song RAM memory already contains song data we need to erase. (Even if the VA-76's Song RAM memory is still empty, using the Initialize function would be a good idea.) Here is how to:

- 2. Press the [Utility] field.
- 3. On the display page that appears now, press the [Initialize] field.

The display now looks more or less as follows:



The warning alerts you to the fact that pressing [EXE-CUTE] (see below) may have disastrous consequences. See "Saving your song" if you still need to save your previous song.

4. Press the following three fields and enter the desired values using the [TEMPO/DATA] dial or the [DATA] button/Numeric Entry pad.

Time Signature—If your new Song uses the 4/4 time signature, there is no need to change this value. Otherwise, enter the desired time signature (1/2~32/16).

Tempo— Allows you to specify the initial tempo of the new song (J = 20-250). Choose a tempo which is comfortable for recording. You can set the final tempo using the Song Header Edit function (see page 161).

Using two drum tracks (2nd Drum Track)

An additional advantage of the *Initialize* function is that you can define a second track as drum track. This allows you to use two Drum Sets: the one assigned to track 10 (fixed, in accordance with GM-2/GS), and another one assigned to the track you define here. This allows you to use a "standard" drum kit alongside a "beat box", or to add orchestral percussion to a song that also requires a "regular" drum kit.

Your song data are saved in the Standard MIDI File (SMF) format. You can therefore play them back using your computer (with suitable software) and any GM/GS compatible module or synthesizer. Bear in mind though, that not all modules accept two Drum Sets. You cannot define a second drum track for existing songs. This is only possible when you initialize the

Song RAM memory. (Songs programmed on other instruments that already contain two drum tracks can be used like VA-76 songs with a "2nd Drum track", though.)

Select Off if you don't need a second Drum Set, or set the number of the desired track. "10" is not available here because it always functions as Drum track.

Assigning the VariPhrase part by initializing the Song RAM memory

The [a on track 13] field allows you to decide whether or not the VariPhrase part should be used in your new song. Press this field and use the [TEMPO/DATA] dial to select "On" if you want to assign the VariPhrase part to track 13. Otherwise, leave this parameter in the "Off" position.

5. Press the [EXECUTE] field to really initialize the Song RAM memory (which you haven't done so far). The VA-76 now confirms that the Song RAM memory is initialized and then jumps to the [Master] 16-track Sequencer page.

All tracks will be initialized as follows:

Volume	100	
Expression	127	
Tone/ Drum Set	"Piano 1" "Standard" Set for track 10 + 2nd Drum Track	
PanPot	64	
Reverb	40	
Chorus	0	
Delay 0 (not available for drum tracks/VariPhr		

6. See "Example 1: Recording a track" on page 142 for what to do now.

Initializing only track 13 for VariPhrase use

The following function allows you to initialize just track 13 for VariPhrase use, leaving the rest of the song untouched. This may come in handy when track 13 of an existing song contains nothing at all (or a part you no longer need). In that case, initialize it and record the desired VariPhrase part.

- 1. Press the [SONG COMPOSER] button and the [16 Tracks Sequencer] field.
- 2. Press the [Utility] field.

3. On the display page that appears now, press the [Initialize 13th Track] field.

The display now looks more or less as follows:



- 4. Press the [EXECUTE] field to initialize track 13. Remember that this erases the notes and other MIDI messages of that track.
- 5. See "Example 1: Recording a track" on page 142 for what to do now.

11.2 Editing 16-track songs

Easy editing and useful functions

After recording a track, you may want to do some touching up. Here are some easy things you can do. See "In-depth editing of a 16-track song" on page 148 for more elaborate functions.

[Play Trk]

If this field is displayed in blue, you are currently on the page you select with the [Options] field. Press [Play Trk] to return to the [Master] 16-track Sequencer page:



Muting tracks

Sometimes, when recording rhythmically intricate parts, it may be necessary to mute already recorded parts that might distract you. To do so, press the [ON] field of such a track so that it reads [OFF]. This setting is not saved to disk.

Solo

If you need to listen to a track in isolation, press the [SOLO] field and the [OFF] field of the track you want to solo, and start playback. This mutes all other tracks. You can add other tracks to this Solo signal by pressing the [OFF] fields. See page 136 for details about the solo function.

Mixer: Changing the volume, adding effects On the above display page, press the [Mixer] field.



The [Level] and [Effect] fields call up two sets of three faders you can use to specify the initial settings for the selected track, or to modify/replace existing settings. If the "Track" field next to [Master] field does not display the number of the desired track, press [Master] and select the desired track:

a) Press the [Track] field...

b) ...and use the [TEMPO/DATA] dial to select the track

REC fields— In Merge mode (see page 142), you can specify for each parameter whether or not to record the settings made on these pages. In *Erase* and *Punch In/Out* modes, all [REC] fields are displayed in white (which means that the settings will be recorded).

1. Use the sliders to set the values.

These parameters can also be changed in realtime: select the Merge mode so as not to overwrite the notes, and start recording from the position where the new settings should take effect. You can stop recording after one beat. For continuous changes, use the slider in question to set the desired values and stop recording when no further changes are required.

Note: Such edits are also possible on the [Tone] page (see page 143). These allow you to "register" another Tone or Drum Set for a track.

2. Switch the desired [REC] fields on (white) or off (blue).

Volume— (0 \sim 127) Allows you to set the track volume (CC07). Use this parameter to specify the initial volume. You can use *Expression* to program temporary volume changes during the course of the song.

Expression— $(0\sim127)$ Allows you to program relative volume changes (CC11). The value "127" means that the resulting volume will be equal to the volume set with the Volume parameter above. All other Express values reduce the Volume value.

Panpot— Use this parameter to specify the stereo position of the selected track. "64" means dead center, values between 0 and 63 shift the sound to the left, while values between 65 and 127 shift the sound to the right.

Reverb, Chorus, Delay— Specify the Send level for the effect in question. See also page 144.

3. Start recording in Merge mode but don't play any notes (because we're only putting the icing on the cake of an already perfect track).


As stated above, you can also move the sliders for realtime changes. You can also use this procedure for adding Pitch Bend, Aftertouch, etc. to the notes of a track.

In-depth editing of a 16-track song

The Edit level of the 16-track mode provides eight functions: Erase, Delete, Insert, Transpose, Velocity, Quantize, Gate T., and Shift.

Here is how to select these Edit functions:

- 1. Load the song you wish to edit (if it does not yet reside in the VA-76's Song RAM memory).
 See page 31.
- 2. Press the [SONG COMPOSER] button.
- 3. Press the [16 Tracks Sequencer] field.
- 4. Press the [Edit] field in the bottom row of the display.



5. Press a field in the left column to select the desired function.

If, after selecting one of these functions, you decide not to execute the transformation, do not press the [EXECUTE] field.

Filers are a few gindelines for editing your 15-track song.

Nate: Save your song track before consuming. That way you can always return to the original if your change: do not work out as expected. See "Saving your song to disk" on page 57 for details.

a) Select the track(a) you wish to modify.

b) Select the range (From and To) for the edit operation:

c) Enter what should be changed and bow it should be changed. Press the desired field and use the [TEMPO/DATA] dial, the [DATA] butlon/humeric Entry pad, or (for notes) the keyboard.

d) Confirm the operation by pressing the [EXECUTE] field.

Available options for 'Note'

For some functions, there is a *Note* parameter (called *Data Type*) with the following options. Be sure to press the correct option field one so as to achieve the desired result:

Only the selected note (note name/note number) will be affected.

Only notes above the selected one will be affected (in this case "From Note" changes to *Than Note*).

Only the notes between the [From Note] and [To Note] will be affected.

Only notes below the selected one will be affected (in this case "From Note" changes to *Than Note*).

Specify the note by pressing the [From Note] field and by playing it on the keyboard or selecting it with the [TEMPOYDATA] dual You can also tak that [DATA] button/Number Entry had You present; there is also a [To Note] tight that allows you to set the upper limit of the desired range.

Note if you safer "Prom Note" and "To Note" by pressing the desired to you the desired range.

Erase

Erase allows you to selectively delete data either within a specified range of measures, beats or clocks, or from the entire track(s). When *Data Type* is set to All, Erase substitutes the required number of rests for the data you delete, so that you end up with the equivalent number of blank measures. If you also want to eliminate the measures themselves, use Delete (see below).

Track (1~16, ALL, M)— Allows you to select the track you wish to edit. You can also select "All" here, in which case the operation applies to all tracks except the Master track (M). The M track can only be selected in isolation.

From/To— "From" refers to the position where the edit operation is to begin. That position is specified as Bar-Beat-CPT values. "To" designates the position where the edit operation is to end (Bar-Beat-CPT value).

Bar (1~9999)— This is where you specify the bar position. By default, the "From" and "To" values are set to the beginning and end of the selected track(s). At first, the "To" value always refers to the end of the longest track.

Beat (1~[number of beats per bar])— This is where you specify the beat position. The number of selectable beats obviously depends on the time signature of the song.

CPT— This is where you specify the CPT position of the beginning and end. CPT is short for "Clock Pulse Time", the smallest step unit used by the VA-76. (There are 120 CPTs to every beat of a bar.) Change this setting only if your edit operation should not commence or end exactly on the selected beat.



Data Type

Allows you to select the data to be erased:

Allº: All editable parameters listed below.

Note: Only note messages.

Modul: Only modulation messages (CC01).

PBend: Pitch Bend data (i.e. use of the BENDER/

MODULATION lever).

Volume: Volume (CC07) data.

Expre: Only Expression messages (CC11).

PanPt: Only pan (or PanPot) messages (CC10).

Reverb: Only Reverb Send messages (CC91).

Chorus: Only Chorus Send messages (CC93).

Delay: Only Delay Send messages.

CC16: M-Value 1 slider messages for the M-FX.

CC17: M-Value 2 slider messages for the M-FX.

Note: In the case of the VariPhrase track (13), CC16 is used for controlling the Pitch and CC17 for Time. See also

page 49.

CC18: Only available if you recorded a VariPhrase part on track 13. It allows you to change the

Formant.

PChng: Program change messages.

NRPN: Non-registered-parameter-number parameters. These are parameter control functions of the GS format that are easier to use than SysEx messages (but have basically the same function).

RPN: Registered-parameter-number parameters.
They work the same as NRPN messages,
except that they are also understood by GM
and GM2-compatible sound modules.

CAF: Channel Aftertouch messages. If you don't really need them, these messages should definitely be erased because they use a lot of memory.

SysEx°: MIDI messages that allow you to change parameter values. For music tracks, these messages cannot be programmed on the VA-76, but songs recorded on other devices may contain them. In the case of the M track, only SysEx messages (for Reverb, Chorus, and Delay setup, etc.) located after 1-1-0 can be erased

Tempo^o: Tempo change messages. The initial tempo value (located at 1-1-0 of the song) cannot be erased. You can change it with *Header Post Edit*, however (see page 161).

Note: Parameters marked with (°) can be selected for the M track. "Tempo" is only available for the M track.

From Note/Than Note (C-1~G9)— This parameter is only displayed if *Data Type* (see above) is set to "Note". It allows you to set the note (or lower limit of the note range) to be modified within the specified From/To time range. If you press [Higher] or [Lower], it is called "Than Note".

To Note (C-1~G9)— This parameter allows you to select the upper limit of the note range you wish to edit. It is only displayed if the [Between] field is displayed in white. See also "Available options for 'Note'" on page 148.

Execute—Press this field to confirm your settings and edit the data.

Delete

Unlike the Erase function, *Delete* not only erases the data but also the measures, so that all measures that lie behind the To position, will be shifted towards the beginning of the track(s). Since Delete also disposes of the *measures* themselves (see the illustration), you cannot choose the data type to be erased.



Track (1~16, ALL, M)— Allows you to select the track you wish to edit. You can also select "ALL" here, in which case the operation applies to all tracks.

From/To, Bar, Beat, CPT-See page 148.

Execute— Press this field to confirm your settings and edit the data.

Note: Not all settings of the M track are erased: the time signature, the GM/GS Reset message, and the initial tempo (all located at 1.1.0) remain. Lyrics events are only deleted if you selected ALL rather than the M track.

Insert



Insert allows you to make an existing track longer by adding rests at the specified position. This will make room for new data and shift data that lie behind the From position further to the right. New data can either be added in realtime (do select the Merge mode, see page 142) or by copying them to the specified position (see page 153).

Note: The Insert function does not provide a To pointer.
Instead, you have to specify the length of the insert using the
For value. "For 2 Bars, 2 Beats, 240 CPT" thus means
"insert 2 bars, 2 beats and 2 beats" (because 120CPT=]).

Track (1~16, ALL, M)— Allows you to select the track you wish to edit. You can also select "ALL" here, in which case the operation applies to all tracks.

From/For— The From level allows you to specify the position where the selected number of bars, beats, and clocks is to be inserted.

For, on the other hand, specifies how many bars, beats, and CPTs are to be inserted.

Bar, Beat, CPT-See page 148.

Time Signature— If *Track*= ALL, you can use these fields to set the time signature of the new measures (1/2~32/16).

Execute— Press this field to confirm your settings and edit the data.

Transpose



Transpose is used to transpose the notes of the selected track (the other non-note data obviously cannot be transposed).

From/To & Bar, Beat, CPT-See page 148.

Track (1~16, ALL)— Allows you to select the track you wish to transpose. You can also select "ALL" here, in which case the operation applies to all tracks except track 10 (Drum track) and any other track that uses a Drum Set. Drum tracks can, however, be selected individually. The M track obviously cannot be transposed. When used with the [Equal] option, Transpose is also useful for drum tracks. It allows you to select another snare or kick sound, for example. Most Drum Sets provide at least two snares, one assigned to note number 38 (D2), and a second assigned to note number 40 (E2). By selecting From Note= 38, pressing the [Equal] field and selecting "+2", you can change your D2 snare to the E2 snare.

Value (-24~+24)— This is where you can set the transposition interval in semi-tone steps. If you wish to transpose a C part to D, enter the Value +2.

Note: Be careful when applying Transpose to a Drum track (track 10 or any other track that uses a Drum Set). Transposing all notes of such a track would mean that the drum part changes dramatically.

From Note/To Note (0 C-1~127 G9)— See "Available options for 'Note" on page 148 as well as page 149.

Execute— Press this field to confirm your settings and edit the data.

Velocity



The Velocity function allows you to modify the dynamics (called *velocity*) of a track or excerpt. Increasing the velocity values means that the notes in question will be louder and brighter than before, while reducing the velocity values means the opposite. Use this function when you are happy with the timing of the notes but would like the sound to be brighter/louder or rounder/softer. Executing this function means that the velocity values will change proportionally:



From/To— "From" refers to the position where the edit operation is to begin. That position is specified as Bar-Beat-CPT values. "To" designates the position where the edit operation is to end (Bar-Beat-CPT value).

Bar, Beat, CPT-See page 148.

Track (1~16, All)— Allows you to select the track you wish to edit. You can also select "ALL" here, in which case the operation applies to all tracks.

From Note/To Note (0 C-1~127 G9)— See "Available options for 'Note'" on page 148 as well as page 149.

Value (-126~+126)— The Value parameter allows you to set the velocity change level. Select a positive value to increase the velocity of the selected track(s), or a negative value to decrease the velocity values.

This parameter can be particularly useful for velocity switched sounds: slightly reducing or increasing the overall velocity, allows you to "shift" all notes to the "other" sound.

Note: Even the highest positive or negative Value doesn't allow you to go beyond "1" or "127". There is a reason why "0" is impossible: that value is used to indicate the end of a note (note-off). "127", on the other hand, is the highest velocity value the MIDI standard can muster. Selecting a high positive velocity value may thus lead to all notes being played at "127", which may be what you had in mind in the first place...

Note: A similar system is also available for other parameters. See "Change" on page 152.

Quantize



Use this function if you chose not to quantize your music during recording (see page 142) and now realize that the timing is not quite what you expected it to be. Quantizing after recording has the advantage that you can first listen to the original and then correct only those notes whose timing is definitely off.

Track— See page 149 for an explanation of this parameter.

From, To, Bar, Beat, CPT, Execute—See page 148 for an explanation of these parameters.

From Note/To Note (0 C-1~127 G9)—See "Available options for 'Note'" on page 148 as well as page 149.

Value—This parameter sets the resolution of the Quantize function. The available values are: 1/8, 1/8t, 1/16, 1/16t, 1/32, 1/32t, 1/64t. Be sure to always select the value that equals the shortest note you recorded. Otherwise, your part no longer sounds the way you played it.

Gate T



The Gate T. function allows you to modify the duration of the notes in the selected time (From/To) range. We recommend you only use this function to shorten notes that seem too long due to the Tone you assigned to the track in question. There is indeed no way to view the duration of the notes here, which makes editing the data "en bloc" a little bit hazardous.

After selecting a Tone with a slow release (i.e. a sound that lingers on after all notes have been released), however, Gate Time will help you cut the notes down to size and thus avoid overlaps. Even though your

release timing may have been correct for the original Tone, you could use Gate Time to shorten all notes to such a degree that they no longer overlap.

Track-See page 149.

From, To, Bar, Beat, CPT-See page 148.

From Note/To Note (0 C-1~127 G9)—See "Available options for 'Note'" on page 148 as well as page 149.

Value (-1920~+1920)— This parameter sets the amount by which the duration (or gate time) of the selected notes is to be changed. The shortest possible Gate Time value is "1" (used for all drum notes), so that selecting "-1000" for notes with a Gate Time value of "1" in the specified time range still leaves you with the same value. Allowing the value "0" would effectively erase the notes, which can only be achieved with Erase (see page 148). You cannot use Gate Time to erase notes.

Execute— Press this field to confirm your settings and edit the data.

Shift



Shift allows you to shift the notes within the selected From/To range. It can be used for two things:

1. To correct "slow" notes due to a slow(er) attack. You may want to use Shift after assigning a Tone to a track that has a considerably slower attack than the Tone you used for recording the part in question. This technique is frequently used in pop music to "time" 1/16-note string arpeggios played with a "slow" pad sound. Rather than have the notes begin at the mathematically correct time (e.g. 2-1-0), you could shift them to the left (e.g. to 1-4-110) of the previous measure, so that the peak volume of the attack is reached on the next downbeat:



2. To correct the timing of notes recorded via MIDI without quantizing them.

You could use sequences, etc. as raw material for your songs. Recording such excerpts via MIDI may cause a slight delay (e.g. 5 CPT). If that is not acceptable, use Shift to "push" all notes to the left (select "-5"). That

allows you to tidy up the timing and still keep any irregularities (music!) the original may contain because it was not quantized.

Track—See page 149. You can also select the M track to shift tempo changes and SysEx messages. The initial settings (located at 1.1.0), however, cannot be shifted.

From, To, Bar, Beat, CPT-See page 148.

From Note/To Note (0 C-1~127 G9)— See "Available options for 'Note'" on page 148 as well as page 149.

Value (-1920~+1920)— This parameter sets the amount by which the notes are shifted. The Value refers to CPT units (one CPT= 1/120 \(\d \)).


Note: Notes on the first beat of the first bar cannot be shifted further to the left (that would mean shifting them to the "0" measure, which doesn't exist).

Execute—Press this field to confirm your settings and edit the data.

Utility: other useful functions

The 16-track sequencer also provides a few practical functions that help you save time. Here is how to select them:

- 1. Load the song you wish to edit (if it does not yet reside in the VA-76's Song RAM memory).
 See page 31.
- 2. Press the [SONG COMPOSER] button.
- 3. Press the [16 Tracks Sequencer] field.
- 4. Press the [Utility] field in the bottom row.



Change



This is a function that allows you to make quick changes to certain settings. The selected change always applies to entire tracks (you cannot use *Change* for changing just a few measures). Designed to help you prepare a Standard MIDI File in such a way as to achieve quick and perfect results with the Style Converter (see page 155), it is also a wonderful tool for the following applications:

- for "upgrading" older Standard MIDI Files to take advantage of the VA-76 new Tones.
- for global changes to the Reverb and/or Chorus Send values, which is downright convenient if you programmed realtime changes (see "Mixer: Changing the volume, adding effects" on page 147) and suddenly notice that the effect is too prominent or not strong enough.

Track (1~16, All)— Allows you to select the track whose data you wish to change. Though you can also select ALL, this should be done with great caution.

If you look carefully at the layout in the center of the display, you will notice that there are two kinds of changes that can be applied:

From/To (0~127, ALL)— Enter the original data value (i.e. the value that is being used right now by the selected track(s)) in the *From* column. For *To*, specify the new value that should *replace* the *From* value. This is what we call "absolute" changes: you don't add or subtract a value, you replace it with another.

Inc/Dec—These are so-called "relative" changes: the positive or negative value you set here will be added to or subtracted from the original values of the selected tracks. This works exactly like "Velocity" on page 150, except that it applies to other parameters. Use these fields to globally increase or decrease the existing values.

[Init Value]—Press this field to reset all values on this page to their initial state if you want to start again.

CC00— This control change is the so-called "MSB" Bank Select message. It allows you to select the Capital Tone (select "0") of a group/bank/number (A11~B88) address if you don't want to use Variations, or to specify another Variation level. The *To* value "0" can be useful for ensuring GM compatibility, which (unlike GM2) does not support Tone Variations.

In the Tone lists starting on page 222, you will see that most Tones are Variations. The value "8" for CC00 is probably the most popular one (as you would discover if you spent your time studying the list of 3,646 Tones). Here are a few examples:

GBN	Var	PC		Name	GBN	Var	PC		Name
A11	Tui	;	7	Piano 1	A12	rui	2	11/10	Piano 2
A11	1	;					2		
	•	1		UprightPiano	A12	1	_		Pop Piano
A11	2	1		Mild Piano	A12	2	2		Rock Piano
A11	3	1		Piano 1w	A12	3	2		Piano 2w
A11	4	1		Mild Piano w	A12	4	2		Rock Piano w
A11	5	1		European Pf	A12	5	2	116	Dance Piano
A11	6	1		Piano + Str.	A12	6	2		Piano 2
A11	7	1		Piano + Str2	A12	7	2	111	Acou Piano2
A11	8	1	26	Piano+Choir1				#福州(100)	
A11	9	1		Piano+Choir2					
A11	10	1	45	MonoAc.Piano					
A11	11	1	46	St.AcPiano 2					
A11	12	1	17	St.AcPiano 1					
A11	13	1	126	Piano 2					
A11	14	1	17	Acou Piano 1					

To change any value for CC00 to "8", for example, enter "ALL" for From and "8" (which corresponds to Piano 1w/Piano 2w) for To. To change all instances of the CC00 value "8" to another value (e.g. "16"), enter "8" for From and "16" for To.

Note: Most Song Composer/16-track Sequencer tracks usually only contain one CC00 value.

CC32— This control change is the so-called "LSB" Bank Select message. Most instruments (including your VA-76) use it for specifying different Tone Maps. You may want to use this parameter for changing a

Standard MIDI File in such a way that all tracks use the new Tones. To do so, select "ALL" for *From* and "4" for *To*. See also page 41.

PC (Program Change)— Use this parameter to change the group/bank/number address of a Tone (e.g. from "1" to "2").

Volume, Expression, Reverb, Chorus (-127~ +127)— These parameters allow you to add (+) or subtract (-) a given value to/from the current Volume, Expression, Reverb Send or Chorus Send values. This may come in handy if the realtime changes you recorded (see page 147) turn out to be too high or too low.

Execute— Press this field to confirm your settings and edit the data.

Note: Similar functions are also available for Standard MIDI Files on disk. Though they have the advantage that they are not permanent (and can thus be restored), they are only understood by the VA-76, the VA-7, the VA-5, the VA-3, the G-1000, and the EM-2000. See "Header Post Edit" on page 161.

Copy

The Copy function allows you to copy one track to another track, or excerpts of one or all tracks to a different location. The latter is useful if you need to repeat the chorus several times at the end of the song but do not feel like recording all those notes.



Source Track (1~16, All)— Allows you to select the track whose data you wish to copy.

From/To— "From" refers to the position where the edit operation is to begin. That position is specified as Bar-Beat-CPT values. "To" designates the position where the edit operation is to end (Bar-Beat-CPT value).

Bar (1~9999)— This is where you specify the bar position. By default, the "From" and "To" values are set to the beginning and end of the selected track(s). At first, the "To" value always refers to the end of the longest track.

Beat (1~[number of beats per bar])— This is where you specify the beat position. The number of selectable beats obviously depends on the time signature of the song.

CPT— This is where you specify the CPT position of the beginning and end of the track to be copied. Unless you do not need all notes within the last bar, you should keep the default setting.

Mode (Replace, Merge) - Selects the Copy mode:

Replace: The data in the selected range will be copied to the destination track and overwrite all data (of the destination track) in the selected source track range.

Merge: The data in the selected range will be added to any existing data on the destination track.

In either case, the length of the destination track may change to include all data of the source track. In other words, you may find that the destination track is longer after executing the copy function.

Note: The VA-76 has no Undo function. Saving your song to disk before copying will allow you to load the previous version if something goes wrong.

Destination Track— This is where you select the track to which you want to copy the selected data.

Into— The bar, beat and CPT values the first data of the source track will be copied to.

Times (1~99)— Sets the number of copies you wish to make. The value "3" means that you will end up with 3 contiguous copies, whereby the second copy is placed immediately after the first, etc.

Execute— Press this field to confirm your settings and edit the data.

Note: Though you can also copy data from track 10 (the main Drum track) to a "music" track, and vice versa, be careful. A drum track sounds odd when played by a piano, for example (and a piano part is not necessarily suited for drumming).

Exchange

Exchange allows you to copy the data of the source track (above) to the destination track (below), and -at the same time- the data from the destination track to the source track.




Track (1~16)— This is where you select the two tracks to be exchanged. Obviously, there is no ALL option here.

Note: Be careful when exchanging a Drum track and a "musical" track. The result may not be what you had in mind.

Name

This page allows you to program the File Name for your song. The "File Name" is the one that you see if you use the *dir* command on an MS-DOS® computer (all VA-76 disks are MS-DOS® compatible), while the "Song Name" is the name that you will see on the respective display pages. The File Name is more important than the Song Name because the File Name is the one that is written to disk – but it can only be 8 characters in length.



See page 68 for how to enter names.

Note: For MS-DOS® compatibility reasons, only the first eight characters will be saved to disk (it's impossible to enter more than 8 characters for the File Name). Furthermore, you cannot use the same name twice on the same disk.

Save— Press this field to jump to the *Save Song* page, where you can save your Song to the desired disk (see page 67). This function is very convenient for saving your new version under a different File Name without overwriting the original. That would leave you with two similar versions on disk. If you like your new version better (and wish to discard the previous version), do not change the existing File Name.

Note: If the original was referenced by a User Program and if you now wish to use the new version (saved under a different File Name), do not forget to change the Song Link setting (see page 130).

Initialize

See page 145.

(1.3KStyle converee

The VA-76's Style Converter is an easy and intuitive tool for creating your own Music Styles based on one of your own songs or a Standard MIDI File. In either case, it is enough to play back the song or Standard MIDI File once to transfer its data into the VA-76's Song RAM memory where you can use the Style Converter. You may want to edit the song before converting parts of it into a Music Style. See "In-depth editing of a 16-track song" on page 148 and "Change" on page 152 for details.

General considerations

Here are a few guidelines for converting song parts to a User Style:

- See "Concept" on page 163 and "Looped vs one-shot" on page 164 for details about User Styles.
- The resulting Music Style can be used in Arranger mode (not in Song Composer/16-track Sequencer mode).
- Music Styles are accompaniment patterns. If the new Style should be generally usable (i.e., also for other songs), try to avoid chord changes in the "basic" patterns (Original, Variation, etc.). You can transpose your Styles in realtime by playing different chords in the chord recognition area. Also, avoid to include the melody in your conversion.
- Try to isolate the parts that are really typical of the
- Transitions, rolls, etc., should be converted to Fill-Ins.
 The intro should be converted to an Intro pattern.
- For a really professional result, you will also have to take advantage of the VA-76's User Style mode to ensure that your new Style also "works" for minor and seventh chords. See "Programming User Styles" on page 163.
- Though pattern length (and memory capacity) is no issue, try to work in small but meaningful units.
 Here's an example: most songs rely on a structure based on 4-measure blocks. Converting 6 measures is thus a bit odd (though perfectly possible).
- Be sure to prepare a simple pattern for Original/Basic (Orchestrator ②) and more complex accompaniments for the remaining patterns.
- Be sure to set the right Key (see page 156). Only then will the Style really work as expected when used in the VA-76's Arranger mode.

- Your new Style resides in the VA-76 Style RAM memory (Disk User). Do not forget to save it to disk before selecting another Style (in Arranger mode) or switching off the VA-76.
- Commercially available Standard MIDI Files are protected by a copyright. Please note that the Style Converter should only be used for creating Music Styles for private use. Roland assumes no responsibility for copyright infringements that may result from the use of the Style Converter.

Using the Style Converter

- 1. If necessary, start playback of a Standard MIDI File to load the data into the VA-76's Song RAM. See "Listening to Standard MIDI Files" on page 31 for details.
- 2. Press the [SONG COMPOSER] button.
- 3. Press the [16 Tracks Sequencer] field.
- 4. Press the [Style Cnvrter] field in the bottom row. If [Setup] is not displayed in white, press this field.



This page allows you to assign the desired song tracks to User Style tracks. Remember that a song can contain up to 16 tracks, while a User Style "only" provides eight. Be sure to select the tracks you want to include in the resulting accompaniment.

Use the numbered Track fields (1~8) to assign a song track to User Style tracks (ADrums, ABass, Acc1~Acc6). You can press [Init Value] to load the default assignments (see the above illustration).

Please note that these defaults are only based on common sense and may not yield the desired accompaniment pattern. As a rule, you should always listen carefully. But you may have noticed that track 4 (the melody) is automatically omitted. You should keep it that way.


Note: Be sure to make all desired assignments before pressing the [From] or [To] field. There, you can indeed only work with the assigned tracks.

5. Press the [From] field to go to the next page,



Here, you can listen to the song you wish to convert. Press the [PLAY \blacktriangleright] field to start playback.

[◀◀ BWD] and [FFW ▶▶] are also available. The [ON/OFF] fields denote the tracks that contain data. Press an [ON] field to switch off ("mute") a track you do not want to hear. This is only for checking purposes. The on/off status does not influence the selection of the data that will be converted.



You also need to specify which measures should be converted. Here, you can only select whole measures.

A:/B:— Use these fields to specify the first (A:) and last (B:) measures to be converted. If you don't remember the measure numbers, here is a convenient way to set these positions:


Use [◀◀ BWD] to rewind to a measure that lies before the presumed beginning. Press [PLAY ▶] to start playback.

Press the [Mark A] field at the beginning of first measure to be converted and [Mark B] when the VA-76 reaches the last measure to be converted. Alternatively, you can stop playback, use [◀◀ BWD] and [FFW ▶▶] to rewind/fast forward to the desired measures, and set the points while the sequencer is stopped.

Playback loop Press this field to listen to the selected excerpt repeatedly. The passage between the "A:" and "B:" points will be continuously played back

(looped). This allows you to check whether the last notes of your Style-to-be allow for a smooth transition to other Music Style patterns, or sound natural when the pattern is repeated. Sometimes, quantizing the last few notes of an excerpt may be helpful to avoid including notes that were played a little ahead of the beat (and are part of the last beat you convert). See page 151 for details.

6. Press the [To] field to go to the next page.



Here, you can select the destination pattern, i.e. whether the selected excerpt should become a Basic/ Original pattern, an Intro, etc. Note that you cannot select tracks here. Go back to a previous page to do so.

Key— (C, C#, D, Eb, F, F#, G, Ab, A, Bb, B) This parameter allows you to tell your VA-76 what key the track (or tracks) is in. Specifying the right key before converting is crucial for realtime use of a pattern. The chord recognition system of the Arranger is indeed based on the assumption that all patterns are in the key of C.

Thus, whenever you play a C (in Arranger Intelligent mode) or C chord in the chord recognition area, the Arranger will use the original notes of the pattern (no realtime transposition). If that pattern is in F# and if you forget to tell the VA-76 that it is, F# is what you will hear when you play a C or C chord in Arranger mode.

Note: There is no need to specify the key for ADR tracks.

Mode—Allows you to select the mode of your pattern: "M" (major), "m" (minor) or "7" (seventh).

Choose the mode that matches the chord being used in the excerpt.

Type— Allows you to select the pattern Type. See page 95 for details.

Division—Allows you to select the Division of the pattern: Or (Original) or Var (Variation), FO (Fill-In To Original), FV (Fill-In To Variation), In (Intro), or Ed (Ending). Furthermore, by selecting an option indicated by "=", you create several patterns at once. That is what we call "cloning", see also page 166.

Execute— After setting the above parameters, press Part Select [UPPER1] to launch the conversion. As you see in the right-most field, your User Style will be temporarily stored in the VA-76's Style RAM memory (D88).

The new User Style will be copied to the Disk User memory. If that memory doesn't yet contain data, the new Style will use the current time signature and tempo. If you like, you can set the default tempo in the field next to [Key]. If the Disk User memory already contains data, the new Division(s) will have the same time signature and tempo as the Style data in the Disk User memory.

Execute— Press this field to start the conversion.

Note: Do not forget to save your new User Style to floppy or Zip disk.

14.4 Edit Lyries

The VA-76 contains a group of functions that allow you to add Lyrics to a Standard MIDI File that does not contain them. It is also possible to edit the Lyrics data of Standard MIDI Files that conform to the Tune 1000 format (other formats cannot be edited on the VA-76).

This may come in handy when you keep forgetting the words of a song you wish to use for your performances and want them to be included in the SMF file.

Note: The VA-76 only allows you to link ("synchronize")

Lyrics data to the note messages of the loaded Standard

MIDI File. The text data proper must be entered on a Windows-compatible PC (or a Mac and saved as .TXT data for Windows).


Here's a step-by-step tour of how to add Lyrics data to a Standard MIDI File:

1. Prepare the text file with the lyrics you wish to associate with a given song.

Use a word processor program on your computer, taking care to type a return after every line or word you wish to synchronize separately. The synchronization function (see below) always works with entire lines of text (i.e. until the following return). In any case, no line should contain more than 28 characters.

Export the file as .TXT file and save it to a floppy or Zip disk.

- 2. Load the song you wish to add Lyrics to. See page 31.
- 3. Press the [SONG COMPOSER] button.



4. On the display page that appears now, press the [Lyrics] field.




The display now changes to:



5. Press the [Edit] field.

This is only possible while Song (or Arranger) play-back is stopped. So be sure to stop playback before pressing [Edit]. Otherwise a "CAN"T EXECUTE" error message is displayed.



Now, we're going to import the text file you created earlier:

6. Insert the Zip or floppy disk that contains the text file you wish to associate with the Standard MIDI File in the VA-76's Song RAM memory.

7. Press the [TXT Import] field.



- 8. Press the [FLOPPY] or [ZIP] field to indicate which drive contains the data with the text file to be imported.
- 9. If necessary, press the [Import] field.
- 10. Press the field that contains the name of the desired file.

If you don't see the desired file name, use $[\leftarrow][\rightarrow]$ to select another group of 8 files. (If you still can't find the desired file, it may not end in ".txt" or not be a text/ASCII file.)

11. Press the [EXECUTE] field to load the desired text file.

12. Press [←Back] to return to the Edit Lyrics page (see above).

Now you're all set for the synchronization work:

13. Press the [Lyrics Synchro] field.



This display page should contain the first line of the text you imported. (This function can also be used to correct the synchronization of Lyrics data contained in a Tune 1000-format SMF you loaded.)

If you like, you can now use the [PLAY ▶], [STOP ■ | ◄], [◀ ■ BWD], and [FFW ▶ ▶] fields to playback and navigate inside your song.

Here's what we're going to do: every line of the text we imported can be associated with a given quarter note of the song. We'll do this while the song is playing back, because that is faster and also more musical. Synchronizing text lines is a matter of pressing the [DATA] button on the beats where they should appear during normal playback of the Standard MIDI File. Every press of the [DATA] button will associate the text line below the arrows (\blacktriangleright \blacktriangleleft) with the quarter note where the button was pressed. The preceding line automatically scrolls above the (\blacktriangleright \blacktriangleleft) section, while the following line will appear below the arrows.

- 14. Press [STOP | ◀] twice to return to the beginning of the song or use [◀ ◀ BWD] or [FFW ▶ ▶] to jump to a measure that lies a little ahead of the place where the first line should be displayed during normal operation.
- 15. Press [REC ●] (LyricsSync).
- **16.** Press the [PLAY ▶] field.

Playback (and Lyric synchronization recording) start.

17. On the beat where the first text line should be displayed, press the [DATA] button (front panel).



18. Repeat this at the quarter note where the second line should be displayed.



- 19. Keep pressing [DATA] on all beats where the subsequent text lines should appear.
- 20. Press the [STOP | ◄] field when all Lyrics data have been synchronized.

The display now again looks more or less as follows.



If you made a mistake somewhere, you can return to that measure using [◀◀ BWD] and start anew from that position. In that case, you will have to keep synchronizing the remaining text until the end of the song.


21. Press the [Save] field and save your song with the synchronized lyrics to disk.

See page 67 for details on how to save your song.

Note: Do not forget to use the [Save] field to save your song along with the lyrics when you are done (see step (21)).

'Utility' functions for Edit Lyrics

There are three functions you may want to use for managing Lyrics files, or songs with associated lyrics. All of them can be accessed via the Edit Lyrics menu:




(See page 157 for how to get there.)

Deleting a text file on disk

This function allows you to delete a text file (ending in ".txt") of the selected Zip or Floppy disk.

1. Go to the TXT Import page.



See page 158.

- 2. Select the drive and the file to be deleted.
- 3. Press the [Delete] field.
- 4. Press the [EXECUTE] field.

Exporting the Lyrics data as text file

Here's what you need to do to export the Lyrics data contained in a Standard MIDI File as text data. This may be useful for editing or printing the lyrics using your computer.

Note: This only works if the Standard MIDI File in the VA-76's Song RAM memory contains lyrics data.

1. On the Edit Lyrics page, press the [TXT Export] field.



- 2. Press the [ZIP] or [FLOPPY] field, depending on where you would like to save the exported text file.
- 3. Press the [Name] field to name the text file. This is only necessary if you do not agree with the preset name (i.e. the one of the song in question). If you press [Name], the display now looks as follows:



See page 68 for how to enter the desired name.

4. Press the [EXECUTE] field to save the file to the selected disk.

Save without Lyrics

This function allows you to save the song in the VA-76's Song RAM to disk without the Lyrics data.

1. On the Edit Lyrics page, press the [Save without Lyrics] field.



2. Press the [YES] field to erase all Lyrics data still present in the VA-76's Song RAM. This takes you to the SAVE Song page where you can save the MIDI data without lyrics.

See page 67 for what to do next.

Press [NO] to return to the Edit Lyrics page without erasing the Lyrics.

fisheader for Edit


The Header Post Edit function allows you to modify certain playback parameters of the song that is currently in the VA-76's Song RAM memory. These modifications are either global or track-specific in nature and can be saved to disk along with the song data.

In a way, these settings are a "User Program" contained in the song itself.

These modifications are SysEx data that *alter* the actual Song Header data (without replacing them). And if we say "SysEx", we mean that only the VA-76, the VA-7, the VA-5, the VA-3, the G-1000, and the EM-2000 can read these data. To other SMF players, the song will still be the original SMF, i.e. they will ignore these newly added SysEx data.

1. On page 129, we told you that the VA-76 allows you to ignore certain User Program settings, in which case some of the settings below will not be used. Load the song you wish to edit (if it does not yet reside in the VA-76's Song RAM memory).

2. Press the [SONG COMPOSER] button.



3. Press the [Header Post Edit] field.



The first set of parameters, called **Global**, allows you to modify settings that apply to all 16 parts (or tracks) of the song.

4. Press a field to select the parameter you wish to set and enter the desired value with the [TEMPO/DATA] dial or the [DATA] button/Numeric Entry pad.

The asterisks (*) indicate all parameters whose values differ from the original Header settings.

The available parameters are:

Parameter	Range	Default setting	
Master Tune	415.3~466.2	Song setting	
Transpose	-12-+12 semitones	0	
Reverb Type	Song/UPr	Song	
Chorus Type	Song/UPr	Song	
Tempo	J= 20-250	Song setting	

- The Transpose parameter does not change the note numbers of Drum tracks (i.e. track 10 and any other track that uses a Drum Set rather than a Tone).
- The Reverb Type and Chorus Type parameters allow you to decide whether the song should use the Reverb and Chorus parameters (see also "Effects and Equalizer" on page 116) of the currently selected User Program, or those contained in the song data.
- Tempo is a relative parameter that modifies all tempo values of the song (including changes) by the same amount. Tempo changes are thus not ruined.
 [Reset]—Press this field to select the default values for the Global and Part parameters.

5. Use [↑][↓] to select a specific song part (1~16) whose parameters you want to change.



You can do this for all 16 song parts.

There is a reason why we chose to use the word *Part* rather than *track*: the following parameters indeed only affect the way in which the tracks will be played back (without changing the track data themselves).

6. Press a field to select the parameter you wish to set and enter the desired value with the [TEMPO/DATA] dial or the [DATA] button/Numeric Entry pad. Be careful to select the desired Song Part before edit-

Be careful to select the desired Song Part before editing these parameters (watch the name in the top left field).

Note: If a given control change message for which the VA-76 provides a parameter is not available, the display will indicate "---".

CC00, CC32— (0~127) These are Bank Select messages. CC00 allows you to select other Tone/Drum Set banks, while CC32 is used to choose the Tone level. See also "Selecting different Tone Maps" on page 41.

PChange— (1~128) These are program change messages that allow you to select another Tone or Drum Set. See page 222 for a list of the VA-76's Tones and Drum Sets.

Volume (07)— Control change messages (CC07) that allow you to modify the Part volume.

Panpot— Control change messages (CC10) that allow you to set the stereo position of the selected part. Values below "64" shift the part to the left, and values above "65" shift it to the right. "64" means "dead center"

Reverb—The Reverb Send level (CC91) of the part, i.e. how strongly it is processed by the Reverb effect.

Chorus— The Chorus Send level (CC93) of the part, i.e. how strongly it is processed by the Chorus effect.

Tone Edit— (Yes/No) Allows you to specify whether or not the Part in question should execute SysEx and NRPN (CC98 and 99) contained in its track. If you select "No", such changes no longer affect the Part. [Default setting: Yes.]

Octave— (-3~+3) Allows you to transpose a part up to three octaves up or down, which may be necessary after you assigned a flute Tone to a bass part (see "CC00, CC32" and "PChange" above). [Default setting: 0.]

Data Send— (All, Int, Mid) This parameter allows you to specify where the data of the selected Part should be transmitted to: to the MIDI OUT port (Mid), to the VA-76's tone generator (Int), or both (All). [Default setting: All.]

Mute— This is a MIDI data filter that allows you to specify which Part data should *not* be transmitted to the Data Send destination. Select *Note* if the part should no longer transmit note messages, Pitch Bend, Modulation, Sustain, and Aftertouch messages. This is the setting to choose for Minus-One performances. *All* means that the part no longer transmits any MIDI messages at all (not even Bank Select and program change messages, etc.). Select *Off* if the Part in question should transmit all MIDI data contained in the track it is assigned to. [Default setting: Off.]

7. Press [Save] to jump to the Disk/Song Save page, where you can save the song. See page 67 for details.

12. Programming User Styles

You can program your own accompaniments (*Styles*) on the VA-76. Styles you program do not reside in ROM, which is why we call them *User Styles*, or Styles created by a user (either you or someone else).

SPA Nacincine de La

There are three ways of creating new Styles:

- By converting portions of a Standard MIDI File into an accompaniment to be played by the Arranger (see page 155).
- By creating new accompaniments from scratch (see page 165).
- By editing existing Styles, which requires that you copy them and then alter the settings or notes you do not like (see page 172).

The third option is the fastest, because you only need to substitute those parts that, in one way or another, do not "work" for the song you want to play. Programming Styles from scratch is a lot faster than you may think because the VA-76 is equipped with a number of functions that allow you to cut down programming time to the absolute minimum.

Patterns

User Styles and internal Styles are short sequences or patterns (usually only four, sometimes eight measures long) you can select in realtime. That is precisely what we showed you in "Using the VA-76's Arranger" on page 25. If you have ever worked with a rhythm programmer (the BOSS DR-770, for example), the pattern concept may sound familiar. You program a pattern only once and then use it at several points in a song. In other words, one short musical phrase can go a long way.

Pattern-based accompaniments usually consist of the following elements:

- The basic *groove*, i.e. the rhythm that is the backbone of the song.
- Several alternatives for the basic groove that keep the accompaniment interesting and suggest some kind of "evolution" or "variation".
- Fill-Ins to announce the beginning of new parts.
- The beginning and ending of a song. As a rule, programming four to eight drum patterns for a three-minute song is enough. Just use them in the right order to make them suitable for your song, and you're ready to play. In fact, what is called a "song" on a drum machine, is called "Arranger" on the VA-76. Drum machine songs have to be programmed beforehand, while the Music Style patterns can be selected on the fly by pressing the appropriate buttons or using the Orchestrator/Morphing function.

The VA-76 allows you to program 36 different patterns per Style, some of which are selectable via dedicated buttons ([ORIGINAL], [VARIATION] or via the display, see "Orchestrator and Morphing" on page 62), or that are selected on the basis of the chords you play in the chord recognition area of the keyboard (major, minor, seventh).

Tracks


Unlike a drum machine, a Style not only contains the rhythm part (drums & percussion) but also a melodic accompaniment consisting of two to three musical parts, such as piano, guitar, bass, and strings. That is why the VA-76's divisions work with *tracks* – eight to be precise. See also "Arranger parts" on page 95.

The part-to-track assignment is fixed. You cannot assign the ADrums part to track 6, for example.

The reason why the ADrums part is assigned to track 1 and the ABass part to track 2 is that most programmers and recording artists start by laying down the rhythm section of a song.

There are exceptions to this rule, however, so feel free to start with any other part if that is easier for the Style you are programming.

Note: Though there are six Acc (or Accomp) parts, most Styles only contain two or three melodic accompaniment lines. In most cases, less means more, i.e. do not program six melodic accompaniments just because the VA-76 provides that facility; too many accompaniment lines tend to blur the arrangement. If you listen very carefully to a CD, you will discover (perhaps to your surprise) that it is not the number of instruments you use that makes a song sound "big" but rather the right notes at the right time.



Looped divisions— Looped divisions are accompaniments that are repeated for as long as you do not select another division or press [START/STOP] to stop Arranger playback. The VA-76 provides four programmable looped divisions with three variations each (levels ① and ③ of the Orchestrator function cannot be programmed). Let us agree to call the variations *modes*:

Distance		
Basic/Original	Major Minor Seventh	As the name implies, this is the simplest accompaniment.
Basic/Variation	Major Minor Seventh	Basic/Variation is an alternative for the Basic accompaniment.
Advanced/Original	Major Minor Seventh	An alternative for the Basic level. Usually contains more instruments but could also be another kind of accompaniment for a given style.
Advanced/Variation	Major Minor Seventh	Variation of the Advanced/Original accompaniment.

Looped divisions do not select other divisions when they are finished: they keep playing until you select another division by hand (or by foot with an optional FC-7). One-shot divisions— One-shot divisions are accompaniments that are only played once and then select a looped division or stop the Arranger.


(Condens)		
Intro (Basic or Advanced)	Major Minor Seventh	Introduction. Selects the Original division of the level you selected (Basic or Advanced).
Ending (Basic or Advanced)	Major Minor Seventh	Ending (or coda). As soon as the Ending is finished, the Arranger stops.
Fill-In To Original	Major Minor Seventh	A musical transition that selects the Original division of the currently active level.
Fill-In To Variation	Major Minor Seventh	A musical transition that selects the Variation division of the currently active level.

The type of division (looped or one-shot) affects the way in which the respective tracks are played back. The Arranger will insert the required number of rests for any one-shot track that is shorter than the longest one.

Any track of a looped pattern that is shorter than the longest track, however, will be repeated until the longest track is finished. In other words, a repetitive phrase of a looped division needs to be recorded only once because it will automatically be repeated until the longest track is finished, after which the entire division (including the "sub-loops") will be repeated. For instance, if the ADrums part is only four measures long, while the ABass line is eight measures in length, the ADrums part will be repeated once while the Arranger plays measures 5~8 of the bass line.


12.2 Recording User Styles from scratch

Note: The following sections also contain comments on what we are doing and possible options. If all you want to do is program a Style, just read everything that appears in bold. You can come back to the related explanations whenever there is something you do not understand.



Selecting the User Style Composer

1. Press the [FUNCTION MENU] button.



2. On the display page that appears now, press the [User Style Composer] field.

The display now looks more or less as follows:



Note: If the above parameters are not visible, press the [Options] field.

Clearing the Disk User memory (Delete)

The first thing we need to do is clear the VA-76's Style RAM memory. That memory is indeed also used when you select a Disk Link, or a Disk User Style. In other words: this memory will not be empty when you select the User Style Composer. On the other hand, this "RAM sharing" system also allows you to prepare the Style you want to edit in no time: all you need to do is select it while in Arranger mode, then activate the User Style Composer.

To record a new User Style, however, you must first clear the Style RAM memory:

- 3. Press the [Utility] field in the bottom row.
- 4. Press the [Delete] field in the left column.



5. Press the [EXECUTE] field to delete the Style that is currently in the Disk User memory.

Preparations

- 6. Press the [Rec] field in the bottom row to jump to the User Style Composer Master page.
- 7. If necessary, press the [Master] field to make the display look like in step (2).

Selecting the track, the Mode, the Type and the Division

To keep things easy, let's start with the drums of the Basic/Original pattern.

- 8. Press the [Track] field and use the [TEMPO/DATA] dial to select the track you wish to record.

 Select "ADrums". Now select a pattern. Start with the Basic/Original division (see the following steps):
- 9. Press the [Division] field and use the [TEMPO/DATA] dial to select "Original".

During Arranger playback (when you start using your User Style like a "regular" Style), the Basic and Advanced levels can be selected using the Orchestrator function. See page 62.

Working with clones

On this page, you can activate three clone functions that allow you to record one part and copy it to up to three divisions and three modes each. The "=" sign means that more than one pattern will be recorded.

10. Use the [Mode] field to select the mode(s), and the [Type] field to select the type(s).

Let us use the following display settings, which mean "record the Basic/Original/Major pattern and copy it to all looped divisions". Thus, by programming one pattern, you will obtain 3 $(M, m, 7) \times 2$ $(Bsc, Adv) \times 2$ (Or, Va) = 12 identical drum patterns!



Note: You can only clone five parts for one-shot divisions because there is no Original/Variation level for Intro, Ending, To Original, or To Variation: only Basic and Advanced levels (see the illustration on page 164).

Record mode

The [Merge] field allows you to select the recording mode.

Erase (if the [Merge] field is displayed in blue/gray)— Everything you record will replace the data on the selected track. This mode is automatically selected when you activate the Record function for a track that does not yet contain data. If you select a track that already contains data, the [Merge] field is automatically displayed in white but can be switched off so as to overwrite the previous version.


Merge (if the [Merge] field is displayed in white)— The music or data you are going to record will be added to the existing data of the selected track.

Specifying the key

If you want to use the accompaniment in a musically meaningful way (see "Remarks" on page 171), you have to tell the VA-76 what key you are recording in. That way, everything you play will be automatically transposed to C during Arranger playback, so that when you play a C (major, minor, or seventh) chord in the chord recognition area of the keyboard, you hear a C chord rather than an D chord.

The VA-76 allows you to play in the original (or your favorite) key of the song. But do set the *Key* parameter to the right value before recording.

11. Press the [Key] field and use the [TEMPO/DATA] dial to set the key.



If you want to play in F#, set this value to F#; to play in A, you must set this value to A, etc.

Note: There is no need to specify the key for the ADrums part since that part is never transposed.

Octave

The field next to [Key] allows you to transpose the keyboard in octave steps, which may be convenient for playing extremely high or low notes – or for using the special "noises" of the new "V" Tones.

12. If necessary, press the [Octave] field and use the [TEMPO/DATA] dial to transpose the keyboard up or down (-4~+4 octaves).

Quantize

Quantize is a function that corrects minor timing problems. See page 142 for details.

Quantize shifts the notes whose timing is not exactly right to the nearest "correct" unit.

Always select a resolution value that is fine enough to accept all note values you play, yet not finer than the shortest note. If the shortest notes of your accompaniment are 1/16th note triplets, set the Quantize value to 1/16t.

Here is how to set the Quantize function:

13. Press the [Quantize] field and use the [TEMPO/DATA] dial to specify the quantize value.

The preset value, 1/16, is OK for most situations. If you do not want quantize your music while recording, set this parameter to Off.

Off is a good choice here because you can also quantize the part after recording it (see page 180). If you quantize all parts, your User Style may sound too perfect. Remember that music is all about tiny imperfections, one of which is a somewhat "loose" timing.


Tone selection

Another important aspect is Tone selection because the address (Group, Bank, Number, Variation) of the Tones and Drum Set you select is recorded at the beginning of every division.

14. Press the [Tone] field in the left column.



We are about to program the drums using the ADrums part. This part works the same way as the MDR part, so we now have to select a *Drum Set* rather than a Tone. In the case of the ADrums part, the display therefore looks as follows:




Use the GROUP/BANK/NUMBER buttons to select a Drum Set for the ADrums part (or a Tone for another part).

It is a good idea to play a few notes on the keyboard to check whether the sounds of the selected Drum Set are suitable for the accompaniment you are going to record. Try other Drum Sets until you find the one that sounds "right".

Time signature

Before you start recording, you must specify the time signature of your accompaniment. Select 4/4 for 8- or 16-beat patterns, 3/4 for waltzes, 2/4 for polkas and 6/8 (or 4/4) for marches. Note that it is also possible to select 5/4, 7/4 etc. time signatures.

15. Press the [Time Signature] field in the left column.



If 4/4 is already selected, there is no need to change it. To specify another time signature, proceed as follows:

a) Select the pattern whose time signature you wish to change by pressing the corresponding field. In most cases, pressing the [ALL] field in the right column is the most sensible choice. That way, your change will apply to all User Style patterns. To do so, first press [ALL], then select any time signature field.

b) Use the [TEMPO/DATA] dial to enter the new time signature.


Note: You can also use this page for changing the time signature of already recorded patterns at a later stage (see page 168).

16. Confirm the (new) time signature by pressing the [EXECUTE] field.

Length: specifying the pattern length


User Styles are patterns, i.e. short musical phrases, some of which will be continuously repeated during Arranger playback. Every pattern must therefore have a set length. A 5-bar Intro, for instance, is no good for a song that has only four introductory bars. Setting the length *now* will help you avoid a lot of confusion once you start recording.

The reason why we suggest you specify the length now rather than cutting the pattern to size after recording it (using the same Length function) is that the Arranger tends to add blank bars at the end of a track, which is usually due to the fact that you stopped the recording a little late (i.e. after the last bar you played). This means that you actually "record" five measures instead of 4:



Furthermore, in User Style Record mode, all patterns are *looped*, so that the VA-76 keeps playing them back until you press the [START/STOP] button. A wrong number of measures (5 instead of 4, for example) is very likely to put you off, so do take the time to set the pattern length before you start recording.

17. Press the [Length] field. The display now looks like this:



It is perfectly possible to specify a different length value for each track and division. Remember, however, that the Basic and Advanced (Original and Variation) tracks are looped during "real-life" use, so that a 64CPT phrase will be repeated for as long as another track of the current division contains data.

Note: Even one-shot patterns are looped by the User Style Composer. That is not the case, however, during Arranger playback (i.e. everyday use of the Styles).

18. Press the [Division] field to select the group of divisions whose length you wish to set.

The other options on this page are [Shared], [ALL] and [Single]. [Shared] allows you to select all patterns that are being shared, i.e. patterns that have been –or will be–"cloned" during recording using the M=m=7, B=A etc. options (see page 165). [Single], on the other hand, allows you to treat all divisions as if they were independent patterns – and select only those whose length you wish to change after recording them. [ALL] allows you to select all currently displayed divisions. In most instances, this is the most convenient setting.

Cloning and edit functions and possible warnings (Shared)

When re-recording or editing just one pattern of a clone group, the following warning may be displayed:



It means that you are about to do something that will disrupt the uniformity of the patterns you have chosen to be identical (by cloning them).

Note that this page only appears if, after cloning several patterns, you decide to only redo or edit the M/Bsc/Or (or Or-M-Bsc) pattern, for example. Since the VA-76 "knows" which tracks are clones, it will warn you that you are about to record or edit a version without copying it to the "shared" patterns. For your reference, the names are displayed.

This should allow you to make up your mind whether to modify the selected pattern without changing the clones, or apply the changes to all clones (or shared patterns).

- Press [Single] to edit the selected pattern without changing the clones.
- Press [ALL] if the clones (or shared patterns) are to change according to the modifications of the pattern you are re-recording or editing.
- Press [ABORT] to leave this page without changing anything, or [EXIT] to leave the User Style Composer altogether.

Back to our accompaniment.

19. Start by selecting the Track whose length you wish to set (using the [Track] field and the [TEMPO/DATA] dial).

Rotating the dial fully clockwise will call up the ALL option. Select ALL to set the length for all User Style tracks (1~8).

20. Press the [Division] field and use the [TEMPO/DATA] dial to select "ALL" Divisions.

Note: Selecting "ALL" means that you can specify the length of all divisions that appear on this page.

To specify the length of only one pattern, press only the corresponding field. To specify the length of several patterns in one pass, press the field of every pattern whose length you wish to set.

21. Press the [BAR] field.

As you see the bar values are now surrounded by a box.

22. Use the [TEMPO/DATA] dial to specify the number of bars. Our pattern should be 4 measures long, so enter the value "4".

Note: You could also specify a CPT value by pressing the [CPT] field and using the [TEMPO/DATA] dial. That CPT value ($\rfloor = 120$ CPT) will be added to the Bar length. Though possible, length values like 4 (bars): 96 (CPT) are probably not what you want to use every day.

23. Press [EXECUTE] to confirm the length you specified

The display now contains an animated clock. Next, the "OK Function Complete" message is displayed to signal that the Length value has been successfully set.

24. Press the [Master] field in the upper left corner.

Tempo



25. The tempo (currently set to J=120) is probably a bit fast for recording, so change it by pressing the tempo field and using the [TEMPO/DATA] dial. The tempo value you set here will be recorded and regarded as preset tempo. You can change the preset tempo at any stage in User Style Composer mode, so start by selecting a tempo that allows you to record the music the way you want it to sound. When all tracks and divisions are programmed, you can record the desired tempo value.

Recording

26. Press the [REC ●] field so that it is displayed in white.

The display now looks as follows:



27. Press the [START/STOP] button. The metronome counts in one measure (4 beats if you selected the 4/4 time signature), and recording starts on the next downbeat.

Note: You can also start recording using an optional footswitch connected to the FOOT SWITCH jack. See "Start/ Stop" on page 191 for how to select the Arranger Start/Stop function.

You could start by playing only the bass drum part. If you specified the track length (see above) before recording, the Arranger jumps back to the beginning of the pattern after four measures. The second time

around you could add the snare drum, the third time the HiHat, and so on. – But you can also play the drum part in one go, of course.

When recording another part (ABass~Accomp6), do everything you would do during a live performance. Feel free to add modulation, Pitch Bend, and use the Ribbon or D Beam controller as well as the hold pedal connected to the SUSTAIN FOOTSWITCH jack. Note: You may notice a short delay before the Arranger jumps back to the beginning of the pattern. That delay is due to the fact that the data you record are "being processed". During playback, the loop will be perfect, however.

28. Press [START/STOP] again to stop recording. If the above Mode, Type, and Division settings you selected for recording do not include all the patterns you wanted to clone, set the Mode, Type, and Division parameters to the desired values to supply the missing drum lines. Next, press [REC ●] and [START/STOP] to start recording. Stop recording after the first or second beat (wait until the count-in is finished before you start counting). Note that this function only adds clones. It does not allow you to erase existing patterns.

Audition your pattern and then keep or redo?

1. Press the [START/STOP] button again to listen to your performance.

If you like your drum part, continue with "Saving your Style to disk". If not, you probably want to give it another try.

2. Press the [Edit] field in the bottom row, followed by [Erase] in the left column.



We'll use *Erase* to erase the data because that way, the Length settings do not change. See "Erase" on page 178 for more information about this function. The ADrums track is already selected, as is the pattern that is used for cloning other tracks.

- 3. Press [†] to select ALL Events for "Data Type".
- 4. Press the [EXECUTE] field to erase the pattern.
- 5. Press [Rec] in the bottom row to jump back to the Master page.
- 6. Continue with step (26) above.


Saving your Style to disk

If you are serious about programming your own Styles, make it a habit to save them as frequently as possible. After all, if someone decided to turn off your VA-76 now, you would lose everything you have programmed so far.

That disk can also serve as backup whenever you erase or change something you actually wanted to keep.

Naming your User Style

1. Press the [Utility] field in the bottom row and the [Name] field in the left column.



Before saving a Style to disk, you should name it. Choose a name that tells you something about the nature of the Style. The name you enter here will be displayed on the Master page every time you select this Style (via Disk Link, if assigned, or as "Disk User Style").

2. Enter the name that should be displayed whenever you select this Style. See page 68 for the available options.

Saving your Style

3. Press the [Save] field to jump to the Save Style page:



4. Press the [ZIP] or [FLOPPY] field to select the drive you wish to use for saving your User Style.

5. Press the [Name] field.



You have just specified the Style name, so there is no need to do so on this page.

6. Press the [File Name] field and enter the name under which your User Style should be saved.
See page 109 for the difference between Style and File Names.

Note: The [A/a] field is not displayed when you select the [File Name] field. That is because the File Name conforms to the MS-DOS standard and only allows for (eight) uppercase characters.

- 7. Insert a floppy or Zip disk into the desired drive and press [EXECUTE] to save your Style to disk. Remember that your VA-76 is multitasking, so that you can leave this page as soon as the VA-76 starts saving the Style to disk:
- 8. Press [←Back] to return to the User Style Composer.
- 9. Press [Rec] (below) and [Master] (left column) to the User Style *Master* page.

Programming other parts and divisions

You can now record the second part – probably the bass. If you'd like to do the guided tour again, go back to page 165. Do not forget to set the key for the bass part (see page 166).

You probably know how to record other parts (Accomp1~Accomp6), so we'll leave you to it (see "Recording User Styles from scratch" on page 165).

Once the first division is finished, you can record other divisions. Use the clone function (see page 166) to record several patterns in one go.

Do not forget to record the Fills and the Intro(s)/Ending(s) to complete your User Style.

Note: The ABass part is monophonic. You will not be able to program two-note patterns.

Muting parts while recording others

After programming a few tracks, you may find that certain tracks tend to confuse you. Playing a steady organ part while listening to a previously recorded syncopated part may indeed be difficult. That is why the VA-76 allows you to mute those parts that you do not want to hear during *recording*.

Note: The on/off status only applies to the User Style mode. In normal Arranger playback mode, all tracks will be played. In other words, this is a help function. To mute a part in Arranger mode, see page 114.

Here is how to mute tracks in User Style mode:

1. On the User Style *Master* page, press the [Play Trk] field:



2. Use the [ON/OFF] fields to switch the various User Style tracks On or Off (mute).

Note: Press the [Options] field if you need to set the Key, etc., parameter for a new track. You can also start recording on this page.

Speed Options— The [Fast] and [Slow] fields allow you to double or halve the playback tempo. The [Slow] option is useful for checking difficult riffs to find out whether all notes were played correctly. [Fast], on the other hand, allows for a quick check of the activated tracks. These options are only available once you have started playback of your of your User Style (by pressing the [START/STOP] button).

Remarks

Working from top to bottom – programming hints


If you listen carefully to the factory Styles, you will notice that most divisions are very similar to one another and that the element of "evolution" or "amplification" between the Original/Variation and Basic/Advanced levels is usually derived from adding instruments to otherwise identical parts. The Advanced/Original division may, for instance, add an electric guitar to the drums, bass, and organ lines of the Basic level, but the drum, bass, and organ lines of the Advanced level are usually identical to those of the Basic level.

In other words, start by recording the most complex accompaniment while cloning all other looped divisions (see page 165). If you then move to the Advanced/Original level and delete the bells and whistles (see page 178), that division is already simpler than "the works".

The next step would then be to select the Basic/Original pattern and delete both the bells and whistles and the distorted guitar.

Metronome and Count-In

In User Style mode, the metronome sounds during recording, unless you switch it off using the [ON/OFF] field. If you also need the metronome when listening to what you have just recorded, select another metronome mode. Press the [Mode] field (only visible when [Options] is displayed in white) and see page 66 for how to select another metronome mode.



Press [←Back] to return to the "regular" User Style pages.

Playback in Arranger mode

As stated on page 163, the Arranger of your VA-76 is very similar to a drum machine, except for one thing: you do not need to program the pattern sequence beforehand. Just select the division you need while playing and feed the Arranger with the right chords so that all the lines you programmed sound in the right key. In short: use your own Styles the way you use the internal Styles.

Note: If, during playback in Arranger mode (i.e. normal VA-76 mode), the Arranger stops unexpectedly, try different chord modes. Chances are that you only programmed the major division, so that the Arranger selects an empty pattern when you play a minor or seventh chord. Remember to always set the Mode parameter to M=m=7 until you have come to grips with the possibilities of the VA-76's Arranger. That way, those three patterns will sound alike, but at least you are sure that the Arranger does not stop when you play a minor or seventh chord.

123 Copying existing Ayles :

Another way of programming User Styles is to use parts from internal Styles in ROM or User Styles on (floppy, Zip) disk. The VA-76 allows you to:

- Copy entire Styles to the Style RAM memory (Disk User)
- · Copy the selected division of one or all tracks
- · Copy just a few notes of an existing part
- Copy tracks or notes between divisions
 This allows you to create new Styles by using tracks from different existing Styles (the drums of Style B34, the bass of Style A63, etc.).

Note: You cannot copy an ADrums track to another track (ABass-Accomp6). Likewise, the bass part can only be copied to an A.Bass track. As far as the ACC tracks are concerned, you are free to copy them to whichever ACC track you like.

Note: If the Style RAM memory already contains new data, save it to disk before copying. The VA-76 has no Undo function. Saving a Style to disk before copying will allow you to load the previous version in case something goes wrong. See "Saving your Style to disk" on page 170.

Copying entire Styles using Load (all tracks)

- 1. Press [EXIT] to return to the Master page.
- 2. Press the [FUNCTION MENU] button.
- 3. Press the [Disk] field to select the Disk mode.
- 4. If the [Load] field in the bottom row is not highlighted, press it.
- 5. Press the [Style] field.



6. Press the [INT A/B] field so that it is displayed in white.

INT A/B allows you to select any internal Music Style (A11~B88). If you wish to copy a Style from disk, press the [FLOPPY] or [ZIP] field.

The window displays a list of Styles in the internal memory (Int) or on the disk.

- 7. Use the [←][→] fields or the [TEMPO/DATA] dial to scroll through the list of available Styles.
- 8. Press the field of the Style you wish to copy.
- 9. Press [EXECUTE] to load the Style.
- 10. Press [←Back] to return to the Function Menu.

11. Press the [User Style Composer] field to return to the User Style Composer.

Note: Pressing [←Back] takes you back to the User Style Composer.

Note: This procedure is not really necessary because selecting a Disk Link or Disk User Style in the VA-76's Arranger mode has exactly the same effect as this function. Here, however, you know exactly what you're doing.

Copying individual Style tracks


While the previous function allows you to copy entire Styles, the Copy function can be used to copy individual tracks, modes, types, and divisions.

- 1. Press the [Utility] field in the bottom row while a User Style Composer page is displayed.
- 2. Press the [Copy] field in the left column.
- 3. Press the [Source] field.



- 4. Press the [Track] field and use the [TEMPO/DATA] dial to select the track to be copied.
- 5. Repeat this operation with the [Mode], [Type] and [Division] fields to select the Mode (Maj, Min, 7th, ALL), the Type (Bsc, Adv, ALL), and the Division (Or, Va, Fo, Fv, In, Ed, ALL).
- 6. Next, select the Style (internal banks A~C) that contains the track(s) to be copied:
- a) Press the [GBN/Style Name] field.
- **b)** Use the [TEMPO/DATA] dial or the BANK/NUM-BER pad to select the desired Style.

Note: Do not forget to insert the required disk before selecting a Style from bank C (Disk Link).



7. Press the [Listen] field to listen to the excerpt you are about to copy.

Note: Listen is not available when you select ALL for one of the above entries.

From

Start by specifying the position of the first event (or note) of the source track to be copied.

8. Press the [Bar], [Beat], or [CPT] field in the *From* row and use the [TEMPO/DATA] dial to set the Bar, Beat and CPT units respectively.

By default, the From parameters are set to "Bar 1, Beat 1, CPT 0".

You can also choose to copy only those notes that you need, in which case, the Beat and CPT parameters will help you select a starting point that lies behind the first beat of the track you wish to copy.

To


The *To* position indicates the end of the excerpt to be copied. By default, the To values are set to include the entire track.

9. Press the [Bar], [Beat], or [CPT] field and use the [TEMPO/DATA] dial to set the Bar, Beat and CPT units respectively.

If you wish to copy an entire bar, select the Bar-Beat-CPT "0" value of the next bar, i.e. to copy bars 1~4 specify "From 1-1-0/To 5-1-0".

10. Press [Listen] to listen to the excerpt again.

11. Press the [Destination] field.



Copy mode

Copying can be carried out in one of two modes:

Replace—The data in the selected range will be copied and overwrite all data of the destination track in the selected source track range.

Merge— The data in the selected range will be added to any existing data on the destination track.

In either case, the length of the destination track may change to include all data of the source track.

Note: If the Style RAM memory already contains new data, save it to disk before copying. The VA-76 has no Undo function. Saving a Style to disk before copying will allow you to load the previous version in case something goes wrong. See "Saving your Style to disk" on page 170.

- 12. Press the Mode [Replace] or [Merge] field.
- 13. Press the [Track] field and use the [TEMPO/DATA] dial to select the track you wish to copy the

Note: It is impossible to copy ADrums data to other tracks than ADrums tracks. Likewise, you cannot copy ABass data to other tracks than ABass tracks.

- 14. Repeat this operation with the [Mode], [Type] and [Division] fields to select the Mode (Maj, Min, 7th, ALL), the Type (Bsc, Adv, ALL), and the Division (Or, Va, Fo, Fv, In, Ed, ALL).
- 15. Press the [Listen] field to listen to the track you are about to copy to.

The Into position indicates the beginning of the excerpt you are about to copy. To copy the source data to the beginning of the selected track, select Bar= 1, Beat= 1, and CPT= 0.

- 16. Press the [Bar], [Beat], or [CPT] field and use the [TEMPO/DATA] dial to set the Bar, Beat and CPT units respectively.
- 17. Press the [Times] field and use the [TEMPO/DATA] dial or the [DATA] button/Numeric Entry pad to specify the number of copies to be made. Select "1" if the excerpt is to be copied only once.
- **18.** Press the [EXECUTE] field to copy the data. The animated clock tells you that the data are being copied.

When the data are copied, the display will tell you:



APACE THE UNDUSANS FIRS

Editing on the fly by recording

Adding notes in realtime

To add notes to an existing part, press the [Merge] field so that it is displayed in white, select the track, and start recording by pressing the [REC •] field and the [START/STOP] button. Play the notes where you want them to sound.

Note: Do not forget to select the desired Division, Mode, and Type (see page 165).

Adding controller data in realtime

To add controller data (modulation, Pitch Bend, Hold, expression) to an existing part, press the [Merge] field so that it is displayed in white. Operate the controller (Pitch Bend lever, modulation lever, optional DP-2, DP-6, or FS-5U footswitch for Hold data, optional EV-5 or BOSS FV-300L or EV-10 foot controller for expression data) where needed.

Note: Do not forget to select the right Division, Mode, and Type (see page 165).

Adding or changing settings of existing parts

The following operations require that you record in [Merge] mode without touching the keyboard or controllers, select the track and division whose settings you wish to change, press the [Merge] field, and start recording. Unless you wish to program continuous value changes (Panpot data, for example), you can stop recording after the first beat. Static settings are always written at the beginning of the track in question, so there is no need to record an entire cycle.

Tone/Drum Set selection— To select another Tone or Drum Set for an existing User Style track, proceed as follows:

1. Press the [Tone] field in the left column, and select the Track you wish to assign another Tone or Drum Set to.



2. Press the [Track] field and use the [TEMPO/DATA] dial to select the desired track.

If you select the ADrums track, the display looks slightly different:



That is because you can only assign Drum Sets to the ADrums track.

- 3. Select the division whose settings you wish to change, and possibly also all clones (see page 165).
- 4. Press the [MERGE] field in the bottom row. (Let us assume that your part already contains data.)
- 5. Select the new Tone (or Drum Set) to be assigned to the currently selected track and division by pressing the [Current Tone]/[Current Drum Set] field and using either the [TEMPO/DATA] dial or the BANK/ NUMBER buttons.
- 6. Press the [REC] field (see the circle in the above illustration) so that it is displayed in white.

 Depending on the selected track (ADrums or another one), this field is located in a different place. It does have the same function, though.
- 7. Press the [REC •] field.
- 8. Press [START/STOP] to start recording.
- 9. Press [START/STOP] again after the first or second beat (but wait until the one-bar count-in is finished). This completes Tone selection. The new Tone address (Group, Bank, Number, Variation) automatically replaces the old one.


Though you can use different Tones for every division of a User Style, beware of too much "artistic license". Using another Acc track for additional parts (if still available) will avoid a lot of confusion.

Drum Set Note & Pitch— After selecting the ADrums track, you can modify the pitch of certain sounds of the selected Drum Set. The eligible sounds and corresponding note numbers are:


 C#2/37 Side Stick	
 D2/38 Stand.2 Snare 1	
 E2/40 Stand 2. Snare 2	
 F2/41 Low Tom 2	
 E3/52 Chinese Cymbal	
 G#3/56 Cowbell	
 A3/57 Crash Cymbal 2	
 F4/65 High Timbale	

Note: The names of the drum/percussion sounds depend on the currently selected Drum Set. The sounds are usually similar in nature, however.

- 1. On the above display page, select the ADrums track.
- 2. Select the division whose settings you wish to change, and possibly also all clones (see page 165).
- 3. Press the [MERGE] field in the bottom row.
- 4. Press the [Drum Set Note] field and select the drum sound whose pitch you wish to change with the [TEMPO/DATA] dial.
- 5. Press the [Pitch] field and use the [TEMPO/DATA] dial to set the desired pitch (-64~+63). You can play on the keyboard to listen to the result.
- 6. Press the [REC] field below [Pitch].



- 7. Press the [REC ●] field.
- 8. Press [START/STOP] to start recording.
- 9. Press [START/STOP] again after the first or second beat (but wait until the one-bar count-in is finished). Expression, Panpot, Reverb, Chorus— Setting or modifying the Expression, Panpot, Reverb (Send), and Chorus (Send) parameters is similar to selecting another Tone for existing tracks.





The Reverb and Chorus settings represent *Send* values (see page 116). The effect settings (Type, Character, etc.) can only be saved to a User Program. In other words, a Music Style's character may change depending on the User Program you select.

You can create interesting panning effects by slowly shifting the selected track from left to right (or vice versa) in the course of a pattern. This is especially effective for synthesizer or guitar riffs. Continuous changes mean that you have to keep recording until the end of the pattern.

Expression (control change CC11) is a subsidiary volume message that works relative to the volume (control change CC07) message. Whenever you set Expression to "127" the resulting part volume will be equal to the value specified for Volume (CC07).

The Volume values of the Arranger parts can be set in Mixer (see page 112) mode.

Setting the preset tempo

The preset tempo is the tempo the Arranger selects in One Touch mode. By now, you know that the [TEMPO/DATA] dial and [AUTO/LOCK] function allow you to override the preset Style tempo and save the new tempo value to a User Program. Setting the right preset tempo is useful for those occasions where you wish to use One Touch Program (see page 29).

To program another preset tempo, set it using the [TEMPO/DATA] dial or the [TEMPO/TAP] button, select any part on a User Style Composer page where the [Rec] field in the bottom row is displayed in white, press the [Merge] field, and record one or two beats.


Do not play on the keyboard or use any controllers connected to the VA-76, though!

Note: The last tempo value you record automatically becomes the Style's preset tempo.

Edit functions that are not part of the User Style Edit mode

Length

Press the [Length] field in the left column



The Length function allows you to modify the length (number of bars, beats, and clocks) both before or after recording. If used after recording, the data that lie beyond the specified end will be discarded.

Note: There is no way to recall the previous version, so think twice before executing the Length function.

See also "Length: specifying the pattern length" on page 167.

Track (ADrums~Acc6, All)— Allows you to select the track whose length setting you wish to change. If the length does not have to be the same for all tracks (which goes unnoticed for looped divisions, see "Looped divisions" on page 164), try to use only integer multiples or fractions for longer or shorter tracks (i.e. 4 bars for one track, while the others are 8 bars in length; 3-bar patterns don't loop well over 4- or 8-bar tracks).

Single—Press this field if you want to select only one pattern of a clone group.

Shared—Press this field to select all shared patterns in one pass. Doing so ensures that clones are always identical to the original.

ALL— Use the [ALL] field to select all patterns on the current display page (i.e., all Original/Variation, Intro/Ending, or Fill-In To Original/To Variation patterns).


BAR— Press this field and use the [TEMPO/DATA] dial to set the length of the selected pattern(s) in steps of one bar. Note that it is perfectly possible to make an existing track longer by specifying a Bar value that lies beyond the last notes (or current end).

CPT—This is another length value that allows you to "fine tune" the length. In most cases, you will probably work with multiples of J notes (i.e. 120CPT) because 120CPT represent one beat of an X/4 bar (1/4, 2/4, 3/4, 4/4, etc.). All intermediary steps are selectable, though the musical functionality of "x-bars-and-a-bit" patterns is questionable, to say the least.

EXECUTE— Press this field to apply the new length value to all selected patterns on this page.

Time Signature

Press the [Time Signature] field in the left column



The Time Signature page allows you to check and set the time signature of certain or all patterns. The time signature of the major (M), minor (m), and seventh (7) patterns must always be the same. This security system helps you avoid switching to another time signature simply by playing a major, minor, or seventh chord in the chord recognition area of the keyboard.

Use this parameter to specify the time signature of the selected pattern (Division, see below). The most commonly used time signatures are: 2/4, 3/4, 4/4, 6/8, and 12/8. Other values (such as 7/4, 13/8, etc.) are also possible.

Note: When you change the time signature of an already recorded pattern, its notes and events are "reshuffled" according to the new time signature, so that you may end up with incomplete measures. However, none of your data are deleted.

Bsc/Adv— This field (rightmost column) allows you to link the selection of a pattern in the Bsc column (left) to the corresponding pattern(s) in the right column (Adv). This is especially useful after selecting multiple patterns.

Use the [TEMPO/DATA] dial to set the desired time signature.

[Single]/[ALL]—Press [Single] if you only wish to change the currently selected pattern. Press [ALL] to select all patterns. If you want to edit multiple patterns, first pressing [ALL] and then switching off the fields of the patterns you don't want to change may be faster than selecting all desired patterns one after the other.

Execute—Press this field to confirm the new time signature and resize the selected pattern(s).


THE PROPERTY OF THE PROPERTY O

All display pages of the User Style Edit mode feature a [←Back] field that allows you to jump back to the [Rec] page. Use it after editing a track (or all tracks) to record new material straight away.

Before discussing the various User Style Edit functions, please note the following: certain functions allow you to select the data type to be edited. Whenever that is the case, you can select one of the following messages. The field in question is called *Data Type*.

	Egiahetion Control of the Control of
Ali	All editable parameters listed below.
Note	Note messages
Modul	Modulation messages (CC01)
PanPt	Panpot messages (stereo position, CC10)
Expre	Expression messages (relative volume, CC11)
Revrb	Reverb Send messages (CC91)
Chrus	Chorus Send messages (CC93)
PChng	Program Change messages
PBend	The Pitch Bend range (i.e. the pitch change that can be obtained by turning the Bender lever fully to the left or right).
NRPN	Non-registered parameter number. A special kind of MIDI message for setting parameter values that is only understood by GS compatible instruments.

These functions are very similar to those of the 16-track Sequencer. If you know how to use those, you will have little trouble understanding how the User Style Edit functions work.



Note: See "Available options for 'Note'" on page 148 for an explanation of the [Equal], [Between], etc. fields.

Erase

[FUNCTION MENU] button ightarrow [User Style Composer] field ightarrow [Edit] field ightarrow [Erase]



Erase allows you to selectively delete data either within a specified range of the pattern(s), or from the entire track(s). In *Data Type* ALL mode, Erase will substitute the required number of rests for the data you delete, so that you end up with the equivalent number of blank measures. If you also want to eliminate the measures themselves, use Delete (see page 178).

Track (ADrums~Acc6, ALL)— Allows you to select the track you wish to edit. You can also select ALL here, in which case the operation applies to all tracks of the selected pattern.

Mode— Allows you to select the mode of the pattern to be edited: Maj (major), min (minor) or 7 (seventh).

Type— Allows you to select the pattern type to be edited: Basic or Advanced.

Division— This parameter is used to select the Division of the pattern: Original or Variation.

From/To— "From" refers to the position where the edit operation is to begin. That position can be specified in a Bar-Beat-CPT format. "To" designates the position where the edit operation is to end (Bar-Beat-CPT value).

Bar (1–9999)— This is where you specify the bar position. By default, the From and To values are set to the beginning and end of the selected track(s). Note that the To value always refers to the end of the longest track.

Beat (1~[number of beats per bar])— This is where you specify the beat position. The number of selectable beats obviously depends on the time signature of the selected pattern.

CPT— This is where you specify the CPT position of the beginning and end. Unless you do not need to edit all the selected data within the last bar, you should keep the default setting. Note that the Micro mode allows you to edit the data on an event basis, which is more precise because there you see the events to be edited, which is not the case here. If you only wish to edit one event (or message), you should definitely do so in the Microscope mode (see page 181).


Data Type— Use $[\uparrow] [\downarrow]$ to select the data to be edited. See the table above for a list of the available data types.

From Note/Than Note, To Note-See page 149.

Execute— Press this field to confirm your settings and edit the data.

Delete

[FUNCTION MENU] button o [User Style Composer] field o [Edit] field o [Delete]



Unlike to the Erase function, Delete also erases the measures, so that all measures that lie behind the "To" position, will be shifted towards the beginning of the track(s). Since Delete also disposes of the *measures*, you cannot choose the data type to be erased.

Track, Mode, Type, Division— See page 178 for details.

From/To— "From" refers to the position where the edit operation is to begin. That position is specified as Bar-Beat-CPT values. "To" designates the position where the edit operation is to end (Bar-Beat-CPT value).

Bar, Beat, CPT—See page 178 for details.

Note that the Micro mode allows you to edit the data on an event basis, which is more precise because there you see the events to be edited, which is not the case here. If you only wish to edit one event (or message), you should definitely do so in the Microscope mode (see page 181).

Insert

[FUNCTION MENU] button \rightarrow [User Style Composer] field \rightarrow [Edit] field \rightarrow Ilnsert!



The Insert function allows you to insert space in an existing pattern. This means that all data lying behind the position calculated by the "For" parameter are shifted further towards the end of the pattern, effectively making the pattern longer. You can only insert blank measures here.

Track, Mode, Type, Division—See page 178 for details.

From/For— "From" allows you to specify the position where the selected number of bars, beats, and CPT is to be inserted.

"For", on the other hand, specifies how many bars, beats, and CPTs are to be inserted.

The Microscope mode also provides an Insert function (see page 182) that allows you to add events without shifting the subsequent events towards the end.

Bar, Beat, CPT-See page 178 for details.

Execute— Press this field to confirm your settings and insert the requested number of bars, beats, and CPTs.

Transpose

[FUNCTION MENU] button \rightarrow [User Style Composer] field \rightarrow [Edit] field \rightarrow [Trnspose]



Transpose is used to change the pitch of the selected pattern (the other non-note data obviously cannot be transposed). Use this function with great caution because the Key value (see page 166) is not updated – even if you transpose entire track(s). We therefore suggest you only use it for parts of an Intro or Ending pattern – for example a difficult phrase you have recorded only once and then copied using Copy (see page 184).

In other words, never transpose an entire pattern as that will invariably lead to a lot of confusion in the Arranger mode.

Track, Mode, Type, Division— See page 178 for details.

When combined with "From Note/Than Note" and "To Note" (see below), Track Transpose is also useful for the ADrums track. It allows you to select another snare or kick sound, for example.

From/To-See page 178.

Bar, Beat, CPT—See page 178 for details.

Value (-24~+24)— This parameter is used to set the transposition interval in semi-tone steps. If you wish to transpose a C pattern to D, enter the Value +2. Note: Be careful when applying Transpose to the ADrums track. After all, transposing all notes of this track would mean that the drum part changes dramatically.

From Note/Than Note, To Note-See page 149.

Execute— Press this field to confirm your settings and edit the data.

Velocity

[FUNCTION MENU] button o [User Style Composer] field o [Edit] field o [Velocity]



The Velocity function allows you to modify the dynamics (called *velocity*) of a track or excerpt. See page 150 for details. Only note events can be changed, which is why you cannot select the data type.

Track, Mode, Type, Division— See page 178 for details.

From/To— See page 178.

Bar, Beat, CPT-See page 178 for details.

Value (-126~+126)— The Value parameter allows you to set the velocity change level. Select a positive value to increase the velocity of the selected track(s), or a negative value to decrease the velocity values. Note: Even the highest positive or negative Value doesn't allow you to go beyond "1" or "127".

From Note, To Note—See page 149.

Quantize

[FUNCTION MENU] button→ [User Style Composer] field→ [Edit] field→ [Quantize]



The Quantize function can be used *after* recording a part if you don't feel comfortable with the timing of what you played. If only certain notes in a given time range need to be quantized, you should narrow down the edit range using the From/To parameters.

Track, Mode, Type, Division— See page 178 for details.

From, To, Bar, Beat, CPT—See page 178 for details.

Value— This parameter sets the resolution of the Quantize function. The available values are: 1/8, 1/8t, 1/16, 1/16t, 1/32, 1/32t, 1/64t. See also page 142 for an example.

Execute— Press this field to confirm your settings and edit the data.

Note: Be sure to always select the value that equals the shortest note you recorded. Otherwise, your part no longer sounds the way you played it.

Gate T

[FUNCTION MENU] button o [User Style Composer] field o [Edit] field o [Gate T]



The Gate Time function allows you to modify the duration of the notes in the selected time (From/To) range. See page 151 for details.

Track, Mode, Type, Division— See page 178 for details.

From, To, Bar, Beat, CPT—See page 178 for details.

Value (-1920~+1920)— This parameter sets the amount by which the duration (or gate time) of the selected notes is to be changed. The shortest possible Gate Time value is "1". Allowing the value "0" would

effectively erase the notes, which can only be achieved with Erase (see page 178). You cannot use Gate Time to erase notes.

Execute— Press this field to confirm your settings and edit the data.

Shift

[FUNCTION MENU] button \rightarrow [User Style Composer] field \rightarrow [Edit] field \rightarrow [Shift]



Shift allows you to shift the the notes within the selected From/To range. See page 151 for details. Note: Before selecting a Shift value, you should have a look at one track in the Microscope mode (see page 181) to determine which negative value to use. If the first note of a track starts on 1-1-6, for example, set Shift to "-6". Be sure to apply the same Shift to all tracks to maintain the timing of the original!

Track, Mode, Type, Division—See page 178 for details.

From, To, Bar, Beat, CPT-See page 178 for details.

Value ($-1920 \sim +1920$)— This parameter sets the amount by which the notes are shifted. The Value refers to CPT units (one CPT= $1/120 \downarrow$).

Note: Notes on the first beat of the first bar cannot be shifted further to the left (that would mean shifting them to the "0" measure, which doesn't exist).

tz,6: User:Style: Micro mode

Select this mode whenever you need to change just one aspect of an otherwise perfect User Style (or copied ROM/Disk User Style).

In this section, we will use the word *event* for any kind of message (identical to MIDI messages that cause the Arranger to play or set something). An event is thus a command (or instruction) for the Arranger.

You can only view and edit one track at a time. In other words, do not forget to select the right track and pattern before you select a Micro function.

Here's how to select the User Style Microscope mode (steps (1)~(3) are only necessary if you have not yet selected the User Style Composer):

- 1. Press the [FUNCTION MENU] button.
- 2. Load the Style you want to change into the Disk User memory.
- 3. On the display page that appears now, press the [User Style Composer] field.
- 4. Press the [Micro] field.


The display now looks more or less as follows:



See "Cloning and edit functions and possible warnings (Shared)" on page 168 for the meaning of the above warning. This message only appears if the selected pattern (Mode/Type/Division) is part of a cloning group.

5. Press the [Track] field and use the [TEMPO/DATA] dial to select the track you wish to record. Next, select the pattern you wish to edit.

See page 178 for details.




6. Press Proceed [Single] if you only want to edit the selected pattern, or [ALL] to modify all "shared" patterns simultaneously.

Note: To edit other tracks and/or patterns at a later stage, you must return to this page by pressing the [*Back] field.

Change

[FUNCTION MENU] button \rightarrow [User Style Composer] field \rightarrow [Micro] field \rightarrow [Change]



The Microscope Change function is used to modify existing events, which may be anything from transforming a C#2 into a D2, velocity value "35" into "70", or control change CC01 into control change CC10.

Event selection (Bar-Beat-CPT)— Allows you to scroll through the events. You can only select Bar-Beat-CPT positions that already contain data. Use the [←][→] fields to scroll through the events. Press the field of the event you want to change.

Listen [↑][↓] & [CURRENT]— To scroll through the events while playing back the note events (such as "C#2" in the above example), press the [↑][↓] fields. The [Current] field allows you to sound the selected event (if it is a note). You could use this function to check the new velocity (Velo) value, and change it again if necessary until the note sounds right. This only works for notes.

Status column— This column contains all the message types you can assign to an event. See page 177 for details. Use the [TEMPO/DATA] dial for selecting an event.

Don't look for CC64 (Hold or Sustain) events because you won't find any. The use of the pedal connected to the SUSTAIN FOOTSWITCH jack is converted into the equivalent Gate T(ime) values. To change such converted "Hold messages", you thus have to modify the duration (Gate T) of the affected notes.


Velo— Don't let the name of this column fool you. It does indeed display the velocity value of *notes*, but it also contains the values assigned to a control change number, a program change, or Pitch Bend event.

Gate T— The values in this column always represent the duration (or Gate Time) of note events. That is why all other events have no Gate T values.

Note: The Gate Time value of drum note events is always "1". The sounds being triggered are indeed one-shot samples that stop automatically. Setting a longer Gate Time value for drum notes (ADrums track) does not make them longer.

Erase— Press this field to get rid of the currently selected event. You can press any field ([Status], [Velo] or [Gate T]) to select the event you wish to erase.

You can now select another function on the menu (Insert, Move Mix, or Copy Mix) or press [←Back] to return to the opening Microscope page in order to select another track or pattern for editing. Press [EXIT] to return to the Master page. As soon as you do, the display will tell you that the new settings are being processed:




You can also decide to save your Style to disk:



There is no need to confirm your settings: all modifications will take effect as soon as you return to the opening Microscope (or Master) page.

Insert

[FUNCTION MENU] button \rightarrow [User Style Composer] field \rightarrow [Micro] field \rightarrow [Insert]



This Insert function is used to add events to an existing track – or to program a part in step time.

The Insert function consists of two pages: the first page is used to add an event at the selected position (using Bar, Beat and CPT), while the second page allows you to define the Status (note, control change, etc.) and values of that event.

Note: It is perfectly possible to insert an event at a position that already contains an event. This allows you to add the missing note of a chord, for example. Be sure, however, not to assign two control changes of the same number (e.g. Pan, CC10) and with different values to the same position.

Bar (1~9999)— As you see, the new event will at first be assigned the position "1:1:000", which is probably not where you want it to be. Press this field and use the [TEMPO/DATA] dial or the [DATA] button/Numeric Entry pad to specify the bar where the new event should be inserted.

Beat (1~[number of beats per bar])—Press this field and specify the beat within the selected bar.

CPT ([BASS/BANK])— This parameter sets the CPT value of the new event. Here is a table of the most commonly used notes and their CPT values:

	in Color		
	480	Ŋ₃	90
ال	240	3	60
	120	٦,	30


[←][→]— Use these fields to scroll through the events already recorded on the selected track/pattern. This is only for viewing purposes or for locating the approximately correct position.

Proceed— After specifying the position of the new event, press [Proceed] to select the second Insert page, where you can assign a function (Status) and value(s) to the new event:



Status— Use the [TEMPO/DATA] dial to select the Status of the new event (note, control change, etc., see the table on page 177). You may have to press the [Type] field if it is not displayed in white. Then press the [Value] field and specify the "identity" of the event (CC number, note number – [Type] only allows you to specify the kind of event to be inserted: note message, control change, etc.).

To insert a note event, you can also press the corresponding key on the VA-76's keyboard. If the velocity value is not the one you need, either press the same key again (harder or softer) or use the [Velo] field to set it. Depending on the selected parameter, the display now looks as follows:



Note: You can only program one note at a time. Playing a chord will only enter the last note you played.

Velo— As stated above, the Velo value does not necessarily refer to a velocity value. It is also used to indicate and (on this page) set the value assigned to the control change, etc. in question.

Gate T— The Gate T value can only be set for note events. Use it to specify the duration of the new note. Remember that Gate Time value "1" is enough for ADrums note events.


Erase—Press this field to get rid of the new event.

Note: Press [*Back] to jump back to the first Insert page if you need to change something.

Proceed—Press this field to confirm your settings and assign them to the event.

Move Mix

[FUNCTION MENU] button \longrightarrow [User Style Composer] field \longrightarrow [Micro] field \longrightarrow [Move Mix]




The Move function allows you move the selected event (or events) to another position. This is similar to using the Shift function (see page 180) but it applies only to one or a few events at a time.

From— Press the [From] field in the left column and the field of the first event you wish to move (this field must be displayed in white). Use the [←][→] fields or the [TEMPO/DATA] dial to call up other groups of 5 events (these are not selected automatically).

To—Press the [To] field. Next, scroll through the available events (using [♣][♣] or the [TEMPO/DATA] dial) to jump to the page where the last event you wish to move is displayed. Press the desired field. All events between [From] and [To] are now selected.

Proceed— Now that the range of events to be moved is selected, press the [PROCEED] field to go to the second Move page:



The parameters on this page are used to specify the new position of the first event you selected on the previous display page. All subsequent events will be positioned relative to the first event (i.e. the distance between the moved events remains the same).

Bar, Beat, CPT— Use these fields and the [TEMPO/DATA] dial to set the position the selected event(s) is (are) to be moved to. Just for your information, the Move function is automatically set to *Mix*, which means that moving events does not overwrite events that may be present at the selected destination.

Execute— Press this field to confirm your settings and move the selected events to the new position.

You could now press [CopyMix] to jump to the Copy function, or [+Back] to return to the opening Microscope page.


Copy Mix

[FUNCTION MENU] button→ [User Style Composer] field→ [Micro] field→ [Copy Mix]



The Copy Mix function allows you to copy the selected events to another position. This means that the events in question will be used twice.

From, To—See "Move Mix" for details. After selecting the events to be copied, press [Proceed] to jump to the second Copy Mix page:



Here, you can specify the Bar/Beat/CPT position for the first event (of the selected range). Press [Bar], [Beat], and [CPT], and use the [TEMPO/DATA] dial to set the desired position.

Execute— Press this field to confirm your settings and copy the selected events to the new position.



The User Style Utility mode contains four functions you may need from time to time.

Change

[FUNCTION MENU] button→ [User Style Composer] field→ [Utility] field→ [Change]



This function allows you to globally edit the Expression, Reverb Send, and/or Chorus Send values of all User Style tracks (of all Divisions, Modes, etc.). This may be necessary if you wish to change the character of your User Style, e.g. when you think these values are either too low or too high. Using this function is a lot faster than returning to the [Rec] page and re-recording these values for all tracks of all divisions. A similar function is also available for the 16-track sequencer, so please see page 153.

Track—Press this field and use the [TEMPO/DATA] dial to select the track you wish to edit. Please note the *All Division Data Change* message: your changes will apply to all patterns of the selected User Style track.

Execute—After setting the desired values, press this field to execute this global change function.

Copy

[FUNCTION MENU] button \rightarrow [User Style Composer] field \rightarrow [Utility] field \rightarrow [Copy]



The Copy function allows you to copy one or all tracks of a Style pattern to the selected User Style pattern. The two important fields here are [Source] and [Destination]. When [Source] is displayed in white, you can select the Style to be copied. When [Destination] is displayed in white, you can select the track and pattern you want to copy the data to. See "Copying individual"

Style tracks" on page 172 for a step-by-step tour of this function. The following does not present all parameters and settings available for the Copy function.

Track (ADrums, ABass, Accl~6, ALL)—Allows you to select the track whose data you wish to copy (the *source* pattern). Do not forget to select the right Style (if it isn't already selected).

Mode— Allows you to specify one third of the source pattern's address: Major, Minor, 7th, or All.


Type— Allows you to specify the type of the source pattern: Basic, Advanced, or ALL.

Division— This parameter is used to select the Division of the source pattern you wish to copy: Original, Variation, or ALL.

Style — Press this field and use the [TEMPO/DATA] dial or the BANK/NUMBER pad to select the Style that contains the desired source pattern. The name of that Style is displayed in the second line.

Disk User— Press this field and use the Find function to select a Style on the inserted Zip or floppy disk.

The *Destination* page allows you to select the address the selected source pattern is to be copied to (the *destination* pattern). Please be aware of the following:




Times (1~99)— Sets the number of copies you wish to make. The value "3" means that you will end up with 3 contiguous copies, whereby the second copy is placed immediately after the first, etc.

Execute—Press this field to copy the data.

Name

[FUNCTION MENU] button→ [User Style Composer] field→ [Utility] field→ [Name]



See "Naming your User Style" on page 170 and page 68 for details.

Delete

[FUNCTION MENU] button→ [User Style Composer] field→ [Utility] field→ [Delete]




Unlike "Delete" on page 178, the User Style Delete function is used to clear the VA-76's Disk User memory. If you are sure you no longer need a given Style, delete it using this function.

13. Miscellaneous


13.1 Choosing the performance functions (Controllers)


The VA-76 provides several built-in controllers as well as three sockets for connecting optional controllers that will make your life a lot easier. It would thus be a good idea to browse through this chapter. The assignments you make here can be written to a User Program (see page 127), which means that you can "reconfigure" the performance functions simply by selecting another User Program.

The available controllers are:



Other realtime control possibilities include the Vari-Phrase sliders (see page 49), an FC-7 foot controller (see page 193), the PAD buttons (see page 194), and the [M-FX] knob (see page 120), while the sliders of the Mixer function can also be used for interesting realtime effects.





D Beam



The VA-76's D Beam Controller is a revolutionary function that allows you to control a selectable parameter by moving your hand over two sensors to the left of the display. On page 51, we showed you how to use the D Beam Controller. Let us now have a look at how to assign a function to it.

One final note before we get down to the available parameters: all options marked with a "o" apply to the currently active Keyboard parts.

Note: If you plan to use the D Beam Controller while controlling the Arranger, it is probably a good idea to activate its Hold function (see page 101).

Pitch Bend Up^o— By moving your hand over the D Beam, you can generate a value between "64" (no Pitch Bend) and "127" (maximum upward bend). As soon as you move your hand outside the D Beam's reach (higher than ±40cm above the "eyes" or further to the left or right), the value returns to "64" (no Pitch Bend). The extent to which a Keyboard part can be controlled depends on the *Pitch* setting (see page 188).

Pitch Bend Down^o— By moving your hand over the D Beam, you can generate a value between "64" (no Pitch Bend) and "0" (maximum downward bend). As soon as you move your hand outside the D Beam's reach, the value returns to "64" (no Pitch Bend). The extent to which a Keyboard part can be controlled depends on the *Pitch* setting (see page 188).

Cut&Reso Up^o— (Only for Upper1 and/or 2) By moving your hand over the D Beam, you can vary the current TVF Cutoff value (see also page 126) of the Upper1 and/or 2 part. The Resonance parameter will be set to "+63" (maximum), while the Cutoff frequency can be controlled between "0" (no change) and "+63" (maximum increase). This allows you to create some nifty filter effects that are particularly useful for Dance/Techno music. When you move your

hand outside the D Beam's range, both Resonance and TVF Cutoff return to their original values ("0"= no change).

Note: If TVF Cutoff is already set to "+63", you cannot increase it using the D Beam Controller. In that case, the following option is probably more useful. Also note that some Tones already use the highest possible TVF Cutoff value by default, in which case you cannot add more overtones (by opening the filter even further).

Cut&Reso Downo— (Only for Upperl or 2) By moving your hand over the D Beam, you can vary the current TVF Cutoff value (see also page 126) of the Upperl and/or 2 part. The Resonance parameter will be set to "+63" (maximum), while the Cutoff frequency can be controlled between "0" (no change) and "-64" (lowest possible TVF Cutoff setting). When you move your hand outside the D Beam's range, both Resonance and TVF Cutoff return to their original values ("0"= no change).

Note: See the above note. The TVF Cutoff frequency cannot be lowered if TVF Cutoff is already set to "-64".

Tempo Up/Down—Select one of these options if you want to increase (Up) or decrease (Down) the current Arranger or Song Composer tempo. By moving your hand outside the D Beam's range, you return to the previous tempo value.

Modulation - Select this function if you want the D Beam to duplicate the modulation function of the Bender/Modulation lever.

Arpeg 1/2/3 Octv—By moving your hand over the D Beam, you cause the Lower2 part to play arpeggios (broken chords) based on the notes you play in the chord recognition area (see page 101). Depending on the setting you select here, the notes of the chord recognition area will be arpeggiated over 1, 2, or 3

Note: Do not forget to assign a suitable Tone to the Lower2 part. See "Selecting Tones for the Keyboard parts" on page 37. Also, activate the Arranger Hold function (see page 101).



Chord 1/2/3 Octv—By positioning your hand inside the D Beam's range, you cause the Lower2 part to sound the notes of the chords you play in the chord recognition area. You could use this function to add syncopated brass or guitar "hits" to your melody. The velocity value used for playing these notes is "100". The number (1, 2, or 3) bears on the octave of this

"added chord": $I = A_{1}3 \sim G4$, $2 = A_{1}4 \sim G5$, and $3 = A_{1}5 \sim G6$. Move your hand outside the D Beam's range to stop the Lower2 part from sounding the chord.

Arr Start/Stop— Depending on the current condition of the Arranger (running or stopped), one move inside the D Beam's range stops (or starts) it. A second movement will start (or stop) it again.

Fill To Var/Or— Here, too, the D Beam performs two functions that depend on the currently selected Division (Original or Variation). The first time the D Beam senses your hand (or other limb), it activates the Fill-In TO VARIATION function. Upon completion of that Fill, the Arranger switches to the Variation pattern. The second time, the Fill-In TO ORIGINAL is activated.

Note: This function is only available while the Arranger is available. During Composer or 16-track Sequencer playback, you may get the impression that the D Beam Controller does not work. But as soon as you return to the Arranger (normal VA-76) mode, everything will be back to normal again.


ADrum On/Off— This setting allows you to switch the Arranger's ADrums part on and off using the D Beam Controller. There are also combined on/off options (see below).

ABass On/Off— This setting allows you to switch the ABass part on and off using the D Beam Controller.

Accomp On/Off— This setting allows you to switch the Accompaniment parts (ACC1~6) on and off using the D Beam Controller.

ABs+ADr On/Off— This setting allows you to use the D Beam for switching on and off the ABass and ADrums parts.

Acc&ABs On/Off— This setting allows you to use the D Beam for switching on and off the ABass and ACC1~6 parts.



Acc&ADr On/Off— This setting allows you to use the D Beam for switching on and off the ADrums and ACC1~6 parts.


Fig Pitch Up/Down— These two options allow you to raise (Up) or decrease (Down) the VariPhrase Pitch parameter. This duplicates "one half" of the [Pitch] slider (see page 49).

Time Up/Time Down— These two options allow you to increase (Up) or decrease (Down) the playback speed of the selected VariPhrase.

Fa Formant Up/Down— These two options allow you to change the character of the selected VariPhrase. See page 48 for details. This function can also be controlled via an on-screen slider (see page 49).

Cut&Reso Up and Formant Up— This is a combination of two functions covered earlier and the only one that allows you to control two aspects simultaneously using the D Beam controller. This is the default setting.

Pitch Bender



Use the fields in the center of the display to select the Keyboard part whose Pitch Bend setting you want to change. Surprising though it may be, you can also specify a Pitch Bend range for the Manual Drums part. Selecting values between "2" and "7" allows you to achieve interesting effects that work well for timpani sounds (of a 71 Orchestra set), for example.


Assign—If this parameter name is not displayed, press the [↑] field. Auto means that the part in question only responds to movements of the BENDER lever if it is assigned to the right half (SPLIT) or the entire keyboard (WHOLE). On means that the part in question always responds to BENDER messages, even if it is assigned to the left half of the keyboard. Off, finally, means that the part does not respond to BENDER messages.

Pitch — (0~24) Select this parameter by pressing [♣] once. It is used to specify the maximum pitch shift that can be achieved by turning the BENDER lever fully to the left or right. Since there is only one parameter, it applies to both upward and downward bends. Remember, however, that the Pitch value can be set individually for each Keyboard part, so be careful to set musically useful Pitch values. Select "0" for Keyboard parts whose pitch should not change in response to Pitch Bend messages (alternatively, you can set Assign to "Off").

Note: The Pitch value you set here will only be effective when you turn the Bender lever fully to the left (downward bends) or to the right (upward bends). Intermediary positions of the lever produce the resulting intermediary bend value.



Modulation



Modulation allows you to add vibrato to the notes you are playing. This is achieved via an LFO (a Low-Frequency Oscillator) whose speed is preset. By pushing the BENDER/MODULATION lever away from you, you specify the depth of this cyclic modulation.

Use the fields in the center of the display to select the Keyboard part whose modulation setting you want to change.

Assign— Auto means that the part in question only responds to modulation messages if it is assigned to the right half (SPLIT) or the entire keyboard (WHOLE). On means that the part in question always responds to modulation messages, even if it is assigned to the left half of the keyboard. Off, finally, means that the part does not respond to modulation messages.


If you select the VariPhrase part, you can also select and set additional parameters. Use the [♠][♣] fields to select: LFO Pitch (tantamount to vibrato), LFO Formnt (modulation of the character), LFO Level (tantamount to a tremolo effect), or LFO Pan (cyclic movements between the left and right stereo channels). The LFO's speed is preset. The setting range for these three parameters is 0~63.

Touch Control (Ribbon)



This page contains the functions that can be assigned to the Touch Control (also called "Ribbon"). With the exception of Off (that deactivates the Ribbon controller), the parameters are identical to the ones of the D Beam controller (see page 186).

Aftertouch



This page does not follow the pattern of the other "Hand" controllers: you cannot select a Keyboard part simply by pressing the corresponding field. There are two reasons for this:

- a) You can set multiple parameter values for one, several or all available Keyboard parts. These will be applied simultaneously whenever you press the keys down even further after playing the desired notes.
- b) Aftertouch can also be used for controlling the Arranger. You can even control one or several Keyboard parts and the Arranger simultaneously.

The best way to proceed is as follows:

1. First select the part whose parameters you wish to assign to the Aftertouch ($[\uparrow] [\downarrow]$).

The options are: Upper1, Upper2, Lower1, Lower2, and ✓ (VariPhrase) (and Arranger).

2. Decide whether or not the part in question should respond to Aftertouch messages by pressing the [ON/OFF] field.

Obviously, [ON] means "yes", and [OFF] means "no".

You can set the Value of several available parameters, so that the Aftertouch allows you to control several parameters simultaneously.

Note: Aftertouch only applies to Keyboard parts that are currently accessible (Keyboard Mode setting, Keyboard part on/off (see page 36)).

- 3. Press the field of the parameter whose setting you wish to change. If the desired parameter is not displayed, use the [←][←] fields to select it.
- 4. Enter the desired value using the on-screen slider, the [TEMPO/DATA] dial, or the [DATA] button/Numeric Entry pad.



Note: Select Arranger with the $[\ \ \ \ \ \ \]$ field to set the effect the Aftertouch can have on the Arranger (see page 97).

Parameters for Keyboard parts (excluding the VariPhrase part)

Aftertouch only works in one direction (i.e., it generates either positive or negative values).

Pitch (-24~24): This parameter has the same effect as the Pitch Bend feature (see page 188). Bear in mind that it only allows for upward (+) or downward (-) bends

TVF Cutoff— (-64~63) Setting a positive or negative value for this parameter means that the cutoff frequency of the Tone assigned to the selected part can be increased or decreased.

Note: Depending on the value you set for TVF Cutoff (see page 126), high positive or negative settings may have no audible effect. That is also the case of Tones whose cutoff frequency is already preset to the maximum value.

Amplitude— (-64~63) Setting a positive or negative value for this parameter allows you to increase or decrease the volume of the selected part using the Aftertouch.

Note: Again, the volume cannot be increased (or decreased) beyond "127" (or "0"). If the volume of the part is question is already set to "127" (or "0"), the Aftertouch will produce no audible effect.

LFO1 Rate— (-64~63) This parameter allows you to increase or decrease the modulation speed of LFO1. Use this function in combination with the Modulation axis of the Bender/Modulation lever, or to change the modulation speed of the preset automatic modulation

LFO1 Pitch— (0~127) This parameter allows you to add pitch modulation using the Aftertouch feature. Pitch modulation is usually referred to as vibrato.

LFO1 TVF— (0~127) This parameter allows you to add cutoff frequency modulation via the Aftertouch. This is also known as WahWah.

LFO1 TVA— (0~127) This parameter allows you to add amplitude modulation using the Aftertouch function. This is also known as tremolo.

LFO2 Rate, LFO2 Pitch, LFO2 TVF, LFO2 TVA-

Same setting range and meaning as the corresponding LFO1 parameters. Note that not all Tones use a second LFO, which is why these settings do not always yield the desired effect.

Note: Except for Rate, the LFO parameters are absolute settings that do not alter existing values. That explains why their setting range is 0~127 rather than -64~63. Use these parameters (Pitch~TVA) to add a new aspect to the selected Tone.

Note: Like the Part parameters (see page 125), the Aftertouch settings apply to the Keyboard part in question, so that selecting another Tone for such a part does not mean that the values will be reset to "0".

Parameters for the VariPhrase part

The following VariPhrase parameters can be controlled via the Aftertouch:

Ed Pitch— (Up, Down, Off) Select "Up" if you want to be able to raise the VariPhrase's pitch via the Aftertouch. "Down" means that you can lower the pitch. Select "Off" if the pitch should not be controlled via the Aftertouch.


™ Time—(Up, Down, Off) Select "Up" or "Down" to be able to increase/decrease the speed of the selected VariPhrase via the Aftertouch. Select "Off" if that is not necessary.

Fa Formant— (Up, Down, Off) Select "Up" or "Down" to be able to raise/lower the Formant of the selected VariPhrase via the Aftertouch. Select "Off" if that is not necessary. See "Things you ought to know about VariPhrase" on page 48 for details about the formant.

☑ LFO Pitch, LFO Frmnt, LFO Level, LFO Pan— (0~63) These parameters behave exactly like the ones you can assign to the Modulation axis of the BENDER/MODULATION lever. See page 188.

Parameters for Arranger control


Use the [♣] field to select *Arranger*. The display should now look like this:



Press the [ON/OFF] field to make it read [ON] if you want to control the Arranger. See page 97.

Note: Even Aftertouch messages generated outside the chord recognition area will trigger the selected switching function.

Sustain Switch (CC64)




The parameters on this page are related to an optional DP-2, DP-6, or BOSS FS-5U footswitch you connect to the SUSTAIN FOOTSWITCH socket. Also called "Hold pedal" or "Damper" pedal, this switch allows you to hold the notes you play on the keyboard in much the same way as on an acoustic piano.

Though you cannot assign other functions to this footswitch, you can decide when a given part should respond to these messages. Note that for the Vari-Phrase part, more refined hold options can be assigned to the optional footswitch (see below), while you could use that optional footswitch as a separate Hold pedal for the Lowerl and/or 2 part.

Use the fields in the center of the display to select the Keyboard part whose Sustain setting you want to change.

Assign— Auto means that the part in question only responds to Sustain messages if it is assigned to the right half (SPLIT) or the entire keyboard (WHOLE). On means that the part in question always responds to Hold messages, even if it is assigned to the left half of the keyboard. Off, finally, means that the part does not respond to Hold messages.

Foot Switch



This parameter allows you to specify the function of the optional DP-2, DP-6, or BOSS FS-5U connected to the FOOT SWITCH socket on the rear panel. The default setting is Start/Stop, which allows you to start and stop Arranger playback. Note also the Soft and Sostenuto options as well as the possibility to select several Hold functions. The footswitch can only perform one function at a time, though.

Start/Stop— Starts and stops Arranger playback. Same function as the [START/STOP] button.

Play/Stop— Starts and stops the Composer. Same function as the [PLAY ▶] field.

Intro— Selects the Intro of the current Style Type during Arranger playback. Same function as [INTRO].

Ending—Selects the Ending of the current Style Type during Arranger playback. Same function as [END-ING].

Fill— Triggers either the To Original or To Variation fill, depending on whether the Original or Variation Division is currently active. Upon completion of the Fill, the Arranger will play the Division selected by the Fill.

Bsc/Adv— Selects either the Basic (Bsc) or Advanced (Adv) Type (levels ② or ④ in Orchestrator terms, see page 62), depending on which one is active at the time you press the footswitch.

Org/Var—Selects either the Original or Variation Division of the currently active Type, depending on which one is active at the time you press the footswitch. Same function as [ORIGINAL] and [VARIATION].

Bass Inversion— Switches the Bass Inversion function on and off (see page 102).

Arr/M.Bass—Allows you to set the Arranger Chord parameter to "Off" (chord recognition plus ABass recognition off, see page 101) and, at the same time, select the Keyboard Mode SPLIT mode and activate the M.Bass part – and vice versa.

PianoSt/Stand—You alternate between the Standard and Piano Style Arranger Chord modes. When the former is selected, the chord recognition area (see page 102) is automatically set to Left. When you switch to Piano Style, the chord recognition area is automati-

cally set to Whole. Furthermore, the Keyboard Mode is set to WHOLE, while the Upper 1 part is activated (if it was off).

Note: This switches off the VariPhrase part if it is on at that time.



Rotary S/F— Allows you to select the slow or fast speed of the Rotary effect. This only works, if the Rotary effect is currently assigned to the M-FX. Note: The Rotary effect is available in the following M-FX types: 13 Rotary, 62 Rotar/Mlt, 85 OD/Rotar, and 88 PH/Rotar.

Upper 1-2 Scale— Allows you to switch the Scale Tuning function on and off for the Upper1 and Upper2 parts (see page 92).

Arr Chord Off—Allows you to switch chord recognition on and off. When off, the notes you play in the chord recognition area of the keyboard no longer cause the Arranger to play another chord. Works well for long piano arpeggios (see page 101).

UsrPrg Up—Selects the next User Program (i.e. A12 if A11 is currently active).

Note: The footswitch function can also be written to a User Program, so that the memory you select using the footswitch in Usr Prg Up mode may contain another footswitch assignment. You could then no longer select the next User Program (i.e. A13) by foot.

UsrPrgDown— Selects the previous User Program (i.e. B88 if A11 is currently active). See also the note

Punch I/O— The footswitch can be used to activate and switch off punch in/out recording of the VA-76's sequencer (see page 144).

Portamento— Switches the Portamento function (see page 89) on and off.

Soft— In this case, the footswitch functions as Soft pedal (a pedal found on grand and digital pianos that reduces the volume).

Note: This function only applies to the Keyboard parts.

Sostenuto— In this case, the footswitch functions as Sostenuto pedal (another pedal found on grand and digital pianos that allows you to sustain only those notes you played at the time you pressed the pedal). Note: This function only applies to the Keyboard parts.

Hold— The footswitch has the same function as a DP-2, DP-6, or BOSS FS-5U connected to the SUSTAIN FOOTSWITCH socket.

Note the Soft and Sostenuto options as well as the possibility to select Hold. Though there is a dedicated SUSTAIN FOOTSWITCH jack that serves the same purpose, you may want to select Hold for certain User Programs.



Hold Lower1—In this case, the footswitch performs the same function as the Lower Hold function when it is assigned to the Lower1 part (see also page 90).

Hold Lower2— The footswitch performs the same function as the Lower Hold parameter. This time, however, it only applies to the Lower2 part.

Hold Lower 1-2— The footswitch performs the same function as the Lower Hold parameter when it is assigned to the Lower1 and 2 parts.

Parameters for the VariPhrase part


The following VariPhrase parameters can be controlled via the footswitch:

- Phrase Loop— The footswitch allows you to switch the Loop function on or off. See also page 82.
- Pause—Allows you to "freeze" the VariPhrase at the current position, so that the syllable or sound can be held indefinitely. See also page 83.
- ☑ Legto Lock—Allows you to use the footswitch as "play/stop" button, while the keys work as intelligent (pitch-sensitive) "mute switches". See also page 82.
- **☑ Hold** In this case, the footswitch functions as dedicated Hold pedal for the VariPhrase part.

Audio In Rev and Ch On/Off— In this case, the footswitch performs the same function as the [ON/OFF] field for the Reverb and Chorus effects on the Audio In page. You could take advantage of this for announcements between songs. See also page 58.

Kbd Exc UP1/UP2— Allows you to switch off the Upper1 part and activate the Upper2 part, and vice versa.

Foot Pedal (Expression)



The expression pedal can be used for several purposes. The default setting of the VA-76 is that the volume of all parts is affected by the position of the optional expression pedal. You could, however, use it to control the M-FX or the VariPhrase part. Note that only one option can be used at a time.

Here's how to assign a Foot Pedal function to a part:

No function for a part (Off)

- 1. Start by selecting all parts that should not be affected by the expression pedal:
- a) Press the field of a part that should use the "Off" setting (no response to the expression pedal).
- **b)** Press [♣] to have access to the Arranger parts.
- 2. Press the [Assign] field and use the slider in the right column or the [TEMPO/DATA] dial to select "Off".
- 3. Repeat steps (1) and (2) for other parts that must not respond to expression messages.

Note: There are also other VariPhrase functions you could assign (see below).

Volume:control (Expression)

- 4. Press the field of a part that should respond to volume messages transmitted by the expression pedal.

 Press [♣] to have access to the Arranger parts.
- 5. Press the [Assign] field and use the slider in the right column or the [TEMPO/DATA] dial to select "Expression".
- 6. Press the [Up] or [Down] field and use the slider, the [TEMPO/DATA] dial, or the [DATA] button/ Numeric Entry pad to set the value.

These two fields refer to the volume to be obtained when the expression pedal is depressed ([Down], highest volume) or closed ([Up], lowest volume).

Up/Down (0~127)— You do not need to specify "0" for the Up position. Selecting any other value will reduce the volume of the selected parts up to the "Up" value. Likewise, you do not need to specify "127" as maximum value.

Note: If you select Expression, the Down and Up values represent MIDI Expression (CC11) values.

Note: It is perfectly possible to set the Up value to "127" and the Down value to "0", so that the selected part only sounds when the Expression pedal is up (closed).

The Expression function can also be used for some clever effects. Instead of alternating between Upper1 and Upper2 by varying your velocity (see page 91), which requires a considerable amount of "striking precision", you could invert Upper2's response to the expression pedal, so that Upper1 does not sound when Upper2 does, and vice versa.

M-FX:Value 1/2

If you select M-Value 1 or M-Value 2, the foot pedal performs the same function as the corresponding M-FX slider (see page 120) with the additional advantage that you can narrow down the setting range (and use e.g. 40~80 rather than 0~127). These parameters apply to all Keyboard parts that use the Insertion effect. In that case, the display looks like this:



Up/Down (0~127)— Press the [Up] or [Down] field and use the slider, the [TEMPO/DATA] dial, or the [DATA] button/Numeric Entry pad to set the effect parameter value to be obtained when the expression pedal is depressed (Down) or closed (Up).

Note: You do not need to specify "0" for the Up position. Likewise, you do not need to specify "127" as maximum value.

Formant Up/Down

If you select Formant Up or Fa Formant Down, the expression pedal performs the same function as the [Formant] slider on the "Controllers/VariPhrase" page (see page 49).


[Up] and [Down] fields: see above.

13.2 FC-7 & Pad parameters


The display page for the following two parameters can be selected in two ways:

1. Press and hold a PAD button for at least one second.

The VA-76 jumps to the following display page:



- 2. Or proceed as follows:
- a) Press the [FUNCTION MENU] button.



b) Press the [FC-7 and PAD] field in the lower left corner to jump to the display page of the same name (see above).

FC-7 Foot Controller

As stated earlier, you can connect an optional FC-7 Foot Controller to the FC7 PEDAL socket. The VA-76 allows you to assign the desired function to each of the seven pedals (foot switches).

Note: The assigned functions apply to the VA-76 as a whole and are not written to individual User Programs. They can, however, be saved to disk (along with all User Programs) using "Save User Program Set" on page 211.

- 1. Jump to the FC-7 and PAD display page (see above).
- 2. In the upper half, press the pedal field that is assigned to the footswitch you wish to assign another function to.

To change the assignment of the second pedal from the right, press the last-but-one pedal field.

3. Use the [TEMPO/DATA] dial to select the desired function:

Start/Stop, Intro, Basic/Advanced, Fill To Variation, Fill To Original, Original/Variation, Ending— These are the default functions of the FC-7's footswitches (1~7). They duplicate the functions of the Arranger control buttons.

Orchestrator 1~4— These functions allow you to select the corresponding Orchestrator level (see page 62).

Break Mute— This function can only be accessed via the FC-7. When you press the assigned footswitch, Arranger playback will be muted for the remainder of the current measure. This is great for rock'n'roll songs.

Arranger RIT Tempo, Arranger ACC Tempo— The assigned footswitch performs the same function as the RIT or ACC field (see page 104).

Arranger Default Tempo— The assigned FC-7 footswitch allows you to reset the Arranger tempo to the preset value (contained in the Music Style itself). This is also the default function of the PAD [1] button (see "Reset Tempo" on page 194).

Tap Tempo— Same function as the [TEMPO/TAP] button.

Bass Inversion— Allows you to switch the Bass Inversion function on and off (see page 102). This is also the default function of the PAD [2] button.

Melody Intelligent— Same function as the button of the same name on the VA-76's front panel: it allows you to switch Melody Intelligence on and off.

Keyboard Exchange UP1/2— Allows you to switch off the Upper1 part and activate the Upper2 part, and vice versa.

Soft, Sostenuto, Sustain— The assigned footswitch can be used as a Soft, Sostenuto, or Sustain (Hold pedal). Note that Sustain is also available via a dedicated (but optional) DP-2, DP-6, or BOSS FS-5U footswitch connected to the SUSTAIN FOOT-SWITCH socket.

Sustain LW1, Sustain LW2, Sustain LW1-2—See "Hold Lower1", "Hold Lower2", and "Hold Lower 1-2" on page 192.

Rotary Slow/Fast—Allows you to select the slow or fast speed of the Rotary effect. This only works, if the Rotary effect is currently assigned to the M-FX.

User Program Up, User Program Down—Selects the next ("Up") or previous ("Down") User Program.

Play/Stop Song— Starts and stops the Composer. Same function as the [PLAY ▶] field.

☑ VariPhrase On/Off

Audio In Rev&Cho On/Off—In this case, the assigned FC-7 footswitch performs between two functions simultaneously: it switches the VariPhrase part as well as the Reverb and Chorus effects of the Audio In part on or off.

PAD buttons

PAD [1] and [2] to the left of the BANK/NUMBER section are freely assignable buttons. The default settings for these buttons are:

PAD [1]—Reset. This function allows you have the Arranger start on the first beat of the currently selected Music Style pattern when you press the PAD button. Use it when you are accompanying a singer or soloist whose timing is a little shaky, and suddenly notice that the Arranger lags one or two beats behind the singer/soloist.

PAD [2]—Bass Inversion. This button allows you to switch the Bass Inversion function (see page 102) on and off.

Note: The PAD assignments can be written to a User Program, so that you could work with 128 different combinations

To assign a different function to these buttons:

- 1. Jump to the FC-7 and PAD display page (see page 193).
- 2. Press the [Pad 1] or [Pad 2] field, depending on whose button's assignment you wish to change.
- 3. Use the [TEMPO/DATA] dial to select the desired function:

Off—The PAD button in question has no function at all.

Rotary Slow/Fast—Allows you to select the slow or fast speed of the Rotary effect. This only works, if the Rotary effect is currently assigned to the M-FX.

Stop/Play Song— Starts and stops the Composer. Same function as the [PLAY ▶] field.

Count In— The assigned PAD button can be used to switch the Count-In function (see page 56) on and off.

Reset Tempo-See "PAD [1]" above.

Half Bar on Fill In— The assigned PAD button allows you to switch the Half Bar function on and off. See also page 97.

Arranger Hold—Allows you to switch the Arranger Hold function on and off. See page 101.

Dynamic Arranger— Allows you to switch the Dynamic Arranger function on and off. See page 103 for details.

Keyboard Exchange UP2/1— Allows you to switch off the Upper 1 part and activate the Upper 2 part, and vice versa.

Keyboard Exchange LW2/1— Allows you to switch off the Lower1 part and activate the Lower2, and vice versa.

Note: If neither Lower1 nor Lower2 are on when you first press the PAD button, one of them will be activated.

MBass/Keyboard Arranger—Allows you to set the Arranger Chord parameter to "Off" (chord recognition as well as ABS recognition off, see page 102) and, at the same time, select the SPLIT Keyboard mode and activate the M.Bass part – and vice versa.

Note: Pressing the PAD button you assign this function to does not mean that the Arranger stops. If you switched on the Arr Hold function (see page 102), the last recognized chord will go on sounding, so that your M.Bass part may drown in the accompaniment. We therefore suggest you assign the "Arranger Hold" function (see above) to the other PAD button. You can then switch off the Arranger Hold function, so that the Arranger only plays the drum pattern of the selected Music Style.

Piano/Standard—By pressing the PAD button, you alternate between the *Standard* and *Piano Style* Arranger Chord modes. When the former is selected, the chord recognition area (see page 102) is automatically set to LEFT. When you switch to *Piano Style*, the chord recognition area is automatically set to WHOLE. Furthermore, the Upper 1 part is activated (if it was off).

Bass Inversion - See "PAD [2]".


Upper 2 to Left — Allows you to switch the function of the same name on and off (see page 88).

Fade In, Fade Out—Fade In is a function you may want to use occasionally. Fading in means that the volume of both the Arranger (Style) and Keyboard parts gradually increases, giving the impression that you have been playing for a long time before what you play becomes audible. The volume is automatically set to zero and then gradually increased to the value specified with the [VOLUME] knob. When the Fade In is completed, the indicator of the PAD button goes dark. Fade Outs are extremely popular in pop music, and the VA-76 allows you to end a song just like the original. To do so, press the assigned PAD button. The volume then gradually decreases until it reaches zero (indicator lights steadily).


13.3 Global parameters (for the entire VA-76)

The VA-76 also provides a number of settings that apply to the entire instrument (which is also the case of the FC-7 assignments, see page 193). Here's how to change the behavior of your VA-76:

1. Press the [FUNCTION MENU] button.



The display now looks as follows:



2. Press the [Global Parameter] field.



3. If necessary, press the [Keyboard] field in the bottom row.


Master Tune

See page 55.

Tone Recall

When this parameter is set to [ON], the VA-76 assigns the "11 St.AcPiano 1" Tone to the Upper1 part whenever you press the Keyboard Mode [PIANO] button. You can, however, block this automatic Tone selection, so that pressing the [PIANO] button only selects the WHOLE mode with only Upper1 (UP1) active. That part will go on using the last Tone you selected for it.

Factory Resume



The Factory Resume fields allow you to select all or only certain settings of the "Free Panel" User Program so as to initialize the section in question. Why would you need such a function since you can also select the "Free Panel" memory by simultaneously pressing User Program [UP] and [DOWN]?

That is because the "Free Panel" memory is, in fact, a RAM memory where your settings are buffered. After switching on the VA-76, the Free Panel settings are identical to the ones you can recall with the [ALL] field. But just one change to the VA-76's parameters (e.g. the selection of another Tone) means that the "Free Panel" settings are different from the factory settings.

If you really want to start anew without switching the VA-76 off and back on again, you must press one of the above fields.

All—All settings of the factory "Free Panel" memory will be loaded.

Tone— Only Tone selection and the lock settings (for Arranger parts) of the factory "Free Panel" memory will be loaded (see below).

Param— Only the "parameter" settings will be initialized. These include such diverse things as the controller assignments, the UP2 Split/UP2 to Left setting, the Scale Tuning setting... In short: all parameters that are neither related to [Tone] nor to [Mixer]. This allows you to reset those slightly more "specific" parameters without changing the current Tone assignments and volume/effect settings.

Mixer—Only the Mixer settings of the factory "Free Panel" memory will be loaded (see below).

Virtual Band Autorun

When this parameter is set to [OFF], the Virtual Band page is no longer displayed automatically every time you switch on the VA-76. This also means that the Virtual Band page does not automatically appear after a few moments of inactivity. It's up to you to decide whether or not the Virtual Band is solicited automatically.


Note that even if you select [OFF], you can still select the Virtual Band page by pressing the [VIRTUAL BAND] button.

- 1. Select a [Global Parameter] page (see page 195).
- 2. Press the [Startup] field.



3. Press the [ON/OFF] field to select "On" (Virtual Band is selected automatically) or "Off" (Virtual Band can only be selected via the button of the same name).

See "User Program selection at power-on" on page 131 for details about [Startup User Program], and "MIDI Set selection at power-on" on page 207 for [Startup MIDI Set].




14. MIDI

14.1 MIDI in general

MIDI connectors

MIDI messages are transmitted and received using three connectors and special MIDI cables:



MIDI IN— This connector receives messages from other MIDI devices.

MIDI OUT— This connector transmits MIDI messages generated on your VA-76

MIDI THRU— This connector "echoes back" all MIDI messages received via MIDI IN

Channels

MIDI can simultaneously transmit and receive messages on 16 channels, so that up to 16 instruments can be controlled. Nowadays, most instruments—like your VA-76— are multitimbral, which means that they can play several musical parts with different sounds.

That concept is not difficult to understand. Just think of your VA-76: it is equipped with an Arranger capable of playing the drums, the bass, and up to six accompaniment parts, while at the same time allowing you to play up to seven Keyboard parts.

MIDI data types

The most important aspect of the MIDI standard is that it allows one instrument to tell another when to play a note, for how long, and how strongly it should be played.

Other aspects of a musical performance include modulation (vibrato), Pitch Bend (bending), volume, Pan-Pot, etc.

Yet another group of MIDI messages is used to tell the receiver when to select another sound and which sound to select. These messages are called *Bank Select*, and *Program Change*. In fact, these are the messages that are automatically recorded at the beginning of each Style division and written to a User Program so that you can recall the Tone selection for *all* available parts simply by selecting a User Program. Program Change and Bank Select messages also allow you to select User Programs, Styles, and Drum Sets.

Still other MIDI data allow you to synchronize two MIDI instruments so that they start and stop at the same time and run at the same tempo.

MIDI messages used by the VA-76

The way a device responds when it receives MIDI messages (i.e. how it produces sound, etc.) depends on the specifications of that device. If the receiving device is not able to perform the function specified by the incoming message, the musical result will not be what you expected. What it comes down to is this: there are several levels of MIDI compatibility, and not all MIDI compatible instruments understand (i.e. receive) all existing MIDI messages.

Note: MIDI messages for which reception capability is required by the GM system (level 1) are marked by a * sign.

Note messages *— These messages convey notes

played on the keyboard. They include the following information:

Note number	A number describing the note corresponding to the key you pressed or released.
Note-on	A message signalling that you pressed a key (i.e. "start playing now").
Note-off	A message signalling that a key was released.
Velocity	A value describing how strongly you pressed a key.

On many instruments (such as your VA-76), a note-on message with the velocity value "0" is used to signal the end of a note (i.e. velocity value "0" effectively functions as note-off message).

Pitch Bend *— This message conveys the position of the Bender lever (or pitch bend wheel). The pitch will change when this message is received.

Bank Select (CC00 and CC32), Program Change *—On the VA-76, these messages are used to select Tones, Styles, and User Programs. By using Bank Select messages (which are in fact control change messages), an even wider variety of memory locations can be selected. Control change messages were added when it became clear that the maximum number of sounds selectable using Program Change messages (128) was no longer sufficient to access all sounds of a given instrument.

Note: Do not forget to send a Program Change message after a Bank Select message because sending only Bank Select messages does nothing whatsoever. The right order for sending these messages is (pay attention to the CPT values):

- 1.1.0 Bank Select CC00 + value
- 1.1.1 Bank Select CC32 + value (0, 1, 2, 3, or 4)
- 1.1.2 Program Change

On the VA-76, CC32 messages are used to select the Tone Map: "0" (don't leave current Tone Map), "1" (SC-55 mode), "2" (G-800), "3" (G-1000 or EM-2000), or "4" (VA-76).

Control change messages

These messages control parameters such as modulation and pan. The function of a message is determined by its control change (e.g. ID) number.

Modulation (CC01) *— This message controls vibrato.

Volume (CC07) *— This message controls the volume of a part. When this message is received, the volume of the part receiving on that MIDI channel will change.

Expression (CC11) *— This message conveys volume changes. It can be used to add expression. The volume of a part will be affected both by Volume messages (CC07) and Expression messages (CC11). If a value of "0" is received for either of these messages, the part volume will be 0 and will not rise even if the other message is sent with a higher value.

Pan(pot) (CC10) *— This message controls the stereo position of a part.

General purpose controllers (CC16~19)— These are control change messages that have no set function within the MIDI standard. On the VA-76, CC16 and CC17 allow you to control two parameters of the M-FX. CC16 is assigned to the [M-Value 1] slider, and CC17 to the [M-Value 2] slider. See also page 219 for the parameters that can be controlled. CC18 and CC19 (as well as CC16 and CC17) are also used for VariPhrase control.

Hold (1) (CC64) *— This message conveys the up/down movements of the Damper (Sustain, Hold) pedal. When a Hold On message is received, notes will be sustained. In the case of decay-type instruments such as a piano, the sound will decay gradually until a Hold Off message is received. In the case of sustaintype instruments such as an organ, the sound will continue sustaining until a Hold Off message is received.

Sostenuto (CC 66)— The Sostenuto pedal on a piano sustains only the notes that were already sounding at the moment the pedal was pressed. The Sostenuto message conveys the movement of this pedal.

Note: This function can be assigned to the optional foot-switch (see page 191) and an optional FC-7 (see page 194).

Soft (CC67)— The Soft pedal on a piano softens the tone during the time the pedal is pressed. The Soft message conveys the movement of this pedal. When Soft On is received, the cutoff frequency will be lowered, causing a softer sound. When Soft Off is received, the previous sound will return.

Note: This function can be assigned to the optional foot-switch (see page 191) and an optional FC-7 (see page 194).

Reverb Send Level (CC91)— This message adds a Reverb effect to the part.

Chorus Send Level (CC93)— This message adds a Chorus effect to the part.

Delay Send Level (CC94) — This message adds a Delay effect to the part. Delay is not available for the Drums (ADrums and M.Drums) parts, nor for the VariPhrase/Audio In parts (VA-7).

Portamento (CC65), Portamento Time (CC05), Portamento Control (CC84)— See page 89 for details. When a Portamento message is received, the Portamento effect will be turned on or off. Portamento Time controls the speed of the pitch change. Portamento Control specifies the source note number (the previously played note).

RPN LSB, MSB (CC100/101) *, Data Entry (CC06/38) *— Since the function of RPN (Registered Parameter Number) messages is defined in the MIDI specification, this message can be used between devices of different types. The RPN MSB and LSB messages specify the parameter which is to be modified. Data Entry messages can be used to modify the value of that parameter. RPN can be used to adjust Pitch Bend Sensitivity, Master Coarse Tune, and Master Fine Tune. Note: The values modified using RPN messages will not be initialized even if Program Change messages etc. are received to select other sounds.

NRPN LSB, MSB (CC98/99), Data Entry (CC06/38)—NRPN (Non-registered Parameter Number) messages can be used to modify the values of sound parameters unique to a particular device. The NRPN MSB and LSB messages specify the parameter which is to be modified, and then Data Entry messages can be used to modify the value of that parameter.

Since the GS format defines the function of several NRPN messages, GS compatible application programs can use NRPN messages to modify sound data parameters for Vibrato, Cutoff Frequency, Resonance, and Envelope values.

Note: The values modified using NRPN messages will not be initialized even if program change messages etc. are received to select other sounds.

Note: With the factory settings, the VA-76 will ignore NRPN messages. After a GS Reset message is received, NRPN messages will be received. You can also manually turn on Rx NRPN (NRPN Receive Switch), so that NRPN messages will be received.

Aftertouch (Channel Pressure only *) — Aftertouch is a message that conveys the pressure applied to the keyboard after playing a note, so that this information can be used to control various aspects of the sound. There are two types of Aftertouch message: Polyphonic Key Pressure which is transmitted separately for each note, and Channel Aftertouch which is transmitted as one value that affects all notes on the specified MIDI channel.

All Sounds Off— This message turns off all currently-sounding notes.

All Note Off message *--- This message causes a noteoff message to be sent to each note of the specified channel that is currently on. However, if Hold 1 or Sostenuto are on, the sound will continue until these are turned off.

Reset All Controllers *— This message returns controller values (modulation, Pitch Bend, etc.) to their initial settings. The following controller values for the specified channel will be reset to their initial values.

Pitch Bend	0 (center)
Polyphonic Aftertouch	0 (minimum)
Channel Aftertouch	0 (minimum)
Modulation	0 (minimum)
Expression	127 (maximum)
Hold	0 (off)
Portamento	0 (off)
Soft	0 (off)
Sostenuto	0 (off)
RPN	no change
NRPN	no change

Note: Parameter values that were modified using RPN or NRPN will not change even when a Reset All Controller message is received.

Active Sensing—This message is used to check for broken MIDI connections, such as MIDI cables that have been disconnected, or are defective. The VA-76 transmits Active Sensing messages at set intervals. Once an Active Sensing message is received via MIDI IN, Active Sensing monitoring will begin, and if an Active Sensing message fails to arrive for more than 420ms, it is assumed that the cable has been disconnected. If this happens, all currently sounding notes will be turned off, the same procedure will be executed as if a Reset All Controller message was received, and Active Sensing monitoring will stop.

System Exclusive messages

System Exclusive (SysEx) messages are used to control functions which are unique to specific devices.

Although Universal System Exclusive messages can be used even between devices of different manufacturers, most exclusive messages only apply to one type of instrument.

In order to recognize the device for which the data are intended, Roland exclusive messages contain a manufacturer ID, device ID and model ID.

Note: See the separate MIDI booklet for details about the SysEx messages recognized by the VA-76.

Universal System Exclusive— When a GM System On message is received, the VA-76 will be set to the basic GM settings. Also, NRPN and Bank Select messages will no longer be received once GM System On is received. The beginning of song data bearing the GM

logo contains a GM System On message. This means that if you play back the data from the beginning, the sound generator will be automatically initialized to the basic settings.

GS Reset (GS Format System Exclusive)— When GS Reset is received, the VA-76 will be set to the basic GS settings. The beginning of song data bearing the GS logo contains a GS System Reset message. This means that if you play back the data from the beginning, the sound generating device will be automatically initialized to the basic settings.

Master Volume (Universal System Exclusive)— This is an exclusive message common to all newer MIDI devices. It controls the master volume of the entire VA-76

Other System exclusive (SysEx) messages—The VA-76 can receive GS format exclusive messages (model ID 42H) that are common to all GS sound generators.

About MIDI implementation charts


MIDI allows many different types of instruments to be connected, but in some cases there will be messages that cannot be conveyed meaningfully. For example, if you wish to use Aftertouch of an external instrument to control the sound, while the sound generator connected to the keyboard does not receive Aftertouch messages, you will not get the musical result you intend. Only messages that are used by both devices will actually be executed.

The MIDI specification requires that the owner's manual for each MIDI device include a "MIDI Implementation Chart" that shows the types of MIDI messages which are actually transmitted and received by a device. Put the *Transmitted* column of the transmitting device's implementation chart side by side with the *Received* column of the receiving device's implementation chart. Messages which are marked as "0" in both charts can be conveyed successfully. If either chart shows a "X" for a certain type of message, that message cannot be conveyed.

14.2 Preparations for using the MIDI functions

Receiving MIDI data (RX)


To take advantage of the VA-76's sounds while playing on an external keyboard or using a computer or sequencer, you must make the following connections:



Transmitting MIDI data (TX)

To have another instrument sound in response to the notes you play on the VA-76, or to record your music with a computer or external sequencer, you must make the following connections:





Note: Use only dedicated MIDI cables (optional) for establishing the connections.

The how-to's...

Selecting the MIDI mode

Do the following to gain access to the MIDI functions:

- 1. Press the [FUNCTION MENU] button.
- 2. On the display page that appears now, press the [MIDI] field.

The display now looks more or less as follows:



3. Press the [Edit] field.

Working with Macros (this is optional)

The opening "MIDI" page contains five big fields with preset settings that you can select by pressing the corresponding fields. In fact, these fields perform the same function as the Resume fields for User Program 00 (see page 196). All you need to do is press them to restore the default settings for the sections or aspects in question.

Keybrd & Style— This field recalls the factory MIDI settings for the Keyboard (Upper 1/2, Lower 1/2, Vari-Phrase, MEL Int, M.Drums) and Arranger parts (ADrums, ABass, Acc1~6). The most important (and practical) use for this field is to select the default MIDI channels after trying out several possibilities.

Note: This field applies to both reception (RX) and transmission (TX). The VA-76 indeed allows you to set separate TX and RX channels for each part.


Only Song— This field restores the factory settings for the VA-76's Song Composer parts. You may not have noticed it so far, but these are separate parts. Your VA-76 is indeed 32-part multitimbral.

All Parts Local On— See page 201 for details about the meaning of "Local". This parameter allows you to once again establish the connection between all VA-76 parts and the internal tone generator. This can be a big time saver if you don't remember which parts were set to Local "Off".

All Parts Local Off— Does the opposite of the above: it breaks the connections between all VA-76 parts and the internal tone generator.

Factory Resume— This field does all of the above (except Local Off) in one pass.


As soon as you press one of these fields, the number of the currently selected MIDI Set is indicated with an asterisk (*) to signal that the current settings no longer correspond to the written settings. See page 207 for details about the MIDI Sets. MIDI Set [0] behaves exactly like the Free Panel buffer for User Programs: it is a buffer memory where your changes are stored temporarily. The VA-76's ROM chip also contains preset settings for this memory: those are the ones you select by pressing the [Factory Resume] field. See page 196 for a more detailed description. The explanations about the User Programs there are also true of the MIDI Sets and Macro Settings.



What's next?

After performing step (3) above, you will notice four fields in the bottom row of the display.

4. Press one of these fields to select the desired part group or the Utility functions:



- 5. On the first three pages (Keyboard MIDI, Style MIDI, Song MIDI), use the [↑][↓] fields in the left column to select the part whose MIDI parameters you wish to set.
- 6. Press the parameter fields in the "TX" or "RX" column and choose the desired setting with the VALUE [↑][↓] fields at the center of the display.
 You can also use the [TEMPO/DATA] dial.
 TX is short for "transmission" (the data the VA-76 sends), while RX refers to "reception".



14.3 Keyboard MIDI, Style MIDI, Song MIDI

Keyboard parts: [FUNCTION MENU] → [MIDI] field → [Keyboard MIDI] field Style parts: [FUNCTION MENU] → [MIDI] field → [Style MIDI] field Song parts: [FUNCTION MENU] → [MIDI] field → [Song MIDI] field



Seeing that these three pages feature the same parameters, we will discuss them together. Just remember to press the right field.

Part (left column)— This is where you select the part whose MIDI settings you wish to change. The selectable parts are:

Field	d Available parts	
Keyboard MIDI	Upper1, Upper2, Lower1, Lower2, M.Bass, M.Drums, MEL Int, 🜠 , Audio In	
Style MIDI	ADrums, ABass, Acc1-Acc6	
Song MIDI	Part 1~Part 16	

The Song parts are 16 additional parts that are available at all times for MIDI control. Of course, these parts are also used by the Song Composer and the 16-track Sequencer, in which case they also *transmit* data.

Channel (1~16)— Allows you to assign a MIDI receive (RX) or transmit channel (TX).

Note: Unless you have a very good reason to do otherwise, we suggest you always select the same TX (transmit) and receive (RX) channel numbers for a part.

Press the [Tx ON] or [Rx ON] field in the left column to select "Off" if the selected part must not transmit or receive MIDI data.

Shift— (-48~48) This parameter allows you to transpose the received or transmitted note messages before sending them to the VA-76's tone generator (RX) or an external instrument (TX). You could change the pitch of the received MIDI note messages, which may be useful if you are used to playing a song (that is being received via MIDI) in another key than the one the data were programmed in. The maximum possible transposition is four octaves up (48) or down (-48), each step representing a semitone.

Loca

(On, Off – TX only) Set Local to On (default setting) whenever you want the VA-76 to respond to the notes you play on the keyboard. Setting Local to Off means that the part in question no longer controls the internal tone generator. When working with a sequencer

equipped with a Soft Thru (MIDI echo) function — and only if (i) you connect the VA-76's MIDI IN and OUT connectors to the external sequencer or computer, and (ii) use the VA-76 as MIDI master keyboard for sequencing — you may have to set this parameter to Off to avoid that each note is sounded twice (producing an unpleasant sound called MIDI loop). In all other cases, select On.

Note: A setting tantamount to Local Off can be achieved by muting a part (see page 114) and setting the Part Switch (see page 206) to Int.

Limit

(High, Low: C-1~G9, RX only) High and Low allow you to set the note range to be received. If not all note messages on the selected MIDI channel should be received by the selected part, set the range to the desired values. This may be necessary when controlling the VA-76 from a MIDI accordion that sends the chord and bass notes on the same channel.

Note: The Low Limit cannot be set to a higher value than the High Limit (and vice versa).

Note: Some instruments start at C-2 and end at G8 (instead of C-1 and G9). You may have to "add an octave" to the value you see on the screen of your computer or external sequencer.



Filter

Press the [Tx Filter] field to filter outgoing MIDI messages. Press the [Rx Filter] field to prevent the reception of certain MIDI messages.



Here, you can specify for each parameter whether (On) or not (Off) the selected message should be received or transmitted. The MIDI messages you can filter are:

PChng— Program change messages (including Bank Select)

PBend—Pitch Bend messages

Modul-Modulation messages (CC01)

Volume — Volume messages (CC07)

PanPot—Pan(pot) messages (CC10)

Expre— Expression messages (CC11)

Hold—Hold (Sustain, Damper) messages (CC64)

Sostn—Sostenuto messages (CC66)

Soft — Soft messages (CC67)

CC69--- Hold 2.

Revrb—Reverb Send messages (CC91)

Chrus—Chorus Send messages (CC93)

Delay—Delay Send messages (CC94)

CAF— Channel Aftertouch

RPN—Registered parameter number (CC100/101)

NRPN— Non-registered parameter number (CC98/99)

SysEx—SysEx messages (system exclusive)

CC16, CC17-M-Value 1 & 2 settings.

CC32= 0— (RX only) What to do when the received CC32 message equals 0 or is missing. For this parameter, you can select "4" (VA-76), "1", "2", or "3". You cannot filter this Bank Select message.

Note: See "MIDI messages used by the VA-76" on page 197 for details about these MIDI messages.

Press the [+ Back] field to return to the "regular" MIDI parameters.

Tx Eliter page of the Style parts

The Style/Arranger parts only transmit and receive the following MIDI messages, which is why the list of parameters that can be filtered is a lot shorter:





Note that the [NRPN] parameter is only available for the ADrums part – not for the melodic Arranger parts. The NRPN messages are used for "Drum Set Note & Pitch" (see page 175).

Tx/Rx Filter of the VariPhrase part

The VariPhrase part is an altogether different tone generator. That explains why it doesn't respond to CC32 messages and why the two filter pages look a little different:



Tx Filter page

Rx Filter page

See above for an explanation of these parameters. The new or different functions are:

CC16, 17, 18— Correspond to the [Pitch], [Time], and [Formant] sliders respectively (see page 49). CC19— General-purpose message for VariPhrase control.

SYNC— Allows you to specify whether the Vari-Phrase's tempo should run in sync with the internal (INT) or an external (EXT) MIDI Clock signal received from a sequencer, etc.

TX/RX Filter of the Audio in part

We already mentioned that the Audio In part does not transmit or receive note messages because it is used for for amplifying your singing. You can, however, transmit and receive its effects, volume, and PanPot settings for remote control. It follows that the list of parameters that can be filtered is the shortest of all Keyboard parts:




Same parameters for the Rx Filter page

14.4 Utilities MIDI

MIDI Sync RX/TX

[FUNCTION MENU]→ [MIDI] field→ [Utilities MIDI] field→ [Sync] field



Style TX Sync

The Style TX Sync parameters allow you to specify whether or not the VA-76 should send MIDI realtime messages whenever you start the Arranger. Sending MIDI realtime (start, stop, clock) messages has the advantage that you can synchronize external instruments or computers with your VA-76.

Start/Stop— If you activate this option, the VA-76 will only send start or stop messages whenever you start (or stop) Arranger playback. In this case, no Clock messages are sent.

Clock— This option means that the Arranger sends Clock messages (usual synchronization method).

Use the [ON/OFF] fields to specify whether or not these messages should be transmitted.

Song TX Sync

Here are the switches for the transmission of MIDI realtime messages whenever you play back a Song using the VA-76's Song Composer:

Start/Stop/Continue— If you activate this option, the VA-76's Song Composer sends only Start/Stop and Continue messages. *Continue*, by the way, is a message used to signal that playback is not started from the beginning of a Song.

Clock— This option means that the Song Composer sends Clock messages. These are used to specify the tempo.

Song Position Pointer— If you select [ON], the Song Composer sends Song Position Pointer (SPP) messages. These messages are used to signal the current playback position, so that the slaved (synchronized) drum machine, sequencer, etc., automatically jumps to the correct position upon receiving a Song Position Pointer message.

Note: See your sequencer's etc. manual to find out whether it accepts Song Position Pointer messages.

Style RX Sync, Song RX Sync

The Style RX Sync and Song RX Sync parameters are used to specify whether and how the Arranger or Composer should be synchronized to external sequencers or drum machines. The available options are:

Internal— The Arranger or Song Composer will follow its own internal tempo.

Auto— This is a function for remote control of Arranger/Song Composer playback (using a PK-5, for example). If the VA-76 receives a MIDI Start message (FA), it looks out for Clock messages. If those Clock messages are *not* received (a PK-5, for instance, doesn't send them), the VA-76 starts playback using its internal tempo. If those Clock messages (F8) follow the Start message, the VA-76 uses the external tempo. You can, however, go on using the Arranger/Song Composer without MIDI Start/Clock messages, which is not possible when you select MIDI.

MIDI—The Arranger or Song can only be started or stopped with MIDI realtime messages (Start, Stop, Clock) coming from an external clock source.


Remote—The Arranger or Song Composer waits for a start message to start playback at its own tempo. As soon as it receives a stop message, playback will stop.

On/Off

Use these switches to enable (On) or disable (Off) the reception of these messages.

Basic

[FUNCTION MENU]→ [MIDI] field→ [Utilities MIDI] field→ [Basic] field



The Basic Channel is used for several things: to receive and transmit Program Change and Bank Select messages for selecting User Programs, as well as for the reception and transmission of other kinds of messages that are not directly related to a specific MIDI channel but may affect the VA-76's parts (such as the Part Switch function, for example). That doesn't mean that the MIDI channel assigned to the Basic Channel function is of no importance. Only, the messages received on that channel may also apply to other aspects of your VA-76.

TX/RX Channel

(1~16) Use these parameters to assign an RX (receive) or transmit (TX) channel to the Basic Channel function. If you do not want the Basic Channel messages to be received (or transmitted), press the [ON/OFF] field so that it reads [OFF].

Filter

There are three functions for which you can specify whether (On) or not (Off) the corresponding MIDI messages should be received (or transmitted):

PartSwtc— Whenever you mute or un-mute a part on the Mixer pages, your VA-76 sends an NRPN message that describes your action. The VA-76 allows you to keep it from sending that message (or to respond to it whenever it is received from an external instrument). Filtering these messages on the TX side may be useful to keep your external sequencer from recording them — or the receiving GS module from muting the part assigned to that channel.


UsrPrgPC— This parameter is used to filter the transmission (TX) or reception (RX) of program change and bank select messages relative to User Program selection.

MstVolum (**RX only**)— This parameter allows you to enable or disable the reception of Master Volume messages (see page 199) that would change the volume of the entire VA-76.

Lyrics (TX only)— The Lyrics function of your VA-76 is MIDI message used to transmit the words (or lyrics) contained in a Standard MIDI File (as meta-text events). Playing back Standard MIDI Files that contain lyrics data causes the VA-76 to send these data on the Basic Channel – unless you set this filter to [OFF]. Select [ON] if you want to transmit Lyrics data to an LVC-1 Lyrics-to-Video Converter.

Style

[FUNCTION MENU] → [MIDI] field → [Utilities MIDI] field → [Style] field



The Style Channel is a MIDI channel used for receiving and transmitting Program Change and Bank Select messages allowing you to select Styles via MIDI, and volume messages that change the volume of a Style. Note that these two message types can only be filtered individually in the RX column (i.e. you can select whether or not to receive them).

Style selection via MIDI

The MIDI address of a Music Style consists of three elements: a Program Change number, a CC00 number, and a CC32 number. CC00 and CC32 are Bank Select messages. The values assigned to CC00 and CC32 define the Style, whereas the Program Change number defines the pattern (Intro, Ending, etc.). Sending only a Program Change number will select another pattern of the currently active Style. Only when the Program Change number is preceded by two values (for CC00 and CC32) will the VA-76 select another Music Style.

Note: Whenever you select another Style on your VA-76, it transmits a CC00-CC32-PC cluster on the Style channel.

Channel

(1~16) Allows you to assign a MIDI channel to the Style select feature. If you don't want the Style Channel messages to be received (or transmitted), press the [ON/OFF] field in question so that it reads [OFF].

Filter (RX only)


You can filter two types of messages:

StlVolum— Volume messages relating to the Music Styles. Select Off if the VA-76 must not receive them.

StylePC— Program Change and Bank Select messages for Style selection. Select Off if the VA-76 must not select other Styles or patterns in response to these incoming messages.

NTA: Note-to-Arranger

[FUNCTION MENU] → [MIDI] field → [Utilities MIDI] field → [NTA] field



NTA notes are only received from an external MIDI instrument. Whatever you play in the chord recognition area of the keyboard to feed the Arranger is automatically converted to the corresponding MIDI note numbers. Unlike other arranger instruments, your VA-76 is blessed with the capability of sending the note numbers of all Arranger parts, so that you could use the internal or your own Styles to quickly record a song with band backing on an external sequencer. As every single note of the Music Style is recorded, there is no need to transmit the note messages used to feed the Arranger (the NTA notes).

1 Channel Rx/2 Channel Rx

(1~16) The NTA notes can be received on two MIDI channels, so that you could control the VA-76's Arranger using a MIDIfied accordion or any other instrument capable of sending accompaniment data (or data used to control the accompaniment) on two channels (such as organs with bass pedals, for example). Use the [♠][♣] fields in the right column to set the desired value. Either channel can be switched off using its [ON/OFF] field.

Note: You cannot assign the same MIDI channel to 1 & 2 Channl Rx.

Shif

(-48~48) This parameter allows you to transpose the received note messages before sending them to the Arranger. The maximum possible transposition is four octaves up (48) or down (-48), each step representing a semitone.

1 Ch Limit, 2 Ch Limit (C-1~G9)


High and Low allow you to set the note range to be received. If not all note messages on the selected MIDI channel should be received by the NTA "part", set the range to the desired values.

Note: The Low Limit cannot be set to a higher value than the High Limit (and vice versa).

Note: Some instruments start at C-2 and end at G8 (instead of C-1 and G9). You may have to "add an octave" to the value you see on the screen of your computer or external sequencer.

MIDI parameters (Param)

 $[FUNCTION \ MENU] \rightarrow [MIDI] \ field \rightarrow [Utilities \ MIDI] \ field \rightarrow [Param] \ field$



This page contains several parameters that are not related to one other (the other MIDI pages always concentrate on one aspect).

Tx Octave

(Absolute, Relative) The TX Octave parameter can be set to **Absolute** or **Relative**. It applies to Tone selection. You may have noticed that whenever you assign a bass sound to the Upper1 part in SPLIT mode, the notes are transposed in such a way that you can play a meaningful bass line using the Upper1 part. *Relative* means that this internal (and automatic) transposition is translated into note numbers, so that playing a C4 (note number 60) may actually result in note number

36 being used and sent to the MIDI OUT port. This, of course, depends on the Tone you assign to the Upperl part.

In Absolute mode, however, the MIDI note number sent to the MIDI OUT port will be the one assigned to the key you press (e.g. note number 60). The advantage of Absolute is that you can play a bass line using the VA-76's Upper1 part and double it with a trumpet of an external instrument.

PartSwtc

The Part Switch parameter allows you determine what happens when you mute a part (see "Muting parts" on page 114). One thing you know will happen is that the part in question no longer sounds when you play on the keyboard – even though its field on the KEY-BOARD MODE page (accessible via the [OTHER] button) is displayed in white, or even though the Arranger is playing. What you do not see, however, is whether a muted part still sends MIDI data. PartSwtc allows you to specify whether or not a muted part should go on sending MIDI messages:

Int—A muted part can no longer be played via the VA-76's keyboard or Arranger but continues to send MIDI messages to MIDI OUT.

Int+Mid— A muted part can no longer be played via the VA-76's keyboard or Arranger and no longer sends MIDI messages.

Selecting *Int* and muting a part thus has the same effect as selecting Local Off (see page 201). Choose whichever is more convenient in a given situation: part mute can be saved to a User Program, while Local and Part Switch can only be saved to a MIDI Set.

Rx Velocity, Tx Velocity

Your VA-76 is equipped with a velocity-sensitive keyboard and a tone generator capable of responding to velocity messages. Velocity messages are an important element for musical expression because the way you strike a key results in a loud/bright or soft/round note, telling the listener something about your feelings.

In some cases, however, it may be wiser not to convey the velocity aspect of music making to emulate instruments that are not velocity sensitive (such as organs, for example). The VA-76 allows you to activate or deactivate the transmission and/or reception of velocity messages. Use the associated [ON/OFF] fields to switch the reception (RX) or transmission (TX) of velocity messages on or off.

If you select [OFF], you have to tell your VA-76 which velocity value to use instead of the continuous flux normally received (in this case, the word *receive* applies to both incoming MIDI data and the messages received from the VA-76's keyboard). That is what Rx Velocity and Tx Velocity are for. The value you set will

be used for all notes received via MIDI IN (RX) or sent to MIDI OUT (TX) – but only when the corresponding velocity filter is set to [OFF].

SoftThru for Local

This function actually overrides the MIDI specifications, according to which the MIDI OUTput of an instrument only sends messages generated on the instrument itself (e.g. your VA-76). When you set Soft Thru to On, all notes received on the NTA channel beyond the NTA's High and Low Limits are re-transmitted to the MIDI OUTput. Use the Soft Thru feature for a digital piano or other keyboard instrument without split function.

When you set Soft Thru to On, The VA-76 sends a Local message (CC122) with a value "0" to the digital piano, so that the piano's sound source no longer responds to the notes you play on its keyboard. Seeing that the VA-76 echoes back all notes that are not used to trigger the Arranger, you hear what you play on the piano — except in the zone set apart for the Arranger. (This requires that you also connect the VA-76's MIDI OUTput to the digital piano's MIDI INput.)

When you set Soft Thru back to Off, the VA-76 sends a Local message with a value "127", thereby switching the piano's Local function back on.

14.5 MIDI Sets

MIDI Sets are memories for the settings you make in MIDI mode. The VA-76 has eight MIDI Set memories on board that you can use to change your MIDI configuration. You can also save your MIDI Sets to disk and load them whenever necessary. Furthermore, you can link a MIDI Set to a User Program (see page 131), and specify which MIDI Set should be loaded each time you switch on the VA-76 (see below). If you need to reset some or all MIDI parameters to their default values, loading the *Macro Settings* (see page 200) may be a wiser choice than selecting a MIDI Set.


Saving a MIDI Set

- 1. Press the [FUNCTION MENU] button.
- 2. On the display page that appears now, press the [MIDI] field.

The display now looks more or less as follows:



3. Press the [Memorize] field.



- 4. Press the field that corresponds to the MIDI Set that should contain your MIDI settings ([1] \sim [8]).
- 5. Press the [EXECUTE] field.

The display confirms that the settings have been written to the selected memory and returns to the page of step (1) on page 127.

Selecting a MIDI Set

- 1. See steps (1) and (2) under "Saving a MIDI Set".
- 2. Press a [1]~[8] field that corresponds to the MIDI Set you need.

You can also select MIDI Set [0] so as to work with the (temporary) setting in that memory. See also page 200.

The Master page looks as follows when you work with a MIDI Set:



MIDI Set selection at power-on

Whenever you switch on the VA-76, it automatically selects MIDI Set 0. But maybe you prefer to be "operational" right away. In that case, tell the VA-76 which MIDI Set it should recall whenever you switch it on:

- 1. Press the [FUNCTION MENU] button.
- 2. Press the [Global Parameter] field on the Function
- 3. Press the [Startup] field in the bottom row of the display.



- 4. Press the [Startup MIDI Set] field so that it is displayed in white.
- 5. Use $[\uparrow] [\downarrow]$ or the [TEMPO/DATA] dial to select the MIDI Set to be recalled.

If you don't want a MIDI Set to be recalled, select "Off".

6. Press [EXIT] to return to the Master page.

Saving MIDI Sets to disk

After programming 8 MIDI Sets, you may find that you need a few more and that you have to make room for the new MIDI Sets. To do so without losing the previously saved MIDI Sets, you must save the "old" set to disk. Even if you do not program more than 8 MIDI Sets, it is a good idea to make a backup copy of your MIDI Sets in case someone else starts fiddling around with your settings.

- 1. Press the [FUNCTION MENU] button.
- 2. Press the [Disk] field.

3. On the display page that appears now, press the [Save] field in the bottom row and the [Midi Set] field in the left column.



Before saving a MIDI Set to disk, you should name it. Press the [Name] field and choose a name that tells you something about the contents. (You can only program a "File Name", because the names of the MIDI Sets are never displayed.) See page 68 for how to enter the name.

- 4. Insert a formatted Zip or floppy disk into the desired drive.
- 5. Select the drive you want to save the data to by pressing the [ZIP] or [FLOPPY] icon.
- 6. Press [EXECUTE] to save your MIDI Set to disk. Remember that your VA-76 is multitasking, so that you can leave this page as soon as the VA-76 starts saving the MIDI Set to disk.
- 7. Press [EXIT] to return to the Master page.

 Note: When saving, the term "Set" is used to refer to all 8

 MIDI Set memories. In others words, when you save "a"


 MIDI Set to disk, you save in fact the contents of all eight

 MIDI Set memories. Loading, on the other hand can be carried out selectively.

Loading a MIDI Set from disk

As stated in the above note, you are free to load just one MIDI Set container of a given MIDI Set on the selected disk. Feel free to only load MIDI Set container 3 from a given MIDI Set if you do not need the other 7 settings of that Set.

- 1. Press the [FUNCTION MENU] button.
- 2. Press the [Disk] field.
- 3. On the display page that appears now, press the [Load] field in the bottom row and the [Midi Set] field in the left column.



- 4. Select the drive you want to load the data from by pressing the [ZIP] or [FLOPPY] icon.
- 5. Press the field that corresponds to the MIDI Set whose data you wish to (partially) load.

 If the name of the desired MIDI Set is not displayed, use the [←][←] fields to select another group of eight MIDI Set names.
- 6. Use the "Disk" [↑] [♦] fields to select the MIDI Set container to be loaded from disk.

You can also select ALL, which means that all eight containers of the selected MIDI Set will be loaded. In that case, you cannot select the destination memory (see below).


7. Use the "To Int" [♠] [♣] fields to select the internal MIDI Set memory you wish to load the selected settings to.

You can select "To Int"= 1, =2, =3..., =8. Note that this is only possible if you did not select "ALL" for "Disk".

- 8. Press the [EXECUTE] field to load the MIDI Set data.
- 9. Press [EXIT] to return to the Master page.
 The possibility to selectively load MIDI Set containers allows you to compile "Best Of" MIDI settings by loading them to different internal MIDI Set memories. After loading your 8 favorite MIDI settings, use the Save function to save the "Best Of" MIDI Set to disk.

15. Disk functions

This is where you will find functions and parameters relating to saving, loading, deleting files, and to formatting new disks or disks previously used on other instruments or devices. The word "disk" refers to both floppy and Zip disks.



15.1 Autoload

The VA-76 provides an Autoload function for the following file types: VariPhrase Sets, Songs, MIDI Sets, and User Programs. This function (semi)automatically loads files called "AUTOLOAD" from the inserted Zip disk (it is not available for floppy disks).

A VariPhrase Set is the most likely candidate for this function. Taking advantage of the Autoload function for the remaining file types (except Songs) is a bit hazardous, because doing so will overwrite the corresponding settings in the VA-76's internal memory.

Note that a Zip disk can only contain one "AUTO-LOAD" file for each type (VariPhrase Set, Song, MIDI Set, User Program Set). So be sure to work with the file(s) you need most often.

Here is what you need to do:

1. Save the data that should be loaded at power-on to a Zip disk (see page 211).

Use the correct save function: Save User Program Set, Save MIDI Set, Save Phrase Set, Save Song.

The name of the file in question (the VariPhrase Set, for example) must be "AUTOLOAD". If the file already resides on the Zip disk, use "Rename" on page 216 to change its name.

- 2. Insert the Zip disk into the appropriate drive.
- 3. Switch off the VA-76.
- 4. Hold down the [DATA] button while switching the VA-76 back on until the message "Autoload Function Activated" appears.

The VA-76 boots and all files called "AUTOLOAD" (one per type) will be loaded automatically.

15.2 Disk Load (loading data from disk)

Load Style/copy Style

[FUNCTION MENU]→ [Disk] field→ [Load] field→ [Style] field



This page allows you to load Styles from disk or to copy a ROM Style to the Style RAM memory (Disk User).

(source)— These fields allow you to select the internal memory (ROM Styles) or a disk. Press [INT A/B] to copy a ROM Style (i.e. one of the 128 factory Styles) to the Disk User memory. Press [FLOPPY] or [ZIP] to load a Style from disk. When you press [INT A/B], the Style names in the Music Style window are preceded by a number (A11~B88). When you select a disk, only the Style name is displayed.

Selection—Press the field of the Style you wish to load (or copy). If the desired Style is not displayed, use the [♣][♣] fields to scroll through the list of available Styles. You can also use the [TEMPO/DATA] dial and —for ROM Styles—the BANK/NUMBER pad.

Execute— Press this field to confirm your settings and load the data.

Load Song

[FUNCTION MENU]→ [Disk] field→ [Load] field→ [Song] field



This function allows you to load a song from disk, thereby overwriting the song currently in the VA-76's Song RAM memory.

Press one of these fields to select the drive that contains the data you wish to load.

Selection— Press the field of the song you wish to load. If the desired song is not displayed, use the [←][→] fields to scroll through the list of available songs. You can also use the [TEMPO/DATA] dial.

Execute— Press this field to confirm your settings and load the data.

Load User Prg

[FUNCTION MENU] → [Disk] field → [Load] field → [User Prq] field



This where you can load User Program Sets. These are groups of 128 User Programs whose main use is for archiving your internal settings. Loading User Program Sets from disk can be selective, i.e. feel free to load only one User Program, or comprehensive (the contents of all 128 User Programs).

Press one of these fields to select the drive that contains the data you wish to load.

Selection—Press the field of the User Program Set whose data you wish to load. If the desired name is not displayed, use the [←][→] fields to scroll through the list. You can also use the [TEMPO/DATA] dial.

Disk (1~128, All)— Use these two [↑][↓] fields to select a specific User Program from the selected User Program Set on disk, or select "ALL" to load all User Programs of that Set.

To Int (1~128, ALL)— Use these two [↑] [↓] fields to specify the User Program memory that should contain the selected data. If you select ALL for *Disk*, ALL is the only option here. Furthermore, ALL cannot be selected when you selected a specific User Program for *Disk*.

Note: By selecting ALL, you not only load the User Program Set data but also the Disk Link settings it contains. These will replace the internal settings, so be sure to save the current Disk Link settings to disk before loading an entire User Program Set. Use "Save User Program Set" on page 211 to do so.

Execute— Press this field to confirm your settings and load the data.

Load MIDI Set

[FUNCTION MENU] \rightarrow [Disk] field \rightarrow [Load] field \rightarrow [Midi Set] field



Loading MIDI Sets from disk can be selective, i.e. feel free to load only one MIDI Set of a "MIDI Set-Set" (consisting of eight MIDI Sets). See page 208 for details. If you select ALL for *Disk*, all 8 MIDI Set memories will be overwritten.

Load Phrase

[FUNCTION MENU] \rightarrow [Disk] field \rightarrow [Load] field \rightarrow [F4 Phrase] field



There are three Load functions for VariPhrases: you can load one VariPhrase, a VariPhrase Set, or .WAV or AIFF file. See page 69 for details. Remember that a VariPhrase Set replaces all 16 VariPhrases in the User memory. Do not forget to save edited phrases before using this function.

15.3 Disk Save (saving data to disk)

In this manual and while designing the VA-76, we tried to make a clear distinction between saving and writing/memorizing data. The terms write/Memorize are used to describe actions that cause certain settings to be saved to an internal memory. Save, on the other hand refers to the act of copying internal memory settings to disk.

Save Style

[FUNCTION MENU] → [Disk] field → [Save] field → [Style] field



Use this function to save a newly programmed or edited User Style to disk. You should do so as frequently as possible.

These fields allow you to select the disk you want to save the data to.

Execute— Press [EXECUTE] to confirm your settings and save the data to disk.

Press the [Name] field if you want to name your Style



Style Name—This is the "internal" name of a Music Style. This name appears on the Master page, the Music Style selection page, etc. It is usually the "meaningful" name. Press this field and enter the Style Name. See page 68 for details.

File Name— This is the name the Music Style has on disk and by which the VA-76 recognizes it (its "address"). If you change this name of a Music Style, the Disk Link function no longer finds the Style. Press this field and enter the desired name. See page 68 and page 170 for details.

Save Song

[FUNCTION MENU]→ [Disk] field→ [Save] field→ [Song] field



This page allows you to save the Song that is currently in the VA-76's Song RAM memory to disk. See page 67 for details.

Save User Program Set

[FUNCTION MENU]→ [Disk] field→ [Save] field→ [User Prg] field



This function allows you to save all 128 User Programs as a set. This also includes the Scale Tuning memories, One Touch assignments, Preferred Tone, and Disk Link Style assignments. The Size value indicates the capacity required to save the User Program Set to disk, while Free Disk Area tells you something about the remaining disk capacity.

These fields allow you to select the disk you want to save the data to.

[Name]—Press this field to name your User Program Set.

File Name—See above for details.

Execute— Press [EXECUTE] to confirm your settings and save the data to disk.

Save MIDI Set


[FUNCTION MENU]→ [Disk] field→ [Save] field→ [Midi Set] field



This function allows you to save all 8 MIDI Sets as a set. The Size value indicates the capacity required to save the "MIDI Set-Set" to disk, while Free Disk tells you something about the remaining disk capacity. See also "Saving MIDI Sets to disk" on page 207.

Save Phrase

[FUNCTION MENU]→ [Disk] field→ [Save] field→ [🛂 Phrase] field



There are two options on this page: you can either save the currently selected User phrase, or the contents of all 16 phrases in the VariPhrase User memory. Press the field that corresponds to the desired option. See page 76 for how to save a single phrase to disk.

1. To save a VariPhrase *Set*, press the [Phrase Set] field.



To save the Set under the default name ("PHRASE S_XX") you can [EXECUTE] right away.

2. Insert a disk into the appropriate drive and select that drive using the [FLOPPY] or [ZIP] field.

It is most unlikely that you will be able to save a Vari-Phrase Set (16 phrases!) to floppy disk. Using a Zip disk is therefore a much better idea. If not all data can be saved to the selected disk, the display responds with:



If this message is displayed, none of your User phrases have been saved to disk (and if they had, they would be unreadable). Do not switch off the VA-76 at this point: eject the disk, and insert another one. If it is not formatted, you will be given the opportunity to do so. Note: A single VariPhrase file or a VariPhrase Set cannot be divided over several floppy disks.

3. Press the [Name] field.



- 4. Enter the name of your VariPhrase Set (8 characters). See page 68 for details.
- 5. Press [EXECUTE] to confirm your settings and save the data to disk.

15.4 Delete

 $[\mathsf{FUNCTION}\ \mathsf{MENU}] {\longrightarrow} [\mathsf{Disk}]\ \mathsf{field} {\longrightarrow}\ [\mathsf{Delete}]\ \mathsf{field}$



The Delete function allows you to erase the selected file, which may be necessary if the "Disk Full" message is displayed when you try to save a file to disk. Be careful to select the right file type using the fields in the left column before pressing [EXECUTE]. Also note that User Program and MIDI Sets contain 128 or 8 different settings, which means that you may lose a lot more than originally intended.

Deleting a VariPhrase Set means that a Set with up to 16 phrases disappears. If in doubt about the selected VariPhrase file type, press the [+ Back] field to return to the following selection page:



Then press [Single Phrase] or [Phrase Set] to select the file type you want to delete.

Here's what the Delete functions allow you to throw away:

File Type (field)	What's deleted
Style	One Style on the selected disk.
Song	One song on the selected disk.
User Prg	A User Program Set that contains 128 User Programs (plus the Disk Link assignments, 3 Scale Tuning memories, plus other settings).
Midi Set	A MIDI Set Set of 8 MIDI Set memories.
₹ Phrase	Depends on whether you selected [Single Phrase] or [Phrase Set] (see above).

These fields allow you to select the disk that contains the file to be deleted.


Selection— Press the field of the file you wish to delete. If the desired file is not displayed, use the [←][→] fields to scroll through the list. You can also use the [TEMPO/DATA] dial.

Execute— Check again whether you really selected the file you wanted to delete, then press [EXECUTE] to delete the file.

Note: The Delete operation cannot be undone.

15.5 Disk Utility


- 1. Press the [FUNCTION MENU] button.
- 2. Press the [Disk] field.
- 3. Press the [Utility] field.
 The display now looks as follows:



4. Press the field that corresponds to the desired option.

Format

[FUNCTION MENU]→ [Disk] field→ [Utility] field→ [Format]



This function allows you to format the disk in the selected drive. It would be a good idea to also format floppy disks formatted for MS-DOS® because that speeds up disk access. All other disks must be formatted by the VA-76 to be usable. To this end, the VA-76 provides two formatting options. See "Formatting a disk" on page 132 for details.

Copy functions

You can copy from Zip to floppy (and vice versa), or from one floppy disk to another floppy disk, which requires changing disks. Let's have a look at a few hands-on examples:


Copying an entire floppy disk to another floppy

WARNING— Copying files from a disk means that the VA-76's Style RAM and Song RAM memories are erased. If you haven't yet saved your last song to disk, you should do so before proceeding. See page 67 for details. For safety reasons, it would be a good idea to also save your User VariPhrases to disk before proceeding (see page 76).

1. On the Disk Utility menu, press the [Copy] field. The display now responds with a warning regarding copyright legislation.



- 2. Press the [Proceed] field.
- 3. On the page that appears now, press the [Disk] field in the left column.



- **4.** Press the [From FDD→ To FDD] field. The display now responds with *Insert Source Protected Disk*.
- 5. Slide the protect tab of the disk you wish to copy in the Protect position and insert the floppy into the floppy disk drive.

Note: It will be impossible to copy the desired floppy disk if you do not write-protect it. In that case, the message "Source Disk unprotected" appears and the display returns to the following page.



6. Press the [EXECUTE] field to start the copy operation.

Note: Press the [ABORT] field if you do not want to copy the floppy disk after all.

The display now displays an animated clock to signal that some (or all) data are being copied to the VA-76's RAM memory.



Once the first chunk of data has been loaded, following message appears:



7. Remove the original floppy (the SOURCE disk) from the drive and insert the one (DESTINATION) you wish to copy the data to.

Note: Be careful to set the PROTECT tab of the Destination disk to the WRITE (or OFF) position.

Note: You need to use the same disk type as the one of the Source disk. If that was a 2DD disk, insert a 2DD disk. If the Source disk is a 2HD disk, use a 2HD disk.

8. Press [EXECUTE] again.

This time, the data in the VA-76's RAM memory are copied (saved) to the destination disk. If all data were copied in one go, the "Function complete" message appears and you're done. If only part of the data was loaded from the source disk, the "Insert SOURCE Pro-

tected Floppy Disk" message appears again. In that case, go back to step (5) and continue until the message "OK Function Complete" is displayed.


9. Press [EXIT] to jump to the Master page (see page 24).

There is no function for copying entire Zip disks. Use the [ALL FILES] field to select all files of the selected type for copies towards a Zip disk. You could, however, copy Zip disks on a PC compatible computer (using Iomega's Copy Machine™ utility, for example). If in doubt, try to stick to the VA-76's Disk Copy functions. They may take a little longer, but at least, they allow you to put all songs on a Song Zip, all Styles on a Style Zip, etc.

Copying single files from floopy to floopy (example, copying songs)

WARNING— Copying files from a disk means that the VA-76's Style RAM and Song RAM memories are erased. If you haven't yet saved your last song to disk, you should do so before proceeding. See page 67 for details. For safety reasons, it would be a good idea to also save your User VariPhrases to disk before proceeding (see page 76).

- 1. On the Disk Utility menu, press the [Copy] field. The display now responds with a warning regarding copyright legislation.
- 2. Press the [Proceed] field.
- 3. Insert the floppy disk that contains data you wish to copy into the (appropriate) drive.
- 4. Press the field that corresponds to the file type you wish to copy. To copy songs, for example, press the [Song] field:



- 5. Press the [FDD] field below the "From" message ("copy from floppy").
- 6. Press the [FDD] field below the "To" message.
- 7. Press the fields of all songs you wish to copy.

 Press the [ALL FILES] field to select all songs on the inserted floppy disk. Use the [♣][♣] fields or the [TEMPO/DATA] dial to select other groups of 8 files.

 Note: Pressing a white field again will "unmark" the song file in question. Files whose fields are blue are not copied.
- **8.** Press the [EXECUTE] field to start the copy operation.

You are now asked whether it is OK to overwrite all files on the Destination disk that have the same file names as the Songs you are about to copy.



9. Press the [YES] field if it is OK to overwrite any song with the same file name on the destination disk. Press the [NO] field if files on the Source disk that have the same name as existing files on the Destination disk should not be copied (only files with "original" names will be copied in that case). Press [EXIT] to abort the Copy operation.

If you press [YES] or [NO], the VA-76 copies the first chunk of data to its RAM memory, after which the display asks you to insert the destination disk.



- 10. Remove the original floppy (the SOURCE disk) from the drive and insert the one (DESTINATION) you wish to copy the data to.
- 11. Press [EXECUTE] again.

The song file(s) is/are now transferred from the VA-76's internal memory to the Destination floppy disk.

Copying from Zip to floppy disk (example: copying Styles)

You can also copy Styles (and other file types) from a Zip disk to a floppy (and vice versa). It is also possible, to copy from one Zip disk in the internal drive to another Zip disk.

WARNING— Copying files from a disk means that the VA-76's Style RAM and Song RAM memories are erased. If you haven't yet saved your last song to disk, you should do so before proceeding. See page 67 for details. For safety reasons, it would be a good idea to also save your User VariPhrases to disk before proceeding (see page 76).

- 1. On the Disk Utility menu, press the [Copy] field.
- 2. Press the [Proceed] field.
- 3. Insert the Zip disk you wish to copy into the Zip drive.

- 4. Insert the floppy disk that should contain the copied data into the floppy drive.
- 5. Press the field that corresponds to the file type you wish to copy. To copy Styles, for example, press the [Style] field:



- 6. Press the [ZIP] field below the "From" message ("copy from Zip").
- 7. Press the [FDD] field below the "To" message.
- 8. Press the fields of all Styles you wish to copy. See also step (7) in the right column on page 215.

 Note: To copy from floppy to Zip, press the [FDD] field below "From" and the [ZIP] field below "To". To copy from Zip to Zip, press the [ZIP] fields below "From" and "To".

Copying other file types

You can also copy other file types, either individually or as a bunch (with the [ALL FILES] field):

- · Styles (Style),
- · User Program Sets (User Prg),
- · MIDI Sets (Midi Set),
- Single VariPhrases or VariPhrase Sets (see below).
 With the exception of the fact that you need to select
 the desired file type using the fields in the left column,
 the procedure is exactly the same as for copying songs.
 Please see above for details.



Copying VariPhrases or VariPhrase Sets works exactly like copying other file types. There is one thing we'd like to point out, though: after pressing the [
Phrase] field, you need to select whether to copy single VariPhrases (one, several, or all) or VariPhrase Sets. Press the appropriate field:



Rename


The Rename functions allow you to modify the name of a file on the disk you inserted into the VA-76's disk drive. Please be aware that the selected file cannot be assigned the same name as that of another file on the same disk.

If you try to assign an already existing name to another file on the same disk, the display will respond with a message telling you that this is impossible:



Press the [REPLACE] field to overwrite the other file, or the [EXIT] field if you wish to assign another name to the currently selected file.

- 1. Press the [FUNCTION MENU] button.
- 2. Press the [Disk] field.
- 3. Press the [Utility] field.
- 4. Press the [Rename] field.



- 5. Select the drive that contains the file to be renamed by pressing the [ZIP] or [FLOPPY] field.
- 6. Press the field of the file type you wish to rename (left column):

Styles (Style), User Program Sets (User Prg), MIDI Sets (Midi Set), Single VariPhrases or VariPhrase Sets.

7. Press the field of the file you wish to rename. Use the [←][→] fields or the [TEMPO/DATA] dial to select other groups of 8 files.

8. Press the [PROCEED] field.



For Styles, and Songs, you can enter two names: the File Name and the Style/Song Name. The first is the file's "address" on the disk, while the second sometimes appears on the VA-76's display (see also page 68). For the remaining files, only the File Name can be set.

- **9.** Press the [EXECUTE] field to save the file under the new name.
- 10. Press [EXIT] to return to the Master page.

16. Specifications

	VA-76 V-Arranger Keyboard
Keyboard (1999)	76 keys, weighted synthesizer action, velocity-sensitive, Aftertouch
Controllers	Tempo/Data dial, assignable PAD buttons x2, D Beam Controller, Bender/Modulation Lever, Touch Controller (Ribbon Controller), Master Volume knob, Keyboard/Accomp Balance knob, M-FX knob (Multi-effect control)
PCM	128-voice polyphonic, GM2/GS compatible, 32 multitimbral parts 3,646 sounds (48 MB worth of PCM samples) 116 Drum Sets incl. oriental Drum Sets
VariPhrase	4 Phrase lines, realtime change of Formant, Pitch and Time Stretch, 48 Factory Phrases (16 MB), 16 User phrases (max. 8 MB in RAM)
Digital effects	Reverb (8 types), Chorus (8 types), Delay (10 types), Parametric EQ, M-FX (DSP, 89 types)
Arranger (automatic	128 Music Styles in ROM, 64 Disk Link Styles from Zip or floppy disk, Disk User Style (instant access to one Style on Zip/floppy disk), 16 Acoustic Styles, Style Orchestrator & Morphing
	8-track User Styles Composer, SMF-to-Style Converter
Memories	128 User Programs, 4 programmable One Touch memories for each Style 5 Super Tones memories for instant Tone access (with programmable User level)
Display 1	Backlit VGA Touch Screen (LCD), new graphic user interface with animated icons
Navigation	Virtual Band (interactive Easy Routing), automatic and/or via button Song and Style navigation system on Zip
Sequencer.	Realtime SMF Player (with Minus-One function), Easy 2-track Recorder, 16-track sequencer with extensive editing functions, Song Header Post Edit, Lyrics (edit & display)
Data storage.	Zip drive (IDE/ATAPI), floppy disk drive (2DD/2HD), realtime load from Zip & FDD, File types managed: Styles, Song SMF, User Program, MIDI Sets, VariPhrases
Connections	Output 1 (L/mono, R), Output 2 (L/R), VariPhrase Sampling Input & Gain, Sustain, Foot Pedal (expression), Foot Switch, Foot Controller (FC-7), Phones
Power supply	100V~240 (universal)
Dimensions	1267 (W) x 150 (H) x 407 (D) mm
Weight 1997	19kg
Accessories	Zip disk with a series of useful supplementary files (see the booklet included with the Zip disk for its contents), metal music stand, Owner's Manual
Options -	PK-5 Dynamic MIDI Pedal, FC-7 Foot Controller, MSA/MSD/MSE series floppy disks (Roland & third-party), RH-25/50 Headphones, DP-2 Pedal switch, DP-6 Pedal switch (piano type), BOSS FS-5U Foot Switch, EV-5 Expression pedal, BOSS FV-300L Foot Volume/Expression Pedal,
	KC-100/300/500 Keyboard Amplifiers

Specifications subject to change without prior notice.

Iomega® is a registered trademark. Zip™ is a trademark of Iomega Corporation.

All other trademarks mentioned in this manual are the property of the respective companies.

17. M-FX Types & controllable parameters

Below please find a list of the M-FX Types available on the VA-76. As stated on page 123, each type provides two parameters that can be controlled via the M-Value 1 and M-Value 2 sliders in the display. Parameters indicated with an asterisk (*) can also be controlled via an optional footswitch. See "Rotary S/F" on page 191 for details. The "o" indicate the assignment to the [M-FX] knob.

TONE COLOR (filter type)				
01 Enhancer	M-Val 1°	Sens	0~127	
	M-Val 2	Mix	0-127	
The Enhancer control	ls the overtone	structure o	of the high frequen-	

cies, adding sparkle and tightness to the sound.

02 Humanizer	M-Val 1°	Vowel	a/i/u/e/o
	M-Val 2	Level	0~127

This adds a vowel character to the sound, making it similar to a human voice.

GUITAR AMPLIFIER EFFECTS

Here is what the abbreviations mean:

Bitin:

single-unit type amp 2-Stk: large double-stack amp 3-Stk: large triple-stack amp

03 Overdrv1 (Small) M-Val 1° Drive M-Val 2 Pan

0~127 L63~0~R63

Overdrive creates a soft distortion similar to that produced by tube amplifiers. Several types of overdrive are available (see the names between brackets).

04 Overdrv2 (Bitin)	M-Val 1°	Drive	0~127
0.0000000	M-Val 2	Pan	L63 ~0~ R63
05 Overdrv3 (2-Stk)	M-Val 1°	Drive	0-127
•	M-Val 2	Pan	L63~0~R63
06 Overdrv4 (3-Stk)	M-Val 1°	Drive	0~127
, ,	M-Val 2	Pan	L63~0~R63
07 Distort1 (Small)	M-Val 1°	Drive	0~127
	M-Val 2	Pan	L63~0~R63

This effect produces a more intense distortion than Overdrive.

08 Distort2 (Bitin)	M-Val 1° M-Val 2	Drive Pan	0~127 L63~0~R63
09 Distort3 (2-Stk)	M-Val 1°	Drive	0~127
10 Distort4 (3-Stk)	M-Val 2 M-Val 1°	Pan Drive	L63-0-R63 0-127
IO DISCOTCH (3-31K)	M-Val 2	Dilve	163~0~R63

MODULATION EFFECTS (EXCEPT CHORUS)

11 Phaser	M-Val 1°	Manual	100Hz~8.0kHz
	M-Val 2	Rate	0.05~10.0 Hz

A phaser adds a phase-shifted sound to the original sound, producing a twisting modulation that creates spaciousness and depth.

12 Auto Wah	M-Val 1°	Manuai	0~127
	M-Val 2	Rate	0.05~10.0 Hz

The Auto Wah cyclically controls a filter to create cyclic change in timbre.

13 Rotary	*M-Val 1°	Speed	Slow/Fast
	M-Val 2	Level	0~127

The Rotary effect simulates the sound of a classic rotary speaker. The unique type of modulation characteristic of these speakers is of a striking realism. This effect is most suitable for electric organ.

14 StFlangr	M-Val 1°	Rate	0.05-10.0 Hz
•	MAVal 2	Feedback	-98% -+98%

This is a stereo Flanger. It produces a metallic resonance that rises and falls like a jet airplane taking off or landing.

15 SpFlangr	M-Val 1	Feedback	-98% ~+ 9 8%	
	M-Val 2°	Step Rate	0.05~10.0 Hz	

A Step Flanger is an effect in which the Flanger pitch changes in audible steps.

16 Tremolo1 (Tri)	M-Vai 1°	Mod Rate	0.05~10.0 Hz
(Triangular wave)	M-Val 2	Mod Depth	0~127

Tremolo cyclically modulates the volume to add tremolo effect to the

M-Val 1°	Mod Rate	0.05~10.0 Hz
M-Val 2	Mod Depth	0~127
M-Val 1°	Mod Rate	0.05-10.0 Hz
M-Val 2	Mod Depth	0~127
M-Val 1°	Mod Rate	0.05~10.0 Hz
M-Val 2	Mod Depth	0~127
M-Val 1°	Mod Rate	0.05~10.0 Hz
M-Val 2	Mod Depth	0-127
M-Val 1°	Mod Rate	0.05~10.0 Hz
M-Val 2	Mod Depth	0~127
	M-Val 2 M-Val 1° M-Val 1° M-Val 2 M-Val 2 M-Val 2 M-Val 1° M-Val 2 M-Val 1°	M-Val 2 Mod Depth M-Val 1° Mod Rate

sound.			
22 AutoPan2 (Sgr)	M-Val 1°	Mod Rate	0.05~10.0 Hz
• • • •	M-Val 2	Mod Depth	0~127
23 AutoPan3 (Sin)	M-Val 1°	Mod Rate	0.05-10.0 Hz
	M-Val 2	Mod Depth	0~127
24 AutoPan4 (Saw1)	M-Val 1°	Mod Rate	0.05-10.0 Hz
	M-Val 2	Mod Depth	0-127
25 AutoPan5 (Saw2)	M-Val 1°	Mod Rate	0.05~10.0 Hz
•	M-Val 2	Mod Depth	0-127

DYNAMICS EFFECTS			
26 Compress	M-Val 1°	Pan	L63~0~R63
	M-Val 2	Level	0~127

A compressor reduces signal peaks and boosts low levels, smoothing out unevenness in volume.

27 Limiter	M-Val 1°	Pan	L63 ~0~ R63
	M-Val 2	Level	0-127

A limiter prevents the volume from exceeding a certain level (Threshold) without boosting low levels.

CHOKUS	EFFECIS
"D" means	dry (no ef

ffect), while "E" means effect (no unprocessed signal); "0" refers to the level

28 Hexa Cho M-Val 1 Rate 0.05~10.0 Hz M-Val 2° Balance D>0E~D0<E

Hexa Chorus uses a six-phase chorus (six layers of chorused sound) to give richness and spatial spread to the sound.

29 Trem Cho M-Val 1° Trem. Rate 0.05~10.0 Hz M-Val 2 Balance D>0E~D0<E

Tremolo Chorus is a chorus effect with added Tremolo (cyclic modulation of the volume).

30 StChorus M-Val 1° Rate 0.05~10.0 Hz M-Val 2 Balance D>0E~D0<E

This is a stereo chorus

31 Space D M-Val 1 Rate 0.05-10.0 Hz M-Val 2° Balance D>0E-D0<E

Space-D is a multiple chorus that applies two-phase modulation in stereo. It gives no impression of modulation, but produces a transparent chorus effect (the perfect "stereo maker").

32 3DChorus M-Val 1 Cho. Rate 0.05-10.0 Hz M-Val 2° Balance D>0E~D0<E

This applies a 3D effect to the chorus sound. The chorus sound will be positioned 90 degrees left and 90 degrees right.

DELAY & REVERB EFFECTS

"D" means dry (no effect), while "E" means only effect (no unprocessed signal).

33 St Delay M-Val 1 Feedback -98% ~+98% M-Val 2° Ralance D-0F-DO-F

Delay is an effect that allows you repeat the input signal. By increasing the Feedback value (M-Val 1), you can control the number of repetitions. Negative values (-) invert the phase of the repeated signals.

34 Mod Dly M-Val 1 Mod Rate 0.05-10.0 Hz M-Val 2° Balance D>0E-D0<E

This effect adds modulation to the delayed sound, producing an effect similar to a Flanger.

35 3Tap Dly M-Val 1 Feedback -98% -+98% M-Val 2° Balance D>0F~D0<F

The Triple Tap Delay produces three delay sounds; center, left and right.

36 4Tap Dly M-Val 1 Feedback -98% -+98% M-Val 2° Balance D>0E~D0<E

The Quadruple Tap Delay has four delays.

37 TmCtrDly M-Vai 1° Dly Time 200m-990m/1sec -98% ~+98% M-Val 2 Feedback

This effect allows you to use M-Val 1 to control the delay time and pitch in realtime. Lengthening the delay time will lower the pitch, and shortening it will raise the pitch.

38 Reverb	M-Val 1 M-Val 2°	Time Balance	0~127 D>0E~D0 <e< th=""></e<>			
39 GteRevNr	M-Val 1°	Balance	D>0E~D0 <e< td=""></e<>			
(Normal nated reverb)	M-Val 2	Level	0~127			

Gate Reverb is a special type of reverb in which the reverberant sound is suddenly cut off (and does not gradually decrease).

40 GteRevRv	M-Val 1°	Balance	D>0E~D0 <e< th=""></e<>
(Reversed gated reverb)	M-Val 2	Level	0~127
41 GteRevS1	M-Val 1°	Balance	D>0E~D0 <e< td=""></e<>
(Sweep 1)	M-Val 2	Level	0~127
The reverberant sound m	oves from r	ight to left.	
42 GteRevS2	M-Val 1°	Balance	D>0E~D0 <e< td=""></e<>
(Sweep 2)	M-Val 2	0~127	
The reverberant sound m	oves from I	eft to right.	
43 3D Delay	M-Val 1	Feedback	-98%+98%
•	MAN/al 29	Rajanco	D-NE_DO-E

This applies a 3D effect to the delay sound. The delay sound will be positioned 90 degrees left and 90 degrees right.

PITCH SHIFT (TRANSPOSITION) EFFECTS

44 2PitchSh M-Val 1 Coarse1 -24 -0~ +12 M-Val 2° Coarse2 -24 ~0~ +12

A Pitch Shifter shifts the pitch of the original sound. This 2-voice effect has two pitch shifters, and can add two pitch shifted sounds to the original sound.

45 Fb P.Shf M-Val 1° Coarse1 -24 -0~ +12 M-Val 2 Feedback -98% -+98%

OTHER EFFECTS

46 3D Auto M-Val 1° Speed 0.05~10.0 Hz M-Val 2 Effect on/off Turn

The 3D Auto effect moves the location of the sound. This effect is derived from Roland's 3-D Sound Space technology (RSS).

M-Val 1° Azimuth 47 3DManual 180/L168~0~R168 M-Val 2 Level 0~127

Allows you to manually move the sound in a 3-D sound space.

48 Lo-Fi 1 M-Val 1° Balance D>0E~D0<E M-Val 2 Pan 163 ~0~ R63

Lo-Fi 1 is an effect that intentionally degrades the sound quality.

49 Lo-Fi 2 M-Val 1° R.Detune 0~127 M-Val 2 Balance D>0E~D0<E

Lo-Fi 2 also degrades the sound quality and adds some noise to further "worsen" the quality.

OD Pan 50 OD→ Chors M-Val 1 L63 ~0~ R63 M-Val 2° ChoBalance D>0F~D0cF

This effect connects an Overdrive and a Chorus in series.

M-Val 1 OD Pan L63 ~0~ R63 51 OD→ Flger M-Val 2° FLBalance D>0E-D0<E

This effect connects an Overdrive and a Flanger in series.

M-Val 1 OD Pan L63 ~0~ R63 52 OD→ Delay M-Val 2° DiyBalance D>0E-D0<E

This effect connects an Overdrive and a Delay in series.

M-Val 1 DS Pan L63 ~0~ R63 53 DS→ Chors M-Val 2° ChoBalance D>0E~D0<E

This effect connects a Distortion effect and a Chorus in series.

M-Val 1 DS Pan 163 ~0~ R63 54 DS→ Figer M-Val 2° FLBalance D>0E~D0<E

This effect connects a Distortion effect and a Flanger in series.

55 DS→ Delay	M-Val 1	DS Pan	L63 ~0~ R63
This effect connects a Di	M-Val 2° istortion effe		D>0E~D0 <e ny in series.</e
56 EH→ Chors	M-Vai 1	EH Sens	0-127
	M-Val 2°		D>0E~D0 <e< td=""></e<>
This effect connects an I	inhancer and	a Chorus in	series.
57 EH→ Flger	M-Val 1 M-Val 2°	EH Sens FLBalance	0~127 D>0E~D0 <e< td=""></e<>
This effect connects an f			
58 EH→ Delay	M-Val 1	EH Sens	0-127
	M-Val 2°	•	D>0E~D0 <e< td=""></e<>
This effect connects an I			
59 Cho→ Dly	M-Val 1 M-Val 2°		D>0E-D0 <e D>0E-D0<e< td=""></e<></e
This effect connects a Ch		•	
60 FL→ Delay	M-Val 1	FL Fb	-98% ~+98%
•	M-Val 2°	•	D>0E~D0 <e< td=""></e<>
This effect connects a Fla	anger and a		
61 Cho→ Flgr	M-Val 1° M-Val 2	ChoBalance FLBalance	D>0E~D0 <e D>0E~D0<e< td=""></e<></e
This effect connects a Ch			
62 RotarMit	M-Val 1°	OD Drive	0~127
	*M-Val 2	RT Speed	Slow/Fast
This connects Overdrive effects in series.	(OD), 3-band	l equalizer (E	Q), and Rotary (RT)
63 GTRMIt1A	M-Val 1°	OD Drive	0~127
(OD Amp Small)	M-Val 2	Dly Mix	0~127
Guitar Multi 1 algorithm rus, and Delay effects in below) so choose your T	series. Differ	ent amp type	
64 GTRMIt1B	M-Val 1°	OD Drive	0-127
(OD Amp BitIn)	M-Val 2	Dly Mix	0-127
65 GTRMIt1C	M-Val 1°	OD Drive	0~127
(OD Amp 2-Stk)	M-Val 2	Dly Mix	0~127
66 GTRMIt1D	M-Val 1° M-Val 2	OD Drive Dly Mix	0~127 0~127
(OD Amp 3-Stk) 67 GTRMIt2A	M-Val 1	OD Drive	0~127
(OD Amp Smail)	M-Val 2°	CF Mix	0~127
Guitar Multi 2 algorithm	s provide Co	mpressor, Ov	erdrive (OD),
Equalizer, and Chorus or	Flanger (CF)	effects conn	ected in series.
68 GTRMit2B	M-Val 1	OD Drive	0~127
(OD Amp Bitin)	M-Val 2°	CF Mix	0~127
69 GTRMIt2C	M-Val 1	OD Drive	0-127
(OD Amp 2-Stk)	M-Val 2°	CF Mix	0~127
70 GTRMIt2D	M-Val 1	OD Drive	0~127
(OD Amp 3-Stk)	M-Val 2°	CF Mix	0~127
71 GTRMit3A (OD Amp Small)	M-Val 1° M-Val 2	Wah Man OD Drive	0~127 0~127
Guitar Multi 3 connects V		th) Overdrise	
and Delay effects in serie		nij, Overanive	. (<i>OD)</i> , CHOIGS (CF),
72 GTRMI+RR	M-Val 1°	Wah Man	0~127
72 GTRMIt3B (OD Amp Bitin)	M-Val 1° M-Val 2	Wah Man OD Drive	0~127 0~127

72 CTD1442C	44.1-1-0	184-1-18-	0.437
73 GTRMIt3C	M-Val 1°	Wah Man	0-127
(OD Amp 2-Stk)	M-Val 2	OD Drive	0~127
74 GTRMIt3D	M-Val 1°	Wah Man	0~127
(OD Amp 3-Stk)	M-Val 2	OD Drive	0-127
75 ClGtMlt1	M-Val 1°	CF Mix	0-127
	M-Val 2	Dly Mix	0-127
Clean Guitar Multi 1 co and Delay (Dly) effects		essor, Equaliz	er, Chorus (CF),
76 ClGtMlt2	M-Val 1°	AW Man	0~127
Dly Time value 60m	M-Val 2	Dly Mix	0-127
Clean Guitar Multi 2 pro Delay (Dly) effects conn			ializer, Chorus, and
77 BassMlti	M-Val 1°	OD Drive	0~127
	M-Val 2	CF Mix	0~127
Bass Multi provides Con rus (CF) effects connect		rdrive (OD), E	qualizer, and Cho-
78 RhodMlt1	M-Val 1	TP ModRT	0.05~6.40 Hz
(Pan)	M-Val 2°	TP ModDep	0~127
Rhodes Multi 1 provide effects connected in ser		naser, Chorus	, and Pan (TP)
79 RhodMlt2	M-Val 1	TP ModRT	0.05~6.40 Hz
(Tremolo)	M-Val 2°	TP ModDep	0~127
Rhodes Multi 2 provide effects connected in ser		naser, Chorus,	and Tremolo (TP)
	M-Val 1	RM ModFro	0-127
80 KeybMiti			
80 KeybMlti (Tremolo)	M-Val 2	RMBalance	D>0E~D0 <e< td=""></e<>

EFFECTS CONNECTE	D IN PARA	ALLEL	
81 Cho/Dly	M-Val 1	ChoBalance	D>0E-D0 <e< th=""></e<>
	M-Val 2°	DiyBalance	D>0E-D0 <e< td=""></e<>
This effect connects a Cho	orus and a D	elay in parall	el.
82 FL/Delay	M-Val 1	FLBalance	D>0E~D0 <e< td=""></e<>
	M-Val 2°	DlyBalance	D>0E-D0 <e< td=""></e<>
This effect connects a Fla	nger and a D	Pelay in paral	lel.
83 Cho/Flgr	M-Val 1	ChoBalance	D>0E~D0 <e< td=""></e<>
_	M-Val 2°	FLBalance	D>0E-D0 <e< td=""></e<>
This effect connects a Fla	nger and a C	horus in para	ıllel.
84 OD1/OD2	M-Val 1	OD1 Drive	0~127
	M-Val 2°	OD2 Drive	0~127
85 OD/Rotar	M-Val 1	OD Drive	0~127
	*M-Val 2°	RTRT Speed	Slow/Fast
86 OD/Phase	M-Val 1	OD Drive	0~127
	M-Val 2°	PH Rate	0.05~10.0 Hz
87 OD/AtWah	M-Val 1	OD Drive	0-127
(Overdrive + Auto Wah)	M-Val 2°	AW Man	0~127
88 PH/Rotar	M-Val 1	PH Rate	0.05~10.0 Hz
	*M-Val 2°	RT Speed	Slow/Fast
89 PH/AtWah	M-Val 1	PH Rate	0.05~10.0 Hz
	M-Val 2°	AW Man	0~127

18. Reference

18.1 Tones

VÁ	-76	Tones	(Tor	ie Map 4)																		
GBN A11	Var 1 2 3 4	PC CC00 1 0 1 1 1 2 1 8 1 9	4 P 4 U 4 M 4 P	iano 1 JprightPiano Aild Piano iano 1w Aild Piano w		14 15 16	8 8 8	39 126 127 0	4 4	Name Pulse Clav E.Piano 1 Honkytonk	GBN A32	Var 1 2 3 4	18 18 18 18	0 1 2 3 4	4 4 4 4	Name Organ 2 Jazz Organ E.Organ 16+2 Jazz Organ 2 Jazz Organ 3	GBN	Var 11 12 13 14 15	PC 26 26 26 26 26	50 51 52 126 127	4 4 4 4 4	Name V AcGuitar 3 V AcGtrHrm v Steel.Gt Picked Bass Syn Brass 2
	5 6 7 8 9 10 11 12 13	1 16 1 24 1 25 1 26 1 27 1 45 1 46 1 47 1 126 1 127	4 F 4 F 4 F 4 F 4 S 4 S	iuropean Pf iiano + Str. iiano + Str. iiano + Str. iiano + Choir1 iiano + Choir2 iiano + Choir2 iiano Ac. Piano it. AcPiano 1 iiano 2 icao Piano 1	A22 A23	2 3 4 1 2	9 9 9 10 10 10	1 47 126 127 0 126 127	4 4 4 4	Pop Celesta CelestaBell Detuned EP1 Elec Org 1 Glockenspiel E.Piano 2 Elec Org 2 Music Box		5 6 7 8 9 10 11 12 13 14	18 18 18 18 18 18 18 18	5 6 7 8 9 32 33 34 35 126	4 4 4 4 4 4	Jazz Organ 4 Jazz Organ 5 Jazz Organ 6 Chorus Or.2 Octave Organ Perc. Organ 2 Perc. Organ 3 Perc. Organ 4 Slap Bass 1	A43	1 2 3 4 5 6 7	27 27 27 27 27 27 27 27 27	0 1 8 48 49 50 126 127	4 4 4 4 4 4 4	Jazz Gt. Mellow Gt. Pedal Steel v Jazz Gt. v Mellow Gt. v Pedal Steel Picked Bass Syn Brass 3 Clean Gt.
A12	1 2 3 4 5 6	2 0 2 1 2 2 2 8 2 9 2 16 2 126 2 127	4 F 4 F 4 F 4 C	Piano 2 Pop Piano Rock Plano Piano 2 Rock Piano Piano 2 Rock Piano W Dance Piano Piano 2 Acou Piano2	A24	2 3 4 1 2 3	11 12 12 12 12	1 8 126 127 0 1 8 9	4 4 4 4 4 4	Music Box 2 St.Music Box Steel Gt. Elec Org 3 Vibraphone Pop Vibe. Vibraphone w Vibraphones Steel Gt.	A33	1 2 3 4 5 6	19 19 19 19 19 19 19	0 8 16 17 18 24	4 4 4 4 4 4	Harpsi 2 Organ 3 Rotary Org. Rotary Org.S Rock Organ 1 Rock Organ 2 Rotary Org.F L-Organ	A	1 2 3 4 5 6 7 8	28 28 28 28 28 28 28 28 28 28	1 2 3 4 5 8 9 16 17	4 4 4 4 4 4 4	Clean Half Open Hard 1 Open Hard 2 IC Clean Gt. Atk CleanGt. Chorus Gt. IC Chorus Gt TC FrontPick TC Rear Pick
A13	1 2 3 4 5 6	3 0 3 1 3 2 3 8 3 47 3 126 3 127	4 4 4 4 4 4	Piano 3 G-Rhodes 1 EG-Rhodes 2 Piano 3 w stackedPiano Piano 2 Acou Piano 3	A25	5 1 2 3 4 5	12 13 13 13 13 13	0 8 16 17 24 126 127	4 4 4 4 4	Marimba Marimba w Barafon Baraton 2 Log drum 12-str.Gt Pipe Org 1	A34	7 8 1 2 3 4 5 6	19 19 20 20 20 20 20 20 20	126 127 0 8 16 24 32 33 126	4 4 4 4 4 4 4	Slap Bass 1 Harpsi 3 Church Org.1 Church Org.2 Church Org.3 Organ Flute Trem.Flute Theater Org. Slap Bass 2		10 11 12 13 14 15 16 17 18 19	28 28 28 28 28 28 28 28 28 28 28	18 19 20 21 22 23 24 25 48 49	4 4 4 4 4 4 4	TC Clean ff TC Clean 2: LP Rear Pick LP Rear 2 LP RearAtack Mid Tone GTR Chung Ruan Chung Ruan 2 v Clean Gt. v Clean Half
A15	1 2 3 1 2 3 4	4 8 4 126 4 127 5 0 5 8 5 9 5 10 5 16	4 4 4 4 4 4	Honky-tonk 2 Honky-tonk Elec Piano 1 E.Piano 1 St.Soft EP Cho. E.Piano SilentRhodes FM+SA EP	A26	2 3 1 2	14 15 15 15	0 8 126 127 0 8	4 4 4 4 4	Xylophone Xylophone w Funk Gt. Pipe Org 2 Tubular-bell Church Bell Carillon	A35	7 1 2 3 4	20 21 21 21 21 21 21	0 8 16 126 127	4 4 4 4 4	Clavi 1 Reed Organ Wind Organ Puff Organ Slap Bass 2 Clavi 2 Accordion Fr		20 21 22 23 24 25 26 27	28 28 28 28 28 28 28 28	50 51 52 53 54 55 56 57	4 4 4 4 4	v OpenHard1 v OpenHard2 v JC CleanGt v AtkCleanGt v Chorus Gt. v JC ChorusGt v TC FrntPick v TC RearPk
	5 6 7 8 9 10 11	5 17 5 24 5 25 5 26 5 44 5 45 5 46 5 47	4 4 4 4 4	Dist E.Piano Wurly Hard Rhodes MellowRhodes PhaseRhodes SA EPiano DynoRhodes1 DynoRhodes1	A28	3 4 5 6		10 16 126 127 0 1 2 8	4 4 4 4 4	Church Bell2 Tubularbellw Muted Gt. Pipe Org 3 Santur Santur 2 Santur 3 Gimbalom		1 2 3 4 5 6 7 8	22 22 22 22 22 22 22 22 22	8 9 16 24 25 47 126 127	4 4 4 4 4 4	Accordion It Dist. Accord Cho. Accord Hard Accord Soft Accord It Muset Slap Bass 2 Clavi 3	Ã45	28 29 30 31 32 33	28 28 28 28 28 28 28 29	58 59 60 61 126 127	4 4 4 4 4	v TC Cin ff v IP Rear Pk v IP Rear 2 v IP Rear Atk Fretless Bs 5yn Brass 4 Muted Gt. Muted Dis Gt
A16	13 14 1 2 3 4 5	5 126 5 127 6 0 6 1 6 8 6 9 6 10 6 16	4 4 4 4 4 4	Piano 1 Elec Piano2 E.Piano 2 E.Piano 3 Detuned EP 2 Detuned EP 3 EP Legend St.FM EP	A31	4 5 6 7 8	16 16 16 16 16 17	16 17 24 126 127	4 4 4 4 4	Zither 1 Zither 2 Dulcimer Slap Bass 1 Accordion Organ 1 Organ 101	A37	1 2 3 4 5	23 23 23 23 23 23 23	0 1 8 9 126 127	4 4 4 4 4	Harmonica Harmonica 2 B.Harp Basic B.Harp Suppl Slap Bass 2 Celesta 1 Bandoneon		2 3 4 5 6 7 8	29 29 29 29 29 29 29	2 8 16 24 48 49 50	4 4 4 4 4 4	TC Muted Gt. Funk Pop Funk Gt.2 Jazz Man v Muted Gt. v Muted Gt. v TC MutedGt v Funk Pop
A17	6 7 8 9 10	6 24 6 32 6 47 5 126 6 127 7 0 7 1	4 4 4 4	Hard FM EP EP Phase Stack Epiano Piano 2 Elec Piano3 Harpsichord Harpsichord2		2 3 4 5 6 7 8 9	17 17 17 17 17 17 17	2 3 4 5 6 7 8 9	4 4 4 4 4	Ful Organ 1 Ful Organ 2 Ful Organ 3 Ful Organ 4 Ful Organ 5 Ful Organ 6 Trem. Organ Organ 0	Ā41	1 4	24 24 24 24 25 25 25		4 4 4 4 4	Bandoneon 2 Bandoneon 3 Fingered Bs Celesta 2 Nylon-str.Gt Ukulele Nylon Gt.o	Ã46	10 11 12 1 2 3	29 29 29 30 30 30 30	52 126 127 0 1 2 3	4 4 4 4 4	v Funk Gt.2 Acoustic Bs Syn Bass 1 Overdrive Gt Overdrive 2 Overdrive 3 More Drive
william	2 3 4 5 6 7 8	7 2 7 8 7 16 7 24 7 32 7 126 7 127	4 4 4 4 4	Harpsichord3 Coupled Hps. Harpsi.w Harpsi.o Synth Harpsi Piano 2 Elec Piano4		10 11 12 13 14 15 16 17	17 17 17 17 17 17 17	10 11 12 16 17 18 19 24	4 4 4 4 4 4	Ful Organ 7 Ful Organ 8 Ful Organ 9 60's Organ 1 60's Organ 2 60's Organ 3 Farf Organ Cheese Organ		3 4 5 6 7 8 9	25 25 25 25 25 25 25 25	32 40 48 49 50 51 52	4 4 4 4 4 4			4 5 7 8 9 10	30	4 5 8 9 10 11 12 48	4 4 4 4 4	Guitar Pinch Attack Drive LP OverDrvGt LP OverDrv: LP Half Drv LP Half Drv2 LP Chorus v Overdry Gt
A18	1 2 3 4 5 6 7 8 9 10 11 12	8 0 8 1 8 2 8 8 8 16 8 17 8 24 8 32 8 33 8 35 8 36 8 37 8 38	4 4 4 4 4 4 4 4	Clav. C Clav. 2 Atk Clav. 1 Atk Clav. 2 Comp Clav. Reso Clav. Phase Clav Clav. 0 Analog Clav. JP8 Clav. 1 JP8 Clav. 2 SynRingClav. SynDistClav. JP8000 Clav.		18 19 20 21 22 23 24 25 26 27 28 29 30	17 17 17 17 17 17 17 17 17 17	25 26 27 28 29 30 31 32 33 40 48 126 127	4 4 4 4 4 4 4 4 4	D-50 Organ JUNO Organ Hybrid Organ V5 Organ Digi Church JX8 Organ FM Organ 70's E.Organ Even Bar Organ Bass Sth Organ Slap Bass 1 Harpsi 1	A42	11 12 1 2 3 4 5 6 7 8 9	25 26 26 26 26 26 26 26 26 26 26 26	0 8 9 10 16 17 18 32 33 48	4 4 4 4 4 4 4 4	MandolinTrem Steel Gt.2 Steel + Body V AcGuitar 1	A47	12 13 14 15 16 17 18 19 20	30 30 30 30 30 30	49 50 51 52 53 54 55 126 127 0 1		v Overdrive2 v Overdrive3 v MoreDrive v LP OvbrvGt v LP HalfDrv v LP HalfDrv v LP Chorus Choir Aahs Syn Bass 2 DistortionGt Dist. Gt2: Dazed Guitar

GBN Var PC CC00 CC32 Name 3 31 3 4 Distortion: 4 31 4 4 Dist. Fast: 5 31 5 4 Attack Dist 6 31 8 4 Feedback Gt. 7 31 9 4 Feedback Gt. 8 31 16 4 Power Guitar 9 31 17 4 Power Gt. 10 31 18 4 5th Dist.	GBN Var PC CC00 CC32 Name 2 39 2 4 CS Bass 3 39 3 4 JP-4 Bass 4 39 4 4 JP-8 Bass 5 39 5 4 PS Bass 6 39 6 4 JPMC Bass 7 39 8 4 Acid Bass 8 39 9 4 TB303 Bass 9 39 10 4 Tekno Bass	GBN Var PC CC00 CC32 Name A64	GBN Var PC CC00 CC32 Name 5 52 5 4 Hybrid Str.2 6 6 52 6 4 DistStrings 7 52 7 4 JUNOFullStr. 8 52 8 4 Air Strings 9 52 9 4 Akt Syn Str. 10 52 10 4 StraightStr. 11 52 125 4 Tombone 12 52 127 4 Pizzicato
11 31 24 4 Rock Rhythm 12 31 25 4 Rock Rhythm2 13 31 26 4 Dist Rtm GTR 14 31 48 4 v Dist Rtm GTR 15 31 49 4 v Dazed Gtr 16 31 50 4 v FeedbackGt 17 31 51 4 v FeedbackGt 18 31 52 4 v Power Gtr 19 31 53 4 v Power Gtr 20 31 54 4 v Sth Dist. 21 31 55 4 v RockRhythm 22 31 56 4 vRockRhythm2 23 31 126 4 Choir Ashs 24 31 127 4 Syn Bass 3	10 39 11 4 TB303 Bass 2 11 39 12 4 Kicked TB303 12 39 13 4 TB303 Saw Bs 13 39 14 4 Rubber303 Bs 14 39 15 4 Reso 303 Bs 15 39 16 4 Reso 5H Bass 16 39 17 4 TB303 Sqr Bs 17 39 18 4 TB303 Sqr Bs 18 39 19 4 Clavi Bass 19 39 20 4 Hammer 20 39 21 4 Jungle Bass 21 39 22 4 Square Bass 22 39 23 4 Square Bass 22 39 23 4 Square Bass 23 39 24 4 Arpeggio Bs	4 45 10 4 SuspenseStr2 5 45 126 4 Organ 2 6 45 127 4 Doctor Solo A66 46 0 4 PizzicatoStr 1 46 1 4 Vcs&Cbs Pizz 2 46 2 4 Chamber Pizz 3 46 3 4 Solo Pizz. 5 46 16 4 Solo Pizz. 5 46 16 4 Solo Pizz. 6 46 17 4 StringsSpic. 7 46 126 4 Organ 2 8 46 127 4 School Daze	A75 53 0 4 Choir Aahs 1 53 8 4 St.Choir Aahs 2 53 9 4 Melted Choir 3 53 10 4 Church Choir 4 53 11 4 Boys Choir 1 5 53 12 4 Boys Choir 2 6 53 13 4 St.BoysChoir 7 53 14 4 Rich Choir 8 53 16 4 Choir Hahs 9 53 24 4 Chorus Aahs 10 53 32 4 Chorus Aahs 11 53 33 4 Male Aah+Str 12 53 48 4 V.Choir Aahs
A48 32 0 4 Gt.Harmonics 1 32 8 4 Gt.Feedback 2 32 9 4 Gt.Feedback 3 32 16 4 Ac.Gt.Harmon 4 32 24 4 E.Bass Harm 5 32 48 4 V.Gt.Feedbk 6 32 49 4 V.Gt.Feedbk 7 32 50 4 V.Ac.Gt.Harmon 8 32 51 4 V.E.Bass Harm 9 32 126 4 Choir Aahs 10 32 127 4 Syn Bass 4	24 39 32 4 Hit&Saw Bass 25 39 33 4 Ring Bass 26 39 34 4 AtkSineBass 27 39 35 4 OB sine Bass 28 39 36 4 Auxiliary Bs 29 39 40 4 3035qDistBs 30 39 41 4 3035qDistBs 32 39 42 4 3035qDistBs 32 39 43 4 3035qrBsBs 33 39 44 TeeBee 34 39 126 4 Organ 1 35 39 127 4 Warm Bell	A67	13 53 49 4 V Melted Choir 14 53 50 4 V Church Chr 15 53 51 4 V Chorr Hahs 16 53 52 4 V ChorrusAshs 17 53 53 4 V ChorrusAshs 18 53 54 4 V MaleAsh-Str 19 53 126 4 Trombone 20 53 127 4 Violin 1 A76 54 0 4 Voice Oohs 1 54 1 4 Chorus Oohs 2 54 2 4 Voice Oohs 2
A51 33 0 4 Acoustic Bs. 1 33 1 4 Rockabilly 2 33 8 4 Wild A.Bass 3 33 9 4 Atk. A.Bass 4 33 16 4 Bass + OHH 5 33 17 4 Bass + Ride 6 33 45 4 AcBass 55 7 33 46 4 AcBass 88Pro 8 33 47 4 AcBass 88Pro 8 33 47 4 AcBass 88 9 33 48 4 V Guitaron 10 33 49 4 VAcoustic Bs. 11 33 50 4 v World A.Bs	A58	A71	3 54 3 4 Chorus Oohs2 4 54 4 0ohsCodeMaj7 5 54 5 4 OohsCodeMaj7 5 54 5 4 OohsCodeMaj7 7 54 8 4 Voice Dahs 8 54 9 4 IzVoice Dat 10 54 11 4 IzVoice Bap 10 54 11 4 IzVoice Thum 11 54 12 4 IzVoice Thum 12 54 16 4 VoiceLah Fem 13 54 17 4 ChorusLahFem 14 54 18 4 VoiceLah Fem 15 54 19 4 ChorusLahFem 16 54 20 4 VoiceLan Fem 17 54 21 4 ChorusLahFem
A52 34 0 4 Fingered Bs. 1 34 1 4 Fingered Bs. 2 34 2 4 Jazz Bass 3 34 3 4 Jazz Bass 2 4 34 4 Rock Bass 5 34 5 4 Heart Bass 6 34 6 4 AttackFinger 7 34 7 4 Finger Slap 8 34 8 4 ChoruslazzBs 9 34 16 4 F.BassHarm. 10 34 48 V BabyBass	14 40 14 4 Syn Beil Bs 15 40 15 4 Odd Bass 16 40 16 4 RubberBass 2 17 40 17 4 SH101 Bass 1 18 40 18 4 SH101 Bass 2 19 40 19 4 SH101 Bass 3 21 40 21 4 SH101 Bass 3 21 40 21 4 SH101 Bass 3 22 40 22 4 House Bass 23 40 23 4 KG Bass 24 40 24 4 Sync Bass 25 40 25 4 MG 5th Bass 26 40 26 4 RND Bass 27 40 27 4 WowMG Bass	12 49 12 4 Strings-Horn 13 49 13 4 Str.+Flute 14 49 14 4 Choir Str. 2 15 49 15 4 Choir Str. 2 16 49 16 4 St. Strings 17 49 17 4 St. Strings 18 49 18 4 St. Strings 19 49 19 4 Orchestra 3 20 49 20 4 Orchestra 4 21 49 24 Velo Strings 22 49 32 4 Oct Strings 23 49 33 4 Oct Strings 24 49 34 Cot Strings 25 49 40 4 60s Strings	18 54 22 4 VoiceAah Fem 19 54 23 4 VoiceAah Fem 20 54 24 4 Fem Lah&Lan 21 54 32 4 VoiceWah Mal 22 54 33 4 ChorusWah Mal 24 54 35 4 ChorusWah Mal 25 54 36 4 VoiceWoh Mal 25 54 36 4 VoiceOoh Mal 27 54 40 4 Humming 28 54 48 4 VoiceOohs 29 54 49 4 VoiceOohs
11 34 126 4 SlowStrings 12 34 127 4 Harmo Pan A53 35 0 4 Picked Bass 1 35 1 4 Picked Bass 2 35 2 4 Picked Bass 3 35 3 4 Picked Bass 4 35 4 Double Pick 5 35 8 4 Muted PickBs 6 35 16 4 P.Bass/Harm. 7 35 126 4 Strings 8 35 127 4 Chorale A54 36 0 4 Fretless Bs.	28 40 28 4 Bubble Bass 29 40 29 4 Attack Pulse 30 40 30 4 Sync Bass 2 31 40 31 4 Pulse Mix Bs 32 40 32 4 MG Dist Bass 33 40 33 4 Seq Bass 2 34 40 34 4 3rd Bass 35 40 35 4 MG Oct Bass 36 40 36 4 SlowEnvBass 37 40 37 4 Mild Bass 38 40 38 4 DistEnvBass 39 40 39 4 MG LightBass 39 40 39 4 MG LightBass 40 40 40 40 51stSymBass	26 49 126 4 Trombone 27 49 127 4 Str Sect 1 A72 50 0 4 Slow Strings 1 50 1 4 SlowStrings2 2 50 2 4 SlowStrings3 3 50 8 4 Legato Str. 4 50 9 4 Warm Strings 5 50 110 4 SI.Slow Str. 6 50 111 4 SI.Slow Str. 7 50 12 4 SI.Slow Str. 7 50 12 4 SI.Slow Str. 8 50 13 4 SI.Slow Str. 9 50 126 4 Trombone	32 54 52 4 v Voice Dahs 33 54 53 4 v JzVoice Dahs 34 54 54 4 v JzVoice Bap 35 54 55 4 v JzVoice Dow 36 54 56 4 v JzVoice Dow 36 54 56 4 v JzVox Thum 37 54 126 4 Trombone 38 54 127 4 Violin 2 A77 55 0 4 SymVox 1 55 1 4 SymVox 2 2 55 2 4 SymVox 3 3 55 8 4 SymVox 3 4 55 9 4 SymVox 3
1 36 1 4 Fretless Bs2 2 36 2 4 Fretless Bs3 3 36 3 4 Fretless Bs4 4 36 4 4 Syn Fretless 5 36 5 4 Mr.Smooth 6 36 8 4 Wood+FlessBs 7 36 126 4 SynStrings3 8 36 127 4 Glasses ASS 37 0 4 Slap Bas 1 1 37 1 4 Slap Pop 2 37 8 4 Reso Slap	40 40 41 4 Distyniass 41 40 41 4 Rise Bass 42 40 42 4 Cyber Bass 43 40 45 4 Lightsyniass 45 40 47 4 101 Bass 46 40 126 4 Organ 1 47 40 127 4 Funny Vox A61 41 0 4 Violin : 1 41 1 4 Violin Atk : 2 41 8 4 Slow Violin 3 3 41 126 4 Organ 2	10 50 127 4 5tr Sect 2 A73 51 0 4 Syn.Strings1 1 51 1 4 OB Strings 2 51 2 4 StackStrings 3 51 3 4 JP Strings 4 51 4 4 Chorus Str. 5 51 8 4 Syn.Strings3 6 51 9 4 Syn.Strings3 7 51 10 4 Syn.Strings6 8 51 11 4 Syn.Strings6 8 51 11 4 Syn.Strings7 9 51 12 4 Loff Strings 10 51 16 4 High Strings	5 55 10 4 Syn.Voice 2 6 55 16 4 V7330 Choir 7 55 17 4 Vinyl Choir 8 55 18 4 JX8P Vox 9 55 19 4 Analog Voice 10 55 126 4 Alto Sax 11 55 127 4 Cello 1 A7B 56 0 4 OrchestraHit 1 56 1 4 Bass Hit 2 56 2 4 6th Hit 3 56 3 4 Euro Hit
3 37 9 4 Unison Slap 4 37 126 4 SynStrings3 5 37 127 4 Soundtrack A56 38 0 4 Slap Bass 2 1 38 1 4 Slap Bass 3 2 38 8 4 FM Slap 3 38 126 4 Organ 1 4 38 127 4 Atmosphere A57 39 0 4 Synth Bass 1 1 39 1 4 Synth Bass 1	A62	11 51 17 4 Hybrid Str. 12 51 24 4 Tron Strings 13 51 25 4 Noiz Strings 14 51 126 4 Trombone 15 51 127 4 Str Sect 3 A74 52 0 4 Syn.Strings2 1 52 1 4 Syn.Strings5 2 52 2 4 JUNO Strings 3 52 3 4 FilteredOrth 4 52 4 4 JP Saw Str.	4 56 8 4 Impact Hit 5 56 9 4 Philly Hit 6 56 10 4 Double Hit 7 56 11 4 Perc. Hit 8 56 12 4 Shock Wave 9 56 13 4 Bounce Hit 10 56 14 4 Drill Hit 11 56 15 4 Thrill Hit 12 56 16 4 Lo Fi Rave 13 56 17 4 Techno Hit 14 56 18 4 Dist. Hit

GBN Var PC CC00 CC32 Name 15 56 19 4 Bam Hit 16 56 20 4 Bit Hit 17 56 21 4 Bitm Hit 18 56 22 4 Technory Hit 19 56 23 4 Rave Hit 20 56 24 4 Strings Hit 21 56 25 4 Stack Hit 22 56 26 4 Industry Hit 23 56 27 4 Clap Hit 24 56 126 4 Tenor Sax 25 56 127 4 Cello 2 A81 57 0 4 Trumpet 1 57 1 4 Trumpet 2 57 2 4 Trumpet:	GBN Var PC CC00 CC32 Name 19 62 36 4 St.Orch Brs 20 62 37 4 St.Orch Brs 21 62 38 4 St.Orch Brs 22 62 43 4 Brass Sect 5 23 62 44 4 Brass Sect 4 24 62 45 4 Brass Sect 1 25 62 46 4 Brass Sect 1 26 62 47 4 Brass Sect 1 27 62 126 4 Brass Sect 1 27 62 126 4 Brass Sect 1 27 63 1 4 JUNO Brass 1 63 1 4 JUNO Brass 2 63 2 4 Stack Brass 3 63 3 4 SH-5 Brass	GBN Var PC CC00 CG32 Name 2 74 2 4 Flute Exp. 3 74 3 4 flut ravelso 4 74 8 4 Flute + Vin 5 74 9 4 Pipe & Reed 6 74 16 4 Tron Flute 7 74 17 4 Indian Flute 8 74 48 4 v Flute 9 74 49 4 v Flute Exp. 10 74 50 4 v Flt Travelso 11 74 50 4 v Flt Travelso 11 74 51 4 v Tron Flute 12 74 127 4 Flute 2 B23 75 0 4 Recorder 1 75 127 4 Piccolo 1	GBN Var PC CC00 CC32 Name 23 82 28 4 D-50 Saw 24 82 29 4 SH-101 Saw 25 82 30 4 CS Saw 26 82 31 4 MG Saw Lead 27 82 32 4 0B Saw Lead 28 82 33 4 P5 Saw Lead 29 82 34 4 MG unison 30 82 35 4 Oct Saw Lead 31 82 35 4 Oct Saw Lead 32 82 38 4 Synchronized 33 82 39 4 MG SawLead 34 82 40 4 SequenceSaw2 35 82 41 4 SequenceSaw2 36 82 42 4 Reso Saw 37 82 43 4 Cheese Saw
3 57 3 4 Dark Trumpet & N2 5 57 8 4 Flugel Hom 6 57 16 4 4th Trumpet & N2 7 57 24 4 Bright Tp. 9 57 26 4 Warm Tp. 9 57 26 4 Warm Tp. 10 57 27 4 Twin Tp. 11 57 32 4 Syn. Trumpet 12 57 47 4 Atk Trumpet 13 57 48 4 V Trumpet 14 57 49 4 V Romantz Tp	4 63 4 4 MKS Brass 5 63 5 4 Jump Brass 6 63 8 4 Fro Brass 7 63 9 4 P5 Brass 8 63 10 4 OrtdSynBrass 9 63 16 4 OrtdSynBrass 10 63 17 4 Hybrid Brass 11 63 18 4 OctSynBrass 12 63 19 4 BPF Brass 13 63 126 4 Brass 1 14 63 127 4 Elec Gtr 2	824 76 0 4 Pan Flute 1 76 8 4 Kawala 2 76 16 4 Zampona Atk 4 76 24 4 Tin Whistle 5 76 25 4 Tin Whistle Nr 6 76 25 4 Tin Whistle Nr 7 76 46 4 Tin Whistle 8 76 47 4 Pan Pipe 9 76 127 4 Piccolo 1 77 46 4 The Blow 1 77 46 4 The Bortle	38 82 44 4 Cheese Saw 2 39 82 45 4 Rhythmic Saw 40 82 46 4 SequencedSaw 41 82 47 4 Techno Saw 42 82 127 4 Sax 4 833 83 0 4 Syn.Calliope 1 83 1 83 0 4 Vent Synth 2 83 2 4 Pure PanLead 3 83 8 4 LM Pure Lead 4 83 9 4 LM Blow Lead 5 83 127 4 Clarinet 1
15 57 50 4 V Mariachi Tp 16 57 51 4 V RomMar Tp 17 57 52 4 V Tp MarShk 18 57 53 4 V Tp Shake 19 57 54 4 V Trugel Horn 21 57 56 4 v Hit Tpts 22 57 126 4 BaritoneSax 23 57 127 4 Contrabass A82 58 0 4 Trombone 2 1 58 1 4 Trombone 2 2 58 2 4 Twin bones	A88 64 0 4 Synth Brass2 1 64 1 4 Soft Brass 2 64 2 4 Warm Brass 3 64 3 4 Synth Brass3 4 64 4 5 Synt Brass 5 64 5 4 Fat SynBrass 6 64 6 4 DeepSynBrass 7 64 8 4 SynBrass f2 8 64 9 4 OB Brass 9 64 10 4 Reso Brass 10 64 11 4 DistSqrBrass 11 64 12 4 JP8000SawBrs 12 64 16 4 Velo Brass 1	2 77 47 4 BottieBlow2 3 77 127 4 Recorder B26 78 0 4 Shakuhachi 1 78 1 4 Shakuhachi 2 78 47 4 Shakuhachi 2 78 47 4 Shakuhachi 2 78 127 4 Pan Pipes B27 79 0 4 Whistle 1 79 1 4 Whistle 2 2 79 127 4 Sax 1 B28 80 0 4 Ocarina	B34
3 58 3 4 Bright Tb 5 58 8 4 Bright Tb 5 58 8 4 Bright Tb 6 58 16 4 Euphonium 7 58 48 4 v Trombone 8 58 49 4 v Trombone 9 58 50 4 v Twin bones 10 58 51 4 v 98: Tbn 11 58 52 4 v Euphonium 12 58 126 4 Alto Sax 13 58 127 4 Harp 1 AB3 59 0 4 Tuba 1 59 1 4 Tuba 2 2 59 8 4 Tuba 3	13 64 17 4 Transbrass 14 64 46 4 5 SoaringHorns 15 64 47 4 Henry IV 16 64 126 4 Orchest-Hit 17 64 127 4 Sitar B11 65 0 4 Soprano Sax 1 65 8 4 Soprano Exp. 2 65 127 4 Acou Bass 1 B12 66 0 4 Alto Sax 1 66 8 4 Alto Sax + Tp 4 66 17 4 Sax Section 5 66 46 4 Alto Sax 5 Color 6 66 47 4 Alto Sax 2	1 80 127 4 Sax 2 B31 81 0 4 Square Wave 1 81 1 4 MG Square 2 81 2 4 Hollow Mini 3 81 3 4 Mellow FM 4 81 4 4 CC Solo 5 81 5 4 Shmoog 6 81 6 4 LM Square 7 81 7 4 JP8000 TWM 8 81 8 4 2600 Sine 9 81 9 4 Sine Lead 10 81 10 4 KG Lead 11 81 11 4 Twin Sine 12 81 16 4 PS Square 13 81 17 4 OB Square	12 84 127 4 Clarinet 2 B35 85 0 4 Charang 1 85 1 4 Wire Lead 2 85 2 4 FB.Charang 3 85 3 4 FB.Charang 4 85 4 Windy GR Ld 5 85 5 4 Mellow GR Ld 6 85 6 4 GR & Pulse 7 85 8 4 Dist.Lead 8 85 9 4 Acid Guitar1 9 85 10 4 Acid Guitar2 10 85 11 4 Dance Dst.Gt 11 85 12 4 DanceDst.Gt 12 85 16 4 PS Sync Lead 13 85 17 4 Fat Sync Lead 14 85 18 4 Rock Lead
AS4 60 0 4 MutedTrumpet 1 60 1 4 Cup Mute Tp 2 60 2 4 MuteTrumpet 3 60 3 4 MuteTrumpet 3 60 3 4 MuteTrumpet 4 60 8 4 MuteTrumpet 5 60 48 4 V MuteTp 6 60 49 4 V MuteTp 7 60 126 4 Brass 1 8 60 127 4 Guitar 1 AS5 61 0 4 French Horris	7 66 127 4 Acou Bass 2 B13 67 0 4 Tenor Sax 1 67 1 4 Tenor Sax 2 67 8 4 BreathyTn.: 3 67 9 4 St.Tenor Sax 4 67 44 4 Latin Tenor 5 67 45 4 Blowd Tenor 7 67 47 4 Super Tenor 8 67 127 4 Elec Bass 1 B14 68 0 4 Bairtone Sax	14 81 18 4 P-8-Square 15 81 19 4 Dist Square 16 81 20 4 3035quarDst2 17 81 21 4 3035quarDst2 18 81 22 4 303 Mix Sqr 19 81 23 4 Dual Sqr&Saw 20 81 24 4 Pulse Lead 21 81 25 4 PP8 PulseLd2 22 81 26 4 JP8 PulseLd2 23 81 27 4 MG Reso, Pis 24 81 28 4 PP8 PulseLd3 25 81 29 4 2608ingLead 26 81 30 4 303bitLead 27 81 31 4 PP8000DistLd	15 85 19 4 5th DecaSync 16 85 20 4 Dirty Sync 17 85 21 4 DualSynclead 18 85 22 4 LA Brass Ld 19 85 24 4 JUNG SUD Osc 20 85 25 4 2600 Sub Osc 21 85 25 4 2600 Sub Osc 22 85 127 4 Oboe B36 86 0 4 Solo Vox 1 86 1 4 Solo Vox 2 2 86 8 4 Vox Lead 3 86 9 4 LFO Vox
1 61 1 4 F.Horn 2 2 61 2 4 Horn + Orche 3 61 3 4 Wide FreHms 4 61 8 4 F.Hm Slow 5 61 9 4 Dual Horns 6 61 16 4 Synth Horn 7 61 24 4 F.Horn Rip 8 61 126 4 Brass 2 9 61 127 4 Guitar 2 A86 62 0 4 Brass 1 1 62 1 4 Brass ff	1 68 1 4 Bari, Sax: 2 68 8 4 Bari & Tenor 3 68 127 4 Elec Bass 2 B15 69 0 4 Oboe 1 69 8 4 Oboe Exp. 2 69 16 4 Multi Reed 3 69 127 4 Slap Bass 1 B16 70 0 4 English Horn 1 70 127 4 Slap Bass 2 B17 71 0 4 Bassoon	28 81 32 4 HipHop SinLd 29 81 33 4 HipHop SqrLd 30 81 34 4 HipHop PSLd 31 81 35 4 Flux Pulse 32 81 127 4 Sax 3 B32 82 0 4 Saw Wave 1 82 1 4 OB2 Saw 2 82 2 4 Pulse Saw 3 82 3 4 Feline GR 4 82 4 8 Bj Lead 5 82 5 Velo Lead	4 86 10 4 Vox Lead 2 5 86 127 4 Engl Horn 837 87 0 4 5th Saw Wave 1 87 2 4 Big Fives 2 87 2 4 5th Ana.Clav 4 87 4 5th Ana.Clav 4 87 4 5th Vox 6 87 5 4 JP Sth Saw 6 87 6 4 JP Sth Saw 8 87 127 4 Bassoon
2 62 2 4 Bones Sect. 3 62 3 4 St. Brass ff 4 62 4 Quad Brass1 5 62 5 4 Quad Brass2 6 62 8 4 Brass 2 7 62 9 4 Brass 3 8 62 10 4 Brass fz 9 62 12 4 Brass sfz 10 62 14 4 FatPop Brass 11 62 16 4 Brass Fall 12 62 17 4 Trumpet Fall 13 62 24 4 Octave Brass 14 62 25 4 Brass - Reed 15 62 26 4 Fat + Reed 16 62 32 4 Orth Brass 17 62 33 4 Orth Brass 2 18 62 35 4 St.FatPopBrs	1 71 127 4 Fretiess 1 B18 72 0 4 Clarinet 1 72 8 4 Bs Clarinet 2 72 16 4 Multi Wind 3 72 17 4 Quad Wind 4 72 127 4 Fretiess 2 B21 73 0 4 Frecios 1 73 1 4 Piccolo: 2 73 8 4 Nay 3 73 9 4 Nay Tremolo 4 73 16 4 Di 5 73 127 4 Flute 1 B22 74 0 4 Flute 1 74 1 4 Flute 2:	6 82 6 4 GR-300 7 82 7 4 LA Saw 8 82 8 4 Doctor Solo 9 82 9 4 Fat Saw Lead 10 82 10 4 JP8000 Saw 11 82 11 4 D-50 Fat Saw 12 82 12 4 0B DoubleSaw 13 82 13 4 JP DoubleSaw 14 82 14 4 FatSawLead 2 15 82 15 4 JP SuperSaw 16 82 16 4 Waspy Synth 17 82 17 4 PM Lead 18 82 18 4 CS Saw Lead 19 82 24 4 MG Saw 1 20 82 25 4 MG Saw 2 21 82 25 4 OB Saw 2	B38

GBN	Var	PC (C00 (C32	Name	GBN	Var	PC	CC00	(32	Name	-OFFICE AND ADDRESS.	GBN	Var	PC	CCOO	CC32Name	GBN	Var	PC	C00	CC32	Name
•••	7	89	7	4	260HarmPad		6	96	9	4	Shwimmer	16	102	16	4 54			868		112	0	4	Shanai
	8	89	44	4	EP Heaven		7	96	10	4	Celestial Pd		17	102 102	17 18	4	LM Has Come FallinInsect		2	112 112	1 8	4	Shanai 2 Pungi
	9 10	89 89	45 46	4	HeavenKey BriteSawKey		8	96 96	11 12	4	Bag Sweep Sweep Pipe		18 19	102	19	4	LFO Oct.Rave		3	112	16	4	Hichiriki
	11	89	47	ă	VoxKey1		10	96	13	4	Sweep Stack		20	102	20	4	Just Before		4	112	24	4	Mizmar
	12		127	4	Trumpet 1		11	96	14	4	Deep Sweep		21	102	21	4	RND Fl.Chord		5	112	32	4	Suona 1
B42					Wisen Bad		12	96	15	4	Stray Pad		22	102	22	4	RandomEnding Random Sine		6 7	112	33 127	4	Suona 2 Breathpipe
842	1	90 90	0	4	Warm Pad Thick Matrix		13 14	96 96	46 47	4	SoftSweep SawsSweep		23 24	102 102	23 24	4	EatingFilter			112	127	7	neonimpe
	2	90	ż	4	Horn Pad		15	96	127	4	Brs Sect 1		25	102	25	4	Noise&SawHit	B71		113	0	4	Tinkle Bell
	3	90	3	4	Rotary Strng		Powers and						26	102	26	4	Pour Magic		1 2	113	8	4	Bonang Gender
	4	90	4	4	OB Soft Pad	B51		97 97	0	4	ice Rain Harmo Rain		27	102	27	4	DancingDrill		3	113 113	10	4	Gamelan Gong
	5 5	90 90	5 6	4	Sine Pad OB Soft Pad2		1	97	2	4	African wood		28 29	102 102	28 29	4	Dirty Stack Big Blue		4	113	11	4	St.Gamelan
	7	90	8	4	Octave Pad		ŝ	97	3	4	Anklung Pad		30	102	30	4	Static Hit		5	113	12	4	Jang Gu
	8	90	9	4	Stack Pad		4	97	4	4	Rattle Pad		31	102	31	4	Atl.Mod.FX		6	113	13	4	Jegogan
	9	90	10	4	Human Pad		5	97	5	4	Saw impulse		32	102	32	4	Acid Copter		7	113	14 15	4	Jublag Pemade
	10	90 90	11 12	4	Sync Brs.Pad Oct.PWM Pad		6 7	97 97	6 7	4	Strange Str. FastFWD Pad		33	102	127	4	Glock		9	113	16	4	RAMA Cymbai
	11 12	90	13	4	JP Soft Pad		8	97	8	4	Clavi Pad	857	*****	103	0	4	Echo Drops		10	113	17	4	Kajar
	13	90	43	4	PWM Soft Pad		9	97	9	4	EP Pad		1	103	1	4	Echo Bell		11	113	18	4	Kelontuk
	14	90	44	4	LFO Pad 2		10	97	10	4	Tambra Pad		2	103	2	4	Echo Pan		12 13	113 113	19 20	4	Kelontuk Mt Kelontuk Sid
	15	90	45	4	Warm5aw2 Warm5aw3		11 12	97 97	11 127	4	CP Pad Brs Sect 2		3	103	3 4	4	Echo Pan 2 Big Panner		14	113	21	4	Kopyak Op
	16 17	90 90	46 47	4	WarmSaw1		12	<i>21</i>	147	-	UIS SECLE		5	103	5	4	Reso Panner		15	113	22	4	Kopyak Mt
	18	90	127	4	Trumpet 2	B52		98	0	4	Soundtrack		6	103	6	4	Water Piano		16	113	23	4	Ceng Ceng
-	AND THE PERSON NAMED IN				O. L	~	1	98	1	4	Ancestral Proloque		7	103	7	4	Echo SynBass		17 18	113 113	24 25	4	Reyoung Kempur
B43	1	91 91	0 1	4	Polysynth 80's PolySyn		2	98 98	2 3	4	Prologue 2		8	103 103	8 9	4	Pan Sequence Aqua		19	113	32	4	Ingl Crash
	ż	91	2	4	Polysynth 2		4	98	4	4	Hols Strings		10	103	10	4	Panning Lead		20	113	40	4	Crash Menu
	3	91	3	4	Paly King		5	98	5	4	HistoryWave		11	103	11	4	PanningBrass		21	113	41	4	RideCym Menu
	4	91	4	4	Super Poly		6 7	98 98	8	4	Rave Vibe 1		12	103	127	4	Tube Bell		22	113	42 47	4	RideBellMenu CymbalRoll
	5 6	91 91	8	4	Power Stack Octave Stack			38	127	4	Vibe 1	B58	-	104	0	4	Star Theme		24	113	127	4	Timpani
	7	91	10	4	Reso Stack	B53		99	0	4	Crystal		1	104	1	4	Star Theme 2	A14 - MOTORM	~.		****	-	-
	8	91	11	4	Techno Stack		1	99	1	4	Syn Mailet		2	104	2	4	Star Mind	B72		114	8	4	Agogo Atarigane
	9	91	12	4	Pulse Stack		2	99 99	2	4	Soft Crystal Round Glock		3 4	104 104	3	4	Star Dust Rep.Trance		1	114	16	4	Tambourine
	10 11	91 91	13 14	4	TwinOct.Rave Oct.Rave		4	99	4	4	Loud Glock		5	104	5	4	Etherality		3	114	127	4	Melodic Tom
	12	91	15	4	Happy Synth		5	99	5	4	GlockenChime		6	104	6	4	Mystic Pad	garan.	Michigan.				
	13	91	16	4	Forward5weep		6	99	6	4	Clear Bells		7	104	8	4	Dream Pad	873	1	115 115	0	4	Steel Drums Island Mit
	14	91	17	4	ReverseSweep		7 8	99 99	7 8	4	ChristmasBei Vibra Bells		8	104 104	9 10	4	Silky Pad Dream Pad 2		ż	115	127	4	Deep Snare
	15	91	24 46	4	Minor Rave SuperSaws 2		9	99	9	4	Digi Bells		10	104	11	4	Silky Pad 2	(Approximate)		active and	DEPTH COMP	نوية كريمانية الراسة	Participate de la companya del companya del companya de la company
	16 17	91 91	47	4	SuperSaws 1		10	99	10	4	Music Bell		11	104	16	4	New Century	B74		116	0	4	Woodblock
	18	91	127	4	Trombone 1		11	99	11	4	Analog Bell		12	104	17	4	7th Atmos.		1 2	116 116	8 16	4	Castanets Angklung
-	angere en	nga-vona	The second second	etiindee	and the second second	ar.	12	99 99	12 13	4	Blow Bell Hyper Bell		13	104	18	4	Galaxy Way Rising OSC.		3	116	17	4	Angki Rhythm
844	1	92 92	0	4	Space Voice Heaven II		14	99	16	4	Choral Bells		14 15	104 104	19 127	4	Xylophone		4	116	24	4	Finger Snaps
	2	92	2	4	SC Heaven		15	99	17	4	Air Bells	-		*********	-				5	116	32	4	909 HandClap
	3	92	3	4	Itopia		16	99	18	4	Bell Harp	B61	_	105	0	4	Sitar		6 7	116 116	40 127	4	HandClapMenu Elec Perc 1
	4	92	4	4	Water Space		17	99	19	4	Gamelimba		1 2	105 105	1	4	Sitar 2 Detune Sitar			110			ENERT GIVE I
	5 6	92 92	5 6	4	Cold Space Noise Peaker		18 19	99 99	20 21	4	JUNO Beli JP Beli		3	105	3	4	Sitar 3	875		117	0	4	Taiko
	7	92	7	4	Bamboo Hit		20	99	22	4	Pizz Bell		4	105	4	4	Sitar/Drone		1 2	117 117	1 8	4	Small Taiko Concert BD
	8	92	8	4	Cosmic Voice		21	99	23	4	Bottom Bell		5	105	5	4	Sitar 4		3	117	9	4	ConcertBD Mt
	9	92	9	4	Auh Vox		22	99	127	4	Vibe 2		6 7	105 105	8 16	4	Tambra Tamboura		4	117	16	4	Jungle BD
	10 11	92 92	10 11	4	AuhAuh Vocoderman	B54		100	0	4	Atmosphere		8	105	127	4	Marimba		5	117	17	4	Techno BD
	12	92	12	4	Holy Voices		1	100	1	4	Warm Atmos		-				Company with Constitution of the Company		6	117	18	4	Bounce Kondang/Madon
	13	92	43	4	JP8Haunting		2	100	2	4	Nylon Harp	862		106	0	4	Banjo		7 8	117 117	24 25	4	KendangWadon Bebarongan
	14	92	44	4	JP8 Hollow		3	100	3 4	4	Harpvox HollowReleas		1 2	106 106	1 8	4	Muted Banjo Rabab		9	117	26	4	Pelegongan
	15	92 92	45 46	4	WarmSqu3 WarmSqu2		5	100	5	4	Nylon+Rhodes		3	106	9	4	San Xian		10		27	4	Dholak 1
	16 17	92	47	4	WarmSqu1		6	100	6	4	Ambient Pad		4	106	16	4	Gopichant		11	117	28	4	Dholak 2
	18	92	127	4	Trombone 2		7	100	7	4	Invisible		5	106	24	4	Oud		12 13	117 117	32 40	4	Ingl BD Roll Kick Menu 1
-	incerpress)		-		and an arrangement of the second of the seco		8	100	8	4	Pulsey Key Noise Piano		6 7	106 106	28 32	4	Oud+Strings Pi Pa		14		41	4	Kick Menu 2
B45	1	93 93	0	4	Bowed Glass SoftBellPad		9 10	100	9 10	4	Heaven Atmos		8	106	127	4	Koto		15	117	42	4	Kick Menu 3
	ż	93	ż	4	JP8 Sqr Pad		11	100	11	4	Tambra Atmos		-			s energe	Guaronpas, and at the source		16			4	Kick Menu 4
	3	93	3	4	7thBelPad		12	100		4	Syn Mallet	863		107 107	0 1	4	Shamisen Tsugaru		17	117	127	4	Elec Perc 2
	4	93	4	4	Steel Glass	B55	M AND YES	101	0	4	Brightness		1 2	107	8	4	Syn Shamisen	B76	present the	118	0	4	Meio. Tom 1
	5 6	93 93	5 47	4	Bottle Stack Gtr Pad		1	101	1	4	Shining Star		3	107		4	Sho		1	118	1	4	Real Tom
	7	93	127	4	Fr Horn 1		2	101	2	4	OB Stab			400	A CONTRACTOR	4	Kota		2	118 118	2	4	Real Tom 2 Jazz Tom
yopen and		VOLUME OF THE SECOND			est the establishment with a serious for the	~	3	101		4	Brass Star Choir Stab	B64	1	108 108		4	Koto Gu Zheng		4	118	4	4	Brush Tom
B46	1	94 94	0	4	Metal Pad Tine Pad		4	101		4	Choir Stab D-50 Retour		2	108	8	4	Taisho Koto		5	118	8	4	Melo. Tom 2
	2	94	2	4	Panner Pad		6	101		4	SouthernWind		3	108		4	Kanoon		6	118	9	4	Rock Tom
	3	94	3	4	Steel Pad		7	101	7	4	SymbolicBell		4 5	108 108		4	Kanoon+Choir Oct Harp		7 8	118 118	16 17	4	Rash SD House SD
	4	94	4	4	Special Rave		8 9	101 101		4	Org Bell Windbell		5	108		4	Shakuhachi		9	118	18	4	Jungle SD
	5 6	94 94	5 127	4	Metal Pad 2 Fr Horn 2		7	iVI	127	040000	mar and the state decisions of the state of	-queens	-				- NAME OF THE PARTY OF THE PART		10	118	19	4	909 SD
(Chronic p			-		ALL ANADAS PROPERTY	B56	-1513000	102		4	Goblin	865		109		4	Kalimba		11			4	Jngi SD Roli SD Menu 1
B47		95	0	4	Halo Pad		1	102		4	Goblinson		1 2	109 109		4	Sanza Bodhran		12			4	SD Menu 1 SD Menu 2
	1	95 95	1 2	4	Vox Pad Vox Sweep		3	102 102		4	50's Sci-Fi Abduction		3			4	Bodhran Mute		14			4	SD Menu 3
	3	95	8	4	Horror Pad		4	102		4	Auhbient		4	109		4	Whistle 1		15	118	43	4	5D Menu 4
	4	95	9	4	SynVox Pad		5	102	5	4	LFO Pad	866	zovar/mess	110	0	4	Bagpipe		16			4	SD Menu 5
	5	95	10	4	SynVox Pad 2		6	102		4	Random Str	900	1	110		4	Didgeridoo		17	118	127	4	Taiko
	6	95	11	4	Breath&Rise Tears Voices		7 8	102		4	Random Pad LowBirds Pad		2	110	9	4	Uillean Pipe	B77	er HM V KE	119		4	Synth Drum
	7 8	95 95	12 127	4	Tuba		9	102		4	Falling Down		3	110		4	UillnPipe Nm		1	119		4	808 Tom
no-weapons.	COTTREAS	-	en e	NA-Develo		ween	10	102	10	4	LFO RAVE		4			4	UillnPipe Or Whistle 2		2	119 119		4	Elec Perc Sine Perc.
848		96	0	4	Sweep Pad Polar Pad		11	102		4	LFO Horror LFO Techno	, married ***	3	pander make libraries	may constitution of	ur.te-me	specification (SEE Co.) - 1 (S		4	119		4	606 Tom
	1 2	96 96	1 2	4	Ambient BPF		12 13	102		4	LFO Techno Alternative	B67		111		4	Fiddle		5	119	12	4	909 Tom
	3	96	3	4	Sync Pad		14	102		4	UFO FX		1 2	111		4	Er Hu Gao Hu		6	119		4	606 Dist.Tom
	4	96	4	4	Warriors		15	102		4	Gargle Man		3			4	Bottleblow		7	119	127	4	Taiko Rim
	5	96	8	4	Converge								-				*						

GB/ B78		12 12 12 12 12 12 12 12 12 12 12 12 12 1	20 0 20 1 20 2 20 3 20 8 20 16 20 16 20 25 26 0 27 27 0 40 0 42 0 42 0 43 0 46		A Reverse Cym. A Reverse Cym. A Reverse Cym3 A Reverse Cym3 A Reverse Cym4 A Rev.Snare 1 A Rev.Snare 2 A Rev.ConBD A Rev.ConBD A Rev.Tom 1 A Rev.Tom 2 A Rev.Tom 3 A Rev.Tom 4 A Rev.SD Menu1 A Rev.SD Menu1 A Rev.BD Menu2 A Rev.BD Menu3 A Rev.BD Menu3 A Rev.ClapMenu A Cymbal	GBI	N V-1 2 2 2 2 2 2 2 2 2 3 3 3 3 3 3 3 3 3 3 3	5 11 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	21 28 21 29 21 30 21 31 21 32 21 34 21 35 21 36 21 37 21 38 21 39 21 40 21 41 21 42 21 44 21 45 21 46 21 47		4 StiGt.SidNz4 4 Gt.StrokeNz1 4 Gt.StrokeNz2 4 Gt.StrokeNz3 4 Gt.StrokeNz3 4 Gt.StrokeNz4 4 EGtrNzMenu 8 AGtrNzMenu 8 BassNzMenu 8 Bass Siide	GB B84 885		11 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	24 24 24 24 24 24 24 24 24 25 25 25 25 25 25 25 25 25	0 1 2 3 4 5 6 7	4 Bi 4 Ki 4 Gi 4 Fa 4 Se 4 Te 4 Te 4 Do 4 So 4 So 4 So 4 So 4 So 4 So 4 So 4 S	rd y y y y y y y y y y y y y y y y y y y	GBI B87	1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	4 12 5 12 6 12 7 12 8 12 9 12 0 12 1 12 2 12 3 12	26 18 20 20 5 21 6 22 6 23 6 24 6 25 6 26 6 27 6 28 6 29 6 30 6 32 6 32 7 0 7 1	4 4 4 4 4 4 4 4 4	Car Horn Boeeen R.Crossing Compresser Sword Boom! Sword Cross Stab! 1 Stab! 2 OneNote Jam Applause Laughing
881	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22	12 12 12 12 12 12 12 12 12 12 12 12 12 1	1 0 1 1 1 2 1 3 1 4 1 5 1 6 1 8 1 9 1 10 1 11 1 13 1 16 1 17 1 18 1 19 20 21 22 22 23 24 25	4	4 GLFretNoise 4 Gt.Cut Noise 4 String Slap 5 Gt.CutNoise 5 String Slap 6 Gt.CutNoise 2 Dist.CutNois 8 Bass Slide 8 Pick Scrape 1 Gt. FX Menu 8 Bartok Pizz. 6 Guitar Slap 1 Chord Stroke 8 Biwa Stroke 8 Biwa Stroke 8 Biwa Tremolo A.Bs.Nz Menu L.G.T.NzMenu L.G.T.NzMenu L.G.T.NzMenu G.S.Siroke-Menu G.S.Siroke-Menu G.S.Siroke-Menu G.S.Siroke-Menu G.S.Siroke-Menu G.S.Siroke-Menu A.Bs.Mute Nz A.Bs.TouchNz A.Bs.TouchNz A.Bs.AtackNz TC Up Nz	B82	1 2 3 4 5 6 6 7 8 9 10 11 2 3 4 4 5 6 6 7 8 9 10 11	12 12 12 12 12 12 12 12	22 3 22 4 22 5 22 7 22 8 22 9 22 47 22 127 23 1 23 3 4 23 5 3 7 6 3 17 3 47	444444444444444444444444444444444444444	FI.Key Click Brth Nz Menu FI.Breath 1 FI.Breath 2 FI.Breath 3 Vox Breath 3 Vox Breath 3 Vox Breath 1 Vox Breath 2 Trombone Nz Trumpet Nz BrthNzMenu Triangle Seashore Rain Thunder Wind Stream Bubble Wind 2 Cricket Pink Noise White Noise Windskitt	B86	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	10 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	225 125 125 125 125 125 125 125 125 125	0 1 2 3 3 4 5 5 6 6 7 7 7 9 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	4 Ph 4 MM 5 Sci 5 Sci 6 Sci 7 Sci 8	in plane rship st Noise culating c. Bang	 888	2 3 4 4 5 6 6 6 7 7 8 8 9 9 10 11 12 13 14 15 16 16 17 18 19 20 20 3 4 4 5	121 122 122 122 122 122 122 122 122 122	7 3 7 4 7 5 7 6 7 7 8 9 7 16 17 7 8 18 19 19 20 12 22 23 19 24 25 127 10 1 1 2 2 3 3 4 4	444444444444444444444444444444444444444	Punch Heart Beat Footsteps Applause 2 Small Club ApplauseWave BabyLaughing Voice One Voice Three Voice Tah Voice Tah Voice Whey
7.	24 Ne J	121	MINISTER SERVICE	4	TC UpMt.Nz								16 17					ck Bottle Ir Bottle		6 7	128 128	6	4 4	Explosion 2 Jungle Tune
	ile:	1		PK.			1																	en galanten et Si Francis
GBN A11	Var 1 2 3	PC 1 1 1 1 1	0 8 16 24	3 3 3 3	2 Name Piano 1 Piano 1w European Pf Piano + Str.	GBN	Var 3 4 5	PC 7 7 7	CC00 16 24 32 126	3 3 3 3	2 Name Harpsi.w Harpsi.o Synth Harpsi Piano 2	GBN A26	Vai 1 2	PC 14 14	120		Xyle Fun	ne ophone k Gt. e Org 2	GBN A33	Var 6 7	PC 18 18	CC00 126 127 0	3 3 3	2 Name Slap Bass 1 Harpsi 2 Organ 3
A12	1 2 3 4	1 1 2 2 2 2 2 2	126 127 0 8 16 126 127	3 3 3 3 3 3	Piano 2 Acou Piano 1 Piano 2 Piano 2w Dance Piano Piano 2 Acou Piano2	A18	7 1 2 3 4 5	8 8 8 8 8	127 0 8 16 24 32 33	3 3 3 3 3 3	Clav. Comp Clav. Reso Clav. Clav.o Analog Clav. JP8 Clav. 1	A27	1 2 3 4	15 15 15 15 15 16	8 9 126 127		Chu Cari Mut Pipe Sant	ed Gt. Org3 ur		1 2 3 4 5 6 7	19 19 19 19 19 19	8 16 17 18 24 126 127	3 3 3 3 3 3 3	Rotary Org. Rotary Org.S Rock Organ 1 Rock Organ 2 Rotary Org.F Slap Bass 1 Harpsi 3
A13	1 2 3 4	3 3 3 3 3	0 1 2 8 126 127	3 3 3 3 3 3	Piano 3 EG+Rhodes 1 EG+Rhodes 2 Piano 3w Piano 2 Acou Piano3	A21	6 7 8 1 2	8 8 8 9 9	35 126 127 0 1 126	3 3 3 3 3	JP8 Clav. 2 E.Piano 1 Honkytonk Celesta Pop Celesta Detuned EP1	A31	2 3 4 5 6 7	16 16 16 16 16	8 16 17 24 126 127	3 3 3 3	Cimi Zith Zith Dulc Siap Acco	balom er 1 er 2 imer Bass 1 Irdion	A34	1 2 3 4 5 6	20 20 20 20 20 20 20 20	0 8 16 24 32 33 126	3 3 3 3 3	Church Org.1 Church Org.2 Church Org.3 Organ Flute Trem.Flute Theater Org. Slap Bass 2
A14	3	4 4 4 4	0 8 126 127	3 3 3	Honky-tonk Honky-tonk 2 Honky-tonk Elec Plano 1	A22	3 1 2	9 10 10 10	127 0 126 127	3 3 3	Elec Org 1 Glockenspiel E.Piano 2 Elec Org 2	A31	1 2 3 4 5	17 17 17 17 17	0 1 8 9 16	3 3 3 3	Orga Trem Orga 60's	n 101 n. Organ	A35	1 2	20 21 21 21	0 8 126	3 3 3	Clavi 1 Reed Organ Wind Organ Slap Bass 2
A15	1 2 3 4 5 6 7 8	5 5 5 5 5 5 5 5 5 5	16 17 24 25 26	3 3 3 3 3 3 3 3 3	E.Piano 1 St.Soft EP Cho. E.Piano SilentRhodes FM+SA EP Dist E.Piano Wurly Hard Rhodes MellowRhodes Piano 1	A23	1 2 1 2 3 4 5	11 11 12 12 12 12 12 12 12	0 126 127 0 1 8 9 126 127	3 3 3 3 3 3 3 3	Music Box Steel Gt. Elec Org 3 Vibraphone Pop Vibe. Vibraphone w Vibraphones Steel Gt. Elec Org 4		6 7 8 9 10 11 12 13	17 17 17 17 17 17 17 17	18 19 24 25 26 27 28 29 32	3 3 3 3 3 3 3 3 3 3 3 3 3 3	60's Farf Chee D-50 JUNC Hybr VS O Digi	Organ 3 Organ se Organ Organ) Organ id Organ	A36	1 2 3 4 5 6 7	21 22 22 22 22 22 22 22 22 22	0 8 9 16 24 25 126 127	3 3 3 3 3 3 3	Accordion Fr Accordion It Dist. Accord Cho. Accord Hard Accord Soft Accord Soft Accord Slap Bass 2 Clavi 3
A16	10	5 6 6	127 0 8	3 3 3	Elec Piano2 E.Piano 2 Detuned EP 2	A25	1 2	13 13 13	0 8 16	3 3 3	Marimba Marimba w Barafon		15 16 17 18	17 17 17 17	33 40 48 126	3 3 3	5th C Slap I	n Bass Irgan Bass 1	A37	1 2 3		0 1 126 127	3	Harmonica Harmonica 2 Slap Bass 2 Celesta 1
A17	3 (6 7 7	24 126 127 0 1	3 3 3 3 3 3 3 3 3	St.FM EP Hard FM EP Piano 2 Elec Piano3 Harpsichord Harpsichord2 Coupled Hps.			13 13 13 13	24 126	3	Barafon 2 Log drum 12-str.Gt Pipe Org 1	A32	19 1 2 3 4 5	18 18 18 18 18 18	0 1 2 8 9 32	3 3 3 3 3	E.Org Chon Octav	gent and a supplementary of	A38	1 2 3 4	24 24 24 24 24	0 8 16 126 127	3 3 3	Bandoneon 2 Bandoneon 3 Fingered Bs Celesta 2

GBN A41	1 2 3 4 5 6 7 7 8 8 1	25 0 25 8 25 12 25 22 25 32 25 40 25 12 25 12 26 0 26 8 26 9 26 16 26 32 26 12 26 12 27 0 27 1	3 Mylon-str.Gt	GBN Var PC CC00 CC32 Name 4 35 8 3 Muted PickBs 5 35 16 3 P.Bass/Harm. 6 35 126 3 Strings 7 35 127 3 Chorale A54 36 0 3 Fretless Bs. 1 36 1 3 Fretless Bs. 2 36 2 3 Fretless Bs. 3 36 3 3 Fretless Bs. 4 36 4 3 5 yn Fretless Bs. 5 36 5 3 Mr.Smooth 6 36 8 3 Wood+FlessBs 7 36 126 3 SynStrings3 8 36 127 3 Glasses A55 37 0 3 Slap Bass 1 1 37 1 3 Slap Pop 2 37 8 8 Reso Slap 3 37 9 3 Unison Slap 4 37 126 3 SynStrings3 5 37 127 3 Soundtrack	GBN A65 A65 A66	Var PC 45 1 45 2 45 3 45 4 45 1 466 2 466 46 6 46 7 46 7 47 2 47 3 47 48	0 8 9 126 127 0 1 2 3 8 16	3 Suspense Str 3 Organ 2 3 Dector Solo 3 PizzicatoStr 4 Vcs&Chs Pizz 5 Sulpizzicato 5 Solo Pizz 5 Solo Spic 6 Organ 2 7 School Daze 7 Synth Harp 7 Trumpet 7 Bellsinger	GBN AB1	Var Pri 10 56 11 5	5 20 5 21 5 22 5 23 5 24 5 25 6 126 6 127 7 1 7 2 7 8 7 16 7 24 7 25 7 32 7 126	CG22 Name 3 Bir Hit 3 Ferhoorg Hit 3 Rave Hit 3 Strings Hit 3 Stack Hit 3 Stack Hit 3 Tenor Sax 3 Cello 2 0 3Trumpet 3 Trumpet 2 Trumpet: 3 Trumpet: 3 Trumpet: 3 Trumpet: 3 Trumpet: 3 Trumpet 3 Trumpet: 3 Trumpet 3 Trumpet 4 Trumpet 5 Flugel Horn 4 th Trumpets 6 Bright Tp. 7 Warm Tp. 7 Warm Tp. 7 Syn. Trumpet 8 Gentrobass 0 3Trombone
A44	2 3 4 1 2 3 4 5 6 7 8 9 10 11 12	27 8 27 12: 27 12: 28 0 28 1 28 2 28 3 28 4 28 9 28 16 28 17 28 18 28 19 28 12:	6 3 Picked Bass 7 3 Syn Brass3 3 Clean Gt. 3 Clean Gt. 3 Open Hard 1 3 Open Hard 2 3 JC Clean Gt. 3 Chorus Gt. 3 JC Chorus Gt. 3 TC FrontPick 7 3 TC Rear Pick 8 3 TC Clean ff. 1 TC Clean ff. 1 TC Clean ff. 2 TC Clean ff.	A56 38 0 3 Slap Bass 2 1 38 8 3 FM Slap 2 38 126 3 Organ 1 3 38 127 3 Atmosphere A57 39 0 3 Synth Bass 1 1 39 1 3 Synth Bass 101 2 39 2 3 CS Bass 3 39 2 3 CS Bass 4 39 4 3 JP-8 Bass 5 39 5 3 PS Bass 6 39 6 3 JPMG Bass 7 39 8 3 Acrid Bass 8 39 9 3 TB303 Bass 9 39 10 3 TB303 Bass 2	A71	1 48 2 48 1 49 1 49 2 49 3 49 5 49 6 49 7 49 8 49 9 10 10 11 49 11 49 11 49	126 127 0 1 2 3 8 9 10 11 12 16 24 32 33 126	3 Square Wave 3 Strings: 3 Bright Str: 3 Callo sect. 4 Orchestra 5 Orchestra 6 Orchestra 7 Orchestra 7 Orchestra 8 Tremolo Orch 8 Choir Str. 8 Strings+Horn 9 St. Strings 9 Oct Strings	AB3	1 58 2 58 3 58 4 58 5 58 1 59 2 59 3 59 60 1 60 2 60 3 60	59 1 127 59 1 127 0 8 8 126 127 0 0	3 Trombone 2 3 Twin bones 3 Bs. Trombone 3 Alto Sax 4 Harp 1 0 3 Tuba 2 3 Brass 1 3 Harp 2 3 Mutted frumpet 3 Mutted Homs 3 Brass 1 3 Guitar 1
A45	1 2 3 4 5 6 7 7 *******************************	29 0 29 1 29 2 29 8 29 16 29 125 29 127 30 0 30 1 30 2 30 3 30 8 30 9 30 127	3 Funk Pop 6 Funk Gt. 2 6 3 Acoustic Bs 7 3 Syn Bass 1 9 Overdrive Gt 3 Overdrive 2 9 Overdrive 3 Deverdrive 3 LP OverDrv: 6 3 Choir Aahs 7 3 Syn Bass 2	11 39 12 3 Kicked TB303 12 39 13 3 TB303 Saw 8s 13 39 14 3 Rubber303 Bs 14 39 15 3 Reso 303 Bs 15 39 16 3 Reso 503 Bs 16 39 17 3 TB303 Syr Bs 17 39 18 3 TB303 Syr Bs 18 39 24 3 Arpeggio Bs 19 39 126 3 Organ 1 20 39 127 3 Warm Bell AS8 40 0 3 Synth Bass 2 1 40 1 3 Synth Bass 2 1 40 1 3 Synth Bass 2 2 40 2 3 Modular Bass 4 40 4 3 MG Bas 4 40 4 3 MG Bas 5 40 5 3 MG Oct Bass 1 6 40 6 3 MG Oct Bass 1	A72	14 49 50 1 50 2 50 3 50 4 50 5 50 6 50 51 1 51 2 51 3 51 4 51 5 51 6 51 7 51 7 51	127 3 8 3 9 3 10 3 127 3 127 3 2 3 3 8 3 3 9 3 16 3	Slow Strings SlowStrings2 Legato Str. Warm Strings St.Slow Str. Trombone Str Sect 2 Syn.Strings1 OB Strings StackStrings Pstrings Syn.Strings3 Syn.Strings4 High Strings Hybrid Str.	A86	1 61 2 61 3 61 4 61 5 61 6 61 7 61 8 61 9 61 1 62 2 62 3 62 4 62 5 62 7 62	2 3 8 9 16 24 126 127 0 1 2 8 9 10 16	3 Fr.Hom 2 3 Horn + Orche 3 Wide FreHrns 3 F.Hm Slow: 3 Dual Howns 3 Synth Horn 5 Synth Horn 6 Brass 2 3 Guitar 2 3 Brass 1 3 Brass 1 3 Brass 3 3 Brass 3 3 Brass 3 3 Brass 3 3 Brass 51 3 Brass 51 3 Trumpet Fall
A47	1 2 3 4 5 6 6 7 8 9 10 11 12 13 1 2 3	31 0 31 1 31 2 31 3 31 4 31 8 31 9 31 16 31 17 31 18 31 25 31 126 31 127 32 0 32 8 32 9 32 9 32 9 32 16	3 Power Gt.2 3 Sth Dist. 3 Rock Rhythm 3 Rock Rhythm2 5 3 Choir Aahs	7 40 7 3 MG Blip Bs: 8 40 8 3 Beef FM Bass 9 40 9 3 Dly Bass 10 40 10 3 X Wire Bass 11 40 11 3 Wire Str Bass 12 40 12 3 Blip Bass: 13 40 13 3 RubberBass 2 15 40 16 3 RubberBass 2 15 40 17 3 SH101 Bass 1 16 40 18 3 SH101 Bass 2 17 40 19 3 Smooth Bass 18 40 20 3 SH101 Bass 3 19 40 21 3 Spike Bass 20 40 22 3 House Bass 21 40 23 3 Syn C Bass 22 40 24 3 Syn C Bass 23 40 25 3 MG 5th Bass 24 40 26 3 RND Bass	A74	8 51 9 51 10 51 11 51 52 2 52 3 52 4 52 5 52 53 1 53 2 53 3 53 5 53 6 53	24 3 25 3 126 3 127 3 0 3 1 3 2 3 8 3 126 3 127 3 0 3 8 3 9 3 10 3 16 3 24 3 32 3	Noiz Strings Trombone Str Sect3 Syn.Strings2 Syn.Strings5 JUNO Strings Air Strings Trombone Pizzicato Choir Aahs St.ChoirAahs Mehted Choir Church Choir Church Choir Chorr Hahs Chorr Hahs	AB7	8 62 9 62 10 62 11 62 63 1 63 2 63 3 63 4 63 5 63 7 63 8 63 9 63 10 63	25 126 127 0 1 2 3 4 8 9 16 17 126 127	3 Octave Brass 3 Brass 4 Reed 3 Brass 2 2 3 Elec Git 1 3 Synth Brass 1 3 JUNO Brass 5 Stack Brass 3 Stack Brass 3 SH-5 Brass 3 MKS Brass 3 Pro Brass 3 Pro Brass 3 Hybrid Brass 3 Hybrid Brass 3 Elec Git 2 3 Synth Brass 2 Soft Brass 5 Soft B
451	4 5 6 1 2 3 4 5	32 24 32 126 32 127 33 0 33 1 33 8 33 16 33 126 33 127	3 E.Bass Harm. 3 Choir Aahs 3 Syn Bass4 3 Acoustic Bs. 3 Rockabilly 3 Wild A.Bass 3 Bass + OHH 3 Choir Aahs	25 40 27 3 WowMG Bass 26 40 28 3 Bubble Bass 27 40 126 3 Organ 1 28 40 127 3 Funny Vox A61 41 0 3 Violin: 1 41 1 3 Violin Ak: 2 41 8 3 Slow Violin 3 41 126 3 Organ 2 4 41 127 3 Echo Bell	A76	7 53 8 53 9 53 54 1 54 2 54 3 54	33 3 126 3 127 3 0 3 8 3 126 3 127 3 55 0 8 3	Male Aah+Str Trombone Violin 1 Voice Oohs Voice Dahs Trombone Violin 2 3SynVox Syn.Voice	B11	2 64 3 64 4 64 5 64 7 64 8 64 9 64	2 8 9 10 16 17 126 127	Warm Brass SymBrass stz OB Brass Reso Brass Velo Brass 1 Transbrass Orchest.Hit Sitar Soprano Sax
A52	1 2 3 4 5 6 7 8	34 0 34 1 34 2 34 3 34 4 34 8 34 16 34 126 34 127	3 Fingered Bs. 3 Fingered Bs2 3 Jazz Bass 3 Jazz Bass 2 3 Rock Bass ChorusJazzBs 5 F.Bass/Harm. 3 Slow/strings Harmo Pan	A62		3 55 5 55 5 55 5 55 5 55 5 56 2 56 3 56 3 56	9 3 16 3 17 3 126 3 127 3 56 0 8 3 9 3 10 3 11 3 12 3	Silent Night VP330 Choir Vinyl Choir Alto Sax Cello 1 3OrchestraHit Impact Hit Philly Hit Double Hit Perc. Hit Shock Wave	B12	1 65 2 65 66 1 66 2 66 3 66 4 66 67 1 67	127 0 8 9 16 127	Grow Sax AltoSax + Tp Acou Bass 2 Tenor Sax
A53	1 2 3	35 0 35 1 35 2 35 3	3 Picked Bass 3 Picked Bass2 3 Picked Bass3 3 Picked Bass4	1 44 126 3 Organ 2 2 44 127 3 Echo Pan	6 7 8 9	56 56 56	16 3 17 3 18 3 19 3	Lo Fi Rave Techno Hit Dist. Hit Bam Hit		2 67 3 67 4 67	8 3 9 3 127 3	BreathyTn. : St.Tenor Sax

| GBN Var PC CC00 CC32 Name |
|--|--|--|--|
| B14 68 0 3 Baritone Sax | 25 82 35 3 Oct Saw Lead | B48 96 0 3 Sweep Pad | B61 105 0 3 Sitar |
| 1 68 1 3 Bari. Sax :
2 68 127 3 Elec Bass 2 | 26 82 40 3 Sequence5aw1
27 82 41 3 Sequence5aw2 | 1 96 1 3 Polar Pad
2 96 8 3 Converge | 1 105 1 3 Sitar 2
2 105 2 3 Detune Sitar |
| 2 68 127 3 Elec Bass 2
B15 69 0 3 Oboe | 27 82 41 3 SequenceSaw2
28 82 42 3 Reso Saw | 2 96 8 3 Converge
3 96 9 3 Shwimmer | 2 105 2 3 Detune Sitar
3 105 3 3 Sitar 3 |
| 1 69 8 3 Oboe Exp. | 29 82 43 3 Cheese Saw 1 | 4 96 11 3 Celestial Pd | 4 105 8 3 Tambra |
| 2 69 16 3 Multi Reed | 30 82 44 3 Cheese Saw 2 | 5 96 12 3 Bag Sweep | 5 105 16 3 Tamboura |
| 3 69 127 3 Slap Bass 1 | 31 82 45 3 Rhythmic Saw | 6 96 127 3 Brs Sect 1 | 6 105 127 3 Marimba |
| 816 70 0 3 English Horn | _ 32 82 127 3 Sax 4
B33 83 0 3 Syn.Calliope | 851 97 0 3 Ice Rain | B62 106 0 3 Banjo |
| 1 70 127 3 Slap Bass 2 | 1 83 1 3 Vent Synth | 1 97 1 3 Harmo Rain | 1 106 1 3 Muted Banjo |
| B17 71 0 3 Bassoon | 2 83 2 3 Pure PanLead | 2 97 2 3 African wood | 2 106 8 3 Rabab |
| 1 71 127 3 Fretiess 1 | 3 83 127 3 Clarinet 1 | 3 97 3 3 Anklung Pad
4 97 4 3 Rattle Pad | 3 106 9 3 San Xian
4 106 16 3 Gopichant |
| reservación discribusión discribidado de Otto Volencia de Companyo de Companyo e companyo de La companyo de La | B34 84 0 3 Chiffer Lead | 5 97 8 3 Clavi Pad | 5 106 24 3 Oud |
| 818 72 0 3 Clarinet
1 72 8 3 Bs Clarinet | 1 84 1 3 TB Lead | 6 97 127 3 Brs Sect 2 | 6 106 28 3 Oud+Strings |
| 1 72 8 3 Bs Clarinet
2 72 16 3 Multi Wind | 2 84 8 3 Mad Lead | B52 98 0 3 Soundtrack | . 7 106 32 3 Pi Pa |
| 3 72 127 3 Fretless 2 | 3 84 127 3 Clarinet 2 | 1 98 1 3 Ancestral | 8 106 127 3 Koto |
| 821 73 0 3 Piccolo | B35 85 0 3 Charang | 2 98 2 3 Prologue | B63 107 0 3 Shamisen |
| 821 73 0 3 Piccolo
1 73 1 3 Piccolo : | 1 85 8 3 Dist.Lead | 3 98 3 3 Prologue 2 | 1 107 1 3 Tsugaru |
| 2 73 8 3 Nay | 2 85 9 3 Acid Guitar1
3 85 10 3 Acid Guitar2 | 4 98 4 3 Hols Strings
5 98 8 3 Rave | 2 107 8 3 Syn Shamisen
3 107 127 3 Sho |
| 3 73 9 3 Nay Tremolo | 4 85 16 3 PS Sync Lead | 6 98 127 3 Vibe 1 | 3 101 121 3 310 |
| 4 73 16 3 Di | 5 85 17 3 Fat SyncLead | Procedure in the Control of the Cont | B64 108 0 3 Koto |
| 5 73 127 3 Flute 1 | 6 85 18 3 Rock Lead | B53 99 0 3 Crystal
1 99 1 3 Syn Mailet | 1 108 1 3 Gu Zheng
2 108 8 3 Taisho Koto |
| 822 74 0 3 Flute | 7 85 19 3 5th DecaSync
8 85 20 3 Dirty Sync | 1 99 1 3 Syn Mailet
2 99 2 3 Soft Crystal | 2 108 8 3 Jaisho Koto
3 108 16 3 Kanoon |
| 1 74 1 3 Flute 2: | 9 85 24 3 JUNO Sub Osc | 3 99 3 3 Round Glock | 4 108 19 3 Kanoon+Choir |
| 2 74 2 3 Flute Exp.
3 74 3 3 Flt Traverso | 10 85 127 3 Oboe | 4 99 4 3 Loud Glock | 5 108 24 3 Oct Harp |
| 4 74 8 3 Flute + Vin | 836 86 0 3 Solo Vox | 5 99 5 3 GlockenChime
6 99 6 3 Clear Bells | 6 108 127 3 Shakuhachi |
| 5 74 16 3 Tron Flute | 1 86 B 3 Vox.Lead | 7 99 7 3 ChristmasBei | 865 109 0 3 Kalimba |
| 6 74 127 3 Flute 2 | 2 86 9 3 LFO Vox | 8 99 8 3 Vibra Bells | 1 109 8 3 Sanza |
| 823 75 0 3 Recorder | 3 86 127 3 Engl Horn | 9 99 9 3 Digi Bells | 2 109 127 3 Whistle 1 |
| 1 75 127 3 Piccolo 1 | B37 87 0 3 5th Saw Wave
1 87 1 3 Big Fives | 10 99 10 3 Music Bell
11 99 11 3 Analog Bell | 866 110 0 3 Bagpipe |
| 824 76 0 3 Pan Flute | 2 87 2 3 5th Lead | 12 99 16 3 Choral Bells | 1 110 8 3 Didgeridoo |
| 1 76 8 3 Kawala | 3 87 3 3 5th Ana.Clav | 13 99 17 3 Air Bells | 2 110 127 3 Whistle 2 |
| 2 76 16 3 Zampona | 4 87 8 3 4th Lead | 14 99 18 3 Bell Harp | B67 111 0 3 Fiddle |
| 3 76 17 3 Zampona Atk | 5 87 127 3 Bassoon | 15 99 19 3 Gamelimba
16 99 20 3 JUNO Bell | 1 111 8 3 Er Hu |
| 4 76 127 3 Piccolo 2 | B38 88 0 3 Bass & Lead | 17 99 127 3 Vibe 2 | 2 111 9 3 Gao Hu |
| 825 77 0 3 Bottle Blow | 1 88 1 3 Big & Raw | marit Francisched volusion der State (and a state of the | 3 111 127 3 Bottleblow |
| 1 77 127 3 Recorder | 2 88 2 3 Fat & Perky | 854 100 0 3 Atmosphere | B68 112 0 3 Shanai |
| 826 78 0 3 Shakuhachi | 3 88 3 3 JUNO Rave
4 88 4 3 JP8 BsLead 1 | 1 100 1 3 Warm Atmos
2 100 2 3 Nylon Harp | 1 112 1 3 Shanai 2 |
| 1 78 1 3 Shakuhachi: | 5 88 5 3 JP8 BsLead 2 | 3 100 3 3 Harpvox | 2 112 8 3 Pungi |
| 2 78 127 3 Pan Pipes | 6 88 6 3 SH-5 Bs.Lead | 4 100 4 3 HollowReleas | 3 112 16 3 Hichiriki
4 112 24 3 Mizmar |
| | 7 88 127 3 Harmonica | 5 100 5 3 Nylon+Rhodes | 5 112 32 3 Suona 1 |
| B27 79 0 3 Whistle
1 79 1 3 Whistle 2 | 841 89 0 3 Fantasia | 6 100 6 3 Ambient Pad
7 100 7 3 Invisible | 6 112 33 3 Suona 2 |
| 2 79 127 3 Sax 1 | 1 89 1 3 Fantasia 2 | 8 100 8 3 Pulsey Key | 7 112 127 3 Breathpipe |
| CONTRACTOR DE CONTRACTOR D | 2 89 2 3 New Age Pad | 9 100 9 3 Noise Piano | 871 113 0 3 Tinkle Bell |
| B28 80 0 3 Ocarina
1 80 127 3 Sax 2 | 3 89 3 3 Bell Heaven
4 89 127 3 Trumpet 1 | 10 100 127 3 Syn Mallet | 1 113 8 3 Bonang |
| (or the string booking as when the sink him is a which is a surface of the strings of the strin | | B55 101 0 3 Brightness | 2 113 9 3 Gender |
| 831 81 0 3 Square Wave | B42 90 0 3 Warm Pad | 1 101 1 3 Shining Star | 3 113 10 3 Gamelan Gong
4 113 11 3 St.Gamelan |
| 1 81 1 3 MG Square
2 81 2 3 Hollow Mini | 1 90 1 3 Thick Matrix
2 90 2 3 Horn Pad | 2 101 2 3 OB Stab | 5 113 12 3 Jang Gu |
| 3 81 3 3 Mellow FM | 2 90 2 3 Horn rad
3 90 3 3 Rotary String | 3 101 8 3 Org Bell
4 101 127 3 Windbell | 6 113 16 3 RAMA Cymbal |
| 4 81 4 3 CC Solo | 4 90 4 3 OB Soft Pad | the state of the s | 7 113 127 3 Timpani |
| 5 81 5 3 Shmoog | 5 90 8 3 Octave Pad | B56 102 0 3 Goblin | 872 114 0 3 Agogo |
| 6 81 6 3 LM Square
7 81 8 3 2600 Sine | 6 90 9 3 Stack Pad
7 90 127 3 Trumpet 2 | 1 102 1 3 Goblinson
2 102 2 3 50's Sci-Fi | 1 114 8 3 Atarigane |
| 8 81 9 3 Sine Lead | | 3 102 3 3 Abduction | 2 114 16 3 Tambourine
3 114 127 3 Melodic Tom |
| 9 81 10 3 KG Lead | B43 91 0 3 Polysynth | 4 102 4 3 Auhbient | 3 114 127 3 Melodic Tom |
| 10 81 16 3 P5 Square | 1 91 1 3 80's Poly5yn
2 91 2 3 Polysynth 2 | 5 102 5 3 LFO Pad | B73 115 0 3 Steel Drums |
| 11 81 17 3 OB Square
12 81 18 3 JP-8 Square | 3 91 3 3 Poly King | 6 102 6 3 Random Str
7 102 7 3 Random Pad | 1 115 1 3 Island Mit |
| 13 81 24 3 Pulse Lead | 4 91 8 3 Power Stack | 8 102 8 3 LowBirds Pad | 2 115 127 3 Deep Snare |
| 14 81 25 3 JP8 PukeLd1 | 5 91 9 3 Octave Stack | 9 102 9 3 Falling Down | B74 116 0 3 Woodblock |
| 15 81 26 3 JP8 PulseLd2 | 6 91 10 3 Reso Stack
7 91 11 3 Techno Stack | 10 102 10 3 LFO RAVE
11 102 11 3 LFO Horror | 1 116 8 3 Castanets |
| 16 B1 27 3 MG Reso. Pls
17 B1 127 3 Sax 3 | 8 91 127 3 Trombone 1 | 11 102 11 3 LFO Horror
12 102 12 3 LFO Techno | 2 116 16 3 Angklung
3 116 17 3 Angki Rhythm |
| and the second s | | 13 102 13 3 Alternative | 4 116 24 3 Finger Snaps |
| B32 B2 0 3 Saw Wave | B44 92 0 3 Space Voice
1 92 1 3 Heaven II | 14 102 14 3 UFO FX | 5 116 32 3 909 HandClap |
| 1 82 1 3 OB2 Saw
2 82 2 3 Pulse Saw | 1 92 1 3 Heaven II
2 92 2 3 SC Heaven | 15 102 15 3 Gargle Man | 6 116 127 3 Elec Perc 1 |
| 3 82 3 3 Feline GR | 3 92 8 3 Cosmic Voice | 16 102 16 3 Sweep FX
17 102 127 3 Glock | B75 117 0 3 Taiko |
| 4 82 4 3 Big Lead | 4 92 9 3 Auh Vox | | 1 117 1 3 Small Taiko |
| 5 82 5 3 Velo Lead | 5 92 11 3 AuhAuh
6 92 12 3 Vocorderman | 857 103 0 3 Echo Drops | 2 117 8 3 Concert 8D |
| 6 82 6 3 GR-300
7 82 7 3 LA Saw | 7 92 12 3 Vocorderman
7 92 127 3 Trombone 2 | 1 103 1 3 Echo Bell
2 103 2 3 Echo Pan | 3 117 16 3 Jungle BD |
| 8 82 8 3 Doctor Solo | A District Control of the Control of | 3 103 3 3 Echo Pan 2 | 4 117 17 3 Techno BD
5 117 18 3 Bounce |
| 9 82 9 3 Fat Saw Lead | B45 93 0 3 Bowed Glass | 4 103 4 3 Big Panner | 6 117 127 3 Elec Perc 2 |
| 10 82 11 3 D-50 Fat Saw | 1 93 1 3 SoftBellPad
2 93 2 3 JP8 Sgr Pad | 5 103 5 3 Reso Panner | PER PROGRAMMENT CONTRACTOR CONTRA |
| 11 82 16 3 Waspy Synth
12 82 17 3 PM Lead | 3 93 3 3 7thBelPad | 6 103 6 3 Water Piano
7 103 8 3 Pan Sequence | 876 118 0 3 Melo. Tom 1
1 118 1 3 Real Tom |
| 12 82 17 3 PM LEAG
13 82 18 3 CS Saw Lead | 4 93 127 3 Fr Horn 1 | 7 103 8 3 ran sequence
8 103 9 3 Aqua | 1 118 1 3 Keal IOM
2 118 8 3 Melo. Tom 2 |
| 14 82 24 3 MG Saw 1 | B46 94 0 3 Metal Pad | 9 103 127 3 Tube Bell | 3 118 9 3 Rock Tom |
| 15 82 25 3 MG Saw 2 | 1 94 0 3 Metal rad | B58 104 0 3 Star Theme | 4 118 16 3 Rash SD |
| 16 82 26 3 OB Saw 1
17 82 27 3 OB Saw 2 | 2 94 2 3 Panner Pad | 858 104 0 3 Star Theme
1 104 1 3 Star Theme 2 | 5 118 17 3 House SD
6 118 18 3 Jungle SD |
| 17 82 27 3 OB Saw 2
18 82 28 3 D-50 Saw | 3 94 127 3 Fr Horn 2 | 2 104 8 3 Dream Pad | 6 118 18 3 Jungle SD
7 118 19 3 909 SD |
| 19 82 29 3 SH-101 Saw | B47 95 0 3 Halo Pad | 3 104 9 3 Silky Pad | 8 118 127 3 Taiko |
| 13 02 23 3 311-101 3041 | ה ה ה Tally rdu | 4 104 16 3 New Century | Contraction of the Contract of |
| 20 82 30 3 CS Saw | 1 95 1 3 Vox Pad | | D77 440 0 7 7 11 7 |
| 20 82 30 3 CS Saw
21 82 31 3 MG Saw Lead | 2 95 2 3 Vox Sweep | 5 104 17 3 7th Atmos. | B77 119 0 3 Synth Drum |
| 20 82 30 3 CS Saw
21 82 31 3 MG Saw Lead
22 82 32 3 OB Saw Lead | 2 95 2 3 Vox Sweep
3 95 8 3 Horror Pad | 5 104 17 3 7th Atmos.
6 104 18 3 Galaxy Way
7 104 127 3 Xylophone | 877 119 0 3 Synth Drum
1 119 8 3 808 Torn
2 119 9 3 Elec Perc |
| 20 82 30 3 CS Saw
21 82 31 3 MG Saw Lead | 2 95 2 3 Vox Sweep | 6 104 18 3 Galaxy Way | 1 119 8 3 808 Tom |

GBN Var PC CC00 CC32 Name 4 119 11 3 606 Tom 5 119 12 3 909 Tom 6 119 127 3 Taiko Rim B78 120 0 3 Reverse Cym. 1 120 1 3 Reverse Cym. 2 120 2 3 Reverse Cym. 3 120 8 3 Rev.Snare 1 4 120 9 3 Rev.Snare 2 5 120 16 3 Rev.Kick 1 6 120 17 3 Rev.ConBD 7 120 24 3 Rev.Tom 2 9 120 127 3 Cymbal B81 121 0 3 GL.FretNoise 1 121 1 3 GL.Cut Noise 2 121 2 3 String Slap 3 121 3 3 GL.Cut Noise 4 121 4 3 Dist.Cut Noise 4 121 4 3 Dist.Cut Noise 5 121 5 3 Bass Slide 6 121 6 3 Pick Scrape 7 121 8 3 GL.Fx Menu 8 121 9 3 Barto Riz. 9 121 10 3 Guitar Slap	GBN Var PC CC00 CC32 Name 10 121 11 3 Chord Stroke 12 121 13 3 Biwa Stroke 12 121 13 3 Biwa Stroke 12 121 13 3 Biwa Tremolo 13 121 127 3 Castanets Castanets	GBN Var PC CC00 CC32 Name 6 124 127 3 Telephone 885 125 0 3 Telephone 1 1 125 1 3 Telephone 2 2 125 2 3 DoorCreaking 3 125 3 3 Door 4 125 4 3 Scratch 5 125 5 3 Wind Chims 6 125 7 3 Scratch 2 7 125 8 3 Scratch 2 7 125 8 3 Scratch 2 9 125 10 3 Phono Noise 10 125 11 3 Mc-500 Reep 11 125 127 3 Bird Tweet 886 126 0 3 Helicopter 1 126 1 3 Car-Engine 2 126 2 3 Car-Stop 3 126 3 3 Siren 6 126 4 3 Car-Crash 5 126 5 3 Siren 6 126 7 3 Jetplane 8 126 8 3 Starship 9 126 9 3 Burst Noise 10 126 10 3 Caiculating	GBN Var PC CC00 CC32 Name 11 126 11 3 Perc. Bang 12 126 127 3 OneMote Jam B87 127 0 3 Applause 1 127 1 3 Laughing 2 127 2 3 Screaming 3 127 3 3 Punch 4 127 4 3 Heart Beat 5 127 5 3 Footsteps 6 127 6 3 Applause 2 7 127 7 3 Small Club 8 127 8 3 Applause Wave 9 127 16 3 Applause Wave 9 127 16 3 Voice One 10 127 17 3 Voice Two 11 127 18 3 Voice Three 12 127 19 3 Voice Whey 14 127 127 3 Water Bell B88 128 0 3 Gun Shot 1 128 1 3 Machine Gun 2 128 2 3 Lasergun 3 128 3 3 Explosion 4 128 4 5 Full State 5 128 5 3 Big Shot 6 128 127 3 Jungle Tune
GBN Var PC CC00 CC32 Name A11 1 0 2 Plano 1 1 1 8 2 Plano 1w 2 1 16 2 Plano 1d 3 1 126 2 Plano 2 4 1 127 2 Acou Plano 2 1 2 8 2 Plano 2w 1 2 8 2 Plano 2w 2 2 126 2 Plano 2 3 2 127 2 Acou Plano 2 3 2 127 2 Acou Plano 2	GBN Var PC CC00 CC32 Name 3 12 126 2 Steel Gt. 4 12 127 2 Elec Org 4 A25 13 0 2 Marimba 1 13 8 2 Marimba w 2 13 16 2 Barafon 3 13 17 2 Barafon 2 4 13 24 2 Log drum 5 13 126 2 12-str.Gt 6 13 127 2 Pipe Org 1	GBN Var PC CC00 CC32 Name A36	GBN Var PC CC00 CC32 Name 3 31 8 2 FeedbackGt 4 31 9 2 FeedbackGt2 5 31 16 2 PowerGuitar 6 31 17 2 Power Gt.2 7 31 18 2 5th Dist. 8 31 24 2 Rock Rhythm 9 31 25 2 Rock Rhythm 10 31 126 2 Choir Aahs 11 31 127 2 Syn Bass3
A13 3 0 2 Piano3 1 3 1 2 EG-Rhodes 1 2 3 2 2 EG-Rhodes 2 3 3 8 2 Piano 3w 4 3 126 2 Piano 2	A26 14 0 2 Xylophone 1 14 126 2 Funk Gt. 2 14 127 2 Pipe Org 2 A27 15 0 2 Tubularbell	2 23 126 2 Slap Bass 2 3 23 127 2 Celesta 1 A38 24 0 2 Bandoneon 1 24 8 2 AccJuno-106 2 24 16 2 DetunedAcc2	A48 32 0 2 Gt.Harmonix 1 32 8 2 Gt.Feedback 2 32 16 2 Ac.Gt.Harm. 3 32 126 2 Choir Aahs 4 32 127 2 Syn Bass4
5 3 127 2 Acou Piano3 A14 4 0 2 Honky-tonk 1 4 8 2 Old Upright	1 15 8 2 Church Bell 2 15 9 2 Carillon 3 15 126 2 Muted Gt. 4 15 127 2 Pipe Org3	3 24 17 2 It. Musette 4 24 126 2 Fingered Bs 5 24 127 2 Celesta 2	A51 33 0 2 AcousticBs. 1 33 126 2 Choir Aahs 2 33 127 2 Fantasy
2 4 126 2 Honky-tonk 3 4 127 2 Elec Piano 1 1 5 8 2 St.Soft EP 2 5 9 2 SA.E.Piano 3 5 16 2 PM-SA.EP 4 5 17 2 Stiky Rhodes 5 5 24 2 60's EPiano 6 5 25 2 Hard Rhodes	A28 16 0 2 Santur 1 16 1 2 Santur 2 2 16 8 2 Cimbalom A31 17 0 2 Organ 1 1 17 1 2 Organ 101 2 17 8 2 DetunedOr.1 3 17 9 2 Organ 109 4 17 16 2 60'sOrgan 1	A41 25 0 2 Nylonstr.Gt 1 25 8 2 Ukulele 2 25 16 2 Nylon Gt.2 3 25 24 2 VeloHarmnix 4 25 32 2 Nylon Gt.2 5 25 40 2 Lequint Gt. 6 25 126 2 Fingered Bs 7 25 127 2 Syn Brass 1 A42 26 0 2 Steelstr.Gt	A52 34 0 2 FingeredBs. 1 34 1 2 FingeredBs. 2 34 2 2 Jazz Bass 3 34 126 2 SlowStrings 4 34 127 2 Harmo Pan A53 35 0 2Picked Bass 1 35 8 2 MutePickBs. 2 35 126 2 Strings 3 35 127 2 Chorale
7 5 26 2 MellwRhodes 8 5 27 2 60°SE/Piano2 9 5 126 2 Piano 1 10 5 127 2 Elec Piano2 A16 6 0 2 E.Piano 2 1 6 8 2 Detuned EP2 2 6 16 2 SLFM EP 3 6 24 2 Hard FM EP	5 17 17 2 60'SOrgan 2 6 17 18 2 60'SOrgan 3 7 17 24 2 CheeseOrgan 8 17 32 2 Organ 4 9 17 33 2 Even Bar 10 17 40 2 Organ Bass 11 17 48 2 Organ Oct 1 12 17 126 2 Slap Bass 1 13 17 127 2 Harpsi 1	1 26 8 2 12-str.Gt 2 26 9 2 Nylon+Steel 3 26 16 2 Mandolin 4 26 17 2 Mandolin 2 5 26 18 2 Mandolin Tr 6 26 32 2 Steel Gt.2 7 26 126 2 Picked Bass 8 26 127 2 Syn Brass 2	3 35 127 2 Chorale A54 36 0 2 FretlessBs. 1 36 1 2 FretlessBs3 2 36 2 2 FretlessBs3 3 36 3 2 FretlessBs3 4 36 4 2 SynFretless 5 36 5 2 Mr.Smooth 6 36 126 2 SynStrings3 7 36 127 2 Glasses
4 6 126 2 Piano 2 5 6 127 2 Elec Piano 3 A17 7 0 2 Harpsichord 1 7 8 2 Coupled Hps 2 7 16 2 Harpsi.w	A32 18 0 2 Organ 2 1 18 1 2 Organ 201 2 18 8 2 DetunedOr 2 3 18 32 2 Organ 5 4 18 126 2 Slap Bass 1	A43 27 0 2 Jazz Gt. 1 27 1 2 Mellow Gt. 2 27 8 2 Pedal Steel 3 27 126 2 Picked Bass 4 27 127 2 Syn Brass3	A55 37 0 2 Slap Bass 1 1 37 8 2 Reso Slap 2 37 126 2 SynStrings3 3 37 127 2 Soundtrack
3 7 24 2 Harpsi.o 4 7 126 2 Piano 2 5 7 127 2 Elec Piano4	5 18 127 2 Harpsi 2 A33 19 0 2 Organ 3 1 19 8 2 Rotary Org.	A44 28 0 2 Clean Gt. 1 28 1 2 Clean Gt. 2 2 28 2 2 OpenHard Gt 3 28 8 2 Chorus Gt.	A56 38 0 2 Slap Bass 2 1 38 126 2 Organ 1 2 38 127 2 Atmosphere
A18 8 0 2 Clav 1 8 125 2 E.Piano 1 2 8 127 2 Honkytonk A21 9 0 2 Celesta 1 9 126 2 Detuned EP1 2 9 127 2 Elec Org 1	2 19 16 2 RotaryOrg.5 3 19 24 2 RotaryOrg.F 4 19 126 2 Slap Bas 1 5 19 127 2 Harpsi 3 A34 20 0 2 ChurchOrg.1 1 20 8 2 ChurchOrg.2 2 20 9 2 Organ Oct 2	4 28 9 2 JC Strat Gt 5 28 126 2 Fretless Bs 6 28 127 2 Syn Brass4 A45 29 0 2 Muted Gt. 1 29 1 2 Muted Gt. 2 29 2 2 Muted Gt. 3 29 8 2 Funk Pop	A57 39 0 2 Sym.Bass 1 1 39 1 2 Sym.Bass 10 2 39 8 2 Acid Bass 3 39 9 2 T8303 Bass 4 39 10 2 Tekno Bass 5 39 16 2 Reso SHBass 6 39 126 2 Organ 1 7 39 127 2 Warm Bell
A22 10 0 2 Glockrspiel 1 10 126 2 E.Piano 2 2 10 127 2 Elec Org 2 A23 11 0 2 Music Box	3 20 16 2 ChurchOrg.3 4 20 24 2 Organ Flute 5 20 32 2 Trem.Flute 6 20 126 2 Slap Bass 2 7 20 127 2 Clavi 1	4 29 16 2 Funk Ct2 5 29 126 2 Acoustic Bs 6 29 127 2 Syn Bass 1 A45 30 0 2 OverdriveCt	A58
1 11 126 2 Steel Gt. 2 11 127 2 Elec Org 3 A24 12 0 2 Vibraphone	A35 21 0 2 Reed Organ 1 21 126 2 Slap Bass 2 2 21 127 2 Clavi 2	1 30 126 2 Choir Aahs 2 30 127 2 Syn Bass 2 A47 31 0 2 DistortionG	4 40 8 2 Beef FMBass 5 40 9 2 X Wire Bass 6 40 16 2 Rubber Bass 7 40 17 2 SH101Bass 1
1 12 1 2 Hard Vibe 2 12 8 2 Vib.w		1 31 1 2 Dist. Gt2 2 31 2 2 DazedGuitar	8 40 18 2 5H101Bass 2 9 40 19 2 Smooth Bass

GBN	Vai 10	40	126	2	Name Organ 1	GBN A82	Var	PC 58	CC00	2	2 Name Trombone	GBN B28	Var	PC 80	CC00	((3)	Name Ocarina	GBN	Var 7	PC 99	CC00 7	(3	Name X'mas Beli
*****	11	40	127	2	Funny Vox		1 2	58 58	1 126	2	Trombone 2 Alto Sax		1	80	127	2	Sax 2		8	99 99	8	2	Vibra Bells Digi Bells
A61	1	41 41	0 8	2	Violin Slow Violin		3	58	127	2	Harp 1	831		81	0	2	Square Wave		10	99	16	2	ChoralBells
	2	41	16	2	Folk Violin	A83	Harrist State of the State of t	59	0	2	Tuba	e .	2	81 81	1	2	Square Hollow Mini		11 12	99 99	17 18	2	Air Bells Bell Harp
	3	41 41	17 126	2	FolkViolnVb Organ 2		1 2	59 59	1 126	2	Tuba 2 Brass 1		3	81 81	3	2	Mellow FM CC Solo		13	99	19	2	Gamelimba
	5	41	127	2	Echo Bell		3	59	127	2	Harp 2		5	81	5	2	Shmoog	TORVINA	14	99	127	2	Vibe 2
A62	***********	42	0	2	Viola	A84	**************************************	50	0	2	Muted Tp.	•	5 7	81 81	6 8	2	LM Square Sine Wave	B54	1	100	0	2	Atmosphere Warm Atmos
	1	42 42	126 127	2	Organ 1 Ice Rain		1 2	60 60	126 127	2	Brass 1		8	81	127	2	Sax 3		2	100	2	2	Nylon Harp
			-	-	W. Martine Laborated Transcriptor (1) Superior States		4	rickamija		2	Guitar 1	. B32	A 40************************************	82	0	2	Saw Wave		3	100	3 4	2	Harpvox HollowRels.
A63	1	43 43	0 126	2	Cello Organ 1	A85	1	61 61	0	2	FrenchHorns Fr.Horn 2		1 2	82 82	1 2	2	Saw Pulse Saw		5	100	5	2	NylonRhodes
	2	43	127	2	Oboe 2001		2	61	8	2	Fr.HornSolo		3	82	3	2	Feline GR		6 7	100 100	6 127	2	Ambient Pad Syn Mallet
A64	WATER STATE OF THE	44	0	2	Contrabass	res	3 4	61 61	16 126	2	Horn Orch Brass 2		4	82 82	4	2	Big Lead Velo Lead	B55		101	0		Brightness
A65	****	45	0	2	Tremolo Str	10	5	61	127	2	Guitar 2		6	82	6	2	GR-300	033	1	101	127	2	Windbell
	1	45	8	2	SlowTremolo	A86	OPICE-1912	62	0	2	Brass 1		7 8	82 82	7 8	2	LA Saw Doctor Solo	B56	W140404-44-44	102	0	2	Goblin
	3	45 45	9 126	2	SuspenseStr Organ 2		1 2	62 62	8 16	2	Brass 2 Brass Fall		9	82	16	2	Waspy Synth		1	102	1	2	Goblinson
	4	45	127	2	Doctor Solo		3	62	24	2	Brass Oct	venderlikele	10	82	127	2	Sax 4			102 102	2 127	2	50's Sci-Fi Glock
A66	i erren erren i	46	0	2	Pizz. Str.	D#	4 5	62 62	126 127	2	Brass 2 Elec Gtr 1	833	1	83 83	0	2	SynCalliope Vent Synth	B57	**********	103	0	<u>-</u>	Echo Drops
	1 2	46 46	126 127	2	Organ 2 School Daze	A87	-	63	0		SynthBrass1		2	83	2	2	PurePanLead			103	1	2	Echo Bell
A67	-	47	0		and sent all the later and the sent and the	~ 01	1	63	1	2	Poly Brass	B34	3	83 84	127 0	2	Clarinet 1 ChifferLead			103 103	2	2	Echo Pan Echo Pan Z
AD/	1	47	126	2	Harp Trumpet		2	63 63	8	2	Syn.Brass 3 Quack Brass		1	84	127	2	Clarinet 2		4	103	4	2	Big Panner
	2	47	127	2	Bellsinger		4	63	16	2	OctaveBrass	B35	1	85 85	0 8	2.	Charang Dist.Lead			103 103	5 6	2	Reso Panner Water Piano
A68	-	48	0	2	Timpani	H+	5 6	63 63	126 127	2	Brass 1 Elec Gtr 2		ż	85	127	2	Oboe			103	127	Ž	Tube Bell
	1 2	48 48	126 127	2	Trumpet Square Wave	A88	-	-cion-		·***	E-WART THE STATE OF THE STATE O	936	1	86 86	0 127	2	Solo Vox Engl Horn	B58	ore common	104	0	2	Star Theme
Ä71		49	0	2	Strings	~ A88	1	64 64	0 1	2	Syn.Brass 2 Soft Brass	B37	- Innextonation	-	87	0	25th Saw			104 104	1 127	2	StarTheme 2 Xylophone
M/ I	1	49	i	2	Strings 2		2	64 64	8 16	2	Syn.Brass 4 VeloBrass 1	151	1	87	1	2	Big Fives	DE 4	-	105	Manager 10	*	Partinental de la companya della companya della companya de la companya della com
	2	49 49	8 9	2	Orchestra Orchestra 2		4	64	17	2	VeloBrass 2		2	87	127	2	Bassoon	B61		105 105	0	2	Sitar Sitar 2
	4	49	10	2	TremoloOrch		5 6	64 64	126 127	2	Orchest.Hit Sitar	B38		88	Ō	2	Bass & Lead		2	105	2	2	DetuneSitar Tambra
	5 6	49 49	11 16	2	Choir Str. St.Strings	April Administra	u necessa	-	Delmaningo		and the last transfer and the same of the		1 2	88 88	1 2	2	Big & Raw Fat & Perky		4	105 105	8 16	2	Tambra Tamboura
	7	49	24	2	VeloStrings	B11	ı	65 65	0 127	2	Soprano Sax Acou Bass 1		3	88	127	2	Harmonica		5	105	127	2	Marimba
	8	49 49	32 126		Strings Oct Trombone	B12		66	0	2	Alto Sax	B41	MARKATE STATE	89	0	2	Fantasia	B62		106	0	2	Banjo
	10				Str Sect 1	914	1	66	8	2	Hyper Alto		1 2	89 89	1 127	2	Fantasia 2 Trumpet 1			106 106	1 8	2	Muted Banjo Rabab
A72	and the state of	50	0	2	SlowStrings	4	2	66 66	9 17	2	Alto Sax 2 Folk A.Sax	7 45 T			all white	-			3	106	16	2	Gopichant
	1	50	1		Slow Str. 2		4	66	18	2	FolkA.SaxVb	842	1	90 90	0 1	2	Warm Pad Thick Pad			106 106	24 25	2	Oud Oud 2
	3	50 50			Legato Str. WarmStrings		5	66	127	2	Acou Bass 2		2	90	2	2	Horn Pad		6	106	28	2	Oud&Strings
	4	50 50			St.SlowStr. Trombone	B13		67	0	2	Tenor Sax		3	90 90	3	2	RotaryStrng Soft Pad	wicestagen	7	106	127	2	Koto
	6				Str Sect 2		1 2	67 67	1	2	Tenor Sax 2 BreathyTnr.		5	90	127	2	Trumpet 2	863		107 107	0	2	Shamisen Tsugaru
A73		51	0	2	SynStrings1	,	3	67	127	2	Elec Bass 1	B43	- Composition	91	G	2	Polysynth			107	127	2	Sho
	1	51	1	2	OB Strings	814	LINES IL TRAVERS	68	0	2	BaritoneSax		1	91 91	1 127	2	80'sPolySyn Trombone 1	B64	*******	108	0	2	Koto
	3	51 51			SynStrings3 Trombone		1	68	127	2	Elec Bass 2	844	~~~~	92	0	2	Space Voice			108 108	8	2	Taisho Koto
	4	51	127	2	Str Sect3	B15		69	0	2	Oboe	544	1	92	1	2	Heaven II			108	16 17	2	Kanoon Kanoon 2
A74	************	52			SynStrings2		1	69	127	2	Siap Bass 1		2	92	127	2	Trombone 2			801	18	2	Kanoon Oct
	1 2				Trombone Pizzicato	B16	1	70 70	0 127	2	EnglishHorn Slap Bass 2	B45		93	0	2	Bowed Glass			108 108	19 127	2	Knoon&Choir Shakuhachi
A75	- COMPANY	nickdrajowy.ie	and the same of	un Naphari	no national and a constitution of a production of the constitution	B17	-	-	Principal Control	rentenne	· Cycocomedianical services and compared to the compared to th	ON HOUSE MA	1	93	127	2	Fr Horn 1	B65	*********	109	0	2	Kalimba
W13	1	53 53	8	2	Choir Aahs St.Choir	B1/	1	71 71	0 127	2	Bassoon Fretless 1	B46	•	94 94	0	2	Metal Pad Tine Pad				127	2	Whistle 1
	2	53 53			Mello Choir ChoirAahs 2	B18	te Dailerebel	72	0	2	Clarinet		2	94	ź	2	Panner Pad	B66	THE RESIDE	10	0	2	Bagpipe
	4	53	126	2	Trombone		1	72	8	2	Bs Clarinet		3	94	127	2	Fr Horn 2			110 110	8 9	2	Mizmar Mizmar Oct
	5	23	127	2	Violin 1		2 3	72 72	16 17	2	Folk Clarin FolkClarnVb	B47		95	0	2	Halo Pad		3	10	10	2	Mizmar Dual
A76	4	54			Voice Oohs		4		127		Fretless 2	0578/44/46	1	95	127	romaniante	Tuba	grane ·	4 1	10	127	2	Whistle 2
	1				Trombone Violin 2	821	-110 -1 Sidana	73	0	2	Piccolo	B48	1	96 96	0	2	Sweep Pad Polar Pad	B67		111	0	2	Fiddle
A77		55	er dates vises		SynVox		1	73 73	8	2	Nay Nay Oct		2	96	8	2	Converge	-photographys-a		111	****	2	Bottleblow
	1	55	8	2	Syn.Vaice				127		Flute 1		3 4	96 96	9 10	2	Shwimmer CelestialPd	B68		12	0	2	Shanai Shanai 2
	3				Alto Sax Cello 1	B22	maric (design)	74	0	2	Flute		5	96	127		Brs Sect 1		2 1	12	8	2	Pungi
A78	*********				Orch. Hit		1		127		Flute 2	851		97	0		Ice Rain				16 127	2	Hichiriki Breathpipe
M/4	1	56	8 .	2 1	Impact Hit	B23	recktop.uz	75	0		Recorder		1 2	97 97	1 2	2	Harmo Rain AfricanWood	871	+ inkinativi	13	0	2	Tinkle Bell
	2				Philly Hit Double Hit		1	75	127	2	Piccolo 1		3	97	8	2	Clavi Pad	9/1	1 1	13	8	2	Bonang
	4	56	16	2 1	Lo Fi Rave	B24	1	76 76	0		Pan Flute		4	97	127	2	Brs Sect 2			13 13	9 10	2	Gender GamelanGong
	5 6				Tenor Sax Cello 2		2	76	8 9		Kawala Kawala 2	B52	4	98	0		Soundtrack		4 1	13	11	2	St.Gamelan -
A81		na conspinare de	~~~~	~~~	Artine Sales (w/m) w///m m math-quine:				10 127	2	Kawala Oct		1	98 98	1		Ancestral Prologue			13 13	16 127	2	RAMA Cymbal Timpani
AB Í	1	57			Frumpet Frumpet 2	- TABLES AND SE		-	fred Mitthroom	MACO DONN	Piccolo 2		3	98	8		Rave	073	~		********		granden granden and a second and a
	2	57	8 :	2 f	Flugel Horn	B25		77 77	0 127		Bottle Blow Recorder	B53	*******	99	0		Crystal	B72		14 14	8	2	Agogo Atarigane
	3 4				FolkTrumpet FolkTrumpVb	DOC.			-	en-re-en-	Militar de Materia de la compansa del compansa de la compansa del compansa de la		1 2	99 99	1 2		Syn Mallet SoftCrystal		2 1				Melodic Tom
	5	57	24	2 E	Bright Tp.	B26			0 127		Shakuhachi Pan Pipes		3	99	3	2	Round Glock	B73		15			Steel Drums
	6 7		25 2 26 2		Warm Tp. BaritoneSax	B27	****		0		Whistle		4 5	99 99	4 5		Loud Glock GlocknChime		1 1	15	127		Deep Snare
	8				Contrabass	JEI			127		Sax 1		6	99	6		Clear Bells						

GBN B74	Var 1 2	116 116 116 117 117 117	0 8 127	2 2 2 2 2 2	Name Woodblock Castanets Elec Perc 1 Taiko Concert BD Elec Perc 2	GBN	Var 4 5 6 7 8	PC 120 120 120 120 120 121	CC00 16 17 24 25 127	CC3 2 2 2 2 2 2	2 Name Rev.Kick 1 Rev.ConBD Rev.Tom 1 Rev.Tom 2 Cymbal Gt.FretNoiz Gf.CutNoise	GBN B84	Va 4 5 6 1 2 3	12 12 12 12 12 12 12	3 4 3 5 3 127 4 0 4 1 1 2	2 2 2 2 2 2 2 2 2	2 Name Stream Bubble Orche Hit Bird Dog HorseGallop Bird 2		2 3 4 5 6 7 8 9	126 126 126 126 126 126 126 126	3 4 5 6 7 8	2 2 2 2 2 2 2 2 2	Car-Stop Car-Pass Car-Crash Siren Train Jetplane Starship Burst Noise OneNote Jam
876 877	1 2 3 4	118 118 118 118 118 119 119	0 1 8 9 127 0 8	2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	Melo. Tom 1 Real Tom Melo. Tom 2 Rock Tom Taiko Synth Drum 808 Tom Elec Perc	олимом В82	2 3 4 5 6 7	121 121 121 121 121 121	2 3 4 5 6 127	2 2 2 2 2 2	String Slap Gt.CutNz. 2 Dist.CutNz. Bass Slide Pick Scrape Castanets BreathNoise	B85	4 5 6 1 2 3	12: 12: 12: 12: 12: 12:	4 1 5 1 127 5 0 5 1 5 2 5 3	2 2 2 2 2 2 2 2	Kitty Growl Telephone Telephone 1 Telephone 2 Creaking Door	887	1 2 3 4 5 6 7	127 127 127 127 127 127 127	0 1 2 3 4 5	2 2 2 2 2 2 2	Applause Laughing Screaming Punch Heart Beat Footsteps Applause 2
B78	1 2 3	119 120 120 120 120	0 1 8 9	2 2 2 2 2	Taiko Rim Reverse Cym ReverseCym2 Rev.Snare 1 Rev.Snare 2	B83	1 2 3	122 122 123 123 123 123	1 127 0 1 2 3	2 2 2 2 2	Fl.KeyClick Triangle Seashore Rain Thunder Wind	B86	4 5 6 7	12: 12: 12: 12: 12: 12:	5 7 127	2 2 2 2 2 2 2	Scratch Wind Chimes Scratch 2 Bird Tweet Helicopter Car-Engine	B88	1 2 3 4	128 128 128 128 128	0 1 2 3	2 2 2 2 2 2	Water Bell Gun Shot Machine Gun Lasergun Explosion Jungle Tune
Ш	IIE	Ma																					
GBN A11	Var 1 2 3	1 1 1	0 8 16 126	1 1 1 1	Name Piano 1 Piano 1w Piano 1d Piano 2	GBN A27	Var 1 2 3	15 15 15 15	0 8 9 126	1 1 1	Name Tubularbeli Church Beli Carillon Muted Gt.	GBN A45	Var 3	28 29 29	127 0 8	1	2 Name Syn Brass4 Muted Gt. Funk Gt.	GBN A64	Var 1 2	44 44 44	0 126 127	1	2 Name Contrabass Organ 2 Echo Pan
A12	1 2	1 2 2 2	0 8 126	1	Acou Piano 1 Piano 2 Piano 2w Piano 2	A28	4 1 2	15 16 16 16	127 0 126 127	1 1 1	Pipe Org3 Santur Slap Bass 1	A46	2 3 4	29 29 29	16 126 127	1 1 1	Funk Gt.2 Acoustic Bs Syn Bass 1 OverdriveGt	A65	1 2	45 45 45	0 126 127	1	Tremolo Str Organ 2 Doctor Solo
A13	3 1	2 3 3	127 0 8	1	Acou Piano2 Piano 3 Piano 3w	. IEA	1 2	17 17 17	0 8 16	1 1 1	Accordion Organ 1 Detuned Or1 60's Organ 1	A47	1 2	30 30 30	126 127	1	Choir Aahs Syn Bass 2 Dist.Gt.	A60	1 2	46 46 46	0 126 127	1 1	Pizzicato Organ 2 School Daze Harp
A14	3	3 3	126 127	1	Piano 2 Acou Piano3 Honky-tonk		3 4 5	17 17 17	32 126 127	1	Organ 4 Slap Bass 1 Harpsi 1	••••	1 2 3	31 31 31	8 126 127	1 1	Feedback Gt Choir Aahs Syn Bass3	A68	1 2	47 47 48	126 127	1	Trumpet Bellsinger Timpani
	1 2 3	4 4	8 126 127	1	HonkyTonk w Honky-tonk Elec Piano1	A32	1 2 3	18 18 18 18	0 8 32 126	1 1 1	Organ 2 Detuned Or2 Organ 5 Slap Bass 1	A48	1 2 3	32 32 32 32	0 8 126 127	1	Gt.Harmonix Gt.Feedback Choir Aahs Syn Bass4	A71	1 2	48 48 49	126 127	i 1	Trumpet Square Wave Strings
A15	1 2 3 4	5 5 5 5	0 8 16 24 126	1 1	E.Piano 1 Detuned EP1 E.Piano 1v 60s E.Piano Piano 1	ŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽŽ	1 2	18 19 19	127 0 126 127	1 1 1	Harpsi 2 Organ 3 Slap Bass 1 Harpsi 3	A51	1 2	33 33 33	0 126 127	1 1	Acoustic Bs Choir Aahs Fantasy	A72	1 2 3	49 49 49 50	8 126 127	1	Orchestra Trombone 5tr Sect 1
A16	5 1 2	5 6 6	127 0 8 16	1	Elec PianoZ E.Piano 2 Detuned EP2 E.Piano 2v	A34	1 2 3	20 20 20 20 20	0 8 16	1 1	Church Org1 Church Org2 Church Org3	A52 A53	1 2	34 34 34	0 126 127	1 1	Fingered Bs SlowStrings Harmo Pan Picked Bass	A73	1 2	50 50 51 51	126 127 0 8	1 1 1	Trombone Str Sect 2 SynStrings1 SynStrings3
A17	3 4	6	126	1	Piano 2 Elec Piano3 Harpsichord	A35	3 4 1	20 20 21 21	126 127 0 126	1	Slap Bass 2 Clavi 1 Reed Organ Slap Bass 2	A54	2	35 35 36	126 127 0	i 1	Strings Chorale Fretless Bs	A74	2 3	51 51	126 127	1	Trombone Str Sect3
,,,,	1 2 3 4	, 7 7 7	8 16 24	1 1	Coupled Hps Harpsi.w Harpsi.o Piano 2	A36	1		127 0 8	1	Clavi 2 Accordion F Accordion I	A55	2	36 36 37	126 127 0	1	SynStrings3 Glasses Slap Bass 1	A75	1 2	52 52 53	126 127 0	1	Trombone Pizzicato
A18	1	8	0 126	1 (Elec Piano4 Clav. E Piano 1	Ã37	3	22 23	126 127 0	1	Slap Bass 2 Clavi 3 Harmonica	A56	1 2	37 37 38 38	126 127 0 126	1	SynStrings3 Soundtrack Slap Bass 2	A76	1 2 3	53	127	•	Choir Aahs2 Trombone Violin 1
A21	1	9	0 126	1 (lonkytonk Celesta Detuned EP1	A38	A STATE OF THE STATE OF	23 24	127 0	1	Slap Bass 2 Celesta 1 Bandoneon Fingered Bs	A57	2	38 39 39	127 0 1	1	Organ 1 Atmosphere Syn.Bass 1 Syn.Bass 101	A76	2	54 54 54 55	0 126 127	1	Voice Oohs Trombone Violin 2
A22	1	10 10	0 126	1 (1 E	ilec Org 1 ilockenspl Piano 2	A41	2		126 127 0 8	1	Celesta 2 Nylon Gt.		2 3 4	39 39 39	8 126 127	1	Syn.Bass 3 Organ 1 Warm Bell	A78	1 2	55 55 56	126 127	1	Alto Sax Cello 1
A23		11 11	0 126	1 A	lec Org 2 Music Box teel Gt. lec Org 3		2 3 4	25 25 25	16 32 126 127	1 1 1	Ukulele Nylon Gt.o Nylon Gt.2 Fingered Bs Syn Brass 1	A58	1 2 3	40 40 40 40	0 B 16 126	1 † 1 1	Syn.Bass 2 Syn.Bass 4 Rubber Bass Organ 1	A81	1 2	56 56 57	126	1	Tenor Sax Cello 2
A24	1	12 12	0	1 V	fibraphone fib.w teel Gt.	Á42	1	26 26	0 8 16	1	Steel Gt. 12-str.Gt Mandolin	A61	1	40 41 41	127 0 8	1	Funny Vox Violin Slow Violin	A82	2	57 57 58		1	BaritoneSax Contrabass Trombone
	3 1	12 1	0	I E	lec Org 4 Aarimba Aarimba w	A43	3 4	26	126	1	Picked Bass Syn Brass 2 Jazz Gt.	A62	2	41 41 42	126 127 0	1	Organ 2 Echo Bell Viola	NYNGC EP YE MAN	1 2 3	58	127	1	Trombone 2 Alto Sax Harp 1
	2	13 1 13 1	26	l 1	2-str.Gt ipe Org 1 ylophone		1 2	27 27	8 126	1	Hawaiian Gt Picked Bass Syn Brass3	A63	1 2		126 127 0	1	Organ 1 Ice Rain Cello	A83	1 2	59	126 127	1	Tuba Brass 1 Harp 2
		14 1	26	F	unk Gt. ipe Org 2	A44	1	28	0 8 126	1	Clean Gt. Chorus Gt. Fretless Bs		1		126 127	1	Organ 1 Oboe 2001	A84	1 2			1	MuteTrumpet Brass 1 Guitar 1

				L/Jungarymon Programme - S Empriment Library St. S	-		المنت المناوم	G-ESSTON-		managamanga melasak sama anema serbesik e	********	ning states	-	ARBOUTH RE	****	engar arawayan kenangan menangan r
GBN A85	Var	PC 61	CC00 CC	2 Name French Horn	GBN B43	Var	91	0	CC32	Name Polysynth	GBN	Var 3	PC 121	127	1	Name Castanets
	1	61	1 1	Fr.Horn 2		1	91	127	1	Trombone 1	B82	***	122	0	1	BreathNoise
	2	61	126 1 127 1	Brass 2 Guitar 2	B44	in secondaria	92	0	1	Space Voice	DUL	1	122	1	i	Fl.KeyClick
	3	61	127	GUILAI 2		1	92	127	1	Trombone 2		2	122	127	1	Triangle
AB6	BY CONTRACTOR	62	0 1	Brass 1	**********	DH/W/MGD	and the	and the same	wearn	Mark Market Commerce of the Co	-	ect seemod	- Constituti			Constant and the second
	1	62	8 1	Brass 2	845		93 93	0	1	Bowed Glass Fr Horn 1	883	1	123 123	0	1	Seashore Rain
	2	62	126 1			1	23	127	1	FT FIGHT 1		2	123	ż	i	Thunder
	3	62	127 1	Elec Gtr 1	846	MA ELLAND	94	0	1	Metal Pad		3	123	3	1	Wind
A87	Marie Dis	63	0 1	Syn.Brass 1		1	94	127	1	Fr Horn 2		4	123	4	1	Stream
	1	63	8 1	Syn.Brass 3	B47	www.no-	95	0	1	Halo Pad		5	123	5	1	Bubble Orche Hit
	2	63	16 1 126 1			1	95	127	i	Tuba		6	123	127	1	Orthe mit
	3	63 63	127 1		-			may room		· · · · · · · · · · · · · · · · · · ·	884		124	0	1	Bird
******	manuscri		EXPERIMENT OF THE OWN	namen alaksis interpresentation and a V	848	1	96 96	0 127	1	Sweep Pad Brs Sect 1		1	124	1	1	Dog
A88		64	0 1				70	127		DIS JEST 1		2	124 124	2	1	HorseGailop Bird 2
	1 2	64 64	8 1 16 1		B51		97	0	1	ice Rain		4	124	127	i	Telephone
	3	64	126 1			1	97	127	1	Brs Sect 2	(ter manusinatus					gerrier-caram-breism and artistration an
	4	64	127 1		B52	Note and Note of Street	98	0	1	Soundtrack	B85		125 125	0	1	Telephone 1 Telephone 2
B11	41.24-4-16.04	65	0 1	Soprano Sax		1	98	127	1	Vibe 1		2	125	2	1	Creaking
B 1 1	1	65	127 1		PENGE-N	man su	99	0	untere-	Crystal		3	125	3	1	Door
					B53	1	99	1	1	Syn Mailet		4	125	4	1	Scratch
B12		66	0 1			ż	99	127	i	Vibe 2		5	125	5	1	Wind Chimes
	1	66	127 1	Acou Bass 2	manistra	-	ngi ng mga kata	other and a second special second		THE PARTY AND ADDRESS OF THE PARTY AND ADDRESS		6	125	127	1	Bird Tweet
B13	aleman de s	67	0 1	Tenor Sax	854		100	0	1	Atmosphere	B86	T-MATE	126	0	1	Helicopter
0.3	1	67	127 1			1	100	127	1	Syn Mallet		1	126	1	1	Car-Engine
-		and restrict			855	********	101	0	1	Brightness		2	126	2	1	Car-Stop
B14		68	0 1			1	101	127	1	Windbell		3	126	3	1	Car-Pass
	1	68	127 1	Elec pass 2				Č	1	Goblin		4	126 126	4	1	Car-Crash Siren
B15	-	69	0 1	Oboe	856	1	102 102	127	1	Glock		6	126	6	i	Train
	1	69	127 1	Slap Bass 1	Output 1		102	12/		and the state of t		7	126	7	1	Jetplane
B16	Anna Marian	70	0 1	EnglishHorn	B57		103	G	1	Echo Drops		8	126	8	1	Starship
210	1	70	127 1			1	103 103	1 2	1	Echo Bell Echo Pan		9	126	9	1	Burst Noise
******	ottoene	~~~=	nto-makinohakrost			2	103	127	i	Tube Bell		10	126	127	1	OneNote Jam
B17		71	0 1	Bassoon Fretiess 1	UNNAUEZ	- waterest			E CONTRACTOR	The state of the s	B87		127	0	1	Applause
	1	71	127 1	Fretiess (858		104	0	1	Star Theme		1	127	1	1	Laughing
B18		72	0 1			1	104	127	1	Xylophone		2	127	2	1	Screaming Punch
	1	72	127 1	Fretless 2	861		105	G.	1	Sitar		3	127 127	3	1	Heart Beat
B21	محتمدا وترجمهم	73	0 1	Piccolo		1	105	1	1	Sitar 2		5	127	5	i	Footsteps
941	1	73	127			2	105	127	1	Marimba		6	127	127	1	Water Bell
-				La Marine (Dielle manifester ann all Mary processor (Marine (Marine))	862	***	106	0	1	Banjo				bernago vo		atriuministrativa nama
822		74	0 1		502	1	106	127	i	Koto	B88	1	128 128	0	1	Gun Shot Machine Gun
	1	74	127 1	Flute 2	a ferrower			NAME OF THE OWNER, WHEN	Antonio	personal contraction of the Pe		ż	128	ż	i	Lasergun
B23		75	0	Recorder	863		107	0	1	Shamisen		3	128	3	1	Explosion
	1	75	127	Piccolo 1		1	107	127	1	Sho		4	128	127	1	Jungle Tune
B24	a residentan	76	0	Pan Flute	B64		108	0	1	Koto						
044	1	76	127			1	108	8	1	Taisho Koto						
2.0%(12)	ng/www.com	P.4856-705	MINISTER STORY	garangen ann ann an ann an an an an an an an an		2	108	127	1	Shakuhachi						
825		77	8		865	*********	109	0	1	Kalimba						
	1	77	127	I Recorder		1	109	127	1	Whistle 1						
B26		78	0		PCC.	-	110	MODELE COM	1							
	1	78	127	l Pan Pipes	B66	1	110 110	0 127	1	Bagpipe Whistle 2						
B27	**********	79	0	l Whistle			110	121		biccommonwealthaman and a control						
827	1	79	127		867		111	0	1	Fiddle						
pir-resum:	ECHARISTON I		prespectation of the section	Committee and a series of a facility of the series of the		1	111	127	1	Bottlebiow						
828		80	0		B68	elocia (na Calaba	112	Ö	7	Shanai						
	1	80	127	Sax 2		1	112	127	1	Breathpipe						
B31	es ar event	81	0	Square Wave	enisseres	ncain situates	in the STate of	MONTH OF THE PARTY	1	Tinkle Bell						
	1	81	1 1	1 Square	B71	1	113	0 127	1	Timpani						
	2	81		Sine Wave	Jan	es prince r		FRAF		agroup transcription to the second second						
	3	81	127	1 Sax 3	872		114	0	1	Agogo						
B32	MA SALA	82	0	Saw Wave		1	114	127	1	Melodic Tom						
	1	82	1		B73	ANTO THE RES		115	Ō	1Steel Drums						
	2	82		Doctor Solo		1	115		ī	Deep Snare						
	3	82		Sax 4	Accesses to	and-on.	Academic W	-		Woodblock						
B33	ndrostia n & 1	83	0	1 SynCalliope	B74		116 116	8	1	Castanets						
	1	83	127			2	116	127	1	Elec Perc 1						
024	بديره بدخوري		0	1 ChifferLead		-		ne september 1. o	-							
B34	1	84 84		Clarinet 2	875		117	0	1	Taiko						
	-	-		- AND THE COMPANY OF THE PARK AND ADDRESS OF		1	117	8 127	1	Concert BD Elec Perc 2						
835		85		1 Charang		2	117	127		FIEL LEIC T						
	1	85	127	1 Oboe	B76	pro-Mad P = m + C	118	0	1	Melo. Tom 1						
B36	Lagionicamen	86	0	1 Solo Vox		1	118	8	1	Melo. Tom 2						
	1	86		1 Engl Harn		2	118	127	1	Taiko						
ere per	ودان تحييداني	and the second	*******	ACADISCO CONTRACTOR AND	877	- Carrier of the	119	0	1	Synth Drum						
B37	1	87 87		1 5th Saw 1 Bassoon		1	119	8	i	808 Tom						
		0/	14/	annum a		2	119	9	1	Elec Perc						
B38		88	0	1 Bass & Lead		3	119	127	1	Taiko Rim						
	1	88	127	1 Harmonica	B78	deryin-	120	0	1	Reverse Cym						
B41	MELON POTEN	89	0	1 Fantasia		1	120	127	1	Cymbal						
5-1 ;	1	89		1 Trumpet 1		war war	-te-best	-	****							
CIONE-	-	n-relative		na established to the state of	881		121	0	1	Gt.FretNoiz Gt.CutNoise						
842		90	-	1 Warm Pad		1 2	121 121	1	1	String Slap						
	1	90	127	1 Trumpet 2		2	121	-	•	-und such						

18.2 Drum Sets

	FC: 1 (CC32: 4) STANDARD 1	PC: 2 (CC32: 4) STANDARD 2	PC: 3 (CC32: 4) STANDARD L/R	PC: 4 (CC32: 4) V-Pop1St	PC: 5 (CC32: 4) V-R&B	PC: 6 (CC32: 4) V-Fiesta	PC: 9 (CC32: 4) ROOM	PC: 10 (CC32: 4) HIP HOP	PC: 11 (CC32: 4) STANDARD 1	PC: 12 [CC32: 4] TECHNO
	Standard 1	Std.1 Kick1	41 rusuretta ta 1	HipHop BD1	HipHop BD1	HipHop BD1	Std. Kick1	Elec Kick 2	Elec Kick 2	Elec Kick 2
;	Std.1 Kick2	Std.T Kick2	-	Jazz Kick 1	Jazz Kick 1	Jarz Kick 1	Std.1 Kick2	Elec Rick 1	Elec Kick 1	Elec Kick 1
	Std.2 Kick 1	Std.2 Kick1		Mex_Kik36	Mex_Kik36	Mex_Kik36	Std.2 Kick1	CR78 BD 1	CR78 BD 1	CR76 BO 1
3	Std2 Kick2	Std2 Kick2		BSRmBsDrum16	BSRmBsDrum18	85AmBsDrum 18	Std2 Kick2	CR78 BD 2	CR78 BD 2	CR78 BD 2 TR-606 BD1
	Kick 1	Kick 3	-	85Rm8sDrum28	85RmBsDrum28	85RmBsDnum29	Kick 1	TR-606 BD1 TR-707 BD	TR-606 BD1 TR-707 BD	TR-707 BD
	Kick 2	Kick 2		909 8D	909 BD 2	909 BD 2	Jazz Kick 1	808 Kick	808 Kirk	808 Kirk
ζ,	Jazz Kick 1	Jazz Kick 1		909 BD 2 ingl BD 2	Ingl BD 2	ingl BD 2	Jazz Kick 2	TR-808 Kick	TR-808 Kick	TR-868 Kick
أحني	Room Kick 1	Jazz Kick 2 Room Kick 1		HipHop BD	HipHop BD	HipHop 8D	Room Kick 1	808 BD	808 BD	808 ED
	Room Kick 2	Room Kick 2	*	HipHop BD 2	HipHop BD 2	HipHop 80 2	Room Kick 2	TR-909 Kick	TR-909 Xick	TR-909 Kick
11	Power Kick1	Power Kick 1	_	85StBsDrum 18	855t8sDrum18	855tBsDrum18	Power Kick!	Dance Kick 2	Dance Kick 2	Dance Kick 2
	Power Kick2	Power Kick2	-	NewizKik	NewizKik	NewizKik	Power Kick2	909 Comp BD	909 Comp BD	909 Comp 8D
	Elec Kick 2	Elec Kick 2	-	NewRockKik	NewflockKik	NewRockKik	Elec Kick 2	TR-909 BD2	TR-909 BO2	TR-909 8DZ
43	Elec Kick 1	Elec Kick 1		CymbalRoll	CymbalRoll	CymbaiRoll	Elec Kick 1	HipHop BD2	HipHop BD2 JungleBD Set	HipHop BD2 JungleBD Set
	TR-808 Kick	TR-808 Kick		NewRXCStkMn	NewAkCStkMn	NewRkCStkMn	TR-808 Kick TR-909 Kick	JungleBD Set Techno BD1	Techno BD1	Techno BD1
- 15	TR-909 Kick	TR-909 Kick		85RmSnare18 85RmSnare28	85RmSnare18 85RmSnare28	BSRmSnare IB BSRmSnare 2B	Dance Kick 2	Bounce	Bounce	Bounce
	Dance Kick 2	Dance Kick 7		855t5nare18	855t5nare18	85StSnare18	Voke One	Voice One	Voice One	Voice One
	Voice One Voice Two	Voice One Voice Two	Voice One Voice Two	855tSnare28	85StSnare28	855tSnare28	Voice Two	Voice Two	Voice Two	Vaice Twa
	Voice Three	Voice Three	Voice Three	Hewiz5nZ	Newlz5o2	Newiz5n2	Voice Three	Voice Three	Voice Three	Voice Three '
213	ESRm BsDrum1			Newiz5n1	Newla5n1	Newiz5n1	85St BsDrum1	ingi BD	HipHop BD 2	909 80
	85Rm 8sDrum2			NewR&BSn	NewR&BSn	NewR&BSn	BSSt BsDrum2	ingl 8D 2	HipHop 8D	fat 8D
12	MC-S00 Beep	MC-500 Beep	MC-500 Beep	WewflockSn2mn	MewRockSn2mn	NewRockSn2mn	MC-500 Beep	MC-500 Beep	MC-SOO Beep	MC-S00 Beep
	MC-500 Beep	MC-500 Beep	MC-500 Beep	NewRockSn Imn	NewRock\$n1mn	NewRockSnimn	MC-500 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep
e hi h	Concert Snr	Concert Snr	Concert Srar	PopSn38mn	Рорбизит	#opfin38mm	Concert Snr	Concert See	Concert Sex	Concert Sor Soure Roll
15	Snare Roll	Snare Roll	Snare Roll	PopGst539mn	IPopGst539mn	IPopGstS39mn	Snare Roll	Snare Roll FingerSnaps2	Snare Roll FingerSnaps2	Share Roll FingerSnaps2
reis		Finger Snap	FingerSnaps2	Popšeš ši me	IPopSe38mn	IPopón38mn EinnerSnans2	Finger Snap High-Q	High-Q	High-Q	High-Q
1	High-Q	High-Q	High-Q	FingerSnaps2	FingerSnaps2 707 Claps	FingerSnaps2 707 Claps	Siap	Slap	Slap	Slap
	Slap ScratchPush	Siap ScratchPush	Slap ScratchPush	707 Claps 808clap	805(lap	806dap	ScratchPush	Scritch Push2	Scretch Push2	Sortch Push2
	ScratchPush ScratchPuli	ScratchPush	ScratchPull	Hand clap2	Hand clap2	Hand clapZ	ScratchPull	Scrich Pull2	Scritch Puil2	Scrich Puil2
STORE SET	Sticks	Sticks	Sticks	909 HandClap	909 HandClap	909 HandClap	Sticks	Sticks	Sticks	Stocks
Mary Will.	SquareClick	SquareClick	SquareClick	(PopPHat32	PopPHst32	Mex_PHat32	SquareClick	SquareClick	SquareClick	SquareClick
	Mtrnm.Click	Mtrnm.Click	Mirrom Click	GospelHClp1	GospeiHClp1	GospetHClp1	Mtrnm.Cick	Mtrnm.Click	Mtmm Click	Mtrnm,Click
3.5	Mirnm. Bell	Mtmrs. Bell	Mtmm. Bell	(PopSRII3Ost	PopSRII30mn	Mex_SnrRol34	Mtrnm. Bell	Mtrnm. Beil	Mtmm. Bell	Mtmm. Bell
1	BsDrum1	StdZ Kick2	85518sDrum18	(PopKik35	PopKik35	Mex_Kik35	858m BsDrum1 858m BsDrum2	HipHop 8D 2 HipHop 8D	ingi BD 2	806 8D 909 8D 2
	855t BsDrum2	Std.2 Kick1	855tBsDrum28	(PopKik36	PopKik36	Mex_Kik36	Side Stick	808 Rimshot	Ingl SD Rim	909 SD Rim
37	Side Stick	Side Stick	Side Stick	iPopC3tk37st iPopSn38st	PopCStk37mn NewR&BSn	iPopCStk37mn Mex_Snr38	85Rm Snare2	Loff SD 1	HipHop SD 1	606 SD 2
1	855t Snare2	Std.2 Snare1	855tSnare28	IPopGstS39st	NewR&BSnGst	Mex Gst539	806riap	707 Claps	R&B Claps 1	909 Claps
	909 HandClap	Std.2 Snare2	909 HandClap 855tSnare18	PopSn40st	iPopSn40mn	Mex Snr40	858m Snare1	Lofi SD 2	Jingi SD	Techno 50
	855t Snare1 855t Tom16	Real Tom 6	855tTom168	(PopTomLFI41	IPopTomLFI41	PopTomLFI41	Room Tom 5	85/z Tom 16	909 Tom	606 Dist.Tom
	85St ChHat	Jazz Osd HH	assicisharB	IPopHat1_42	IPopHat1_42	Mex_Hat1_42	85Rm CkHat	Room Chh	606 CH	17R-707 HH-c
5 8 4000	855t Tom16	Real Yom 6	855t7om168	iPopTomL43	PopTomi.43	PopTomL43	Room Tom 5	85.b; Tom16	909 Tom	606 Dist. Tom
1.1	Peda) HiHat2	Pedal HiHat	Pedal HiHat2	PopHat2_44	(PopHat2_44	Mer_Hat2_44	Pedal HiHat	Pedal HiHat	Jungle HH	CR-78 chh
	855t Tom12	Real Tom 4	855tTom128	IPapTomMFI45	iPopTomMFI4S	PopTomMFI45	Room Tom 2	B5/z Tom13	909 Tom	606 Dist.Tom
	855t OpenHat	Jazz Open HH	855tOpenHatil	IPopHat3_46	IPopHat3_46	Mez Hat3 46	85Rm OpenHat	R8 Ohh2	606 HiHat Op	909 CH 506 Dist, Tom
	#55t Tom 12	Real Tom 4	8SStTom12B	IPspTomM47	IPopTomM47	PopTomM47	Room Tam 2	85/z Tom13	909 Tom	506 Dist Tora
a le	855t Tom 10	Real Tom 1	855tTom 108	iPopTomHFI48	PopTomHFI48	PopTomHFI48	Room Tom 2 85Rm CrsCyrn1	85iz Tom12 909 Crash	909 Tom Jngl Crash	909 Crash
:3	BSSt CrsCym1	Crash Cym.1	855tCrsCym18	IPopCymI2_52	iPopCym1_49 iPopTomH50	iPopCym1_49 iPopTomHS0	Room Tom 2	851z Tom12	909 Tom	506 Dist. Torn
	BSSI Tom10	Real Torn 1	85StRdCymB	iPopTomH50 iPopRd1_51	PopTomH50	PopRd1_51	85Rm RdCym	Ride Cymbal	Ride Cymbal	Ride Cymbal
EEE/CO.	B5St RdCym	Ride Cymbal	ChinaCymbal	iPopCym1_49	PopCymi2_52	PopCymi2_52	ChinaCymbal	ReverseCymbi	ReverseCymbi	ReverseCymbi
4	ChinaCymbai 855t RdBell	ChinaCymbal Ride Bell	#55tRdBellB	iPopRd2_55	IPopRd2_55	PopRd2_55	85Rm RdBell	Ride Bell	Ride Bell	Ride Bell
	Tambourine	Tambourine	Tambourine	Tambourine	Tambourine	Tambourine	Tambounne	Shake Tamb	Shake Tamb	Shake Tamb
STATE OF THE PARTY.	Splash Cym.	Spiash Cym.	Splash Cym.	Spiash Cym.	Splash Cym.	Splash Cym.	Splash Cym.	Splash Cym.	Splash Cym.	Splash Cym.
13	Cowbell	Cowbell Snare	Cowbell	ChaChaCliell	ChaChaCBell	ChaChaCBell	Cowbell	BOBcowbe	808cowbe	808cowbe 909 Crash
	Crash Cym.2	Crash Cym.2	Crash Cym.2	NewRkCrCym2	NewRkCrCym2	NewRkCrCym2	Crash Cym.2	Crash Cym.2	Crash Cym.Z	Vibraslap
35	Vibrasiap	Vibrasiap	Vibraslap	Vibraslap	Vibrasias	Vibraslap	Vibraslap Dide Combol	Vibrasiap Bide Cumbal	Vibrasiap Ride Cymbal	Ride Cymbai
	Ride Cymbal	Ride Cymbal	Ride Cymbai	NewRkRdCym1	NewHillongo	NewRkRdCym1 NewHiBongo	Ride Cymbal Songo High	Ride Cymbal Bongo High	Bongo High	CR78 HiBongo
7	Bongo High	Bongo High	Bongo High	NewHiBango HewLaBango	NewLoBongo	NewLoBongo	Bongo Lo	Bongo Lo	Bongo Lo	CR78 LoSongo
	Bongo Lo	Bongo Lo Mute H Conga	Bongo Lo Mute H.Conga	NewCongaSip	NewCongaSlp	NewCongaSip	Mute H.Conga	Mute H. Conga	Mute H.Conga	806 Conga
	Mute H.Conga Conga Hi Opn	Conga Hi Opn	Conga Hi Opn	NewCongaOp	NewCongaOp	NewCongaOp	Conga Hi Opn	Conga Hi Opn	Conga Hi Opn	806 Conga
		Conga Lo Opn	Conga Lo Opn	NewLoConga	NewLoConga	NewLoConga	Conga Lo Opn	Conga Lo Opn	Conga Lo Opn	808 Conga
		High Timbale	High Timbale	NewTmb#li	NewTmblfti	New1mblKi	High Timbale	High Timbale	High Timbale	High Timbale
escala)	Low Timbale	Low Timbale	Low Timbale	New Tmb&o	NewTmbilo	NewTmblLa	Low Timbale	Low Timbale	Low Timbale	Low Timbale
		Agogo	Agogo	Agogo	Agogo	Agoga	Agogo	Agogo	Agogo	Agogo
43	Agogo	Agogo	Agogo	Agogo	Agoga	Agogs	Agogo	Agogo Cabasa	Agogo Cabasa	Agogo Cabasa
10.00		Cabasa	Cabasa	NewShaker2	NewShaker2	NewShaker2	Cabasa Mararas	Cabasa B08marac	808marac	808marac
100	Maracas	Maracas	Maracas	NewShaker 1	NewShaker1 ShorMhistle	NewShaker1 ShrtWhistle	Maracas ShrtWhistle	ShrtWhistle	ShrtWhistie	ShrtWhistle
	ShrtWhistle	ShrtWhistle	ShrtWhistle LongWhistle	ShrtWhistle LongWhistle	ShrtWhistle LongWhistle	LongWhistle	LongWhistle	LongWhistle	LangWhistle	LongWhistle
	LongWhistle	LongWhistle Short Guiro	Short Guiro	NewQuide!	NewQuide1	NewQuide1	Short Guiro	Short Guiro	Short Guiro	Short Guiro
iner a	Short Guiro	Short Guiro Long Guiro	Long Guiro	NewQuide2	NewQuide2	NewQuide2	Long Guiro	CR78 Guiro	CR78 Guiro	CR78 Guito
90001112	Long Guiro Claves	Claves	Claves	NewClaves	NewClaves	NewClaves	Claves	80Bclave	808ciave	808clave
	Woodblock	Woodblock	Woodblock	Woodblock	Woodbiock	Woodblock	Woodblock	Woodblock	Woodblock	Woodbinck
17.00	Woodblock	Woodblock	Woodblock	Woodblock	Woodbick	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock
20	Mute Cuica	Mute Cuica	Mute Cuica	Mute Cuica	Mute Cuica	Mute Cuica	Mute Cuica	Hoo	Hoo	Hoo
	Open Cuica	Open Cuica	Open Cuica	Open Cuica	Open Cuica	Open Cuica	Open Cuica	Hoo	Hoo MetaTorogi	Hoo MuteTriangl
	MuteTriangl	MuteTriangl	MuteTriangl	MuteTriangl	MuteTriangl	MuteTriangl	MuteTriangl OpenTriangl	MuteTriangl OpenTriangl	MuteTriangi OpenTriangi	OpenTriangi
	OpenTriangl	OpenTriang	OpenTriangl Ebaker	OpenTriangl	OpenTriangl Shaker	OpenTriangl Shaker	OpenTriangi Shaker	Shaker 2	Ingl Shaker	626 Shake
encode de	Shaker	Shaker Shaker	Shaker George Reil	Shaker Jingle Bell	Jingle Bell	angie Bell	Jingle Bell	Jingle Bell	Jingle Bell	lingle Bell
	Jingle Bell	Jingle Bell	Jingle Bell Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree
New York	Bell Tree Castanets	Bar Chimes Castanets	Castanets	Castanets	Castanets	Castanets	Castanets	Castanets	Castanets	Castanets
	Murte Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo
	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo
	Applause 2	Applause 2	Applause 2	CRcif	CRcir	CRair	Applause 2	Small Club	Small Club	Applause 2
				NewTmblHiflm	NewTmbtHiFim	NewTmb#tiFlm		HipHop SD 2	ingl BD Roll	Dance SD
21	-			NewTmblLaflm	NewTmbiLoFim	HewTmblLoFim		LoFi SD Rim	Ingl SD Roll	House SD
1				NewTmbiPHS	NewTmbiPHS	HewTmbIPHS	**	HipHop Claps	606 SD 2	Rock SD Dry
- 32	_			NewShekere1	NewShekere1	NewShekere1		B55t Snare1	Dance SD Techno SD	Ingi SD LoFi SD 1
-				NewShekere2	NewShekere2	NewShekere2		8551 Snare2 RSRm Snare1	House SD	LoFi SD 2
-				NHBngoMute	NHBngoMute	NHBngoMute NewtBngoMute	85St Snare2	BSRm Snare2 85Rm Snare2	Rock SD Dry	HipHop SD 1
5	85Rm Snare2		855t BsDrum1	NewLBngoMute	NewiBrigoMute	mewa Knacoskute	n.>31 304(EZ	mannin afferes		

	PC: 1 [CC32: 4] STANDARD 1	PC: 2 (CC32: 4) STANDARD 2	PC: 3 (CC32: 4) STANDARD L/R	PC: 4 (CC32: 4) V-Pop1\$t	PC: 5 (CC32: 4) V-R&B	PC: 6 (CC32: 4) V-Fiesta	PC: 9 [CC32: 4] ROOM	PC: 10 [CC32: 4] HIP HOP	PC: 11 (CC32: 4) STANDARD 1	PC: 12 [CC32: 4] TECHNO
96)_	(85Rm Snare1)	144	(855t BsDrum2)	(CajonHi)	(CajonHi)	(CajonHi)	(BSSt Snare1)	(Dance SD)	(LoFi SD 1)	(HipHop SD 2)
-	Std.1 Snare I	Std. 1 Snare1	855t CrsCym1	CajonHiFlm	CajonHiFlm	CajonHiFlm	Std.1 Snare1	Techno Hit	Techno Hit	Techno Hit
8 _	Std.1 Snare2	Std.1 Snare2	855t Snare2	Cajonilo	Cajonto	Cajonto	Std.1 Snare2	Philly Hit	Philly Hit	Philly Hit
	Std.2 Snare 1	Std.2 Snare1	855t RdCym	CajonLoFim	CajonLoFim	CaionLoFlm	Std.2 Snare1	Shock Wave	Shock Wave	Shock Wave
00	Std.2 Snare2	Std.2 Snare2	85St Snare1	FirmncoHClp1	FinnceHCp1	FirmncoHClp1	Std.2 Snare2	La Fi Rave	Lo Fi Rave	Lo fi Rave
01_	Tight Snare	Tight Snare	855t Tom16	FinncoHClp1	FirmncoHClp1	FirmcoHClp1	Tight Snare	Bam Hit	Bam Hit	Ram Hit
	Standard SN1	Standard SN1	855t CisHat	BongoCowBell	BongoCowBell	BongoCowBell	Standard SH1	Bim Hit	Bim Hit	Bim Hit
0.1_	LD Snare M	LD Snare M	855t Tom12	AfHey	AfHey	Afriev	LD Snare M	TapeRewind	TapeRewind	
	LD Snare C	LD Snare C	85St RdBell	MamboCowBell	MamboCow8el	MamboCowBell	LD Snare C	Phone Noise	Phono Noise	TapeRewind
05_	Jazz Snare 1	Jazz Snare I	855t Tom10	MexFVox2	MexFVox2	MexFVox2	Jazz Snare 1	Dance Snare1		Phono Noise
	lazz Snare Z	Jazz Snare 2	855t OpenHat	AfFoots	Affoots	AfFoots	Jazz Snare 2	Power Snare2	Dance Snare1	Dance Snare1
107	Room Snare 1	Room Snare 1	85StBsDrum1P	MexFVox1	MexFVox1	MexFVox1	Room Snare 1	Bec Snare 1	Power Snare2	Power Snare2
108	Room Snare 2	Room Snare 2	85StBsDrum2P	MexMVox1	MexMVox1	MexMVm 1	Room Snare 2	Dance Snare 2	Elec Snare 1	Elec Snare 1
-1	Dance Snare1	Dance Snare1	85StCrsCyrn1P	YorleiFVox1	YodelPVox1	YodelFVox1	Dance Snare 1	Elec Snare 2	Dance Snare2	Dance Snare2
110	Power Snare1	Power Snare1	85StSnare2P	MesMVox2	MexMVox2	MexMVox2	Power Soure 1		Elec Snare 2	Elec Share 7
-	Rev.Snare	Rev.Snare	BSSt RdCym P	YodelMVqx1	YodelMVox1	YodelMVox1	Rev.Snare	Elec, Snare	Flec Snare	Elec. Snare
112	Power Snare2	Power Snare2	855t Snare IP	MexMVox3	MexMVox3	ExaVVaxaM	Power Snare2	Elec Snare 3	Elec Snare 3	Elec Snare 3
13	Elec Snare 1	Elec Snare 1	BSSt Tom16 P	FitnncoFVox1	FirmcoFVox1	FlmncoFVox1	Elec Snare 1	66sn260	66sn260	66sn260
	Dance Snare2	Dance Snare2	BSSt CisitatP	YodelPVox2	YodelFVox2	Yode/FVox2		TR-707 SO	TR-707 SD	TR-707 SD
15	Elec Snare 2	Elec Snare 2	85St Tom12 P	FirmcoPVox2	FimocoFVax2	HmncoFVox2	Dance Snare2	808 Snare 1	808 Snare 1	808 Snare 1
	Elec. Spare	Elec. Snare	85St RdBellP	NewWhistle1	NewWhistie1	NewWhittle1	Elec Snare 2	808 Snare 2	BOB Snare 2	808 Snare 2
17	Elec Snare 3	Elec Snare 3	855t Tom ID P	FirmcoFVox3	FirmsoFVax3		Elec. Snare	TR-808 5D2	TR-808 SD2	TR-808 SD2
-	TR-707 SD	TR-707 SD	855tOpenHatP	NewWhistle2	NewWhistle2	FlmncoFVox3	Elec Snare 3	909 Snace 1	909 Snare 1	909 Snare 1
19	806 Snace 1	508 Snare 1	97310p0x347	FirmcoMVox1	FilmocoMVox1	NewWhistie?	TR-707 SD	909 Snare 2	909 Snare 2	909 Snare 2
120	808 Snare 2	808 Snare 2	~	FirmscoMVox2	FinnesMVax2	FimncoMVox1	BOB Snare 1	909 SD 1	909 SD 1	909 SD 1
	909 Snare 1	909 Snare 1		BrazilVox1	BrazilVox1	FirmcoMVox2	808 Snare 2	TR-909 SD2	TR-909 SD2	TR-909 502
22	909 Spare 2	909 Snare 2		FirmcoMVox3		BrazilVox1	909 Snare 1	Rap Snare	Rap Snare	Rap Snare
	Rap Snare	Rap Snare		BrazilVox2	FirmncoMVox3	FimncoMVox3	909 Snare 2	JungleSD1	JungleSD1	lungleSD1
24	AungleSD1	JungleSD t		BrazilVox2 BrazilVox3	BrazilVox2	BrazilVox2	Rap Snare	House SD	House SD	House SD
25	House SD	House SD			BrazilVox3	BrazilVox3	JungleSD1	House Snare	House Snare	House Snare
-	House Snare	House Snare		AfAabhh	AfAahhh	AfAahhh	House SD	House SD	House SD	House SD
-	House SD			p33137v	p33137v	p33137v	House Snare	Voice Tah	Voice Tah	Voice Tah
27	morae 30	House SD		p33168v	p33168v	p33168v	House SD	Noise Slap	Noise Stap	Noise Slap

		PC: 13 (CC32: 4) ROOM L/R	PC: 14 (CC32: 4) HOUSE	PC: 17 [CC32: 4] POWER	PC: 18 (CC32: 4) V-Rock15t	PC: 19 [CC32: 4] V-Rock1St	PC: 25 (CC32: 4) ELECTRONIC	PC: 26 (CC32: 4) TR-808	PC: 27 (CC32: 4) DANCE	PC: 28 (CC32: 4) CR-78	PC: 29 (CC32: 4) TR-606
(C7)	(96)	(85Rm BsDrum2)	(Jngl 5D)	()	(CajonHí)	(Cajontti)	()	(→)	(HigHop SD 2)	()	()
	97	85Rm CrsCym1	Techno Hit	Std.1 Snare1	CajonHiFim	CajonHifim	Techno Hit	Techno Hit	Techno Hit	Techno Hit	Techno Hit
	98	85Rm Snare2	Philly Hit	Std.1 Snare2	CajonLo	CajonLo	Philly Hit	Philly Hit	Philly Hit	Philly Hit	Philly Hit
	99	85Rm RdCym	Shock Wave	Std.2 Snare1	CajonLuFlm	CaionLoFim	Shock Wave	Shock Wave	Shock Wave	Shock Wave	Shock Wave
	100	85Rm Snare1	Lo Fi Rave	Std.2 Snare2	FirmcoHClp1	FlmacoHClp1	Lo Fi Rave	Lo Fi Rave	Lo Fi Rave	Lo Fi Rave	Lo Fi Rave
	101	Room Tom 5	Bam Hit	Tight Snare	FirmncoHClp1	FirmscoHClo1	Bam Hit	Barn Hit	Sam Hit	Bam Hit	Bam Hit
	1817	85Rm ClsHat	Bim Hit	Standard SN1	BongoCowBell	BongoCowBell	Birn Hit	Bim Hit	Birn Hit	Rim Hit	Blm Hit
	103	Room Tom 2	TapeRewind	LD Snare M	Afriey	Affley	TapeRewind	TapaRawind	TapeRewind	TapeRewind	TapeRewind
	101	858m RdBell	Phona Naise	LD Snare C	MamboCow8elf	MamboCowBell	Phono Noise	Phono Noise	Phono Noise	Phono Noise	Phono Noise
	105	Room Tom 2	Dance Snare1	Jazz Snare 1	MexFVox2	MexPV0x2	Dance Snare 1	Dance Snare)	Dance Spare1	Dance Snare 1	Dance Snare 1
	186	85Rm OpenHat	Power Snare2	Jazz Snare 2	AfFoots	Affoots	Power Snare2	Power Snare2	Power Snare2	Power Snare2	Power Stare2
	107	85Rm8sDrum1P	Elec Snare 1	Room Snare 1	MexFVox1	MexFVox]	Elec Snare 1	Elec Snare 1	Elec Snare 1	Elec Snare 1	Elec Snare 1
C8	108	85RmBsDrum2#	Dance Snare2	Room Snare 2	MexMVax1	MexMVox1	Dance Snare2	Dance Snare2	Dance Snare2	Dance Snare2	Dance Snare2
	1019	85RmCrsCym1P	Elec Sriare 2	Dance Snare1	YadelFVax1	YodelFVox1	Elec Snare 2	Elec Snare 2	Elec Snare 2	Elec Snare 2	Elec Snare 2
	110	BSRmSnare2 P	Elec Snare	Power Snare1	MexMVox2	MexMVq22	Flec Snare	Elec. Share	Elec. Snare	Elec. Smare	Elec. Snare
	181	85Rm RdCymP	Elec Snare 3	Rev.Snare	YodelMVox1	YodelMVox1	Elec Snare 3	Elec Snare 3	Elec Snare 3	Elec Snare 3	Elec Snare 3
į	112	85RmSnare1P	66sn260	Power Snare2	MexMVax3	MexMVox3	66sn260	66sn260	66sn250	66sn260	66sn260
	113	Room Tom 5 P	TR-707 SD	Elec Snare 1	FirmcoFVox1	FirmnceFVaxI	TR-707 SD	TR-707 SD	TR-707 SD	TR-707 SD	TR-707 50
		85Rm ClsHatP	808 Snare 1	Dance Snare2	YadelPVax7	YodelFVox2	808 Snare 1	908 Snare 1	808 Snare 1	808 Snare I	806 Snare 1
	115	Room Tom 2 P	808 Snare 2	Elec Snare 2	FimncoFVax2	FirmcoFVax2	808 Snare 2	808 Snare 2	BG8 Snare 2	808 Snare 2	808 Snare 2
		BSRm RdCymP	TR-8G8 5D2	Elec. Snare	NewWhistle1	NewAMhistle I	TR-808 5D2	TR-806 SD2	TR-808 SD2	TR-808 SD2	TR-808 SD2
	117	Room Tom 2 P	909 Snare 1	Elec Snare 3	HmncqFVox3	FirmscoFVox3	909 Snare 1	909 Snare 1	909 Snare 1	909 Snare 1	909 Spare 1
	118	85RmOpenHatP	909 Snare 2	TR-707 SD	NewWhistie2	NewWhistle2	909 Snare Z	909 Snare 2	909 Snare 2	909 Snare 2	
	119		909 50-1	808 Snare 1	FirmncoMVox1	FirmmcoMtVox 1	909 SD 1	909 SD 1	909 SD 1	909 SD 1	909 Snare 2 909 SD 1
C9			TR-909 SD2	808 Snare 2	FirmcoMVax2	FirmcoMVox2	TR-909 SD2	TR-909 SD2	TR-909 SD2	TR-909 SD2	
ł			Rap Snare	909 Snare 1	BrazilVox1	BrazilVox1	Rap Snare	Rap Snare	Rap Snare	Rap Snare	TR-909 SD2
1	122	_	JungleSD1	909 Snare 2	FirencoMVax3	FirmsoMVox3	Jung(eSD)	kingleSD1	JungleSD1	JungieSD1	Rap Snare
t	123	***	House SD	Rap Snare	BrazilVox2	BrazilVoz2	House SD	House SD	House 5D	House SD	JungleSD1
l	124	***	House Snare	JungleSD1	BrazilVox3	BrazilVox3	House Snare	House Snare	House Snare	House Snare	House SD
ſ	125	-	House SD	House SD	AfAahhh	AfAahhh	House SD	House SD	House SD	House SD	House Snare
- 1	125		Voice Tah	House Snare	p33137v	p33137v	Voice Tah	Voice Tah	Voice Tah	Voice Tah	House SD
69	127		Noise Slap	House SD	p33168v	p33168v	Noise Slap	Noise Slap	Noise Slap		Voice Tah
ι.									mon neg	Noise Stap	Noise Slap

	PC:13 (CG2: 4)	PC: 14 (CC32: 4)	PC: 17 (CC32: 4)	PC: 18 (CC32: 4) V-Rock1St	PC; 19 [CC32; 4] V-Rock25t	PC: 25 (CC32: 4) ELECTRONIC	PC: 26 (CC32: 4) TR-808	PC: 27 (EC32: 4) DANCE	PC: 28 (CC32: 4) CR-78	PC: 29 (CC32: 4) TR-606
	ROOM L/R	HOUSE	POWER Std.1 Kick1	V-Rock1St HipHop BO1	V-Rock25t HipHop 8D1	Elec Kick 2	Elec Kick Z	Elec Kick 2	Elec Kick 2	Elec Kick 2
-		Elec Kick 2 Elec Kick 1	Std.1 Kick2	Jazz Kitk 1	Jazz Kick 1	Elec Kick 1	Elec Kick 1	Elec Kick 1	Elec Kick 1	Elec Kick 1
		CR78 BD 1	Std.2 Kick1	Mex Kik36	Mex_Kik36	CR78 BD 1	CR78 BD 1	CR78 8D 1	CR78 BD 1	CR78 BD 1
	-	CR78 BD 2	Std2 Kick2	85Rm8sDrum18	asamasDrum18	CR78 8D 2	CR78 BD 2	CR78 BD 2 TR-606 BD1	CR78 BD 2 TR-606 BD1	CR78 8D 2 TR-606 8D1
		TR-606 BD1	Kick 1	85RmBsDrum2B	85RmBsDrum28 909 BD	TR-506 BD1 TR-707 BD	TR-606 BD1 TR-707 BD	TR-707 BD	TR-707 BD	TR-707 BD
		TR-707 8D 806 Kick	Kick 2 Jazz Kick 1	909 BD 2	909 8D 2	808 Kick	898 Kick	808 Kick	808 Kick	808 Kick
		TR-BOB Kick	lazz Kick 2	ingl BD 2	ingi BD 2	TR-808 Kick	TR-808 Kick	TR-806 Kick	TR-808 Kick	TR-808 Kick
		GB 808	Room Kick 1	HipHop BD	HipHop BD	808 BD	808 BD	808 BD	808 BD	806 BD
		TR-909 Kick	Room Kick 2	HipHop BD 2	HipHop 8D 2	TR-909 Kick	TR-909 Kick	TR-909 Kick	TR-909 Kick Dance Kick 2	TR-909 Kick Dance Kick 2
16		Dance Kick 2	Power Kick1	855tBsDrum18	855tBsDrum1B	Dance Kick 2 909 Comp BD	Dance Kick 2 909 Comp BD	909 Comp BD	909 Comp BD	909 Comp BD
		909 Comp 8D TR-909 BD2	Power Kick 2	New Jz Kik New Rock Kik	NewizKik NewRockKik	1R-909 BD2	TR-909 BD2	TR-909 BD2	TR-909 BD2	TR-909 BD2
2		HipHop BD2	Elec Kick 1	CymbalRoli	CymbalRoll	HipHop BD2	HipHop 8D2	HipHop 802	HipHop BD2	HigHop BD2
,		Jungle80 Set	7R-806 Kick	NewRkCStkMn	HewRkC5tkMn	JungleBD Set	JungleBD Set	Jungletti) Set	JungleBD Set Techno BD1	AungieSD Set
15;	_	Techno 8D1	TR-909 Kick	85ftm5nare18	#SRmSnare18	Techno 8D1	Techno BD1	Techno BD1 Bounce	Bounce	Techno 801 Bounce
,		Bounce	Dance Kick 2	85RmSnare28	858mSnare28 855rSnare18	Bounce Voice One	Bounce Voice One	Voice One	Voice One	Voice One
·	Voice One	Voice One Voice Two	Voice One Voice Two	855tSnare1B 855tSnare2B	85StSnare2B	Voice Two	Voice Two	Voice Two	Voice Two	Voice Two
	Voice Two Voice Three	Voice Three	Voice Three	NewizSn2	HewJz5n2	Voice Three	Voice Three	Voice Three	Voice Three	Voice Three
20	-	Fat BD		New)z5n1	NewJzSn1			909 BD		
·		Dance BD		New#aBSn	NewR&8Sn			909 BD 2 MC-500 Beep	MC-500 Beep	IAC-500 Beep
3	MC-500 Reep	MC-SOO Beep	MC-S00 Beep	iPopSn40mn	PopSn40mn	MC-500 Beep MC-500 Beep	MC-500 Beep MC-500 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep
	MC-S00 Beep	MC-SOO Beep	MC-500 Beep Concert Snr	iPopSn38mn iPopSn38mn	iPopSn38mn iPopSn38mn	Concert Snr	Concert Snr	Concert Snr	Concert Snr	Concert Snr
	Concert Snr Snare Roll	Concert Size Snare Roll	Snare Roll	PopGstS39mn	PopGst339mn	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll
10000	Finger Snap	FingerSnaps2	FingerSnaps2	#PopSn40mn	iPopSn38mn	Finger Snap	FingerSnaps2	Finger Snap	FingerSnaps2	FingerSnaps2
77	High-Q	High-Q	High-Q	FingerSnaps2	FingerSnaps2	High-Q	High-Q	High-Q Siap	High-Q Slap	High-Q Slap
	Slap	Slap	Stap	707 Claps	707 Claps 808clap	Step Scrtch Push2	Slap Scritch Push2	Scritch Push2	Scrich Push2	Scritch Push2
9	ScratchPush ScratchPull	Scrich Push2 Serich Pull2	ScratchPush ScratchPull	808clap Hand clap2	808clap Hand clap2	Scritch Pull2	Scrich Pull2	Scrich Puli2	Scrich Pull2	Scrich Pull2
inger of the second sec	ScratchPull Sticks	Sticks	Sticks	909 HandClap	909 HandClap	Sticks	Sticks	Sticks	Sticks	Sticks
2	SquareClick	SquareClick	SquareClick	NewRkHatPdl	NewRicHatPdl	SquareClick	SquareClick	SquareClick	SquareClick	SquareClick Mtmm.Click
100000	Mtrren.Click	Mtrnm.Click	Mtrnm.Click	GospelHClp1	GospelHClp1	Mtrnm.Cick	Mtrom.Click Mtrom. Bell	Mtrnm.Click Mtrnm. Bell	Mtrnm.Click Mtrnm. Bell	Minn. Gick Minns. Beli
en de	Mtrnm. Bell	Mtrnm, Bell	Mirnin, Bell	NewRkSnRiiSt	NewRk5nRifst NewRockKik	Mitenen. Bell Elec Kick 2	age BD	Fat BD	CR78 BD 2	CR78 BD 2
	85RmBsDrum18	909 BD 2	Power Kick? Power Kick!	NewRockKik NewRockKik	NewRockKit	Elec Kick 1	TR-808 Kick	Dance BD	CR78 BD 1	TR-606 BD1
	85RmBsDrum2B Sicie Stick	House 5D Rim	Side Stick	NewRkCStkSt	NewRkCStk5t	Side Stick	808 Rimshot	Dance SD Rim	CR7E Rim	CR78 Rim
	85RmSnareZB	House SD	Dance Snare1	HewRockSn1st	NewRock\$n1st	Elec. Snare	808 Snare 1	Dance SD	CR78 SD 1	66sn 160 707 Claps
37	808clap	909 Claps	806ciap	NewRk5nGstSt	NewtkSnGstSt	808clap	868ciap 78-808 SD2	Rock 5D Dry	707 Claps CR78 SD 2	66sn260
0	85RmSnare18	House SD	Power Snare1	NewRockSn2st	NewRockSn2st NewRkTomL1FI	Elec Snare 2 Synth Drum 2	808 Tom 2	Synth Drum 2	78 TOM	606 Torn
Û Zest	Room Torn 5	909 Tom	Rock Tom 4 Close HiHat2	NewRkTomLZFI NewRkHat1	NewRkHat1	Jazz Chot.HH	TR-BOS CHH	CR-78 chh	CR-78 chh	606 CH
	Room Tom 5	1R-707 HH-c 909 Tom	Rock Tom 4	HewRkTorni.2	NewRkTomL1	Synth Drum 2	808 Tom 2	Synth Drum 2	78 TOM	606 Tom
	Pedal HiHat	CR-78 dih	Pedal HiHat2	HewRkHat2	NewRkHat2	Pedai HiHat	808chh	808_chh	606 CH	606 CH
	Room Tom 2	909 Torn	Rock Tom 4	NewfikTomi, I FI	NewRkTomMFI	Synth Drum 2	BOB Tom 2	Synth Drum 2	78 TOM CR-78 ohh	606 Tom 606 HiHat Op
613 613	85RmOpenHat8	909 OH	Open HiHat2	NewRkHat3	NewfikHat3 NewfikTomM	Synth Drum 2	TR-808 CHH 808 Tom 2	CR-78 ohh Synth Drum 2	78 TDM	606 Tpm
1 1000	Room Tom 2	909 Tons	Rock Tom 4	NewRkTomi.1	New/RkTomitiFi	Synth Drum 2	808 Tom 2	Synth Drum 2	78 TOM	606 Tom
	Room Tom 2 85RmCrsCym18	909 Tom 909 Crash	Crash Cym.1	NewRkCrCym1	NewRkCrCym1	Crash Cym. 1	808 Crash	808 Crash	808 Crash	868 Crash
	Room Torn 2	909 Torn	Rock Tom 1	Newfik TornM	NewRixTomHi	Synth Drum 2	808 Tom 2	Synth Drum 2	78 TOM	606 Tom
	85RmRdCym8	909 Ride Cym	Ride Cymbul	NewRkRdCym1	NewRkRdCym1	Ride Cymbal	606 Ride Cym	606 Ride Cym ReverseCymbl	606 Ride Cym ChinaCymbal	606 Ride Cym ChrraCymbai
2 1	ChineCymbal	ReverseCymbi	ChinaCymbai	NewRkRdCym2	NewfikCrCym2 HewfikRdCym2	ReverseCymbi Ride Bell	ChinaCymbal Ride Bell	Ride Bell	Ride Bell	Ride Bell
3	85RmRdCym8	Ride Bell Shake Tamb	Ride Bell Tambourine	Tambourine	Tambourine	Tambourine	CR78 Tmb	Shake Tamb	CR78 Tmb	CR78 Tmb
	Tambourine Splash Cym.	Splash Cym.	Splash Cym.	NewRkCrCym3	NewRkCrCym3	Spiash Cym.	Splash Cym.	Spiash Cym.	Splash Cym.	Spiash Cym.
	Cowbell	806cowbe	Cowbell	ChaChaCBell	ChaChaCBell	Cowbell	508cowbe	B08cowbe	CR78 Cow	CR78 Cow 909 Crash
	Crash Cym.2	909 Crash	Crash Cym.2	NewRkCrCym4	HewRkCrCym4	Crash Cym.2	909 Crash Vibrasiap	Crash Cym.Z Vibraslap	909 Crash Vibraslap	Vibraslap
S. Contrares	Vibraslap	Vibrasiap	Vibrasiap	Vibraslap	Vibrasiap PopRd1_51	Vibraslap Ride Cymbal	RideCym Edge	Ride Cymbal	RideCym Edge	RideCym Edge
	Ride Cymbal	Ride Cymbal	Ride Cymbal Bongo High	PopRd1_51 NewHiBongo	NewHiBango	Banga High	CR78 Hillongo	Bongo High	CR78 HiBango	CR78 Hillango
1 1 1 1	Bango High Bango Lo	CR78 HiBongo CR78 LoBongo	Bongo Lo	NewLoBongo	NewLoBongo	Bongo Lo	CR78 LoBongo	Bongo La	CR78 Lollongo	CR78 LoBongo
¥	Mute H.Conga	908 Conga	Mute H.Conga	NewCongaSip	NewCongaSip	Mute H.Conga	808 Conga	Mute H.Conga	808 Conga	808 Conga
5 73	Conga Hl Opn	808 Conga	Conga Hi Opn	NewCongaOp	NewCongaOp	Conga Hi Opn	808 Conga 808 Conga	Conga Hi Opn Conga Lo Opn	808 Conga 808 Conga	808 Conga 808 Conga
4	Conga Lo Opn	808 Conga	Conga Lo Opn	NewtoConga NewTmbiHi	NewLoConga NewImbHi	Conga Lo Opn High Timbale	High Timbale	High Timbale	High Timbale	High Timbale
	High Timbale Low Timbale	High Timbale Low Timbale	High Timbale Low Timbale	NewTmblLo	NewTmblto	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale
1		Agogo	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo
	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo Cabasa
0.00		Cabasa	Cabasa	NewShaker2	NewShaker2	Cabasa	Cabasa 808marac	Cabasa Maracas	Cabasa CR78 Maracas	CR78 Maracas
10	Maracas	808marac	Maracas	NewShaker1	NewShaker 1 ShrtWhistle	Maracas ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle
de la companya de la	ShrtWhistle LongWhistle	ShrtWhistle LongWhistle	ShrtWhistle LongWhistle	ShrtWhistle LangWhistle	LongWhistle	LongWhatle	LongWhistle	LongWhistle	LongWhistle	Long'Athistle
3	Short Guiro	Short Guiro	Short Guiro	NewQuide1	NewQuide1	Short Guro	Short Guiro	Short Guiro	Short Guiro	Short Guiro
7	Long Guiro	CR78 Guiro	Long Guiro	NewQuide2	NewQuide2	Long Guiro	CR78 Guiro	Long Guiro	CR78 Guiro CR78 Cly	CR78 Guiro CR78 Civ
	Claves	808klave	Claves	NewClaves	NewClaves	Claves	808clave Woodblock	Claves Woodblock	Woodblock	Woodblock
16	Woodblock	Woodblock	Woodblock	Woodblock Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock
7	Woodblock Mute Cuica	Woodblock Hoo	Woodblock Mute Cuica	Mute Cuka	Mute Cuica	Mute Cuica	Hoo	Hoo	Hoo	Hoo
	Open Cuica	Hoo	Open Cuica	Open Cuica	Open Cuica	Open Cuica	Hoo	Hoo	Hoo	Hoo Ch79 M Tow
8.1	MuteTriangi	MuteTriangl	MuteTriangl	MuteTriangi	MuteTriangl	MuteTriangi	MuteTriangl	MuteTriangi	CR78 M.Beat CR78 M.Beat	CR78 M.Beat CR78 M.Beat
81	OpenTriangl	OpenTriangl	OpenTriangl	OpenTriangl	OpenTriangl	OpenTriangl	OpenTriangl 626 Shaker	OpenTriangi 626 Shaker	626 Shaker	626 Shaker
() ()	Shaker	626 Shaker	Shaker Foots Ball	Shaker Logia Rall	Shaker Jingle Bell	Shaker Jingle Bell	lingle Bell	Jingle Bell	Jingle Bell	Jingle Bell
89	Jingle Bell	Jingle Bell Rali Tree	Jingle Bell Bell Tree	Jingle Bell Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree
84	Bell Tree Castanets	Bell Tree Castanets	Castanets	Castanets	Castanets	Castanets	Castanets	Castanets	Castanets	Castanets
86	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo
ου Ε/	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo Small Club	Open Surdo Smali Club
88	Applause 2	Applause 2	Applause 2	CAcir	CRCir	Small Club	Small Club	Small Club 606 SD 2		21AF COD
89]	606 SD 2		New Trabilities	NewTmbilifirm NewTmbil.oFim			Techno SD		-
		Dance SD		NewTmbiLoFim NewTmbiPriS	NewTmbIPH5		-	House SD		
50	1	Techno SD		NewShekere1	NewShekere!			Ingi SD		-
59 91								LoFi SD 1		
50		Rock SD Dry HipHop SD 1		NewShekere2	NewShekere?					
91 97		Rock SD Dry HipHop SD 1 Loff SD 1 Loff SD 2		NewShekere2 NH8ngoMute NewL8ngoMute	NewShekere? NHBngoMute NewLBngoMute			Lofi SD 2 HipHop SD 1		

62 (06)	PC: 30 (CC32: 4) TR-707	PC: 31 [CC32: 4] TR-909 Elec Kick 2	PC: 33 (CC32: 4) IAZZ	PC: 34 [CC32: 4] IAZZ L/R	PC: 41 [CC32: 4] BRUSH	PC: 42 (CC32: 4) BRUSH 2	PC: 43 (CC32: 4) BRUSH 2 L/R	PC: 44 [CC32: 4] V-Jazzilinish	PC: 49 [CC32: 4] ORCHESTRA	PC: 50 (CC32: 4) ETHNIC
	Elec Kick 2 Elec Kick 1	Elec Kick 2	Std.1 Kick1 Std.1 Kick2		Std. 1 Kick 1 Std. 1 Kick 2	Std.1 Kick1		HipHop BD1	Std.1 Kick1	
,	CR78 BD 1	CR78 BD 1	Std.2 Kick S			Std.1 Kick2		Jazz Kick 1	Std.1 Kick2	
_	CR78 8D 2	CR78 8D 2	Std2 Kick2		Std.2 Kick1	Std.2 Kick1	-	Mex_Kik36	5td.2 Kick1	***
4	TR-606 BD1	TR-606 8D1	Kick 1		Std2 Kick2	Std2 Kick2	-	85RmBsDrum18	Std2 Kick2	
	TR-707 BD	TR-707 BD	Kick 2		Kick 1	Kick 1		85RmBsDrum28	Kick 1	
	808 Kick	808 Kick	Jazz Kick 1		Kick 2	Kick 2		909 8D	Kick 2	***
7	TR-S08 Kick	TR-808 Kick	Jazz Kick 2		Jazz Kick 1	Jazz Kick 1		909 BD 2	Jazz Kick 1	
s	808 BD	808 BD	Room Kick 1		lazz Kick 2	Jazz Kick 2	***	Jingil BD 2	Jazz Kick 2	
,	TR-909 Kick	TR-909 Kick			Room Kick 1	Room Kick 1		HipHop BD	Room Kick †	_
	Dance Kick 2		Room Kick 2		Room Kick 2	Room Kick 2		HipHop 8D 2	Room Kick 2	
,		Dance Kick 2	Power Kick1		Power Kick1	Power Kick1		855tBsDrum 18	Power Kick1	
	909 Comp 8D TR-909 8D2	909 Comp BD	Power Kick2	-	Power Kick2	Power Kick2		HewleKik	Power Kick2	-
2		TR-909 8D2	Elec Kick 2		Elec Kick 2	Elec Kick 2	_	NewRockKik	Flor Kick 2	-
	HipHop BD2	HipHop BD2	Elec Kick 1		Elec Kick 1	Elec Kick 1		Cymbalftoll	Elec Kick 1	
ئـــــــــــــــــــــــــــــــــــــ	JungleBD Set	JungleBD Set	TR-808 Kick	_	TR-808 Kick	TR-808 Kick		NewRkCStkMn	TR-808 Kick	
15	Techno BD1	Techno BD1	TR-909 Kick	***	TR-909 Kick	TR-909 Kick	_	85RmSnare1B	TR-909 Kick	
6	Bounce	Bounce	Dance Kick 2	***	Dance Kick 2	Dance Kick 2	-	85RmSnare2B	Dance Kick 2	
7	Voice One	855tSnare16	Voice One							
18	Voice Iwo	Vaice Two	Voice Two	Voice Two	Vaice Two	Voice Two	Voice Two	85StSnare28	Voice Two	
9	Voice Three	Newiz5n2	Vaice Three							
28)			85Br BsDrum1	_	***	851z BsDrum1	_	New/zSn1		
١ا		-	RSBr BsDrum2	~	~	85iz BsDrum2	***	NewR&BSn		
222	MC-S00 Beep	MC-500 8eep	MC-500 Been	IPapSn38mn	MC-500 Bean					
	MC-500 Beep	MC-500 Beep	MC-S00 Beep	MC-500 Beep	MC-500 Beep	MC-500 Been	MC-500 Beep	PopSn40mn	MC-500 Beep MC-500 Beep	
1.40.300	Concert Snr	IPopSn38ms	Concert Snr							
25	Snare Roll	Soare Roll	Snare Roll	PopGst539mn						
	FingerSnaps2	FingerSnaps2	Finger Snap		Snare Roll	Finger Snap				
	High-Q	High-Q	High-Q	High-Q	High-Q	High-O	High-Q	iPopSn38mn	Finger Snap	Tambourine
	Slap	Slap	Slap	Slap	Slap	Siap		FingerSnaps2	Jazz Cisci Hit	Castanets
100	Scrich Push2	Scrich Push2	ScratchPush	ScratchPush	ScratchPush	ScratchPush	Slap	707 Claps	Pedal HiHat	Crash Cym.1
30	Screen Puil2	Sertch Pull2	ScratchPull	ScratchPull	ScratchPull	ScratchPull	ScratchPush ScratchPull	508clap	larr Open HH	Snare Roll
	Sticks	Sticks	Sticks	Sticks	Sticks			Hand clap?	Ride Cymbal	Concert Ser
12	SquareClick	SquareClick	SquareClick			Sticks	Sticks	909 HandClap	Sticks	Concert Cym
1300000	Mtrnm.Click	Mtrnm.Click		SquareClick	SquareClick	SquareClick	SquareClick	NewizHatPdi	SquareClick	Concert BD
3.1	Mtrnm. Bell	Mizram. Beli	Mtrnm.Click	Mtrom Click	Mirrom Click	Mtrnm.Click	Mtmm.Click	GospelHClp1	Mtmm.Click	Jingle Bell
200	TR-707 BD 2	Techno 8D2	Mitmin Bell	Mtrnm Bell	Miznm. Sell	Mtrnm. Beil	Mtrnm. Bell	iPop5Rif30st	Mtrnm. Beli	Bell Tree
AND SHOW	TR-707 BD 2		85/z BsDrum 1	851zBsDrum18	Jazz Kick 2	BSBr BsDrum1	B5BrBsDrum:1B	NewIzKik	Jazz Kick 1	Bar Chimes
	TR-707 Rim	1R-905 BD2	85/z 8sDrum2	851z8sDrum28	Jazz Kick 1	858r 8sDrum2	858rBsOrum28	Newizkik	Concert BD	Wadaiko
17		TR-909 Rim	Side Stick	New/zSW1	Side Stick	Wadaiko Rim				
27474	1R-707 SD	909 SD 1	85Jz Snare1	85JzSnare1B	Brush Swirl	858r Snare1	858rSnare18	NewJzSn1	Concert Snr	Shimedaiko
	707 Claps	909 HandClap	Hand clap2	Hand clap2	Brush Slap 1	85Br Snare2	858rSnare28	New IzSW2	Castanets	Atarigane
	TR-707 SD 2	TR-909 SD2	851z Snare2	85izSnare2B	Brush Swirl	Brush Swirl	Brush Swirt	New/z5n2	Concert Snr	Hyoushigi
	TR-707 TOTR	909 Tom	851z Tom16	85/zTom16H	Lite Tom 4	8SBr Tom1	858rTom18	Newiz TornLoff	Timpani	Ohkawa
22.	TR-707 HH-c	TR-707 HH-c	85Jz ClsHat	851zClsHat8	Brs Chh	858r OsHat	B58rClsHatB	NewJzHat1	Timpani	H kotsurumi
	TR-707 Tom	909 Tom	85Jz Tom16	85JzTom168	Lite Tom 4	85Br Toen1	858rTom18	NewJzTomLo	Timpani	1. Kotsurumi
3.3	TR-707 HH-c	TR-707 HH-c	Pedal HiHat	New)zHat2	Timpani	Ban_Gu				
新教教	TR-707 Tom	909 Tom	853z Tam13	85JzTom13B	Lite Tom 4	858r Tom2	858rTom28	NewizTomMFI	Timpani	Bia Gona
-10	TR-707 OHH	905 OH	BSiz Openilat	85JzOpenHat8	Brush Ohh	85Br OpenHat	858rQpenHatB	NewJzHat3	Timpani	Small Gong
	TR-707 Tam	909 Tom	851z Tom13	85JzTom138	Lite Torn 4	858r Tom2	B5BrTom2B	NewRkTomMid	Timpani	Bend Gong
	TR-707 Torn	909 Tom	851z Tom12	ESizTom128	Lite Torn 4	BSBr Tom3	858rTom38	NewIcTomHift	Timpani	RAMA Cymbal
49	909 Crash	909 Crash	85Jz CrsCym I	8SJzCrsCym1B	Brush Crash	858r CrsCvm1	BSBrCrsCym 1B	New/zCrCym!	Timpani	RAMA Cymbal
	TR-767 Tom	909 Tom	85/z Tom12	85IzTom12B	Lite Tom 4	858r Tom3	858rTom38	NewJzTomHi	Timpani	Gamelan Gong
51	909 Ride Cym	909 Ride Cym	85/z RdCym	851zRdCym8	Ride Cym IN	858r RdCym	85BrRdCym8	New/zRide1	Timpani	Udo Shart
	ChinaCymbal	ChinaCymbal	ChinaCymbal	ChineCymbal	ChinaCymbal	ChinaCymbal	ChinaCymbal	New/2CrCym2	Timpani	Lido_Long
W222	Ride Bell	Ride Bell	85/z RdBell	85JzRd8ell8	Brush RideBl.	858: RdBell	85BrRd8elBB	New/zRide2	Timpani	Lido_slap
54	344Tambourn	344Tambourn	Tambourine	Bendir						
美国教育	Splash Cym.	Splash Cym	Splash Cym.	Splash Cym.	Splash Cym.	Splash Cyrn.	Splash Cym.	Splash Cym.	Solash Cym.	
56	808cowbe	808cowbe	Cowbell	Cowbell	Cowbell	Cowbell	Cowbell	ChaChaCBell	Cowbell	Req_Dum
32.2	Crash Cym.2	Crash Cym.2	Crash Cym.2	Crash Cyrn.2	Crash Cym.2	Crash Cym 2	Crash Cym.2			Req_tik
58	Vibraslap	Vibrasiap	Vibraslap	Vibradap	Vibraslap	Vibraslap		NewJzCrCym1	Con.Cymbal2	Tabla Te
新羅羅	RideCym Edge	Vibraslap RideCym Edge	Vibraslap	Vibrasiap	Tabia Na					
			- material rade					NewRkRdCym1	Concert Cym.	Tabla_Tun
16.642	Bango High		Rongo Hisk	Rongo High				44 4400		
61	Bango High Bango La	Bongo High	Banga High Ranga La	Bongo High	Bango High	Bongo High	Bongo High	NewHiBongo	Bonga High	Tabla_Ge
61	Bongo Lo	Bonga High Bonga La	Rango La	Bonga Lo	Banga High Banga La	Bongo High Bongo Lo	Bongo High Bongo Lo	NewLoBongo	Bongo Lo	Tabla_Ge Tabla Ge Hi
	Bongo Lo Mute H.Conga	Bongo High Bongo Lo Mute H.Conga	Rongo Lo Mute H Conga	Bongo Lo Mute H.Conga	Bongo High Bongo Lo Mute H.Conga	Bongo High Bongo Lo Mute H.Conga	Bongo High Bongo Lo Mute H.Conga	NewLoBongo NewCongaSip	Bongo La Mute H.Conga	Tabla_Ge
61	Bongo Lo Mute H.Conga Conga Hi Opn	Bongo High Bongo Lo Mule H.Conga Conga Hi Opn	Rongo Lo Mute H Conga Conga Hi Opn	Bongo Lo Mute H.Conga Conga Hi Opn	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn	NewCongaSIp NewCongaSIp NewCongaOp	Bongo Lo Mute H.Conga Conga Hi Opn	Tabla_Ge Tabla Ge Hi Talking Drum Bend tik_dem
	Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn	Bongo High Bongo Lo Mule H.Conga Conga Hi Opn Conga Lo Opn	Rongo Lo Mute H Conga Conga Hi Opri Conga Lo Opri	Bongo Lo Mute H. Conga Conga Hi Opn Conga Lo Opn	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn	Bongo High Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn	NewCongaSIp NewCongaSIp NewCongaOp NewLoConga	Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn	Tabla_Ge Tabla Ge Hi Talking Drum Bend tik_drm Caxixi
	Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale	Rongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale	Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale	Bongo High Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale	NewLoBongo NewCongaSIp NewCongaOp NewLoConga NewTmbiHi	Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale	Tabla_Ge Tabla Ge Hi Talking Drum Bend tik_drm Caxixi Diembe
51	Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale	Rongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale	Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn Eonga Lo Opn High Timbale Low Timbale	NewLoBongo NewCongaSIp NewCongaOp NewLoConga NewTmbiHi NewTmbiLo	Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale	Tabla_Ge Fable Ge Hi Talking Druen Bend tilk_dem Caxixi Djembe Djembe_rim
**	Bongo Lo Mute H. Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo	Rongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo	Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo	Bongo High Bongo Lo Muse H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo	Bongo High Bongo Lo Mute H Conga Conga Hi Opn Eonga Lo Opn High Timbale Low Timbale Agogo	NewLoBongo NewCongaSIp NewCongsOp NewLoConga NewTmbiHi NewTmbiLo Agogo	Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale	Tabla_Ge Tabla Ge Hi Talking Orum Benst tik_drm Casixi Djembe Djembe rim Low Timbale
61	Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo	Bongo High Bongo Lo Mule H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo	Rongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo	Bongo Lo Mute H. Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Tembale Low Timbale Agogo Agogo	Bongo High Bongo Lo Mute H Conge Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo	Bongo High Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo	NewLoBongo NewCongaSIp NewCongaOp NewLoConga NewTmbIHi NewTmbILo Agogo Agogo	Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn riigh Timbale Low Timbale Agogo Agogo	Tabla_Ge Tabla Ge Hi Talking Drum Bend tik_drm Canixi Diembe Djembe_tim Low Timbale Timbi Paila
	Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn Conga Hi Opn High Timbale Low Timbale Agogo Agogo Cabasa	Rongo Lo Mute H Conga Conga Hi Opu Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa	Bonga Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabase	Bongo High Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Tembale Low Timbale Agogo Cabesa	Bongo High Bongo Lo Mute H.Conga Conga H Opn Conga Lo Opn High Tirsbale Low Timbale Agogo Agogo Cabasa	Bongo High Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa	NewLoBongo NewCongaSIp NewCongaOp NewLoConga NewTmbHH NewTmbHLO Agogo Agogo NewShaker2	Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa	Tabla_Ge Tabla_Ge Hi Talking Drum Bend tik, drm Caxixi Diembe Djembe rin Low Timbale Timbl Paila High Timbale
61 200 63 63 63	Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa 808marac	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn Conga Hi Opn High Timbale Low Timbale Agogo Agogo Cabasa 808marac	Rongo Lo Mute H Conga Conga Hi Opri Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Maracas	Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Maracas	Bongo High Bongo Lo Muse H Conga Conga H Opn Conga Lo Opn High Tembale Low Timbale Agogo Agogo Cabesa Maracas	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Maracas	Bongo High Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Maracas	NewLoBongo NewCongaSIp NewCongaOp NewLongaOp NewLoBiHi NewTmblLo Agogo Agogo Agogo NewShaker2 NewShaker1	Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High I mbale Low Timbale Agogo Agogo Cabasa Maraces	Tabla_Ge Tabla Ge Hi Talking Drum Bend tik_drm Canixi Diembe Djembe_tim Low Timbale Timbi Paila
61	Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa 888marac ShrtWhistle	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa SoBmarac ShrtWhistle	Rongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Maracas ShrtWhistle	Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Maracas ShrtWhistle	Bongo High Bongo Lo Muse H.Conga Conga Hi Opn Conga Lo Opn High Tembale Low Timbale Agogo Agogo Cabbas Maracas ShrtWhistle	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Maracas ShrtWhistle	Bongo High Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Maracas ShrtWhistle	NewLoBongo NewCongaSIp NewCongaOp NewCongaOp NewTmblH NewTmblLo Agogo Agogo Agogo Agogo Agogo ShewShaker2 NewShaker1 ShrtWhittle	Bongo Lo Muter H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cahasa Maraces ShrtWhistle	Table_Ge Table_Ge Table_Ge Hi Talking Drum Bend tik_dem Casis Diembe Djembe_rim Low Timbale Timbl Paila High Timbale Covbell Bongo High
	Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa 808marac ShrtWhistle LongWhistle	Bongo High Bongo Lo Mule H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa 808marac ShrtWhistle LongWhistle	Rongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Maracas ShrtWhistle LongWhistle	Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Marcas ShrtWhistle LongWhistle	Bongo High Bongo Lo Bongo Lo Muste H.Conga Conga Hi Opn Conga Lo Opn High Tembale Low Timbale Agogo Agogo Cabetaa Maraca ShrtWhistie LongWhistie	Bongo High Bongo Lo Mute H Longa Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Maracas ShrttWhistle LongWhistle	Bongo High Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Marazas ShrtWhistle LongWhistle	NewLoBongo NewCongaSIp NewCongaSIp NewConga NewTmbitH NewTmbitH NewTmbitLO Agogo Agogo NewShaker1 NewShaker1 ShrtWhittle LongWhistle	Bongo Lo Mute H.Conga Conga H Opn Conga Lo Opn risgh Timbale Low Timbale Agogo Agogo Cabasa Maraces ShriWhistle LongWhistle	Table, Ge Table Ge Hi Table Ge Hi Taking Drum Bend tik, dem Casizi Diembe Ojembe rim Low Timbale Timbl Paila High Timbale Cowkell Bongo High Bongo Lo
61 66 66 66 66 66 66 66 66 66 66 66 66 6	Bongo Lo Mute N Conga Conga Hi Opn Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cubasa 808mars ShrtWnisite LongWhistle Short Guiro	Bongo High Bongo Lo Morie H. Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Gabasa Bollmara Shrwinsile LongWhistle Short Guira	Rongo Lo Mutz H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Maracas ShrtWhistle LongWhistle Short Guiro	Bongo Lo Mute H Conga Conga Hi Orn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Maracas Shrivinite LowWhistle Short Guiro	Bongo High Bongo Li B	Bongo High Bongo Lo Bongo Lo Maite H Conga Conga Hi Opn Conga Lo Opn High Yimbale Low Timbale Low Timbale Agogo Agogo Cabasa Maracas ShrtWhistle LongWhistle Short Guiro	Bongo High Bongo LO Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Maracas Shriffhistle LongWhistle Short Guiro Short Guiro	NewLoBongo NewCongaSip NewCongaCip NewLoConga NewI mbiH NewTmbiH NewTmbiLo Agogo Agogo Agogo Agogo Agogo HewShaker2 NewShaker1 ShrtWhittle LongWhistle NewQuide1	Bongo Lo Muter H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cahasa Maraces ShrtWhistle	Table_Ge Table_Ge Table_Ge Hi Talking Drum Bend tik_dem Casis Diembe Djembe_rim Low Timbale Timbl Paila High Timbale Covbell Bongo High
	Bongo Lo Mutre N Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Low Timbale Agogo Agogo Cabasa SBBmarac ShrtWhistle LongWhistle Short Guiro Long Guiro	Bongo High Bongo Lo Mule H.Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Cabasa Bößmarac Shrwinistle Longwhistle Bont Guiro CR78 Guiro CR78 Guiro CR78 Guiro	Rongo to Mutte H Gropa Conga Hi Opn Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabesa ShrtWhistle LongWhistle Short Guro Long Guiro	Bongo Lo Mute It Conga Conga Hi Opn Conga Li Opn High Timbale Low Timbale Agogo Agogo Cubss ShrtWhittle LongWhistle Long Gairo Long Gairo Long Gairo	Bongo High Bongo Li Bongo Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Cabasa Maracas ShrtWhistle LongWhistle LongWhistle LongGuiro Long Guiro	Bongo High Bongo Lo Bongo Bong	Bongo High Bongo Lo Bongo Lo Mute H Conga Conga Hi Opn Conga to Opn High Timbale Low Timbale Agogo Cabasa Maracas ShrtWhistle LongWhistle LongGuiro Long Guiro Long Guiro Long Guiro Long Guiro	NewLoBongo NewCongaSIp NewCongaSIp NewConga NewTmbitH NewTmbitH NewTmbitLO Agogo Agogo NewShaker1 NewShaker1 ShrtWhittle LongWhistle	Bongo Lo Mute H.Conga Conga H Opn Conga Lo Opn risgh Timbale Low Timbale Agogo Agogo Cabasa Maraces ShriWhistle LongWhistle	Table, Ge Table Ge Hi Table Ge Hi Taking Drum Bend tik, dem Casizi Diembe Ojembe rim Low Timbale Timbl Paila High Timbale Cowkell Bongo High Bongo Lo
51	Bongo Lo Mute H Conga Conga Hi Dgn Conga Lo Opn High Tembale Low Timbale Agogo Agogo Cabasa 808mars ShrtWhistle LongWhistle Short Guiro Long Guiro Cones Con	Bongo High Bongo Lo Mute Hi Chnga Conga Hi Opn Conga Hi Opn High Timbale Low Timbale Special Congali	Bongo Lo Mutte H. Conga Conga Hi Opn Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Marcas ShrtWhistle LongWhistle Short Guiro Cong Guiro Cares Gares	Bongo Lo Mute It Conga Conga Hi Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Agogo ShrtWhitste LongWhistle Short Guiro Long Guiro Claws Claws Claws	Bongo High Bongo Li Bongo Li Bongo Li Maze H Conga Conga H Opn Conga H Opn Low Timbale Low Timbale Low Timbale Agogo Agogo Cabna Maracas Shruffwiste LongWhistle Short Guiro LongWhistle L	Bongo High Bongo Lo Matte H Conga Conga Hi Opn Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Low Timbale Agogo Agogo Cabes Marses Shriffinish Shriffinish Short Galve Long Guiro Claves	Bongo Lo Bongo Lo Butte H Conga Conga Hi Opn Conga Hi Opn Conga Lo Gong Lo High Timbale Low Timbale Low Timbale Agogo Agogo Cabesa Maracas Shriffwhistle Short Giarro Long Whistle Short Giarro Calves Claves	NewCobongo NewCongsSip NewCongsSip NewCongsDip NewCoConge NewTrabbli NewTrabbli NewTrabbli Agapa Agapa Agapa NewShaker1 NewShaker1 NewShaker1 NewShaker1 NewShaker1 NewGuide1 NewQuide1 NewQuide2 NewClares	Bongo Lo Mute H.Conga Conga H. Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Maraces ShrtWhistle LongWhistle Short Guiro	Table Ge Table Ge Hi Taking Drum Bend tik, drm Casisi Diembe Djembe, frim Low Timbale Timbil Paila High Timbale Gowbell Bongo Didth Mute H.Conga
	Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa S88marac ShrtVmisite LongWinstel Short Guiro Long Whoolsck	Bongo High Bongo Lo Mule H.Conga Conga Lo Opn High Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Sidmarax ShrtWhistle LongWhistle Short Guira CR76 Guira BOBClave BOBClave BOBClave	Bongo Io Mute H Conga Conga Hi Opn Conga Li Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Calbas Marcan ShrtWhistle Low Shriftistle Long Skrift Cong Guiro Calva Cong Guiro Calva Cong Guiro Cones Cong Guiro Cones	Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Cabasa Maracas ShrtWhittle Lors/Whistle Lors/Whistle Lors/Guro Cabasa Cabasa Maracas Cabasa Cabasa Cabasa Maracas Cabasa C	Bongo High Bongo Li Bongo Conga Li Don High Timbale Low Timbale Low Timbale Agogo Agogo Cabna Maracas ShrtWhistle LongWhistle Short Gutro Long Guiko Claves	Bongo High Bongo Lo Muse H Conga Conga H Opn Conga Lo Opn High Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Maracas ShrtWhistle LongWhistle Short Galor Long Guiro Cleves Woodblock	Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Low Timbale Agogo Agogo Cabasa ShrtWhistle LongWhistle LongWhistle Long Guiro Clavs Long Guiro Clavs Long Guiro Clavs	NewCoBongo NewCongaSip NewCongaSip NewCongaSip NewCoConga NewCoConga NewCoConga NewCoConga NewCoConga NewCoConga NewCoConga NewCoCoCo NewCoCoCoCo NewCoCoCoCoCo NewCoCoCoCoCo NewCoCoCoCoCo NewCoCoCoCoCoCo NewCoCoCoCoCo NewCoCoCoCoCoCoCo NewCoCoCoCoCoCoCoCoCo NewCoCoCoCoCoCoCoCoCoCo NewCoCoCoCoCoCoCoCoCoCoCoCoCoCoCoCoCoCoCo	Bongo Lo Mare H Conga Canga H Ogn Canga H Ogn Canga Lo Ogn High Timbale Low Timbale Agogo Cabasa Maraces Maraces Short Guiro Long Whistle Short Guiro Long Guiro	Table Ge Table Ge th Table Ge th Table Go th Table Go th Table Go th Table Go th Table Table Table Timble Timble Timble Timble Timble Timble Timble Tongo High Bongo Lo Mute H.Conga Conga Hi Opn
	Bongo Lo Mute N L'Conga Conga Hi Dyn Conga Lo Opn High Timbale Low Timbale Low Timbale Agogo Agogo Agogo Agogo Astrony Statistic Long Minstle Shart Guaro Leng Guaro Claves Woodblock Woodblock	Bongo High Bongo Lie Mute H.Conga Conga If Opn Conga If Opn Conga If Opn High Timbale Low Timbale Low Timbale Japogo Agogo Cabasa Struwniste LongWhistle LongWhistle Short Guira CR78 Guira SSICher Woodblock	Bongo Lo Mutte H. Conga Conga Hi Opn Conga Hi Opn Conga Lo Con High Timbale Low Timbale Agogo Agogo Agogo Agogo Agogo ShirtWhistle LongWhistle Short Geuro Long Guiro Claves Woodblock Woodblock	Bongo Lo Mute II Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Low Timbale Agogo Cabasa Maracas ShrtWhitite Long Gwiro Long Gwiro Cubes Cub	Bongo High Bongo Li Bongo Li Bongo Li Mater H. Conga Conga H. Opn Conga Li Opn High Timbale Low Timbale Low Timbale Agogo Agogo Cebesa Meracas ShriWhistle LongWhistle Long Guiro Long Long Long Long Long Long Long Long Long	Bongo High Bongo Lo Maure H Compa Compa H Opn Compa H Opn Compa H Opn Low Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Marzeas Shrwithiste LongWhistie Long Güro Claves Woodblock	Rongo Lo Mute H Conga Conga Hi Opn Conga Hi Opn Conga Lo High Timbale Low Timbale Low Timbale Agogo Agogo Cabria Maracas ShrtWhistle Short Guiro Claves Woodblock	NewCobongo NewCongasip NewCongasip NewCongasip NewCoconga NewTrabita NewTrabita Agaga NewTrabita Agaga NewShaker1 NewShaker1 NewShaker1 NewShaker1 NewShaker1 NewCuide1 NewCuide3 NewCuide3 NewCuide4 NewCuide	Bongo Lo Mare H Conga Mare H Conga Gnaga H Ogn Canga H Ogn Canga Lo Opn right Imbale Low Timbale Agogo Agogo Agogo Agogo Maraces Maraces Short Guito Uniformatic Short Guito Canes	Table Ge Table Ge Hi Taking Drum Bend Lik, dem Casizi Diembe Ojembe Irim Low Timbale Timbl Paila High Timbale Covbell Bongo Nigh Bongo Lo Mute H Gonga Mute H Gonga Conga Hi Opn Conga Mictor
61 66 63 70 70 73 73 75	Bongo Lo Mote N Conga Mote N Mote Mote N Mote Mote N Mote N Mote N Mote Mote N Mote N Mote N Mote Mote N Mote N Mote N Mote N Mote Mote N M Mote N M Mote N M M M M M M M M M M M M M M M M M M	Bongo High Bongo Lo Mute H Longa Conga H Opn Conga H Opn Cenga LO Opn High Timasle Low Timbate Low Timbate Agogo Agogo Cabasa Sillmarac Shrivihistle LongWhistle Short Guira Short Guira Woodblack Woodblack Hoo	Borgo I o Mute H Conga Conga Hi Opn Conga Li Opn High Timbale Low Timbale Agogo Calbas Massca ShrtWhistle LongWhistle Short Guiro Long Guiro Woodblock Woodblock Mute Cuica	Bongo Lo Mute H Conga Gnaga Hi Opin Conga Lo Opin High Timbale Low Timbale Agogo Cabasa Agogo Cabasa ShrtWhittle LongWhistle Long Grant Long Garrio Claves Woodblock Woodblock Mute Cuco	Bongo High Bongo Le Bongo Le Bongo Le Bongo Le Conga H Opn Conga H Opn Low Timbale Low Timbale Low Timbale Agogo Agogo Cabasa ShrtWhistle LongWhistle Short Guiro Cong Guiro Claves Woodblock Mute Cuica	Bongo High Bongo Lo Muse H Conga Conga H Opn Conga Lo Opn High Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Maracas ShrtWhistle LongWhistle Short Galor Long Guiro Cleves Woodblock	Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Low Timbale Agogo Agogo Cabasa ShrtWhistle LongWhistle LongWhistle Long Guiro Clavs Long Guiro Clavs Long Guiro Clavs	NewCoBongo NewCongaSip NewCongaSip NewCongaSip NewCoConga NewCoConga NewCoConga NewCoConga NewCoConga NewCoConga NewCoConga NewCoCoCo NewCoCoCoCo NewCoCoCoCoCo NewCoCoCoCoCo NewCoCoCoCoCo NewCoCoCoCoCoCo NewCoCoCoCoCo NewCoCoCoCoCoCoCo NewCoCoCoCoCoCoCoCoCo NewCoCoCoCoCoCoCoCoCoCo NewCoCoCoCoCoCoCoCoCoCoCoCoCoCoCoCoCoCoCo	Bongo Lo Mare H. Conga Conga H. Opin Conga Lo Opin Figh Timbale Low Timbale Agogo Cabasa Maraces ShrtWhistle LongWhistle LongWhistle Long Guiro Cabes Cabasa Maraces Cabasa	Table Ge Table Ge Hi Taking Drum Bend tik, drm Casisi Diembe Djembe, rim Low Timbale Timbal Paila High Timbale Gowbell Bongo High Rongo Lo Mute H Conga Conga Hi Opn Conga Mitow Conga Stap
73 - 75 - 75 - 75 - 75 - 75 - 75 - 75 -	Bongo Lo Mute N Conga Conga Hi Opn Conga Lo Opn High Timbale Low T	Bongo High Bongo Lo Mute H.Conga Conga Hi Opn Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Biblimara ShrtWhistle LongWhistle Short Guira CR78 Guito Woodblock Hoo	Bongo Io Mute H Conga Conga Hi Opn Conga Li Opn Conga Lo Opn High Timbale Lov Timbale Agogo Agogo Cabasa Maraca ShrtWhistle LongWhistle Short Guro Long Guiro Caves Mondolock Woodblock Woodblock Mute Cuica Opn Culca	Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Sabrawiniste Low Shriviniste LonsyMissite LonsyMissite Long Guiro Claves Woodblock Woodblock Woodblock Open Cuica Open Cuica	Bongo High Bongo Li B	Bongo Liph Bongo Lo Matte H Comga Conga H Opn Conga H Opn Conga H Opn Low Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Maraca ShrtWhiste LongWhiste Short Galro Long Guro Claves Woodblock Woodblock Mute Cuica	Rongo Lo Mute H Conga Conga Hi Opn Conga Hi Opn Conga Lo High Timbale Low Timbale Low Timbale Agogo Agogo Cabria Maracas ShrtWhistle Short Guiro Claves Woodblock	NewCobongo NewCongasip NewCongasip NewCongasip NewCoconga NewTrabita NewTrabita Agaga NewTrabita Agaga NewShaker1 NewShaker1 NewShaker1 NewShaker1 NewShaker1 NewCuide1 NewCuide3 NewCuide3 NewCuide4 NewCuide	Bongo Lo Mare H Conga Mare H Conga Gnag H G Ogn Conga H G Ogn Conga Lo Ogn High Timbale Low Timbale Agogo Agogo Cabasa Maraces Maraces Short Guiro Long Guiro Canes Woodblock Woodblock	Tabla Ge Tabla Ge Tabla Ge Hi Tabla Ge Hi Tabla Go Tun Bend tik, dem Casixi Diembe Djembe Irin Low Timbale Timbl Paila High Timbale Cowhell Bango High Bango Lo Mute H. Conga Mute H. Conga Groga Hi Opn Conga MiLow Conga Siap Conga I Gopn
73	Bongo Lo Mute H Conga Conga H G Opn Conga Lo Opn High Tembale Low Timbale Low	Bongo High Bongo Lo Mute Hi Chonga Conga Hi Opn Conga Hi Opn Conga Hi Opn High Timbale Low	Bongo i o Mute H Conga Conga Hi Opri Conga Lo Opn High Timbale Low Timbale Agogo Cabasa Marzas Shriffhiste LongWhiste LongWhiste Short Gairo Long Guiro Canes Woodblack Woodblack Mute Likes Open Cuica Mute Likes Open Cuica	Bongo Lo Mute H Conga Conga H I Onn Conga Lo Opn High Timbale Low Timbale Low Timbale Agogo Cabasa Maracas Shriffwhite Long Kinde Short Guiro Long Geario Claves Woodblock Mute Cuica Open Cuica Muter Cuica Muter Cuica	Bongo High Bongo Le Bongo Le Bongo Le Bongo Le Conga H Opn Conga H Opn Low Timbale Low Timbale Low Timbale Agogo Agogo Cabasa ShrtWhistle LongWhistle Short Guiro Cong Guiro Claves Woodblock Mute Cuica	Bongo High Bongo Li Bongo Li Bongo Li Bongo Li Bongo Li Conga Hi Opn Conga Hi Opn Li Low Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Agogo Cabasa Shrwinste Long Whitside Short Gairo Long didro Claves Woodblock Muta Cuica	Bongo Lo Mutre H Conga Conga Hi Opn Conga Hi Opn Conga Li Opn High Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Maracas Shriffhistle Long Ministle Short Guiro Long Guiro Claves Woodblock Motor Cuica	NewLoBongo NewCongstip NewCongstip NewCongs NewLoCongs NewLoCongs NewTriblit NewSpaker NewSpaker NewSpaker NewQuide2 NewQuide3 NewQuide3 NewQuide2 NewQuide2 NewQuide2 NewQuide2 NewQuide2 NewQuide2 NewQuide2 NewQuide2 NewQuide2 NewQuide3 NewQuide3 NewQuide3 NewQuide4 NewQuide4 NewQuide4 NewQuide5 NewQuide5 NewQuide5 NewQuide6	Bongo Lo Mure H.Conga Conga H.Gong Conga Lo Djun Fight Timbale Low Timbale Agogo Cabasa Maracas ShrtWhistle LongWhistle LongWhistle LongWhistle LongWhistle LongWhistle LongWhistle LongWhistle ModelOck Woodblock Woodblock	Tabla Ge Tabla Ge H Tabla Ge H Tabla Go H Ta
63 4 6 6 7 7 6 7 7 6 7 7 7 7 7 7 7 7 7 7 7	Bongo Lo Muta H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Selfmene ShrttWhistle LongWhistle ShrttWhistle LongWhistle Shrtt Guino Long Guro Clabes Woodblock Woodblock Hoo Hoo Hoo DoenTriangi OpenTriangi	Bongo High Bongo Lo Bongo Bong	Bongo Io Muta H Conga Conga Hi Opn Conga Li Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Marzeas ShrtWhistle LongWhistle Short Garo Garo Woodblock Woodblock Woodblock Woodblock Muta Ctica Open Cuica Muta Triangl OpenTriangl	Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Sabrawiniste Low Shriviniste LonsyMissite LonsyMissite Long Guiro Claves Woodblock Woodblock Woodblock Open Cuica Open Cuica	Bongo High Bongo Li B	Bongo Liph Bongo Lo Matte H Comga Conga H Opn Conga H Opn Conga H Opn Low Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Maraca ShrtWhiste LongWhiste Short Galro Long Guro Claves Woodblock Woodblock Mute Cuica	Rongo Lipih Bongo Lo Mute H Conga Conga Hi Opn Conga Hi Opn Conga Lo Opn High Timbate Lor Timbate Agogo Agogo Agogo Agogo Cabasa Marasa ShrtWhistle LongWhistle Short Guiro Long Guiro Claves Woodblock Woodblock Mute Culca	NewColgasip NewCongasip NewCongasip NewCongasip NewCongasip NewCongasip NewTrabit NewCuide	Bongs in Mute H.Conga Conga Hi Opin Conga Lo Opin Hispat India Hispat India Hagopo Cabasa Maraces Shriffhiste Long Guiro Cabesa Woodblock Woodblock Moodblock Mare Cuica Open Cuica Mute Fringgl India Hagopo Cabasa Cabes Moodblock Woodblock Mare Cuica Open Cuica Mute Fringgl India Hispat Indi	Table Ge Table Ge Hi Taking Drum Bend tik, dem Casisi Diembe Ojembe Irim Low Timbale Timbi Pasia High Timbale Cowbell Bongo Nigh Bongo Lo Mute H Conga Conga Hi Opn Conga Sup Conga Sup Conga Sup Conga Sup Conga Sup
51	Bongo Lo Muta H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale LongWhistle ShrtWhistle LongWhistle LongWhistle LongWhistle Long Guro Claves Long Guro Clave Moodblock Woodblock Woodblock Moodblock Soodblock Moodblock Moodblock Moodblock Moodblock Moodblock Moodblock Soodblock Moodblock Moodbloc	Bongo High Bongo Lo Mute Hi Chonga Conga Hi Opn Conga Hi Opn Conga Hi Opn High Timbale Low	Bongo i o Mute H Conga Conga Hi Opri Conga Lo Opn High Timbale Low Timbale Agogo Cabasa Marzas Shriffhiste LongWhiste LongWhiste Short Gairo Long Guiro Canes Woodblack Woodblack Mute Likes Open Cuica Mute Likes Open Cuica	Bongo Lo Mute H Conga Conga H I Onn Conga Lo Opn High Timbale Low Timbale Low Timbale Agogo Cabasa Maracas Shriffwhite Long Kinde Short Guiro Long Geario Claves Woodblock Mute Cuica Open Cuica Muter Cuica Muter Cuica	Bongo High Bongo Li B	Bongo Liph Bongo Liph Bongo Liph Bongo Liph Bongo Liph Congo Liph Congo Liph High Finibale Low Timbale Low Timbale Agogo Agogo Cabbea Maracas ShrryWhistle LongWhistle LongWhistle Long Guiro Claves Woodblock Mote Cuica Mute Triangi	Bongo Liph Bongo Lo Mutre H Conga Conga Hi Opn Conga Hi Opn Conga Lip Opn High Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Maracas Shriffwhiste Long Whistel Bond Guiro Long Guiro Long Guiro Long Guiro Moodblock Woodblock Woodblock Open Cotica Open Cotica Open Cotica Open Cotica	NewLobongo NewCongstlp NewCongstlp NewCongstlp NewLobongo NewCongstl NewCondo NewCond	Bongo Lo Mare H.Conga Conga H.Opn Conga Lo Opn Figh Timbale Low Timbale Agogo Cabasa Maracas ShrtWhistle LongWhistle LongWhistle LongWhistle LongWhistle LongWhistle Modelblock Woodblock Woodblock MuteTriangl OpenTilangl	Table Ge Table Ge Hi Taking Drum Bend tik, dem Casisi Diembe Djembe, frim Low Timbale Timbil Paila High Timbale Gowbell Bongo Di Mute H. Conga Conga Hi Opn Conga Hi Opn Conga Slap Conga Slap Conga Slap Conga Slap Conga Slab Mut Pandiero Oppen Surdo Mute Pandiero Oppen Surdo
51	Bongo Lo Muta H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Selfmene ShrttWhistle LongWhistle ShrttWhistle LongWhistle Shrtt Guino Long Guro Clabes Woodblock Woodblock Hoo Hoo Hoo DoenTriangi OpenTriangi	Bongo High Bongo Lo Bongo Bong	Bongo Io Muta H Conga Conga Hi Opn Conga Li Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Marzeas ShrtWhistle LongWhistle Short Garo Garo Woodblock Woodblock Woodblock Woodblock Muta Ctica Open Cuica Muta Triangl OpenTriangl	Bongo Lo Mute H Conga Conga H i Opn Conga Lo Opn High Timbale Low Timbale Agogo Cabasa Marscas ShrtWhistle Low Whistle LongWhistle LongWhistle LongWhistle Woodblock Woodblock Woodblock Mute Cuica Open Cuica MuteTriangl MuteTriangl	Bongo High Bongo Le Bongo Le Bongo Le Bongo Le Conga H Opn Conga H Opn Low Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Maracas ShrtWhistle LongWhistle Short Gurro Long Guiro Claves Woodblock Woodblock Woodblock Woodblock Open Cuka Muter Cinary Open Cuka Muter Triangl Open Triangl	Bongo High Bongo Lo Bongo Lo Maure H Compa Compa Hi Opn Compa Hi Opn Compa Lo Opn High Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Mazacas ShrtWhistle Long Whistle Long Guidro Claves Woodblock Woodblock Mute Cuica Mute Triangl Open Tiriangl Open Tiriangl Open Tiriangl	Bongo Lo Mute H Conga Conga Hi Opn Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Maracas ShrtWhistle LongWhitsle Short Guiro Claves Woodblock Mute Cuica Open Cuita Mute Triangl	NewColongo NewCongasip NewCongasip NewCongasip NewConga NewConga NewTrabits NewTrabits Agaga Agaga HewShakeri ShrtVihite LangWhitie NewCuide NewCui	Bongo Lo Matre H. Conga Mare H. Conga Mare H. Opn Conga Lo Opn Conga Lo Opn Figh Timbale Low Timbale Agogo Adogoo Cahasa Maraces Marac	Tabla Ge Tabla Ge Tabla Ge Tabla Ge Tabla Grum Bend tik, drm Casixi Diembe Djembe Jim Low Timbale Timbi Paila High Timbale Cowhell Bongo Lo Mute H Conga Mute H Conga Conga Hi Opn Conga Slap Conga Slap Conga Lo Mut Pandiero Opn Pandiero Opn Pandiero Open Surdo Mute Surdo Open Surdo Mute Surdo Open Surdo Mute Surdo
	Bongo Lo Muta H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale LongWhistle ShrtWhistle LongWhistle LongWhistle LongWhistle Long Guro Claves Long Guro Clave Moodblock Woodblock Woodblock Moodblock Soodblock Moodblock Moodblock Moodblock Moodblock Moodblock Moodblock Soodblock Moodblock Moodbloc	Bongo High Bongo Le Bongo High Bongo Le Congo Agogo Cabasa Signmara ShrtWhistle LongWhistle Short Guira CR78 Guira Signic Woodblock Woodblock Hoo Mutel Triangl OpenTriangl CopenTriangl CopenTriangl	Bongo to Muter Konga Conga Hi Opn Conga Hi Opn Conga Lo Con High Timbale Low Timbale Agogo Agogo Cabess Maracs Maracs ShrtWhistle Long Whistle Short Gairo Long Guiro Cayes Mate Cuca Open Cida Mute Luca Open Cida Mute Triangl Open Tidarcal Shaler	Songo Lo Mute H Conga Gonga Hi Opm Conga Lo Opm High Timbale Low Timbale Low Timbale Agogo Cubasa Marscas ShrWhitie Low Gorin ShrWhitie Long Gorin Claves Wroodblock Woodblock Mute Cuca Open Cuice Mute Triangl OpenTriangl OpenTriangl OpenTriangl Shater Jingle Bell	Bongo High Bongo Li Bongo Low Timbale Low	Bongo High Bongo Lo Bongo Lo Gonga Hi Opn Conga Hi Opn Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Maracas Mondiblock Muta Cuica Open Ciuca Muta Cuica Open Ciuca Muta Tirangl Open Tirangl Open Tirangl	Bongo Liph Bongo Lo Mutre H Conga Conga Hi Opn Conga Hi Opn Conga Liph High Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Maraca Shrivihistle Long Whistle Short Guiro Long Guiro Claves Woodblock Mutre Cuica Open Cuica Mutre Triangl Open Triangl Shater Jungle Bell	NewLobongo NewCongstip NewCongstip NewCongs NewLobongo NewLobongo NewLobongo NewLobongo NewLobongo NewShaker? NewShaker? NewShaker? NewShaker? NewShaker? NewShaker? NewQuide2 NewQuide3 NewQuide2 NewQuide3 NewQuide2 NewQuide3 NewQuide2 NewQuide3 NewQuide2 NewQuide3 N	Bongs to Mure H.Conga Gongs H.Gong Gongs H.Gong Gongs Lo Djon Fisigh Timbale Low Timbale Agogo Cabasa Maracas ShrWhistie LongWinstel LongWinstel Long Guiro Cahes Woodblock Woodblock Mate Cuica Materiana John China John C	Table Ge Table Ge Table Ge Hi Taking Drum Bend tik, dem Casixi Diembe Ojembe, rim Low Timbale Timbl Paila High Timbale Cowbell Bongo Nigh Bongo Lo Mute H.Conga Mute H.Conga Gonga Hi Opn Conga Slap Conga Hi Opn Conga Slap Conga Slap Conga Slap Conga Slab Mut Panoliero Open Sarde Mut Panoliero Open Sarde Mute Surde Tamborine
	Bongo Lo Mote N Conga Mote N Co	Bongo High Bongo Lo Morte Hi Chonga Conga Hi Opn Conga Hi Opn Conga Hi Opn High Timbale Low Timbale Low Timbale Agogo Agogo Agogo Agogo Cabasa Bühmare Shruthinsile LongWhitsile Short Guira CR78 Guira Woodblock Hoo Hoo Hoo Hoo Onen'riandl Open'riandl Open'riandl Open'riandl Open'riandl	Bongo Io Mute H Conga Conga Hi Opn Conga Li Opn Conga Li Opn High Timbale Lov Timbale Agogo Agogo Calbasa Markes ShrtWhistle LongWhistle Short Guro Long Guiro Cares Ucong Guiro Cares Model Care Long Guiro Cares Model Care Model Car	Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Cabasa Maracas ShrtWhittle LonsWhistle LonsWhistle Lons Gorro Claves Woodblock Woodblock Mute Cuica Open Cuica Mute Triangl Open Cuica Mute Cristangl Shaker	Bongo High Bongo Li Bongo Agogo Agogo Agogo Agogo Agogo Agogo Agogo Agogo Cabeas Maracas Shurt Guiro Long Guiro Claves Woodblock Mute Cula Bongo Cide Bongo Claves Mute Cula Bongo Claves Bongo C	Bongo High Bongo Lo Maure H. Comga Conga H. Opn Conga H. Opn Conga Lo Opn High Timbale Long Agogo Agogo Agogo Agogo ShrrwMhistle LongWhistle Short Guiro Long Guiro Claves Woodblock Mute Cuica Mute Triangl Open Cruca Mute Triangl Shaker Jingle Bell Bell Tee	Bongo Lipih Bongo Lo Mute H Conga Conga Hi Opn Conga Hi Opn Conga Lo Opn High Timbale Long Gabasa Agogo Agogo Agogo Cabasa Maratas Short Guiro Long Whistle Long Whistle Long Guiro Claves Woodblock Mute Culca Mute Triangl Cheen Triangl Shaker Jonen Triangl Shaker Jonen Triangl Shaker	NewGoBongo NewCongaSip NewCongaSip NewCongaSip NewConga NewConga NewConga NewConga NewTmbH NewTmbH NewTmbH NewTmbH NewTmbH NewTmbH NewTmbH NewTmbH NewConga NewShaker NewChaler ShrtWhitte LongWhite NewColde NewC	Bongo Lo Mare H Conga Conga H Gop Conga Lo Ogn Conga Lo Ogn High Tribale Low Timbale Agogo Cabasa Maraces Maraces Short Guito Long Whistle Long Whistle Long Guiro Cabasa Maraces Mondiblock Mondiblock Mondiblock Mondiblock Mondiblock Mondiblock Marace Maraces Mar	Table Ge Table Ge th Table Ge th Table Ge th Table Go th Table Go th Table Go th Table Go th Diembe Djembe Jim Low Timbale Timbil Paila High Timbale Cowbell Bongo High Bongo Lo Mute H.Conga Konga Hi Opn Conga Hi Opn Conga Hi Opn Conga Siap Conga Lo Opn Conga Siap Conga Lo Opn Conga Siap Conga Sia
	Bongo Lo Mote N Conga Mong N Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Low Timbale Low Timbale Agogo Cabbas Soltmana Shriffhisite Long Minstel Long Guro Cabas Hoo Mutel Timbale Hoo Hoo Mutel Timag Moodbook Hoo Deen Timag Jimag Jima	Bongo High Bongo Lo Mute Hi Chonga Conga Hi Opn Conga Hi Opn Conga Hi Opn High Timbale Low Timbale Response Bollowe Response R	Bongo i o Mute H Conga Conga Hi Opn Conga Li Opn Conga Lo Opn High Timbale Low Timbale Agogo Cabasa Marzas Shriffhiste LongWhiste LongWhiste Short Gairo Long Guiro Cawas Woodsbluck Woodsbluck Mute Triangi Open Cuica Mute Triangi Open Cuica Mute Triangi Open Cuica Mute Triangi Open Timoge Bell Bell Time Bell Timoge Bell Bell Time Castannes	Bongo Lo Mute H Conga Conga H i Onn Conga Lo Opin High Timbale Low Timbale Low Timbale Agogo Cabasa Agogo Cabasa ShriWhite Long White Short Guiro Long Guaro Claves Woodblock Mute Cuica Open Cuica Mute Triangl OpenTicangl Shale High Bell Bell Hell Ties Shale	Bongo High Bongo Li Bongo Agogo Agogo Cabria Maracas Shriffwistle Long-Whistle	Bongo High Bongo Lo Matte H Konga Conga Hi Opn Conga Hi Opn Conga Lo Opn High Finibale Low Timbale Agogo Agogo Cabesa Maracas Shriffwhistle LongWhistle LongWhistle Long Guiro Claves Woodblock Woodblock Mute Cuica Mute Triangl Open Cica Mute Triangl Open Cica Mute Triangl Open Triangl Shaker Jingle Bell Bell Tree Castanets	Bongo Lo Mute H Conga Conga Hi Opn Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Maracas ShrtWhistle LongWhistle Short Gwiro Long Guiro Claves Woodblock Mute Cuica Mute Triangl Maratas Maratas ShrtWhistle Long Guiro Claves Woodblock Mute Cuica Open Crist Mute Triangl Open Crist Mu	NewGobongo NewCongstlp NewCongstlp NewCongstlp NewGobongo NewGobon	Bongs in Mute H.Conga Gnag Hi Opn Gnag Lo Opn High Imbale Low Timbale Agogo Cabasa Maraces ShriWhistle Long Guiro Canes Woodblock Woodblock Mute Cuica Open Cuica Mute Cuica Open Timangl Shrifter Ingle Bell Bell Tree Gestanets	Tabla Ge Tabla Ge Tabla Ge Tabla Ge Tabla Ge Tabla Ge Bend tik, dem Casixi Diembe Gend tik, dem Casixi Diembe Jim Low Timbale Ismbl Paila High Timbale Covrbell Bengo High Bengo High Bengo High Conga Mittow Conga Mittow Conga Mittow Conga Mittow Conga Mittow Conga Slap Conga High Mute Low Conga Slap Conga High Mute Mittow Conga Slap Conga Bide Mut Pandiero Open Pandiero Open Pandiero Open Burde Mute Surde Tamborine Agoggo Agoggo
	Bongo Lo Muta H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Selfmere ShrtWhistle LongWhistle ShrtWhistle LongWhistle ShrtGuiro Long Guro Clabes Woodblock Woodblock Woodblock Hoo Hoo Hoo Hoo Butteriangi OpenTriangi CaS Shaker Jinigla Bell Bell Tree Castanets Castanets Muter Sundo	Bongo High Bongo Lo Bongo High Bongo Lo Conga Hi Can Conga Hi Can Conga Hi Can Conga Lo Bongo Agogo Agogo Agogo Agogo Agogo Cabasa Billimara Shrivihisile LongWhitsile Short Guira CR78 Guira Billimara Shrivihisile Hoo Hoo Hoo Hoo Hoo Hoo Hoo Hoo Hoo Ho	Bongo io Muta H Conga Conga Hi Opn Conga Li Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Caleas Marcas ShrtWhistle LongWhistle Short Guro Long Guiro Cayes Woodblock Woodblock Woodblock Muta Citica Open Cuica Muta Triangl OpenTimangl Shaker Innige Bell Bell Tree Castannes	Bongo Lo Mute H Conga Gonga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Cabasa Maracas ShrtWhistle Low Whistle LongWhistle LongWhistle LongWhistle Woodblock Woodblock Woodblock Woodblock Woodblock Shuter Gonga Conga Shater Gonga Conga Gonga Gonga Conga Gonga Gong	Bongo High Bongo Le Bongo High Bongo Le Kaze H Conga Conga H Opn Conga Le Opn High Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Maracas ShrtWhistle LongWhistle Short Guiro Cong Guiro Claves Woodblock Woodblock Mute Cuica Open Cuica Muter Timal Shaker Bell Timple Bell Rell Tree Castanets Muter Surdo	Bongo High Bongo Lo Bongo Lo Bongo Lo Conga Hi Opn Conga Hi Opn Conga Lo Gongo Lo Go	Bongo Lo Bon	NewGobongo NewCongaSip NewCongaSip NewCongaSip NewGobongo NewGobongo NewGobongo NewGobongo NewGobongo NewShaker? NewShaker? ShrtWhistle LangWhistle NewGuide2 NewGuide	Bongo Lo Marie H.Conga Conga H.Opin Conga Lo Opin Figh Timbale Low Timbale Agogo Cabasa Maracas ShrtWhistle LongWhistle Maracas ShrtWhistle LongWhistle Long Opin Short Guita Open Ciucia Mozellica Open Ciucia Mare Ciucia Open Ciucia Mozellica Shater Lingle Bell Rell Tree Castaness Lingle Bell Rell Tree Castaness	Table Ge Table Ge Hi Taking Drum Bend tik, dem Canizia Diembe Ojembe Irim Low Timbale Timbh Paila High Timbale Cowbell Bongo Nigh Bongo Lo Mute H. Conga Conga Hi Opn Conga Slap Conga Lo Gonga Slap Conga Lo Mute H. Conga Conga Slap Conga Slap Conga Slap Conga Slap Conga Lo Mut Pandiero Opp Pandiero Opp Pandiero Oppe Surdo Mute Surdo Tamborim Agogo
	Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Low Timbale Low Timbale Low Timbale Low Timbale Long Mindel Salmarac Short Guiro Long Guro Cabass Short Guiro Long Guro Caves Woodblock Woodblock Woodblock Hoo Mute Triangl Open Triangl Open Triangl Gas Shaker Iningle Bel Bell Tire Castanets Mutes Surdo Open Surdo Ope	Bongo High Bongo Lo Mute H Longa Congu Ri Opn Congu Ri Opn Congu Ri Opn Congu Ri Opn Low Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Billimare Shrtviniste LongWhistie Short Guira CR78 Guira CR78 Guira Woodblock Woodblock Woodblock Hoo Mute Triangl Open Triangl Bell Bell Tree Castanets Mute Starlo Open Surdo Ope	Bongo Io Mute H Conga Conga Hi Opn Conga Li Opn Conga Li Opn High Timbale Lov Timbale Agogo Agogo Cabasa Maraca ShrtWhistle Long Whistle Short Guro Long Guiro Canes Unon Guiro Canes Mute Citica Mute Citica Open Cuica Mute Triangl Shaker Inigle Bell Bell Tree Cassanes Mute Suro Casses	Bongo Lo Mute H Conga Conga Hi Opin Conga Lo Opin High Timbale Low Timbale Agogo Agogo Sabraw Maracas ShrtWhittle LonsWhistle LonsWhistle Short Gulro Long Guiro Claves Woodblock Woodblock Woodblock Mute Cuica Open Cuica Mute Timangl Shaker Jingle Bell Bell Tee Castanest Mute Cuica Copen Guica Mute Timangl Shaker Jingle Bell Bell Tee Castanest Moons Gurdo Open Surdo Open S	Bongo High Bongo Li Bongo Agogo Agogo Cabea Maraca ShruWhiste Long Whiste Short Gustro Long Guiso Cares Woodblock Woodblock Woodblock Woodblock Mute Cuica Open Cuica Mute Tiangi Open Tiringi DeetTriangi Shaker Lingke Bell Bell Reel Tree Castanes Mute Surdo Open	Bongo High Bongo Lo Maure H Compa Compa Hi Opn Compa Hi Opn Compa Hi Opn Low Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Mazacas Sherwibiste Long Shiritiste Short Galze Woodblock Woodblock Woodblock Woodblock Mute Luica Open Ciriand Mute Triangl Open Triangl Shaler Single Bell Bell Tree Catarasis Mute Surdo Open Surdo	Bongo Lipih Bongo Lo Mutre H Conga Conga Hi Opn Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Agogo Agogo Cabasa Maraca ShrtWhistle Long Whistle Long Guiro Llows Woodblock Woodblock Woodblock Mutr Cuica Open Crist Mutr Triangl Open Triangl Shate Jone Firangl Shate Jone Firangl Open Triangl Shate Jone Firangl Shate Jone Bell Bell Tre Castames Muta Farangl Open Surdo	NewColgasip NewCongasip NewCongasip NewCongasip NewCongasip NewCongasip NewCongasip NewTrabiti NewTrabiti NewTrabiti NewTrabiti NewTrabiti NewTrabiti NewCalabiti	Bongo Lo Matre H. Conga Mare H. Conga Gong H. Gong Gong Lo Ogn Marsces Moodblock	Tabla Ge Tabla Ge Tabla Ge Tabla Ge Tabla Grum Bend tik, drm Casixi Diembe Djembe Jim Low Timbale Timbi Paila High Timbale Cowhell Bongo High Bongo Lo Mute H.Conga Mute H.Conga Gonga High Conga High Conga Side Mute Mute Conga High Conga Side Mute Mute Tambile Conga High Tambile Conga High Tambile Tonga Side Mute Mute Tambile Tonga Side Mute Surdo Tamborie Tamborie Tamborie Tamborie Agogo Agogo Shaker Low Whistle
	Bongo Lo Muta H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa Selfmere ShrtWhistle LongWhistle ShrtWhistle LongWhistle ShrtGuiro Long Guro Clabes Woodblock Woodblock Woodblock Hoo Hoo Hoo Hoo Butteriangi OpenTriangi CaS Shaker Jinigla Bell Bell Tree Castanets Castanets Muter Sundo	Bongo High Bongo Lo Mute Hi Chonga Conga Hi Opn Conga Hi Opn High Timbale Low Timbale Low Timbale Low Timbale Agogo Agogo Agogo Cobasa Böömara Sörmara	Bongo io Muta H Conga Conga Hi Opn Conga Li Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Caleas Marcas ShrtWhistle LongWhistle Short Guro Long Guiro Cayes Woodblock Woodblock Woodblock Muta Citica Open Cuica Muta Triangl OpenTimangl Shaker Innige Bell Bell Tree Castannes	Bongo Lo Mute H Conga Gonga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Cabasa Maracas ShrtWhistle Low Whistle LongWhistle LongWhistle LongWhistle Woodblock Woodblock Woodblock Woodblock Woodblock Shuter Gonga Conga Shater Gonga Conga Gonga Gonga Conga Gonga Gong	Bongo High Bongo Le Bongo High Bongo Le Kaze H Conga Conga H Opn Conga Le Opn High Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Maracas ShrtWhistle LongWhistle Short Guiro Cong Guiro Claves Woodblock Woodblock Mute Cuica Open Cuica Muter Timal Shaker Bell Timple Bell Rell Tree Castanets Muter Surdo	Bongo High Bongo Lo Bongo Lo Bongo Lo Conga Hi Opn Conga Hi Opn Conga Lo Gongo Lo Go	Bongo Lo Bon	NewLobongo NewCongstip NewCongstip NewCongs NewC	Bongo Lo Mare H.Conga Conga H.Opn Conga Lo Opn Figh Timbale Low Timbale Agogo Cabasa Maracas ShrtWhistle LongWhistle Maracas ShrtWhistle LongWhistle Long Opid Maracas ShrtWhistle Long Opid Maracas ShrtWhistle Long Opid Shoter Jimpie Ball Rell Tree Castaness Rell Tree Castaness	Table Ge Table Table Table Table Table Table Table Timble Towga Timble Timble Towga Timble Timble Tomga Timble Tomga Timble Tomga Timble Tim
1	Bongo Lo Muta H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa ShritWhidale LongWhistle ShritWhidale LongWhistle ShritWhidale LongWhistle ShritWhidale LongWhistle ShritWhidale Long Shrit Minot Shrit M	Bongo High Bongo Lo Mute H.Conga Conga It Opn Conga It Opn Conga It Opn High Timbale Low Timbale Apogo Apogo Apogo Apogo Edbasa B08mare ShrtWhistle LongWhistle Short Guira R78 Guito Woodblock Hoo Mute Triangl Mute Triangl G26 Shaker Jingle Bell Bell Tree Castanes Capalianes Capalianes Capalianes Capalianes Capalianes Capalianes Capalianes Capalianes Capalianes Castanes Capalianes C	Bongo Io Mute H Conga Conga Hi Opn Conga Li Opn Conga Li Opn High Timbale Lov Timbale Agogo Agogo Cabasa Maraca ShrtWhistle Long Whistle Short Guro Long Guiro Canes Unon Guiro Canes Mute Citica Mute Citica Open Cuica Mute Triangl Shaker Inigle Bell Bell Tree Cassanes Mute Suro Casses	Bongo Lo Mute H Conga Conga H i Opn Conga Lo Opn High Timbale Low Timbale Agogo Cabasa Mareas ShrtWhitste Low Whitste Long Whitste Mareas ShrtWhitste Long Whitste Mareas ShrtWhitste Long Whitste Mareas ShrtWhitste Long Whitste Mareas ShrtWhitste Long Guiro Claves Woodblock Woodblock Woodblock Woodblock Shaker Jone Timbale Bell Tree Castanets Shaker Castanets Shaker Castanets Shaker Castanets Mute Surdo Open Surdo Applause	Bongo High Bongo Li Bongo Agogo Agogo Cabea Maraca ShruWhiste Long Whiste Short Gustro Long Guiso Cares Woodblock Woodblock Woodblock Woodblock Mute Cuica Open Cuica Mute Tiangi Open Tiringi DeetTriangi Shaker Lingke Bell Bell Reel Tree Castanes Mute Surdo Open	Bongo High Bongo Lo Maure H Compa Compa Hi Opn Compa Hi Opn Compa Hi Opn Low Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Mazacas Sherwibiste Long Shiritiste Short Galze Woodblock Woodblock Woodblock Woodblock Mute Luica Open Ciriand Mute Triangl Open Triangl Shaler Single Bell Bell Tree Catarasis Mute Surdo Open Surdo	Bongo Lipih Bongo Lo Mutre H Conga Conga Hi Opn Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Agogo Agogo Cabasa Maraca ShrtWhistle Long Whistle Long Guiro Llows Woodblock Woodblock Woodblock Mutr Cuica Open Crist Mutr Triangl Open Triangl Shate Jone Firangl Shate Jone Firangl Open Triangl Shate Jone Firangl Shate Jone Bell Bell Tre Castames Muta Farangl Open Surdo	NewGobongo NewCongaSip NewCongaSip NewCongaSip NewConga NewConga NewConga NewConga NewConga NewShaker? NewTmblti NewTmblto Agogo NewShaker? NewShaker? ShrtWhittle Langwifstiel NewCaloic NewClares	Bongo Lo Matre H. Conga Mare H. Conga Gong H. Gong Gong Lo Ogn Marsces Moodblock	Tabla Ge Tabla Ge Tabla Ge Tabla Ge Tabla Grum Bend tik, drm Casixi Diembe Djembe Jim Low Timbale Timbi Paila High Timbale Cowhell Bongo High Bongo Lo Mute H.Conga Mute H.Conga Gonga High Conga High Conga Side Mute Mute Conga High Conga Side Mute Mute Tambile Conga High Tambile Conga High Tambile Tonga Side Mute Mute Tambile Tonga Side Mute Surdo Tamborie Tamborie Tamborie Tamborie Agogo Agogo Shaker Low Whistle
1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Bongo Lo Mote N Conga Mote N Co	Bongo High Bongo Lo Mute Hi Chonga Conga Hi Opn Conga Hi Opn High Timbale Low Timbale Low Timbale Low Timbale Agogo Agogo Agogo Cobasa Böömara Sörmara	Bongo i o Mute H Conga Conga Hi Opi Conga Lo Opi High Timbale Low Timbale Agogo Cabesa Marzes Shriffhiste Low Shribite Low Good Cabesa Marzes Shriffhiste Short Gairo Cangaline Marzes Mute Cisica Opin Culca Mute Cisica Opin Cisica Mute Cisica Opin Cisic	Bongo Lo Mute H Conga Conga Hi Opin Conga Lo Opin High Timbale Low Timbale Agogo Agogo Sabraw Maracas ShrtWhittle LonsWhistle LonsWhistle Short Gulro Long Guiro Claves Woodblock Woodblock Woodblock Mute Cuica Open Cuica Mute Timangl Shaker Jingle Bell Bell Tee Castanest Mute Cuica Copen Guica Mute Timangl Shaker Jingle Bell Bell Tee Castanest Moons Gurdo Open Surdo Open S	Bongo High Bongo Li Bongo Agogo Agogo Cabena Maracas ShriffWistle Long-Whistle Long-Whistle Long-Whistle Long-Whistle Long-Whistle Long-Whistle Long-Whistle Long-Guiko Claves Woodblock Woodblock Mute Cuika Open Cuika Mute Triangl Open-Tangl Shaker Lingle Bell Bell Teel Castanets Mute Surdo Open-Surdo Applaxoe ————————————————————————————————————	Bongo High Bongo Lo Maure H Compa Compa Hi Opn Compa Hi Opn Compa Hi Opn Low Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Mazacas Sherwibiste Long Shiritiste Short Galze Woodblock Woodblock Woodblock Woodblock Mute Luica Open Ciriand Mute Triangl Open Triangl Shaler Single Bell Bell Tree Catarasis Mute Surdo Open Surdo	Bongo Lipih Bongo Lo Mutre H Conga Conga Hi Opn Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Agogo Agogo Cabasa Maraca ShrtWhistle Long Whistle Long Guiro Llows Woodblock Woodblock Woodblock Mutr Cuica Open Crist Mutr Triangl Open Triangl Shate Jone Firangl Shate Jone Firangl Open Triangl Shate Jone Firangl Shate Jone Bell Bell Tre Castames Muta Farangl Open Surdo	NewLobongo NewCongstip NewCongstip NewCongs NewC	Bongo Lo Matre H. Conga Mare H. Conga Gong H. Gong Gong Lo Ogn Marsces Moodblock	Table Ge Table Table Table Table Table Table Table Timble Towga Timble Timble Towga Timble Timble Tomga Timble Tomga Timble Tomga Timble Tim
1	Bongo Lo Mute H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Low Timbale Agogo Agogo Cabasa SBBmarac ShrtWhistle LongWhistle Short Guiro Long Guro Claves Woodblock Woodblock Woodblock Hoo Mute Triangi OpenTriangi GSS Shaker Imige Bell Bell Tree Castanets Mune Surdo Open Surdo Small Club	Bongo High Bongo Lo Mute H.Conga Conga It Opn Conga It Opn Conga It Opn High Timbale Low Timbale Apogo Apogo Apogo Apogo Edbasa B08mare ShrtWhistle LongWhistle Short Guira R78 Guito Woodblock Hoo Mute Triangl Mute Triangl G26 Shaker Jingle Bell Bell Tree Castanes Capalianes Capalianes Capalianes Capalianes Capalianes Capalianes Capalianes Capalianes Capalianes Castanes Capalianes C	Bongo I o Must H Conga Conga Hi Opn Conga Li Opn Conga Lo Opn High Timbale Low Timbale Agogo Cabasa Masscas ShrtWhistle Low Whitstle LongWhistle LongW	Bongo Lo Mute H Conga Conga H i Opn Conga Lo Opn High Timbale Low Timbale Agogo Cabasa Mareas ShrtWhitste Low Whitste Long Whitste Mareas ShrtWhitste Long Whitste Mareas ShrtWhitste Long Whitste Mareas ShrtWhitste Long Whitste Mareas ShrtWhitste Long Guiro Claves Woodblock Woodblock Woodblock Woodblock Shaker Jone Timbale Bell Tree Castanets Shaker Castanets Shaker Castanets Shaker Castanets Mute Surdo Open Surdo Applause	Bongo High Bongo Le Bongo High Bongo Le Rose Hi Conga Conga Hi Opin Conga Le Conga Rango Cabasa Maracas ShriWhistle Long Whistle Short Guiro Long Guiro Claves Woodblock Woodblock Mute Cuica Open Cuica Mute Cuica Open Cuica Mute Cuica Open Cuica Mute Cuica Open Ciusa Mute Triangl Open Triangl Shaker Rell Tree Castanees More Surdo Open Surdo Ope	Bongo High Bongo Lo Maure H Compa Compa Hi Opn Compa Hi Opn Compa Hi Opn Low Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Mazacas Sherwibiste Long Shiritiste Short Galze Woodblock Woodblock Woodblock Woodblock Mute Luica Open Ciriand Mute Triangl Open Triangl Shaler Single Bell Bell Tree Catarasis Mute Surdo Open Surdo	Bongo Lipih Bongo Lo Mutre H Conga Conga Hi Opn Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Agogo Agogo Cabasa Maraca ShrtWhistle Long Whistle Long Guiro Llows Woodblock Woodblock Woodblock Mutr Cuica Open Crist Mutr Triangl Open Triangl Shate Jone Firangl Shate Jone Firangl Open Triangl Shate Jone Firangl Shate Jone Bell Bell Tre Castames Muta Farangl Open Surdo	NewGobongo NewCongaSip NewCongaSip NewCongaSip NewConga NewConga NewConga NewConga NewConga NewShaker NewTmbIti NewTmbIti NewTmbIti NewTmbIti NewTmbIti NewShaker NewShaker NewShaker NewShaker NewGuide	Bongo Lo Marie H. Conga Marie H. Conga Gong H. Gong Gong Lo Ogn Gong Gong Gong Gong Gong Gong Gong Go	Tabla Ge Tabla Ge Tabla Ge Tabla Ge Tabla Go Rend Ik, dem Casixi Diembe Ojembe Im Low Timbale Timbil Paila High Timbale Cowbell Bongo High Bongo Lo Mute H.Conga Mute H.Conga Mute H.Conga Mit Opn Conga Hill Opn Conga Side Mut Pandiero Opn Surdo Mute Surdo Tamborina Agogo Agogo Shaker Low Whistle Low Whistle Low Whistle Low Whistle
1	Bongo Lo Mote N Conga Mote N Co	Bongo High Bongo Lo Mute H.Conga Conga It Opn Conga It Opn Conga It Opn High Timbale Low Timbale Apogo Apogo Apogo Apogo Edbasa B08mare ShrtWhistle LongWhistle Short Guira R78 Guito Woodblock Hoo Mute Triangl Mute Triangl G26 Shaker Jingle Bell Bell Tree Castanes Capalianes Capalianes Capalianes Capalianes Capalianes Capalianes Capalianes Capalianes Capalianes Castanes Capalianes C	Bongo i o Mute H Conga Conga Hi Opi Conga Lo Opi High Timbale Low Timbale Agogo Cabesa Marzes Shriffhiste Low Shribite Low Good Cabesa Marzes Shriffhiste Short Gairo Cangaline Marzes Mute Cisica Opin Culca Mute Cisica Opin Cisica Mute Cisica Opin Cisic	Bongo Lo Mute H Conga Conga H i Opn Conga Lo Opn High Timbale Low Timbale Agogo Cabasa Mareas ShrtWhitste Low Whitste Long Whitste Mareas ShrtWhitste Long Whitste Mareas ShrtWhitste Long Whitste Mareas ShrtWhitste Long Whitste Mareas ShrtWhitste Long Guiro Claves Woodblock Woodblock Woodblock Woodblock Shaker Jone Timbale Bell Tree Castanets Shaker Castanets Shaker Castanets Shaker Castanets Mute Surdo Open Surdo Applause	Bongo High Bongo Li Bongo Agogo Agogo Cabena Maracas ShriffWistle Long-Whistle Long-Whistle Long-Whistle Long-Whistle Long-Whistle Long-Whistle Long-Whistle Long-Guiko Claves Woodblock Woodblock Mute Cuika Open Cuika Mute Triangl Open-Tangl Shaker Lingle Bell Bell Teel Castanets Mute Surdo Open-Surdo Applaxoe ————————————————————————————————————	Bongo High Bongo Lo Maure H Compa Compa Hi Opn Compa Hi Opn Compa Hi Opn Low Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Mazacas Sherwibiste Long Shiritiste Short Galze Woodblock Woodblock Woodblock Woodblock Mute Luica Open Ciriand Mute Triangl Open Triangl Shaler Single Bell Bell Tree Catarasts Mute Surdo Open Surdo	Bongo Lipih Bongo Lo Mutre H Conga Conga Hi Opn Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Agogo Agogo Cabasa Maraca ShrtWhistle Long Whistle Long Guiro Llows Woodblock Woodblock Woodblock Mutr Cuica Open Crist Mutr Triangl Open Triangl Shate Jone Firangl Shate Jone Firangl Open Triangl Shate Jone Firangl Shate Jone Bell Bell Tre Castames Muta Farangl Open Surdo	NewGobongo NewCongstip NewCongstip NewCongstip NewGobongo NewGobon	Bongs Lo Mute H.Conga Gnag Hi Opn Gnag Lo Opn High I Thouse Hard Hard Agogo Cabasa Maracas ShriWhistle Low Gribale Short Guiro Long Guiro Canes Woodblock Mute Cuica Open Cuica Mute Frangi Bell Tree Castanets Mote Survivo Mote Survivo Mote Survivo Open Faring Hingle Bell Bell Tree Castanets Mote Survivo Mote Survivo Open Survivo Applance ————————————————————————————————————	Tabla Ge Tabla Ge Tabla Ge Tabla Ge Tabla Ge Tabla Ge Bend tik, drm Casixi Djembe Djembe Jim Low Timbale Timbi Paila High Timbale Cowbell Bongo Hoh Mute H.Conga Bongo Ho Mute H.Conga Mutow Conga Side Mutow Con
1	Bongo Lo Mote N Conga Mote N Co	Bongo High Bongo Lo Mute Hi Chonga Conga Hi Opn Conga Hi Opn Conga Hi Opn High Timbale Low	Bongo I o Must H Conga Conga Hi Opn Conga Li Opn Conga Lo Opn High Timbale Low Timbale Agogo Cabasa Masscas ShrtWhistle Low Whitstle LongWhistle LongW	Bongo Lo Mute H Conga Conga H i Opn Conga Lo Opn High Timbale Low Timbale Agogo Cabasa Mareas ShrtWhitste Low Whitste Long Whitste Mareas ShrtWhitste Long Whitste Mareas ShrtWhitste Long Whitste Mareas ShrtWhitste Long Whitste Mareas ShrtWhitste Long Guiro Claves Woodblock Woodblock Woodblock Woodblock Shaker Jone Timbale Bell Tree Castanets Shaker Castanets Shaker Castanets Shaker Castanets Mute Surdo Open Surdo Applause	Bongo High Bongo Le Bongo High Bongo Le Bongo Le Conga Hi Opn Conga Hi Opn Conga Le Conga Maracas ShriWhistle Long Whistle Short Guiro Long Guiro Claves Woodblock Woodblock Woodblock Mute Cuica Open Cuica Muter Cuica Open Survio Conga Cuica Shaker Conga Cuica Conga Cuica Conga Cuica Muter Cuica Open Survio Conga Cuica Conga Cuica Cuica Conga Cuica	Bongo High Bongo Lo Maure H Compa Compa Hi Opn Compa Hi Opn Compa Hi Opn Low Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Mazacas Sherwibiste Long Shiritiste Short Galze Woodblock Woodblock Woodblock Woodblock Mute Luica Open Ciriand Mute Triangl Open Triangl Shaler Single Bell Bell Tree Catarasts Mute Surdo Open Surdo	Bongo Lipih Bongo Lo Mutre H Conga Conga Hi Opn Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Agogo Agogo Cabasa Maraca ShrtWhistle Long Whistle Long Guiro Llows Woodblock Woodblock Woodblock Mutr Cuica Open Crist Mutr Triangl Open Triangl Shate Jone Firangl Shate Jone Firangl Open Triangl Shate Jone Firangl Shate Jone Bell Bell Tre Castames Muta Farangl Open Surdo	NewGobongo NewCongaSip NewCongaSip NewCongaSip NewConga NewConga NewConga NewConga NewConga NewShaker NewTmbIti NewTmbIti NewTmbIti NewTmbIti NewTmbIti NewShaker NewShaker NewShaker NewShaker NewGuide	Bongo Lo Marie H.Conga Gang H.G Opin Canga Lo Opin Figh Timbale Low Timbale Agogo Cabasa Maracas ShrtWhiste LongWhiste Maracas ShrtWhiste LongWhiste LongWhiste Maracas ShrtWhiste LongWhiste Maracas ShrtWhiste LongWhiste Maracas ShrtWhiste LongWhiste Maracas Mar	Table Ge Table Ge Table Ge Table Ge Table Grin Rend tik, drm Casizi Diembe Djembe rin Low Timbale Timbi Pasia High Timbale Cowbell Bongo High Bongo Li Mute H. Conga Conga Hi Opn Conga Side Mut Pamoliero Opn Pamoliero Opn Pamoliero Opn Pamoliero Opn Sando Mute Surdo Agogo Shaker Low Whistle Low Whistle Low Whistle Low Whistle Low Whistle Mute Cuica Open Cuica Mute Cuica
1	Bongo Lo Muta H Conga Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Cabasa ShritWhidale LongWhistle ShritWhidale LongWhistle ShritWhidale LongWhistle ShritWhidale LongWhistle ShritWhidale Long	Bongo High Bongo Lo Mute H.Conga Conga It Opn Conga It Opn Conga It Opn High Timbale Low Timbale Apogo Apogo Apogo Apogo Edbasa B08mare ShrtWhistle LongWhistle Short Guira R78 Guito Woodblock Hoo Mute Triangl Mute Triangl G26 Shaker Jingle Bell Bell Tree Castanes Capalianes Capalianes Capalianes Capalianes Capalianes Capalianes Capalianes Capalianes Capalianes Castanes Capalianes C	Bongo I o Must H Conga Conga Hi Opn Conga Li Opn Conga Lo Opn High Timbale Low Timbale Agogo Cabasa Masscan ShrtWhistle Low Whitstle LongWhistle Long Guiro Cawas Woodblock Woodblock Woodblock Woodblock Woodblock Cawas Copen Cuica Mute Triangl Open Timorgl Shaker Lingle Bell Bell Tree Castannes Long Guiro Long	Bongo Lo Mute H Conga Conga H i Opn Conga Lo Opn High Timbale Low Timbale Agogo Cabasa Maracas ShrtWhistle Low Whistle Long Whistle Long Whistle Maracas ShrtWhistle Long Whistle Long Gairip Claves Woodblock Mute Cuica Open Cuica Mute Triangl Open Triangl Shaker Gastanets Shaker Long Gairip Claves Woodblock Mute Triangl Open Triangl Shaker Castanets Castanets Castanets Castanets Castanets Castanets Shaker Castanets Cast	Bongo High Bongo Le Bongo High Bongo Le Bongo Le Conga Hi Opn Conga Hi Opn Conga Le Conga Maracas ShriWhistle Long Whistle Short Guiro Long Guiro Claves Woodblock Woodblock Woodblock Mute Cuica Open Cuica Muter Cuica Open Survio Conga Cuica Shaker Conga Cuica Conga Cuica Conga Cuica Muter Cuica Open Survio Conga Cuica Conga Cuica Cuica Conga Cuica	Bongo High Bongo Lo Maure H Compa Compa Hi Opn Compa Hi Opn Compa Hi Opn Low Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Mazacas Sherwibiste Long Shiritiste Short Galze Woodblock Woodblock Woodblock Woodblock Mute Luica Open Ciriand Mute Triangl Open Triangl Shaler Single Bell Bell Tree Catarasts Mute Surdo Open Surdo	Bongo Lipih Bongo Lo Mutre H Conga Conga Hi Opn Conga Hi Opn Conga Lo Opn High Timbale Long Gabasa Agogo Agogo Agogo Cabasa Maracas ShrrtWhistle Long Whistle Long Whistle Long Whistle Woodblock Woodblock Woodblock Mutr Culca Open Circla Muta Prinang Long Circla Muta Prinang Long Circla Muta Prinang Long Farinang Shaker Inngle Bell Bell Bell Tree Castanets Muta Prinang Open Surdo Applause	NewGoborgo NewCongstlp NewCongstlp NewCongstlp NewCongstlp NewCongstlp NewTmblti Agogo NewTmblti NewTmblti Agogo NewShaker1 NewShaker1 NewShaker1 NewGoborg NewShaker1 NewGoborg NewShaker1 NewGoborg NewGobor	Bongo Lo Mare H.Conga Mare H.Conga Gonga H.Gong Gonga Lo Ogn Maraces Maraces ShrtWhistle LongWhistle LongWhistle LongWhistle Long Guiro Cares Short Guiro Long Guiro Cares Moodblock Woodblock Woodblock Moodblock Jone Guiro Open Cuka Mute Crisngl Open Cuka Mute Grangl Shater Jingle Bell Bell Bell Bell Tree Castanets Muter Sarad Open Surdo	Tabla Ge Tabla Ge Tabla Ge Tabla Ge Tabla Ge Tabla Grun Bend tik, drm Casizi Diembe Djembe Jim Low Timbale Timbl Paila High Timbale Cowhell Bongo High Bongo Lo Mute H.Conga Bongo High Rongo Lo Mute H.Conga Mute M.Conga High Conga High Conga Side Mute Michael Conga Side Mute Michael Conga Side Mute Michael Conga Side Mute Michael Conga Side Mute Side Copen Sid
(1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	Bongo Lo Mote N Conga Mote N Co	Bongo High Bongo Lo Mute Hi Chonga Conga Hi Opn Conga Hi Opn Conga Hi Opn High Timbale Low	Bongo I o Must H Conga Conga Hi Opn Conga Li Opn Conga Lo Opn High Timbale Low Timbale Agogo Cabasa Masscan ShrtWhistle Low Whitstle LongWhistle Long Guiro Cawas Woodblock Woodblock Woodblock Woodblock Woodblock Cawas Copen Cuica Mute Triangl Open Timorgl Shaker Lingle Bell Bell Tree Castannes Long Guiro Long	Bongo Lo Mute H Conga Conga H i Onn Conga Lo Opin High Timbale Low Timbale Low Timbale Agogo Cabasa Maracas Shriffmitte Long Whithite Long Whithite Long Whithite Short Guiro Long Gairo Claves Woodblock Mute Cuica Open Cuica Mute Friangl OpenTicknet Shriffmitte Bell Tiree Castanets Mute Surdo Open Surdo Applause	Bongo High Bongo Le Bongo High Bongo Le Bongo Le Conga Hi Opn Conga Hi Opn Conga Le Conga Maracas ShriWhistle Long Whistle Short Guiro Long Guiro Claves Woodblock Woodblock Woodblock Mute Cuica Open Cuica Muter Cuica Open Survio Conga Cuica Shaker Conga Cuica Conga Cuica Conga Cuica Muter Cuica Open Survio Conga Cuica Conga Cuica Cuica Conga Cuica	Bongo High Bongo Lo Maure H Compa Compa Hi Opn Compa Hi Opn Compa Hi Opn Low Timbale Low Timbale Low Timbale Agogo Agogo Cabasa Mazacas Sherwibiste Long Shiritiste Short Galze Woodblock Woodblock Woodblock Woodblock Mute Luica Open Ciriand Mute Triangl Open Triangl Shaler Single Bell Bell Tree Catarasts Mute Surdo Open Surdo	Bongo Lipih Bongo Lo Mutre H Conga Conga Hi Opn Conga Hi Opn Conga Lo Opn High Timbale Low Timbale Agogo Agogo Agogo Agogo Cabasa Maraca ShrtWhistle Long Whistle Long Guiro Llows Woodblock Woodblock Woodblock Mutr Cuica Open Crist Mutr Triangl Open Triangl Shate Jone Firangl Shate Jone Firangl Open Triangl Shate Jone Firangl Shate Jone Bell Bell Tre Castames Muta Farangl Open Surdo	NewGobongo NewCongasip NewCongasip NewCongasip NewConga NewTinbiti NewTinbiti NewTinbiti NewTinbiti NewTinbiti NewTinbiti NewTinbiti NewTinbiti NewTinbiti NewConga NewShakeri NewConga NewShakeri NewConga NewShakeri NewCongasi NewCo	Bongo Lo Mare H.Conga Conga H.Gong Conga Lo Opin Figh Timbale Low Timbale Agogo Cabasa Maracas ShrtWhistle LongWhatle Short Gulto Canga Ed Gulto Cabasa Mutatas Mutata	Table, Ge Table Ge Hi Table Ge Hi Table Ge Hi Table Ge Hi Table Grown Bend til, dem Casais Diembe Djembe Jen Low Timbale Timble Pala High Timbale Convbell Bengo Irish Bengo Lo Mute H. Conga High Tembale Conga Hill Conga Hill Conga Hill Conga Hill Mute H. Conga Mute M. Conga Lo Conga Sibp Conga Sibp Conga Sibp Conga Sibp Conga Sibp Conga Sibp Sibp Sibp Sibp Sibp Sibp Sibp Sibp

		PC: 30 (CC32: 4) TR-767	PC: 31 (CC32: 4) TR-909	PC: 33 (CC32: 4) JAZZ	PC: 34 [CC32: 4] JAZZ L/R	PC: 41 (CC32: 4) BRUSH	PC: 42 CC32: 4 BRUSH 2	PC: 43 (CC32: 4) BRUSH 2 L/R	PC: 44 (CC32: 4) V-lazzBresh	PC: 49 [CC32: 4] ORCHESTRA	PC: 50 (CC32: 4) ETHNIC
co [96)	()	()	()	(851z BsDrum2)	()	()	(858r BsDrum2)	(CajonHi)	()	(Cabasa Down)
7	97	Techno Hit	Techno Hit	**	851z CrsCym1		-	85Br CrsCym1	CajonHifim	Applause 2	Claves
- 1	96	Philly Hit	Philly Hit	858r Snare1	85iz Snare1	-	851z Snare 1	85Br Snare 1	CajonLo	Small Club	Woodbiock
-	(ii)	Shock Wave	Shock Wave	\$58r Snare2	85/z AdCym		85.lz Snare2	BSBr RdCym	CajonLoFim	Timpani	Woodbiock
	100	Lo fi Rave	Lo fi Rave	Brush Sweri	85/z Snare2	Brush Switl	Brush Swirl	85Br SnareZ	FirmcoHClp1	Timpani	
t	101	Bam Hit	Bam Hit	Brush Tap	851z Tom16	Brush Tap	Brush Tap	858r Tom3	FirmwoHClp!	Timpani	
L	102	Birm Hit	Birn Hit	Brush Slap1	85iz CisHat	Brush Slap 1	Brush Siap 1	85Br ClsHat	BangoCowBell	Timpani	
	103	Tapellewind	TapeRewind	Brush Slap2	8512 Tom13	Brush Slap2	Brush Slap2	858r Torn2	Afiley	Timpani	
-	184	Phono Noise	Phono Noise	Brush Slap	USJ2 RdBell	Brush Slap	Brush Slap	858r RdBell	MamboCowBell	Timpani	
ĺ	105	Dance Snare1	Dance Snare !	Brush Swirt	R51z Tam12	Brush Swirl	Brush Swirt	BSBr Tom1	MexFV012	Timpani	
- }	105	Power Snare2	Power Snare2	Brush Swirt	851z OpenHat	Brush Swirl	Brush Swirl	85Er OpenHat	Affoots	Timpani	
- 1	107	Elec Snare 1	Elec Snare 1	Long Swirl	851zBsDrum 1P	Long Swirl	Long Swirl	85Br8sDrum SP	MexFVox1	Timpani	
a [108	Dance Snare2	Dance Snare2	Jazz Snare 1	85Jz9sDrum2P	Jazz Snare 1	Jazz Snare 1	858rBsDrum2P	MexMVox1	Timperi	
_ [109	Elec Snare 2	Elec Snare 2	Jazz Snare 2	85.tzCrsCym 1P	Jazz Snare 2	Jazz Snare Z	BSBrCrsCym1P	YodelFVox1	limpani	
	110	Elec. Spare	Elec, Snare	Std. 1 Snare 1	851z Snare 1P	Std.1 Snare1	Std.1 Snare1	858r Snare 1P	MexMVox2	Timpani	
ŀ	- 111	Elec Snare 3	Elec Snare 3	Std.1 Snare2	85.12 RdCym P	Std.1 Snare2	Std.1 SnareZ	85Br RdCynt P	YodelMVax 1	Timpani	
	112	66sn260	66sn260	Std.2 Snare 1	85Jz SnareZP	Std.2 Snare1	Std.2 Snare1	858r Snare2P	MexMVox3	Timpani	_
ł	113	TR-707 SD	TR-707 SD	Std.2 Snare2	851z Tom16 P	Std.2 Snare2	Std.2 Snare2	8581 Tom3 P	FirmcoFVox1	Timpani	_
1	110	808 Snare 1	808 Snare 1	Tight Snare	851z CisHatP	Tight Snare	Tight Snare	858rClsHat P	YadelFVax2	-	
ı	115	806 Snare 2	808 Snare 2	Standard SN1	85Jz Tom13 P	Standard SN1	Standard SN1	858r Tom2 P	FirmncoFVox2	-	-
ļ	116	TR-808 SD2	TR-808 SD2	LD Snare M	BS/z AdBellP	LD Snare M	LD Snare M	BSBr RdBeliP	NewWhistle1	_	
- 1	117	909 Snare 1	909 Snare 1	LD Snare C	BSJz Tom12 P	LD Snare C	LD Snare C	858r Tom1 P	FirmncoFVox3		
ŀ	118	909 Snare 2	909 Snare 2	Room Snare !	85/zOpenHatP	Room Snare 1	Room Snare 1	858rOpenHatP	NewWhistle2		
- 1	119	909 SD 1	909 SD 1	Room Snare 2	-	Room Snare 2	Room Snare 2		FirmncoMVox 1		-
أوح	120	TR-909 SD2	TR-909 SD2	Dance Strare1		Dance Snare1	Dance Snare1	-	FimncoMVox2	-	
- [Rap Snare	Rap Snare	Power Snare1		Power Snare1	Power Snare1	-	BrazilVos i		
-	122	JungleSD1	JungleSD1	Rev.Snare		Rev.Snare	Rev.Snare	_	Flmn(oMVox3	-	<u> </u>
1		House SD	House SD	Power Snare2		Power Snare2	Power Snare2		BrazilVox2		
- 1	124	House Snare	House Snare	Elec Snare 1		Ejec Snare 1	Elec Snare 1	_	BrazilVox3		
1	125	House SD	House SD	Dance Snare2		Dance Snare2	Dance Snare?	100	AfAahhh		
ĺ	120	Voice Tah	Voice Tah	Elec Snare 2		Elec Snare 2	Elec Snare 2	tre-	p33137v		
9	127	Noise Slap	Noise Slap	Elec Snare 3		Elec Snare 3	Elec Snare 3		p33168v		

		PC: 51 (CC32: 4) KICK & SMARE	PC: 52 (CC32: 4) KICK & SNARE 2	PC: 53 [CC32: 4] ASIA	PC: 54 [CC32: 4] CYMBALRCLAPS	PC: 55 (CC32: 4) GAMELAN 1	PC; 56 (CC32: 4) GAMELAN 2	PC: 57 [CC32: 4] SFX	PC: 58 (CC32: 4) Rhythm fx	PC: 59 [CC32: 4] RHYTHM FX 2	PC: 60 [CCI3: 4] RHYTHM EX 3
(0)	(96)	(HipHop SD2)	(HipHop SD2)	()	()	()	()	(Perc. Bang)	()	()	(R Boeeeen)
,,	39	JungleSD1	JungleSD1	_	-		-			***	R Bounce
	98	Jungle SD2	Jungle 5D2			***				-	R CD Tray
}	99	Slap	Slap			-					R Drill
1	100	MG Blip	MG_Blip	_		-					R Glass Stir
1	101	House SD	House SD					-			R ke Ring
1	192	CR78 SD 1	CR78 SD 1	-	**		-	-			R Kinzapom
	103	CR78 SD 2	CR78 SD 2			-					R Scratch 4
	104	66sn160	66sn160	_		***					R Scratch S
	105	66sn260	66sn26D								R Scraich 6
1	106	TR-707 SD	TR-707 SD								A Scratch 7
	107	1R-707 SD 2	TR-707 SD 2	-	-	**				м.	R Seal
C8	108	TR-707 5D 3	TR-707 SD 3		**		-	-	**		R Stabl 1
-	102	TR-808 SD2	TR-608 5D2			_			***	-	R Stab! 2
	110	909 SD 1	909 50 1								R Swid Boomi
	-	TR-909 SD2	TR-909 SD2	_			-	-	-		R Swed Cross
	112	-	-				_	_	***		A Thrill Hit
	113			-			_			-	R Audio Sw
- 1	i dili				_	_	_	_		-	R Typing 1
	135			-				-	-	-	R Typing 2
	116			_			-	_	-		R Typing 3
	117	-			-						R Typing 4
- 1	1118	-		_							R Typing 5
	119	_			**	-	_				R Typing 6
C9	120					-	***		•	-	
	.2								-	-	
	122			***	***				-		-
		_			-		_		-		
	124						-	-			***
	125							-	-		_
	125		***		_	~-		_			
GS					***			_			
G9	127				<u></u>						

10 13 13 13 13 13 13 13 13 13 13 13 13 13					Let a control to the		and		services and services are services and services are services and services and services and services are services and services and services and services are services and servi	
10 13 13 13 13 13 13 13 13 13 13 13 13 13	The state of the s			10 10 10 10 10 10 10 10 10 10 10 10 10 1	To the second se		10 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		100 mm m m m m m m m m m m m m m m m m m	
10 13 13 13 13 13 13 13 13 13 13 13 13 13	The state of the s				TO THE PROPERTY OF THE PROPERT				45	
13 13 13 13 13 13 13 13 13 13 13 13 13 1					TO THE PROPERTY OF THE PROPERT			ala		-
13 13 13 13 13 13 13 13 13 13 13 13 13 1			ten		TO THE PROPERTY OF THE PROPERT				-	
13 13 13 15 15 15 15 15 15 15 15 15 15 15 15 15			ten		TO THE PROPERTY OF THE PROPERT					
13 - 13 - 13 - 13 - 13 - 13 - 13 - 13 -			ten		TO THE PROPERTY OF THE PROPERT					
13 - 13 - 13 - 13 - 13 - 13 - 13 - 13 -			ten		TO THE PROPERTY OF THE PROPERT		100			
13 13 14 15 15 15 15 15 15 15 15 15 15 15 15 15			ten		12 12 12 12 12 12 12 12 12 12 12 12 12 1		-			
15			ten				_			
15			ten				_			
15			-					***		
15 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -		-					-			
15							-		-	
20							_	-	_	
15			**					_		
	±.								_	R Bs Mute NZ
	±.			***		 				R 8s StQuail
										R 8s Atk NZ
							MC-500 Beep			R CinGtCutUp
						**	MC-500 Beep			R CinGtCutDn R CinGtrMtUp
	 C978 BD 5					-	ytwn3.xtp	~		R GnGtrMtDn
	C978 RD 1	_					ytwn2.xtp	-	-	R DstGtCutUp
		CR78 BD 1	Gamelan Gong				Guitar Slap			R OstGtCutOn
	CR78 8D 2	CR78 8D 2	Gamelan Gong				Chord Stroke			R DstGtr\$gdn
	TR-606 BD1 TR-707 BD	7R-606 BD1 TR-707 BD	Gamelan Gong				Chard Strake			R DstGtrMute
(3)(2)(3)(3)	1R-707 BD 808 BD	19-707 BD 808 BD	Gamelan Gong Gamelan Gong				Siwa 3			R SIGHTSON21
- confession and	909 Comp 8D	909 Comp 80	Gameian Gong Gameian Gong	_			Phono Noise TapeRewind			R SIGIrSoNzZ
	TR-909 BD2	TR-909 BD2	Gamelan Gong				Scritch Push2			R SIGtrSdNz3 R SiGtrSdNz4
	HipHop 8D2	HipHop 802	Gamelan Gong	rev.fvohh	_	~	Scritch Pull2			R SIGtrStkSD
· H	HipHop 8D1	HipHop SD1	Gamelan Gong	Rev. LVCHH 1			Gt CutNoise2			R SIGuStkU1
	Jungle BD2	Jungle BD2	Gamelan Gong	Rev. LVCHH 2			Gt.CutNaise2			R SIGIrStkD1
	JungleBD Set	JungleBD Set	Gender	Jungle HH			Dist.CutNoiz			R SIGtrStkUZ
	Techno BD2	Techno BD2	Gender	Close HiHat	KendangWadon	KendangWadon	Dist.CutNoiz	Rev.Kick 1	rev 707tsd	R SIGtrStkD2
_	Techno 801	Fechno BD1	Gender	Jazz Ckd.HH	KendangWadon	KendangWadon	Bass SRde	Rev.ConBD	rev.909bd2	R Thone NZ
	Mix Kick Standard KX1	Mix Kick Standard KK1	Gender Gender	Room Chh	Beberongen	Bebarongan	Pick Scrape	Rev.PowerK1	rev.hphp_bd1	R Tpet NZ
	Std.1 Kick1	855t BsDrum1	Bonang	Close HiHat!	Pelegongan Kelentuk	Pelegongan Kelontuk	High-Q Slap	Rev.Elec.K1	rev jgl_bd2	R St BsDrum1
	Std.1 Kick2	85St BsDrum2	Banang	TR-707 HH-c	Kelontuk Mt	Kelontuk Mt	ScratthPush	Rev.Snare 1 Rev.Snare 2	rev.tech_bd2 rev.606sn2	R St BsDrum2 R Rm BsDrum1
	Std.2 Kick1	858r 8sDrum1	Bonang	606 CH	Kelontuk Sid	Kelontuk Sid	ScratchPull	Rev.Std1SD1	rev.cr78id1	R Rm BsDrum2
	Std2 Kick2	85Br 8sDrum2	Bonang	808_chit	Gong Wadon	Gong Wadon	Sticks	Rev.TightSD	rev.cr78sd2	R /z BsDrum1
К	Kitk 1	85Jz BiDrumi	8onang	TR-808 CHH	Gong Lanang	Gong Lanang	SquareClick	Rev.DanceSD	rev.jgl_sd2	R Iz BsDrum2
	Kick 2	851z BsDrum2	RAMA Cymbai	CR-78 chh	Ceng Ceng	Cenq Cenq	Mtrnm.Click	Rev.8085D	rev.tech_sd2	R Sr BsDrum1
	Saft Kick	HipHap BD 2	RAMA Cymbal	GS Pedal HH	Kopyak Op	Коруак Ор	Mirnm Bell	Rev.Tom 1	rev.707sd	R Br BsDrum2
100000000	lazz Kick 1	HipHop BD	Sagat R	Pedal HiHat	Kopyak Mt	Kopyak Mt	GLFretNoiz	Rev.Tom 2	rev.606sn1	R HipHop BD2
	Jazz Kick 2 Concert BD	Concert BD	Sagat L-c Jaw Harp Wow	Pedai HiHat2 Haif OpenHH1	Kajar	Kajar	Gt.CutNoise	Rev.Sticks	rev.909sd1	R HipHop BD
	Coom Kick 1	BSRm BsDrum1	Wadaiko	Haif OpenHH2	Kempur Jegogan	Kempur Jegogan	Gt.CutNoise String Slap	ReverseCymbl	rev.hphp_sd2	R Ingl BD
25,2-9, 16,97	Room Kick 2	BSRm BsDrum2	Wadaiko Rim	Open Hi Hat	Jegogan33up	Jegogan40up	Fl.KeyClick	Rev.Cymbal2	rev.jgl_sd1 Rev House SD	R ingli BD 2 R 808 BD
	Power Kick t	Jngl BD	Taiko	Jazz Open HH	Jegogan33dw	Jegogan20dw	Laughing	Rev.Open HH	Rev. LVCHH 1	R 909 BD
Po	Power Kick2	Jngl 8D 2	Shimedaiko	R8 Ohh2	Jegogan 33dw	Jegogan20up	Screaming	Rev RideCym	rev.606htcl	R 909 8D 2
	lec Kirk 2	Jngl 80 Roll	Atarigane	Open HiHat?	Jegogan	Jegogan40up	Punch	Rev.CR 78OHH	rev.707chh	R Fat SD
110/11/1955	Hec Kick 1	Fat 80	Hyoushigi	909 OH	lublag	lublag	Heart Bzat	Rev.Clsti.HH	rev.808chh	R Dance BD
	lec. Kick	Dance BD	Ohkawa	1R-767 CHH	Jublag 33up	Jublag4Dup	Footsteps	Rev.BendGong	rev.jgl_hh	R St Snare2
	R-808 Klck R-909 Kick	808 BD	H kotsuzumi	506 HiHat Op	lublag33dw	Jublag20dw	Footsteps	Rev.Beiltree	rev.344tmb2	R St Snare1
and the same of th	Dance Kick 2	909 BD 2	L Kotsuzumi Yyaa Dude	806_ohh TR-808 OHH	Jublag33dw Jublag	Jublag20up	Applause	Rev.Guiro	rev.344tmb3	R Rm Snare2
	itd.1 Snare1	85St Snare2	Buk f	CR-78 ohh	Penyacah33dw	Aubiag40up Penyacah20up	Creaking Door	Rev.Bendir Rev.GuriShot	rev.808ahh rev.707ahh	R Rm Snare1 R Jz Snare1
	td.1 Snare2	85St Snare1	Buk r	Crash Cym.1	Penyacah	Penyacah40up	Scratch	Rev.Scratch	rev.lvahh	R Jz Snare2
	td.2 Snare1	Std.2 Snare1	Gengari_p	Crash Cym.2	Fenyacah	Fenyacah	Wind Crimes	Rev.Lasergun	rev.606cym	R Br Snare1
dia St	td.2 Snare2	Std.2 Snare2	Gengari_m	GS Crash	Penyacah33up	Penyacah40up	Car-Engine	Click	Rev. Hyntuo	R Br Snare2
	ight Snare	Tight Snare	Gengari_f	Brush Crash	Penyacah33dw	Penyacah20dw	Car-Stop	Tekno Thip	rev.707fx	R LaFi SD 1
	Concert Snr	Concert Snr	Gengari_m	Hard Crash	Penyacah33dw	Penyacah 20up	Car-Pass	Pop Drop	Voice One	A LoFFSD 2
	azz Snare 1	851z Snare1	Gengari S	909 Crash	Penyacah	Penyacah40up	Car-Crash	Wood Slap	rev.one	A HipHop SD1
	azz Snare 2 Dom Snare 1	85iz Snare2 85Rm Snare2	Jang-Gu_c	808 Crash	Pemade33up	Pemade40up	Siren	Dist.Kick	Vaice Two	R HipHop SD2
	oom Snare 1		Jang-Gu_k	Cresh Mute 1	remade33dw	Pemade20dw	Train	Syn.Drops	rev.two	R House SD
	nom snare 2 Nance Snare 1	85Rm Snare1 LoFi SO 1	tang-Gu r ting p	Crash Mute 2 ReverseCymbi	Pernade33dw Pernade	Pemade20up Pemade20up	Jetplane Heliconter	Rev.Hi-Q ShrtWhistle	Voice Three	R Ingl SD
COUNTRIES	ower Snare 1	Lofi SD 2	ang p 1_pnit	Rev.Cymbal2	Pernade	Pemade20up Pemade	Helicopter Starship	ShrtWhistle Ice Block	Voice Tab	R 606 SD 2
	ev.Snare	Rev.Snare	Jing_m	Reverse Cym.	Pernade33up	Pemade40up	Gun Shot	Digi Tambrn.	Voice Tah rev.tah	R Techno SD R Dance SD
	ower Snare2	LoFi SD Rim	Asian Gong 1	rev.tra_crsm	Pernade 13dw	Pemade20dw	Machine Gun	Alias	Voice 1	R RockSD Dry
Electric Box	lec Snare 1	Elec Snare 1	Rig Gong	Crash Cym.1	Pemade33dw	Pemade20up	Lasergun	Mod.Bell	Voice Au	R LoFi SDRim
	lance Snare2	HipHop SD 1	Small Gong	Spiash Cym.	Pemade	Pemade20up	Explosion	Tambourine	Voice Whey	R 909 SD Rim
	lec Snare 2	HipHop SD 2	Pai Ban	Ride Bell	Pemade33up	Pemade	Dog	Metalic Perc	Frag Vpace	R Ingl SDRim
	ouse Snare	Dance 5D	Ban_Gu	Brush RideBL	Reyong 33dw	Reyong 20dw	HorseGallop	Velo FX Noiz	rev.yyooh	R DanceSDRim
	lec. Snare	606 SD 2 Techno SD	tangu60	Ride Cymbal	Reyong33dw	Reyong20up	Bird	St NoiseClap	Douby	R HouseSDRim
	lec Snare 3		tanmt60	Ride Cymbal	Reyoung	Reyong20up	Rain	Swish	rev,douby	A Brsh Tom1
	08 Snare 1 08 Snare 2	House SD Book SD Dou	Bend Gong L	Brush Ride	Reyoung	Reyoung	Thunder	Noise Slap	Baert	R Brsh Tom2
	09 Snare 1	Rock SD Dry Ingi SD	Bend Gong Huyin Luo L	Ride Cym IN	Reyong33up Reyong33dw	Reyong40up	Wind	Voice 1	Baert	R Brsh Tom3
WW. Co.	09 Snare 2	Ingi SD Rali	hynlo60	Ride Cym IN Ride Cym IN	Reyong 33dw Reyong 33dw	Reyong20dw Reyong20up	Seashore Stream	Voice Au	Bounce	R 506 Tom
	rush Swirl	Brush Swirl	Huyin Luo Mt	RideCym Edge	Reyoung Reyoung	Reyongzuup Reyong40up	Stream Bubble	Tape Stop 1	rev.bounce	R Ingl Crash
	rush Tap	Brush Tap	Hu yin Luo H	RideCym Edge	Reyoung	Reyoung	Kitty	Tape Stop 2	Dist Knock ytwn3.xtp	R St CisHat R Rm CisHat
	rush Slap t	850r Snarel	Hynio mute	RideCym Edge	Reyong33up	Reyong40up	Bird 2	Missile	yiwn3.xtp	R Jz CisHat
	rush Siap2	85Br Snare2	naobo60	606 Ride Cym	Reyong 33dw	Reyong20dw	Growl	Space Birds	Noise Attack	R Br CisHat
	rush Slap	Brush Slap	zaobo60	TRBOS Ride	Reyong 33dw	Reyong20up	Applause 2	FlyingMonstr	SpaceWorms	R 707 Claps
	rush Swirl	Brush Swiri	Dholak 1	ChinaCymbal			Telephone 1		Emergencyl	R 909 Claps
	rush Swirl	Brush Swiri	Dholak 2	Chaina Cym2	-		Telephone 2	_	Calculating	R R&B Claps1
	ong Swirt	Long Swirl		Hand Clap		_	Small Club		SawLFOSaw	R HipHopClap
	andard SN1	Standard SN1		Hand clap2	_		Small Oub 2		***	R CompClaps2
		LD Snare M		806clap			ApplauseWave			R Shaker 2
		LD Snare C	745	909 HandClap			Eruption			R IngiShaker
		Rap Snare HipHop SDZ		HC2 Claps 2 707 Claps	-	-	Big Shot Perc. Bang			A Clap Hit

	PC: 61 (CC32: 4) SFX 2	PC: 63 (CC32: 4) CYMACLAPS 2	PC: \$4 [CC32: 4] V-VoxDrum	PC: 128 [CC32: 4] CM-64/32L	GM2 STANDARD	GMZ ROOM	GM2 POWER	GMZ ELECTRIC	GM2 ANALOG	GAQ IAZZ
			HipHop BD1							
			Jazz Kick 1		-		_	-		
			p05002v							-
اللتك			85RmBsDrum 18	***						-
			85Rm8sDrum28							-
			909 BD							***
ь			909 RD 2							
			Ingl BD 2	-		*				
3			HipHop BD							
			Нірнор BD 2							
			8551BsOrum 1B						 	
			NewizKik	**						
			NewRockKik							
			CymbalRoll					-		
		_	NewRkCStkMn	-		**				
15		_	85Rm5nare18			_				
	-	***	#5Rm5nare2B						-	
			#55tSnare 18							
18			85515nare28		-					
			New/25n2	**						***
20			New)zSri1							
			NewR&BSn							
22			NewRock5n2mn	-						
	PM.		NewRockSn1mn				-			
		***	iPop5n38mn			_		-	-	
75			iPopGst\$39mn		***	-				-
			PopSn38mn	***						
27			FingerSnaps2		High-Q	High-Q	High-Q	High-Q	High-Q	High-Q
			707 Claps		Slap	Slap	Siap	Slap	Slap	Slap
PE CEL		-	898dap		ScratchPush	ScratchPush	ScratchPush	ScratchPush	ScratchPush	ScratchPush
0 ## 65 PM 70	l		Hand clap2		ScratchPull	ScratchPuB	ScratchPull	ScratchPull	ScratchPull	ScratchPull
AND RES	A Bs Mute Nz		909 HandClap		Sticks	Sticks	Sticks	Sticks	Sticks	Sticks
\$24000 12		R St CliHat			SquareClick	SquareClick	SquareClick	SquareClick	SquareClick	SquareClick
	A.Bs.TouchNz		iPopPHat32 GospelHClp1		Mirno Click	Mtrom.Click	Mirner Click	Mtrnm.Click	Mtrnm Click	Mtrnm.Click
	A.Bs.AtackNz	R Rm CisHat							Mirrom, Bell	Munn. Bell
	DstGT.MuteNz	R Jz CisHat	p35010v		Mtrnm. Bell	Mitrom, Bell	Mtunm. Bell	Mirnen, Bell		
1 Tab	StiGLSidNz1	R Br CisHat	p05006v	Kick 1	Mix Kick	Mix Kick	Mix Kick	Mix Kick	Mix Kick	Jazz Kick 2
100	StiGLSidNz2	85St ClsHat	p33079v	Kick 1	Standard KK1	Standard KK 1	Power Kick 1	Elec Kick 1	TR-808 Kick	Jazz Kick 1
37	StiGt.SkiNz3	85Rm ChHat	p33146v	Side Stick	Side Stick	Side Stick	Side Stick	Side Stick	BOB Rimshot	Side Stick
建	StiGt.SkiNz4	85Jz CisHat	p3201 tv	Fat Snare	Standard SM1	Standard SN1	Dance Snare1	Elec. Snare	BOB Snare 1	Standard SM1
	Gt.StrokeNz1	85Br CisHat	p43001v	Hand Clap	909 HandClap	909 HandClap	909 HandClap	909 HandGap	909 HandClap	909 HandClap
	Gt_StrokeHz2	TR-707 HH-c	p33137v	Elec. Snare	Elec Snare 3	Elec Snare 3	Elec Snare 3	Elec Snare 2	Elec Snare 3	Flec Snare 3
404.	Gt.StrokeNz3	606 CH	p33168v	Tom	Real Tom 6	Room Tom 5	Rock Tom 4	Synth Orum 2	808 Tom 2	Real Tom 6
42	Gt.StrakeNz4	TR-808 CHH	p33012v	Close HiHat	Close HiHat2	Close HiHat2	Close HiHat2	Close HiHat2	TR-808 CHH	Close HiHat2
188	Gt.StrokeNz5	CR-78 chh	p34001v	Tom	Real Tom 6	Room Tom 5	Rock Tom 4	Synth Drum 2	808 Tom 2	Real Tom 6
4.4	Open CD Tray	GS Pedai HH	p33014v	Open HiHat2	Pedal HiHat2	Pedal HiHat2	Pedal HiHat2	Pedal HiHat2	808_chh	Pedal HiHat2
THE POST	Audio Switch	Pedal HiHat	p33157v	Tom	Real Tom 4	Room Tom 2	Rock Tom 4	Synth Drum Z	808 Tom 2	Real Tom 4
465	Key Typing 1	Pedal HiHat2	ρ33019v	Open Hi Hat	Open HiHat2	Open HiHat2	Open HiHat2	Open HiHat2	TR-808 OHH	Open HiHat2
湖南	Key Typing 2	Half OpenHH1	p33164v	Tom	Real Tom 4	Room Tom 2	Rock Tom 4	Synth Drum 2	806 Tom 2	Real Tom 4
11	Key Typing 3	Half OpenHHZ	p33159v	Tom	Real Tom 1	Room Tom 2	Rack Torn 1	Synth Drum 2	808 Tom 2	Real Tom 1
15		855t OpenHal	p35029v	GS Crash	Crash Cym, I	Crash Cym.1	Crash Cym. 1	Crash Cym.1	806 Crash	Crash Cyrn.1
	Key Typing 4	B5Rm OpenHat	p33158v	Tom	Real Tom 1	Room Tom 2	Rock Tom 1	Synth Drum 2	806 Tom 2	Real Tom 1
	Key Typing 5				Ride Cymbal	Ride Cymbal	Ride Cymbal	Ride Cymbal	Itide Cymbal	Ride Cymbal
awwe	Key Typing 5	85iz OpenHat	p43002v	Ride Cymbal			ChinaCymbal	ReverseCymbi	ChinaCymbal	ChinaCymbal
1	BabyLaughing	BSBr OpenHat	cym013v		ChinaCymbal	ChinaCymbal	Ride Bell	Ride Bell	Ride Bell	Ride Bell
170	Clap Hit	909 OH	p45002v		Ride Bell	Ride Beil				
5-1	Stabl 1	TR-707 OHH	p36017v	Tambourine	Tambourine	Tambourine	Tambourine	Tambourine	Tambourine	Tambourine
NY KON	Stab! 2	606 HiHat Op	p34109v		Splash Cym.	Splash Cym.	Splash Cym.	Splash Cym	Spiash Cym.	Splash Cym.
(H)	Bounce Hit	TR-BOS OHH	p36019v	Cowbell	Cowbell	Cowbell	Cowbell	Cowbell	808cowbe	Cowbell
12.00	Boereen	CR-78 ohh	p44001v		Crash Cym.2	Crash Cynn.2	Crash Cym.2	Crash Cym.2	Crash Cym. 2	Crash Cym.2
-68	Glass & Glam	855t CrsCym1	p36009v		Vibraslap	Vibrasiap	Vibrasiap	Vibraslap	Vibraslap	Vibraslap
lan.	ice Ring	85Rm CrsCym1	Alaahhh		Ride Cymbal	Ripe Cymbai	Ride Cymbal	Ride Cymbai	Ride Cymbal	Ride Cymbal
	Crack Bottle	851z CrsCym1	NewHiBongo	High Bongo	Bonge High	Bongo High	Bongo High	Bongo High	Bongo High	Bongo High
61	Pour Bottle	858r CrsCym1	NewLoBongo	Low Bongo	Bongo i.o	Bongo Lo	Bonga Ło	Bongo Lo	Bongo Lo	Bongo Lo
X PA	Soda	Hard Crash	NewCongaSip	Mute Conga	Mute H.Conga	Mute H.Conga	Mute H.Conga	Mute H. Conga	808 Conga	Mute H.Conga
63	Car Engine 2	909 Crash	NewCongaOp	Conga	Conga Hi Opn	Conga Hi Opn	Conga Hi Opn	Conga Hi Opn	808 Conga	Conga Hi Opn
Teles .	Car Horn	Ingi Crash	NewLoConga	Conga	Conga Lo Opn	Conga Lo Opn	Conga Lo Opn	Canga Lo Opn	808 Conga	Conga Lo Opri
i piglis	R.Crossing	808 Crash	NewTmblHi	Timbales	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale
100	51.1	Std4 CrsCym1	NewTmbiLo	Timbales	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale
	SL 2	Rom2 CrsCym1	Agego	Agogo	Agogo	Agoge	Agoge	Agogo	Agogo	Agago
1/8	Over Blow	Jaz2 CrsCym1	Agogo	Agoge	Agogo	Agogo	Agogo	Agogo	Agogo	Agogo
en week	Sword Boom!	Brs2 CrsCym1	NewShaker2	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa
7/.	Sword Cross	Crash Mute 1	NewShaker1	Maracas	Maracas	Maracas	Maracas	Maracas	808marac	Maracas
1772	Industry Hit	Crash Mute 2	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle
	Drill Hit	rStd4CrhSym1	LangWhistle	LongWhistle	LongWhistle	LangWhistle	LongWhistle	LangWhistle	LongWhistle	LongWhistle
110000	Compresser	rev.tra_crom	NewQuide1	Vibraslap	Short Guiro	Short Guiro	Short Guiro	Short Guiro	Short Guiro	Short Guiro
201000000000000000000000000000000000000	Thrill Hit	rJaz2Crh5ym1	NewQuide2		Long Guiro	Long Guiro	Long Guiro	Long Guiro	Long Guiro	Long Guiro
n 94844466	Explosion 2	rBrs2CrhSym1	NewClaves	Claves	Claves	Claves	Claves	Claves	806ciave	Claves
33841010						Woodblock	Woodblock	Woodblock	Woodblock	Woodblock
	Seal	Splash Cym.	Woodblock	Laughing	Woodblock			Woodblock		Woodblock
	Fancy Animal	85St RdBell	Woodblock	Screaming	Woodblock Made Crise	Woodblock	Woodblock		Woodblock Mute Cuica	
75	Cricket	85Rm RdBeil	Mute Cuica	Punch	Mute Cuica	Mute Cuica	Mute Cuica	Mute Cuica		Mute Cuica
3600	Baert	85Jz AdReli	Open Cuica	Heart Beat	Open Cuica	Open Cuica	Open Cuica	Open Cuica	Open Cuica	Open Cuica
50	Frog Vpoce	BSBr RdBell	MuteTriangi	Footsteps	MuteTriangl	MuteTriangl	MuteTriangl	Mute/riangl	MuteTriangl	MuteTriangl
建國鄉	Wind 2	855t RdCym	OpenTriangl	Footsteps	OpenTriangl	OpenTriangl	OpenTriang	OpenTriangl	OpenTriangl	OpenTriangl
52	Scratch 3	8SRm RdCym	Shaker	Applause	Shaker	Shaker	Shaker	Shaker	Shaker	Shaker
	Scratch 4	851z RdCym	Jingle Bell	Creaking	lingle Bell	Jingie Bell	lingle Bell	Jingle Sell	tingle Bell	Jingle Bell
	Scratch S	858r AdCym	Bell Tree	Door	Bell Tree	Bell Tree	Beil Tree	Bell Tree	Bell Tree	Bell Tree
87	Scratch 6	606 Ride Cym	Castanets	Scratch	Castanets	Castanets	Castanets	Castanets	Castanets	Castanets
	Scratch 7	TRB08 Ride	Mute Surdo	Wind Chimes	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo
87	Noise Attack	ChinaCymbal	Open Surdo	Car-Engine	Open Surdo	Open Surdo	Open Surda	Open Surdo	Open Surdo	Open Surdo
	Bourke	Chaina Cym2	CROI	Car-Stop						
		707 Claps	New1mbiHiFlm	Car-stop Car-Pass						
	Dist Knock									
	1XX	HipHop Claps	NewTmbiLoFim	Car-Crash						
90	-	R&B Claps 1	NewTmbiPHS	Siren	***					
50		909 Claps	NewShekere 1	Train		-				
90	_							••		_
	-	Comp Claps 2	NewShekere2	Jetplane	<u> </u>					
90 92 94	- -		NewShekere2 NHBngoMuse	Jetplane Helicopter						
		Comp Claps 2						**		-

(CC32=122 only via MIDI)

	lancour or second or secon	PC: 61 [CC32: 4] SFX 2	PC 63 [CC32: 4] CYMBCLAPS 2	PC: 64 [CC32: 4] V-VoxDrum	PC: 128 (CC32: 4) CM-64/321	GAZ STANDARD	GM2 ROOM	GM2 POWER	GM2 ELECTRIC	GM2 ANALOG	GMZ JAZZ
(C7)	(96)	()	(707 Claps)	(CajonHi)	(Gun Shot)	()	()	()	()	(···)	()
	97	NAV.	_	CajonHiflm	Machine Gun			-			
	98	_		CajonLo	Lisergun		-		_		-
	99			CajontoFim	Explosion			_			
	100			FimncoHGp1	Dog		-	-	-	-	_
	101			PimnceHClp1	HorseGallop	_	-	***		-	_
	30.2			BangaCowileil	Ried					-	
	103			AfHey	Rain		-			***	***
	1(4			MarrboCowBell	Thunder			-	-	-	-
	105			MexFVax2	Wind						
	196			Affoots	Seashore	***					_
	107			MexFVax1	Stream						
a	108		-	MexMVax1	Bubble			-	_		
	199	-	-	YodeiFVox1	•••	**	-		***	-	-
	110			MexMVax2	***	***	-				-
	2211			YadelMVax1				-	-		_
	112			MexMVax3	-	-	-		**	-	+
	113		**	FirmcoFVox1		_	-				_
		-		YodelFVox2		-			**		_
	115	-		FinuxoFVox2	-	_		-	-	-	***
		-		NewWhistie1		_			-	_	_
	117		111	FirmncoFVox3	-						
	118			NewWhistleZ							
	119		144	FimncoMVox1			-		***		
C9	120	-		FirmncoMVox2	***		_	-	***		
	121	-	~	BrazilVox1			~	_	_	**	
	122			FimncoMVox3		-			-		
	123	_	-	BrazifVox2			-	_	_	_	
	124	_		BrazilVox3	_		-			-	-
	125	_	-	AlAahhh	-	_			***		-
	1.8	_	_	p33137v					_	***	
G9	127	_	-	p33168v	-	_		-	***	***	-

(CC32=122 only via MIDI) (CC32= 119 only via MIDI)

	ANTICESCI SEMI 12 BRUSH	GAZ ORCHSTRA	GM2 SFX	standard kit	standed kit2	room kit	rock kit	electro kit	analog kit	paz kit
7			-	***			-		***	
				-						
_			-	-						
			-	-		***		-		
— —							-			
					-	_		-		
<u> </u>		-	,		_					
š		_	-			***				
_										
10										
										-
						Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo	Mute Surdo
12				Mute Surdo Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo	Open Surdo
				High-Q	High-Q	High Q	High-Q	High-O	High-Q	High-Q
				Siap	Siap	Slap	Slap	Slap	Slap	Slap
				ScratchPush	ScratchPush	ScratchPush	ScratchPush	ScratchPush	ScratchPush	ScratchPush
18				ScratchPull	ScratchPull	ScratchPuil	ScratchPull	ScratchPull	ScratchPull	ScratthPull
_				FungerSnaps2	Finger5naps2	FingerSnaps2	Finger\$naps2	FingerSnaps2	FingerSnaps2 SquareClick	FingerSnaps2 SquareClick
20				SquareOick	SquareClick	SquareClick	SquareClick	SquareClick	Mtrnm.Click	Mtrnm Cick
				Mtrnm.Click	Mtrnm.Click	Mtrnm.Gick	Mtrnm Click	Mtrnm.Click Mtrnm. Bell	Mirram. Bell	Munm. Beli
37				Mtrnm Bell	Mitrom, Bell	Mtrom Rell	Mtmm. Bell MC-500 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep
				MC-500 Beep	MC-500 Beep	MC-S00 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep	MC-500 Beep
- M				MC-SOO Beep	MC-500 Beep	MC-500 Beep	Brush Swirt	Brosh Swirl	Brush Swirl	Brush Swirl
No				Brush Swirl	Brush Swirl	Brush Swirl	Brush Swirl	Brush Swirl	Brush Swirl	Brush Swirl
1988 -		-		Brush Swirl	Brush Swirl	Brush Swirl Brush Slap1	Brush Slap1	Brush Slap1	Brush Slap 1	Brush Slap1
	igh-Q	Jazz Clsd.HH		Brush Slap 1	Brush Slap 1	Brush Swiil	Brush Swirl	ReverseCymbi	ReverseCymbi	Brush Swid
Sla		Pedal HiHat		Brush Swirl	Brush Swirl Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Ruff
	cratchPush	Jazz Open HH		Snare Roll	Castanets	Castanets	Castanets	High-Q	High-Q	Castanets
	ratchPull	Ride Cymbal		Castanets Convert Ser	Concert Snr	Concert Sor	Room Snare 1	Standard 5N1	Power Snare1	Concert Snr
	ticks	Sticks		Concert Snr	Sticks	Sticks	Sticks	Sticks	Sticks	Sticks
	quareClick	SquareClick		Stocks	Jazz Kick 1	Jazz Kick 1	Room Kick 2	Std2 Kick2	Mix Kick	Jazz Kick 1
	trnm.Click	Mtrnm.Click		Jazz Kick 1 Jazz Snare 2	Jazz Kick 1	Jazz Kick 1	Jazz Snare 2	lazz Snare Z	Jazz Snare 2	Jazz Snare 2
	ttrnra. Bell	Mirnon, Bell		Mix Kick	Std2 Kick2	Mix Kick	Std2 Kick2	Elec Kick 2	808 BD	Mu Kick
	AZZ Kick 2	Concert 8D		Standard KK1	Std.2 Kick1	Room Kick 1	5td.2 Kick1	Power Kick 1	TR-808 Kick	Jazz Kick 2
Minds St. N	azz Kick 1	ConcertBD Mt Side Stick		Side Stick	Side Stick	Side Stick	Side Stick	Side Stick	808 Rimshot	Side Stick
	ide Stick	Concert Snr		Standard SN1	Std.2 Snare1	Standard SN1	LD Snare M	Dance Snare 1	808 Snare 1	Standard SN1
	rush Swirl	Castanets	High-Q	909 HandClap	909 HandClap	909 HandClap	909 HandClap	909 HandClap	808ciap	909 HandClap
_	rush Slap1 Irush Swirl	Concert Snr	Slap	LD Snare M	Std.2 Snare2	LD Snare M	Jazz Snare 2	Power Snare1	TR 808 SD2	LD Snare M
	teal Tom 6	Timpani	ScratchPush	Red Tom 6	Real Tom 6	Room Tom 5	Rock Tom 4	Synth Drum 2	808 Tom 2	Real Tom 6
	Jose HiHat2	Timpani	ScratchPull	Close HiHatZ	Close HiHat2	Close H:Ha12	Close HiHat2	Close HiHat2	TR-808 CHH	Close HiHat2
	teat Tom 6	Timpani	Sticks	Real Tom 6	Real Tom 6	Room Tom 5	Rock Tom 4	Synth Drum 2	808 Tom 2	Real Tom 4
	edal Hillat2	Timpani	SquareClick	Pedal HiHat2	Pedai HiHat2	Pedal HiHat2	Pedal HiHat2	Pedal HiHat2	808_chh	Pedal HiHatZ Real Tom 4
	leal Tom 4	Timpani	Mtrnm.Click	Real Tom 4	Real Tom 4	Room Tom 2	Rock Tom 4	Synth Drum 2	808 Tom 2	Open HiHat2
0	Open HiHat2	Timpani	Mtrom, Bell	Open HiHat2	Open HiHat2	Open HiHat2	Open HiHat2	Open HiHat2	TR-808 OHH	Real Tom 1
	Real Tom 4	Timpani	GLFretNoiz	Real Tom 4	Real Tom 4	Room Tom 2	Rock Tom 4	Synth Drum 2	808 Tom 2	Real Tom 1
	leal Tom 1	Timparsi	Gt.CutNoise	Real Yorn 1	Real Tom 1	Room Tom 2	Rock Torn 1	Synth Drum 2	808 Tom 2 808 Crash	Crash Cym. 1
	Crash Cym !	Timpani	Gt.CutNoise	Crash Cym. 1	Crash Cym.1	Crash Cym.1	Crash Cym. 1	Crash Cym.1	808 Tom 2	Real Tom 1
	teal Tom 1	Timpare	String Slap	Real Tom 1	Real Torn 3	Room Tom 2	Rock Tom 1	Synth Drum 2 Ride Cymbal	Ride Cymbal	Ricie Cymbal
91 R	Ride Cymbal	Timpani	Fl.KeyClick	Ride Cymbal	Ride Cymbal	Ride Cymbal	Ride Cymbal ChinaCymbal	ChinaCymbal	ChinaCymbal	ChinaCymbal
	ChinaCymbal	Timpani	Laughing	ChinaCymbal	ChinaCymbal Ride Bell	ChinaCymbal Ride Bell	Ride Bell	Ride Bell	Ride Bell	Ride Bell
A R	Ride Bell	Timpani	Screaming	Ride Bell		Tambourine	Tambourine	Tambourine	Tambourine	Tambourine
	Tambourine	Tambourine	Punch	Tambourine	Tambourine Splash Cym.	Splash Cym.	Splash Cym.	Spiash Cym	Splash Cym.	Splash Cym.
	Splash Cym.	Splash Cym.	Heart Beat	Splash Cym	Cowbell	Cowbell	Cowbell	Cowbell	808cowbe	Cowbell
	Cowbell	Cowbell	Footsteps	Cowbell Crash Cym.2	Crash Cym.2	Crash Cym.2	Crash Cym.2	Crash Cym.2	Crash Cym.2	Crash Cym.2
	Crash Cym.2	Con.Cymbal2	Footsteps	Vibraslap	Vibraslap	Vibrasiao	Vibraslap	Vibrasiap	Vibraslap	Vibraslap
CHAPTER TOT	Vibraslap	Vibraslap	Applause Creaking	Ride Cymbal	Ride Cymbal	Ride Cymbai	Ride Cymbal	Ride Cymbal	Ride Cymbal	Ride Cymbal
-	Ride Cymbal	Concert Cym. Bongo High	Door	Bongo High	Bongo High	Bongo High	Bongo High	Bongo High	Bongo High	Banga High
	Bongo High	Bongo Lo	Scratch	Bungo Lo	Bonga Lo	Banga Lo	Bongo La	Bongo Lo	Bungo Lo	Bongo La
	Banga La	Mute H.Conga	Wind Chimes	Mute H.Conga	Mute H.Conga	Mute H.Conga	Mute H.Conga	Mute H.Conga	808 Conga	Mule H.Conga
	Mute H.Conga Conna Hi Onn	Conga Hi Opn	Car-Engine	Conga Hi Opn	Conga Hi Opn	Conga Hi Opn	Conga Hi Opn	Conga Hi Opn	\$08 Conga	Conge Hi Opn
	Conga Hi Opn Conga Lo Opn	Conga to Opn	Car-Stop	Conga Lo Opn	Conga Lo Opn	Conga Lo Opn	Conga Lo Opn	Conga to Opn	808 Conga	Conga Lo Opn
	Longa Lo Opn High Timbale	High Timbale	Car-Pass	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale
	tow Timbale	Low Timbale	Car Crash	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale	Low Timbale
	Agogo	Agogo	Siren	Agogo	Agogo	Agago	Agogo	Agogo	Agogo	Agogo
	Agogo	Agogo	Train	Agoga	Agago	Agogo	Agogo	Agogo	Agogo	Agogo Cabasa
	Cabasa	Cabasa	Jetplane	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa	Cabasa	Maracas
	Maracas	Marecas	Helicopter	Maracas	Maracas	Maracas	Maracas	Maracas Showhistle	BOB marac ShrtWhistle	ShrtWhistle
	ShrtWhistle	ShrtWhistle	Starship	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle	ShrtWhistle LongWhistle	LongWhistle	LongWhistle
	LongWhistle	LongWhistle	Gun Shet	LongWhistle	Long\/histle	LangWhistle	LangWhistle	Short Guiro	Short Guire	Short Guiro
7: 3	Short Guiro	Short Guiro	Machine Guri	Short Guiro	Short Guiro	Short Guiro	Short Guiro Long Guiro	Long Guiro	Long Guiro	Long Guiro
-T-007/30124523	Long Guiro	Long Guiro	Lasergun	Long Guiro	Long Guiro	Long Guito Claves	Claves	Claves	BOSclave	Claves
	Claves	Claves	Explosion	Claves	Claves	Claves Woodblock	Woodblock	Woodblock	Woodblock	Woodblack
F-SECTION 1	Woodblock	Woodblock	Dog	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock	Woodblock
Second Control of the	Woodblock	Woodblack	HorseGallop	Woodblock	Woodblock Mute Cuica	Mute Cuica	Mute Cuira	ScratchPush	ScratchPush	Mute Cuica
	Mute Cuica	Mute Cuica	Bird	Mute Cuica	Open Cuka	Open Cuica	Open Cuita	ScratchPuil	ScratchPuil	Open Cuica
	Open Cuica	Open Cuica	Rein	Open Cuica MuteTriangl	MuteTriangl	MuteTriangl	MuteTriangl	MuteTriangl	MuseTriangl	MuteTriangl
	MuteTriangi	MuteTriangl	Thunder	OpenTriangl	OpenTriangl	OpenTriangl	OpenTriangl	OpenTriangl	OpenTriangl	OpenTriangl
	OpenTriangl	Open1riang)	Wind	Shaker	Shaker	Shaker	Shaker	Shaker	Shaker	Shaker
TOTAL PROPERTY.	Shaker Court Coll	Shaker timele Red	Seashore Stream	Jingle Bell	Jingle Bell	Jingle Bell	tingle Bell	Jingle Bell	tingle Rell	Jingle Bell
25.00 to 2	lingle Bell	Jingle Bell	Bubble	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Bell Tree	Beil Tree
200000000000000000000000000000000000000	Bell Tree	Bell Tree Castanets	BURNIE							
_	Castanets	Mute Surdo				-				
	Mute Surdo	Open Surdo								
	Open Surdo	Applause								
	-									
-		-						-		
92					_		144			
94								***		
94							***			

(CC32= 119 only via MIDI)

(CC32=122 only via MIDI)

	RINUSCHII	MARTIN	en karab	E MARIO MA	SPC: 1 (CC32: 3)	PC: 2 (CC32: 3)	PC: 3 (0C32: 3)	PC: 9 (CC32: 1)	PC: 10 (CC32: 3)	PC: 11 [CC32: 3]
	brush kit	ciassic kit	SFX 1 kit	SFX 2 kit	STANDARD 1	STANDARD 2	STANDARD 3	ROOM	Hip-Hop	Jungle
0			-		97 Standard 1 Kirk 1	(#2) Standard 1 Kick 1	[#2] Standard 1 Kick 1		feet agents they a	[#2] Electric Kick 2
7					#2 Standard 1 Kick 2 #2 Standard 2 Kick 1	(#2) Standard 1 Kick 2		11		[#2] Electric Kick 1 *
	_			***	[#2] Standard 2 Kick 2	[#2] Standard 2 Kick 1 [#2] Standard 2 Kick 2				CR-78 Kick 1
4					[#1] Kick Drum 1	[81] Kick Drum 1	[#2] Standard 2 Kick 2 [#1] Kick Drum 1			CR-78 Kick 2
5	-				[#1] Kick Drum 2	[#1] Kick Drum 2	[#1] Kick Drum 2	(#1) Kick Drum 1 (#1) Kick Drum 2	TR-606 Kick 1 TR-707 Kick 1	TR-606 Kick 1
9			_		(#2] Jazz Kick 1	[82] Jazz Kich 1	[02] Jazz Kick 1	[92] Jazz Kick 1	[#1] TR-808 Kick	TN-707 Kick 1 [#1] TR-808 Kick
7			-	141	(02) Jazz Kick 2	(02) Jazz Kick 2	[#2] Jazz Kick 2	(#2) Jazz Kick 2	[#2] TR-808 Kick	[#2] TR-808 Kick
			***	-	[62] Room Kick 1	#2 Room Kick 1	[82] Room Kick 1	[#2] Room Kick 1	TR-808 Kick 2	TR-808 Kick 2
9 100					[F2] Room Kick 2	[#2] Room Kick 2	[#2] Room Kick 2	[82] Room Kick 2	[#2] TR-509 Kick	(#2) TR 909 Kick
,,					[62] Fower Kick 1	[82] Power Kick 1	(#2) Power Kick 1	[82] Power Kick 1	[#2] Dance Kick	[82] Dance Kick
12					[#2] Power Kick 2	[82] Power Kick 2	[#2] Power Kick 2	[#2] Power Kick 2	Hip-Hop Kick 2	Hip-Hop Kick 2
	Mute Surdo	Mute Surdo			[#2] Electric Kick 2 [#2] Electric Kick 1 *	(#2) Electric Kick 2 (#2) Electric Kick 1	(#2) Electric Kick 2	(#2) Electric Kick 2	TR-909 Kick 1 *	TR-909 Kick 1 *
14	Open Surdo	Open Surdo			(#2) TR-808 Kick	(92) TR-808 Kick	[#2] Electric Kick 1 * [#2] TR-BOB Kick	[82] Electric Kick 1 *	Hip-Hop Kick 3	Hip-Hop Kick 3
	High-Q	High-Q			[#2] TR-909 Kick	(#2) TR-909 Kick	[92] TR-909 Kick	62 TR-808 Kick 62 TR-909 Kick	Jungle Kick 1	Jungle Kick 1
16	Slap	Slap			[#2] Dance Kick	[#2] Dance Kick	[92] Dance Kick	(#2) Dance Kick	Techno Kick 1 Bounce Kick	Techno Kick 1 Sounce Kick
17	ScratchPush	ScratchPush			Voice One	Voice One	Voice One	Voice One	Voice One	Voice One
	ScratchPull	ScratchPull			Vaice Two	Voice Two	Voice Two	Voice Two	Vaice Two	Voice Two
9	FingerSnaps2	Finger\$naps2		-	Voice Three	Voice Three	Vaice Three	Voice Three	Voice Three	Voice Three
,	SquareClick	SquareClick			-			_	**	-
22	Mirnen, Click Mirnen, Bell	Mtrnm. Gick Mtrnm. Bell								
3	MC-500 Beep	MC-500 Beep			MC-500 Beep !	MC-500 Beep 1	MC-500 Beep 1	MC-500 Seep 1	MC-500 Beep 1	MC-500 Beep 1
	MC-500 Beep				MC-500 Seep 2	MC-500 Beep 2	MC-500 Beep 2	MC-500 Beep 2	MC-S00 Beep 2	MC-500 Beep 2
	Brush Swirl	MC-500 Beep Brush Swirl			Concert SD Snare Roll	Concert SD	Concert SD	Concert SD	Concert SD	Concert SD
	7 - 1 - 1	Brush Swid			Snare Roll Finger Snap 2	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll
9	Brush Slap 1	Brush Slap1			High Q	Finger Snap High Q	Finger Snap 2	Finger Snap	Finger Snap 2	Finger Snap 2
	Brush Swirl	Brush Swirl			Slap	Slap	High Q Siao	High ()	High O	High Q
	Snare Roil	Snare Boli			Scratch Push [EXC7]	Scratch Push	Scratch Push	Stap Scratch Push	Slap	Slap
20	Castanets	Castanets	-		Scratch Pull (EXC7)	Scratch Pull	Scratch Pull	Scratch Pull	Scratch Push 2 [EXC7]	Scratch Aush 2 (EXC7)
	Brush Slap 1	Concert Snr	_		Sticks	Sticks	Sticks	Sticks	Sticks	
	Sticks	Sticks		-	Square Click	Square Click	Square Click	Square Click	Square Click	Sticks Square Click
		Jazz Kick 1			Metronome Click	Metronome Click	Metronome Click	Metronome Click	Metronome Click	Metronome Click
Paresson	Jazz Snare 2	jazz Snare 2			Metronome Beil	Metronome Bell	Metronome Bell	Metronome Bell	Metronome Bell	Metronome Bell
170	Mix Kick	Concert BD			Standard 1 Kick 2	Standard 2 Kick 2	Standard 3 Kick 2	Roam Kick 2	Hip-Hop Kick 2	Jungle Kick 2
	Jazz Kick ! Siele Stick	Concert BD m	Gt.CutNoise	Telephone 2	Standard 1 Kick 1	Standard 2 Kick 1	[RMO] Kick	Room Kick 1	Hip-Hop Kick 1	Jungle Kick 1
ar N	Brush Slap 1	Side Stick Standard SN1	Gt.CutNoise	Creaking	Side Stick	Side Stick	Side Stick	Side Stick	TR-808 Rim Shot	Side Stick
ESSTATE SE	909 HandClap	909 HandClap	Dist CutNoiz	Door	Standard 1 Snare 1	Standard 2 Snare 1	(RND) Snare	Room Snare 1	Rap Snare	Jungle Snare 1
Teasure	Brush Swirl	LD Snare M	String Slap Bass Slide	ScratchPush XG Scratch2	Hand Clap	TR-808 Hand Clap	(RHO) Hand Clap *	TR-806 Hand Clap	Hand Clap	Hand Clap 2
	Lite Torn 4	Real Tom 6	Pick Scrape	Wind Chimes	Standard 1 Snare 2	Standard 2 Snare 2	Standard 3 Snare 2	Room Snare 2	Hip-Hop Snare 2	Jungie Snare 2
	Close HiHat2	Close HiHat2	- AN ALEBE	Telephone 2	Closed Hi-Hat [EXC1]	Low Tom2	Low Tom2	Room Low Torn 2 *	TR-909 Low Tom 2 *	7R-909 Low Tom 2
	Lite 7cm 4	Real Tom 4	-	- reepixie 1	Low Tom 1 *	Closed Hi-Hat 2 [EXC1]	[RNO] Closed Hi-Hat (DIC Low Tom)		Closed Hi-Hat 3 (EXC)	
(E 181	Pedal HiHat2	Pedai HiHat2		_	Pedal Hi-Hat (EXC1)	Pedal Hi-Hat 2 [EXC1]		Room Low Tom 1 *	TR-909 Low Tom 1 *	TR-909 Low Tors 1
10000	Lite Tom 4	Real Tom 4		***	Mid Torn2 *	Mid Tom2	Mid Tom2	Room Pedal Hi Hat EXC Room Alid Tom 2 *		
16	Open HiHat2	Open HiHat2			Open Hi-Hat (EXC1)	Open Hi-Hat 2 EXC1	[RND] Open Hi-Hat (EXC		TR-909 Mid Tom 2 * Open Hi-Hat 3 (EXCS)	TR-909 Mid Tom 2
	Lite Tom 4	Real Tom 1	***		Mid Tom 1 *	Mid Tom 1	Mid Tom 1	Room Mid Tom 1 *	TR-909 Mid Tom 1 *	TR-606 Open Hi-Hat (EXC TR-909 Mid Tom 1
EAST IN	Lite Tom 4	Real Torn 1	_	-	High Tom 2 *	High Yorn 2	High Tom 2	Room High Torn 2 *	TR-909 High Tom 2 *	TR-909 High Tom 2
1	Crash Cym.1	Concert Cym.		_	Crash Cymbal1	Crash Cyreball	[RND] Crash Cymbal	Crash Cymbail	TR-909 Crash Cymbal	TR-808 Crash Cymbal
0.230.0	Lite Tom 4	Real Tom 1			High Torn 1 *	High Tom 1	High Tom 1	Room High Tom 1 *	TR-909 High Tom 1 *	TR-909 High Tom 1
aresenea.	Ride Cymbal	ConcertCymCl	_	-	Ride Cymbal 1	Ride Cymbal 1	[RND] Ride Cymbal 1 *	Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1
781	ChinaCymbal Ride Bell	ChinaCymbal	Fl. KeyClick	Car-Engine	Chinese Cymbal	Chinese Cymbal	Chinese Cymbal	Chinese Cymbal	Reverse Cymbal	Reverse Cymbal
212216-02	Tambouring	Ride Bell Tambourine		Car-Stop	Rice Bell	Ride Bell	(RNO) Ride Bell	Rade Bell	Ride Bell	Ride Bell
Marin Service	Splash Cyrn.	Splash Cym		Car-Pass Car-Crash	Tambourine	Tambourine	Tambourine	Tambourine	Shake Tambourine	Shake Tambourine
36	Cowbell	Cowbell		Siren	Splash Cymbal Cowbell	Splash Cymbai	Splash Cymbai	Splash Cymbal	Splash Cymbal	Splash Cymbal
	Crash Cym.2	Concert Cym.	_	Train	Crash Cymbal 2	Crash Cymbal 2	Cowbell	Cowbell	TR-808 Cowbell	TR-808 Cowbell
58	Vibraslep	Vibrastap		Intplane	Vibra-siap	Vibra-slap	Crash Cymbal 2 Vibra-siao	Crash Cymbal 2 Vibra-siap	Crash Cymbal 2	Crash Cymbal 2
(水学)	Ride Cymbal	ConcertCymC	-		Ride Cymbal 2	Ride Cymbal 2	4	Ride Cymbal 2	Vibra-slap	Vibra-slap
	Bango High	Bongo High		Burst Naise	High Bongo	High Bongo	High Bongo	High Bongs	Ride Cymbal 2	Ride Cymbal 2 High Bongo
91	Bongo Lo	Bongo Lo		Coaster	Low Bongo		Law Bango	Low Bongo	High Bongo Law Bongo	Low Bongo
	Mute H.Conga	Mute H.Conga		Submarine	Mute High Conga		Mute High Conga	Mute High Conga	Mute High Conga	Mute High Conga
1.3	Conga Hi Opn	Conga Hi Opn			Open High Conga		Open High Conga	Open High Conga	Open High Conga	Open High Congs
and the second	Conga Lo Opn	Conga Lo Opn					Open Low Conga	Open Low Conga	Open Low Conga	Open Low Conga
	High Timbale Low Timbale	High Timbale			High Timbale	High Timbale	High Timbale	High Timbale	High Timbale	High Timbale
	Agogo	Low Timbale Agogo					Low Timbale	Low Timbale	Low Timbale	Low Timbale
451	Agogo	Agogo	Rain	Lauphing	High Agago	High Agogo	High Agogo	High Agage	High Agago	High Agaga
	Cabasa	Cabasa	Thunder		Cahara	Low Agogo Cabasa	Colors	Low Agogo	Law Agoga	Low Agogo
70	Maracas	Maracas	Wind		Marke			Cabasa	Cabasa TR One Leave	Cabasa
	ShrtWhistle	ShrtWhistle	Stream		Short High Whistle (EXC2)			Maracas Chnet Wiek Mikielo	TR-806 Maracas	TR-808 Maracas
	LongWhistle	LongWhistle	Bubble		Long Low Whistle (EXC2)				Short High Whistle Long Low Whistle	Short High Whistle
22	Short Guiro	Short Guira	feed				***************************************		Short Guiro	Long Low Whistle Short Guiro
	Long Guiro	Long Guiro								CR-78 Guiro (EXC3)
Jan 19 per on	Claves	Claves							TR-808 Claves	TR-808 Claves
100 m	Woodblock	Woodblock	**			High Wood Block			High Wood Block	High Wood Block
の政権を表現	Woodblock	Woodblock				Low Wood Block	Low Wood Block		Law Wood Block	Low Wood Block
DAGGENTARY -	Mute Cuica	Mute Cuica					Mare Cuica		High Hao (EXC4)	High Hoo (EXC4)
HO.	Open Cuica MuteTriangl	Open Cuica MuteTriangl						Open Cuica	Low Hoo (EXE4)	Low Hoo (EXC4)
	OpenTriangi	OpenTriangl							Electric Mute Triangle	Electric Mute Triangle
6)	Shaker	Shaker							Electric Open Triangle	
	Jingle Bell	lingle Bell								IR-626 Shaker
1334		Bell Tree								Jingle Bell
35		-								Beil Tree
										Castanets
87	_	A								Mute Surdo
			Growl							Open Surdo Small Club 1 *
7-		-	Huanted		-				mail Cup 1 *	
				-		-				
70	_		Maou			-			-	
				_						-
70 92										
90		-					-			
90 92 34		-		-						
93				-					-	-

		brush kit	classic kit	5FX 1 ldt	5FX 2 let	PC 1 [CC32: 3] STANDARD 1	PC: 2 (CC32: 3) STANDARD 2	PG 3 [CE32: 3] STANDARD 3	PC: 9 (CC32: 3) ROOM	PC: 10 (CC32: 3) HipHop	PC: 11 (CC32: 3) Jungle
(C7) (9	161	()	()	()	(-)	()	()	()	()	()	(-)
-	1) 1	-		-	_	(#2) Standard 1 Snare 1					Techno Hit
90				-	-	(82) Standard 1 Snare 2		[#2] Standard 1 Snare 2			Philly Hit *
- H	1969			_		(#2) Standard 2 Snare 1		[#2] Standard 2 Snare 1			Shock Wave *
10	00		-	_		(#2) Standard 2 Snare 2	[F2] Standard 2 Snare 2	[#2] Standard 2 Snare 2	[#2] Standard 2 Snare 2	Lo-fi Rave *	Lo-Fi Rave *
11	01	-				(#1) Snare Drum 2	(#1) Snare Drum 2	[#1] Snare Drum 2	P1 Snare Drum 2	Bam Hit	Barn Hit
	192	-				Standard 1 Snare 1	Standard 1 Snare 1	Standard 1 Snare 1	Standard 1 Snare 1	Bim-Hit	Bim-Hit
11	03		-	_	-	Standard 1 Snare 2	Standard 1 Snare 2	Standard 1 Snare 2	Standard 1 Snare 2	Tape Rewind	Tape Rewind
-	133		-	_	_	Standard Snare 3	Standard Snare 3	Standard Snare 3	Standard Snare 3	Phonograph Noise	Phonograph Noise
10	05	-		_	-	67 Jazz Snare 1	IRZI Jazz Snare 1	1821 Jazz Snare 1	1021 Jazz Snare 1	[#2] Power Snare 1	#2] Power Snare 1
-	106		-	-		(02) Jazz Snare 2	(02) Jazz Snare 2	(42) Jazz Snare 2	1821 Jazz Snare 2	(#2) Dance Snare 1	(F2) Dance Snare 1
16	07	-	-	_		[#2] Room Snare 1	#2] Room Snare 1	(#2) Room Snare 1	(#2) Room Snare 1	[#2] Dance Snare 2	#2 Dance Snare 2
CB 1	OR.			-	-	(#2) Room Snare 2	[82] Room Snare 2	(#2) Room Snare 2	(82) Room Snare 2	[#2] Disco Snare	(#2) Disco Snare
	133	-		-	_	92 Power Snare 1	[82] Power Snare 1	(42) Power Snare 1	[#2] Power Snare 1	(82) Electric Snare 2	(#2) Electric Snare 2
1	10		~			[82] Power Snare 2	[#2] Power Snare 2	82] Power Snare 2	[#2] Power Snare 2	(#1) Electric Snare	[81] Electric Snare
- 1				_		[#1] Gated Snare	[#1] Gated Snare	(#1) Gated Snare	[#1] Gated Snare	[#2] Electric Snare 3 *	(#2) Electric Snare 3 *
- 11	12		_		-	[82] Dance Snare 1	(#2) Dance Snare 1	[#2] Dance Snare 1	(#2) Dance Snare 1	TR-606 Snare	TR-606 Snare
- ti	13					[82] Dance Snare 2	(42) Dance Snare 2	[#2] Dance Snare 2	(#2) Dance Snare 2	TR-707 Snare	TR-707 Snare
- 1.	1	**	-		-	1821 Disco Snare	(#2) Disco Snare	[82] Disco Snare	(#2) Disco Snare	[#2] TR-808 Snare 1	(#2) TR-808 Snare 1
Γ,	15				-	92 Electric Snare 2	[82] Electric Snare 2	(#2) Electric Snare 2	#2 Electric Snare 2	[#2] TR-808 Snare 2 *	[#2] TR-808 Snare 2 *
Ľ	100	_				[81] Electric Snare	(#1) Electric Snare	[#1] Electric Snare	(61) Electric Snare	TR-808 Snare 2	TR-808 Snare 2
lı.	17		~			In21 Electric Snare 3 *	le2 Electric Snare 3 *	(82) Electric Snare 3 *	(#2) Electric Snare 3 *	(#2) TR-909 Snare 1	[#2] TR-909 Snare 1
-		_	_	_	_	TR-707 Snare	TR-707 Snare	TR-707 Snare	TR-707 Snare	[#2] TR-909 Snare 2 *	[#2] TR-909 Snare 2 *
1	19	_	-	***		[82] TR-806 Snare 1	(#2) TR-808 Snare 1	(#2] TR-808 Snare 1	(#2) TR-808 Snare 1	TR-909 Snare 1	TR-909 Smare 1
0	20		_			(02) TR-808 Snare 2 *	[#2] TR-808 Snare 2 *	[82] TR-808 Snare 2 *	(#2) TR-806 Snare 2 *	TR-909 Snare 2	1R-909 Snare 2
-	20			-		(42) TR-909 Snare 1	(#2) TR-909 Soure 1	[82] TR-909 Snare 1	[62] TR-909 Snare 1	Rap Snare	Rap Snare
,	22					(62) TR-909 Snare 2 *	[62] TR-909 Snare 2 *	[#2] TR-909 Snare 2 *	[42] TR-909 Snare 2 *	Jungle Snare 1	Jungle Snare 1
ļ.	- 100					Rep Snare	Rap Snare	Rap Snare	Rap Snare	House Snare 1	House Snare 1
١,	24		_		_	Jungle Snare 1	Jungle Snare 1	Jungle Snare 1	Jungle Snare 1	[92] House Snare *	(#2) House Snare *
-	25			**	-	House Snare 1	House Snare 1	House Snare 1	House Snare 1	House Snare 2	House Snare 2
- ["	126				-	1821 House Snare *	(82) House Snare *	[82] House Snare *	[87] House Snare *	Voice Tah	Voice Tah
G9 1			_			House Snare 2	House Snare 2	House Snare 2	House Snare 2	(#2) Slappy *	(#7) Slappy *

		PC: 12 (CC32: 3)	PC: 17 [CC32: 3]	PC: 25 (CC32: 3)	PC: 26 (CC32: 3)	PC: 27 [CC32: 3]	PC: 28 (CC32: 3)	PC: 29 [CC32: 3]	PC: 30 (CC32: 3)	PC: 31 (CC32: 3)	PC: 33 (CC32: 3)
		TECHNO	POWER	ELECTRONIC	TR-808	DANCE	CR-78	TR-606	TR-707	TR-909	JAZZ
(C7)	(96)	[]	()	()	()	()	()	(⊷)	()	()	(-)
		Techno Hix	(#2) Standard 1 Snare 1	Techno Hit	Techno Hit	Techno Hit	Techno Hit	Techno Hit	Techno Hit	Techno Hit	
	98	Philly Hit *	(#2) Standard 1 Share 2	Philly Hit "	Philly Hit *	Philly Hit *	Philly Hit "	Philly Hit *	Philly Hit *	Philly His *	
	Gr	Shock Wave *	[#2] Standard 2 Snare 1	Shock Wave *	Shock Wave *	Shock Wave *	Shock Wave *	Shock Wave *	Shock Wave *	Shock Wave *	
	100	Lo-fi kave '	[#2] Standard 2 Snare 2	Lo-Fi Rave *	Lo-Fi Rave *	Lo-Fi Rave "	Lo-Fi Rave *	Lo-fi Rave *	Lo-fi Rave *	Lo-fi Rave *	(#Z) Srush Tap 1
	101	Bam Hit	[F1] Snare Drum 2	Barn Hit	Barn Hit	Bam Hit.	Bam Hit	Barn Hit	Bars Hit	Bam Hit	[#2] Brush 7ap 2
	107	Sim-Hit	Standard 1 Snare 1	Birm-Hit	Birn-Hit	Birm-Hit	Bim-Hit	Biss-Hist	Birn-Hit	Bim-Hit	[#2] Brush Slap 1
	103	Tape Rewind	Standard I Snare 2	Tape Rewind	Tape Rewind	Tape Rewind	Tape Revind	Tape Rewind	Tape Rewind	Tape Rewind	(#2) Brush Slap 2
	10.0	Phonograph Noise	Standard Snare 3	Phonograph Noise	Phonograph Noise	Phonograph Noise	Phonograph Noise	Phonograph Noise	Phonograph None	Phonograph Noise	(#2) Brush Slap 3
	105	[62] Power Snare 1	02 Jazz Snare 1	1821 Power Snare 1	(#2) Power Snare 1	[82] Power Snare 1	[82] Power Snare 1	[82] Power Snare 1	#21 Power Snare 1	(#Z) Power Snare 1	1821 Brush Swirl 1
	107	[82] Dance Snare 1	[#2] Jazz Snare 2	(#2) Dance Snare 1	(#2) Dance Snare 1	[#2] Dance Snare 1	[62] Dance Snare 1	(#2) Dance Snare 1	[82] Dance Snare 1	02 Dance Snare 1	[#2] Brush Swirl 2
	107	192) Dance Snare 2	(#2) Room Snace 1	[#2] Dance Snare 2	[#2] Dance Snare 2	(#2) Dance Snare 2	[#2] Dance Snare 2	(#2) Dance Snare 2	(#2) Dance Snare 2	#2] Dance Snare 2	(#2) Brush Long Swirl
~	108	#2 Disco Snare	(#2) Room Snare 2	[#2] Disco Snare	(#2) Disco Snare	[92] Disco Snare	[42] Disco Snare	[92] Disco Snare	(#2) Disco Snare	(#2) Disco Snare	(#2) Jazz Snare 1
٠.	128	(82) Electric Snare 2	(#2) Power Snare 1	[#2] Electric Snare 2	[82] Electric Snare 2	[62] Electric Snare 2	[#2] Electric Snare 2	(82) Jazz Snare 2			
	110	[81] Electric Snare	[#2] Power Snare 2	81) Electric Snare	[#1] Electric Snare	[#1] Electric Smare	(#1) Electric Snare	[61] Electric Snare	(41) Electric Smare	(81) Electric Snare	(#2) Standard 1 Snare1
		(IZ) Electric Snare 3 *	(#1) Gated Snare	(#2) Electric Snare 3 *	[#2] Electric Snare 3 *	[#2] Electric Snare 3 *	(42) Electric Snare 3 *	[42] Electric Snare 3 *	[42] Electric Snare 3 *	(#2) Electric Snare 3 *	[82] Standard 1 Snare2
	112	TR-606 Snare	#2! Dance Snare 1	TR-606 Snare	TR-606 Snare	TR-506 Snare	TR-606 Snare	TR-606 Scrare	TR-606 Snare	TR-606 Snare	[02] Standard 2 Snare1
	113	TB-707 Snare	(#2) Dance Snare 2	TR-707 Snare	111-707 Snare	TR-707 Snare	TR-707 Snare	TR-707 Snare	TR-707 Snare	TR-707 Snare	[82] Standard 2 Snare2
	113	(#2) TR-808 Snare 1	(#2) Disco Snare	(#2) TR-808 Snare 1	[42] TR-808 Soare 1	[#2] TR-808 Snare 1	[82] TR-808 Snare 1	[62] TR-808 Snare 1	(82) TR-808 Snare 1	[02] TR-808 Snare 1	[#1] Snare Orum 2
	115	[62] TR-808 Snare 2 *	[82] Electric Snare 2	(#2) TR-808 Snare 2 *	(#2) TR-808 Snare 2 *	[#2] TR-806 Snare 2 *	[52] TR-806 Snare 2 *	(62) TR-808 Snare 2 *	[02] TR-808 Snare 2 *	[#2] TR-808 Snare 2 *	Standard 1 Snare 1
	· · · · · · · · · · · · · · · · · · ·	TR-808 Snare 2	[81] Electric Snare	TR-808 Snare 2	TR-806 Snare 2	TR-808 Snare 2	TR-808 Snare Z	TR-808 Snare 2	TR-808 Snare 2	TR-808 Snare 2	Standard 1 Snare 2
	117	(e2) TR-909 Snare 1	[62] Electric Spare 3 *	(#21 TR-909 Snare 1	[#2] TR-909 Snare 1	1#25 TR-909 Snace 1	[42] TR-909 Snare 1	[#2] TR-909 Snare 1	(#2) TR-909 Snare 1	[#2] TR-909 Soure 1	Standard Snare 3
	11.6	[42] TR-909 Snare 2	1R-707 Snare		[#2] TR-909 Snare 2 *	(#2) TR-909 Snare 2 *	(#2) TR-909 Share 2 *	(#Z) TR-909 Snare Z *	(#2) TR-909 Snam 2 *	[82] TR-909 Snare 2 *	[42] Room Snare 1
	119	TR-909 Smare 1	(#2) TR-808 Snare 1	TR-909 Snare 1	TR-909 Snare 1	TR-909 Snare 1	TR-909 Snare I	TR-909 Snare 1	TR-909 Snare 1	TR-909 Snare 1	#2 Room Snare 2
CI.	120	TR-909 Snare 2	(#2) TR-808 Snare 2 *	TR-909 Snare 2	TR-909 Snare 2	TR-909 Snare 2	TR-909 Snare 2	TR-909 Snare 2	TR-909 Snare 2	TR-909 Soure 2	(#2) Power Snace 1
G		Rap Snare	(42) TR-909 Snare I	Rap Snare	Rap Snare	Rap Snare	Rap Snare	Rap Snare	Rap Snare	Rap Snare	(#2) Power Snare 2
	122	Jungle Snare 1	(62) TR-909 Snare 2 *	Jungle Snare 1	Jungle Snare 1	Jungle Snare 1	Jungle Snare 1	Jungle Snare 1	Jungle Snare 1	Jungle Snare 1	(42) Gated Snare
		House Snare 1	Rap Snare	House Snare 1	House Snare 1	House Snare 1	House Snare 1	House Snare 1	House Snare 1	House Snare 1	[82] Dance Snare 1
	124	[#2] House Snare *	Jungle Snure 1	[#2] House Snare *	(#2) House Snare *	(#2) House Snare *	(#2) House Snare *	[#2] House Snare *	82 House Snare *	[#2] House Snare *	[#Z] Dance Snare Z
	125	House Snare 2	House Snare 1	House Snare 2	House Snare 2	House Snare 2	House Snare 2	House Snare 2	House Snare 2	House Snare 2	(#2) Disco Snare
	125	Voice Tah	(82) House Snare *	Voice Tah	Voice Tah	Voice Tah	Voice Tah	Voice Tah	Voice Tah	Voice Tah	(#2) Electric Snare 2
		[82] Slappy *	House Snare 2	[82] Slappy *	[#2] Slappy *	[#2] Slappy *	[62] Slappy *	[#2] Stappy *	[#2] Slappy *	(#2) Slappy *	[02] Electric Snare 3 *
GP	127	141 mbh1		11	*:=====================================						

å		PC: 12 (CC32: 3) TECHNO	PC: 17 (CC32: 3) POWER	PC: 25 [CC32: 3] ELECTRONIC	PC: 26 (CC32: 3) TR-806	PC: 27 (CC37: 3) DANCE	PC: 28 (CC32: 3) CR-76	PC: 29 (CC32: 3) TR-606	PC: 30 (CC32: 3) TN-707	PC: 31 (CC32: 3) TR-909	PC: 33 (CC32: 3) JAZZ
C-1	0	[82] Electric Kick 2	(#2) Standard 1 Kick 1	[PZ] Electric Kick 2	[#2] Electric Kick 2	42 Electric Kick 2	[#2] Electric Kick 2	(#7) Standard 1 Kick 1			
		[#2] Electric Kick 1 *	[#2] Standard 1 Kick 2	[#2] Electric Kick 1 *	[#2] Electric Kick 1 *	[62] Electric Kick 1 *	[02] Electric Kick 1 *	[82] Electric Kick 1 *	[82] Electric Kick 1 *	[#2] Electric Kick 1 *	#2 Standard 1 Kick 2
	2	CR-78 Kick 1 CR-78 Kick 2	(#2) Standard 2 Kick 1 [#2] Standard 2 Kick 2	CR-78 Kick 1 CR-78 Kick 2	CR-78 Kick 1 CR-78 Kick 2	CR-78 Kick 1 CR-78 Kick 2	CR-78 Kick 1 CR-78 Kick 2	CR-78 Kick 1	CR-78 Kick 1	CR-78 Kick 1	#2 Standard 2 Kick 1
	4	TR-606 Kick 1	[#1] Kick Drum 1	TR-606 Kick 1	TR-506 Kick 1	TR-606 Kick 1	TR-606 Kick 1	CR-78 Kick 2 TR-606 Kick 1	CR-78 Kick 2 TR-606 Kick 1	CR-78 Kick 7 TR-606 Kick 1	[#2] Standard 2 Kick 2 [#1] Kick Drum 1
	5	TR-707 Kick 1	(#1) Kick Drum 2	TR-707 Kick 1	TR-707 Kick 1	TR-767 Kick 1	TR-707 Kick 1	TR-707 Kick 1	TR-707 Kick 1	TR-707 Kick 1	[#1] Kick Drum 2
	,	[81] TR-808 Kick [82] TR-808 Kick	(62) Jazz Kick 1	[#1] TR-808 Kick [#2] TR-808 Kick	[#1] TR-808 Kick [#2] TR-808 Kick	[#1] TR-806 Kick	[#1] TR-808 Kick	[#1] TR-808 Kick	[81] TR-808 Kick	(#1) TR-808 Kick	(#2) Jazz Kick 1
	, B	TR-808 Kick 2	(#2) Room Kick 1	TR-808 Kick 2	TR-808 Kick 2	TR-808 Kick Z	[02] TR-808 Kick TR-808 Kick 2	(02) TR-808 Kick TR-808 Kick 2	[42] TR-808 Kick TR-808 Kick 2	[82] TR-808 Kick TR-808 Kick 2	[82] Jazz Kick 2 [82] Room Kick 1
	9	[82] TR-909 Kick	[#2] Room Kick 2	(#2) TR-909 Kick	(02) TR-909 Kick	[82] TR-909 Kick	[82] TR 909 Kick	[#2] TR 909 Kick	(#2) TR-909 Kick	(02) TR-909 Kick	[#2] Room Kick 2
	11		[82] Power Kick 1 [82] Power Kick 2	[02] Dance Kick	[82] Dance Kick	[#2] Dance Kick	[#2] Dance Kick	[#2] Dance Kick	(#2) Dance Kick	(#2) Dance Kick	[82] Power Kick 1
a	12	TR-909 Kick 1 *	[82] Electric Kick 2	Hip-Hop Kick 2 TR-909 Kick 1 *	Hip-Hop Kick 2 TR-909 Kick 1 *	Nip-Hop Kick 2 TR-909 Kick 1 *	Hip-Hop Kick 7 TR-909 Kick 1	Hrp-Hop Kick 2 TR-909 Kick 1 *	Hip-Hop Kick 2 TR-909 Kick 1 *	Hip-Hop Kick 2 TR-909 Kick 1 *	[#2] Power Kick 2 [#2] Electric Kick 2
	- It	Hip-Hop Kick 3	[#2] Electric Kick 1 *	Hip-Hop Kick 3	Hip-Hop Kick 3	Hip-Hop Kick 3	[#2] Electric Kick 1				
	14	Jungle Kick 1 Techno Kick 1	[02] TR-808 Kick [02] TR-908 Kick	Jungle Kick 1 Techno Kick 1	Jungle Kick 1 Techno Kick 1	lungle Kick 1 Techno Kick 1	Jungie Kick 1 Techno Kick 1	Jungle Kick 1 Techno Kick 1	lungle Kirk (Jungle Kick 1	[#2] TR-BOS Kick
	16	Bounce Kirk	(#2) Dance Kick	Bounce Kick	Bounce Kick	Bourse Kick	Bounce Kick	Bounce Kick	Techno Kick 1 Bounce Kick	Fechno Kick 1 Bounce Kick	[#2] TR-909 Kick [#2] Dance Kick
	17	Voice One	Voice One	Voice One	Voice One						
	19	Vaice Two Vaice Three	Voice Two Voice Three	Voice Two	Voice Two Voice Three	Voice Two Voice Three	Voice Two	Voice Two	Vaice Two	Voice Two	Voice Two
	- 33		-	-		-	VOCE HEED	Voice Three	Voice Three	Voice Three	Voice Three
	21				-			-			-
	23	MC-500 Beep 1 MC-500 Beep 2	MC-500 Reep 1	MC-500 Beep 1	MC-500 Beep 1						
CI	24	Concert SD	Concert 50	Concert SD	MC-500 Beep 2 Concert SD	MC-500 Beep 2 Concert SD	MC-500 Beep 2 Concert SD				
	FFI CONTROL	Snare Roll	Snare Roll	Snare Roti	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll	Snare Roll
		Finger Snap 2 High Q	Finger Snap 2 High Q	Finger Snap High Q	Finger Snap 2 High Q	Finger Snap High Q	Finger Snap 2 High Q	Finger Snap 2 High Q	Finger Snap 2	Finger Snap 2	Finger Snap
	20	Siap	Slap	Slap	Slap	Slap	Slap	Stap	High Q Slap	High Q Slap	High Q Slap
	29	Stratch Push 2 (EXC7)	Scratch Push (EXC7)	Scratch Push 2 (EXC7)	Scratch Push 2 [EXC7]	Scratch Push 2 [EXC7]	Scratch Push 2 (EXC7)	Scratch Push 2 [EXC7]	Scratch Push 2 (EXC7)	Scratch Push 2 (EXC7)	Scratch Push
	T.	Scratch Pull 2 (EXC7) Sticks	Scratch Pull (EXC7) Slicks	Scratch Pull 2 (EXC7) Sticks	Scratch Pull 2 [EXC7] Sticks	Scratch Pull 2 [EXC7] Sticks	Scratch Pull 2 (EXC7) Sticks	Scratch Pull 2 [EXC7] Sticks	Scratch Pull 2 (EXC7) Sticks	Scratth Pull 2 (EXC7) Sticks	Scratch Pull
	12 8001	Square Click	Square Click	Sticks Square Click	Sticks Square Click						
		Metronome Cirk Metronome Bell	Metronome Click	Metronome Cick	Metronome Click	Metronome Click					
	35 2000	Techno Kick 2	Metronome Bell Power Kick 2	Metronome Beil Electric Kick 2	Metronome Bell TR-808 Kick 2	Metronome Bell TR-909 Kirk 1	Metronome Bell CR-78 Kick 2	Metronome Bell CR-78 Kick 2	Metronome Bell TR-707 Kick 2	Metronome Bell Techno Kick 2	Metronome Bell
a	36	Techno Kick 1	Power Kirk 1	Electric Kick 1	TR-808 Kick 1	Electric Kick 2	CR-78 Kick 1	TR-606 Kick 1	TR-707 Kick 1	TR-909 Kick 1	Jazz Kick 2 Jazz Kick 1
	SEE Consequence	TR-808 Rim Shot Techno Snare 1	Side Stick Power Snare 1	Side Stick	TR-808 Rim Shot	Side Stick	CR-78 Rien Shot	CR-78 Rim Shot	TR-767 Rim Shot	TR-909 Rim	Side Stick
	35	TR-707 Hand Clap	FR-888 Hand Clap	Electric Snare 1 TR-808 Hand Clap	TR-808 Snare I TR-808 Hand Clap	House Snare 1 Hand Clap	CR-78 Snare 1 TR-707 Hand Clap	TR-606 Snare 1 TR-707 Hand Clap	TR-707 Snare 1 TR 707 Hand Clap	TR-909 Share 1	Jazz Snare 1 Hand Clap 2
	40	Techno Snare 2	Power Snare 2	Electric Snare 2	TR-808 Snare 2	Dance Snare 2	CR-78 Snare 2	TR-606 Snare 2	TR-707 Snare 2	Hand Clap TR-909 SnareZ	Jazz Snare 2
	41	TR-808 Low Tom 2 *	Power Low Tom 2 *	Electric Low Tam 2 *	TR-808 Low Tom 2 *	Flectric Low Tom 2 *	CR-78 Low Tom 2 *	IR-606 Low Tam 2	TR-707 Low Tom 2 *	TR-909 Low Tom 2	Low Tom2
		TR-707 Closed Hi-Hat (EXC TR-80R Low Tom 1 *	Power Low Tom 1 *	Closed Hi-Hat 2 [EXC1] Electric Low Tom 1 4	TR-806 Low Tom 1 *	Electric Low Tom 1 *	CR-78 Closed Hi-Hat(EXC CR-78 Low Tom 1 4	I]TR-606 ClosedHiHat(EXC TR-606 Low Torn 1	TR-707 ClosedH#Hat(EXC TR-707 Low York 1 *	1] TR 707 ClosedHiHat(EXC TR-909 Low Tom 1	tj Closed Hi-Hat 2 (EXC1) Low Tom1
		CR-78 Closed Hi-Hat [EXC	1} Pedal Hi-Hat		TR-866 Closed Hi-Hat2]EXC			1 TR-606 ClosedHiHadEXC		1) TR-707 ClosedHiHat(E)C	1) Pedal Hi-Hat 2 [EXC1]
	45 8 16	TR-909 Open Hi-Hat (EXC	Power Mid Tom 2 *	Electric Mid Tom 2	TR-B08 Mid Tom 2 *	Electric Mid Tom 2 *	CR-78 Mid Tom 2 *	TR-606 Mid Tora 2	TR-707 Mid Tom 2 *	TR-909 Mid Tom 2	Mid Yom2
	42	TR-606 Misi Tom 1 *	Power Mid Tom 1 *	Open Hi-Hat 2 (EXC1) Electric Mid Tom 1	TR 808 Mid Tom 1	Electric Mid Tom 1	CR-78 Mid Tom 1 *	TR 606 OpenHiHat EXCI TR-606 Mid Tom 1	TR-707 OpenHattEXCI	TR-909 OpenHiHat[EXC TR-909 Mid Tom 1	I Open Hi-Hat 2 (EXC1) Mid Tom I
ß		TR-805 High Tom 2 *	Power High Tom 2 *		TR-808 High Tom 2 *	Flextric High Tom 2 *	CR-78 High Tom 2 *	TR-606 High Tom 2	TR-707 High Tom 2 *	TR-909 High Tora 2	
	2524 5003	TR-909 Crash Cymbal						m-out night fam 2	neror might tom 2	ra-sus mign rota 2	High Tom 2
	大学的		Crash Cymball	Crash Cymbal 1	TR-BOB Crash Cymbal	TR-808 Crash Cymbal	TR-808 Crash Cymbal	TR-808 Crask Cymbai	TR-909 Crash Cymbal	TR-909 Crash Cymbal	Crash Cymbal1
	50	TR-808 High Tom 1 * Ride Cymbal 1	Crash Cymbal 1 Power High Tom 1 * Ride Cymbal 1	<u>-</u>	TR-808 High Tom 1 *			TR-808 Crask Cymbal TR-606 High Tom 1	TR-909 Crash Cymbai TR-707 High Tom 1	TR-909 Crash Cymbal TR-909 High Tom 1	Crash Cymbal 1 High Tom 1
	50 51	TR 808 High Tom 1 * Ride Cymbal 1 Reverse Cymbal	Power High Torn 1 * Ride Cymbal 1 Chinese Cymbal	Electric High Tom 1 * Ride Cymbal 1 Reverse Cymbal	TR-808 High Tom 1 * TR-606 Ride Cymbal Chinese Cymbal	TR-808 Crash Cymbal Electric High Torn 1 * TR-606 Ride Cymbal Reverse Cymbal	TR-808 Crash Cymbal CR-78 High Yorn 1 * TR-606 Ride Cymbal Chinese Cymbal	TR-606 Fligh Tom 1 TR-606 Fligh Tom 1 TR-606 Ride Cymbal Chinese Cymbal	TR-909 Crash Cymbai TR-707 High Tom 1 * TR-909 Ride Cymbai Chinese Cymbai	TR-909 Crash Cymbal TR-909 High Tom 1 TR-909 Ride Cymbal Chinese Cymbal	Crash Cymbal1
	50 53 53	TR-808 High Tom 1 * Ride Cymbal 1 Reverse Cymbal Ride Bell	Power High Tom 1 * Ride Cymbal 1 Chinese Cymbal Ride Bell	Electric High Tom 1 * Ride Cymbal 1 Reverse Cymbal Ride Bell	TR-808 High Tom 1 * TR-606 Ride Cymbal Chinese Cymbal Ride Bell	TR-B08 Crash Cymbal Electric High Torn 1 * TR-606 Ride Cymbal Reverse Cymbal Ride Bell	TR-808 Crash Cymbal CR-78 High Torn 1 * TR-606 Ride Cymbal Chinese Cymbal Ride Bell	TR-808 Crash Cymbal TR-606 High Tom 1 TR-606 Ride Cymbal Chinese Cymbal Ride Bell	TR-909 Crash Cymbal TR-707 High Tom 1 * TR-909 Ride Cymbal Chinese Cymbal Ride Bell	TR-909 Crash Cymbal TR-909 High Tom 1 TR-909 Ride Cymbal Chinese Cymbal Ride Bell	Crash Cymbal 1 High Tom T Ride Cymbal Inner Chinese Cymbal Ride Bell
	50 52 63 83 85	TR 808 High Tom 1 * Ride Cymbal 1 Reverse Cymbal	Power High Torn 1 * Ride Cymbal 1 Chinese Cymbal	Electric High Tom 1 * Ride Cymbal 1 Reverse Cymbal Ride Bell Tambourine	TR-808 High Tom 1 * TR-606 Ride Cymbal Chinese Cymbal	TR-808 Crash Cymbal Electric High Torn 1 * TR-606 Ride Cymbal Reverse Cymbal	TR-808 Crash Cymbal CR-78 High Yorn 1 * TR-606 Ride Cymbal Chinese Cymbal	TR-606 Fligh Tom 1 TR-606 Fligh Tom 1 TR-606 Ride Cymbal Chinese Cymbal	TR-909 Crash Cymbai TR-707 High Tom 1 * TR-909 Ride Cymbai Chinese Cymbai	TR-909 Crash Cymbal TR-909 High Tom 1 TR-909 Ride Cymbal Chinese Cymbal Ride Bell Tambourine 2	Crash Cymbal 1 High Tom 1 Ride Cymbal Inner Chinese Cymbal Ride Bell Tambourine
		TR-808 High Tom 1 * Ride Cymbal 1 Reverse Cymbal Ride Bell Shake Tambourine Splash Cymbal TR-808 Cowbell	Power High Tom 1 * Ride Cymbal 1 Chinese Cymbal Ride Bell Tambourine Splash Cymbal Cowbell	Electric High Tom 1 * Ride Cymbal 1 Reverse Cymbal Ride Bell Tambourine Splash Cymbal Cowbell	TR-808 High Tom 1 * TR-606 Ride Cymbal Chinese Cymbal Ride Bell CR-78 Tambourine Splash Cymbal TR-808 Cowbell	TR-BOB Crash Cymbal Electric High Tom 1 * TR-BOB Ride Cymbal Reverse Cymbal Ride Bell Shake Tambourine Splash Cymbal TR-BOB Cowbell	TR-808 Crash Cymbal CR-78 High Yom 1 * TR-606 Ride Cymbal Chinese Cymbal Ride Bell CR-78 Tambounne Spiash Cymbal CR-78 Cowbell	TR-808 Crash Cymbal TR-606 High Tom 1 TR-606 Ride Cymbal Chirese Cymbal Ride Bell CR-78 Tambourine Splath Cymbal CR-78 Cowbell	TR-909 Crash Cymbal TR-707 High Tom 1 * TR-909 R-de Cymbal Chinese Cymbal Ride Bell Tambourine 2 Splash Cymbal TR-808 Cowbell	TR-909 Crash Cymbal TR-909 High Tom 1 TR-909 Ride Cymbal Chinese Cymbal Ride Bell	Crash Cymbal 1 High Tom T Ride Cymbal Inner Chinese Cymbal Ride Bell
	B 34 34 35 55 57	TR-808 High Tom 1 * Ride Cymbal 1 Reverse Cymbal Ride Bell Shake Tambourine Splash Cymbal	Power High Tom 1 * Ride Cymbal 1 Chinese Cymbal Ride Bell Tambourine Splash Cymbal Cowbell Crath Cymbal 2	Electric High Tom 1 * Ride Cymbal 1 Reverse Cymbal Ride Bell Tambourine Splash Cymbal Cowbell Crash Cymbal 2	TR-808 High Tom 1 * TR-606 Ride Cymbal Chinese Cymbal Ride Betl CR-78 Tambourine Splash Cymbal TR-808 Cowbell TR-909 Crash Cymbal	TR-BOR Crash Cymbal Blectric High Tom 1 * TR-BOR Ride Cymbal Reverse Cymbal Ride Bell Shake Tambourine Splash Cymbal TR-BOR Cowbell Crash Cymbal 2	TR-808 Crash Cymbal CR-78 High Yom 1 * TR-608 Ride Cymbal Chinese Cymbal Ride Bell CR-78 Tambourine Spiash Cymbal CR-78 Cowbell TR-909 Crash Cymbal	TR-808 Crash Cymbal TR-606 High Tom 1 TR-606 Ride Cymbal Chinese Cymbal Ride Bell CR-78 Tambourine Spiach Cymbal CR-78 Cowbell TR-909 Crash Cymbal	TR-909 Crash Cymbai TR-707 High Tom 1 * TR-909 Ride Cymbai Chinese Cymbai Ride Bell Tambourine 2 Splash Cymbai TR-808 Cowbell Crash Cymbai 2	TR-909 Crash Cymbal TR-909 High Tom 1 TR-909 High Tom 1 TR-909 Hide Cymbal Chinese Cymbal Ride Bell Tambourne 2 Splash Cymbal TR-808 Cowbell Crash Cymbal 2	Crash Cymbail High Tom 1 Ride Cymbai Inner Chinese Cymbai Ride Bell Tambourine Splank Cymbai Condell Crash Cymbai Crash Cymbai
		TR-808 High Tom 1 * Ride Cymbal 1 Reverse Cymbal Ride Bell Shake Tantbourine Splash Cymbal TR-808 Cowbell TR-909 Crash Cymbal	Power High Tom 1 * Ride Cymbal 1 Chinese Cymbal Ride Bell Tambourine Splash Cymbal Cowbell	Electric High Tom 1 * Ride Cymbal 1 Reverse Cymbal Ride Bell Tambourine Splash Cymbal Cowbell	TR-808 High Tom 1 * TR-606 Ride Cymbal Chinese Cymbal Ride Bell CR-78 Tambourine Splash Cymbal TR-808 Cowbell	TR-BOB Crash Cymbal Electric High Tom 1 * TR-BOB Ride Cymbal Reverse Cymbal Ride Bell Shake Tambourine Splash Cymbal TR-BOB Cowbell	TR-808 Crash Cymbal CR-78 High Yom 1 * TR-606 Ride Cymbal Chinese Cymbal Ride Bell CR-78 Tambounne Spiash Cymbal CR-78 Cowbell	TR-808 Crash Cymbal TR-606 High Tom 1 TR-606 Ride Cymbal Chirese Cymbal Ride Bell CR-78 Tambourine Splath Cymbal CR-78 Cowbell	TR-909 Crash Cymbal TR-107 High Tom 1 * TR-909 Ride Cymbal TR-909 Ride Cymbal Ride Bell Tambourine 2 Splash Cymbal Tambourine 2 Splash Cymbal Crash Cymbal Crash Cymbal 2 Vibra-slap	TR-909 Crash Cymbal TR-909 Ride Cymbal TR-909 Ride Cymbal Chiese Cymbal Ride Bell Tambourne Z Splash Cymbal TR-808 Cowbell Crash Cymbal Z Vibra-slap	Crash Cymbal I High Tom 1 Ride Cymbal Inner Chinese Cymbal Ride Bell Tambourine Splank Cymbal Cowbell Crash Cymbal 2 Vibra-slap
а	94 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	TR-808 High Tom 1 * Ride Cymbal 1 Reverse Cymbal Ride Bell Shake Taxtbourine Splash Cymbal TR-808 Cowbell TR-808 Cowbell TR-908 Crash Cymbal Vibra-slap Ride Cymbal 2 CR-78 High Bongo	Power High Tom 1 * Rice Cymbal 1 Chinese Cymbal R Riche Beil Tambourine Splash Cymbal Cowbell Cash Cymbal 2 Vitra-slap Ride Cymbal 2 High Bongo	Electric High Tom 1 * Ride Cymbal 1 Reverse Cymbal Ride Bell Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vitra-slap Ride Cymbal 2 High Bongo	TR-808 High Tom 1 * TR-608 Ride Cymbal Chinese Cymbal Chinese Cymbal Ride Bell CR-78 Tambourine Splash Cymbal TR-808 Cowbell TR-909 Crash Cymbal Vibra-slap Ride Cymbal Erige CR-78 High Bongo	TR-808 Crash Cymbal Bectric High Tom 1 ° TR-608 Ride Cymbal Reverse Cymbal Ride Bell Shake Tambourne Splash Cymbal TR-808 Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo	TR-908 Crash Cymbal CR-78 High Yom 1 * TR-508 Ride Cymbal Chinese Cymbal Ride Bell CR-78 Tambourine Spisch Cymbal CR-78 Cowbell TR-909 Crash Cymbal Vibra-slap Ride Cymbal Edge CR-78 High Bongo CR-78 High Bongo	TR-808 Crash Cymbal TR-606 Ride Cymbal TR-606 Ride Cymbal Chriese Cymbal CR-78 Tambourine Splash Cymbal CR-78 Tambourine Splash Cymbal CR-78 Cowbell TR-999 Crash Cymbal Vibra-1ap Ride Cymbal Edge CR-78 High Bongo	TR-909 Crash Cymbal TR-107 High Ton 1 * TR-909 Ride Cymbal Chinese Cymbal Ride Bell Tambourine 2 Splash Cymbal TR-808 Cowbell Crash Cymbal TR-808 Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal Edge High Bongo	TR-909 Crash Cymbal TR-909 Ride Cymbal TR-909 Ride Cymbal Chinese Cymbal Ride Bell Tambourine 2 Splash Cymbal TR-808 Cowbell Crash Cymbal TR-808 Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal Edge High Bongo	Crash Cymbail High Tom 1 Ride Cymbail Inner Chinese Cymbai Ride Bell Tambourine Splank Cymbai Condell Crash Cymbai Crash Cymbai
a		TR-808 High Tom 1 * Ride Cymbal 1 Reverse Cymbal Reverse Cymbal Ride Bell Shake Tantbourine Splash Cymbal TR-808 Cowbell TR-905 Crash Cymbal Vibra-Jag Ride Cymbal 2	Power High Tom 1 * Ricle Cymbal 1 Chinese Cymbal Rede Bell Tembourine Splash Cymbal Cowbell Crath Cymbal 2 Witra-blap Ride Cymbal 2	Electric High Tom 1 ° Ride Cymbal 1 Reverne Cymbal Ride Bell Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo	YR-808 High Tom 1 * TR-606 Ride Cymbal Chinese Cymbal Ride Bell GR-78 Tambourine Splanh Cymbal TR-808 Cowbell TR-909 Cush Cymbal Vibra-Ilap Ride Cymbal Edge CR-78 High Bongo CR-78 Low Bongo	IR-808 Crash Cyenbal Electric High Trom 1 ° IR-608 Ride Cymbal Reverie Cymbal Ride Bell Shake Tambourne Splash Cymbal TR-808 Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo	TR-808 Crash Cymbal CR 78 High Tom 1 * TR-608 Ride (ymbal Chinese Cymbal Ride Bell CR-78 Tambourine Spiash Cymbal CR-78 Cowbell TR-909 Crash Cymbal Vibra-slap Ride Cymbal Edge CR-78 Tigh Bongo CR-78 Low Bongo CR-78 Low Bongo	TR-868 Grash Cymbal TR-666 High Tom 1 TR-666 High Tom 1 TR-666 High Cymbal Chinese Cymbal Ride Bell Gr.78 Tambourine Splash Cymbal Gr.78 Tambourine Splash Cymbal Gr.78 Cowbell Wibra-4lap Ride Cymbal Edge GR-78 High Bongo GR-78 How Bongo	TR-909 Crash Cymbal TR-707 High Ton 1 * TR-707 High Ton 1 * TR-909 Ride Cymbal Chinese Cymbal Ride Bell Tambourine 2 Splash Cymbal TR-808 Cowbell Crash Cymbal 2 Vibra-4isp Ride Cymbal Edge High Bongo Low Bongo	TR-909 Crash Cymbal TR-909 Righ Tom 1 TR-909 Rick Cymbal Chinese Cymbal Rick Bell Tambourne 2 Splash Cymbal TR-908 Cowbell Crash Cymbal Rick Cymbal Rick Cymbal Rick Cymbal Rick Cymbal Cymbal Rick Cymbal Cymbal Cowbell Crash Cymbal Cymbal Cowbell Crash Cymbal Cy	Crash (ymball High Tom 1 Ride Cymbal Inner Chinese Cymbal Ride Bell Tambourine Splank Cymbal Crash (ymbal Crash (ymbal Crash (ymbal Cymbal Cymbal Lythra-slap Ride Cymbal Edge High Bongo Low Bongo
Œ	51 51 51 51 51 51 51 51 51	TR-ABB High, Tom 1 * Rode Cymbal I * Rode Cymbal I * Rode Sell Shark Cymbal Rode Sell Shark Cymbal Rode Sell Shark Cymbal I * Rode Cowbell I * 959 Crash Cymbal V Vbra-siles Rode Cymbal Z * CR-78 High Bongo CA-78 Low Bongo TR-80 W Rode Figh Conga TR-80 M Rode Figh Conga TR-80 M Rote High Conga TR-80 M Rote High Conga TR-800 M Rote Figh Conga TR-	Power High Tom 1 * Rick Cymbal 1 Rick Cymbal 1 Rick Cymbal Rick Splack Cymbal Rick Seli Tambourine Splack Cymbal Cowbell Cash Cymbal 2 Vibra-Slap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga	Electric High Tom 1 ° Ride Cymbal 1 Reverse Cymbal Ride Bell Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vitra-slap Ride Cymbal 2 High Bongo Low Bongo Mutt High Conga	TR-808 High Tom 1 * TR-608 Ride Cymbal Chinese Cymbal Chinese Cymbal Ride Bell CR-78 Tambourine Splash Cymbal TR-808 Cowbell TR-909 Crash Cymbal Vibra-slap Ride Cymbal Erige CR-78 High Bongo	IN-808 Crash Cymbal Electric Righ Tom 1 ' H 608 Ride Cymbal Reverse Cymbal Ride Bell Ride Bell Ride Bell Ride Bell Ride Rell Ride Cymbal Ride Cymbal Low Brogo Mute High Coopa	TR-808 Crash Cymbal CR-78 High Tom 1 - H-608 Kite Cymbal Chinere Cymbal Ride Beil Ride Ride Ride Ride Ride Cymbal Ride Cymbal Ride Cymbal Ride Cymbal Edge CR-78 High Bongo RR-808 Mitte High Cong	TR-808 Crash Cymbal TR-606 Ride Cymbal TR-606 Ride Cymbal Chriese Cymbal CR-78 Tambourine Splash Cymbal CR-78 Tambourine Splash Cymbal CR-78 Cowbell TR-999 Crash Cymbal Vibra-1ap Ride Cymbal Edge CR-78 High Bongo	TR-909 Crash Cymbail TR-707 High Tom 1 TR-707 High Tom 1 TR-909 Rick Cymbail Chinese Cymbail Rick Sell Tambourine 2 Splath Cymbail TR-808 Covrbeil Crash Cymbail Vibra-High Rick Cymbail Edge High Bongo Motre High Canga	TR-996 Crash Cymbal TR-999 Righ Tom 1 R-999 Rick Cymbal Chinese Cymbal Rick Bell Tambourne 2 Splash Cymbal TR-898 Cowbed Crash Cymbal TR-898 Cowbed Crash Cymbal 2 Kidz Stala Ride Cymbal Edge High Bongo Mote High Conga	Crash Cymbal I High Tom I Ride Cymbal Inner Chinese Cymbal Ride IBE Tambourine Splant (Cymbal Cowhell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 Vibra-slap Ride Cymbal Edge High Bongo Low Bongo Low Bongo Morte High Conga
Ø	52 63 55, 55, 57 60 60 60 60 60 60 60 60	TR A08 High Ton 1 * Ride Cymbal 1 Ride Synnbal 1 Ride Self Shake Tanbourine Splate Cymbal Ride Bell TR 498 Camb Cymbal TR 498 Camb Cymbal TR 498 Camb Cymbal Votra-Hap Ride Cymbal 2 CA 7 H Low Bongo CA 7 H Low Bongo TR 488 Open High Conga TR 488 Open Hi	Power High Tom 1 * Ride Cymbal 1 Chinese Cymbal Ride Beil Tambourne Splash Cymbal Cowhell Cash Cymbal 2 Vere-slap Ride Cymbal 2 Vere-slap Ride Cymbal 2 Link Bongo Link Bongo Matte High Conga Open High Conga Open Low Conga	Electric High Tom 1 * Ride Cymbal 1 Reverse Cymbal Ride Bell Tambourine Solath Cymbal Control Crash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Cow Bongo Mute High Conga Open High Conga Open High Conga Open Low Conga	TR-808 High Tom 1 * TR-606 Ride Cymbal Chinese Cymbal Ride Beil Ride Gowbeil TR-800 Cowbeil Ride Cymbal Mikra-Hap Ride Cymbal Ride	18 MBG (rath Cymbal Bectiv High Tom 1 * H 608 Ride Cymbal Reverse Cymbal Rade Bell Stake i Zambourne Splank Cymbal T 808 Cowbell Crash Cymbal 2 Witz-Hap Ride Cymbal 2 Witz-Hap Ride Cymbal 2 Witz-Hap Ride Cymbal 2 Open High Conga Open High Conga Open High Conga	TR-808 Crash Cymbal CR 78 High Yom 1 TR-606 Nete Cymbal Chinese Cymbal Chinese Cymbal Ride Bell CR-78 Tambounine Spilach Cymbal TR-908 Crash Cymbal TR-908 Crash Cymbal Ride Cymbal Edge CR-78 Goobel TR-908 Cymbal TR-908 Open High Cong TR-808 Open High Cong TR-808 Open High Cong TR-808 Open High Cong TR-808 Open High Cong	18.808 Crask Cymbal 18.406 Filigh Tom 1 18.406 Cymbal 18.406 Cymba	18-905 Cash Cymbal TR-907 High Tom 1* TR-907 High Tom 1* TR-909 Acts Cymbal Chinese Cymbal Ride Bell Tambourine 2 Splant Cymbal Tambourine 2 Splant Cymbal Cash Cymbal Cash Cymbal Libra-slop Ride Cymbal Edge High Bongo Low Bongo Javier High Conga Open High Conga Open High Conga	TR-996 Crash Cymbal TR-996 High Tweb TR-996 High Tweb TR-996 High Tweb Treb Treb Treb Treb Treb Treb Treb Tr	Crash (ymball High Tom 1 T Ride (ymball Inner Chinese Cymbal Ride (ymbal Inner Chinese Cymbal Ride Bell Iambourine Splant (ymbal Cowhell Crash Cymbal Cowhell Crash Cymbal Liby Bell (ymbal Liby Bongo Libw Bongo Mute High Conga Open Liby Conga Open Low Gonga Open Low Gonga
Œ	52 63 55, 55, 57 60 60 60 60 60 60 60	TR-ABB High, Tom 1 * Rode Cymbal I * Rode Cymbal I * Rode Sell Shark Cymbal Rode Sell Shark Cymbal Rode Sell Shark Cymbal I * Rode Cowbell I * 959 Crash Cymbal V Vbra-siles Rode Cymbal Z * CR-78 High Bongo CA-78 Low Bongo TR-80 W Rode Figh Conga TR-80 M Rode Figh Conga TR-80 M Rote High Conga TR-80 M Rote High Conga TR-800 M Rote Figh Conga TR-	Rower High Torn 1 ** Rade Cymhal 1 ** Chrines Cymbal Rode Bell Tambourine Splein Cymbal Cowbell Splein Cymbal Cowbell Splein Cymbal 2 ** Vlorz-Nap Rade Cymbal 2 ** Vlorz-Nap Rade Cymbal 2 ** High Borgo Low Borgo Cymr High Conga Cymr High	Electric High Tom 1 * Ride Cymbal 1 Reverse Cymbal Reverse Cymbal Ride Bell Tambourine Splath Cymbal Cowdeal Cowdeal Cymbal Cowdeal Cymbal Cowdeal Ride Bell Tambourine Splath Cymbal 2 Vibra-slap Ride Cymbal 2 High Rongo Low Bongo Gpen High Conga Open Low Conga High Conga Open Low Conga	TR-808 High Tom 1 * TR-608 Righ Tom 1 * TR-608 Righ Cymbal Ride Bell GR-78 Tambourine Schalt Cymbal TR-808 Cowbell TR-909 Cash Cymbal Vidra-slap Ride Cymbal Edge CR-78 High Bongo CR-78 Low Bongo TR-808 Mare High Croya TR-808 Mare	1R -BBG (Cash Cymbal Beetrik High Tom 1 ** H 608 Ride Cymbal Reverse Cymbal Ride Bell Shake Tambourine Splash (ymbal TR -BBG Combell Cresh Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Unw Bongo Open High Conga Open High Conga	TR-808 Crash Cymbal CR-78 High Yean 1- TR-606 Ride Cymbal Chinere Cymbal Chinere Cymbal Ride Bell CR-78 Tambounne Spilash Cymbal CR-78 Combell TR-509 Crash Cymbal Viltra-Liga Ride Cymbal Edge CR-78 High Bongo CR-78 Low Bongo CR-78 High Bongo CR	18. 808 Crash Cymbal 178. 406 Fligh Tom 1 18. 406 Fligh Cymbal Chinese Cymbal Cit. 78 Tambourine Splash Cymbal CR. 78 Cambel 178. 409 Crash Cymbal Wibra-lab Med Cymbal Edge CR. 78 Kaw Borgo CR.	17.490 Crah Cymbal TR-909 Arde Cymbal TR-909 Arde Cymbal Chinese Cymbal Chinese Cymbal Tambourine 2 Splath Cymbal Tambourine 2 Splath Cymbal Canh Cymbal Canh Cymbal Edge High Bongo Low Bongo Low Bongo Open Liw Conga Open Low Conga Open Low Conga Open Low Conga	TR-996 Crash Cymbal TR-996 High Tom 1 TR-996 High Tom 1 TR-996 High Cymbal Chinene Cymbal Ride Bell Tambourne 2 Splash Cymbal Tambourne 3 Splash Cym	Crash Cymball High Tom 1 Ride Cymbal Inner Chinese Cymbal Ride Inner Chinese Cymbal Ride Bell Tambourine Splash Cymbal Crowbell Crash Cymbal 2 Vibra-slap Ride Cymbal Edge High Bongo Low Bongo Open High Conga Open High Conga Open Hogh Conga High Timbale
Œ	55 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	IT AGE High Ton 1 * Rode Cymbal I Rode Cymbal Rice Bell Rode Bell Rode Bell Rode Bell The AGE Conded! The AGE	Rower right Tom) 1 " Ride Cymhal 1 Christe Cymbal Ride Ride Ride Ride Ride Ride Ride Ride	Electric High Tom 1* Reverse Cymbal 1 Reverse Cymbal Reverse Cymbal Ride Bell Tambourine Splant Cymbal Cootede Splant Cymbal Cootede Vibra-Nap Ride Symbal 2 High Rongo Low Bongo Deen High Congal Deen High Congal High Timbale Low Timbale High Timbale	TR-808 High Tom 1 * TR-608 Ride Cymbal Chinese Cymbal Ride Beil Ride	TR-BBG (rash Cymbal Bectiv High Tom 1 * HI 608 Ride Cymbal Revene Cymbal Revene Cymbal Shake Tambourne Splash (rymbal TR-BBG Cymbal TR-BBG Cymbal Ride Cymbal Ride Cymbal Lingh Bongo Low Rongo Mute High Coopa Open Lingh Coopa Righ Coopa Righ Coopa Righ Coopa Righ Coopa Righ Coopa Righ Timbale Leav Timbale Leav Timbale Leav Timbale Leav Timbale	TR-808 Crash Cymbal CR 78 High Yom 1 * TR 606 Ride Cymbal Chinese Cymbal Ride Bell CR-78 Tambourine Spissh Cymbal CR-78 Tambourine Spissh Cymbal CR-78 Tambourine Spissh Cymbal Vibra-1gip Ride Cymbal Vibra-1gip Ride Cymbal CR-78 Low Bongo CR-78 Low Bongo RR-78 Low Bongo	18.808 Crash Cymbal TR-406 High Tom T TR-406 High Tom T TR-406 High Cymbal Chinese Cymbal Ride Beil CR-70 Tembourine Spilath Cymbal CR-70 Tembourine Spilath Cymbal CR-70 Tembourine Spilath Cymbal Vibra-Hall Re-899 Crash Cymbal Vibra-Hall TR-899 Crash Cymbal CR-70 Tem Bongo CR-70 Tem Bongo CR-70 Tem Bongo TR-808 Uner High Conga TR-808 Uner Hig	18-905 Cash Cymbal TR-907 High Tom 1* TR-907 High Tom 1* TR-909 Acts Cymbal Chinese Cymbal Ride Bell Tambourine 2 Splant Cymbal Tambourine 2 Splant Cymbal Cash Cymbal Cash Cymbal Libra-slop Ride Cymbal Edge High Bongo Low Bongo Javier High Conga Open High Conga Open High Conga	TR-996 Crash Cymbal TR-996 High Tweb TR-996 High Tweb TR-996 High Tweb Treb Treb Treb Treb Treb Treb Treb Tr	Crash (ymball High Tom 1 T Ride (ymball Inner Chinese Cymbal Ride (ymbal Inner Chinese Cymbal Ride Bell Iambourine Splant (ymbal Cowhell Crash Cymbal Cowhell Crash Cymbal Liby Bell (ymbal Liby Bongo Libw Bongo Mute High Conga Open Liby Conga Open Low Gonga Open Low Gonga
	55. 55. 55. 55. 55. 55. 55. 55. 55. 55.	IT ADS High Ton 1 * Rode Cymbal 1 Rode Symbal Reverse Cymbal Rode Bell Polket Tanthouries Splata Cymbal Th-890 Comb Cymbal Th-890 Comb Cymbal Th-890 Comb Cymbal Vibra-slap Rode Cymbal 2 Ch-71 Low Bongo Th-800 More High Bongo Ch-71 Low Bongo Th-800 More High Conga Th-800 More	Power High Tom 1 * Ride Cymhal 1 Chinese Cymhal 1 Canhose Cymhal Ride Beil Tambourine Spiech Cymhal Combal	Electric High Tom 1 * Ride Cymbal 1 Ride Symbal 1 Revense Cymbal Ride Bell Tambourine Solath Cymbal Cowteel Ride Symbal 2 Vibra-shap Ride Cymbal 2 Vibra-shap Ride Cymbal 2 Natre High Rongo Low Bongo Den Low Conga Open Low Conga Ope	TR-808 High Tom 1 * TR-608 Ride Cymbal Chinese Cymbal Ride Beil Ride Grah Ride Grah Ride Grah Ride Gymbal Literatap Ride Cymbal Vibra-slap Ride Cymbal Vibra-slap Ride Cymbal Vibra-slap Ride Cymbal Ride	TR-BBC (rash Cymbal Bectir Righ Tom 1 ** Med She Rice Cymbal Reverse Cymbal Reverse Cymbal Reverse Cymbal Reverse Cymbal Th 806 Cowbell TR-806 Cowbell TR-806 Cowbell Creah Cymbal 2 High Bongo Low Bongo Donn High Compa Cymbal 2 High Bongo Low Bongo Quen Liwy Compa High Compa Quen Liwy Compa High Timbale High Apogra Liwy Compa High Compa Quen Liwy Compa High Timbale High Apogra Liwy Compa High Compa Quen Liwy Compa High Compa Liwy Compa High Compa Hi	TR-808 Crash Cymbal Gn 78 High Yon 1 TR 606 Nide Cymbal Chneec Cymbal Ride Bell Gr. 78 Tambounne Spidas Cymbal Chr. 78 Tambounne Spidas Cymbal Gn 78 Coebell TR-507 Crash Cymbal TR-507 Crash Cymbal Vilfrar-High Ride Cymbal Cidge Ride Cymbal Gog Ride Cymbal Gog TR-808 Marte High Cong TR-808 Open Low Cong	18.808 Crask Cymbal 18.406 Filed Crask Cymbal 18.406 Filed Cymbal Chinese Cymbal Ride Bell CR. 78 Embourine Spilat Cymbal Spilat Cymbal 18.409 Crash Cymbal 18.400 Crash 18.400 Sengo CR. 78 Low Bongo CR. 78 Low Bo	18-905 Cash Cymbal TR-907 High Tom 1 * TR-907 High Tom 1 * TR-909 Ande Cymbal Chinese Cymbal Ride Bell Tambourine 2 * Selauh Cymbal TR-808 Combell Crash Cymbal TR-808 Combell Crash Cymbal Grab Cymbal High Bongo Low Bongo Low Bongo Open High Conga Open High Conga Open How Conga High Timbale Low Ilmahe Low Ilmahe Low Ilmahe Low Ilmahe Low High Conga Open Low Conga High Timbale Low Ilmahe Low High Gonga Open Low Conga High Timbale Low Ilmahe Low Ilmahe Low High Gonga Open Low Conga Low Agogo Low Agogo Low Agogo Low Agogo Low Agogo	TR-906 Crash Cymbal TR-909 High Tree TR-909 High Tree TR-909 High Tree Tree Tree Tree Tree Tree Tree Tree	Crash (ymball High Tom I Ride Cymbal Inner Chinese Cymbal Ride Cymbal Ride Ell Tamburine Spdath Cymbal Cowbell
		IT ADS High Ton 1 * Rode Cymbal 1 Rode Symbal Reverse Cymbal Rode Bell Pale Franciscope System Cymbal Rode Bell Pale T Ambourine Splank Cymbal T - 895 Crash Cymbal T - 895 Crash Cymbal T - 895 Crash Cymbal Vibra-lap Rode Cymbal 2 C-7. Th High Bongo C-7. The Mongo TH - 885 More High Conga TH - 88	Rower High Torn 1 ** Rade Cymhal 1 ** Chrinese Cymbal Rode Bell Tambourine Splein Cymbal Cowbell Splein Cymbal Cowbell Splein Cymbal 2 ** Vibra-lap Rade Cymbal 2 ** Vibra-lap Rade Cymbal 2 ** High Bongo Low Bongo Cymra High Conga Cymra	Electric High Tom 1 * Rive Errors 1 * Rive Cymbal 1 Reverse Cymbal Rive Bell Tambourine Splath Cymbal Cowteel Cowte Bell Tambourine Splath Cymbal Cowteel Rive Cymbal 2 * Vibira-slap Ride Cymbal 2 * High Rongo Low Bongo Chen High Conga Open Low Conga High Tombale Low Timbale High Timbale Low Timbale Low Timbale Low Timbale High Agogo Low Agogo Cabasa Maracax	TR-808 High Tom 1 * TR-608 Ride Cymbal Chinese Cymbal Chinese Cymbal Ride Bell Ride Bell Ride Bell TR-808 Cowbell TR-808 Cowbell TR-808 Cowbell RR-809 Cash Cymbal Vikra-18p Ride Cymbal Erige CR-78 High Bongo CR-78 Low Bongo TR-808 Mote High Conga TR-808 Mote High Conga TR-808 Mote High Conga TR-809 Cash Timbale High Timbale High Timbale Low Timbale High Agogo Low	TR-BBG (rash Cymbal Beetix High Tom 1° HIGH Tom 1° HIGH Sold Rick Cymbal Revene Cymbal Revene Cymbal Shake Tambourne Splash Cymbal TR-BBG Chwbell Crash Cymbal 2 High Bongo Low Angolo Low Angolo Low Angolo Low Angolo Cabasa Low Angolo Cabasa	TR-808 Crash Cymbal CR 78 High Yom 1 TR-608 Nete Cymbal Chinese Cymbal Chinese Cymbal Ride Bell CR 78 I Ambourine Spiash Cymbal CR 78 Coxbel TR-509 Crash Cymbal TR-509 Transbel TR-50	18.808 Crask Cymbal 18.406 Filed Crask Cymbal 18.406 Filed Cymbal Ohinese Cymbal Ride Bell GR. 78 Tambourine Splath Cymbal 18.209 Crash Cymbal Whys-Han Ride Cymbal Cymbal Whys-Han Ride Cymbal Cymbal 18.209 Crash Cymbal 18.200	18-905 Cash Cymbal TR-907 High Tom 1 * TR-907 Aide Cymbal Ohinese Cymbal Ride Bell Tambourine 2 * Splain Cymbal Tambourine 2 * Splai	TR-990 Fich Cymbal TR-909 Fich Fich TR-909 Fich Fich TR-909 Fich Fich TR-909 Fich Cymbal Chinese Cymbal Ride Bell Tambourne 2 Solath Cymbal TR-908 Combel TR-908 Compa Open Lew Compa High Tombale Ligh Timbale	Crash (ymbal) High Tom 1 Ride Cymbal Inner Chinese Cymbal Ride Eell Jambourine Splank (ymbal Croshell Crash (ymbal Crash (ymbal Crash (ymbal Cymbal Low Bongo Low Bongo Low Bongo Open High Conga Open Low Conga High Timbale Low Timbale
	5	TR ADB High Ton 1 * Rode Cymbal 1 Rode Cymbal 1 Rode Sell Shake Tambourine Spake Tambourine Spake Tambourine Spake Tambourine Spake Tambourine Spake Tambourine Spake Tambourine Th-800 Canb Cymbal Vora-slap Rode Cymbal Con-Timbole Lon-Timbole Lon-Rodgo Chibpa Rodgo Chibpa Rode Shararas Rode High Angog Chibpa Rode Chibpa Rodgo Chibpa Rode Shararas Rode High Angog Chibpa Rode Shararas Rode High Angog Chibpa Rode Shararas Rode High Angog Chibpa Rode Shararas Rode High Moriolie	Power High Tom 1 ** Ride Cymhal 1 Chinese Cymhal 1 Canbournes Ride Beil Tambournes Ride Beil Tambournes Rode Beil Tambournes Cowbeil Ride Cymhal 2 Vibra-slap Ride Cymhal 2 Vibra-slap Ride Cymhal 2 Vibra-slap Ride Cymhal 2 Nore Songo Rode Gymhal Compa Open Lew Gongo Open High Conga Open High Conga Open Lew Carnga High Angoga Low Imbate High Angoga Low Jongog Cabbasa Maracas Maracas Short High Whistie	Electric High Tom 1 * Ride Cymbal 1 Ride Symbal 1 Reverse Cymbal Ride Bell Tambourine Splain Cymbal Cowbell High Rongo Low Bongo High Compal Low Bongo High Conga Open High Conga Open High Conga Open Low Conga High Timbale Low Timbale Splain Timbale Low Timbale Low Timbale Low Timbale Low Timbale Splain Timbale Low Timbale Low Timbale Splain Timbale Low Timbale Splain	TR-808 High Tom 1 * TR-608 Ride Cymbal Chinese Cymbal Chinese Cymbal Ride Beil Ride Growbeil Ride Growbeil Ride Cymbal Ride Cymbal Vidra-Hap Ride Cymbal Edge CR-78 High Bongo CR-78 Lion Bongo CR-78 Lion Bongo CR-78 Lion Bongo RR-800 Deen High Conga RR-800 Deen Low Conga High Timbale Low Timbale Low Timbale Low Appop Cabasa Cabasa Cabasa Cabasa Short High Whistle	IR HBR Crash Cymbal Beetir High Tom 1 * HIGH STOR HIGH Cymbal Reverse Cymbal Reverse Cymbal Ride Bell Shake Farmbourne Spilesh Cymbal Th Bidd Gowleil Crash Cymbal High Bongo Low Bongo Low Bongo Low Bongo Low Bongo Low Wongal Ligw Timbale L	TR-808 Crash Cymbal CR 78 High Yon 1 TR-608 Nide Cymbal Chneese Cymbal Ride Bell CR-78 Tambounne Spiach Cymbal Ride Bell TR-509 Crash Cymbal CR-78 High Borgo TR-78 High Borgo TR-78 High Borgo TR-78 High Borgo TR-808 Open Low Conga High Throbale Lingh Timbale High Agogo Cabasa Cabasa CR-78 Maracas Short High Whistle	18.808 Crask Cymbal 18.406 Filed Crask Cymbal 18.406 Filed Cymbal Ohinese Cymbal Ride Bell GR. 78 Tambourine Splath Cymbal 18.209 Crash 18.20	18-805 Cash Cymbal TR-907 High Tom 1* TR-907 Aide Cymbal Ohinese Cymbal Ride Bell Tambourine 2* Splain Cymbal Tambourine 2* High Tonga Open Low Conga High Timbale Low Timbale Neyt Timbale Low Apogo Cabasa TR-808 Maracas Short High Whistle	TR-990 Fich Cymbal TR-909 Fich Fich TR-909 Fich Fich TR-909 Fich Fich TR-909 Fich Cymbal Chinese Cymbal TR-800 Fich Tambourne 2 Solath Cymbal TR-808 Cowbel Crash Cymbal Ley Tribabe Low Tombale High Anopo Cohen Low Apopo Cohes Low Apopo Cohes Low Apopo Cohes TR-808 Marzea TR-808 Marzea	Crash (ymball High Tom 1 Ride Cymbal Inner Chinese Cymbal Ride Ell Jambourine Splank (ymbal Crowbell Crash (ymbal Crash (ymbal Cymbal Ride Cymbal Cymbal Ride Cymbal Cymbal Ride Righ Rongo Open High Conga Open Low Conga High Timbale Low Timbale High Agogo Low Agogo Cabasa Maracas Short High Whiste
		IT ADS High Ton 1 * Rode Cymbal 1 Rode Cymbal 1 Rode Bell Polket Tankburine Splate Cymbal Th-898 Combel Th-898 Apopo Cobbys Th-898 Marrars Short High Whitel Long Low Whitele Short Gwinn Sh	Rower right Tom 1 ** Ride Cymhal 1 Christe Cymbal Ride Reil Christe Cymbal Ride Reil Tambbourine Splash Cymbal Contheli Splash Cymbal Contheli Ride Reil Tambbourine Splash Cymbal 2 Wors-Nap Ride Cymbal 2 High Bongo Low Bongo Copen High Conga Open High Conga Open High Conga Open High Conga Open Low Corga High Timbale Low Imbale High Apogo Low Agogo Cabbasa Marzexa Marzexa Marzexa Marzexa Marzexa Marzexa Loro Iow Whistie Long Iow Whistie Long Iow Whistie	Electric High Tom 1 * Ride Cymbal 1 Ride Symbal 1 Revens Cymbal Ride Bell Tambourine Splain Cymbal Cowbell High Rongo Ride Cymbal 2 Vibra-slap Ride Cymbal 2 Vibra-slap Ride Cymbal 2 North Cymbal 2 Ride Rymbal 3 R	TR-808 High Tom 1 * TR-608 Ride Cymbal Chinese Cymbal Chinese Cymbal Ride Beil Ride Growbeil Ride Cymbal Ride Cymbal Ride Cymbal Edge CR-78 High Bongo CR-78 High Groga Ride Cymbal Edge CR-78 High Bongo CR-78 High Bongo CR-78 High Conga Ride Open Low Conga High Timbale High Agngo Cabhra Cabra Cabra Short High Whistle Long Low Witssle Short High Whistle	TR-BBG (rash Cymbal Beetix High Tom 1° HIGH Tom 1° HIGH Sold Rick Cymbal Revene Cymbal Revene Cymbal Shake Tambourne Splash Cymbal TR-BBG Chwbell Crash Cymbal 2 High Bongo Low Angolo Low Angolo Low Angolo Low Angolo Cabasa Low Angolo Cabasa	TR-808 Crash Cymbal CR 78 High Yom 1* TR 606 Riete Cymbal Chinese Cymbal Chinese Cymbal Riede Bell CR-78 Tambounne Spissh Cymbal TR-509 Crash Cymbal TR-509 Crash Cymbal Valra-sign TR-509 Crash Cymbal Valra-sign TR-508 Marte High Cong Low Tabale Low Timbale Low Timbale Low Timbale Low Timbale Low Timbale Cong College Colle	18.808 Crash Cymbal TR-606 High Tom 1 TR-606 High Tom 1 TR-606 High Cymbal Chinese Cymbal TR-606 High Cymbal Chinese Cymbal Ride Beil CR-78 Tambourine Spilatin Cymbal TR-909 Crash Cymbal Witz - Han TR-909 Crash Cymbal Witz - Han TR-909 Crash Cymbal TR-908 Marte High Cong TR-	17.490 Crah Cymbal TR-909 Arde Cymbal TR-909 Arde Cymbal Chinese Cymbal Chinese Cymbal Arde Bell Tambourine 2 Splath Cymbal Tambourine 2 Splath Cymbal Tambourine 2 Splath Cymbal Gubh Cym	TR-990 Fich Cymbal TR-909 High Tom 1 TR-909 High Tom 1 TR-909 High Cymbal Chinece Cymbal Ride Bell Tambourne 2 Splan Kymbal Tambourne 3 Ride Cymbal Tambourne 3 Ride Cymbal High Bongo Low Bongo Low Hoph Conga Open Lew Conga High Timbale High Apogo Low Agogo Cabbas TR-808 Karacas TR-808 Karacas TR-808 Karacas TR-808 Karacas Long Low Whistie Long Low	Crash Cymbal I High Tom 1 Ride Cymbal Inner Chinese Cymbal Ride Ighal Ride Iseli Tambourine Splash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal 2 Vibra-slap Ride Cymbal Edge High Bongo Low Bongo Open High Conga Open High Conga Open High Conga Open Hop Conga High Timbale Low Timbale High Rimbale Low Agogo Low Agogo Low Agogo Cabess
		IT ASS High Ton 1 * Rode Cymbal I Rode Cymbal I Rode Selvense Cymbal Rode Sell Rode Sell TE ASS Combel TE ASS Selvense TE ASS Must High Congo TE ASS Combel TE ASS	Rower isigh Tom) 1 Ride Cymhal 1 Christe Cymbal 1 Christe Cymbal Ride Bill Ride Bill Tambourine Splash Cymbal Corebell Corebell Corebell Corebell Corebell Corebell Corebell Corebell Corebell Lore Bongo Lore B	Electric High Tom 1* Reverse Cymbal 1 Reverse Cymbal Reverse Cymbal Ride Bell Tambourine Solath Cymbal Cooebel Creat Cymbal 2 Vibra-Nes Mide Sell Tambourine Solath Cymbal 2 Vibra-Nes Mide Cymbal 2 High Rongo Low Bongo Low High Congal High Timbale Low Timbale Low Timbale Low Timbale Low Timbale Low Timbale Low Withits Short High Whitise Long Low Whitise Short High Whitise Long Low Whitise Short Guide Long Guiro Long	TR-808 High Tom 1 * TR-608 Ride Cymbal Chinese Cymbal Ride Beil Griese Cymbal Ride Beil Ride Spah Cymbal Vitz-eilap Ride Cymbal Ride Cymbal Ride Beigh Rongo Ride Giph Bengo Ride Giph Bengo Ride Giph Bengo Ride Giph Bengo Ride Giph Ride	IR MBR Crash Cymbal Beetric High Tom 1 * HIG	TR-808 Crash Cymbal CR 78 High Yom 1 TR-608 Nete Cymbal Chinese Cymbal Chinese Cymbal Ride Bell CR 78 I Ambourine Splash Cymbal TR-509 Crash Triba TR-509 Crash TR-509 C	18.808 Crask Cymbal TR 4006 Righ Tom 1 TR 4006 Righ Cymbal Dhinese Cymbal TR 4006 Righ Cymbal Dhinese Cymbal Ride Bell CR 78 Tambourine Spilath Cymbal CR 78 Tambourine Spilath Cymbal Whar-slap Ride Cymbal CR 78 Combell TR 999 Crash Cymbal Whar-slap Ride Cymbal Edge CR 78 Righ Bongo TR 4008 Righ Cong TR 4008 Righ Cong TR 4008 Cpen Righ Cpen Righ Cong TR 4008 Cpen Righ Cpen Righ Cong TR 40	18-905 Cash Cymbal TR-907 High Tom 1* TR-907 High Tom 1* TR-909 Acts Cymbal Ohinese Cymbal Ambourine 2 Solain Cymbal Tambourine 2 Solain Cymbal Low Brongo Low Brongo Doen High Conga Open Low Conga High Timbale Low Brongo Low Agogo Cobers TR-808 Kalescas Short High Whistle Long Low Godon	TR-990 Crash Cymbal TR-990 High Twy TR-990 High Twy TR-990 High Twy Tre	Crash (ymball High Tom 1 Ride (ymbal Inner Chinese Cymbal Ride (ymbal Inner Chinese Cymbal Ride (High Tom 1 Ride Bell Iambourine Splain (ymbal Cowhell Crash Cymbal Cymbal Cymbal Low Bongo Ride Cymbal Edy High Bongo Low Bongo Mute High Conga Open Low Conga High Timbale Low Timbale High Agogo Cobe High Bongo Low Agogo Cabbas Maracas Short High Whitele Long Low Whistle Short Guiro Long
	55 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	IT ADS High Ton 1 * Rode Cymbal 1 Rode Symbal 1 Rode Self Self Self Self Self Self Self Sel	Rower High Torn 1 ** Rate Lymbal 1 ** Chinese Cymbal Red Bell Tambourine Spleich Cymbal Cowbell Spleich Cymbal Cowbell Red Bell Tambourine Spleich Cymbal 2 ** Vibra-Hap Red Cymbal 2 ** Vibra-Hap Red Cymbal 2 ** High Bongo Low Bongo Low Bongo Cym High Conga Cym High Fimbale Low Timbale Low Timbale High Fimbale Low Timbale L	Electric High Tom 1* Reverse Cymbal Reverse Cymbal Ride Bell Tambourine Splath Cymbal Cowteel Splath Cymbal Cowteel Ged Gymbal Cowteel Witz-Hap Ride Symbal 2 Witz-Hap Ride Cymbal 2 Witz-Hap Ride Cymbal 2 High Rongo Low Bongo Open Lew Conga High Conga Open Lew Conga High Conga Open Lew Conga High Timbale Low Timbale High Timbale Low Timbale Low Apopo Cabasa Short High Whistle Long Low Whistle Short Guiro Cong Guiro Clowes Clowes	TR-808 High Tom 1 * TR-608 Ride Cymbal Chinese Cymbal Chinese Cymbal Ride Bell TR-608 Ride Cymbal Ride Bell TR-608 Ride Robel TR-608 Cowbell TR-608 Maracan Short Tight Whistie Charla TR-608 Maracan Short Tight Cowbell TR-608 Maracan Short Tight Whistie Charla TR-608 Maracan Short Tight Whistie Short Garba Charla TR-608 Maracan Short Tight Whistie Sh	IR HBR Crash Cymbal Beetin High Tom 1 7 HOS Ride Cymbal Revene Cymbal Revene Cymbal Revene Cymbal Revene Cymbal Rese Red Revene Sylach Cymbal Re 888 Cowbell Crash Cymbal Ride Ride Ride Ride Ride Ride Ride Ride Ride	TR-808 Crash Cymbal G. 78 High; You Crash Cymbal Chniese Cymbal Chniese Cymbal Chniese Cymbal Ride Bell CH: 78 Tambounne Ghida Christ The Solida Cymbal Christ The Solida Christ The So	18.808 Crask Cymbal 18.406 Filed Crash Cymbal 18.406 Filed Cymbal Chinese Cymbal Ride Bell CR. 78 Cambourine CR. 78 Cambal TR-599 Crash Cymbal CR. 78 Combal TR-599 Crash Cymbal CR. 78 Combal TR-599 Crash Cymbal TR-598 Crash	1R-905 Cash Cymbal TR-907 high Tom 1 * TR-907 high Tom 1 * TR-909 high Cymbal Chinese Cymbal Ride Bell Tambourine 2 * Selauh Cymbal TR-808 Lebruhal TR-808 Corebi Crash Cymbal TR-808 Corebi TR-808 Carebi Crash Cymbal TR-808 Carebi Crash Cymbal Crash Cymbal Graph Cymbal Low Brongo Low Gronga Open Low Conga High Tembale Low Timbale Low Timbale Low Timbale Low Timbale Low Timbale Low Margoo Low Agogo Low Martin Short Rulen Long Guide Cabata Short High Whistle Short Guine Long Guide Clases Long Low Whystle Short Guine Long Guide Clases Long Guide Long	TR-909 Crash Cymbal TR-909 High Tein Tranbourne 2 Soliah Cymbal TR-808 Cowbell Crash Cymbal TR-808 Cowbell TR-809 High Conga Dpen Low Conga High Apogo Low Timbale Low Timbale Low Timbale Low Timbale Low Timbale Timbale Low Whistle Short High Whistle Short Guiro [Scc) TR-808 Metracas Short High Whistle Short Guiro [SCC] TR-70 Clows TR-70 Clows	Crash Cymball High Tom T Ride Cymbal Inner Chinese Cymbal Ride Inner Chinese Cymbal Ride Bell Tambourine Splant (Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 12 Vibra-slap Ride Cymbal 12 Vibra-slap Ride Cymbal 12 Vibra-slap Ride Cymbal 12 Vibra-slap Righ Rongo Down High Conga Open Righ Conga Open Righ Conga Open Righ Conga High Timbale Low Timbale Low Timbale Low Righ Rongo Low Agogo Calbesa Maracas Short High Whistle Short Guiro Long Low Whistle Short Guiro Long Guiro Closer
		IT ASS High Ton 1 * Rode Cymbal I Rode Cymbal I Rode Selvense Cymbal Rode Sell Rode Sell TE ASS Combel TE ASS Selvense TE ASS Must High Congo TE ASS Combel TE ASS	Rower High Torn 1 ** Ride Cymhal 1 ** Ride Cymhal 1 ** Chinese Cymbal Ride Bell ** Tambourine 5 Splain Cymbal Cowbell ** Splain Cymbal Cowbell ** Ride Ride Tornbal 2 ** Vibre-slap Ride Cymbal 2 ** V	Electric High Tom 1 * Ride Cymbal 1 Ride Symbal 1 Revense Cymbal Ride Bell Tambourine Splain Cymbal Conteel High Rongo Low Bongo Mute High Conga Open High Conga Open High Conga Open Low Gongo High Samgo Low Hongo Low Hongo Low Hongo Cabasa Maracas Short High Whistle Long Itow Whistle Short Guiro Claves Short High Whistle Long Guiro Claves	TR-808 High Tom 1 *T TR-608 Ride Cymbal Oninese Cymbal Ride Beil Fich 26 Ride Cymbal Ride Beil Ride Beil TR-808 Cowbeil TR-808 Cowbeil TR-809 Cisch Cymbal Viktra-Hap Ride Ride Ride Ride TR-809 Cisch Cymbal Viktra-Hap Ride	IR MBR Crash Cymbal Beetric High Tom 1 * HIG	TR-808 Crash Cymbal CR 78 High Yom 1 TR-608 Nete Cymbal Chinese Cymbal Chinese Cymbal Ride Bell CR 78 I Ambourine Splash Cymbal TR-509 Crash Triba TR-509 Crash TR-509 C	18.808 Crask Cymbal 18.406 Filed Crask Cymbal 18.406 Filed Cymbal Ohinese Cymbal Ride Bell GY. 78 Tambourine Splath Cymbal 18.406 Filed Cymbal Whiza-Han Ride Cymbal Edge CH-78 Crabe 18.408 Cymbal 18	18-905 Cash Cymbal 18-907 Meb, Cymbal 18-907 Meb, Cymbal Ohinese Cymbal Reide Bell Jambourine 2 Splain Cymbal Splain Cymbal 18-808 Combell Crash Cymbal Crash Cymbal Liver Bell	TR-990 Fish Cymbal TR-909 Fish Fish TR-909 Fish Fish TR-909 Fish Fish TR-909 Fish Fish TR-909 Fish TR-909 Fish TR-909 Fish TR-909 Fish TR-909 Fish TR-900 Fish TR-	Crash (ymbal) High Tom T Ride Cymbal Inner Chinese Cymbal Ride Ell Jambaurine Splank Cymbal Crash (ymbal Crash (ymbal Crash (ymbal Cymbal Low Bongo Cymbal High Timbale Low Bongo Cymbal High Timbale Low Japogo Calessa Maracas Maracas Short High Whistile Long Low Whistile Short Guiro Long Gairo Cuneve High Wood Block
	55 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	IT ADB High Ton 1 * Rode Cymbal 1 Rode Septimal 1 Rode Cymbal 1 Rode Cymbal 2 CA-71 High Bongo CA-71 Love Bongo TA-800 Cymbal 2 CA-71 High Bongo CA-71 Love Bongo TA-800 Septimal 2 Rode Cymbal 2 CA-71 High Bongo CA-71 High Bongo CA-71 High Bongo TA-800 Septimal 2 Rode Cymbal 3 R	Rower High Torn 1 ** Rade Cymhal 1 ** Chrinese Cymbal Rode Beil' Tambourine Spleah Cymbal Combell Spleah Cymbal Combell Spleah Cymbal 2 Vibra-slap Rade Beil High Bongo Low Bongo Low Bongo Low Bongo Low Bongo Low Bongo Low Bongo Copen High Conga Copen High Conga Copen High Conga Copen Low Corga High Tombale Low Timbale High Timbale Low Timbale High Apogo Low Agogo Cabasa Short High Whistle Short Hogh Whistle Short Guiro Long Guiro Chives High Wood Block Low Wood Block	Electric High Tom 1 * Rive try the Internal 1 in Reverse Cymbal Rive Bell Tambourine Splath Cymbal Control Bell Control Be	TR-808 High Tom 1 * TR-608 Ride Cymbal Chinese Cymbal Chinese Cymbal Ride Bell Ride Bell TR-808 Cowbell TR-808 Cowbell TR-808 Cowbell TR-809 Cisph Cymbal Vikra-slap Ride Cymbal stelp Ride Cymbal TR-808 More High Conga TR-808 More High Conga TR-808 More High Conga TR-808 More High Conga Ride Cymbal Ride Cymbal Ride Cymbal Ride Cymbal Ride Cymbal Ride Conga Ride Ride Conga Ride Ride Ride Conga Ride Ride Ride Conga Ride	IR HBR Crash Cymbal Beetric High Tom 1 ** HB GGS Ride Cymbal Reverse Cymbal Reverse Cymbal Reverse Cymbal Reverse Cymbal Ride Bell Th RGG Cowbell Crash Cymbal 2 HBry Mary Crash Cymbal HBry Bongo Low Bongo Dom High Conga Cymbal 2 HBry Bongo Cymbal 2 HBry Bongo Low Bongo Cymbal 3 HBry Bongo Cymbal 3 HBry Bongo Cymbal 4 HBry Bongo Cymbal 4 HBry Bongo Cymbal 4 HBry Bongo Cymbal 5 HBry Bongo Cymbal 5 HBry Bongo Cymbal 5 HBry Bongo Cymbal 6 HBry Bongo Cymbal 6 HBry Bongo Cymbal 6 HBry Bongo Cymbal 7 HBry Bongo Cymbal 6 HBry Bongo Chasa Short Guro Long Golfro Chasa HBry Bongo Chasa HBry	TR-808 Crash Cymbal GN 78 High Yon 1 TR 606 Nide Cymbal Chneese Cymbal Ride Bell GN-78 Tambounne Spiash Cymbal Ride Bell GN-78 Conbell TR-507 Conbell TR-507 Conbell TR-507 Crash Cymbal TR-507 Crash TR-507 C	18.808 Crask Cymbal 18.408 Crask Cymbal 18.408 Filiph Tom 1 18.406 Filiph Tom 1 18.406 Filiph Tom 1 18.406 Filiph Tom 1 18.406 Filiph Tom 1 18.408	18-806 Cash Cymbal TR-907 High Tom 1 * TR-907 High Tom 1 * TR-909 Ands Cymbal Ohinese Cymbal Ride Bell Tambourine 2 * Splash Cymbal Cash Cymbal Cash Cymbal Cash Cymbal Low Bongo Low Low Long Low Timbale Low Timbale Low Jongo Cabasa Short High Whistile Long Low Whette Short Gaira Long Guiro Claves High Wood Block Low Wood Bl	TR-906 Crash Cymbal TR-909 High Tein Tranbourne 2 Solash Cymbal Tr-808 Cowbell Tr-809 Dopen High Conga Dopen High Conga Dopen High Conga Dopen High Teinbale Low Tembale High Anopo Low Mysile Short Guiro Tribale Low Tembale Low Tembale Low Tembale Low Tembale Teinbale Low Hopogo Cabbra Short High Whistile Long Low While Tri-808 Marteria Short High Whistile Long Low While Tri-808 Marteria Short High Whistile Low Glood Tribale High Mood Block High Wood Block Low Wood Block High Wood Block Low Wood Block High Mood Block Low Wood Block High Hos [EXC4]	Crash Cymball High Tom T Ride Cymbal Inner Chinese Cymbal Ride Inner Chinese Cymbal Ride Bell Tambourine Splant (Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 12 Vibra-slap Ride Cymbal 12 Vibra-slap Ride Cymbal 12 Vibra-slap Ride Cymbal 12 Vibra-slap Righ Rongo Down High Conga Open Righ Conga Open Righ Conga Open Righ Conga High Timbale Low Timbale Low Timbale Low Righ Rongo Low Agogo Calbesa Maracas Short High Whistle Short Guiro Long Low Whistle Short Guiro Long Guiro Closer
		IT AGE High Ton 1 * Rode Cymbal 1 Rode Cymbal 1 Rode High Cymbal 1 Rode Bell Cymbal 1 Rode Bell Cymbal 1 Rode Bell 1 Rode Bell 1 Rode Cymbal 1 Rode Cymbal 2 Ch. 71 High Bongo Ch. 71 Rode Cymbal 2 Ch. 71 High Bongo Ch. 71 Rode Mutte High Congo Th. 400 High Congo High Timbale Long Low Aggos College Short High While Long Low Whiste Short Gome Children 1 Rode Children High Model Short Light While Long Low Whiste Short Gome DCC Th. 400 Low Block Low White Block Low Who EDCK Low Hore DECK Low Hore DECK Low Hore Block Low Hore Block Low Who EDCK Low Hore DECK Low Hore Block Low Hor	Rower isigh Tom 1 ** Ride Symhal 1 Chinese Cymbal Ride Self I Chinese Cymbal Ride Self I Cambourine Splash Cymbal Cowbell Sylash Cymbal 2 Vibra-lap Ride Self I Hall Ride Self I Hall Ride Symhal 2 High Rongo Low Bongo Open Halp Conga Open Halp Conga Open Halp Conga Open Halp Conga Open Low Conga High Timbale Low Timbale Low Timbale High Apogo Low Agogo Calabase Marscas Marscas Harracas Ha	Electric High Tom 1* Reverse Cymbal Reverse Cymbal Reverse Cymbal Ride Bell Tambourine Solath Cymbal Cooebel Creat Grath Cymbal Cooebel Creat Gymbal 2 Vibra-Nap Ride Symbal 2 High Rongo Low Bongo Low Bongo Denn High Congal Open High Congal High Timbale Low Timbale Low Timbale Low Timbale High Agogo Low Agogo Cabasa Maracas Short High Whitel High Agogo Low Agogo Cabasa Maracas Low Minister Long Guiro Cabasa Maracas Low Minister Long Guiro Claves Model Block Mute Cuta Mute Mute Mute Mute Mute Mute Mute Mute	TR-808 High Tom 1 * TR-608 Ride Cymbal Chinese Cymbal Ride Bell Chinese Cymbal Ride Bell Ride	IR MBR Crash Cymbal Beetir High Tom 1* HIGH STOR HIGH ST	TR-808 Crash Cymbal CR 78 High Yon 1 TR 608 Nets Cymbal Chnees Cymbal Chnees Cymbal Chnees Cymbal Ride Bell CR 78 I Anbourne Spiach Cymbal CR 78 Coxbell TR-909 Crash Cymbal TR-908 Marca High Bongo TR-908 Marca High Cong TR-908 Marca High Cong TR-908 Open Low Cong High Timbale Low Timbale Low Timbale CR-78 Marca CR-78 Marca CR-78 Guine (EXCS) CR-78 G	18.808 Crask Cymbal 18.406 Filed Crask Cymbal 18.406 Filed Cymbal Ohinese Cymbal Ohinese Cymbal Ride Beil OR. 78 Tambouries Splain Cymbal OR. 78 Cambel 18.409 Crash Cymbal 18.409 Crash 18.400 Crash 18	18-805 Cash Cymbal 18-807 High Tom 1* 18-909 Acts Cymbal Ohinese Cymbal Ohinese Cymbal Acts Bell Sambourine 2 Solain (ymbal Solain Sambourine 2 Solain (ymbal Cash (ymbal Low Bongo Low Bongo Open Low Gonga Open Low Conga High Timbale Low Bongo Low Agogo Low Agogo Low Agogo Low Agogo Cobata Sambourine Samb	TR-990 Fich Cymbal TR-909 High Toymbal TR-909 High Toymbal Chinese Cymbal Chinese Cymbal Ride Bell Tambourne 2 Splath Cymbal Tambourne 2 High Bongo Ride Cymbal Edge High Bongo Rote High Conga Open High High High High High High High High	Crash (ymbal) High Tom T Ride (ymbal Inner Chinese (ymbal Inner Chinese (ymbal Ride III) Ride IEII Tambourine Splain (ymbal Cowhell Crash (ymbal Cowhell Crash (ymbal Cowhell Crash (ymbal Cowhell Ride Cymhal Edge High Bongo Low Bongo Muter High Conga Open High Conga Open High Conga Open High Conga Open High Conga Copen Low Conga High Timbale Low Sango Low Agogo Cabese Maracas Maracas Maracas Maracas Long Low Whistle Short Guiro Long Gairo Claver High Wood Block Low Wood Block Low Wood Block Maraca Open Coica Open Coica Open Coica Open Coica
		IT ADB High Ton 1 * Rode Cymbal 1 Rode Septimal 1 Rode Cymbal 1 Rode Cymbal 2 CA-71 High Bongo CA-71 Love Bongo TA-800 Cymbal 2 CA-71 High Bongo CA-71 Love Bongo TA-800 Septimal 2 Rode Cymbal 2 CA-71 High Bongo CA-71 High Bongo CA-71 High Bongo TA-800 Septimal 2 Rode Cymbal 3 R	Rower High Torn 1 ** Rade Lymbal 1 ** Chinese Cymbal Red Bell Tambourine Spleah Cymbal Cowbell Spleah Cymbal Cowbell Spleah Cymbal 2 ** Vibra-Hap Rade Red Nate Cowbell Rade Red Nate Cowbell Rade Symbal 2 ** Vibra-Hap Rade Cymbal 2 ** Vibra-Hap Rade Cymbal 2 ** Vibra-Hap Rade Cymbal 2 ** High Bango Low Bongo Copen Hapi Gonga Low Hapi Timbale High Agogo Cabbase Maracza Short High Whistle Long Guiro Chores High Wood Block Low Open Cukca Gone Gone Cukca Gone Cukca Gone Cukca Gone Gone Cukca Gone Gone Cukca	Electric High Tom 1* Reverse Cymbal 1 Reverse Cymbal Reverse Cymbal Ride Bell Tambourine Splath Cymbal Cowbell Ride Bell Tambourine Splath Cymbal Cowbell Ride Bell Tambourine Splath Cymbal Cowbell Ride Splath Cymbal 2 High Bongo Low Bongo Low Bongo Gpen Helph Conga High Timbale High Angog Low High Timbale High Agogo Low Agogo Cabbas Marazas Short High Whisile Long Guiro Long Guiro Claves High Whisile Long Guiro Claves High Wood Block Mute Cuizo Copen Cuizo More Triangle Mute Triangle	TR-808 High Tom 1 * TR-808 High Tom 2 * TR-808 High Tom 2 * TR-808 Country TR-808 Mote High Conga TR-808 Mich Country TR-808 Mich High Agogo Low Agogo Country TR-808 Mich Tombale High Agogo Low Agogo Country Low Mich High Agogo Low Agogo Country Low Michael Michael Country Low Michael M	IR BBB (cash Cymbal Beetir High Tom 1 * 1 * 1 * 1 * 1 * 1 * 1 * 1 * 1 * 1	TR-808 Crash Cymbal Gr. 78 High You You TR 608 Ride Cymbal Chniese Cymbal Chniese Cymbal Ride Bell Gr. 78 I anhbounne Gr. 78 I Conbell TR-507 Crash Cymbal Chr. 78 Conbell TR-507 Crash Cymbal Vitra-High Ride Cymbal Lide Gr. 78 Conbell TR-507 Crash Cymbal Vitra-High Ride Cymbal Lide Gr. 78 I Konbell TR-508 Mintra High Cong TR-508 Mintra High Cong TR-508 Mintra High Cong TR-508 Open Low Cong High Timbale Low Timbale High Agogo Low Agogo Cabesa Short High Minital Low Low Marca Short High Agogo Cabesa Short High Minital Short Guillo CR-78 Guino (EXC)	18.808 Crash Cymbal 18.408 Filey Tom 1 18.408 Filey Cymbal 18.408 Filey Cymbal 18.408 Filey Cymbal 18.408 Filey Cymbal 18.408 Filey Crash Cymbal 18.408 Filey Filey Crash 18.408 Filey Filey Crash 18.408 Filey Filey Filey 18.408 Filey Filey Filey 18.408 Filey Filey 18.408 Filey Filey 18.408 F	1R-905 Cash Cymbal TR-907 high Tom 1 * TR-907 high Tom 1 * TR-909 high Cymbal Chinese Cymbal Ride Bell Tambourine 2 * Selauh Cymbal TR-808 Leber Cymbal TR-808 Combel Low Bongo Low Gonga Low High Conga Open Low Conga High Tembale Low Timbale Low Timbale Low Timbale Low Wood Block Long Low Wood Block Long Guide Clases High Wood Block Low Hool (EXC4)	TR-905 Crash Cymbal TR-905 High Tree TR-905 High Tree TR-905 High Tree TR-905 High Tree Tree Tree Tree Tree Tree Tree Tree	Crash (ymball High Tom 1 Red Cymbal Inner Chinese Cymbal Red Cymbal Inner Chinese Cymbal Ride Ell Tamburine Splath Cymbal Cowhell Crash Cymbal Cowhell Crash Cymbal Cowhell Crash Cymbal Cowhell Crash Cymbal Edge High Conga Dione North Eligh Conga Dopen Ligh Conga Open Ligh Conga Open Ligh Conga Open Ligh Conga Open Ligh Conga Copen Ligh Timbale Light Conga Copen Ligh Timbale Light Timbale Light Compa Copen Light Compa Copen Light Copen Light Copen Copen Lig
		IT AGE High Ton 1 * Rode Cymbal 1 Rode Cymbal 1 Rode September 1 Rode Sept	Rower right Torn 1 ** Ride Cymhal 1 Christe Cymbal Ride Ride North All Christe Cymbal Ride Ride Ride Ride Ride Ride Ride Ride	Electric High Tom 1* Reverse Cymbal 1 Reverse Cymbal 1 Reverse Cymbal Reverse Cymbal Ride Bell 1 Tambourine Splath (Cymbal Coneted Reverse Cymbal Coneted Reverse Cymbal 2 Vistra-Nap Ride Cymbal 2 High Rongo Low Bongo Mutr High Conga Open Helph Conga Open Helph Conga Open Helph Conga Open Low Conga High Timbale Low Timbale High Apogo Low Apogo Cabasa Maracas Short High Whistie Long Guiro Claves Hong Guiro Claves High Whistie Long Guiro Claves High Wood Block Mutr Culsa Open Culra Mutr Fringele Open Culra Mutr Fringele Open Culra Mutr Fringele Open Culra Mutr Fringele Open Culra Gene Trinnele Shater	TR-808 High Tom 1 * TR-608 Ride Cymbal Chinese Cymbal Ride Beil Chinese Cymbal Ride Beil Ride Spah Cymbal Vitz-eilap Ride Cymbal Ride Cymbal Ride Gymbal Ride Bengo R. 78 Bei Bengo R. 78 Being Being Ride	IR MBR Crash Cymbal Beetir High Tom 1* High Son 1* High Bongs Low Appal 2 High Songs Low Appal 3 High Conga Open Low Appal High Timbale Low Timbal	TR-808 Crash Cymbal Crash Cymbal Crash Cymbal Chinese Cymbal Chinese Cymbal Chinese Cymbal Chinese Cymbal Ride Bell Cr. Til Tambourine Spilath Cymbal Cris Til Tambourine Spilath Cymbal Til Spilath Comp Til Spilath Til	18.808 Crask Cymbal TR 406 High Tom 1 TR 406 Hig	17.400 Crash Cymbal TR-909 Acts Cymbal TR-909 Acts Cymbal Chinese Cymbal Ride Bell Tambourine 2 Splant Cymbal Tambourine 3 Donn High Conga Open Low Gonga High Timbale Low Brongo Low Agogo Cabeta TR-BER Maracas Short High Warst Short Gain TR-BER Maracas Short High Wissile Long Guiro Clases High Wood Block Long Guiro Clases Low Wood Block High Wood Block Low Wood Block Low Wood Block High Wood Block Low Wood Block High Wood Block High Wood Block Low Wood Block High Wood Block High Wood Block High Wood Block Low Wood Block High Wood Block High Ford Triangle	TR-990 Fich Cymbal TR-909 High Toymbal TR-909 High Toymbal Chinese Cymbal Chinese Cymbal Ride Bell Tambourne 2 Splath Cymbal Tambourne 2 High Bongo Ride Cymbal Edge High Bongo Rote High Conga Open High High High High High High High High	Crash (ymbal) High Tom T Ride Cymbal Inner Chinese Cymbal Ride Cymbal Inner Chinese Cymbal Ride Bell Tambourine Splant (ymbal Condell Crash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Cybra-dap Ride Cymbal Edge High Bongo Low Bongo Mute High Conga Open Holy Conga Open Holy Conga Open Low Conga High Timbale Low Timbale High Apogo Low Apogo Cabers Maracas Short High Whistle Short Guiro Long Guiro Long Gairo Claves High Wood Block Low
ß		IT ADS High Ton 1 * Rode Cymbal 1 Rode Symbal 1 Rode Sept Service Cymbal Rode Sept Service Cymbal Rode Sept Sept Sept Sept Sept Sept Sept Sep	Rower High Torn 1 ** Rade Cymhal 1 ** Chrines Cymbal Rode Beil Teanbourine Splein Cymbal Rode Beil Teanbourine Splein Cymbal Conbell Splein Cymbal 2 ** Vibra-slap Rade Cymbal 2 ** High Bongo Low Bongo Cymra High Conga Cymra High Cymra Cym	Electric High Tom 1* Reverse Cymbal Reverse Cymbal Reverse Cymbal Ride Bell Tambourine Splant Cymbal Cowteel Splant Cymbal Cowteel Gell Gell Gell Gell Gell Gell Gell	TR-808 High Tom 1 * TR-808 High Tom 1 * TR-606 Ride Cymbal Th-606 Ride Cymbal Chinese Cymbal Ride Bell TR-808 Cowbell TR-808 Cowbell TR-808 Cowbell TR-808 Cowbell TR-808 Cowbell TR-809 Cash Cymbal Vibra-18p Ride Cymbal Edge CR-78 High Bongo CR-78 Low Bongo TR-808 Mote High Conga TR-808 Mote North Conga High Timbale High Agogo Low Agogo Casha TR-808 Maracan Rhort High Mote Conga Low Wood Block Low Form Low Wood Block Ligh Hoo [EXC4] Low Hoo [EXC4] Excit Mut Enringle Rectif Mut Enringle Rectif Staker inangle Bell Lection Staker Inangle Lection S	IR HBR Crash Cymbal Beetric High Tom 1 ** HBR GSR Ride Cymbal Reverse Cymbal Reverse Cymbal Reverse Cymbal Reverse Cymbal Ride Bell Th Ride Cowbell Th Ride Cymbal 2 High Bengo Low Bengo Dopen High Conga Open High Conga Copen High Conga Copen High Conga Copen High Monga Low High Monga Copen High Monga Copen High Monga Low High Monga Low Monda High Ride High Hoog Elect Low Hood Block High Mong Elect Low Hood Block High Hoo Elect	TR-808 Crash Cymbal GN 78 High Yon 1 TR 606 Nide Cymbal Chnwere Cymbal Ride Bell CR-78 Tambounne Spidas Oyste	18.808 Crask Cymbal 18.408 Crask Cymbal 18.406 Righ Tom 1 18.406 Righ Tom 1 18.406 Righ Tom 1 18.406 Righ Cymbal Ninese Cymbal Ride Bell CR-78 Canbell 18.499 Crash Cymbal Vilya-Hab Ride Cymbal 18.499 Crash Cymbal Vilya-Hab Ride Cymbal 18.499 Crash Cymbal 18.498 Ride Cymbal 18.49	18-806 Cash Cymbal 18-807 High Tron 1 * 18-807 High Tron 1 * 18-807 High Tron 1 * 18-807 High Cymbal Chinese Cymbal Ride Bell Sambourine 2 * Splash Cymbal Splash Cymbal Splash Cymbal Cash Cymbal Cash Cymbal High Bongo Low High Long Low Long Low Jone High Hinhale Low Jone Long Low Hinhale Long Low Whetel Short Gaire Long Guiro Claves High Wood Block High Wood Block Low Wood Block Low Wood Block Low Hood Block	TR-906 Crash Cymbal TR-906 High Tree TR-906 High Tree TR-906 High Tree Tree Tree Tree Tree Tree Tree Tree	Crash (ymball High Tom 1 Red Cymbal Inner Chinese Cymbal Red Cymbal Inner Chinese Cymbal Ride Ell Iambourine Splank Cymbal Cowhell Crash Cymbal Edge High Conga Dione Norgo Mure High Conga Open Low Bongo Chapt High Conga Open Low Conga High Conga Open Low Conga High Conga Copen Low Conga High Timbale Low Conga High Timbale Low Sport Guiro Sharing Conga Cabers Maracas Short High Whittle Short Guiro Long Guiro Claver High Wood Block Low Wood Block Low Wood Block Low Wood Block Market Carica Open Cuica Marte Triangle Spaker Insige Spel Insige Bell Insige B
		IT AGE High Ton 1 * Rode Cymbal 1 Rode Symbal 1 Rode Self Reverse Cymbal Rode Self Reverse Cymbal Rode Self 1 The Mill Combell 17-886 Combel 17-886 Combel 17-886 Cymbal 17-886 Cymbal 17-886 Cymbal 17-886 Cymbal 17-886 Cymbal 17-886 Cymbal 17-886 Miller High Conga 17-886 Miller Miller Com Finishet High Agogo Cobasa 18-886 Cymbal 18-886 Cymbal 18-886 Cymbal 18-886 Miller Com Finishet High Agogo Cobasa 18-886 Miller Miller Com Finishet Miller Com Miller Com Finishet Miller Com Miller Com Miller Com Miller Com Finishet Miller Com Fini	Rower High Torn 1 1 Rade Lymbal 1 Rade Lymbal 1 Chanes Cymbal Rade Bell Tambourine Spleah Cymbal Cowbeel Spleah Cymbal Cowbeel Rade Bell Tambourine Spleah Cymbal 2 Vibra-Hap Rade Symbal 2 Vibra-Hap Rade Cymbal 2 High Bongo Low Bongo Low Bongo Cym High Conga Low Grapa High Timbale Low Timbale High Agogo Low Agogo Cabassa Marson Marson Marson Marson Marson Marson Choves High Whood Block Low Whood Block Low Whood Block Marte Cultar Cyme Civica Chore Colore Chore Splead Marte Triangle Cyme Timagle Splead Filingle Bell Bell Tree Cartarnetts	Electric High Tom 1* Reverse Cymbal 1 Reverse Cymbal Reverse Cymbal Ride Bell Tambourine Solath Cymbal Cooebel Cymbal Cymbal Cooebel Cymbal Cymbal Cooebel Cymbal C	TR-808 High Tom 1 * TR-608 Ride Cymbal Chinese Cymbal Ride Beil Chinese Cymbal Ride Beil Ride	IR MBR Crash Cymbal Beetir High Tom 1* High Son 1* High Bongs Low Appal 2 High Songs Low Appal 3 High Conga Open Low Appal High Timbale Low Timbal	TR-808 Crash Cymbal CR 78 High Yen 1 TR 608 Nide Cymbal Chneec Cymbal Ride Bell CR 78 Ta Anbounne Spiach Cymbal Side Bell TR-909 Crash Cymbal TR-909 Tranton TR-908 Mura High Bongo TR-908 Mura High Cran TR-908 Open Low Coogs High Timbale Low Timbale The Timbale T	18.808 Crask Cymbal 18.406 Filed Crask Cymbal 18.406 Filed Cymbal Ohinese Cymbal Christo Cymbal Christo Cymbal Christo Crash Cymbal 18.406 Filed Cymbal Christo Crash Cymbal 18.406 Filed Cymbal 18.406 Crash Cymbal 18.406 Cymbal	18-905 Cash Cymbal 18-907 Acts Cymbal 18-907 Acts Cymbal 18-907 Acts Cymbal Chinese Cymbal Reide Bell 1ambourine 2 Splain Cymbal 1 Acts Cymbal	TR-990 Fich (symbal TR-909 Fich (symbal TR-909 Fich (symbal Chinese (symbal Robert (symbal Robert (symbal Robert (symbal Tambourne 2 Splash (symbal Tambourne 2 Splash (symbal Tambourne 2 Splash (symbal Tambourne 2 Splash (symbal Trabet Robert (symbal Robert (sy	Crash (ymbal) High Tom T Ride (ymbal Inner Chinese (ymbal Inner Chinese (ymbal Ride (ymbal Inner Chinese (ymbal Ride III) Tambourine Splain (ymbal Cowhell Crash (ymbal Cowhell Crash (ymbal Cowhell Ride (ymbal Edge High Bongo Low Bongo Low Bongo Muter High Conga Open High Conga Open High Conga Open High Conga Open Low Conga High Timbale Low Bongo Low Apago Cabese Maracas Short High Whitele Long Low Whistle Short Guiro Long Gairo Claver High Wood Block Low Hong Cairo Claver High Wood Block Low Hong Gairo Claver Open Cuica Muter Cirica Open Cuica Muter Triangle Gen Triangle Gen History Charles Gen Triangle Gen History Charles Gen Triangle Gen History Charles Gen Triangle Gen History Gen History Gen High Wood Block Muter Cirica Muter Triangle Gen History Gen His
ß		IT ADS High Ton 1 * Rode Cymbal 1 Rode Self Share Reverse Cymbal Rode Bell Share Tanasha Rode Bell Rode Cymbal 2 CA-71 High Bongo CA-71 Love Bongo TR-808 Cymbal 2 CA-71 High Bongo CA-71 Love Bongo TR-808 Cymbal 2 TR-808 Marte High Gonga TR-808 Cymbal 2 TR-808 Marte High Gonga TR-808 Open High Conga TR-808 Open High Conga TR-808 Open High Conga TR-808 Cymbal Cymbal Love Magoga Cabips Love Magoga Cabips Love Migh Model Cong Love Whiste Bont Gwino Call Tanasha High Hood Block Long Love Whiste Bont Gwino CA-71 Binni (EXC) TR-808 Claver High Wood Block Love Wood Block High Hood Block Love Wood Block High Hood Block Love Wood Block High Hood Block Love Hood Block High High Hood Block High Hood Block High Hood Block High Hood Block	Rower sight Tom 1 ** Ride Symbal 1 Chinese Cymbal 1 Chinese Cymbal 1 Ride Bid 1 Chinese Cymbal 1 Ride Bid 1 Choele 1 Splash Cymbal 2 Vibra-lap 1 Ride Bid 1 King Bid	Electric High Tom 1* Reverse Cymbal 1 Reverse Cymbal Reverse Cymbal Ride Bell Tambourine Solath Cymbal Conebell Cone Bongo Idea High Congal Open High Congal Open High Congal Open Low Gonga High Timbale Low Bongo Idea Conebell Co	TR-808 High Tom 1 * TR-608 Risk Cymbal Chinese Cymbal Chinese Cymbal Rick Bell Rick Gymbal TR-909 Cash Cymbal Vilva-lap Rick Cymbal Rick	TR-BBC (rash Cymbal Beetir High Tom 1 ** TH 608 Ride Cymbal Reverse Cymbal Reverse Cymbal Reverse Cymbal Reverse Cymbal Ride Bell Shake Tambourne Splach Cymbal Th 808 Cowbell Crash Cymbal 2 Viltra-Hap Ride Cymbal 2 Low Borgo Copen High Conga Copen High Conga Copen Haph Conga Copen Low Conga High Angoga Low Whitel High Angoga Low Whitel Short Gairo Low Modga Short High Whitel Long Low Whitel Short Gairo Long Giro Cabesa High Wood Block Low Wood Block Low Hood Block Ling Hoo Rick() Low Hood Block Low Hood Bl	TR-808 Crash Cymbal CR. 78 High Yon 1 TR-606 Nide Cymbal Chrisece Cymbal Ride Bell CR. 78 Lambourine Spiach Cymbal Ride Bell CR. 78 Lambourine Spiach Cymbal Ride Bell TR-909 Crash Cymbal CR. 78 Low Boxpo TR-808 More High TR-909 Crash Cymbal TR-808 Cymbal TR-909 Cymb	18.808 Crask Cymbal 18.406 Filed Crask Cymbal 18.406 Filed Cymbal Ohinese Cymbal Ridd Siled Cymbal Ohinese Cymbal Ridd Siled Cymbal Ohinese Cymbal Ridd Siled Cymbal Ohinese Cymbal 18.408 Crash Cymbal 18.409 Crash 18.409 Crash 18.409 Crash 18.409 Crash 18.409 Crash 18.409 Crash 18.400	18-806 Cash Cymbal 18-807 High Tom 1* 18-909 Acts Cymbal Ohinese Cymbal Ride Bell Tambourine 2 Splain Cymbal Splain Cymbal Tambourine 2 Splain Cymbal Tambourine 2 Splain Cymbal Tambourine 2 Splain Cymbal Tambourine 2 Splain Cymbal Cash Cymbal Cash Cymbal Low Brogo Splain Low Brogo Copen Low Corga High Tambale Low Brogo Copen Low Corga High Tambale Low Brogo Copen Low Google High Mong Splain Ride Bell High Agogo Low Whitels Short Gains Long Guiro Clases High Wood Block Low Wood Block High Mong Ext 4 Low Hoo (Ext 4) Low Hoo	TR-909 Crash Cymbal TR-909 High Cymbal Chisec Cymbal Chisec Cymbal Chisec Cymbal Chisec Cymbal TR-808 High Compa Transburne 2 Solah Cymbal TR-808 Cowbel Crash Cymbal Low Boxgo Compa High Conga Open Low Conga High Conga Open Low Conga High Apogo Low Timbale Low Timbale Low High Apogo Cobbsa Cobbsa Cobbsa Sobri High Whistile Long Low Whistile Low Hoog EXC4 Low Hoo EXC4 Low Hoo EXC4 TR-808 Maraca Trinspile Bect Tree Castaneers Minter Suriou	Crash (ymball High Tom 1 Ride Cymbal Inner Chinese Cymbal Ride Cymbal Ride Bell Jambourine Splank Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal
0		IT AGE High Ton 1 * Rode Cymbal 1 Rode Cymbal 1 Rode Synnau 1 Rode Servers Cymbal Rode Bell Rode Bell Rode Bell Ta-Bell Consteel Rode Synnau Ta-Bell Consteel Ta-Bell Marter High Conga Ta-Bell Marter High Angon Ta-Bell Marter High Angon Ta-Bell Marter High Angon Ta-Bell Marter High Angon Ta-Bell Marter High Tong Ta-Bell Tong Ta-	Rower injih Tom 1 ** Ride Cymbal 1 Ride Cymbal 1 Ride Cymbal 1 Ride Reiman 1 Ride Cymbal 2 Vibra-Nap 1 Ride Cymbal 2 High Bongo Low High Conga Open Liel Conga Open Liel Conga Low Ride Conga Low	Electric High Tom 1* Reverse Cymbal 1 Reverse Cymbal 1 Reverse Cymbal Reverse Cymbal Ride Bell Tambourine Splant Cymbal Contebel Splant Cymbal Contebel Splant Cymbal 2 Vibra-Nap Ride Cymbal 2 High Bongo Low Bongo Charles High Conga Open Lew Conga High Tombal 2 Low Bingh Conga Open Lew Conga High Timbale Low Timbale High Agogo Low Agogo Cabasa Maraca: Short High Whistial Long Guiro Cabasa Maraca: Maraca High Whistial Long Guiro Cabasa Maraca High Revenue Cabasa Maraca Maraca High Revenue Cabasa Maraca Maraca Ma	TR-808 High Tom 1 * TR-808 High Tom 1 * TR-606 Ride Cymbal Th-606 Ride Cymbal Ride Bell Tree Solah Cymbal Ride Bell Tree Solah Cymbal Ride Bell Tree Solah Cymbal Tree Solah Cymbal Tree Solah Cymbal Tree Solah Cymbal Lide Cymbal Edge CR-7a High Bengo CR-7a High Bengo RR-808 Mote High Conga TR-808 Mote High Conga TR-808 Mote High Conga TR-809 Cape High Timbale Low Timbale High Agogo Low Agogo Cabra Cape High Timbale Low Timbale High Agogo High Timbale Conga High Timbale Low Timbale High Agogo High Timbale Conga High Timbale Low Timbale High Agogo High Timbale Conga High Agogo High Timbale Low Timbale High Agogo Hi	IR RBIG Crash Cymbal Beetir High Tom 1* High Son 1* High Song Low Robel Crash Cymbal Ride Cymbal Ride Cymbal Ride Cymbal 2 High Bong Low Robel Crash Cymbal 2 High Bong Ride Cymbal 2 High Bong Ride Cymbal 2 High Bong Ride Cymbal 2 High Rong Ride Cymbal 2 High Rong Ride Cymbal 2	TR-808 Crash Cymbal CR 78 High Yom 1 TR 608 Nets Cymbal Chniese Cymbal Chniese Cymbal Chniese Cymbal Ride Bell CR 78 Tambourine Splash Cymbal CR 78 Cowbel TR-909 Crash Cymbal TR-908 Trash Trash TR-909 Crash Cymbal TR-908 Trash TR-908 Crash TR-908 Cra	18.808 Crask Cymbal TR 4006 Righ Tom 1 TR 4006 Righ Tom 1 TR 4006 Righ Cymbal Dhinese Cymbal Ride Righ CR 78 Tombouries Splach Cymbal CR 78 Combell TR 999 Crash Cymbal Ride Cymbal CR 78 Combell TR 999 Crash Cymbal White - Hap Ride Cymbal Edge CR 78 Righ Bongo AT 988 Mare Righ Cong. AT 808 Cpan Righ Bongo AT 988 Mare Righ Cong. AT 988 Cpan Righ Bongo TR 988 Cpan Righ Tombale Low Right Line Windle Righ Agogo Low Agogo CR 98 Right CR 98 Righ CR 98 Right CR 98 R	17.400 Cash Cymbal 17.407 High Tom 1* 17.407 High Tom 1* 17.409 Acts Cymbal Chinese Cymbal Ambourine 2 Solain Cymbal 18.408 Acts 18.408 Ac	TR-896 Crash Cymbal TR-896 High Twee TR-896 High Twee Tree Tree Tree Tree Tree Tree Tree	Crash Cymball High Tom 1 Ride Cymbal Inner Chinese Cymbal Ride Lell Jambourine Splain Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Cymbal Cymbal Cymbal Cymbal Cymbal Cymbal Cymbal Low Bongo Low Bongo Low Bongo Muter High Conga Open High Conga Open High Conga Open Low Conga High Timbale Low Bongo Low Apago Cabase Maracas Short High Whitele Long Low Whistle Short Guiro Long Gairo Claver High Wood Block Low Hong Gairo Claver High Wood Block Low Hong Block Low Hong Gairo Claver High Wood Block Low Hong Block Low Hong High High High Hong High High High Hong High High High Hong High High High Hong High
0		IT AGE High Ton 1 * Rode Cymbal 1 Rode Cymbal 1 Rode Synnau 1 Rode Servers Cymbal Rode Bell Rode Bell Rode Bell Ta-Bell Consteel Rode Synnau Ta-Bell Consteel Ta-Bell Marter High Conga Ta-Bell Marter High Angon Ta-Bell Marter High Angon Ta-Bell Marter High Angon Ta-Bell Marter High Angon Ta-Bell Marter High Tong Ta-Bell Tong Ta-	Rower injih Tom 1 ** Ride Cymbal 1 Ride Cymbal 1 Ride Cymbal 1 Ride Reiman 1 Ride Cymbal 2 Vibra-Nap 1 Ride Cymbal 2 High Bongo Low High Conga Open Liel Conga Open Liel Conga Low Ride Conga Low	Electric High Tom 1* Reverse Cymbal 1 Reverse Cymbal 1 Reverse Cymbal Reverse Cymbal Ride Bell Tambourine Solath Cymbal Cooebel Creat Gymbal 2 Vibra-Hap Ride Symbal 2 Vibra-Hap Ride Cymbal 2 High Rongo Low Bongo Low Bongo Den High Congal Open High Congal Open High Congal Open High Congal Open High Congal Com Angole Low Angole Cabasa Maracas American Cabasa Maracas Companies Companies Cabasa Maracas Companies Cabasa Maracas Maracas Maracas Cabasa Maracas Maracas Maracas Cabasa C	TR-808 High Tom 1 * TR-808 High Tom 1 * TR-606 Ride Cymbal Th-606 Ride Cymbal Th-606 Ride Cymbal Ride Bell The Cr. 28 Tambourine Solash Cymbal Th-806 Code Cr. 28 Tambourine Solash Cymbal Tr. 2909 Cash Cymbal Vilzra-ilap Kind Cymbal Tr. 2909 Cash Cymbal Vilzra-ilap Kind Cymbal Edge CR-78 High Bongo CR-78 High Bongo CR-78 High Bongo TR-800 Ride Gymbal Fidge Crybal Fidge Fidge Crybal Fidge Fi	IR MBR Crash Cymbal Beetir High Tom 1* High Son 1* High Song Low Appal 2 High Bong Low Appal 2 High Bong Low Appal 2 High Bong Low Bong High Craph Cymbal 2 High Bong Low Appal 2 High Song Low Appal 2 High Song Low Appal 2 High Tonga Open High Conga Open Low Appal High Timbale Low Appal Low Appal Low Appal High Timbale Low High High Appal Low Appal Low Appal Low Appal High Whole Block High Hole Sinch Low Goog Glaro Claves High Whold Block High Hole Block High Hol	TR-808 Crash Cymbal CR 78 High Yom 1 TR 608 Nets Cymbal Chniese Cymbal Chniese Cymbal Chniese Cymbal Ride Bell CR 78 Tambourine Splash Cymbal CR 78 Cowbel TR-909 Crash Cymbal TR-908 Trash Trash TR-909 Crash Cymbal TR-908 Trash TR-908 Crash TR-908 Cra	18.808 Crask Cymbal TR 4006 Righ Tom 1 TR 4006 Righ Tom 1 TR 4006 Righ Cymbal Dhinese Cymbal Ride Righ CR 78 Tombouries Splach Cymbal CR 78 Combell TR 999 Crash Cymbal Ride Cymbal CR 78 Combell TR 999 Crash Cymbal White - Hap Ride Cymbal Edge CR 78 Righ Bongo AT 988 Mare Righ Cong. AT 808 Cpan Righ Bongo AT 988 Mare Righ Cong. AT 988 Cpan Righ Bongo TR 988 Cpan Righ Tombale Low Right Line Windle Righ Agogo Low Agogo CR 98 Right CR 98 Righ CR 98 Right CR 98 R	17.400 Cash Cymbal 17.407 High Tom 1* 17.407 High Tom 1* 17.409 Acts Cymbal Chinese Cymbal Ambourine 2 Solain Cymbal 18.408 Acts 18.408 Ac	TR-896 Crash Cymbal TR-896 High Trey TR TR-896 Crash Cymbal Tambourne 2 Splan Cymbal Tambourne 2 Splan Cymbal Tambourne 2 Splan Cymbal Tr TR-896 Combal Tr TR-896 Combal Tr TR-896 Combal Tr TR-896 Combal Tr TR-896 Crash Tr TR-896 Tr	Crash (ymball High Tom 1 Ride Cymbal Inner Chinese Cymbal Ride Cymbal Ride Bell Jambourine Splank Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal
8		IT AGE High Ton 1 * Rode Cymbal 1 Rode Cymbal 1 Rode Synnau 1 Rode Servers Cymbal Rode Bell Rode Bell Rode Bell Ta-Bell Consteel Rode Synnau Ta-Bell Consteel Ta-Bell Marter High Conga Ta-Bell Marter High Angon Ta-Bell Marter High Angon Ta-Bell Marter High Angon Ta-Bell Marter High Angon Ta-Bell Marter High Tong Ta-Bell Tong Ta-	Rower High Torn 1 1 Rade Lymbal 1 Rade Lymbal 1 Chanese Cymbal Rade Bell Tambburine Splech Cymbal Cowbeel Splech Cymbal Cowbeel Splech Cymbal Cowbeel Rade Bell Tambburine Splech Cymbal 2 Vibra-Hap Rade Cymbal 2 Vibra-Hap Rade Cymbal 2 High Bongo Low Bongo Low Bongo Cymr High Conga Low Groga High Timbale Low Timbale High Agogo Coban Marte Culta Cong Low Groga High Whole Short High Whistle Long Guillo Choves High Whod Block Low Wood Block Marte Culta Cymr Limagle Cymr Timagle Splect Timagle Cymr Timagle Splect Finnigle Bell Bell Tree Cartarnetts Marte Storio Cymr Jordon Cymr Jordon Cymr Jordon Cymr Cortan Marte Storio Cymr Timagle Splect Finnigle Bell Bell Tree Cartarnetts Matte Storio Cymp Nurrido Applature 2	Electric High Tom 1* Reverse Cymbal 1 Reverse Cymbal 1 Reverse Cymbal Reverse Cymbal Ride Bell Tambourine Splath Cymbal Cowbeal Ride Bell Tambourine Splath Cymbal Cowbeal Ride Bell Ride Bell Ride Bell Ride Symbal 2 High Bongo Low Bongo Com High Conga Open Hegh Conga High Timbale Ride Cymbal 2 Low Timbal Ride Cymbal 2 Low Timbal Ride Cymbal 2 Low Timbal Ride Conga High Timbale Ride Conga High Timbale Ride Compa Low Apopo Cabbas Short High Whistle Long Guiro Cong Guiro Cong Guiro Cong Guiro Cong Guiro Cong Guiro Copen Culca Must Culca Open Culca Must Palage Ride Ride Ride Ride Ride Ride Ride Rid	TR-808 High Tom 1 * TR-808 High Tom 2 * TR-908 High Tom 3 * TR-908 High Tom 4 * TR-908	IR MBR Crash Cymbal Beetir High Tom 1* High Son 1* High Song Low Appal 2 High Bong Low Appal 2 High Bong Low Appal 2 High Bong Low Bong High Craph Cymbal 2 High Bong Low Appal 2 High Song Low Appal 2 High Song Low Appal 2 High Tonga Open High Conga Open Low Appal High Timbale Low Appal Low Appal Low Appal High Timbale Low High High Appal Low Appal Low Appal Low Appal High Whole Block High Hole Sinch Low Goog Glaro Claves High Whold Block High Hole Block High Hol	TR-808 Crash Cymbal GN 78 High Yon 1 TR 608 hide Cymbal Chneec Cymbal Ride Bell Ch-78 Tambounne Spidas Openal GN 78 Cookbel TR-507 Cookbel TR-507 Cookbel TR-507 Crash Cymbal Viltra-High Ride Cymbal Crash Crash Gymbal Ch-78 Cookbel TR-507 Crash Cymbal Viltra-High Ride Cymbal Cidge TR-508 High Bongo CN-78 Low Bongo CN-78 Low Bongo TR-508 High Bongo CN-78 Low Bongo TR-508 High Bongo CN-78 Low Bongo TR-508 High Crash High Mystal Low Timbale Low Timbale Low Timbale Low Timbale Low Timbale Low Hopo Cabasa Short High Whittle Long Low Whotel Short Gairo CR-78 Gairos High Whittle Low Hopo GN-78 Gairos High Wood Block Low Wood Block To-78 Gairos High Wood Block Low Wood Block To-78 Gairos CR-78 Low Beat [EXCS] CR-78 High Host [EXCS] CR-78 Low Beat	18.808 Crask Cymbal TR 4006 Righ Tom 1 TR 4006 Righ Tom 1 TR 4006 Righ Cymbal Dhinese Cymbal Ride Righ CR 78 Tombouries Splach Cymbal CR 78 Combell TR 999 Crash Cymbal Ride Cymbal CR 78 Combell TR 999 Crash Cymbal White - Hap Ride Cymbal Edge CR 78 Righ Bongo AT 988 Mare Righ Cong. AT 808 Cpan Righ Bongo AT 988 Mare Righ Cong. AT 988 Cpan Righ Bongo TR 988 Cpan Righ Tombale Low Right Line Windle Righ Agogo Low Agogo CR 98 Right CR 98 Righ CR 98 Right CR 98 R	18-805 Cash Cymbal 18-807 High Trom 1* 18-809 Ande Cymbal Chinese Cymbal Ride Sell Sanda Sell Sanda Cymbal Crash Cymbal TR-808 Carbon Selau Cymbal TR-808 Carbon TR-808 Ca	TR-906 Crash Cymbal TR-906 High Tree TR-906 High Tree TR-906 High Tree TR-906 High Tree Tree Tree Tree Tree Tree Tree Tree	Crash (ymball High Tom 1 Ride Cymbal Inner Chinese Cymbal Ride Cymbal Ride Gell Jambourine Sodah Cymbal Cowbell Cowbel
8		IT AGE High Ton 1 * Rode Cymbal 1 Rode Cymbal 1 Rode Cymbal 1 Rode Sel Rode Cymbal 1 Rode Sel 1 Rode Cymbal 2 Ch. 71 High Bongo TR AGE Murt High Congo TR AGE TR AGE CONGO TR AGE T	Rower isigh Tom 1 ** Ride Symbal 1 Christe Cymbal 1 Christe Cymbal 1 Ride Beil 1 Cambourine Splash Cymbal 2 Vibra-lap 1 Ride Beil 1 Cambourine Splash Cymbal 2 Vibra-lap 1 Ride Ride (mmhal 2 Vibra-lap 1 Ride Cymbal 2 Vibra-lap 1 Ride Cymbal 2 High Bongo Low High Long Low High Long Low High Long Low High Long Low High Low Bongo Low High Low Bong Low High Long Low High Low	Electric High Tom 1* Reverse Cymbal 1 Reverse Cymbal 1 Reverse Cymbal Reverse Cymbal Ride Bell Tambourine Solath Cymbal Cooebel Creat Gymbal 2 Vibra-Hap Ride Symbal 2 Vibra-Hap Ride Cymbal 2 High Rongo Low Bongo Low Bongo Den High Congal Open High Congal Open High Congal Open High Congal Open High Congal Com Angole Low Angole Cabasa Maracas American Cabasa Maracas Companies Companies Cabasa Maracas Companies Cabasa Maracas Maracas Maracas Cabasa Maracas Maracas Maracas Cabasa C	TR-808 High Tom 1 * TR-608 Ride Cymbal Chinese Cymbal Chinese Cymbal Ride Beil The Solah Cymbal Ride Beil The Solah Cymbal Ride Beil TR-909 Cash Cymbal Mbrz-elsp TR-808 Cowbell TR-909 Cash Cymbal Ride Cymbal Ride Cymbal Ride Cymbal TR-808 Ride Ride TR-800 Cowb Corga High Timbale Low Apopo Low Apopo Lobata TR-800 Ride Timbale Low High TR-808 Cowbell Tringle TR-808 Salaker Inigh Hool Elick Timbale Low High Hool Tringle TR-808 Cowbell Tringle TR-808 Salaker Inigh Hool Tringle TR-808 Salaker Inigh Hool Tringle Tringl	IR MBR Crash Cymbal Beetir High Tom 1* High Son 1* High Song Low Appal 2 High Bong Low Appal 2 High Bong Low Appal 2 High Bong Low Bong High Craph Cymbal 2 High Bong Low Appal 2 High Song Low Appal 2 High Song Low Appal 2 High Tonga Open High Conga Open Low Appal High Timbale Low Appal Low Appal Low Appal High Timbale Low High High Appal Low Appal Low Appal Low Appal High Whole Block High Hole Sinch Low Goog Glaro Claves High Whold Block High Hole Block High Hol	TR-808 Crash Cymbal GN 78 High Yon 1 TR 608 hide Cymbal Chneec Cymbal Ride Bell Ch-78 Tambounne Spidas Openal GN 78 Cookbel TR-507 Cookbel TR-507 Cookbel TR-507 Crash Cymbal Viltra-High Ride Cymbal Crash Crash Gymbal Ch-78 Cookbel TR-507 Crash Cymbal Viltra-High Ride Cymbal Cidge TR-508 High Bongo CN-78 Low Bongo CN-78 Low Bongo TR-508 High Bongo CN-78 Low Bongo TR-508 High Bongo CN-78 Low Bongo TR-508 High Crash High Mystal Low Timbale Low Timbale Low Timbale Low Timbale Low Timbale Low Hopo Cabasa Short High Whittle Long Low Whotel Short Gairo CR-78 Gairos High Whittle Low Hopo GN-78 Gairos High Wood Block Low Wood Block To-78 Gairos High Wood Block Low Wood Block To-78 Gairos CR-78 Low Beat [EXCS] CR-78 High Host [EXCS] CR-78 Low Beat	18.808 Crask Cymbal TR 4006 Righ Tom 1 TR 4006 Righ Tom 1 TR 4006 Righ Cymbal Dhinese Cymbal Ride Righ CR 78 Tombouries Splach Cymbal CR 78 Combell TR 999 Crash Cymbal Ride Cymbal CR 78 Combell TR 999 Crash Cymbal White - Hap Ride Cymbal Edge CR 78 Righ Bongo AT 988 Mare Righ Cong. AT 808 Cpan Righ Bongo AT 988 Mare Righ Cong. AT 988 Cpan Righ Bongo TR 988 Cpan Righ Tombale Low Right Line Windle Righ Agogo Low Agogo CR 98 Right CR 98 Righ CR 98 Right CR 98 R	18-805 Cash Cymbal 18-807 High Trom 1* 18-809 Ande Cymbal Chinese Cymbal Ride Sell Sanda Sell Sanda Cymbal Crash Cymbal TR-808 Carbon Selau Cymbal TR-808 Carbon TR-808 Ca	TR-906 Crash Cymbal TR-906 High Tree TR-906 High Tree TR-906 High Tree Tree Tree Tree Tree Tree Tree Tree	Crash Cymball High Tom T Ride Cymbal Inner Chinese Cymbal Ride Cymbal Ride Bell Tambourine Splank Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal
8		IT ASS High Ton 1 * Rode Cymbal 1 Rode Symbal 1 Rode Self Self Self Self Self Self Self Sel	Rower isigh Tom 1 ** Ride Symbal 1 Christe Cymbal 1 Christe Cymbal 1 Ride Beil 1 Cambourine Splash Cymbal 2 Vibra-lap 1 Ride Beil 1 Cambourine Splash Cymbal 2 Vibra-lap 1 Ride Ride (mmhal 2 Vibra-lap 1 Ride Cymbal 2 Vibra-lap 1 Ride Cymbal 2 High Bongo Low High Long Low High Long Low High Long Low High Long Low High Low Bongo Low High Low Bong Low High Long Low High Low	Electric High Tom 1* Reverse Cymbal 1 Reverse Cymbal 8 Ride Reb 1 Reverse Cymbal 8 Ride Rell Tambourine Solant Cymbal Conebell High Congal Open High Congal Copen Low Grogal High Timbale Low Timbale Low Timbale Low Timbale Low Timbale Long Low Whistiel Short High Whistiel Long Low Whistiel Short Girls Conebell Maracas Short High Whistiel Long Low Whistiel Short Girls Conebell Conebel	TR-808 High Tom 1 * TR-608 Ride Cymbal Chinese Cymbal Chinese Cymbal Ride Beil The Solah Cymbal Ride Beil The Solah Cymbal Ride Beil TR-909 Cash Cymbal Mbrz-elsp TR-808 Cowbell TR-909 Cash Cymbal Ride Cymbal Ride Cymbal Ride Cymbal TR-808 Ride Ride TR-800 Cowb Corga High Timbale Low Apopo Low Apopo Lobata TR-800 Ride Timbale Low High TR-808 Cowbell Tringle TR-808 Salaker Inigh Hool Elick Timbale Low High Hool Tringle TR-808 Cowbell Tringle TR-808 Salaker Inigh Hool Tringle TR-808 Salaker Inigh Hool Tringle Tringl	IR MBR Crash Cymbal Beetir High Tom 1* High Son 1* High Song Low Appal 2 High Bong Low Appal 2 High Bong Low Appal 2 High Bong Low Bong High Craph Cymbal 2 High Bong Low Appal 2 High Song Low Appal 2 High Song Low Appal 2 High Tonga Open High Conga Open Low Appal High Timbale Low Appal Low Appal Low Appal High Timbale Low High High Appal Low Appal Low Appal Low Appal High Whole Block High Hole Sinch Low Goog Glaro Claves High Whold Block High Hole Block High Hol	TR-808 Crash Cymbal GN 78 High Yon 1 TR 608 hide Cymbal Chneec Cymbal Ride Bell Ch-78 Tambounne Spidas Openal GN 78 Cookbel TR-507 Cookbel TR-507 Cookbel TR-507 Crash Cymbal Viltra-High Ride Cymbal Crash Crash Gymbal Ch-78 Cookbel TR-507 Crash Cymbal Viltra-High Ride Cymbal Cidge TR-508 High Bongo CN-78 Low Bongo CN-78 Low Bongo TR-508 High Bongo CN-78 Low Bongo TR-508 High Bongo CN-78 Low Bongo TR-508 High Crash High Mystal Low Timbale Low Timbale Low Timbale Low Timbale Low Timbale Low Hopo Cabasa Short High Whittle Long Low Whotel Short Gairo CR-78 Gairos High Whittle Low Hopo GN-78 Gairos High Wood Block Low Wood Block To-78 Gairos High Wood Block Low Wood Block To-78 Gairos CR-78 Low Beat [EXCS] CR-78 High Host [EXCS] CR-78 Low Beat	18.808 Crask Cymbal TR 4006 Righ Tom 1 TR 4006 Righ Tom 1 TR 4006 Righ Cymbal Dhinese Cymbal Ride Righ CR 78 Tombouries Splach Cymbal CR 78 Combell TR 999 Crash Cymbal Ride Cymbal CR 78 Combell TR 999 Crash Cymbal White - Hap Ride Cymbal Edge CR 78 Righ Bongo AT 988 Mare Righ Cong. AT 808 Cpan Righ Bongo AT 988 Mare Righ Cong. AT 988 Cpan Righ Bongo TR 988 Cpan Righ Tombale Low Right Line Windle Righ Agogo Low Agogo CR 98 Right CR 98 Righ CR 98 Right CR 98 R	18-805 Cash Cymbal 18-807 High Trom 1* 18-809 Ande Cymbal Chinese Cymbal Ride Sell Sanda Sell Sanda Cymbal Crash Cymbal TR-808 Carbon Selau Cymbal TR-808 Carbon TR-808 Ca	TR-906 Crash Cymbal TR-906 High Tree TR-906 High Tree TR-906 High Tree Tree Tree Tree Tree Tree Tree Tree	Crash (ymball High Tom 1 Red Cymbal Inner Chinese Cymbal Red Cymbal Inner Chinese Cymbal Ride Eyll Inner Chinese Cymbal Ride Eell Inner Chinese Cymbal Ride Eell Inner Chinese Cymbal Cowbell
D 6		IT AGE High Ton 1 * Rode Cymbal 1 Rode Cymbal 1 Rode Cymbal 1 Rode Sel Romero Cymbal Rode Sell T-Ball Combal T-Bal	Rower isigh Tom 1 ** Ride Symbal 1 Christe Cymbal 1 Christe Cymbal 1 Ride Beil 1 Cambourine Splash Cymbal 2 Vibra-lap 1 Ride Beil 1 Cambourine Splash Cymbal 2 Vibra-lap 1 Ride Ride (mmhal 2 Vibra-lap 1 Ride Cymbal 2 Vibra-lap 1 Ride Cymbal 2 High Bongo Low High Long Low High Long Low High Long Low High Long Low High Low Bongo Low High Low Bong Low High Long Low High Low	Electric High Tom 1* Reverse Cymbal 1 Reverse Cymbal 8 Ride Reb 1 Reverse Cymbal 8 Ride Rell Tambourine Solant Cymbal Conebell High Congal Open High Congal Copen Low Grogal High Timbale Low Timbale Low Timbale Low Timbale Low Timbale Long Low Whistiel Short High Whistiel Long Low Whistiel Short Girls Conebell Maracas Short High Whistiel Long Low Whistiel Short Girls Conebell Conebel	TR-808 High Tom 1 * TR-608 Ride Cymbal Chinese Cymbal Chinese Cymbal Ride Beil The Solah Cymbal Ride Beil The Solah Cymbal Ride Beil TR-909 Cash Cymbal Mbrz-elsp TR-808 Cowbell TR-909 Cash Cymbal Ride Cymbal Ride Cymbal Ride Cymbal TR-808 Ride Ride TR-800 Cowb Corga High Timbale Low Apopo Low Apopo Lobata TR-800 Ride Timbale Low High TR-808 Cowbell Tringle TR-808 Salaker Inigh Hool Elick Timbale Low High Hool Tringle TR-808 Cowbell Tringle TR-808 Salaker Inigh Hool Tringle TR-808 Salaker Inigh Hool Tringle Tringl	IR MBR Crash Cymbal Beetir High Tom 1* High Son 1* High Song Low Appal 2 High Bong Low Appal 2 High Bong Low Appal 2 High Bong Low Bong High Craph Cymbal 2 High Bong Low Appal 2 High Song Low Appal 2 High Song Low Appal 2 High Tonga Open High Conga Open Low Appal High Timbale Low Appal Low Appal Low Appal High Timbale Low High High Appal Low Appal Low Appal Low Appal High Whole Block High Hole Sinch Low Goog Glaro Claves High Whold Block High Hole Block High Hol	TR-808 Crash Cymbal GN 78 High Yon 1 TR 608 hide Cymbal Chneec Cymbal Ride Bell Ch-78 Tambounne Spidas Openal GN 78 Cookbel TR-507 Cookbel TR-507 Cookbel TR-507 Crash Cymbal Viltra-High Ride Cymbal Crash Crash Gymbal Ch-78 Cookbel TR-507 Crash Cymbal Viltra-High Ride Cymbal Cidge TR-508 High Bongo CN-78 Low Bongo CN-78 Low Bongo TR-508 High Bongo CN-78 Low Bongo TR-508 High Bongo CN-78 Low Bongo TR-508 High Crash High Mystal Low Timbale Low Timbale Low Timbale Low Timbale Low Timbale Low Hopo Cabasa Short High Whittle Long Low Whotel Short Gairo CR-78 Gairos High Whittle Low Hopo GN-78 Gairos High Wood Block Low Wood Block To-78 Gairos High Wood Block Low Wood Block To-78 Gairos CR-78 Low Beat [EXCS] CR-78 High Host [EXCS] CR-78 Low Beat	18.808 Crask Cymbal TR 406 High Tom 1 TR 406 Hig	18-805 Cash Cymbal 18-807 High Trom 1* 18-809 Ande Cymbal Chinese Cymbal Ride Sell Sanda Sell Sanda Cymbal Crash Cymbal TR-808 Carbon Selau Cymbal TR-808 Carbon TR-808 Ca	TR-906 Crash Cymbal TR-906 High Tree TR-906 High Tree TR-906 High Tree Tree Tree Tree Tree Tree Tree Tree	Crash (ymbal) High Tom T Ride Cymbal Inner Chinese Cymbal Ride Cymbal Ride Bell Tambourine Splank Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal
C		IT ASS High Ton 1 * Rode Cymbal 1 Rode Septimbal 1 Rode S	Rower High Torn 1 1 Ride Cymbal 1 Ride Cymbal 1 Chmese Cymbal Ride Bell Tambburine Splesh Cymbal Cowbell Splesh Cymbal Cowbell Splesh Cymbal Cowbell Ride Bell Tambburine Splesh Cymbal 2 Vibra-High Ride Cymbal 2 Vibra-High Ride Cymbal 2 Vibra-High Ride Cymbal 2 High Bongo Low Bongo Cymr High Conga Low Groga High Timbale Low Timbale High Agogo Cobate Short High Whistle Low Timbale High Agogo Cobate Marson Marson Marson Marson Marson Short High Whistle Long Guillo Chores High Wood Block Low Wood Block Marte Cular Cymr Timogle Cymr Timogle Splesh Timogle Cymr Timogle C	Electric High Tom 1* Reverse Cymbal 1 Reverse Cymbal 8 Ride Reb 1 Reverse Cymbal 8 Ride Rell Tambourine Solant Cymbal Conebell High Congal Open High Congal Copen Low Grogal High Timbale Low Timbale Low Timbale Low Timbale Low Timbale Long Low Whistiel Short High Whistiel Long Low Whistiel Short Girls Conebell Maracas Short High Whistiel Long Low Whistiel Short Girls Conebell Conebel	TR-808 High Tom 1 * TR-608 Ride Cymbal Chinese Cymbal Chinese Cymbal Ride Beil The Solah Cymbal Ride Beil The Solah Cymbal Ride Beil TR-909 Cash Cymbal Mbrz-elsp TR-808 Cowbell TR-909 Cash Cymbal Ride Cymbal Ride Cymbal Ride Cymbal TR-808 Ride Ride TR-800 Cowb Corga High Timbale Low Apopo Low Apopo Lobata TR-800 Ride Timbale Low High TR-808 Cowbell Tringle TR-808 Salaker Inigh Hool Elick Timbale Low High Hool Tringle TR-808 Cowbell Tringle TR-808 Salaker Inigh Hool Tringle TR-808 Salaker Inigh Hool Tringle Tringl	IR HBR Crash Cymbal Beetin High Tom 1* HBR Crash Cymbal Revene Cymbal Revene Cymbal Revene Cymbal Revene Cymbal Revene Cymbal Red Bell Shale Fambourne Spish Cymbal Th 808 Cowbell Crash Cymbal Th HBR Crash Cymbal HBR Crash	TR-808 Crash Cymbal GR 78 High You 1 TR 606 hide Cymbal Chnives Cymbal Chnives Cymbal Chnives Cymbal Ride Bell CR-78 Tambounne Spidas Cymbal CR-78 Tambounne Spidas Cymbal TR-897 Spidas Cymbal TR-897 Spidas Cymbal TR-897 Spidas Cymbal TR-898 Spidas Cymbal TR-898 Spidas Cymbal TR-898 Spidas Cymbal TR-898 Spidas Trymbal TR-898 Spidas TR-898	18.808 Crask Cymbal TR 406 High Tom 1 TR 406 Hig	1R-806 Cash Cymbal TR-807 High Trom 1* TR-907 And Cymbal Chinese Cymbal Rode Sell Tambourine 2 Solauh Cymbal Tambourine 2 Solauh	TR-890 Fish Crash Cymbal TR-890 Fish TR-990 Fish Crash Cymbal TR-890 Fish Fish TR-890 Fish Fish TR-890 Fish Crash TR-890 Fish Crash Tranbourne 2 Soliah Cymbal TR-890 Crash Cymbal TR-890 May Tranbol TR-890 May Tranbol T	Crash (ymball High Tom 1 Ride Cymbal Inner Chinese Cymbal Ride Cymbal Ride Bell Jambaurine Splank Cymbal Crash Cymbal Low Rongo Copen High Conga Open Low Conga High Conga Open Low Conga High Ronga Copen Low Conga High Whitsle Lom Guow Whitsle Short Guiro Long Guiro Claver High Wood Block Low Wood Block Low Wood Block Low Wood Block Marte Craica Chare High Wood Block Low Wood Block Marte Craica Chare High Wood Block Marte Craica Marte Triangle Cipen Triangle Cipen Triangle Cipen Triangle Cipen Triangle Cipen String Copen String

		BRUSH	PC: 49 (CC32: 3) ORCHESTRA							PC: 59 (CC32: 3) Rhythm FX 2	PC: 128 [CC32: 3] CM-64/32L
C-1 0		[#2] Standard 1 Kick 1	[#2] Standard 1 Kick 1		-					-	***
-		[62] Standard 1 Kick 2	[62] Standard 1 Kick 2				-	-			-
2		(#2) Standard 7 Kick 1	[#2] Standard 2 Kick 1					-			
Ī.		(#2) Standard 2 Kick 2	[62] Standard 2 Kick 2								···
1		[81] Kick Drum 1	#1 Kick Drum ! #1 Kick Drum 2						_		
5	-	(91) Kick Drum 2 (92) Jazz Kick 1	(#2) Jazz Kick 1				**		-		-
1,		[62] Jazz Kick 2	(#2) Jazz Kick 2								
Ľ	- 6	#2] Room Kick 1	[62] Room Kick 1	_	-	-	-	+			
9	,	(#2) Room Kut 2	[#2] Room Kick 2								
١.		[82] Power Kick 1	[42] Power Kick 1		-						
1	11	#2 Power Kick 2	[62] Power Kick 2	***				-	_		
C6 1	12	[#2] Electric Kick 2	[82] Electric Kick 2 [82] Electric Kick 1							**	
l,	4	[82] Electric Kick 1 [82] TR-808 Kick	JUZ TR-SOS Kick							-	
Ľ	15	(#2) TR-909 Kick	(#2) TR-909 Kick					_		-	-
h	16	(82) Dance Kick	[82] Dance Kick	_				-	_		
l,	17	Vake One	Voice One	_	_	-		_			
- [18	Vaice Two	Voice Two	_	-					-	
- 11	19	Voice Three	Voice Three							··	
l.						···	-			-	
1	27	***************************************	MC 500 Base 1		-	-		MC-500 Beep 2	_		
- 12	23	MC-500 Beep 1 MC-500 Beep 2	MC-500 Beep 1 MC-500 Beep 2		····	<u></u>		Guitar Slide	-		***
a	24 : 11	Concert SD	Concert 5D		_		-	Guitar Wah		-	-
	C Commissions	Source Roll	Snare Roll	Finger Snap	CR-78 Kick 1	Gemelen Gong C#		Guitar Slap	_		
	26 (1 1 2 2 2	Finger Snap	Finger Snap			-		Chord Strake Down			
Ĉ	27	High Q	Closed Hi-Hat 2 [EXC1]	Castanets		Gamelan Gong G		Chord Stroke Up			-
8	24	Slap	Pedal Hi-Hat [EXC1]	Crash Cymbal 1		Gamelan Gong All		Riwa * Phonograph Hose			
1	29	Scratch Push	Open Hi-Hat 2 (EXC1)	Snare Roll		Gamelan Gong c		Tape Rewind			-
		Scratch Pull	Ride Cymbal 1 Sticks	Concert SD Concert Cymbal		Gamelan Gong dil		Scratch Push 2 [EXC1]			_
	11 3 4 4	Sticks Source Click	Square Click	Concert BD 1		Gameian Gong g		Scratch Pull 2 (EXC1)			
		Metronome Click	Metronome Cick	Jingle Bell	Hi-Hop Kick 1	Gameian Gong all		Cutting Naise 2 Up	_		
į.	3.1	Metronome Bell	Metronome Bell	Beil Tree		Gamelan Gong C		Cutting Noise 2 Down	-		
	35	Jagz Kick Z	Jazz Kick 1	Bar Chimes		Gender CP		Distortion GustarCutting	- "		Kick 1
a	36	Jazz Kick 1	Concert 8D 1	Wadarko *	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	Gender D#	[#1] Closed Hitlat(EXC1)		Reverse Concert Bass	Reverse TR-707 Kick 1 Reverse TR-909 Kick 1	Side Stick
	362 550	Side Stick	Side Stick	Wadaiko Rim *			[#2] Clid Hi-Hat 2 (EXC1) [#2] Clid HiHat 3 (EXC1)		Reverse Power Kick 1	Reverse Hi-Hoo Kick 1	Fat Snare
	38: ATT	Brush Seare 1	Concert SD	Shime Taiko	Standard 1 Kick 2 Standard 1 Kick 1	Gender All Gender C	Closed Hi Hat 4 [EXC1]		Reverse Electric Kick 1	Reverse Jungle Kick 2	Hand Clap
ı		Brush Stap Brush Stare 2	Concert SD	Atarigane Hyoushigi	[#2] Standard 1 Kick 1	Bonang Co	Closed Hi-Hat (EXC1)	Slao	Reverse Snare 1	Reverse Techno Kick 2	Elec. Snare
ľ	42.5	Brush Low Torn 2 *	Timpani F	Ohkawa		Bonang De	TR-707 Clsd HiHat(EXC1)		Reverse Snare 2	Reverse TR-606 Snare 2	Tom
		Brush Closed Hi-Hat(EXC)		High Kotsuzumi	[#2] Standard 2 Kick 1	Bonang G	TR-606 Clsd HiHat[EXC1]	Scratch Pull [EXC7]	Reverse Standard 1	Reverse CR-78 Snare 1	Close Hillat
ľ	0135723	Brush Low Tom 1	Timpani G	Low Kotsuzumi	[#2] Standard 2 Kick 2	Bonang Af	[82] TR-806 Closed[EXC1	Sticks	Reverse Snare Drum 2	Reverse CR 78 Snare 2	Tom
Į	.;;	Pedal Hi-Hat (EXC1)	Timpani G#	Ban Gu	[#1] Kick Drum 1	Bonang c	TR-808 Clsd HiHat(EXC1)		Reverse Tight Snare	Reverse Jungle Snare 2	
	49 700 100	Brush Mid Tom 2 *	Timpani A	Biq Gong	(#1) Kick Drum 2	Thai Gong	CR-78 CladHiHat 3[EXC1]		Reverse 808 Snare	Reverse Techno Snare	Open Hi Hat
Ī	15	Brush Open Hi-Hat DICT		Small Gong	(#2) Soft Kick	Rama Cymbal	[#1] Pedal Hi-Hat [EXC]		Reverse Torn 2	Reverse TR-707 Snare 1 Reverse TR-606 Snare 1	Tom
- 1	46	Brush Mid Tom 1	Timpani B	Bend Gong	(#2) Jazz Kick 1 #2 Jazz Kick 2	Sagat Open Sagat Closed	#2 Pedal Hi-Hat [EXC] Pedal Hi-Hat [EXC]	Guitar Cutting Noise Up		Reverse TR-909 Snare 1	Tom
в	48	Brush High Tom 2 * Brush Crash Cymbal	Timpani c	Thai Gong Rama Cymbal	[#1] Concert 8D 1	Jaws Harp	Half-Open HiHat 1[EXC]		Reverse Slap	Reverse Hi-Hop Snare 2	GS Crash
1	101	Brush High Tore 1 *	Timpani d	Gameian Gong	(#2) Room Kick 1	Wadano *	Half-Open HiHat 2[EXC]		Reverse Cymbal 1	Reverse Jungle Snare 1	Tom
	1	Ride Cymbal Inner	Timpani dif	Udo Short [EXC1]	[#2] Room Kick 2	Wadaiko Rim *	[#1] Open HiHat [EXC1]		Reverse Cymbal 2	Reverse House Snare	Ride Cymbal
	57 70 10	Chinese Cymbai	Timpani e	Udo Long (EXC1)	(#2) Power Kick 1	Tako	(#2) Open HiHat 2(EXC)		Reverse Open Hi-Hat	Reverse Closed Hi-Hat	
	53	Brush Ride Bell	Timpani f	Udo Slap	(#2) Power Kick 2	Shimedaiko	[#2] Open HiHat 3[EXC1		Reverse Ride Cymbal	Reverse TR-606 Closed Reverse TR-707 Closed	Tambourine
l	5.0	Tambourine	Tambourine	Bendir	[#2] Electric Kick 2	Atarigane	Open Hi-Hat (EXC1) TR-909 OpHiHat(EXC1)	Punch Have Bass	Reverse CR-78 Open Reverse Closed Hi-Hat	Reverse TR-806 Closed	
-	95 PBREET	Splash Cymbal	Spiash Cymbal	Reg Dum	[#2] Electric Kick 1 *	Hyoushigi Ohkawa	TR-707 OpHiHat [EXC1]		Reverse Gong	Reverse Jungle Hi-Hat	Cowbell
1	57 01923 2061	Crash Cymbal 2	Concert Cymbal 2	Req Tik Tabla Te	(#2) TR-808 Kick	High Katsuzum:	TR-606OpHiHat [EXC1]		Reverse Bell Tree	Reverse Tambourine 2	
1	13	Vibra-siap	Vibra-slao	Tabla Na	[#2] TR-909 Kick	Low Kotsuzumi	[92] TR-808OpHiHat[EXC]		Reverse Guiro	Reverse Shake	
	59	Ride Cymbal 2	Concert Cymbal 1	Tabla Tun	[#2] Dance Kick	Yyoo Dude	TR-806 Open HiHat(EXC)		Reverse Bendir	Reverse TR-808 Open	
C4	60	High Bango	High Bongo	Tabla Ge	[#2] Standard 1 Snare 1	Buk	CR-78 Open HiHat EXC1	Door	Reverse Gun Shot	Reverse TR-707 Open	High Bango
		Law Bongo	Low Bongo	Tabla Ge Hi	(#2) Standard 1 Snare 2		Crash Cymbal 1 [EXC3]	Sciatch	Reverse Scratch	Reverse Open Hi-Hat	Low Bongo
	62	Mule High Conga	Mute High Conga	Talking Drum *	(#2) Standard 2 Snare 1		Crash Cymbal 2 [EXC4]	Wind Chimes	Reverse Laser Gun Key Click	Reverse TH-606 Open Reverse Hu Yin Luc	Mute Conga Conga
	63	Open High Conga	Open High Conga	Bend Taking Dium *	#2 Standard 2 Snare 2	Gengari Mute Low Gengari f	Crash Cymbal 3 Brush Crash Cymbal	Car Engine Car Stop	Tekno Thip	Reverse TR-707 Crash	· Conga
ļ	64	Open Low Conga	Open Low Conga	Caxixi Djembe	#1 Snare Drum 2 [#1] Concert Snare	Gengari Mute High	Hard Crash Cymbai	Car Passing	Pop Drop	Voice One	Timbalis
	65.	High Tembale Low Tembale	High Timbale Low Timbale	Diembe Rim	#2] Jazz Snare 1	Gengari Samil	TR-909 Crash Cymbal	Car Crash	Woody Slap	Reverse Voice One	Timbales
		High Agogo	High Agogo	Timbales Low	(#2) Jazz Snare 2	Jang-Gu Che	TR-808 Crash Cymbal	Siren	Distortion Kick *	Voke Two	Agogo
Ì	65	Low Agage	Low Agogo	Timbales Paila	[#2] Room Snare 1	Jang-Gu Kun	MuteCrashCyrribal1[EXC		Syn. Drops	Reverse Voice Two	Agogo
	69	Cabasa	Cabasa	Timbales High	[#2] Room Snare 2	lang-Gu Rim	MuteCrashCymbal2[EXC		Reverse Hi Q	Voice Thre	Cabasa
		Maracas	Maracas	Cowbell	[82] Power Snare 1	Jung p	Reverse Crash Cymbal 1		Pipe ke Block	Reverse Voice Three Voice Tah	Maracas ShrtWhistle
}	100 70 2	Short High Whistle	Short High Whistle	High Bongo	[#2] Power Share 2 [#1] Gated Share	ling 1 *	Reverse Crash Cymbal 2 Reverse Crash Cymbal 3		Digital Tambourine *	Reverse Voice Tah	LongWhistle
CS	加加斯	Long Low Whistle	Long Low Whistle Short Guiro	Low Bongo Mute High Conga	[#2] Dance Snare 1	Asian Gong 1	Reverse TR-909 Crash	Machine Gun	Alias	Voice Ou	Vibrasiap
-	Paris in the second	Short Guire Long Guire	Long Guiro	Open High Conga	[#2] Dance Snare 2	Big Gong	[#1] Splash Cymbal	Laser Gun	Modulated Bell	Vaice Au	-
. !	75	Claves	Claves	Mute Low Conga	[#2] Disco Snare	Small Gong	Splash Cymbal	Explosion	Spark	Voice Whey	Claves
	7 6	High Wood Block	High Wood Block	Conga Siap	[92] Electric Snare 2	Pai Ban	#2 Ricie Bell	Dog	Metallic Percussion	Frag Vpoce *	Laughing
1	η	Low Wood Black	Law Wood Block	Open Low Conga	[#2] House Snare *	Ban Gu	(#2) Brush Ride Bell	Horse-Gallop	Velocity Noise FX	Reverse Yyoo Dude	Screaming
1	/E	Mule Cuca	Mute Cuica	Conga Slide *	[#1] Electric Snare 1	Tang Gu	[82] Ride Cymbal 1	Birds Rain	Stereo Noise Clap * Swish	Bouby Reverse Douby	Punch Heart Beat
- 1	79	Open Cuica	Open Cuica	Mute Pandiero	[#2] Electric Snare 3 *	Tang Gu Mute Shou Luo *	[82] Ride Cymbal 2 [82] Brush Ride Cymbal	Thunder	Slappy *	Baert High	Footsteps
	EDAN SO	Mute Triangle	Mute Triangle	Open Pandiero	(#2) TR-808 Snare 3 *	Bend Gong	Ride Cymbal Low Inner	Wind	Voice Ou	Baert Low	Footsteps
		Open Triangle Shaker	Open Triangle Shaker	Open Surdo (EXC2) Mute Surdo (EXC2)	#2 TR-909 Snare 1	HuYin Luo Low *	Ride Cymbal Mid Inner	Seashore	Voice Au	Bounce	Applause
	83	ingle Bell	Jingle Bell	Tamborim	(#2) TR-909 Snare 2 *	HuYin Luo Mid	Ride Cymbal High Inner		Hoo	Peverse Bounce	Creaking
C6	B4	Beil Tree	Bell Tree	High Agogo	[#2] Brush Tap 1	HeYin LuoMid MutejFXC	i Ride Cymbal Low Edge	Bubble	Tape Stop 1 *	Distortion Knock	Door
-0	65	Castanets	Castanets	Low Agogo	[#2] Brush Tap 2	HuYin LuoHigh	Ride Cymbal Mid Edge	Kitty	Tape Stop 2 *	Guitar Slide	Scratch Scratch
1	86	Muta Surdo	Mute Surdo	Shaker	(#2) Brush Slap 1		Ride Cymbal High Edge		Missile *	Sub Marine Hoise Attack	Wind Chimes
	37	Open Surdo	Open Surdo	High Whistle (EXC3)	[#2] Brosh Slap 2	Nac Bo	TR-606 Ride Cymbal	Growl	Space Birds	Noise Attack Space Worms	Car-Engine Car-Stop
	88	Applause *	Applause *	Long Whistle [EXC3]	[#2] Brush Siap 3	Xiao Bo	TR-808 Ride Cymbal	Applause 2	Flying Manster	Emergency ! *	Car-Pass
I	89			Mute Cuica (EXC4)	[#2] Brush Swirl 1		Chinese Cymbal 1 Chinese Cymbal 2	Telephone 1 Telephone 2		Calculating*	Car-Crash
- 1	90			Open Cuica (EXC4)	[#2] Brush Swirl 2 [#2] Brush Long Swirl		[#1] Hand Clap	Small Club 1		Saw LFO Saw	Siren
	91			Mute Triangle [EXC5] Open Triangle [EXC5]	Standard 1 Snare 1		[#2] Hand Clap 2	Small Club 2	_		Train
	93			Short Guiro [EXC6]	Standard 1 Snare 2		[82] Hand Clap	Applause Wave		_=	ietplanė
	9.1			Long Guiro (EXC6)	Standard Snare 3		Hand Clap	Eruption			Helicopter
1				Cabasa Up	Rap Snare	-	Hand Clap 2	Bag Shot		-	Starship
	95			COLUMN UP	Hip-Hop Snare 2		TR-707 Hand Clap	Percussion Bang		-	Gun Shot

CC C C C C C C		,	PC: 41 (CC32: 3) BRUSH	PC: 49 (CC32: 3) ORCHESTRA	PC: 50 (CC32: 3) ETHINC	PC: 51 [CC32: 3] Kick & Snare	PC: 53 (CC32: 3) ASIA	PC: 54 [CC32: 3] Cymbel & Cleps	PC: 57 (CC32: 3) SFX	PC: 50 (CC32: 3) RHYTHM FX	PC: 59 [CC32: 3] Mrythm FX 2	PC: 128 (CC32: 3) CM-54/321
Second Color Seco	(C7		()	()	(Cabasa Down)	()	()	(TR-707 Hand Clap)	()	(···)	()	(Gun Shot)
103			_		Claves	Jungle Snare 1	-	-	_	_		Machine Gun
100			7-						-	_		Laserque
10 12 Brock Tup 2 19 Tempor F House Soure 2 Hostocklop 10 10 12 Brock Tup 2 19 Tempor F House Soure 2 Hostocklop 10 10 12 Tempor Sup 2 19 Tempor G House Soure 1 House Soure 2 House Soure 2 10 10 12 Brock Sup 2 19 Tempor G House Soure 2 House Soure 2 House Soure 3 House Sou			-		Low Wood Block	Techno Snare 1	-	_	_		_	Explosion
		100				Techno Share 2		_	-		-	Deg
103						House Snare 2	+	_	-	_		
105 197						CR-78 Snare 1		_	-	_		8trd
105					-			_		-	_	Rain
107		_							_	-		Thunder
107							=					Wind
10 10 10 10 10 10 10 10										-		Seashore
10 2											-	Stream
110	CB							-	_		-	Bubble
112								_		_		- 1
112 24/2 Standard Standard 18/11 Improved					-		_				-	
113					**	1R-909 Share 2		-	-	-	+	
115								-	_	-	-	
115 Standard Stane				(#1) Timpani f			_			_		~
117					<u> </u>					_	_	_
117										***		
119						-		-				-
119												-
120 120								_				
122 122 123 124												
122	G									-	-	-
124 197 Denot Starr 1					**	-	-		-	-		-
124								_			-	-
125 (2) Door Seare				-					_		_	_
20 2 Berris State 2				-		-	_		_	-	-	_
es 177 Millionin Caus 24							_					-
G9 127 [82] Electric Soare 3 *											_	_
	G5	127	(02) Electric Snare 3 *		***							***

CHA					PC: 25 (CC32: 2) Electronic		,		PC: 41 (CC32: 2) Brush	PC: 49 [CC32: 2] Orchestra
-1 0					-	-	-		-	
	-				-				-	
2				-						_
									-	-
-	-			**	_	-				
1	-			-				-		
7						-		-	~	
-		_	-	-		_		-		
3										
11				mer	-		-			
CO 12		_	-			**				-
14				***			-	-	-	
- 15				~	-	_		-		
16				_						
17										
13					_					-
19	_	_			-				**	
21								_		
23	<u> </u>							_	-	+
SECTION AND	d 								-	-
G 24	Snare Roll	****	Snare Roll	Snare Roll	Snare Roll Finger Snap 2					
25 1111	Finger Snap	Finger Snap 2	Finger Snap 2	Finger Snap 2	Finger Snap 2	Finger Snap 2 High Q		Finger Snap 2 High Q	Finger Snap 2 High O	Closed Hi-hat2 [EXC1]
	High Q Slap	Slap	Sap	Slap	Siap	Pedal Hi-hat (EXC1)				
20	Scratch Push (EXC7)	Scratch Push	Scratch Push	Scratch Push	Scratch Push2 (EXC7)	Scratch Push2 [EXC7]	Scratch Push2 [EXC7]	Scratch Push	Scretch Push	Open Hi-hat2 [EXC1]
30	Scratch Puli (EXC7)	Scratch Pull	Scratch Pull	Scratch Pull	Scratch Pult2 EXC7	Scratch Pull2 (EXC7)	Stratch Pull2 (EXC7)	Scratch Pull Sticks	Scratth Pull Sticks	Ride Cymbal 1 Sticks
	Sticks Circle	Sticks Course Click	Sticks Square Click	Sticks Square Click	Sticks Square Click	Sticks Square Click	Square Click	Square Click	Square Click	Square Click
er er som	Square Click Metronome Click	Square Click Metronome Click	Metronome Click	Metronome Click	Metronome Cick	Metronome Click	Metronome Click	Metronome Click	Metronome Click	Metranome Click
	Metronome Jeli	Metronome Bell	Metroname Bell	Metronome Bell Jazz Kick 2	Metronome Bell Jazz Kick 1					
35	Standard 1 Kick 2	Standard 2 Kick 2	Room Kick 2	Power Kick 2	Electric Kick 2	909 Bass Drum 808 Bass Drum	Dance Kick Flectric Kick 2	Jazz Kick 2 Jazz Kick 1	Jazz Kick 1	Concert BD1
CZ BE	Standard T Kick 1 Side Stick	Standard 2 Kick 1 Side Stick	Room Kick 1 Side Stick	Power Kick 1 Side Stick	Electric Kick 1 Side Stick	808 Rim Shot	Side Stick	Side Stick	Side Stick	Side Stick
क्षा विकास समिति । विकास समिति ।	Standard 1 Snare 1	Standard 2 Snare 1	Room Snare 1	Power Snare 1	Electric Snare 1	806 Snare 1	Dance Snare 1	Jazz Srure 1	Brush Tap1	Concert 50
12	Hand Clap	Hand Clap2 Jazz Snare 2	Brush Slap1 Brush Swiri1	Castanets Concert 3D						
44.77	Standard 1 Snare 2	Standard 2 Snare 2	Room Low Yorn2 *	Power Snare 2 Power Low Yorn2 *	Electric Snare 2 Electric Low Tom2 *	909 Snare 1 808 Low Yorn2 *	Dance Snare 2 Electric Low Tom2 *	Low Tom?	Brush Low Tom2 *	Timpani F
42.00	Closed Hi-hat) [EXC1]	Closed Hi-hat2 [EXC1]	Closed Hi-hat3 [EXC1]	Closed Hi-hat3 [EXC1]	Closed Hi-hat2 [EXC1]	808 CHH (EXC1)	CR-78 CHH [EXC1]	Closed Hi-hatZ [EXC1]	Brush Closed Hi-hat	Timpani F#
P. Carlon		Low Tom1	Room Low Tom? *	Power Low Tom? *	Electric Law Tom1 *	808 Low Tomi *	Electric Low Tom1 *	Low Tom!	Brush Low Tom1 *	Timpani Gil
(d) (1)		Pedal Hi-Hat	Pedai HI-Hat	Pedal Hi-Hat	Pedal Hi-Het	BOB CHH [EXC1] BOB Mid TornZ *	808 CHH {EXC1} Electric Mid Tom2 *	Pedal Hi-Hat Mid Tom2	Pedal Hi-Hat Brush Mid Tom2 *	Timpani A
45	Mid Tom2 * Open Hi-hat1 (EXC1)	Mid Tom2 Open Hi-hat2 (EXC1)	Room Mid Tom2 * Open Hi-hat3 (EXC1)	Power Mid Tom2 * Open Hi-hat3 (EXC1)	Open Hi-hat2 [EXC1]	808 OHH [EXC1]	CR-78 OHH (EXC1)	Open Hi-hatZ [EXC1]	Brush Open HiHat[EX	
1	Mici Tore!	Mid Tom I	Room Mid Tom1 *	Power Mid Tom1 "	Electric Mid Torn! *	806 Mid Tom1 *	Electric Mid Tom1 *	Mid Tom 1	Brush Mid Tom!	Tirapani B
C3 44	High Tom2 *	High Tom 2	Room Hi Tom2 *	Power Hi Tom2 *	Electric Hi Torni2 *	BOE High Tom2	Electric High Tom2 * Crash Cymbal 1	High Yom 2 Crash Cymbal 1	Brush Hi Tom2 * Brush Crash Cymbal	Timpani c Timpani ce
Min 10		Crash Cymbal 1 High Tom 1	Crash Cymbal 1 Room Hi Torn 1 *	Crash Cymbal 1 Power Hi Tom1 *	Crash Cymbal 1 Electric Hi Tom! *	808 Hi Tom1	Electric High Tom1	High Tom 1	Brush Hi Tomi *	Tempani d
	High Tomt * Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1	Ride Cymbal 1	Brush Ride Cymbai	Timpani di
		Chinese Cymbal	Chinese Cymbal	Chinese Cymbal	Reverse Cymbal	Chinese Cymbal Rido Bell	Reverse Cymbei Ride Bell	Chinese Cymbal Ride Bell	Chinese Cymbai Brush Ride Bell	Timpani e Timpani f
53	Ride Bell					TUDE BEH	KKSE BEII		BLATE COMP. NO.	
100 E		Ride Bell	Ride Bell	Ride Bell	Ride Bell Yambourion	Tambourine	Tambourine	Tambourine	Tambourine	Tambourine
1966 (1966)	Tambourine	Tambourine	Tambourine	Tambourine Splash Cymbai	Yambourine Splash Cymbal	Tambourine Splash Cymbal	Tambourine Splash Cymbal	Splash Cymbal	Splash Cymbal	Splash Cymbal
55	Tambourine Splash Cymbai			Tambourine	Tambourine Splash Cymbal Cowbell	Spiash Cymbai 808 Cowbell	Splash Cymbal Cowbell	Splash Cymbal Cowbell	Splash Cymbal Cowbell	Spiash Cymbal Cowbell
	Tambourine Splesh Cymbai Cowheli Crash Cymbal?	Tambourine Splash Cymbal Cowbell Crash Cymbal 2	Splash Cymbal 808 Cowbell Crash Cymbal 2	Splash Cymbal Cowbell Crash Cymbal 2	Splash Cymbal Cowbell Crash Cymbal 2	Splash Cymbal	Splash Cymbal Cowbell Concert Cymbal2			
1000 2000 2000	Tambourive Splesh Cymbai Cowheli Crash Cymbal2 Vibra-slap	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap	Tambourine Splash Cymbai Cowbell Crash Cymbal 2 Vibra-siap	Tambourins Splash Cymbal Cowbell Crash Cymbal 2 Vibra-stap	Splash Cymbal 806 Cowbell Crash Cymbal 2 Vibra-slap	Splash Cymbal Cowbell	Splash Cymbal Cowbell	Splash Cymbal Cowbell Crash Cymbal 2	Spiash Cymbal Cowbell
57 16	Tambourine Splash Cymbai Cowheli Cush Cymbal2 Vibra-slap Ride Cymbal2	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vibra slap Ride Cymbal 2	Tambourine Splash Cymbal Cowbell Crash Cymbal 2	Tambourine Splash Cymbal Cowbell Crash Cymbal 2	Tambourine Splash Cymbal Cowbell Crash Cymbal 2	Splash Cymbal 808 Cowbell Crash Cymbal 2	Splash Cymbel Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo	Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo	Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo	Spiash Cymbai Cowbell Concert Cymbat2 Vibra-stap Concert Cymbai1 High Bongo
	Tambourine Splash Cymbai Cowbel Crash Cymbal2 Vibra-stap Ride Cymbal2 High Bongo Law Bongo	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vibra-siap Ride Cymbal 2 High Bongo Low Bongo	Tambourins Splash Cymbal Cowbell Crash Cymbal 2 Vibra-stap Ricke Cymbal 2 High Bongo Low Bongo	Spiesh Cymbal 808 Cowbell Crash Cymbal 2 Vibre-slap Ride Cymbal 2 High Bongo Low Bongo	Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Songo	Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo	Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo	Splash Cymbal Cowbell Concert Cymbal2 Vibra-stap Concert Cymbal1 High Biongo Low Bongo
S 8 8	Tambourine Splesh Cymbai Corel Crash Cymbai Vibra-slap Ride Cymbai High Bongo Low Bongo Mute High Conga	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vibra-Hap Ride Cymbal 2 High Bongo Low Songo Mute High Congu	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vibra-isg Ride Cymbal 2 High Bongo Low Bongo Murte High Conga	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slag Ride Cymbal 2 High Bongo Low Bongo Mute High Conga	Tambourins Splash Cymbal Cowbell Crash Cymbal 2 Vibra-Hap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga	Spiash Cymbal 808 Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo 808 High Conga	Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga	Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga	Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo	Spiash Cymbai Cowbell Concert Cymbat2 Vibra-stap Concert Cymbai1 High Bongo
S 6 4	Tambourine Splesh Cymbai Cowlei Cush Cymbai Vshzaslap Ride Cymbai Ride Cymbai High Bongo Mute High Conga Open High Conga	Tambourine Splash Cymbal Cowbell Cowbell Crash Cymbal 2 Vors-slap Ride Cymbal 2 High Bongo Low Bongo Mute High Congs Open High Congs	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vibra-siap Ride Cymbal 2 High Bongo Low Bongo	Tambourins Splash Cymbal Cowbell Crash Cymbal 2 Vibra-stap Ricke Cymbal 2 High Bongo Low Bongo	Spiesh Cymbal 808 Cowbell Crash Cymbal 2 Vibre-slap Ride Cymbal 2 High Bongo Low Bongo	Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Songo	Spissh Cymbal Cowbell Crash Cymbal 2 Vibra-Jiap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open Low Conga	Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mure High Conga Open High Conga Open Low Conga	Splash Cymbal Conhell Conhell Connert Cymbal2 Vibra-shap Connert Cymbal1 High Bongo Low Bongo Natte High Conga Open High Conga Open High Conga Open Low Conga
S 8 8	Tambourine Splash Cymbai Cowheil Crash Cymbal? Vibra-stap Ride Cymbal? High Bongo Low Bongo Murr Bigh Conga Open High Conga Low Conga Low Conga	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vibra-Hap Ride Cymbal 2 High Bongo Low Songo Mute High Congu	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mutte High Conga Open High Conga	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open Low Gonga High Timbale	Tambourins Splash Cymbal Cowbeil Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open Low Conga High Timbale	Splash Cymbal 808 Cnwbell Crash Cymbal 2 Vibra-Sap Ride Cymbal 2 High Bongo Low Bongo BOB High Conga 808 Mid Conga 808 Mid Conga High Timbale	Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open Low Conga High Timbale	Spiash Cymbal Cowbell Crash Cymbal 2 Vibra-siap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open High Conga Open Low Conga High Timbale	Splash Cymbal Covebell Cresh Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mure High Conga Open High Conga High Timbale	Splash Cymbal Corbeel Corpert Cornert Cymbal2 Vibra-slap Concert Cymbal1 High Bongo Low Bongo Marte High Conga Open High Conga
S 2 2 3 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8	Tambourine Splack Cymbai Cowheil Cowheil Casch Cymbal1 Vibra slap Rade Cymbal2 Hagh Bongo Low Bongo Low Bongo Low Conga Low Co	Tambourine Splash Cymbal Covobel Covobel Cost Cymbal 2 Vibra-slas Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open Low Conga Low Longa Low Tambale Low Tambale	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open Low Conga High Timbale Low Timbale	Tambourtine Splash Cymbal Cowbell Ccash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open Low Conga High Timbale Liow Timbale Low Timbale	Tambourine Splast Cymbal Cowbell Crash Cymbal 2 Vibra-stap Ride Cymbal 2 High Bongo Low Bongo Mate High Conga Open High Conga Open Low Conga High Timbale Low Tembale	Splash Cymbal 806 Crwbell Crash Cymbal 2 Vibra-lap Ride Cymbal 2 High Bongo Low Bongo 808 High Conga 808 Mid Conga 808 Low Conga High Timbale Low Timbale	Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open Low Conga High Timbale Low Timbale	Spissh Cymbal Cowbell Cresh Cymbal 2 Vibra-Hap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open Low Conga Ligh Timbale Low Timbale	Splash Cymbal Cowbell Cresh Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mure High Conga Open High Conga High Timbale Low Timbale	Splash Cymbal Corbell Corbell Corpert Cymbal2 Vibra-slap Corpert Cymbal1 High Bongo Low Bongo Nater High Corga Open High Corga Open High Corga High Timbale Low Timbale
S S	Tambourine Splack Cymbai Cowheil Cowheil Cash Cymbal2 Vibra-stap Rate Cymbal2 High Bongo Low Bongo Mutre High Conga Open High Conga Lew Conga High Timbale Low Timbale Migh Agogo	Tambourine Spissh Cymbal Cowbell Cash Cymbal 2 Vibra-alas Ride Cymbal 2 High Brongo Low Bongo Low Bongo Marte Righ Conga Open High Conga Open Low Conga High Timbale Low Tambale High Agogo	Tamburine Spain Kymbal Covbell Criph Cymbal 2 Vibra-laip Ride Cymbal 2 High Bongo Low Bongo Mare High Conga Open High Conga Open High Conga High Timbale Low Timbale High Agogo	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open Low Gonga High Timbale	Tambourins Splash Cymbal Cowbeil Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open Low Conga High Timbale	Splash Cymbal 808 Cnwbell Crash Cymbal 2 Vibra-Sap Ride Cymbal 2 High Bongo Low Bongo BOB High Conga 808 Mid Conga 808 Mid Conga High Timbale	Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open Low Conga High Timbale	Splash Cymbal Cowbeil Cowbeil Cash Cymbal 2 Vibra-Hep Ride Cymbal 2 High Bongo Low Bongo Nutue High Conga Open High Conga Open High Conga High Timbale Low Timbale Low Timbale Low Agogo Low Agogo Low Agogo	Spitah Cymbal Cowbell Cowbell Crayb Cymbal 2 Vibra-dap Ride Cymbal 2 High Bongo Mate High Corga Open High Corga Open High Corga Open Low Congs High Timbale Low Timbale Low Minbale Low Magogo Low Agogo	Splash Cymbal Cowbell Cowbell Coment Cymbal2 Vidar-slap Concent Cymbal1 High Bongo Low Bongo Marte High Conga Open High Conga Open High Conga Open Low Conga High Timbale Low Timbale Low Timbale Low Mpago Low Apago
S 2 2 3 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8	Tambasine Tambasine Tambasine Topish (ymbai Cowbeil Cowbeil Combeil Combeil Combeil Combeil Combeil Combeil Combeil Combeil Combeil Mare High Conga Dopen High Conga Low Konga Low Low Conga Low Low Conga Low Low Conga Low Low Conga Low Agogo Low Agogo Low Agogo Low Agogo Low Agogo	Tambourine Splash Cymbal Covobel Covobel Cost Cymbal 2 Vibra-slas Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open Low Conga Low Longa Low Tambale Low Tambale	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open Low Conga High Timbale Low Timbale	Tanbourine Splash Cymbal Cowbell Cowb (Cymbal 2 Whra-diap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open High Conga Open High Conga Open Low Conga High Timbale Low Timbale High Agogo Low Agogo Cobasa	Tambourine Splant Cymbal Cowbell Crash Cembal 2 High Bongo Low Bongo Low Bongo Open High Conga Open High Conga Open High Conga Open How Conga High Timbale Low Timbale High Angogo Low	Spiteth Cymbal 800 Cowbell Crish Cymbal 800 Cowbell Crish Cymbal 2 Vibre-slap 800 Cymbal 2 High Bongo Low Bongo 800 Mid Conga 800 Mid Conga 800 Mid Conga 800 Mid Conga 800 Low Conga High Timbale High Appgo Low Appgo Cobesa	Splash Cymbal Cowbeil Cowbeil Cowbeil Cowbeil Fide Cymbal 2 Vibra-Hap Ride Cymbal 2 Nigh Bongo Low Bongo Mutar High Conga Ogen High Conga Ogen How Conga High Timbdal Low Timbala Liow Timbala	Splash Cymbal Corebell Corebell Corebell Corebell Cred Cymbal 2 Vobra-Hap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open High Timbale Low Timbale High Agogo Low Bongo Cabsal Core Core Core Core	Splash Cymbal Contoell Contoell Cresh Cymbal 2 Vibra-slap Ride Cymbal 2 High Brongo Low Brongo Hute High Conga Open High Conga Open Low Conga High Timbale High Agogo Low Timbale High Agogo Low Agogo Cabasa	Splash Cymbal Corbell Corbell Corbell Corpert Cymbal2 Vibra-slap Corpert Cymbal1 High Bongo Low Bongo Nater High Corga Open High Corga Open High Corga Open Low Corga High Timbale Low Timbale High Agogo Low Agogo Cobasa
	Tambourine Splack Cymbai Cowhell Crain Cymbal2 Fact Cymbal2 Ref Cymbal2 Ref Cymbal2 High Bongo Mere High Conga Open High Conga Open High Conga Low Eonga High Timbale Low Timbale High Rogo Low Mayogo Cabasa Mareca	Tambourine Spissis Cymbal Cymbal Crash Cymbal 2 Vibra size Kide Cymbal 2 Kigh Bonge Low Bonge Kide Kigh Conga Open High Conga Open High Conga High Timbale Low Tambale Low Tam	Tambourine Splash Cymbol Cowbell Crash Cymbol 2 Vibra-slap Ride Cymbol 2 High Bongo Low Bongo Mure High Conga Open High Conga Open High Conga Low Timbole Low Timbole Low Timbole Low High Agogo Low Agogo Cabasa Maraxss	Tambourine Sphah Cymhal Cowbell Crash Cymbal 2 Wibra-slap Ride Cymbal 2 High Bongo Ride Cymbal 2 High Bongo Ride Cymbal 2 High Bongo Ride Cymbal 2 High Rongo Ride Cymbal 2 High Rongo Open High Conga Open High Conga High Timbale Low Timbale Low Timbale Low Timbale Low Agogo Cabasa Maraca	Tambourine Splan Cymbal Cowbell Crash Cembal 2 Vitra-falo Pitra Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open High Conga High Timbale Low Tim	Splash Cymbal 800 Crobbel 600 Crobbel 600 Crobbel 610	Splash Cymbal Cowboil Cowboil Cash Cymbal 2 Whar-alap Side Cymbal 2 High Bongo Low Bongo Low Bongo Cypen High Conga Open High Conga Open High Conga Cypen Low Copen Liny Konga Low Trobale	Splash Cymbal Corebeal Corebeal Corebeal Corebeal Crede Cymbal 2 Vibra-Hap Ride Cymbal 2 Nibra-Hap Ride Cymbal 2 Nibra-Hap Ride Cymbal 2 Low Bongo Low Bongo Mute High Conga Open Low Conga High Timbale Low Timba	Spitah Cymbal Cowbell Cowbell Crayb Cymbal 2 Vibra-dap Ride Cymbal 2 High Bongo Mate High Corga Open High Corga Open High Corga Open Low Congs High Timbale Low Timbale Low Minbale Low Magogo Low Agogo	Splash Cymbal Cowbell Cowbell Coment Cymbal2 Vidar-slap Concent Cymbal1 High Bongo Low Bongo Marte High Conga Open High Conga Open High Conga Open Low Conga High Timbale Low Timbale Low Timbale Low Appgo Low Appgo
3	Tambourine Tambourine Splach Cymbai Cowhell Cash Cymbal? Valurablap Rode Cymbal? High Bongo Low Bongo Mutz High Conga Low Conga Mutz High Conga Low Conga High Timbale Low Timbale High Agogo Low Agogo Low Agogo Shout B Whittle (EXC) Shout B Whittle (EXC)	Tambourine Splash Cymbal Conthell Conthell Conthell Conthell Conthell Conthell Ride Cymbal 2 High Boroga Ride Cymbal 2 High Boroga Ride Cymbal 2 High Boroga Open High Conga Open High Conga Open Low Conga High Rimbale Liow Timbale High Agogo Cabma Maracs Maracs Short High Whistin	Tambourine Spiash Cymbal Combell Cysh Cymbal 2 Vibra-risp Ride Cymbal 2 High Bongo Low Bongo Muter High Conga Open High Conga Open High Conga Cipen Low Conga High Timbale Low Timbale High Agogo Low Timbale Low Agogo Cabasa Maracs Maracs Maracs Maracs Maracs Maracs Maracs Maracs	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Wishr-Alap Ride Cymbal 2 High Rongo Low Bongo Mute High Conga Open High Conga Open Low Conga High Timbale Low Timbale High Agogo Cabasa Maratos Maratos Maratos Maratos Maratos Short High Whistle	Tambourine Spiah Cymbal Cowbeil Crash Cembal 2 High Bongo Live Bongo Live Bongo Live Bongo Open High Conga Open High Conga Open Low Conga High Timbale Low Timbale Live Timbale Live Timbale Live Timbale Short High Whistle Markes Marke	Spiteth Cymbal 800 Cowbell Crish Cymbal 800 Cowbell Crish Cymbal 2 Vibre-slap 800 Cymbal 2 High Bongo Low Bongo 800 Mid Conga 800 Mid Conga 800 Mid Conga 800 Mid Conga 800 Low Conga High Timbale High Appgo Low Appgo Cobesa	Splash Cymbal Cowbeil Cowbeil Cowbeil Cowbeil Fide Cymbal 2 Vibra-Hap Ride Cymbal 2 Nigh Bongo Low Bongo Mutar High Conga Ogen High Conga Ogen How Conga High Timbdal Low Timbala Liow Timbala	Splash Cymbal Corebell Corebell Corebell Corebell Cred Cymbal 2 Vobra-Hap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open High Timbale Low Timbale High Agogo Low Bongo Cabsal Core Core Core Core	Splain Cymbal Convbell Convbell Crish Crothal 2 Vibra-slap Ride Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Low Bongo Low Bongo Open High Conga Open High Conga Open Low Conga High Timbale Low Wight Low High Whitelle Long Low Whostle Long Low Whostle Long Low Whostle	Splash Cymbal Corbeel Corbeel Corport Cymbal2 Vida-slap Cornert Cymbal2 Vida-slap Cornert Cymbal1 High Bongo Low Bongo Mare High Conga Open High Conga Open High Conga Low Finshale Low Timbale Low Ti
	Tambasrine Tambasrine Spiah Cymbai Cowheil Crain Cymbai Crain Cymbai Crain Cymbai Rae Cymbai Rae Cymbai Rae Cymbai Rae Cymbai Murr High Conga Low Bongo Low Bongo Low Gonga High Timbai Low Finnbai Low Finnbai Low Finnbai Sharae Short H Whittle (EXC2) Short H Whittle (EXC2)	Tambourine Splash Cymbal Conthell Conthell Conthell Conthell Conthell Conthell Ride Cymbal 2 High Boroga Ride Cymbal 2 High Boroga Ride Cymbal 2 High Boroga Open High Conga Open High Conga Open Low Conga High Rimbale Liow Timbale High Agogo Cabma Maracs Maracs Short High Whistin	Tambourine Splash Cymbol Cowbell Crash Cymbol 2 Vibra-slap Ride Cymbol 2 High Bongo Low Bongo Mure High Conga Open High Conga Open High Conga Low Timbole Low Timbole Low Timbole Low High Agogo Low Agogo Cabasa Maraxss	Tambourine Sphah Cymhal Cowbell Crash Cymbal 2 Wibra-slap Ride Cymbal 2 High Bongo Ride Cymbal 2 High Bongo Ride Cymbal 2 High Bongo Ride Cymbal 2 High Rongo Ride Cymbal 2 High Rongo Open High Conga Open High Conga High Timbale Low Timbale Low Timbale Low Timbale Low Agogo Cabasa Maraca	Tembourine Splain (Symbal Constell Crish (Crish) Witz-slap Ride (Symbal 2 High High (Symbal 2 High High (Symbal 2 High High High High High High High High	Spitath Cymbal 808 Crobbel 808 Crobbel 608 Mid Cropa 808 Mid Cropa 100 Midple 100 Midpl	Splash Cymbal Cowbeil Cowbeil Cowbeil Whar Alap Mide Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open How Co	Splash Cymbal Cowbedi Cowbedi Cash Cymbal 2 Vibra-lap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Ango Open High Conga Open High Conga Open High Ango Open High Ango Open High Maraca Short High Whistle Short Giuto Short Giuto Short Giuto	Spiab Cymbal Combell Combell Crish Cryshal 2 Vibra-dalp Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open High Conga Open Low Conga Low Timbale Low Timbale Low Timbale Low Magogo Cobsta Short High Whistle Long Low Whastle Long Low Whattle	Splash Cymbal Cowbell Cowbell Coment Cymbal2 Vidar-slap Concert Cymbal2 Vidar-slap Concert Cymbal1 High Biongo Low Bongo Marte High Conga Open High Conga Open High Conga Open High Conga Open Low Conga High Timbale Low Timbale Low Timbale Low Apogo Cobasa Marte Righ Marte Righ Marte Righ Sport High Whistle Long Low Whistle Short Righ Whistle Long Low Whistle Short Guiro Short Guiro Short Righ Whistle Long Low Whistle Short Guiro
	Tambasrine Tambasrine Spiah Cymbai Cowheil Crain Cymbai Crain Cymbai Crain Cymbai Rae Cymbai Rae Cymbai Rae Cymbai Rae Cymbai Murr High Conga Low Bongo Low Bongo Low Gonga High Timbai Low Finnbai Low Finnbai Low Finnbai Sharae Short H Whittle (EXC2) Short H Whittle (EXC2)	Tambourine Splash Cymbal Conthell Conthell Conthell Conthell Conthell Conthell Conthell Mark High Conga Deen High Conga Open High Conga Open Hop Conga Open How Conga High Timbale Low Apogo Low Apogo Low Apogo Low Apogo Low Markes Markes Short High Whistle Short Guro Long Guro Long Guro Long Guro Low Whistle Short Guro Long L	Tambourine Splash Cymbal Combell Crish Cymbal 2 High Bongo Live Bongo Live Bongo Doen High Conga Open High Conga Open High Conga Open Live Conga High Timbale Live Timbale High Agogo Low Agogo Cabesa Maracsa Short High Whistle Short Guiro Long Gurra	Tanbourine Splash Cymbal Cowbell Crash Cymbal 2 Wifer Mongo Ride Cymbal 2 High Bongo Ride Cymbal 2 High Bongo Ride Cymbal 2 High Bongo Ride Cymbal 2 High Ride Gymen High Conga Open High Whistle Long Low Whistle Short High Whistle Long Low Whistle Short High Whistle Long Guiro Nord Guiro Long	Tambourine Splath Cymbal Cowbell Crash Cembal 2 High Bongo Live Bongo Live Bongo Doen High Hongo Open High Gonga High Hinshale High Agogo Cabata Maraca Maraca Maraca High Whitale Long Low Whistle Short Gaire Long Guiro Long Guiro Long Guiro	Spiash Cymbal SDE Chebel Crish Cymbal 2 Wiler-slap Ride Cymbal 2 High Bongo Low Bongo Bide High Conga SDE High Conga SDE High Conga SDE High Conga SDE High Timbale Low Timbale High Apogo Low Agogo Low Agogo Low Agogo Low Agogo Low High Andrea SDE High Whidle Long Low Whittile Short Gairo Long Guiro Long Lo	Splash Cymbal Cowbeil Cowbeil Cowbeil Cowbeil Cash Cymbal 2 High Bongo Rick Cymbal 2 High Bongo Mute High Conga Open Hote Conga High Conga Open How Conga High Tombal Low Tembale High Agogo Low Banca Short High Whistie Long I Low Whistie Short Gairo Long Guilro Mongo Long Culto Whistie Short Gairo Long Guilro	Splash Cymbal Cowbell Cowbell Cowbell Cowbell Cresh Cymbal 2 Vibra-Hap Ride Cymbal 2 High Bongo Low Bongo Open High Conga Open High Conga Open High Conga Chew Low Timbale High Agogo Low Agogo Gabasa Narrasa Short High Whistle Short Gairo Long Guiro Long Guiro Long Guiro Long Guiro	Splain Cymbal Convbell Griph Cymbal 2 Vibra-daip Ride Cymbal 2 Vibra-daip Ride Cymbal 2 High Bongo Low Bongo Mure High Conga Open High Conga Open High Conga High Timbale Low Timbale High Agogo Low Agogo Cebsta Marko Short High Whidle Long Low Whatle Short Guro Long Guro	Splash Cymbal Corbeel Corbeel Corbeel Corpert Cymbal2 With valsip Corpert Cymbal1 High Brongo Low Brongo High Cornga Open High Cornga Open High Cornga Open High Cornga High Timbale Low Timbale High Agogo Low Agogo Corbes Market Short Righ Whistile Long Low Whistile Short Guiro Long
CA 100 100 100 100 100 100 100 100 100 10	Tambourine Splach Cymbai Cowheil Cowheil Cicah Cymbal2 Vibra-stap Rate Cymbal2 High Bongo Low Bongo Mure High Conga Open High Conga Lew Conga High Timbale High Timbale Nigh Agogo Low Agogo Low Agogo Cabasa Maraca Short H Whistle (EXC) Short Gurre (EXCS) Long Guire (EXCS) Cong Guire (EXCS) Clares Cong Guire (EXCS) Cong Guire (EXCS) Cong Guire (EXCS) Clares	Tambourine Spissis Cymbal Crash Cymbal Crash Cymbal User slies Worselse Worselse Worselse Worselse Worselse Worselse Worselse Worse	Tambourine Splash Cymbal Cowbell Crish Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open High Conga Open Low Conge High Timbale Low Timbale High Agogo Low Agogo Cabassa Maracs Short High Whistle Short Gairo Long Low Whistle Short Gairo Long Gourn Claves	Tambourine Sphah Cymhal Cowbell Crash Cymbal 2 Wibra-dap Ride Cymbal 2 High Bongo Ride Cymbal 2 High Bongo Ride Cymbal 2 High Bongo Mute High Conga Open High Conga Open High Conga Open Low Conga High Timbale Low Timbale High Agogo Low Agogo Cabasa Maraza Maraza Short High Whistle Long Low Whistle Short Guire Long Guire Cong Glire Cong Colwest	Tambourine Splant Cymbal Cowbell Crash Crembal 2 Vilvar-stap Rick Cymbal 2 High Bongo Rick Cymbal 2 High Bongo Rick Cymbal 2 High Bongo Rick Cymbal 2 High Ronga Open High Conga Open High Conga High Timbale Low	Splash Cymbal 800 Crobbel 600 Mariaca 600	Splash Cymbal Cowbell Cowbell Cowbell Cash Cymbal 2 Vibur-alap Side Cymbal 2 Nigh Bongo Low Bongo Mute High Conga Open High Conga Open High Conga Open High Conga Copen Low Copen Low Rongo Low Tombale High Agogo Low Agogo Low Agogo Cabbba Maracas Shont High Whistle Short Garo Long Gow Colessa	Splash Cymbal Cowbedi Cowbedi Cash Cymbal 2 Vibra-lap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Ango Open High Conga Open High Conga Open High Ango Open High Ango Open High Maraca Short High Whistle Short Giuto Short Giuto Short Giuto	Spiab Cymbal Combell Combell Crish Cryshal 2 Vibra-dalp Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open High Conga Open Low Conga Low Timbale Low Timbale Low Timbale Low Magogo Cobsta Short High Whistle Long Low Whastle Long Low Whattle	Splash Cymbal Cowbell Cowbell Coment Cymbal2 Vidar-slap Concert Cymbal2 Vidar-slap Concert Cymbal1 High Biongo Low Bongo Marte High Conga Open High Conga Open High Conga Open High Conga Open Low Conga High Timbale Low Timbale Low Timbale Low Apogo Cobasa Marte Righ Marte Righ Marte Righ Sport High Whistle Long Low Whistle Short Righ Whistle Long Low Whistle Short Guiro Short Guiro Short Righ Whistle Long Low Whistle Short Guiro
	Tambourine Tambourine Tambourine Splanh Cymbai Counteil Fach Cymbai Fach Cymbai Fach Cymbai Fach Congo Marre High Congo Low Googe Low Congo High Timbale Low Timbale Low Timbale High Agogo Counteil Short Hi Whistle (EXC) Short Haw Whistle (EXC) Short Haw Counteil Short Haw Counteil Short Haw Counteil Short Haw Counteil Short Garre (EXCS) Long Gairo (EXCS) Long Gairo (EXCS) Long Gairo (EXCS)	Tambourin's Splash Cymbal Cowbell Cowbell Cash Cymbal 2 High Bongo Low Song Song Song Song Song Song Song Song	Tambourine Spiash Cymbal Combell Crash Cymbal 2 Vibra-risp Ride Cymbal 2 Righ Bongo Low Bongo Ogen High Gonga Open High Gonga Open Low Conga High Timbale Low Timbale High Agogo Cabasa Maracas Maracas Maracas Short High Whistle Long Low Whistle Short Guiro Low Gong Cabasa Maracas Righ Timbale Long Low Whistle Short Guiro Cong Guiro Cloves Righ Wood Block Righ Wood Block Righ Wood Block	Tanbourine Splash Cymbal Cowbell Crash Cymbal 2 Wifer Mongo Ride Cymbal 2 High Bongo Ride Cymbal 2 High Bongo Ride Cymbal 2 High Bongo Ride Cymbal 2 High Ride Gymen High Conga Open High Whistle Long Low Whistle Short High Whistle Long Low Whistle Short High Whistle Long Guiro Nord Guiro Long	Tambourine Splath Cymbal Cowbell Crash Cembal 2 High Bongo Live Bongo Live Bongo Doen High Hongo Open High Gonga High Hinshale High Agogo Cabata Maraca Maraca Maraca High Whitale Long Low Whistle Short Gaire Long Guiro Long Guiro Long Guiro	Spiash Cymbal SDE Chebel Crish Cymbal 2 Wiler-slap Ride Cymbal 2 High Bongo Low Bongo Bide High Conga SDE High Conga SDE High Conga SDE High Conga SDE High Timbale Low Timbale High Apogo Low Agogo Low Agogo Low Agogo Low Agogo Low High Andrea SDE High Whidle Long Low Whittile Short Gairo Long Guiro Long Lo	Splash Cymbal Cowdedi Cowdedi Cash Cymbal 2 Whar alsp Riske Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Low Agogo Low Agogo Low Agogo Low Agogo Low High Whistle Short Sairo Long Gow Whistle Short Sairo Long Gow Whistle Short Sairo Long Gow High Whool Block Lingw Wood Block Low Wood Block	Splash Cymbal Cowbell Cowbell Cowbell Cash Cymbal 2 (seah Cymbal 2 Vibra-lispe Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open High Conga High Timbale Low Timbale Low Timbale Low Timbale Low Timbale Low Timbale Low Timbale Lorg Low Magogo Cobase Marzeas Short High Whittle Long Low Whoste Short Getto Lorng Guiro Lorng Guiro Lorng Guiro Clares High Wood Block Low Wood Blo	Splash Cymbal Cowbell Cowbell Cowbell Cowbell Crish Cymbal 2 Vibra-dalp Ride Cymbal 2 Vibra-dalp Ride Cymbal 2 High Bongo Low Bongo Cow Bongo Charles Congo Copen Low Conga High Tenbale Low Timbale Long Low Angogo Low Angogo Low Angogo Low Angogo Low Timbale Timbale Long Low Whoste Short Guiro Long Guiro Clares Long Guiro Clares Long Guiro Clares Long Guiro Clares Low Whood Block Low Whood Bl	Splash Cymbal Corbeel Corbeel Corpert Cymbal2 Vidra-slap Concert Cymbal2 Vidra-slap Concert Cymbal1 High Bongo Low Bongo High Conga Open High Conga Open High Conga Open Low Conga High Timbale Low Timbale Low Timbale Low Timbale Low William Maracea Short High Whistle Long Low Myogo Cabasa Maracea Short High Whistle Long Low Whistle Short Guiro Long Girin Claves High Wood Slock Low Wood Block Low Wood Block
CA 100 100 100 100 100 100 100 100 100 10	Tambasrine Tambasrine Tambasrine Spiah Cymbai Cowheil Crain Cymbai Crain Cymbai Tamb Cymbai Rade Cymbai Rade Cymbai Rade Cymbai Rade Cymbai Rade Cymbai Rade Cymbai Low Bongo Low Bongo Low Bongo Low Gongo High Timbai Rady Rady Low Inhaile High Agogo Low Agogo Cabasa Maraca Short Rad Whittis (EXC2) Short Gure (EXC3) Long Galore (EXC3) Long Long Cabara Long Long Cabara Long Long Cabara Long Lo	Tambourine Spissis Cymbal Crash Cymbal Crash Cymbal User slies Worselse Worselse Worselse Worselse Worselse Worselse Worselse Worse	Tambourine Spiash Cymbal Combell Crash Cymbal 2 High Bong Ride Cymbal 2 High Bong Open High Conga Open Low Conga High Timbale Low Timbale High Ropog Cobsta Low Hogg Cabasa Maracas Short High Whistle Long Low Whistle Long Low Whistle Long Gurra Claves High Whood Block Low Wood Bl	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Wise Ampal Ride Cymbal 2 Wise Ampal Copen High Conga Open Lide Conga High Romag Open Low Conga High Romag Low Timbale Low	Tambourine Spiate Cymbal Consbell Crash Cembal 2 Visiz-Map Risks Cymbal Risks Compa High Timbale Visiz-Map Risks Compa High Whistle Long Low Whistle Long Low Whistle Long Gwiro Clares High Wood Block Low Wood Block L	Spiash Cymbal 808 Crowbell 608 Crowbell 608 Crowbell 608 Crowbell 608 Crowbell 608 Crowbal 608 Crowpa 608 Mid Crowpa 609 Mid C	Splash Cymbal Cowbeil Cowbeil Cowbeil Cowbeil Cowbeil Cowb Cowbeil Cow	Splash Cymbal Cowbell Cowbell Cash Cymbal 2 Crash Cymbal 2 Crash Cymbal 2 High Bongo Low Bongo Mute High Conga Open High White Sport Guito Long Guro Claves High Wood Block Low Wood Block Low Wood Block Low Wood Block Low Wood Block	Spiab Cymbal Combell Combell Combell Crish Crmbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open High Conga Open High Conga High Timbale Low Timbale Low Timbale High Agogo Low Agogo Cabbts Short High Whistle Long Low Whistle Short Guro Long Guro Claves High Wood Block Low Block Low Education Low Block	Splash Cymbal Cowbell Cowbell Coment Cymlast2 Vibra-slap Concent Cymbal1 High Bongo Low Bongo Marte High Conga Open High Conga Open High Conga Open High Conga Open Low Conga High Timbale Low Timbale Low Timbale High Agogo Low Agogo Cabasa Maraccal Short High Whistle Long Low Whistle Short Guiro Long Goiro Claves High Wood Block Low Wood Block Low Wood Block Maraccal Low Wood Block Maraccal Low Wood Block
	Tambasine Tambas	Tambourin's Splash Cymbal Cymbal Cowbell Cowbell Cash Cymbal 2 Whra slass Nide Cymbal 2 High Bonoga Low Bonga Charles This Shore Sales Companies C	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Wikza-slap Ride Cymbal 2 Wikza-slap Ride Cymbal 2 Wigh Bongo Low Bongo Open High Conga Open Low Khisle Short High Whistle Short High Whistle Short Gairo Claves High Wood Block Low Wood Block Low Wood Block Low Wood Block Low Muta Cuica Open Cuica	Tambourine Splash Cymbal 2 Whra-diap Ride Cymbal 2 High Bongo Low Bongo Ride Cymbal 2 High Bongo Low Bongo Open High High Conga Open Hor Lore Conga High Timbale Low Timbale High Agogo Cabasa Maraca Short High Whistle Long Low Whittle Short Guiro Cay High Whistle Long Guiro Cabasa Maraca Maraca Maraca Long Guiro Cabasa Long Whittle My Model Block Long Guiro Cabasa	Tambourine Splath Cymbal Cowbel Crash Cembal 2 High Bongo Live Bongo Live Bongo Den High Conga Open High Conga Open High Conga Open High Conga Open High Conga Live Bongo Live Agogo Live A	Spiash Cymbal SDE Corbel Grash Cymbal 2 Vibre-slap Ride Cymbal 2 High Bongo Low Bongo SDE High Conga SDE High Conga SDE High Conga SDE High Conga SDE High Timbale Low Timbale High Apogo Low Agogo Cabata SDE How Conga SDE High Whidle Long Low Whittle Short High Whidle Long Guiro SDE Cabata SDE High Whidle Long Guiro SDE Cabata Low Whittle Short Gairo Low Guiro SDE Cawa SDE High Wood Block Low Weed Block Low Cong Conga SDE Conga	Splash Cymbal Cowdedi Cowdedi Cowdedi Cash Cymbal 2 Whar algo Ride Cymbal 2 Wigh Bongo Low Bongo Gyen Holy Conga Open High Conga Open High Conga Open High Conga Open High Conga High Timbale Low Timb	Splash Cymbal Cowbell Cowbell Cowbell Cowbell Celeb (minds 2 Vibra-leipe Ride Cymbal 2 High Bongo Dew Bongo Chen Bigh Conga Open High Conga Open High Conga High Tribbale Low Timbale	Splain Cymbal Convbell Griph Cymbal 2 Vibra-dalp Ride Cymbal 2 Vibra-dalp Ride Cymbal 2 High Bongo Low Bongo Mure High Conga Open High Conga Open Low Conga High Timbale Low Timbale High Robgo Low Apogo Cabsta Marica Short High Whidle Long Low Whostie Short Guro Long Guro Clave High Wood Block Low Wood Block Low Wood Block Maric Cuica Open Coulca	Spiash Cymbal Corbeel Corbeel Corbeel Corpert Cymbal2 Vidar-alsip Corpert Cymbal1 High Bongo Low Bongo High Conga Open High Conga Open High Conga Open High Conga Open Low Conga High Timbale Low Timbale High Apogo Low Apogo Cabasa Maracas Maracas Short High Whistle Long Low Whistle Short Guire Long Guire Claves High Wood Biock Low Wood Block Mute Cucica Open Colicia
	Tambasrine Tambasrine Splach Cymbai Cowheil Crash Cymbai Crash Cymbai Parac Cymbai Rade Conga Rade Tonga Rade Tong	Tambourine Spisoh Cymbal Crash Kymbal 2 Whra slam Rida Cymbal 2 High Bongo Low Bongo Mute High Conga Open Hore Canga High Timbale Low Tambal High Agogo Low Agogo Low Agogo Low Hongo Hore High Whistle Low Long Low Murace Low Timbale High Agogo Low Mogos Cabasa Marrace Low Goro Low Mogos Cabasa Marrace Long Gurre Claese High Wood Block Low Wood Block Low Wood Block Mute Clara Open Caka Marrace Mate Caka Marrace Mate Caka Marrace Marrace Claese High Wood Block Low Wood Block Mute Clara Open Caka Marrace Mate Caka Mate Caka Mate Caka Mate Caka Mate Caka	Tambourine Splash Cymbal Cowbell Crish Cymbal 2 Vibra-slap Ride Cymbal 2 Vibra-slap Ride Cymbal 2 Vibra Shap Ride Cymbal 2 Vish Rongo Low Bongo Mure High Conga Open Low Conga High Timbale Low Timbale Short Guiro Long Gurra Claves High Whotal Long Gurra Claves Long Gurra Claves Long Gurra Claves Low Wood Block Mute Timbale Mute Timbale Mute Timbale	Tambourine Spitah Cymhal Cowbell Crash Cymbal 2 Wibra-diap Ride Cymbal 2 High Bongo Ride Cymbal 2 High Bongo Ride Cymbal 2 High Bongo Mute High Conga Open Iow Conga High Timbale Low Timbale High Agogo Low Agogo Low Agogo Cabasa Maraca Short High Whistle Long Gwire Claves High Wood Block Low Wood Block Mate Curica Open Culica Mate Timple	Tambourine Splant Cymbal Cowbel Crash Creshal 2 Viliza Hap Bida Cymbal 2 High Bongo Bida Cymbal 2 High Bongo Bida Cymbal 2 High Bongo Mate High Conga Open Ingle Conga High Imitabale Low Timbale High Mogoo Low Appop Low Appop Cabeta Marracas Short High Winhale Short Guiro Long Guiro Chees High Wood Block Low Wood Block Mate Clura Open Cuica Mate Cuica Open Cuica Mate Cuica Open Cuica Mate Cuica Open Cuica Mate Toungle	Splash Cymbal 800 Crobbel 600 Crobbel 600 Crobbel 610	Splash Cymbal Cowbeil Cowbeil Cowbeil Cowbeil Cowbeil Cowb Cowbeil Cow	Splash Cymbal Cowbell Cowbell Cash Cymbal 2 Vibra-lape Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open High Conga Open High Conga Chen High Conga Chen High Conga Chen High Conga Chen Low Conga Low Agogo Low Agogo Low Agogo Low High Whitel Short High Whotel Short High Whotel Galro Collega Marzea Short High Whotel Garro Low Gulfo Low Gold High Wood Shok Low Wood Block Marte Cukra Open Culica Sy Muter Trangle	Spiab Cymbal Combell Combell Combell Crish Crmbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open High Conga Open High Conga High Timbale Low Timbale Low Timbale High Agogo Low Agogo Cabbts Short High Whistle Long Low Whistle Short Guro Long Guro Claves High Wood Block Low Block Low Education Low Block	Splash Cymbal Cowbell Cowbell Cowbell Coment Cymbal2 Vibra-slap Concert Cymbal2 Vibra-slap Concert Cymbal1 High Biongo Low Rongo Marte High Conga Open High Conga Open High Conga Open Low Conga High Timbale Low Timbale Low Timbale Low Apogo Cobasa Marte High Mysstle Long Low Apogo Cabasa Marte High Whistle Long Low Whistle Short High Whistle Long Low Whistle Short Righ Whostle Long Guito Claves High Wood Block Low Wood Block Mute Cuika Open Cuika Mute Triangie Open Cuica Mute Triangie Open Triangie Open Triangie
	Tambasine Tambas	Tambourin's Splash Cymbal Cymbal Cowbell Cowbell Cash Cymbal 2 Whra slass Nide Cymbal 2 High Bonoga Low Bonga Charles This Shore Sales Companies C	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Wikza-slap Ride Cymbal 2 Wikza-slap Ride Cymbal 2 Wigh Bongo Low Bongo Open High Conga Open Low Khisle Short High Whistle Short High Whistle Short Gairo Claves High Wood Block Low Wood Block Low Wood Block Low Wood Block Low Muta Cuica Open Cuica	Tambourine Splash Cymbal 2 Whra-diap Ride Cymbal 2 High Bongo Low Bongo Ride Cymbal 2 High Bongo Low Bongo Open High High Conga Open Hor Lore Conga High Timbale Low Timbale High Agogo Cabasa Maraca Short High Whistle Long Low Whittle Short Guiro Cay High Whistle Long Guiro Cabasa Maraca Maraca Maraca Long Guiro Cabasa Long Whittle My Model Block Long Guiro Cabasa	Tambourine Splath Cymbal Cowbel Crash Cembal 2 High Bongo Live Bongo Live Bongo Den High Conga Open High Conga Open High Conga Open High Conga Open High Conga Live Bongo Live Agogo Live A	Splash Cymbal SDE Chwbel SDE Chwbel SDE Chwbel Crish Cymbal White-laip Ride Cymbal High Bongo Low Bongo SDE Migh Conga SDE Mid Conga SDE Mid Conga SDE Mid Conga High Rongo Low Timbale Low Timbale Low Timbale Low Timbale Low Timbale Low White SDE Low Agogo Cabsta SDE Maracia SDE Claves High Wood Block Low Wood Block Mute Titangle Open Circa Mute Titangle	Splash Cymbal Cowdedi Cowdedi Cowdedi Cash Cymbal 2 Mybra-lap Ride Cymbal 2 Nigh Bongo Low Bongo Low Bongo Copen Hole Conga Open High Conga Open High Conga Open High Conga High Timbale Low Timbale L	Splash Cymbal Cowbell Cowbell Cowbell Cash Cymbal 2 (cash Cymbal 2 Vibra-lage Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open High Conga High Timbale Low Agogo Cobase Marzeas Short High Whistle Long Low Moste Short Gelfor Lorng Gairo Clares High Wood Block Low Woo	Splash Cymbal Cowbell Cowbell Cowbell Cowbell Crish Cymbal 2 Vibra-dalpa Ride Cymbal 2 Vibra-dalpa Ride Cymbal 2 High Bongo Low Bongo Low Bongo High Bongo Low Gonga High Thribale Low Timbale Low Timbale High Agogo Low Agogo Cebasa Marrica High Whistle Short High Whistle Short High Whistle Short High Whistle Short Midro Claro Guiro Chaw Gongo Clave Marrica Charles	Splash Cymbal Corbeel Corbeel Corpert Cymbal2 Vidra-slap Corpert Cymbal2 Vidra-slap Corpert Cymbal1 High Bongo Low Bongo High Conga Open High Conga Open High Conga Open High Conga Low Apogo Low Apogo Cabasa Marracea Short High Whistle Long Low Whistle Short Guivo Long Guiro Calves High Whostle Cong Guiro Calves High Whostle Cong Guiro Calves High Wood Slock Low Wood Block Mutte Cuizo Open Cuica Mutte Tutangle Coem Titangle Splate
	Tambasine Tambas	Tambourin's Splash Cymbal Cowbell Cowbell Cash Cymbal 2 Wigh Borogo Live Splash Cymbal 2 Wigh Borogo Live Songo Dpen High Chorga Dpen High Chorga Cipen Live Companing Timbale Live Magge Cabase Marzas Short High Wigh Agogo Live Might Pimbale Live Magge Cabase Marzas Short High Wigh Agogo Cabase Marzas Cabase Cabase Marzas Cabase Cabase Marzas Cabase C	Tambourine Spiash Cymbal Consbell Crash Cymbal 2 High Bong Ride Cymbal 2 High Bong Ride Cymbal 2 High Bong Ride Cymbal 2 High Bong Open High Conga Open Low Conga High Timbale Low Timbale Low Timbale Low Timbale Low High Agogo Low Mare High Agogo Low Mare Short High Whistle Lom Yaogo Cabasa Maracas Short High Whistle Lom Yaogo Cabasa Maracas Short High Whistle Lom Yood Block Low Wood Block Low	Tambourine Splash Cymbal 2 Owbell Crash Cymbal 2 Witer-dap Ride Cymbal 2 High Rongo Ride Cymbal 2 High Rongo Ride Cymbal 2 High Rongo Open Lingh Conga High Rongo Conga Lingh Rongo Conga High Wood Block Low Wood Block Marte Curs Open Cuica Mate Ciran Open Cuica Mate Ciran High Wood Block Low Wood Block Low Wood Block High Wood Block Low Wood Block High Wood Block Low Wood Block High Rongo	Tambourine Spiate Cymbal Consbell Crash Creshal 2 Visiz-Map Risks Cymbal Risks Compa Risks C	Spitath Cymbal 800 Crobbel 600	Splash Cymbal Cowbell	Splash Cymbal Cowbell Cowbell Cash Cymbal 2 Cysh Cymbal 2 Cysh Cymbal 2 High Bongo Low Bongo Mute High Conga Open Low Agogo Cabasa Short High Whotel Short Guito Long Low Whosle Short Guito Long Guiro Claves High Wood Block Low Wood Block Mare Cuica Open Cuica S, Mute Frangie CS Open Triangle Shabet Shape Bell Shabet Impge Bell	Splash Cymbal Convbell Convbell Crish Crmbal 2 Vibra-slap Ride Cymbal 2 Vibra-slap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open High Conga Copen Low Conga High Timbale High Romal Low Timbale High Ropop Low Apopo Cabasa Short High Whotel Long Low Whissile Short Guro Long Gairo Claves High Wood Block Low Wood Block Mute Triangle Open Cuica Mute Triangle Shaler Single Bell	Splash Cymbal Cowbell Cowbell Coment Cymbal2 Vibra-slap Concent Cymbal2 Vibra-slap Concent Cymbal1 High Bongo Iow Bongo Mate High Conga Open High Magop Iow Agogo Cabasa Maracca Short High Whistle Short Gaire Long Low Whistle Short Gaire Claves High Wood Block Iow Wood Block Iow Wood Block Mutte Tolangie Open Triangle Sheker Jingle Bell
	Tambasine Tambas	Tambourin's Splash Cymbal Cowbell Cash Cymbal 2 Whra slass Nide Cymbal 2 Whra slass Nigh Tambale Now Timbale Nigh Agogo Cabasa Maraza Short High Whistle Short High Whistle Short High Whistle Short Gare Low Agogo Cabasa Maraza Maraza Nor Mindel Nor M	Tambourine Splash Cymbal Cowbell Cysh Cymbal Cymbal 2 High Bongo Liu Bongo Ride Cymbal 2 High Rongo Open High Gongo Open High Congo Open High Congo Copen High Congo Copen High Congo Copen High Rongo Copen High Congo Copen High Rongo Copen High Rongo Copen High Congo Copen High Congo Copen High Congo Copen High Whistle Short High Whistle Short High Whistle Short Righ Wood Block Low Wood Block Low Wood Block Low Wood Block Low High Wood Block Aute Cakea Open Cinica Mute Triangle Shaker Lingie Bell Bell Bell Bell Bell Bell Bell Bel	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Wishra-diap Ride Cymbal 2 High Bongo Low Bongo Ride Cymbal 2 High Bongo Gopen High High Conga Open High High Conga Open How Low Bongo Copen High Splash High Agogo Com Timbale High Agogo Cabasa Maraca Short High Whistle Long Low Whistle Long Low Whistle Long Low Whistle Long Guiro Cawa High Wood Block Low High Wood Block Low High Wood Block Low High High Wood Block Low Wood Block Low High High Block Low High High Block Low High High Block Low High High Block Low Hi	Tambourine Splath Cymbal Cowbell Crash Cembal 2 High Bongo Live Bongo Live Bongo Den High Conga Open High Conga High Timbale Low Timbale Live Timbale High Hoppo Cabesa Maraca Maraca Live Agogo Cabesa Maraca Maraca Live Mydogo Colore Live Mydogo Colore Live Mydogo Colore Live Mydogo Low Whistle Short Girli Live Mydogo Low Whistle Short Girli Live Mydogo Low Whistle Short Girli Live Mydogo Live Myd	Spiash Cymbal SDE Crobbel GDE	Splash Cymbal Cowdedi Cowdedi Cowdedi Cash Cymbal 2 Mybra-lap Ride Cymbal 2 Nigh Bongo Low Bongo Low Bongo Copen Hole Conga Open High Conga Open High Conga Open High Conga High Timbale Low Timbale L	Splash Cymbal Cowbell Cowbell Cowbell Cash Cymbal 2 (cash Cymbal 2 Vibra-lage Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open High Conga High Timbale Low Agogo Cobase Marzeas Short High Whistle Long Low Moste Short Gelfor Lorng Gairo Clares High Wood Block Low Woo	Splash Cymbal Cowbell Cowbell Cowbell Cowbell Crish Cymbal 2 Vibra-dalpa Ride Cymbal 2 Vibra-dalpa Ride Cymbal 2 High Bongo Low Bongo Low Bongo High Bongo Low Gonga High Thribale Low Timbale Low Timbale High Agogo Low Agogo Cebasa Marrica High Whistle Short High Whistle Short High Whistle Short High Whistle Short Midro Claro Guiro Chaw Gongo Clave Marrica Charles	Splash Cymbal Corbeel Corbeel Corpert Cymbal2 Vidra-slap Corpert Cymbal2 Vidra-slap Corpert Cymbal1 High Bongo Low Bongo High Conga Open High Conga Open High Conga Open High Conga Low Apogo Low Apogo Cabasa Marracea Short High Whistle Long Low Whistle Short Guivo Long Guiro Calves High Whostle Cong Guiro Calves High Whostle Cong Guiro Calves High Wood Slock Low Wood Block Mutte Cuizo Open Cuica Mutte Tutangle Coem Titangle Splate
	Sandhaurive Sandha Cymbai Cowbeil Cranh Cymbai Cowbeil Cranh Cymbai Cranh Cymbai Fish Cymbai Fish Cymbai Fish Cymbai Fish Cymbai Fish Cymbai Fish Conga Low Bongo Marer High Conga Low Bongo Low Bongo Marer High Conga Low Conga Low Conga Low Gonga Cabasa Maracca Shoon Ha Whittle (EXC) Conno Gourre (EXCS) Shoon Ha Whittle (EXCS) Conga Congress Fish Wood Block Low Gonga Conga Conga Fish Wood Block Low Gonga	Tambourine Spisoh Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Did Spison Bidd Cymbal 2 High Bongo Low Bongo Haufe High Conga Open High Conga High Timbale Low Timbale High Agogo Low Agogo Cabasa Marracs Shorn High Whistle Hong Low Cabasa Marracs Low Exact Open Timande Short High Whistle Hong Low W	Tambourine Spiash Cymbal Consbell Crash Cymbal 2 High Bong Ride Cymbal 2 High Bong Ride Cymbal 2 High Bong Ride Cymbal 2 High Bong Open High Conga Open Low Conga High Timbale Low Timbale Low Timbale Low Timbale Low High Agogo Low Mare High Agogo Low Mare Short High Whistle Lom Yaogo Cabasa Maracas Short High Whistle Lom Yaogo Cabasa Maracas Short High Whistle Lom Yood Block Low Wood Block Low	Tambourine Splash Cymbal 2 Owbell Crash Cymbal 2 Witer-dap Ride Cymbal 2 High Rongo Ride Cymbal 2 High Rongo Ride Cymbal 2 High Rongo Open Lingh Conga High Rongo Conga Lingh Rongo Conga High Wood Block Low Wood Block Marte Curs Open Cuica Mate Ciran Open Cuica Mate Ciran High Wood Block Low Wood Block Low Wood Block High Wood Block Low Wood Block High Wood Block Low Wood Block High Rongo	Tambourine Spiate Cymbal Consbell Crash Creshal 2 Visiz-Map Risks Cymbal Risks Compa Risks C	Spitath Cymbal 800 Crobbel 600	Splash Cymbal Cowdedi Cowdedi Cowdedi Cash Cymbal 2 Whar algo Ride Cymbal 2 Wigh Bongo Low Bongo Mute High Conga Open High Conga Open High Conga Open High Conga High Timbale Low Hose Low Whodel Short High Whotel Low Glotic Low Wood Block Low Hoo (EXCAI) Electricher Timpale [IN] Shaker Indig Bell Shaker In	Splash Cymbal Cowbedi Cowbedi Cash Cymbal 2 Vibra-lape Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Mute High Agogo Low Agogo Cobass Short Guiro Long Low Whotel Short Guiro Long Guiro Claves High Wood Block Low High Wood Block Low Wood Block Low Wood Block Low Wood Block Low High Wood Block Low	Spiab Cymbal Combell Combell Combell Crish	Splash Cymbal Cowbel Cowbel Cowbel Coment Cymbal2 Vibra-slap Concert Cymbal2 Vibra-slap Concert Cymbal1 Righ Bongo Low Rongo Marte High Conga Open High Conga Open High Conga Open Low Conga High Timbale Low Timbale Low Timbale High Agogo Low Agogo Cobasa Maracas Short High Whistle Long Low Whistle Short Guiro Claves High Wood Slock Low Wood Slock Low Wood Slock Low Wood Slock Matter Cide Open Cide Matter Cide Open Cide Matter Cide Open Tidangle Shaker Jingle Bell Bell Tree Castanets Matter Surdo
	Tambasine Tambas	Tambourin's Splash Cymbal Cowbell Cash Cymbal 2 Whra slass Nide Cymbal 2 Whra slass Nigh Tambale Now Timbale Nigh Agogo Cabasa Maraza Short High Whistle Short High Whistle Short High Whistle Short Gare Low Agogo Cabasa Maraza Maraza Nor Mindel Nor M	Tambourine Splash Cymbal Cowbell Crish Cymbal C Vibra-slap Bide Cymbal 2 High Bongo Low Bongo Den High Conga Open High Conga Open High Conga Open High Conga Low Timbale Short Righ Mistle Long Gourn Claese High Myood Block Low Wood Block Low Timbale Shuker Jingle Bell Rel Tree Lostanets	Tambourine Splash Cymbal 2 Whoradap Ride Cymbal 2 Whoradap Ride Cymbal 2 Whoradap Ride Cymbal 2 Whoradap Ride Cymbal 2 Low Bongo Low Bongo Low Bongo Low Bongo Cypen High Conga Low Agogo Cabasa Short High Whistle Long Low Whittle Short Guiro Long Guiro Calves High Wood Block Low Low Wood	Tambourine Splath Cymbal Consbell Crash Creshal 2 High Stongo Hide Cymbal 2 High Stongo Hide Cymbal 2 High Stongo Hide Cymbal 2 High Stongo Doen Lingh Conga Open High Conga Open High Conga Open High Conga High Timbale Low Gairo Low Hood Block Low Wood Block Low W	Splash Cymbal SDE Chwbel SDE Chwbel SDE Chwbel SDE Chwbel SDE Chwbel SDE Chwbel SDE Chwbal SDE Chwb	Splash Cymbal Cowbell	Splash Cymbal Cowbell Cowbell Cash Cymbal 2 Cysh Cymbal 2 Cysh Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open High Conga Open High Conga Open High Conga Chen Low Conga Chen Low Conga Low Timbale Low Timbale Low Timbale Low Timbale Low Timbale Low Timbale Low High Monga Compan Marzea Short High Whitel Long Low Whosle Short Guiro Long Guiro Collega Collega Short High Wood Slock Low Wood Block Morte Cuica Copen Cuica Cy Mont Cuica Shaker Ling Harlingle Shalt Tree Carsaneets	Splash Cymbal Convolal Convolation C	Splash Cymbal Corbeel Corbeel Corbeel Corpert Cymbal2 Vida-slap Corpert Cymbal2 Vida-slap Corpert Cymbal1 High Bongo Low Bongo High Conga Open High Conga Open High Conga Open High Conga High Timbale Low Timbale Short Gaive Long Guiro Claves Long Guiro Claves Long Guiro Claves Long Guiro Claves Low Wood Block Low Wood Block Low Wood Block Mutte Cuizo Open Cuiza Mutte Timpile Sholter Jingle Bell Bell Tree Catamets Mutte Surdo Open Surdo Open Surdo
	Tambasine Tambas	Tambourin's Splash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Risie Compa Risie Com	Tambourine Spiash Cymbal Conobell Crash Cymbal 2 Vibra riap Rice Cymbal 2 Vibra riap Rice Cymbal 2 Vibra riap Rice Cymbal 2 Vispa Bongo Rice Cymbal 2 Vispa Rice C	Tambourine Splash Cymbal 2 Owbell Crash Cymbal 2 Wise Ange Ride Cymbal 2 High Bongo Ride Cymbal 2 High Bongo Mute High Conga Open Low Conga High Timbale Low Timba	Tambourine Spiate (Symbal Consbell Crash Cembal 2 High Bongo Living Combal 2 High Bongo Living Bongo Living Bongo Living Bongo Open High Conga Open Living Longa Living Magogo Cabasa Mar acas Mar acas Mar acas Mar acas Long Model Long Guiro Carera High Whotal Long Guiro Long Guiro Carera Long Guiro Long Long Lingte Red Bell Tree Castaneets Mute Sundo	Spiash Cymbal 800 Crobbel 800 Crobbel 800 Crobbel 600 Low Bongo 600 Low Bongo 600 Low Conga 600 Mid Croga 600 Mid Croga 600 Mid Croga 600 Low Conga 600 Maraca 5hort High Mhristle Long Low Whistle 5hort Gairo Long Guiro 800 Maraca 5hort High Mhristle Long Low Whistle 5hort Gairo Long Guiro 800 Claws High Whood Block Low Wood Blo	Splash Cymbal Cowbell Cowbell Cowbell Cowbell Careh Cymbal 2 High Bongo Low Bongo Marte High Conga Open Low Bongo Open Low Bongo Open Low Bongo Open Low Conga Open Low Conga Low Timbale High Tenbale Low Tembale Low Good Cowbell Cow High White Short Guino Loog Guiro Calves High Wood Block Low W	Splash Cymbal Cowbedi Cowbedi Cash Cymbal 2 Vibra-lape Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Mute High Agogo Low Agogo Cobass Short Guiro Long Low Whotel Short Guiro Long Guiro Claves High Wood Block Low High Wood Block Low Wood Block Low Wood Block Low Wood Block Low High Wood Block Low	Spiab Cymbal Combell Combell Combell Crish	Splash Cymbal Cowbel Cowbel Cowbel Coment Cymbal2 Vibra-slap Concert Cymbal2 Vibra-slap Concert Cymbal1 Righ Bongo Low Rongo Marte High Conga Open High Conga Open High Conga Open Low Conga High Timbale Low Timbale Low Timbale High Agogo Low Agogo Cobasa Maracas Short High Whistle Long Low Whistle Short Guiro Claves High Wood Slock Low Wood Slock Low Wood Slock Low Wood Slock Matter Cide Open Cide Matter Cide Open Cide Matter Cide Open Tidangle Shaker Jingle Bell Bell Tree Castanets Matter Surdo
C4 00 00 00 00 00 00 00 00 00 00 00 00 00	Taphanirie Taphan Cymbai Taphan Cymbai Cowbell Crash Cymbal? Tapha Congo Rode Cymbal? High Bongo Low Rosgo Muter High Conga Low Conga High Conga Low Conga High Tenbade Low Timbale High Tenbade Low Timbale High Agogo Low Agogo Cabasa Mareza Short IR Whistle (EXC) Long Low Whistle (EXC) Compa Guiro (EXC) This Conga Congress (EXC) This Cong Low Whistle (EXC) Low Whood Block Low Shader High Whood Block Low Shader H	Tambourin's Splash Cymbal Cymbal Cowbell Cash Cymbal 2 Whra slash Nide Cymbal 2 High Bonoga Low Bonga Splash Cymbal 2 High Bonoga Chew High Timbale Low Bonga Open How Canga High Timbale Low Tambale High Agogo Cabasa Maracs Short High Whistia 2 Low Agogo Cabasa Maracs Short High Wholat Bour Timbale High Agogo Cabasa Maracs Short High Wholat Bour Short High Wholat Bour Short High Wholat Bour Short High Wholat Bour Bong Garre Chews High Wholat Bour High Wholat Bour Bong Garre Low Bong Garre Low Bong Garre Chew Bong Garre Chew Bong Garre Chew Chew Chew Chew Chew Chew Chew Che	Tambourine Spiash Cymbal Combell Crash Cymbal 2 Vibra-risap Ride Cymbal 2 Righ Bongo Low Bongo Rome High Conga Open High Conga Open High Conga Open Low Conga High Timbale Low Hongo Copen Low Conga High Timbale Low High Agogo Cobata Maracs Short High Whistle Short High Whistle Lom You Whistle Short Guiro Cong Guro Clove Rome Copen Guro Clove Rome Copen Copen Lingin Boll Shuke	Tambourine Splash Cymbal Cowbell Crash Cymbal 2 Wishra-diap Ride Cymbal 2 High Bongo Low Bongo Ride Cymbal 2 High Bongo Open High High Conga Open Low Conga High Timbale Low Timbale High Agogo Cabasa Maraza Maraza Maraza Low Agogo Cabasa Maraza Low Agogo Cabasa Maraza Low Gold High Wood Block Low Wood Block Low Wood Block Low High Whistle Long Cou	Tambourine Spiate (Symbal Consbell Crash Cembal 2 High Bongo Living Combal 2 High Bongo Living Bongo Living Bongo Living Bongo Open High Conga Open Living Longa Living Magogo Cabasa Mar acas Mar acas Mar acas Mar acas Long Model Long Guiro Carera High Whotal Long Guiro Long Guiro Carera Long Guiro Long Long Lingte Red Bell Tree Castaneets Mute Sundo	Spiash Cymbal 800 Crobbel 800 Crobbel 800 Crobbel 600 Low Bongo 600 Low Bongo 600 Low Conga 600 Mid Croga 600 Mid Croga 600 Mid Croga 600 Low Conga 600 Maraca 5hort High Mhristle Long Low Whistle 5hort Gairo Long Guiro 800 Maraca 5hort High Mhristle Long Low Whistle 5hort Gairo Long Guiro 800 Claws High Whood Block Low Wood Blo	Splash Cymbal Cowbell Cowbell Cowbell Cowbell Careh Cymbal 2 High Bongo Low Bongo Marte High Conga Open Low Bongo Open Low Bongo Open Low Bongo Open Low Conga Open Low Conga Low Timbale High Tenbale Low Tembale Low Good Cowbell Cow High White Short Guino Loog Guiro Calves High Wood Block Low W	Splash Cymbal Cowbell Cowbell Cash Cymbal 2 Cybra-lap Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open Low Zonga High Angogo Low Tanga Low Timbale High Angogo Low Agogo Cabasa Marzeat Short High Whitel Long Low Whod Hord Long Guiro Claves High Wood Block Mute Cuica Open Cuica Splath Sigh Wood Block Mute Cuica Open Cuica Splath Shart Fungle Shater Shate	Spiab Cymbal Combell Combell Combell Crish	Splash Cymbal Corbeel Corbeel Corbeel Corpert Cymbal2 Vida-slap Corpert Cymbal2 Vida-slap Corpert Cymbal1 High Bongo Low Bongo High Conga Open High Conga Open High Conga Open High Conga High Timbale Low Timbale Short Gaive Long Guiro Claves Long Guiro Claves Long Guiro Claves Long Guiro Claves Low Wood Block Low Wood Block Low Wood Block Mutte Cuizo Open Cuiza Mutte Timpile Sholter Jingle Bell Bell Tree Catamets Mutte Surdo Open Surdo Open Surdo
CA C	Taphanirie Taphan Cymbai Taphan Cymbai Cowbell Crash Cymbal? Tapha Congo Rode Cymbal? High Bongo Low Rosgo Muter High Conga Low Conga High Conga Low Conga High Tenbade Low Timbale High Tenbade Low Timbale High Agogo Low Agogo Cabasa Mareza Short IR Whistle (EXC) Long Low Whistle (EXC) Compa Guiro (EXC) This Conga Congress (EXC) This Cong Low Whistle (EXC) Low Whood Block Low Shader High Whood Block Low Shader H	Tambourin's Splash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Risie Compa Risie Com	Tambourine Spiash Cymbal Conobell Crash Cymbal 2 Vibra riap Rice Cymbal 2 Vibra riap Rice Cymbal 2 Vibra riap Rice Cymbal 2 Vispa Bongo Rice Cymbal 2 Vispa Rice C	Tambourine Splash Cymbal 2 Owbell Crash Cymbal 2 Wise Ange Ride Cymbal 2 High Bongo Ride Cymbal 2 High Bongo Mute High Conga Open Low Conga High Timbale Low Timba	Tambourine Spiate (Symbal Consbell Crash Cembal 2 High Bongo Living Combal 2 High Bongo Living Bongo Living Bongo Living Bongo Open High Conga Open Living Longa Living Magogo Cabasa Mar acas Mar acas Mar acas Mar acas Long Model Long Guiro Carera High Whotal Long Guiro Long Guiro Carera Long Guiro Long Long Lingte Red Bell Tree Castaneets Mute Sundo	Spiash Cymbal SDE Crobbel GDE	Splash Cymbal Cowbell Cowbell Cowbell Cowbell Careh Cymbal 2 High Bongo Low Bongo Marte High Conga Open Low Bongo Open Low Bongo Open Low Bongo Open Low Conga Open Low Conga Low Timbale High Tenbale Low Tembale Low Good Cowbell Cow High White Short Guino Loog Guiro Calves High Wood Block Low W	Splash Cymbal Cowbell Cowbell Cowbell Cowbell Cresh Cymbal 2 Vibra-lage Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open High Conga Open High Conga Open High Conga Open High Conga High Timbale Low Whood Block Low Whood Bloc	Splash Cymbal Cowbell Cowbell Cowbell Combell Combell Combell Combell Composition Composit	Splash Cymbal Corbeel Corbeel Corbeel Corbeel Corbeel Corbeel Corbeel Corbeel Vibra-slap Corbeel Vibra-slap Corbeel Vibra-slap Corbeel Vibra-slap Corbeel Vibra-slap High Brongo Low Brongo Norse High Corga Open High Corga Open High Corga Open Low Corga High Timbale Low Timbale High Agogo Low Agogo Corbesa Maraces Maraces Maraces Maraces Short Righ Whostle Long Low Whistle Short Guiro Long Guiro Carbes Long Guiro Carbes Long Guiro Carbes Nort Righ Whood Block Low Whood Block Low Whood Block Mutte Cuica Open Circla Mutte Triangle Shalar Jongla Bell Bell Tree Castarrets Mutte Surdo Open Surdo Applace * — — — — — — — — — — — — — — — — — — —
C4 00 00 00 00 00 00 00 00 00 00 00 00 00	Taphabarine Taphab Cymbai Conhell Crash Cymbal Crash Cymbal Crash Cymbal Tapha Bongo Inw Bongo Muter High Conga Inw Bongo Inw Bongo Inw Bongo Inw Bongo Inw Bongo Inw Conga Ingh Tenbale Inw Tenbale Inw Tenbale Inw Ministe IEXCI Inmg Lew Whistle IEXCI Inmg Lew Whistle IEXCI Inmg Lew Whistle IEXCI Inmg Lew Whistle IEXCI Inmg Gairo (IEXCI) Inmg High Wood Block Indu Whood Bloc	Tambourin's Splash Cymbal Cymbal Cowbell Cash Cymbal 2 Whra slash Nide Cymbal 2 High Bonoga Low Bonga Den High Timbale Low Bonga Open High Conga Open High Conga Open High Conga Open How Compa High Timbale Low Timbale High Agogo Cabasa Maraca Short High Wood Block Low Wood Block Low Wood Block Low My Cash Cabasa Maraca Short High Wood Block Low Mood Block Shaler Shal	Tambourine Spiash Cymbal Combell Crash Cymbal 2 Vibra-diap Rick Cymbal 2 High Bongo Rick Cymbal 2 High Rongo Open High Conga Open High Conga Open High Conga Open High Rongo Conga Righ Timbale Low Timbale Low Timbale Low Timbale Low Timbale High Rogo Cobaza Maracas Short High Whistle Long Low Whistle Short High Whistle Long Low Whistle Short Rich Com Gourn Claves High Wood Block Low Wood Block Maracas Righ Wood Block Maracas Righ Timbale Short Giaro Caves High Timbale Low Timbale High Timbale Low Timbale Rich Rich Timbale Caves Righ Rod Block Low Wood Block Maracas Rich Timbale Short Giaro Caves High Timbale Rich Timbale Caves Righ Rod Block Low Wood Block Lo	Tambourine Splash Cymbal 2 Owbell Crash Cymbal 2 Witer-dap Ride Cymbal 2 Witer-dap Ride Cymbal 2 Witer-dap Ride Cymbal 2 Low Bongo Low Bongo Low Bongo Low Bongo Cypen High Conga Open High Conga Open High Conga Low High Ronga Low Timbale High Ragoo Low Timbale High Ragoo Low Agogo Cabasa Short High Whistle Long Low Whittle Short Guiro Cong Guiro Caves High Wood Block Low Wood Blo	Tambourine Splath Cymbal Cowbell Crash Cembal 2 High Bongo Live Bongo Live Bongo Den High Tonga Open High Tonga Open High Conga Open High Conga Open High Conga Open High Conga High Timbale Live Timbale Live Timbale High Agogo Live Agogo Cabeta Maraca Maraca Maraca Long Guiro Curve High Wood Block Low Wood Block Low Wood Block Mate Cuica Open Curic Mate Timple Open Curic Mate Timple Splate Sp	Splash Cymbal SDE Chwbel SDE Chwb. SDE C	Splash Cymbal Cowbell Cowbell Cowbell Cowbell Careh Cymbal 2 High Bongo Low Bongo Marte High Conga Open Low Bongo Open Low Bongo Open Low Bongo Open Low Conga Open Low Conga Low Timbale High Tenbale Low Tembale Low Good Cowbell Cow High White Short Guino Loog Guiro Calves High Wood Block Low W	Splash Cymbal Cowbell Cowbell Cowbell Cash Cymbal 2 Vibra-lape Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open Low Angogo Cobassa Marrasa Short High Whotle Low Timbale High Wood Block Low Wood Block Mute Cuica Open Cuica Sy Mute Toungle Sign Triangle Sign Triangle Sign Triangle Sign Shaker Jangle Bell Bell Tree Cartaneets Mute Sudo Open Cuica Cartaneets Mute Sudo Open S	Splash Cymbal Cowbell Cowbell Cowbell Crigh Cymbal 2 Vibra-dalp Ride Cymbal 2 Vibra-dalp Ride Cymbal 2 High Bongo Low Bongo Low Bongo High Conga Open High Conga Open High Conga High Trebale Low Timbale Long Low Whatte Short High Whistle Long Low Claves High Wood Block Low Timagle Spaker Finghe Bell Bell Tree Castanets Mutz Surdo Open Surdo	Spilesh Cymbal Corbeel Corbeel Corbeel Corpert Cymbal2 Vibra-shap Corpert Cymbal1 High Bongo Low Bongo High Conga Open High Conga Open High Conga Open High Conga High Timbale Low Timbale High Agogo Low Agogo Low Agogo Low Agogo Low Agogo Low High Whistle Long Low Whistle Long Low Whistle Long Low Whistle Short Gaivo Long Guiro Clares High Wood Block Mutra Coica Open Caica Mutra Triangle Shabar Jingla Rell Bell Tree Castanets Mutra Surdo Open Tilangle Shabar Jingla Rell Bell Tree Castanets Mutra Surdo Open Surdo Applator
CA CS	Tambasine Tambas	Tambourin's Splash Cymbal Cowbell Crash Cymbal Cowbell Crash Cymbal 2 High Bongo Live Songo High Bongo Live Songo Open High Conga Open Low Canga High Timbale Live Maggo Cabase Marass Marass Marass Short High Whistle Short High Whode Low Whistle High Maggo Cabase Marass Marass Marass Marass Marass Marass Low Mogge Cabase Marass Ma	Tambourine Spiash Cymbal Combell Crash Cymbal 2 Vibra-risap Ride Cymbal 2 Righ Bongo Low Bongo Rober High Conga Copen High Gonga Copen Ligh Conga Copen Low Conga Righ Timbale Low Hongo Copen Low Conga Righ Timbale Low Hongo Copen Low Ministe Short High Monga Cabasa Maracas Short High Whistle Lom You Whistle Short Guiro Low Moggo Cabasa Maracas Short Righ Wholal Low Wood Block Maracas Copen Guira Mate Critica Copen Guira Mate Trinngle Open Trinngle Open Trinngle Dopen Trinngle Bell Bell Tree Castanets Mute State Shaker Limingle Bell Bell Tree Castanets Mute State Open Surdo Ope	Tambourine Splash Cymbal 2 Owbell Crash Cymbal 2 Vishr Angel Ride Cymb	Tambourine Spiate Cymbal Consbell Crash Creshal 2 Visig-Bang Risks Cymbal Risks Cymbal Copen High Conga High Timbale Live Timbale Visigh Righg Risks Short High Whistle Long Low Whistle Short Giaro Long Giaro Clabera Migha Risks Risk	Spiash Cymbal 800 Crobbel 800 Crobbel 800 Crobbel 600 Mariaca 600	Splash Cymbal Cowbell Cowbell Cowbell Cowbell Careh Cymbal 2 High Bongo Low Bongo Marte High Conga Open Low Bongo Open Low Bongo Open Low Bongo Open Low Conga Open Low Conga Cybell Cow Tambale High Turbale Low Tambale Low Low Cow Cowbell Cow Low Low Low Low Low Low Low Low Low L	Splash Cymbal Cowbell Cowbell Cowbell Cash Cymbal 2 Vibra-lape Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open Low Angogo Cobassa Marrasa Short High Whotle Low Timbale High Wood Block Low Wood Block Mute Cuica Open Cuica Sy Mute Toungle Sign Triangle Sign Triangle Sign Triangle Sign Shaker Jangle Bell Bell Tree Cartaneets Mute Sudo Open Cuica Cartaneets Mute Sudo Open S	Splash Cymbal Cowbell Cowbell Cowbell Combell Combell Combell Combell Composition Composit	Splash Cymbal Corbeel Corbeel Corbeel Corbeel Corbeel Corbeel Corbeel Corbeel Vibra-slap Corbeel Vibra-slap Corbeel Vibra-slap Corbeel Vibra-slap Corbeel Vibra-slap High Brongo Low Brongo Norse High Corga Open High Corga Open High Corga Open Low Corga High Timbale Low Timbale High Agogo Low Agogo Corbesa Maraces Maraces Maraces Maraces Short Righ Whostle Long Low Whistle Short Guiro Long Guiro Carbes Long Guiro Carbes Long Guiro Carbes Nort Righ Whood Block Low Whood Block Low Whood Block Mutte Cuica Open Circla Mutte Triangle Shalar Jongla Bell Bell Tree Castarrets Mutte Surdo Open Surdo Applace * — — — — — — — — — — — — — — — — — — —
CA CC C	Taphabarine Taphab Cymbai Conhell Crack Cymbal Crack Cymbal Track Track Cymbal Track Tra	Tambourin's Splash Cymbal Cowbell Crash Cymbal Cowbell Crash Cymbal 2 High Bongo Live Songo High Bongo Live Songo Open High Conga Open Low Canga High Timbale Live Maggo Cabase Marass Marass Marass Short High Whistle Short High Whode Low Whistle High Maggo Cabase Marass Marass Marass Marass Marass Marass Low Mogge Cabase Marass Ma	Tambourine Splash Cymbal Combell Crish Cymbal 2 High Bongo Live Bongo Ride Cymbal 2 High Bongo Ride Cymbal 2 High Bongo Ride Cymbal 2 High Bongo Rome High Conga Open High Conga Open High Conga Open Low Conga High Timbale Low Timbale High Agogo Low Agogo Cabasa Maracas Short High Whistle Short Guiro Long Guura Claves High Wood Block Mara Cuira Open Cuira Mute Tiringle Shaker Jingle Bell Bel Tree Castare Strd Open Surdo Chere Castare Strd Castare Castare Single Bell Bel Tree Castare Strd Open Surdo	Tambourine Splash Cymbal 2 Owbell Crash Cymbal 2 Witer-dap Ride Cymbal 2 Witer-dap Ride Cymbal 2 Witer-dap Ride Cymbal 2 Low Bongo Low Bongo Low Bongo Low Bongo Cypen High Conga Open High Conga Open High Conga Low High Ronga Low Timbale High Ragoo Low Timbale High Ragoo Low Agogo Cabasa Short High Whistle Long Low Whittle Short Guiro Cong Guiro Caves High Wood Block Low Wood Blo	Tambourine Splath Cymbal Cowbell Crash Cembal 2 High Bongo Live Bongo Live Bongo Den High Tonga Open High Tonga Open High Conga Open High Conga Open High Conga Open High Conga High Timbale Live Timbale Live Timbale High Agogo Live Agogo Cabeta Maraca Maraca Maraca Long Guiro Curve High Wood Block Low Wood Block Low Wood Block Mate Cuica Open Curic Mate Timple Open Curic Mate Timple Splate Sp	Spiash Cymbal 800 Crobbel 800 Crobbel 800 Crobbel 600 Mariaca 600	Splash Cymbal Cowbell Cowbell Cowbell Cowbell Careh Cymbal 2 High Bongo Low Bongo Marte High Conga Open Low Bongo Open Low Bongo Open Low Bongo Open Low Conga Open Low Conga Cybell Cow Tambale High Turbale Low Tambale Low Low Cow Cowbell Cow Low Low Low Low Low Low Low Low Low L	Splash Cymbal Cowbell Cowbell Cowbell Cash Cymbal 2 Vibra-lape Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open Low Angogo Cobassa Marrasa Short High Whotle Low Timbale High Wood Block Low Wood Block Mute Cuica Open Cuica Sy Mute Toungle Sign Triangle Sign Triangle Sign Triangle Sign Shaker Jangle Bell Bell Tree Cartaneets Mute Sudo Open Cuica Cartaneets Mute Sudo Open S	Splash Cymbal Convolal Convolation C	Spissh Cymbal Corbeel Corbeel Corbeel Corpert Cymbal2 Vidra-stap Cornert Cymbal2 Vidra-stap Concert Cymbal1 High Bongo Low Bongo High Conga Open High Conga Open High Conga High Timbale Low Timbale High Agogo Low Agogo Cabasa Maraca Short High Whistle Long Low Whistle Long Low Whistle Short Gaivo Low Agogo Cabasa Maraca Short High Whostle Long Low Whistle Short Gaivo Long Guico Low Guico Mutta Cuica Open Cuica Mutta Cuica Open Cuica Mutta Cuica Open Cuica Mutta Tilangie Open Tilangie Shalter Jingle Hell Bell Tree Castaness Mutta Surdo Open Surdo Applacoe *
C4 00 00 00 00 00 00 00 00 00 00 00 00 00	Tambasine Tambas	Tambourin's Splash Cymbal Cowbell Crash Cymbal Cowbell Crash Cymbal 2 High Bongo Live Songo High Bongo Live Songo Open High Conga Open Low Canga High Timbale Live Maggo Cabase Marass Marass Marass Short High Whistle Short High Whode Low Whistle High Maggo Cabase Marass Marass Marass Marass Marass Marass Low Mogge Cabase Marass Ma	Tambourine Splash Cymbal Combell Crish Cymbal 2 High Bongo Live Bongo Ride Cymbal 2 High Bongo Ride Cymbal 2 High Bongo Ride Cymbal 2 High Bongo Rome High Conga Open High Conga Open High Conga Open Low Conga High Timbale Low Timbale High Agogo Low Agogo Cabasa Maracas Short High Whistle Short Guiro Long Guura Claves High Wood Block Mara Cuira Open Cuira Mute Tiringle Shaker Jingle Bell Bel Tree Castare Strd Open Surdo Chere Castare Strd Castare Castare Single Bell Bel Tree Castare Strd Open Surdo	Tambourine Splash Cymbal 2 Owbell Crash Cymbal 2 Vishr Angel Ride Cymb	Tambourine Spiate Cymbal Consbell Crash Creshal 2 Visig-Bang Risks Cymbal Risks Cymbal Copen High Conga High Timbale Live Timbale Visigh Righg Risks Short High Whistle Long Low Whistle Short Giaro Long Giaro Clabera Migha Risks Risk	Spiash Cymbal SDE Crobbe® Crish Cymbal SDE Crobbe® Crish Cymbal Vibre-slap Ride Cymbal High Bongo Low Bongo SDE Mid Croga SDE Low Timbale High Timbale Low Timbale High Apopo Low Agopo Cabasa SDE Marace Short High Whistle Long Guiro SDE Claves High Whistle Long Guiro SDE Claves High Wood Block Low Wood Block Mute Curao Open Cura Muter Triangle Staker Irigh Boll Bell Tree Castanets Muter Surdo Open Surdo — — — — — — — — — — — — — — — — — — —	Splash Cymbal Cowbell Cowbell Cowbell Cowbell Careh Cymbal 2 High Bongo Low Bongo Marte High Conga Open Low Bongo Open Low Bongo Open Low Bongo Open Low Conga Open Low Conga Cybell Cow Tambale High Turbale Low Tambale Low Low Cow Cowbell Cow Low Low Low Low Low Low Low Low Low L	Splash Cymbal Cowbell Cowbell Cowbell Cash Cymbal 2 Vibra-lape Ride Cymbal 2 High Bongo Low Bongo Mute High Conga Open Low Angogo Cobassa Marrasa Short High Whotle Low Timbale High Wood Block Low Wood Block Mute Cuica Open Cuica Sy Mute Toungle Sign Triangle Sign Triangle Sign Triangle Sign Shaker Jangle Bell Bell Tree Cartaneets Mute Sudo Open Cuica Cartaneets Mute Sudo Open S	Splash Cymbal Cowbell Cowbell Cowbell Combell Combell Combell Combell Composition Composit	Splash Cymbal Cowbell Cowbell Coment Cymbal2 With-a-lap Concent Cymbal2 With-a-lap Concent Cymbal1 High Bongo Low Bongo Marte High Conga Open High Conga Open High Conga Open Low Conga High Timbale Low Timbale Low Timbale High Apopo Low Apopo Cabasa Maracas Short High Whistle Long Low Whistle Short Guire Long Low Whistle Short Guire Long Guiro Claves High Wood Block Mutre Cuica Open Cuica Mutre Triangle Open Triangle Shelter Jingle Bell Bell Bell Bell Tree Castanets Maracas Maracas Maracas Maracas Mither Cuica Open Cuica Mutre Triangle Open Triangle Open Surdo Applaces *

o	PC: 50 [CC32: 2] Ethnic	PC: 51 [CC32: 2] Kick & Snare	PC: 52 [CC32: 2] E-40 Modified	FC: 57 (CC32: 2) SFX	PC: 58 (CC32: 2) Mythm FX	PC: 128 (CC32: 2) CM-64/32L	PC: 1 (CC32: 1) Standard	PC: 9 [CC32: 1] Room	PC: 17 (CC32: 1) Power	PC: 25 (CC32: 1) Electronic
_										
2									-	
3	**	_	_		-					
4	-	_	***	-	_			-		-
5		***	-		-					
	-		-		_	-		_		
7		-		-		_				~
	-					_				
12	d									
11	-									
12								+-		
	-									
14	-							**		
15	~								-	
16				***		_				
17	_			-	_		-			
			_	-	-	_	_			~
19					-	_	_	_	_	
20	-					-				_
- 22				-						-
23	1									
C.C. ABORD					**					
	Finger Snap				~-					
	Tambourine	_				-				_
SALES OF THE SALES	Cattanets									
	Crash Cymbail			~			High Q	High Q	High Q	High Q
9	Share Roll						Slap Scratch Push	Slap Scratch Burk	Slap Soutch Duck	Slap
10	Concert Soure Drum	_		_			Scratch Pull	Scratch Push Scratch Pull	Scratch Push Scratch Pull	Scratch Push Scratch Puli
	Concert Cymbal	_	-	Scratch Push2 [EXC1]			Sticks	Sticks	Sticks	Sticks
製剤 12 関題	Concert #D1		-	Scratch Pull2 [EXC1]			Square Click	Square Click	Square Click	Square Click
1 1544	Jingle Sell			Cutting Noise 2 Up	_		Metronome Click	Metronome Click	Metronome Click	Metronome Click
er Centrale	Bell Tree			Cutting Noise 2 Down			Metronome Bell	Metronome Bell	Metronome Bell	Metronome Bell
	Bar Chimes		TR-707 8D	DistortionGustarCuttin		Kick 1	Kick Drum2 / Jazz DB2			Kick Drum2 / Jazz 082
	Wadaiko film *		TR-707 BD	DistortionGuitarCuttin		Kick 1	Kick Drum / Jazz D81	Kick Drum 1 / Jazz D81	MONDO Kick	Flec BD
Bon to a to to	Stime Taiko		TR-707 Rim	Bass Slide	Reverse Concert BO1	Side Stick	Side Stick	Side Stick	Sicie Stick	Side Stick
	Atarigane		TR-707 SD	Pick Scrape	Reverse Power Kirk 1	Fat Snare	Snare Drum1	Snare Drum1	Gated SD	Elec SD
0 75155	Hyoushigi	Standard 1 Kick I	Hand Clap 22 TR-707 SD	High Q	Reverse Electric Kick 1	Hand Clap	Hand Clap	Hand Clap	Hand Clap	Hand Clap
	Ohkawa	Standard 1 Kick 2	Tom	Slap	Reverse Snare 1	Elec. Snare	Snare Drum?	Snare Drum2	Snare Drum2	Gated SD
	High Kotsuzum	Standard 2 Kick 1	TR-707 HH-c	Scratch Push (EXC7) Scratch Pull (EXC7)	Reverse Standard set1	Tom Close HiHat	Low Tora2	Room Low Tom2	Room Low Tork?	Elec Low Torn2
	Low Kotsuzumi	Standard 2 Kick 2	Tom	Sticks	Reverse Tight Snare		Closed Hi-hat1 (EXC1)	Closed Hi-hat?	Closed Hi-hat1	Closed Hi-hat1
.11	Ban Gu	Kick 1	7R-707 HH-c	Square Click	Reverse Dance Snare	Tom Open HiHat2	low Tom1	Room Law Tom1	Room Low Tom1	Elec Low Tom1
100	Big Gong	Kick 2	Torn	Metronome Click	Reverse 806 Snare	Tom Timatz	Pedal Hi-hat (EXC1) Mid Tom2	Pedal Hi-hat	Pedal Hi-hat	Pedal Hi-hat
15	Small Gong	Soft Kirk	TR-707 НИ-а	Metronome Bell	Reverse Tom1	Open Hi Hat	Open Hi-hat1 (EXC1)	Room Mid Tom2	Room Mid Tom2	Elec Mid Tom2
12.2	Bend Gong	Jazz Kick 1	Tom	Guitar Fret Noise	Reverse Tom2	fom	Mid Tom1	Open Hi-hat1 Room Mid Tom1	Open Hi-hat1 Room Mid Tom1	Open Hi-hat1
	Thai Gong	Jazz Kick 2	Tom	Guitar Cutting NoiseU		Tom	High Tom?	Room Hi Tom2	Room Hi Tom2	Elec Mid Tom1 Elec Hi Tom2
200 200	Rama Cymbai	Concert BD	TR-707 Crash	Guitar Cutting Noise	Reverse Slap	GS Crash	Crash Cymbal 1	Crash Cymbal 1	Crash Cymball	Crash Cymbal1
0 19 11 11	Gameian Gong	Room Kick I	Tom	String Slap of Double	Reverse Cymbal 1	Tom	High Tors1	Room Hi Tom I	Roam Hi Tornt	Elec Hi Tom1
	Udo Short (EXC1)	Room Kick 2	Ride Cymbal	Fl. Key Click	Reverse Cymbal2	Ride Cymbal	Ride Cymbal1	Ride Cymbal1	Ride Cymbal 1	Ride Cymbal1
2	Udo Long (EXC1)	Power Kick 1	Dholla2 Dom2	Laughing	Reverse Open Hi-hat	_	Chinese Cymbal	Chinese Cymbal	Chinese Cymbai	Reverse Cymbal
PIC.	Udo Slap	Power Kick 2	Dholla 2 Sak	Scream	Reverse Ride Cymbal	_	Ride Bell	Ride Beli	Ride Bell	Ride Bell
es :	Bendir	Electric Kick 2	Tambourine	Punch	Reverse CR-78 OHH	Tambourine	Tambourine	Tambourine	Tambourine	Tambourine
	Req Dum Req Tik	Electric Kick 1 *	Dholla2 Rim1	Heart Beat	Reverse Closed Hi-hat		Spiash Cymbai	Splash Cymbal	Spiash Cymbai	Splash Cymbal
L. Carrier	Tabia Te	808 Bass Drum	Cowbell Dholla2 RimC	Footsteps1	Reverse Gong	Cowbell	Cowbell	Cowbell	Cowbell	Cowbell
5.6	Table Na	909 Bass Drum	Cabasa	Footsteps2	Reverse Bell Tree		Crash Cymbal2	Crash Cymbai2	Crash Cymbal2	Crash Cymbal2
	Tabla Tun	Dance Kick	Doff 2 Dom 2	Applause * Door Creaking	Reverse Guiro Reverse Bendir		Vibra slap	Vibra slap	Vibra-slap	Vibra-slap
14.18	Tabla Ge	Standard 1 Snare 1	Doff2 Sak 18	Door	Reverse Gun Shot	High Bongo	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2	Ride Cymbal2
63	Tabia Ge Hi	Standard 1 Snare 2	Low Bongo	Scratch	Reverse Scratch	Low Bongo	High Bongo Low Bongo	High Bongo	High Bongo	High Bongs
3.5 E. S. (1)	Taking Drum *	Standard 2 Snare 1	Doff 2 Sak 2	Wind Chimes *	Reverse Laser	Mute Conga	Mute High Conga	Low Bongo Mute High Conga	Low Bongo Mute High Conga	Low Bange
63	Bend Talking Drum *	Standard 2 Snare 2	High Bongo	Car-Engine	Key Click	Conga	Open High Conga	Open High Conga	Open High Conga	Mute High Conga
Faller	Cariti	Tight Snare	Doff 2 Rim 3	Car-Stop	Tekno Thio	Conga	Low Conga	Low Conga		Open High Conga
	Djembe	Concert Snare	Tabla 1 Dom 2	Car-Pass	Pop Drop	Timbales	High Timbale	High Timbale	Low Conga High Timbale	Low Conga High Timbale
-6	Djembe itim	Jazz Snare 1	Tabla Roll	Car-Crash *	Woody Slap	Timbales	Low Timbale	Low Timbale	Low Timbale	Low Timbale
AND THE	Timbales Low	Jazz Snare 2	Tabia 2 Sak	Siren	Distortion Kick *	Agogo	High Agaga	High Agogo	High Agogo	High Agoga
S15.00000	Timbales Paila	Room Snare 1	Tabla fx	Train	Sym Drop	Agaga	Low Agaga	Low Agogo	Low Agogo	Low Agago
(0	Timbales High	Room Snare 2	Tabla2 Tak tD	Jelpiane *	Reverse High Q	Cabase	Cabasa	Cabasa	Cabasa	Cabasa
	Cowbeil Vi Bassa	Power Snare 1	Tabla 2 Tik	<u>Helicopter</u>	Pipe	Maracas	Maracas	Maracas	Maracas	Maracas
	Hi Banga Ław Banga	Power Snare 2 Gated Share	Tabla2 Rim 2 Rek 2 Dom 18	Starship *	ice Black	ShrtWhistle	Short Hi Whistle [EXC2]		Short Hi Whistle	Short Hi Whistle
73	Mute Hi Conga	Dance Snare 1	Rek 2 Rim 2	Gun Shot Machine Gun	Digital Tambourine *	LongWhistle	Long Low Whistle (EXC)			Long Low Whistle
CANADA A	Open Hi Conga	Dance Snare 2	Rek Dom 1	Machine Gun Lasergun	Alias Modulated Bell	Vibraslap	Short Guiro	Short Guiro		Short Guiro
75	Mute Low Conga	Disco Snare	Rek 2 Tak 1	Explosion *	Spark	Claves	Long Guiro Claves	Long Guiro		Long Guiro
	Conga Slap	Electric Snare2	Rek 2 Tak 2C	Dog	Metalic Percussion	Laughing	High Wood Block	Claves High Wood Block		Claves
	Open Low Conga	House Snare *	Rek 2 Sak 1	Horse-Gallop	Velocity Noise FX	Screaming	Low Wood Block	High Wood Block Low Wood Block		High Wood Block
78	Conga Slide *	Electric Snare 1	Hager 2	Birds *	Stereo Noise Clap *	Punch	Mute Cuica (EXC4)	Mute Cuica		Low Wood Block Mute Cuica
1987年	Mute Pandiero	Electric Snare 3 *	Rek2Khan CI2	Rain	Swish	Heart Beat	Open Cuica (EXC4)	Open Cuica		Open Cuica
80	Open Pandiero	BOR Snare 1	Zit 2	Thunder	Slappy *	Footsleps		Mute Triangle		Mute Triangle
SHOWN ROSE	Open Surdo (EXC2)	908 Snare 2 *	Rek2Khan Op?		Voice Ou	Footsteps				Open Triangle
	Mute Surdo (EXCZ)	909 Snare 1	Rek 2 Roll		Voice Au	Applause	5haker			Shaker
-	Temborim	909 Snare 2 *	Rek 2 Sak 1		Hoo	Creaking		Jingle Bell		lingle Bell
ere -	High Agoge	Brush Tap1	Sagat Mid		Tape Stop! *	Door	Bell Tree	Bell Tree		Beil Tree
85	Low Agogo Shaker	Brush Tap2	Sagat Hi		Tape Stop2 *	Scratch			Castanets	Castanets
87	High Whittle (EXCI)	Brush Slap I	Sagat Sak		Missile *	Wind Chimes			Mute Surdo	Mute Surdo
-	Low Whistle (EXC3)	Brush Slap2	lingle Bell L		Space Bird	Car-Engine	Open Surdo (EXC6)	Open Surdo		Open Surdo
	Mute Cuica (EXC4)	Brush Slap3 Brush Swirt1	Zaghrouta5m3		Flying Manster	Car-Stop	-			
99	Open Cuica (EXC4)	Brush Swirl2	ZaghroutaEd3 TablaNurDom3			Car Pass	***************************************	-		to:
-	Mute Triangle (EXCS)	Brush Long Swirl	Nakrazhan 1			Car-Crash		~		***
92	Open Triangle (EXCS)		TablaNurRim2			Siren			·	
	Short Guiro (EXC6)	_	Nakrazhan 2			Train				-
						<i>l</i> etplane				**
94	Long Guiro (EXCE)	***	TablaNutTak 1	_						
_	Long Guiro (EXCE) Cabasa Up	_	TablaNurTak3 TR-707 BD			Helicopter Starship			"	

		PC: 50 (CC32: 2) Ethnic	PC: 51 [CC32: 2] Kick & Snare	PC: 52 CC32: 2 E-40 Modified	PC: 57 (CC32: 2) SFX	PC: 58 (CC32: 2) Rhythm FX	PC: 128 (CC32: 2) CM-64/32L	PC: 1 (CC32: 1) Standard	PC: 9 (CC32: 1) Room	PC: 17 (CC32: 1) Power	PC: 25 (CC32: 1) Electronic
2)[0	96)	(Cabasa Down)	()	()	()		(Gun Shot)	()	()		(-)
-	97	Ciaves				-	Machine Gun				
9	8	High Wood Block	_				Lasergun				
1	56	Low Wood Block			_		Explosion				
1	00	_	v-	***		_	Dog				
- 1	101	_					HorseGallop				
L	102	_			_		Bird				
- 1	03	_		-			Rain				
-	104		-			-	Thunder				
- 1:	105		-				Wind				
H	106	-	-				Seashore				-
- 1	107	-					Stream				
a i	ins.				-	_	Bubble	-	-	***	
٣.	102	-			-		-	-	-	_	
- [10		***		_		~	-		-	
-	- 10			186				_		_	
- 1	112	_									
ŀ	113	 									
	113	_					-	_		_	
T	115				_	_			-		-
L	113				_	_					
ı	117										
- }-	118		_		-	-					
- (119		-	_	**		***		*		
أوح	120			-		-		_	-		-
٦	120		***				_	_			
ı	122	1 									
- 1							-		-		
- 1	124	=				-	~	-			***
}					-						
- 1	125				**					_	_
ł	126										_
G9	127										


		PC: 26 [CC32: 1] TR-808	PC: 33 (CC32: 1) Jazz	PC: 41 [CC32: 1] Brush	PC: 49 [CC32: 1] Orchestra	PC: 57 (CC32: 1) SFX	PC: 128 (CCI2: 1) CM-64/123.
(C7)	(96)	()	()	()	()	()	()
(97		-	_	***		Machine Gun
	98				_		Laxergun
			_		***		Explosion *
	100	-			-		Dog
	101	_					Horse-Gallop
	(12		_			-	Airds *
	103	_		_		-	Rain *
	104	-		-			Thunder
	105						Wind
	106	atra .					SeaShore
	107	_					Stream '
CB	108	_	-			***	Rubble *
	109	-					**
	110						
	112	-		_	-		
	113						
	111		*			_	
	115						
			_		***		
	117						141
	118	-	_				
	119						
~	120		_		-		
-	120				-	-	
	122				_		
	123			_		-	**
	124						
	125	-				**	**
	125	-		-			-
	1						
Ģ9	127						


		PC: 26 (CC32: 1) TR-808	PC: 33 (CC32: 1)	PC: 41 (CC32: 1)	PC: 49 [CC32: 1]	PC: 57 [CC32: 1]	PC: 128 (CC32: 1)
C-1	<u></u>] ~-	lazz	Brush	Orchestra	SFX	CH4/31
					-		
	2						**
ı	4						
İ	5						-
}							
-	, S	-					
	9 16					_	**
	11						**
a	12	_	-	_	-		**
ŀ	14	-	-	-	-		
-		-					_
- }-	16				**	_	
	17						*
	19						M**
1					-		
F							**
1	23	-	-				-
cı [24 × 100			_			-
							-
	4 2923	High Q Slap	High Q Slap	High ()	Closed Hi-hat2 [EXC1] Pedal Hi-hat [EXC1]		
	29	Scratch Push	Scratch Push	Slap Scretch Push	Open Hi-hat2 [EXC1]		
	(1) (1)	Scratch Pull	Scratch Pull	Scratch Pull	Ride Cymbal 1		
T. N.	1	Sticks Square Click	Sticks Square Click	Sticks Square Click	Sticks Square Click		*
1	3	Metronome Click	Metronome Click	Metronome Click	Metronome Click		
175	Service and	Metronome Bell Kick Drum2 / Jazz DB2	Metronome Bell Kick Drum2 / Jazz DB2	Metronome Bell Jazz BD 2	Metronome Bell Concert BD2	_	CIVE Day
2	36	808 Bass Drum	Kick Drum! / Jazz DB1	Jazz BD 1	Concert BD1	_	CM Kick Drum CM Kick Drum
200		808 Rim Shot 806 Share Drum	Side Stick	Side Stick	Side Stick	_	CM Rim Shot
200		Hand Clap	Snare Drum) Hand Clap	Brush Tap Brush Slap	Concert SD Castanets	High Q	CM Share Drum CM Hand Clap
51.5	40	Snare Drum2	Snare Drum2	Brush Swirt	Concert SD	Slap	CM Electronic Snare
2007		808 Low Tom2 808 CHH (EXC1)	Low Tom2 Closed Hi-hat1 [EXC1]	Low Torn2 Closed Hi-hat1	Timpani F#	Scratch Push [EXC7] Scratch Push (EXC7)	CM Acoustic Low York CM Closed High Hat [EXC1]
Ž		358 Low Tam1	Law Toml	Low Tom1	Timpani G	Sticks	CM Acoustic Low Tom
		868 CHH (EXC1) 808 Mid Tom2	Pedal Hi-hat [EXC1] Mid Tom?	Pedal Hi-hat Mid Tom2	Timpani G# Timpani A	Square Cick	CM Open Hi-Hat2
	11.	808 CHH (EXC1)	Open Hi-hat1 [EXC1]	Open Hi-hat1	Timpani Alf	Metronome Click Metronome Bell	CM Acoustic Middle Tom CM Open Hi-Hart [EXC.]
22	47 48	806 High Tom2	Mid Tom1	Mid Tom)	Timpani 8	Guitar Fret Noise	CM M. TomAcqustic
7 198		808 Cymbal	High Tom2 Crash Cymball	Tom2 Crash Cymbai1	Timpani c	Guitar cutting noise/up	CM Acoustic High Tom
5	P ESSENCE THE PERSON		CLOSE CAMPAIL	Creat Chinesis	Timpani cit	Guitar cutting	CM Crash Cymbal
5	X STATE	808 Hi Tom 1	High Tom1	High Tom!	Timpani d	Guitar cutting String slap of double	CM Crash Cymbal CM Acoustic High Ton
Š				High Tom! Ride Cymbal!	Timpani d Timpani dë	String slap of double FLKey Click	
58	9 9	808 Hi Tom1 Ride Cymbal I Chinese Cymbal Ride Bell	High Tom1 Ride Cymbal1 Chinese Cymbal Ride Bell	Ride Cymbal I Chinese Cymbal Ride Bell	Timpani d Timpani dë Timpani e Timpani f	String slap of double FI Key Click Laughing Scream	CM Acoustic High Tom CM Ride Cymbal
2.0		808 Hi Tom I Ride Cymbal I Chinese Cymbal Ride Bell Tambourine	High Tom1 Ride Cymbal1 Chinese Cymbal Ride Bell Tambourine	Ride Cymbal I Chinese Cymbal Ride Bell Tambourine	Timpani d Timpani dë Timpani e Timpani f Tambourine	String slap of double FI Key Click Laughing Scream Punch	CM Acoustic High Tom OM Ride Cymbal
		808 Hi Tom1 Ride Cymbal1 Charlese Cymbal Ride Bell Tambourine Splash Cymbal 808 Cowbell	High Tom1 Ride Cymbal1 Chinese Cymbal Ride Bell Tambourine Splash Cymbal Cowbell	High Tom1 Ride Cymbal I Chinese Cymbal Ride Bell Tambourine Splash Cymbal Cowbell	Timpani d Timpani d Timpani d Tompani e Timpani f Tambourine Splash Cymbal Cowbell	String slap of double Ft Key Click Laughing Scream Punch Heart Best Footsteps1	CM Acoustic High Tom CM Ride Cymbal
\$ 1.5 m		808 Hi Tom1 Ride Cymbal1 Charlese Cymbal Ride Self Tambourine Splash Cymbal 808 Cowbell Crash Cymbal2	High Tom1 Ride Cymbal1 Chinese Cymbal Ride Bell Tambourine Splash Cymbal Cowbell Crash Cymbal2	High Tom1 Ride Cymbal I Chinese Cymbal Ride Bell Tambourine Splash Cymbal Cowbell Crash Cymbal2	Timpani d Timpani d Timpani d Timpani e Timpani f Tambourine Splash Cymbal Cowbell Concert Cymbal2	String viap of double FI Key Click Laughing Suream Punch Heart Best Footsteps 1 Footsteps 2	CM Arousik High Tom OM Ride Cymbal
4 4 4 4		809 Hi Tom I Ride (cymbal) Chrese Cymbal Ride Bell Tambourine Splach Cymbal 808 Cowbell Cash Cymbal Vibra-Iap Ride Cymbal2	High Tom1 Ride (ymbal1 Chinese Cymbai* Ride Bell Tambourine Splash Cymbal Cowbell Crash Cymbal2 Vibra-Hap Ride Cymbal2	High Tom1 Ride Cymbal Ride Cymbal Chinese Cymbal Ride BeB Tambourine Splash Cymbal CowbeB Crash Cymbal2 Vibra-lap Ride Cymbal2	Timpani d Timpani d Timpani d Timpani e Timpani e Timpani f Tambourine Splash Cynbal Cowbell Concert Cymbal2 Vibra-slap	String slap of double Ft Key Click Laughing Scream Punch Heart Best Footsteps1	CM Arousik High Tom OM Ride Cymbal
4		808 Hi Tom 1 Ride Cymball Chines Cymbal Chines Cymbal Ride Bell Tambourine Splash Cymbal 808 Cowbell Czab Cymbal Vibra-slap Ride Cymbal High Bongo	High Tom1 Ride Cymbal1 Ride Cymbal1 Chinese Cymbal Ride Bell Tambourine Splash Cymbal Cowbell Crash Cymbal2 Vibra-slap Ride Cymbal2 High Bongo	High Tom1 Ride Cymbal Ride Eymbal Ride Be# Tambourine Splash Cymbal Cowbe# Crash Cymbal Cybra-slap Ride Cymbal2 High Bongo	Timpani di Timpani di Timpani di Timpani e Timpani e Timpani f Tambourine Spiash Cymbal Cowbell Concert Cymbal2 Vibra-laip Concert Cymbal1 High Bongo	String slap of double F1 Key Click Laughing Suream Punch Heart Beat Footsteps1 Footsteps2 Applause * Door Creaking	CM Ansadis High Tom OM Ride Cymbal
4 5		808 Hi Tom I Ride Cymball Ride Cymball Ride Sphall Ride Bef Yambourine Splach Cymball 808 Cowbell Czeb Cymball Ride Ride Ride Ride Ride Ride Ride Ride	High Tom1 Ride (ymball Ride (ymball Ride SeB Tambourine Splash (ymbal Cowbell Crash (ymbal Crash (ymbal Ride (ymbal Ride (ymbal Ride (ymbal)	High Tom1 Ride Cymbal Ride Cymbal Chinese Cymbal Ride BeB Tambourine Splash Cymbal CowbeB Crash Cymbal2 Vibra-lap Ride Cymbal2	Timpani di Timpani di Timpani di Timpani e Timpani e Timpani f Tambourine Splash Cymbal Concert Cymbal2 Vibra-lisp Concert Cymbal2 Vibra-lisp Concert Cymbal1 High Bongo	String slap of double F1 Key Click Laughing Suream Punch Heart Best Footsteps1 Footsteps2 Applause * Door Creaking	CM Acousic High Tom CM Ride Cymbal
4 6 6		908 Hi Tom I Ride Cymball Chriese Cymbal Ride Bell Tambourine Splach Cymbal Splach Cymbal Splach Cymbal Vidra-tlap Ride Cymbal Vidra-tlap Ride Cymbal Low Borgo Low Borgo Boll High Conga 808 High Conga	High Tom! Refe (ymbal) Refe (ymbal) Refe (ymbal) Refe Bell Tambourine Spitan (ymbal) Combell Grash (ymbal) Vibra-slav High Bongo Low Bon	High Tom1 Ride Cymbal Ride Symbal Ride Be8 Tambourine Splash Cymbal Cowbell Crash Cymbal Cvibra-tias Ride Gymbal Low Bongo Low Bongo Multe High Conga Open High Conga	Fimpani d Timpani d Timpani e Timpani e Timpani e Timpani i Tambourine Splash Cymbal Cowbell Cowbell Concert Cymbal2 Vibra-lag Concert Cymbal1 High Bongo Low Bongo Mute High Conga Open High Conga	Syring dap of double R Key Citch Lauphing Suream Punch Heart Best Footsteps1 Footsteps2 Applases* Door Cessing Door Soratch Wind Chimes* Car Engine	CM Arosic High Tom OM Ride Cymbal CM Tambourine CM Cowbell CM Cowbell CM High Bongo CM Low Bengo CM High Conga CM Mass High Conga
4		808 Hi Tom I Ride Cymball Ride Cymball Ride Sphall Ride Bef Yambourine Splach Cymball 808 Cowbell Czeb Cymball Ride Ride Ride Ride Ride Ride Ride Ride	High Tom1 Ride (ymball Ride (ymball Ride SeB Tambourine Splash (ymbal Cowbell Crash (ymbal Crash (ymbal Ride (ymbal Ride (ymbal Ride (ymbal)	High Tom1 Ride Cymbal Chinese Cymbal Chinese Cymbal Ride Bel Tambourine Splash Cymbal Cowbell Crash Cymbal Vibra-Hap Ride Cymbal2 High Bongo Low Bongo Mute High Conga	I'mpani di I'mpani di I'mpani di I'mpani di I'mpani e I'mpani e I'mpani e I'mpani e I'mpani di I'mp	String stap of double FF Key Clack Laughing Suream Punch Heart Best Footsteps1 Footsteps2 Applause * Door Geaking Door Seratch Wind Chimes *	CM Actasids High Tom OAR Ride Cymbal
6 6 6		1999-14 Tomal Rude Cymbral Rude Cymbral Rude Bed Tentosourine Syston Cymbral 898 Combell Crash Cymbral Rude Bed Willer-1480 Rude Crash Cymbral Rude Compa 808 Rude Compa 8	High Tomi Bade (ymbal Chinese (ymbal Ride Bel Tambourine Solstin (ymbal Cowbell Grash (ymbal Grash (ymbal High Bongo Low Bongo Mute High Conga Low Conga High Conga Low Conga High Timbale Low Low Low Low Low Low Low Low Low Low	High tron1 Ride Cymbal I Ride Rymbal I Chinese Cymbal Ride Bel Ride Bel Tambourine Splash Cymbal Cowbell Ride Wymbal Vibra-Hap Ride Cymbal2 High Bongo Low Bongo Muta High Conga Low Conga	Impael d Timpael d Timpael d Timpael e Timpael	String day of double PI Key Cick Laughing Suream Punch Heart Best Footsteps2 Applases* Door Creaking Doo Scratch Wind Chimes* Car-Engine Car-Pess Car-Pess Car-Pess Car-Pess	GM Actasid: High Tom ON Ride Cymbal ———————————————————————————————————
6 6 6		1928 ht from 1 Note Cymbal 1 Note Cymbal 1 Note Bed 1 N	High Tomi Rde Cymbal O'mere Cymbal Ride Bel Tambourine Sptath Cymbal Cowbell Cresh Cymbal Cresh Cymbal Vibra-Lap Ride Cymbal High Bongo Low Bongo Low Bongo Low Bongo Low Bongo Low Low Low Low High Conga Low Conga Low Conga Low Conga Cymbal Combal Cowbell Low Conga Cymbal Cowbell Cow	High Tom1 Ride Cymbal Ride Symbal Ride Bell Tambourine Solash Cymbal Cowbell Crash Cymbal Crash Cymbal Crash Cymbal Ride Cymbal High Bongo Low Bongo Muta High Conga Open High Conga High Timbale	Impael d Timpael d Timpael d Timpael e Timpael	Syring day of double T Key Click Laughing Suream Panich Heart Best Footsteps2 Applase* Door Cessing Door Gesting Coart-Engine Car-Engine Car-Stop Car-Sto	CM Acasidis High Tom OAR Rick Cymbal
6 6 6		928 H Tem 1 Side Cymbal 1 Onnes Cymbal 1 Onnes Cymbal 8 Ride 8de 1 Tarbourine 5/sha (Cymbal 806 Sowbell Cospa 806 Combal 1 Cash Cymbal 2 Vidra-tias 1 High Boogo 1 Low Boogo 808 High Conga 808 Med Conga 808 Med Conga 808 Low Conga High Temaske 1 Low Finnaske 1	High Tomit Aide Cymbal Chinese Cymbal Ride Bel Ride Cymbal Crubbll Crub Cymbal Crub Cymbal Crub Cymbal Crub Cymbal Ride Cymbal Ride Ride Ride Cymbal Ride Ride Ride Ride Ride Ride Ride Ride Ride	High Trom 1 Kide Cymbal I Chinese Cymbal Ride Bei Ride Bei Cymbal Ride Bei Cash Cymbal Cowbell Cash Cymbal Cowbell Ride Bei Ride Cymbal Cowbell Ride Ride Cymbal Philips Bongo Low Bongo Mute High Conga Cypen High Conga Low Conga High Timbale Low Firmbale Low Firmbale Low Firmbale Low Firmbale Cow Fir	Impani d Impani d Impani d Impani d Impani e Imp	String day of double PI Key Cick Laughing Suream Punch Heart Best Footsteps2 Applases* Door Creaking Doo Scratch Wind Chimes* Car-Engine Car-Pess Car-Pess Car-Pess Car-Pess	GM Attackit High Tom OH Ride Cymbal — — — — — — — — — — — — — — — — — —
6 6 6		1928 H. Iron I Note Cymbal I Chrese Cymbal I Note Ber Cymbal I Note Ber I Note Ber I Splach Cymbal B80 Combal I Crash Cymbal B80 Combal I Crash Cymbal I Note Ber I Note Ber I Note Cymbal I	High Tomit Ride Cymbal Ride Eymbal Ride Bell Ride Bell Ride Bell Ride Bell Ride Bell Ride Bell Ride Cymbal Cowbell Spiech Cymbal Cowbell Wibra-Jap Ride Cymbal Low Bongo Low Bongo Low Bongo Low Bongo Low Bongo High Conga High Timbale Low Cornga High Timbale Low Tompa High Timbale Low Tompa Low Apopo Cabasa Marzes	High Tromal Ride Symbal I Ohirese Cymbal Ride Bel Ride Bel Tambourine Solash Cymbal Cowbell Grash Cymbal Cowbell Ride Bel Tambourine Solash Cymbal Cowbell High Bongo Low Bongo Low Bongo Dpen High Conga Upen High Conga Low Conga High Timbale Low Timbale Low Timbale Low Mango Low Agogo Cabasa Mareces	Impani d Impani d Impani d Impani d Impani e Impani e Impani i Israbourine Splash Cymbal Cowbebl Vibra-slap Concert Cymbal2 Vibra-slap Concert Cymbal1 High Bongo Lew Bongo Lew Bongo Lew Bongo High Conga High Timbale Low Ti	String day of double Pit Rey Cick Laughing Suream Panch Heart Best Footsteps2 Applase* Door Greating Door Soratin Gar-Foots Car-Foots Ca	CM Acasida High Tom OM Ride Cymbal
6 6 6		1928 ht from 1 Side Cymbal 1 Chrese Cymbal 1 Chrese Cymbal 1 Ride Bell 1 Tarbourine 1 Solah Cymbal 1 Side And 1 Tarbourine 1 Solah Cymbal 1 Crash Cymbal 2 Viffor-tila 1 High Boogo 1 Low Bongo 1 Low Bongo 1 Boll Low Conga 808 latel Conga 1 Sigh Timbale 1 Low Finadeo 1 Low Finadeo 1 Solah 1 Solah Markoth 3 Solah Markoth 1 Solah Low Conga Low Angoo 1 Cabasa 808 Markoth 1 Solah Markoth 1 Solah Markoth 1 Solah Low Conga Low Markoth 1 Solah Markoth	High Tomit Aide Cymbal Ofnines Cymbal Ride Bell Tambourine Spisan Cymbal Cowbell Cowbe	High Trom 1 Kitle Cymbal I Chinese Cymbal Ride Bef Ride Bef Grash Cymbal Cymbal Crash Cymbal Libra Bongo Low Bongo Muta High Conga Low Bongo High Timbale Low Conga Low Conga Low Conga Low Conga Low Gonga Cabana Mareca	Impani d Impani d Impani d Impani d Impani e Impani e Impani e Impani f Impani e Splah (ymbal Cowbet) Cowbet Sylah (ymbal Cowbet Impani d Impani f	Syring dags of double FI Key Click Laughing Suream Punch Heart Blost Footsteps1 Footsteps1 Footsteps2 Applaus* Door Creating Door Gestings Door Gestings Crarl- Wind Chimes* Car-Engine Car-Stop Car-Pass Car-Carbo Siren Train	GM Actasids High Tom ON Rick Cymbal ———————————————————————————————————
		1998 H. Iron I Nick Cymbal Nick Cymbal Nick Bell Nick Dell Nick Dell Nick Dell Nick Dell Nick Dell Nick Cymbal Nick Nick Nick Cymbal Nick Nick Nick Cymbal Nick Nick Nick Nick Nick Nick Nick Nick	High Tomi Rde Cymbal Rde Cymbal Ohnese Cymbal Ride Bel Tambourine Sptath Cymbal Cowbell Sptath Cymbal Cowbell Sptath Cymbal Cowbell Ward	High Iron1 Ride Cymbal I Ohinese Cymbal Ride Bel Ride Bel Tambourine Splash Cymbal Cowbell Tambourine Splash Cymbal Cowbell High Bongo Low Bongo Low Bongo Low Bongo Low High Conga Low Conga High Conga Low Conga High Conga Low Conga High Conga Low Conga High Agogo Cabasa Short Ri Whistle Long Low Whistle Short Guro Short Short Guro Short Short Guro Short Short Guro Short Shor	Impani d Impani d Impani d Impani e Impani e Impani e Impani e Impani I Impani o Imp	String day of double Pit Rey Cick Laughing Suream Planch Heart Best Footsteps2 Applause Door Greating Door Creating Door Creating Tool Car-Fase Car-Fase Car-Fase Car-Cardy Stein Train Train Train Train Steingle Steinby Ste	CM Attackis High Ton OM Ride Cymbal CM Tambourine CM Cowbell CM Cowbell CM High Bongo CM Low Bengo CM Low Group CM Low Group CM Low Bengo CM Low Janes CM Low J
		1928 ht from 1 Side Cymbal 1 Chrese Cymbal 1 Chrese Cymbal 1 Ride Bell 1 Tarbourine 1 Solah Cymbal 1 Side And 1 Tarbourine 1 Solah Cymbal 1 Crash Cymbal 2 Viffor-tila 1 High Boogo 1 Low Bongo 1 Low Bongo 1 Boll Low Conga 808 latel Conga 1 Sigh Timbale 1 Low Finadeo 1 Low Finadeo 1 Solah 1 Solah Markoth 3 Solah Markoth 1 Solah Low Conga Low Angoo 1 Cabasa 808 Markoth 1 Solah Markoth 1 Solah Markoth 1 Solah Low Conga Low Markoth 1 Solah Markoth	High Tomit Aide Cymbal Chinese Cymbal Chinese Cymbal Ride Bell Tambourine Spissh Cymbal Cowbell Cowbel	High Trom 1 Nide Cymbal I Ohinese Cymbal Ride Bei Ride Bei Ride Bei Frambourine Splash Cymbal Cowbell Light Bongo Low Bongo Muta High Conga Low Bongo Muta High Conga Low Conga High Timbale Low Timbale Lo	Finnpani d Finnpani d Finnpani d Finnpani e	String dag of double They Cick Laughing Suream Panich Heart Beet Footsteps1 Footsteps1 Footsteps2 Applause* Door Cessking Door Soratch Wind Okines* Car-Engine Car-Stop Car-Stop Car-Stop Car-Stop Car-Stop Laughing String Train Train Hekingster Starship* Gun Sbot Gun Sbot Gun Sbot	CM Acasais High Ton OAR Rick Cymbal
		1928 H. Tem I Side Cymbal Chree Cymbal Chree Cymbal Side Bel Side Bel Side Sed Side Symbal Side Sed Conbel Creb Cymbal Creb Cymbal Mic Mic Cymbal Mic Mic Cymbal Mic	High Tomit Mich Cymbal Chinese Cymbal Ride Bel Ride Symbal Ride Bel Spisson Cymbal Crash Cymbal Line Ride Cymbal Righ Rongo Low Bongo Mute High Conga Open High Conga Upen High Conga High Timbale Low Gonga Low Ganga Low Ganga Low Agogo Cabasa Marzes Marzes Sport Hi Whistle (EXCZ) Long Low Whistle (EXCZ) Long Low Whistle (EXCZ) Long Low Whistle (EXCZ) Long Guiro Claves Long High Wood Block Long Low High Wood Block Long High Wood Block	High Trom 1 Kitle Cymbal I Chinese Cymbal Ride Bei Ride Bei Frankourine Splash Cymbal Cymbal Crash Cymbal Lish Bongo Low Bongo Mula High Conga Low Bongo Mula High Conga Low Gonga Low Conga Low Conga Low Gonga Low Gonga Low Gonga Low Fimbale Low Gonga Low Fimbale Low Fimbale Low Agogo Cabasa Maracea Maracea Low Agogo Cabasa Maracea Long Guiaro	Impani d Timpani d Timpani d Timpani i Timpani i Timpani i Timpani i Timpani i Splash Cymbal Cowbetl C	Syring dag of double F1 Key Click Laughing Suream Punch Heart Beat Footsteps1 Footsteps1 Footsteps2 Applases Door Greaking Door Scratch Wind Chimer Car-Engine Car-Stop Car-Regine Car-Carb Step Car-Carb	CM Areasis High Ton OM Ride Cymbal
		1928 H Tomal Nicke Cymbal Nicke Cymbal Nicke Cymbal Nicke Serve Nicke Cymbal Nicke Serve N	High Tomit Aide Cymbal Chinese Cymbal Chinese Cymbal Ride Bell Tambourine Spisan Cymbal Cowbell Cowbel	High Trom1 Nide Cymbal I Ohinese Cymbal Ride Bell Tambourine Splash Cymbal Cowbell Tambourine Splash Cymbal Cowbell Ride Bell Tambourine Splash Cymbal Cowbell High Bongo Low Bongo Low Bongo Mute High Conga Low Bongo Low Bongo Low Bongo Low Gonga High Timbale Low Timbale High Agogo Cahasa Meraces Short Hi Whistle Long Guiro Cawes High Wood Block Low Gonga Low Gonga Low Long Guiro Cabes High Model Compa Low Long Guiro Cabes Long Guiro Care Care Long Guiro Care Care Low Wood Block Low	Impani d Impani d Impani d Impani e Impani e Impani e Impani I Impani I Impani I Impani I Impani I I Impani I I I I I I I I I I I I I I I I I I I	String day of double PI Key Cick Laughing Suream Panch Heart Beet Footsteps1 Footsteps1 Footsteps2 Applause* Door Cessking Door Sorten Car-Stop Car	GM Acadis High Ton ON Rick Cymbal
		1928 H. Tienel Side Cymbal Chrise Cymbal Chrise Cymbal Ride Bel Ride Bel Tarbourine Sylab (Cymbal Ride Bel Cash Cymbal Ride Bel Cash Cymbal Ride Ride Cash Cymbal Ride Cymbal	High Tomit Aide Cymbal Chinese Cymbal Chinese Cymbal Ride Bell Ride Bell Ride Bell Ride Bell Ride Ride Cowbell Ride Cymbal Ride Cymbal Ride Ride Ride Cymbal Ride Ride Ride Cymbal Ride Ride Ride Ride Cymbal Ride Ride Ride Ride Ride Ride Ride Ride	High Trom 1 Nide Cymbal I Ohinese Cymbal Ride Bei Ride Bei Ride Bei Ride Bei Grash Cymbal Cowbell Crash Cymbal Ligh Bongo Low Bongo Low Bongo Low High Conga Copen High Conga Low Conga High Timbale Low Conga Low Angogo Calwal Short Hi Whistle Long Low Whistle Short Guiro Long Guiro Clave Clave Long Guiro Clave Long Guiro Clave Low Wood Block Low Long Clave Cla	Impani d Impani d Impani d Impani d Impani e Impani e Impani e Impani I Impani I Impani I Impani I Impani I I Impani I I I I I I I I I I I I I I I I I I I	Syring dag of double F1 Key Click Laughing Suream Punch Heart Beat Footsteps1 Footsteps1 Footsteps2 Applases Door Greaking Door Scratch Wind Chimer Car-Engine Car-Stop Car-Regine Car-Carb Step Car-Carb	CM Areasis High Ton OM Ride Cymbal
		1928 ht from 1 Rick Cymbal 1 Chrese Cymbal 1 Rick Bell Cymbal 1 Rick Bell 1 Rick Cymbal 2 Rick Rick Cymbal 2 Rick Cymbal 2 Rick Rick Cymbal 2 Rick Rick Cymbal 2 Rick Rick Cymbal 2 Rick Rick Rick Rick Rick Rick Rick Rick	High Tomit Ride Cymbal Ride Bell Ride Cymbal Cowbell Ride Bell Ride Cymbal Cowbell Ride Ride Cymbal Ride Cymbal Ride Ride Cymbal Ride	High Trom1 Ride Cymbal I Ohirese Cymbal Ride Bell Tambourine Splash Cymbal Cowbell Ride Bell Tambourine Splash Cymbal Cowbell Ride Bell Tambourine Splash Cymbal Cowbell High Bongo Low Bongo How Bongo Low Bongo Low Bongo High Conga Low Bongo Low High Conga Low Gonga High Timbale Low	Impani d Impani d Impani d Impani d Impani e Impani e Impani i Impani i Impani i Israbourine Splash Cymbal Cowbeil Vibra-slap Concert Cymbal? Vibra-slap Concert Cymbal? Vibra-slap Concert Cymbal! High Bongo Low Bongo Low Bongo Low Bongo Low Bongo Low Bongo Low Gonga High Timbale Low Timbale Low Timbale Low Timbale Low High Rongo Low Agogo Cabesa Marraca Marraca Marraca High Wistel Long Goldro Clove High Wood Block Long Goldro Clove Mitth Cucka Open Cucka Mitthe Cucka Dopen Cucka Mitthe Cucka Mi	String day of double PI Key Cick Laughing Suream Punch Heart Best Footsteps1 Footsteps2 Applase * Door Creaking Door Creaking Door Creaking Door Creaking Door Creaking Door Car-Pess Car-Footsteps1 Footsteps2 Applase * Door Creaking Door Car-Pess Car-Footsteps2 Car-Pess Car-Footsteps2 Stratch Train Lesspine Laugher Streen Train Lesspine Lesspin	CM Attackis High Tom OM Rick Cymbal
		1928 H. Tienel Side Cymbal Chrise Cymbal Chrise Cymbal Ride Bel Ride Bel Tarbourine Sylab (Cymbal Ride Bel Cash Cymbal Ride Bel Cash Cymbal Ride Ride Cash Cymbal Ride Cymbal	High Tomit Aide Cymbal Chinese Cymbal Chinese Cymbal Ride Bell Ride Bell Ride Bell Ride Bell Ride Ride Cowbell Ride Cymbal Ride Cymbal Ride Ride Ride Cymbal Ride Ride Ride Cymbal Ride Ride Ride Ride Cymbal Ride Ride Ride Ride Ride Ride Ride Ride	High Trom 1 Nide Cymbal I Ohinese Cymbal Ride Bei Ride Bei Ride Bei Ride Bei Grash Cymbal Cowbell Crash Cymbal Ligh Bongo Low Bongo Low Bongo Low High Conga Copen High Conga Low Conga High Timbale Low Conga Low Angogo Calwal Short Hi Whistle Long Low Whistle Short Guiro Long Guiro Clave Clave Long Guiro Clave Long Guiro Clave Low Wood Block Low Long Clave Cla	Finnani d Finnan	Syring dasp of double Fit key Click Laughing Suream Panch Heart Best Footsteps1 Footsteps1 Footsteps2 Applanes* Door Creating Door Scratch Wind Chimes* Car-Engine Car-Stop Car-Pass Car-Gash Steen Train Steen Train Steen Gun Short Machine Gun Lastergun Euplosion* Don Short Machine Gun Lastergun Euplosion* Don Short Machine Gun Lastergun Euplosion Don Short Machine Gun Lastergun Euplosion Don Short Machine Gun Lastergun Euplosion Don Gun Gun Gun Gun Gun Gun Gun G	GM Accessic High Tom ON Rick Cymbal
5 5 7 7 7 7 TO NO. 10 10 10 10 10 10 10 10 10 10 10 10 10		1928 ht from 1 Nick Cymbal 1 Nick Cymbal 1 Nick Bell 1 Nick Cymbal	High Tomit Rde Cymbal Rde Cymbal Ohmese Cymbal Ride Bell Rde Bell Rambourine Splath Cymbal Cowbell Ride Bell Rde	High Trom1 Ride Symbal I Ohinese Cymbal Ride Bell Tambourine Solauh Cymbal Cowbell Solauh Cymbal Cowbell High Bongo Low Bongo Mute High Conga Chen High Conga Low	Impani d Timpani d Timpani d Timpani e Timpani e Timpani e Timpani e Timpani e Timpani e Spiash Cymbal Cowbeti Spiash Cymbal Cowbeti Vibra-slav Vibra-slav Mater High Bongo Low Bongo Low Bongo Low Bongo Low Conga Low Mgogo Cabasa Materia Short Hi Whistle Short Guico Long Gorer Clave High Wood Block Low Wood Block High Wood Block Low High Timpale Low Timpanie Low	String day of double Pit Rey Clack Laughing Suream Panch Heart Best Footsteps2 Applause Door Creaking Door Creaking Door Creaking Toor Car-Stop Car	CM Araskis High Ton OM Rick Cymbal
		1928 ht Irona 1 Nick Cymbal 1 Nick Cymbal 1 Nick extra 1 Nick Cymbal 2 Nick Cymbal 3 Nick Cymbal 2 Nick Conga 808 Nick Conga 808 Nick Conga 808 Nick Conga 808 Nick Conga Nick Nick Nick Nick Nick Nick Nick Nick	High Tomit Aide Cymbal Chinese Cymbal Chinese Cymbal Ride Bell Ride Bell Ride Bell Ride Bell Ride Ride Cowbell Ride Cymbal Ride Cymbal Ride Ride Ride Cymbal Ride	High Trom1 Nide Cymbal I Ohinese Cymbal I Ohinese Cymbal Ride Bell Ride Bell Tambourine Splash Cymbal Cowbell High Bonga Liow Bonga Liow Bonga Muta High Conga Liow Bonga Liow Angag Cabasa High Timbale Low Timbale Low Timbale Low Timbale Low Timbale Low Timbale Low White Short Guiro Long Guiro Cabasa Marcca Long Guiro Caves Mute Custa Open Cuica Mute Triangle Open Cuica Mute Triangle Open Cuica Mute Triangle Open Cuica Mute Triangle	Finnani d Finnan	String day of double PI Key Cick Laughing Suream Panch Heart Beet Footsteps1 Footsteps1 Footsteps2 Applause* Door Cessking Door Sorten Footsteps2 Car-Engline Car-	GM Acadis High Ton ON Rick Cymbal
5 5 7 7 7 7 TO NO. 10 10 10 10 10 10 10 10 10 10 10 10 10		1928 H. Irms I Side Cymbal Tones Cymbal Side Apropal Tones Cymbal Side Apropal Side Cymbal Side Side Side Side Side Side Side Side	High Tomit Aide Cymbal Chinese Cymbal Chinese Cymbal Ride Bell Ride Bell Ride Bell Crash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Crash Cymbal Ride Ride Ride Cymbal High Rongo Low Bongo Mute High Conga Open High Conga Cymbal High Timbale Low Gonga Low Gonga Low Gonga Low Gonga Low Agogo Calabasa Marzesa Marzesa Calabasa Marzesa Marzesa Claves Long Low Ministe (EXC2) Long Low Ministe (EXC2) Long Low Ministe (EXC2) Long Low Ministe (EXC2) Copen Titungle Ride Mute Timagle (EXC3) Shaker Lore (EXC3) Shaker Lore Castanett Bell Tree Castanett Lore Ministe (EXC5) Bell Tree Castanett Bell Tree Castanett Lore Ministe (EXC5) Bell Tree Castanett Mante Syndo (EXC6)	High Trom 1 Nide Cymbal I Chinese Cymbal Ride Bel Ride Bel Ride Bel Ride Bel Grash Cymbal Crash Cymbal Cymbal Cymbal Cymbal Ligh Bongo Low Bongo Mute High Conga Low Bongo Mute High Conga Low Conga Low Conga Low Conga Low Agogo Cabana Marcac Cabana Marcac Low Jimbale Low Jimbal	Finnpani d Finnpani d Finnpani d Finnpani e	Syring dasp of double F1 Key Clek Laughing Suream Punch Heart Beat Footsteps1 Footsteps1 Footsteps1 Footsteps2 Applaase* Door Creating Door Contings Door Contings Door Contings Contch Wind Chimen* Can-Engine Can-Stop Can-Pass Can-Stop Can-Pass Can-Canh* Siren Train Helicopper Stanhip Gun Shoot Machine Gun Lautengum Capiologic Contings Helicopper Stanhip Gun Shoot Machine Gun Lautengum Capiologic Gun Backengum Capiologic Gun Capiolog	GM Assaski High Ton ON Rick Cymbal ————————————————————————————————————
		1928 ht from 1 Rick Cymbal 1 Rick expression 1 Rick elect Cymbal 1 Rick elect 1 Rick Cymbal 1 Rick Cymbal 1 Rick Cymbal 2 Rick Rick Rick Rick Rick Rick Rick Rick	High Tomit Aide Cymbal Chinese Cymbal Chinese Cymbal Ride Bell Ride Bell Ride Bell Crash Cymbal Ride Gymbal High Rongo Low Bongo Mute High Conga Open High Conga Low Gonga Com Crashasa Marzets Dan July Mary Timbale Low Gonga Low Gonga Com Crashasa Marzets Maryets Long Low Whistle (EXC2) Long Low Whistle (EXC2) Long Low Whistle (EXC2) Long Low Whistle (EXC2) Copen Tirangle (EXC3) Shaker Gonga (EXC4) Open Couca (EXC5) Shaker Bell Tires Bell Tires Bell Tires Castanets Marse Surdo (EXC6)	High Trom1 Ride Cymbal I Ohirese Cymbal Ride Bell Ride Ride Ride Cymbal Cowbell Ride Cymbal Cowbell Ride Cymbal Ligh Bongo Low Gonga Low Conga Ride Trimbale Low Trimbale Low Trimbale Low Trimbale Low Trimbale Long Guiro Conse Low Wood Block Mute Cuica Doen Cuica Doen Cuica Ride Conse Ride	Impani d Impani d Impani d Impani d Impani e Impani e Impani i Imp	String day of double They Cick Laughing Suream Panch Heart Bost Footsteps1 Footsteps2 Applause* Door Cessiving Door Sorath Wind Chines* Car-Englie C	GM Acadis High Ton OAR Rick Cymbal
		1928 H. Irms I Side Cymbal Tones Cymbal Side Apropal Tones Cymbal Side Apropal Side Cymbal Side Side Side Side Side Side Side Side	High Tomit Aide Cymbal Chinese Cymbal Chinese Cymbal Ride Beë Tambourine Spisst (Cymbal Cowbell Cow Bongo Mute High Conga Copen Cowbell Cow Gonga Cow Apogo Calabas Marzess Short Hi Winstle (EXC2) Long Low Whistie (EXC2) Long Guro Claves Claves Copen Cuca (EXC4) Mute Triangle (EXC5) Copen Cuca (EXC4) Mute Triangle (EXC5) Shalter Lingle Bell Bell Bell Bell Bell Bell Bell Tee Castanets Castan	High Trom 1 Nide Cymbal I Chinese Cymbal Ride Bel Ride Bel Ride Bel Ride Bel Grash Cymbal Crash Cymbal Cymbal Cymbal Cymbal Ligh Bongo Low Bongo Mute High Conga Low Bongo Mute High Conga Low Conga Low Conga Low Conga Low Agogo Cabana Marcac Cabana Marcac Low Jimbale Low Jimbal	Impani d Timpani d Timpani d Timpani e Timpani e Timpani e Timpani e Timpani i Splash Cymbal Cowbeil Splash Cymbal Cowbeil Vibra-lay Mark High Bongo Luw Bongo Cubasa High Timbale Luw Timbale High Apogo Low Agogo Cubasa Bont Hi Whistle Long Gudro Cives High Wood Block Mutra Cuira Dyen Cuisa Long Bouro Cives High Wood Block Mutra Cuira Dyen Cuisa Bont High Rongo Open Crisin Bigh Wood Block Mutra Cuira Dyen Cuisa Bell Timale Sharianale S	String day of double They Cick Laughing Suream Panch Heart Bost Footsteps1 Footsteps2 Applause* Door Cessiving Door Sorath Wind Chines* Car-Englie C	GM Accessit High Tom ON Rick Cymbal ————————————————————————————————————
6 6 6 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8		1908 ht from 1 Rick Cymbal 1 Chrese Cymbal 1 Rick Bell 1 Tarbourine 1 Splant Cymbal 1 Bill Bell 1 Tarbourine 1 Splant Cymbal 1 Bill Compa 1 Bill Low Compa 1 Bill L	High Tomit Ride Cymbal Ride Cymbal Chinese Cymbal Ride Bell Ride Bell Ride Bell Ride Bell Ride Bell Ride Cymbal Comboli Ride Bell Ride Cymbal Comboli Ride Ride Ride Cymbal Ride Cymbal Ride Cymbal Ride Cymbal Ride Cymbal Ride Ride Ride Cymbal Ride	High Trom 1 Nide Cymbal I Ohinese Cymbal Ride Bell Tambourine Solash Cymbal Cowbell Ride Bell Tambourine Solash Cymbal Cowbell Ride Bell Tambourine Solash Cymbal Cowbell High Bongo Low Bongo Low Bongo Low Bongo Low Bongo Low High Conga Low High Conga Low Long High Timbale Low Tonga Low Agogo Cabesta Hagh Agogo Cabesta Maracas Short Hi Whistle Long Guiro Long Guiro Long Guiro Chawa Characas Short Hi Whistle Long Guiro Chawa Characas Short Ri Whistle Long Guiro Chawa Characas Short Ri Whistle Long Guiro Chawa Characas Short Ri Whistle Long Guiro Chawa General Timangle Shaker Inngle Bell Bell Tree Castanets Mare Surdo Copen Surdo Co	Fingani d Fingani d Fingani d Fingani d Fingani e Fingani Fi	String day of double PI Key Cick Laughing Suream Punch Heart Best Footsteps2 Applaus* Door Cessking Door Cessking Door Cessking Car-Footsteps2 Car-Footsteps2 Applaus* Door Cessking Door Cessking Door Cessking Door Cessking Toric Car-Footsteps2 Car-Footsteps3 Ca	GM Associal High Tom OM Rick Cymbal
6 86 89 91		1928 H. Irms I Side Cymbal Tones Cymbal Side Apropal Tones Cymbal Side Apropal Side Cymbal Side Side Side Side Side Side Side Side	High Tomit Make Cymbal Ofninse Cymbal Ofninse Cymbal Ride Bell Ride Side States Cymbal Carbourine States Cymbal Ride Ride Cymbal Ride C	High Trom 1 Nide Cymbal I Ohinese Cymbal I Ohinese Cymbal Ride Beif Ride Beif Tambourine Solash Cymbal Cowbell Crash Cymbal Cowbell Crash Cymbal Cowbell Grash Cymbal Cowbell Grash Cymbal Cowbell Grash Cymbal Cowbell High Bongo Low Bongo Low Bongo Low Bongo Low High Conga Low Gonga Low Conga High Timbale Low Conga Low Angogo Calwal Short Hi Whistle I Long Low Whistle Short Guiro Long Guiro Claves Marc Clave Marc Clave Marc Clave Marc Clave Gongo Clave Short High Wood Block Low Wood Block Low Wood Block Marc Prinangle Open Cuica Mate Criangle Gongo Shaker High Wood Block Low Gongo Clave Gongo Mate Criangle Copen Firangle Shaker High Wood Block Low Wood Block Low Wood Block Low Gongo Marc Clave Clave Gongo Clave Marc Clave Clave Gongo Clave Clave Gongo Clave Clave Marc Clave Clave Clave Marc Clave Clave Clave Marc Clave Clave Clave Marc Clave Marc Clave Clave Marc Clave Clave Marc Clave Marc Clave Marc Clave Clave Marc	Finnani d Finnan	Syring day of double Fit Key Click Laughing Suream Panch Heart Best Footsteps2 Applases* Door Creatings Door Scratch Wind Chimes * Car-Engine Car-Engine Car-Engine Car-Stop Saream Fishing Stream Fishing Stream Fishing Stream Fishing Stream Fishing Stream Fishing Gun Short Markine Gun Lasergun Englosion * Dog Morse-Gallog Birst * Rain Thundes Wind Sasachere Stream * Thundes	GM Acadis High Tom OAR Rick Cymbal
6 6 6 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8 8		1928 H. Iren I Side Cymbal Tones Cymbal Side Apropal Tones Cymbal Side Apropal Side Cymbal Side Side Side Side Side Side Side Side	High Tomit Ride Cymbal Ride Ed Cymbal Tomese Cymbal Ride Bell Ride Bell Ride Bell Ride Bell Ride Bell Ride Bell Ride Cymbal Cowbell Ride Bell Ride Cymbal Cowbell Ride Cymbal Cowbell Ride Cymbal Ride Cymbal Ride Cymbal Ride Cymbal Ride Cymbal Ride Ride Cymbal Ride	High Trom1 Ride Symbal I Ohirese Cymbal Ride Beil Frambourine Solash Cymbal Cowbell Ride Beil Frambourine Solash Cymbal Cowbell Ride Beil Ride Ride Ride Symbal Cowbell High Bongo Low Bongo Low Bongo Deen High Conga Low High Conga Low High Conga Low Gonga Line Agogo Cabasa Low Gonga Low Agogo Cabasa Low High Whistle Long Guiro Cabasa Low Wood Block Mute Cuica Open Cuica Copen Ride Ride Ride Ride Ride Ride Ride Ride	Fingani d Fingani d Fingani d Fingani d Fingani e Fingani	String day of double PI Key Cick Laughing Suream Punch Heart Best Footsteps1 Footsteps2 Applase * Door Greating Door Control Car-Engine Car-Eng	GM Arabita High Tom OM Ride Cymbal
6 86 89 91		1928 H. Tienel Siele Cymbal Chrise Cymbal Chrise Cymbal Ride Bell Crash Cymbal Ride Ride Crash Cymbal Ride Ride Cymbal Ride Ride Cymbal Ride Cymbal Ride Ride Ride Cymbal Ride	High Tomit Ride Cymbal Ride Ed Cymbal Tomese Cymbal Ride Bell Ride Bell Ride Bell Ride Bell Ride Bell Ride Bell Ride Cymbal Cowbell Ride Bell Ride Cymbal Cowbell Ride Cymbal Cowbell Ride Cymbal Ride Cymbal Ride Cymbal Ride Cymbal Ride Cymbal Ride Ride Cymbal Ride	High Trom 1 Nide Cymbal I Ohinese Cymbal I Ohinese Cymbal Ride Bell Tambourine Splash Cymbal Cowbell High Bongo Low Bongo Muta High Conga Low Bongo Muta High Conga Low Conga High Imbale Low Timbale Long Guiro Claws Mare Cuta Open Cuica Muta Triangle Open Timbale Shater Inigle Bell Bell Tree Castanets Mare Surdo Open Surdo	Finnpani d Finnpani d Finnpani d Finnpani d Finnpani e	Syring day of double Fit Rey Click Laughing Suream Panch Heart Best Footsteps2 Applases* Door Creating Door Scratch Wind Chimes* Car-Engine Car-Engine Car-Stop Car-Pass Car-Carch Steren Train Latergun Explosion* Doog Norse-Galloo Birds ** Name Wind Sasshore Stream Thunder Wind Sasshore Stream Laugh Car-Carch	GM Assasis High Tom OM Rick Cymbal
5 5 5 5 7 7 7 7 7 7 8 8 8 8 9 9 1 9 3		1928 H. Tienel Siele Cymbal Chrise Cymbal Chrise Cymbal Ride Bell Crash Cymbal Ride Ride Crash Cymbal Ride Ride Cymbal Ride Ride Cymbal Ride Cymbal Ride Ride Ride Cymbal Ride	High Tomit Aide Cymbal Chinese Cymbal Chinese Cymbal Bide Bell Tambourine Spisse (Cymbal Cowbell Cow Bongo Low Bongo Low Conga High Timbale Low Conga Low Conga Low Conga Low Conga Low Conga Low Conga Low Compa Cowbell Cowb	High Trom1 Ride Symbal I Ohirese Cymbal Ride Beil Frambourine Solash Cymbal Cowbell Ride Beil Frambourine Solash Cymbal Cowbell Ride Beil Ride Ride Ride Symbal Cowbell High Bongo Low Bongo Low Bongo Deen High Conga Low High Conga Low High Conga Low Gonga Line Agogo Cabasa Low Gonga Low Agogo Cabasa Low High Whistle Long Guiro Cabasa Low Wood Block Mute Cuica Open Cuica Copen Ride Ride Ride Ride Ride Ride Ride Ride	Impani d Impani d Impani d Impani d Impani d Impani e Imp	String dag of double PI Key Cick Laughing Suream Panch Heart Beet Footsteps1 Footsteps1 Footsteps2 Applaus* Door Cessking Door Cessking Door Cessking Car-Engine Car-	GM Arabita High Tom OM Ride Cymbal

18.3 Internal Music Styles

					,						na na sangananahanan kanan	
ROCK	PROPERTY OF THE PROPERTY OF TH	AND	Construction of the second section of the	SWIN					(Disk Link)	ALE	179	
A11 1	LightRk1	4/4	J=86	811	SISwing1	4/4 4/4	j= 55 j= 85	C11 C12	Party_1 Party_2	4/4 4/4	j= 128 j= 110	
	LightRk2	4/4	J= 100	B12	SISwing2 MedSwng1	4/4]= 03]= 100	C12	Prtyjive	4/4	= 90	
	LightRk3 PowerRk1	4/4 4/4	J= 105 J= 120	B13 B14	Med5wng2	4/4	J= 110	C14	VSchlagr	4/4	J=92	
	PowerRk2	4/4	J= 130	815	ScatSwng	4/4	= 125	C15	Prtypika	4/4	J= 136	
	PowerRk3	4/4	J= 136	B16	CoolSwng	4/4	J= 135	C16	PartyWlz	3/4	J= 180	
	Rock	4/4	J= 172	B17	Swing	4/4	J= 180	C17	Gt'oldie Old'rock	4/4 4/4	j= 97 j= 120	
A18	ShRock	4/4	J= 135	B18	FstSwing	4/4	j= 220	C18	Old TOOK	444	3= 120	
	erroma andre in in del (IVIII)	BOX OF THE PART	and the second s	worker deserved	anti-energy or measurements are second	romania and a secondaria de la constantia d	ent and more than the court		Appropriate the supplemental and supplem	Name and the second	THE RESIDENCE AND ADDRESS OF THE PERSON NAMED IN	-
DANCE				LATI		4/4	J= 106	CZ1	(Disk Link) D'rock	4/4	J= 125	
	House 1	4/4 4/4	J= 134 J= 136	B21 B22	Bossa 1 Bossa 2	4/4	= 125	C22	Latparty	4/4	J= 128	
	House 2 Dance 1	4/4	J= 135	B23	Bossa 3	4/4	J= 150	C23	Foxdance	4/4	J= 136	
	Dance 2	4/4	J= 130	B24	Bossa 4	4/4]= 173	C24	Olddisco	4/4]= 100	
	Techno 1	4/4	J= 140	B25	JzLatin1	4/4	J= 102	C25	Dcountr1	4/4 4/4	j= 120 j= 108	
	Techno 2	4/4	J= 140	826	IzLatin2	4/4 4/4	140 = ا ا = 105	C26 C27	Dcountr2 Lgrfeuer	4/4	J= 120	
	HipHop 1	4/4	J=90 	B27 B28	Samba 1 Samba 2	4/4	J= 100	(28	Obrkrai2	4/4	= 128	
A28	HipHop 2	4/4	J=110	DZO	3011100 2	747	3- 130		00		•	
Street Company		and management of the contract	CONTRACTOR OF THE PROPERTY.		MARINE THE PROPERTY OF	MANAGEMENT AND	and Spherical and a second	710 3	(Disk Link)	1000 AT 10 1000	DIRECTOR OF A LEGISLANIAN BATTLE A	cpetro*
	EMPORARY		1 100	LAT B31	IN 2 Mambo 1	4/4	J= 89	(31	Mazurka1	3/4	J= 162	
	FunkyPop Funky	4/4 4/4	J= 108 J= 103	B32	Mambo 2	4/4	J= 92	GZ	Mazurka2	3/4	J= 154	
	70s80s 1	4/4	J= 103 J= 114	B33	Mereng 1	4/4	J= 106	C33	Polka1	4/4	J= 125	
	70s80s 2	4/4	= 122	B34	Mereng 2	4/4	J= 155	C34	Polka2	4/4	J = 128	
	ElectHop	4/4	J= 94	B35	Bomba	4/4	J= 90	C35	^Quadrgi	4/4] = 135	
A36	WaveJazz	4/4	J = 95	836		4/4	J= 98	C36	Valzer1	3/4 3/4] = 175] = 170	
A37	Contemp1	4/4	J= 93	B37		4/4 4/4]= 120]= 168	G7 G8	Valzer1 Beguine1	3/4 4/4	j= 170 j= 120	
8EA	Contemp2	4/4	J= 123	B38	ChaCha 2	4/4	J= 100	Ca	begunne :		2- 120	
279/20 10000	AND DESCRIPTION OF THE PERSON NAMED IN		BARRONNI EL ANNONONON ANNON ANTONONON (\$ 40)	marany range		E-M-25/4/4/3-4	- A CONTRACTOR OF THE PARTY OF	710	4 (Disk Link)	CONTRACTOR (NO. 4)	# GC PEND THE GOVERNMENT OF THE THE	estate to
8 BEA			l. co		NETY 1	2/4	j= 93	ZIP -		4/4	j= 118	
A41	Pop 1A	4/4	J= 60	B41 B42		2/4	J= 120	C42		4/4	J= 120	
A42 A43	Pop 2A Pop 3A	4/4 4/4	J= 64 J= 72	B43		4/4	J= 125	C43		4/4	J= 126	
A44	Pop 4A	4/4]= 83	B44		4/4	J= 152	C44	^Taranti	4/4	J≃ 135	
A45	Pop 5A	4/4	= 85	845		4/4	J= 110	C45		4/4	= 134	
A46	Pop 6A	4/4	J = 86	B46		4/4	= 130	C46		4/4	j≖ 170 167	
A47	Pop 7A	4/4	J = 80	B47		4/4	J≈86	C47 C48		4/4 4/4] = 167] = 125	
A48	Pop 8A	4/4	J= 88	848	l Calypso	4/4	J= 165	(40	nunyou	••	3- 123	
Market Control	yayaa aayaay oo oo goodadaa	****	Company of the Company of Company	mountes series	RIETY 2	NACOTAL STATES	and the state of t	71P	5 (Disk Link)	***	Anny management of the State of	ALMANIA.
16 BE		4/4	J=70	B51		4/4	J=96	C51		4/4	J=90	
A51 A52	Pop 1B Pop 2B	4/4	J= 75	B52		4/4	J= 105	C52		4/4	97 = ل	
A53	Pop 3B	4/4]= 80	853		4/4	J=97	C53		4/4	J= 120	
A54	Pop 4B	4/4	J= 80	B54	Mariachi	3/4	J= 112	C54		4/4	J= 128	
A55	Pop 5B	4/4	J= 85	B55		4/4	J= 105	C55		4/4 4/4	J= 140 J= 100	
A56	Pop 6B	4/4	J= 93	B50		4/4 4/4	j= 120 J= 98	CSE CS7		4/4	J= 113	
A57	Pop 78	4/4	J= 93 J= 98	857 851		4/4	J= 36 J= 185	CSE		4/4	= 127	
A58	Pop 88	4/4	J= 30	2.0	, ioxuot	•	,					
tiyranı Pot		eportation environ	agrangement of the comment	- year	RIETY 3		and color space to the Williams	710	6 (Disk Link)	****	THE RESERVE OF THE PROPERTY OF THE PERSON NAMED IN	ADDINATE.
	§ 60's SI Book 1	6/8	J= 84	B6		3/4	J= 85	Ce.		4/4	J= 60	
A61	SI Rock1 SI Rock2	6/8] = 84] = 96	B6:		3/4	J=90	C6		4/4	J=70	
A62 A63	Si Rock3	6/8	J= 90	B6:		3/4	J= 106	C6:		4/4	J= 75	
A64	SI Rock4	4/4	J= 80	B6-		3/4	= 120	C6-		4/4]= 84	
A65	PopRock	4/4	J= 140	B6		6/4	.= 185 130	C6		4/4 4/4	J=85 J=92	
A66	Surf	4/4	J= 153	B6		4/4 4/4	J= 120 J= 120	C6		4/4]= 96	
A67	Charlest	4/4 4/4] = 193] = 140	86 86		4/4	j= 120 j= 128	CG		4/4	J= 75	
A68	Dixie	44	J= 140	30					,			
anus e	14 (A C	-	=#####################################	A P	OUSTIC 1	CONTRACTOR CO.		710	7 (Disk Link)		AND THE PARTY OF THE PROPERTY	al mindress.
ROCI		414	J≈ 150	AC 87		4/4	J= 64	7		4/4	J=65	
A71	Boogie 1 Boogie 2	4/4 4/4	J= 150 J= 186	87		44	J=65	ä		4/4	J= 75	
A72 A73	Rock'N1	4/4]= 100]= 122	B7		4/4	J= 70	ä	3 &168Pop2	4/4	= 85	
A74		4/4	j= 176	87	4 G FstPop	4/4	= 90	7		4/4	J= 100	
A75		4/4	J= 168		5 P Ballad	4/4	J= 55		5 &16BPop4	4/4	J= 100 I= 130	
A76	Rock'N4	4/4	J= 181		6 G Ballad	4/4	J= 130 I− co		6 &16BPop5 7 &BidRckS	4/4 4/4	J= 120 J= 78	
	Twist 1	4/4	J= 160		7 P Night	4/4 4/4	∫≕ 60 ∫= 150	a a		4/4	J= 100	
A78	Twist 2	4/4	J= 158	87	8 PJazz	4/4	3= 130	C		-11-17		
Savaire	entra anno compres	material (sec.)	an designaturas necessiti con medicare re	guidanne mar	Olictic 3	ante sobrado e es 2 v h	PROPERTY AND SOUTH STREET	7H	8 (Disk Link)	CONTRACTOR OF THE PARTY OF THE		ya Nasani
	NDARDS Sh Baidt	4/4	J= 88	A(OUSTIC 2 11 P Latin	4/4	J= 100		1 &SISwng1	4/4	J= 56	
	Sh Bald2	4/4			12 G Bossa	4/4		CB	2 &515wng2	4/4	J= 60	
	Sh Bald3	4/4		BE	3 G Samba	4/4	J= 100		3 &SISwng3	4/4	= 100	
A84	Blues	4/4	J = 60		4 PRock'N	4/4			4 &MedSwng	4/4 4/4	J= 110	
A85	FstBlues	4/4			S P Shuffl	4/4		CE	5 &Swng1 6 &Swng2	4/4 4/4	∫= 130 J= 150	
	R&B	4/4			86 PRagtim 87 PWaltz	4/4 3/4		Œ		4/4	J= 160	
A87		4/4 4/4			88 G Waltz	3/4		CE			j= 184	
88A	Shuffle	444	j = 143	ь								

18.4 Chord Intelligence





18.5 MIDI Implementation Chart

[V-Arranger Keyboard] Model: VA-76

Date: January 2001 Version: 1.00

	Function	Transmitted		Recognized		Remarks
Basic Channel	Default Changed	1~16 1~16, Off		1~16 1~16, Off		32 Parts 1 VariPhrasePart '3 1 Audio In Part '3 4 Logical Parts
Mode	Default Message Altered	Mode 3 Mode 3, 4 (M=	:1)	Mode 3 Mode 3, 4 (M=	:1)	*2
Note Number	True Voice	0~127	*1	0~127 0~127	*1	
Velocity	Note ON Note OFF	O X	*1	o x	*1	
After Touch	Key's Ch's	0		0	*1	
Pitch Bend		0	*1	0	*1	
Control Change	0,32 1 5 6,38 7 10 11 16 17 18 19 64 65 66 67 69 84 91 93 94 98,99	000000000000000000000000000000000000000	" " " " " " " " " " " " " " "	O O O O O O O O O O O O O O O O O O O	** ** ** ** ** ** ** ** ** ** ** ** **	Bank Select Modulation Portamento Time Data Entry Volume Panpot Expression M-FX Value 1 (VariPhr. Pitch) M-FX Value 2 (VariPhr. Time) VariPhrase Formant General-purpose contr. Hold 1 Portamento Sostenuto Soft Hold 2 Portamento Control Effect 1 Depth Effect 3 Depth Effect 4 Depth NRPN LSB, MSB RPN LSB, MSB
Program Change	True #	0	*1	O 0~127	*1	Program Number 1~128
System Exclu	sive	0	*1	0	*1	
System Common	Song Position Pointer Song Sel Tune	X X X	*1	X X X	*1	
System Real Time	Clock Commands	0 0	*1	0	*1 *1	
Aux Messages	Local On/Off All Notes Off Active Sense	x x o x o x	*1	O (120, 126, 120 O (121) O O (123-125) O X	7)	
Notes		*1 O X is selectable *2 Recognized as M=1 even if M≠1				

Mode 1: OMNI ON, POLY Mode 3: OMNI OFF, POLY

Mode 2: OMNI ON, MONO Mode 4: OMNI OFF, MONO O: Yes X: No

19. Index

_		C W. famatiana 196	Diele
Numerics	Auto 104	Controller functions 186	Disk Format 132
00 Free Panel 128	Chain Mode 139	Converter (Style) 155	Link, saving 210
1 Ch Limit 205	Lock 115	Copy 184	Link, programming 108
1 Channel Rx 205	M-FX 121	16-track 153	Link, programming 100
1st Style 63	Sync 204	Existing Styles 172	Mode 209
2 Ch Limit 205	Autoload 209	Functions 214	
2 Channel Rx 205	Autorun 196	Microscope 184	Save 67
2nd Drum Track 145	В	Mode 154, 173	User 61, 165
2nd Style 63	B: 135, 156	Style 209	Display Contrast 18
2nd Trk 66	Background 30, 46	User Style 184	Division 165
3.5", see Floppy	Balance 27, 113	Count-In 56, 66	Double Speed On 84
	Bank Select 197	PAD function 194	Down 129
A	Basic Channel 204	User Style 171	DP-2 8
A. Drums 95	Bass 63	Country 109	Drum
A.Bass 95	Inversion 102	CPT 105, 176, 182	Morphing 63
On/Off 187	Beat 75	User Style 169	VariPhrase 47
A/a 68	Between 148	Current 181	Drum Set 44
A: 135, 156	BPM 75, 104	Capturing Area 72	Note pitch 175
Abort 168	VariPhrase 84	Drum Set 143	Select (User Stl) 174
ABs&ADr On/Off 187	Break Mute 194	Tone 143	Drumming 42
Absolute 205	Bsc 98	Curve 79	DSP, see M-FX
ACC 104	BWD 31, 135	Customize	Dynamic (Arranger) 103
Acc 95		Preferred Tone 40	E
Acc&ABs On/Off 187	C	Super Tones 85	Easy Routing 22
Accomp 63	Cancel	Cut&Reso 186	Edit 125
On/Off 187	Options 100	Cutoff 186	16-track 148
Accompaniment 95	Song Chain 138	Freq 126	Header 161
ADrum On/Off 187	User Program 129	D	MIDI 200
Adv 98	Capital 40	D Beam 51, 186	Phrase 72
Aftertouch 52, 189	Capture 71	VariPhrase 48	Song Chain 138
Arranger control 97	Field 105	Damper 55, 190, 202	User Style 174
AIFF 70	Capturing Free Area 71	Data 49	Effect 116
Ali	CC00 153	Send 162	16-track 144
Parts 92	CC32 153	Type 148, 149, 178	Parameters 117
Time Signature 167	Chain 137	DATA (button) 49	Send (16-track) 144
Alteration 106	Mode 139	Database 109	VariPhrase 50, 124
Alternate (PanPot) 79	Change	Dec 153	EFX, see M-FX
Always 56	16-track 152	Decay 126	Eject Zip 62
Amplitude 78, 189	Microscope 181	Default 55	Encode 74
Announcements 57	User Style 184	Tempo 27	End 138
Arpeg(gio) 187	Channel Aftertouch 189	Value 118	Ending 26, 95
Arr Start/Stop 187	Character 118	Delay 116, 119	Enter 49
Arranger 95	Chord	16-track 144	Env
Aftertouch 97	Family Assign 105	Delete 68, 213	Attack 126
Button 34	Sequencer 65, 132	16-track 149	Decay 126
Chord 102	Chorus 116, 118, 175	Last Note 134, 140	Release 126
Hold 101	16-track 144	Names 68	Envelope 126
Operation 25	VariPhrase 50, 124	Numeric Pad 49	Equal (16-track) 148
Options 104	Chrus 149	Song 139	Equalizer 119
Tempo 104	Click track 56	Song Chain 139	Erase 178
Assign	Clinic 34	Style 111	16-track 142, 148
Foot Pedal 193	Clones 166, 168	User Style 165, 185	Record 166
Lower Hold 90	Coarse	User Type 178	· Event Sense 75
Asterisk (*) 129, 161, 200	Start/End 73	Demo songs 19	Exchange 154
Attack 126	Upper2 88	o	Execute 68
Audio 19	VariPhrase 77		Exit 49
Audio In 57	Combo 23		Expre 149
Effect 124	Compatibility 8		Expression 51, 175, 192, 198
Rev & Cho On/Off 192	Composer 65		16-track 147
Author 133	Continue 203		Pedal 55
	Compract 19		

Contrast 18

F	Genre 109	Keyboard	Manual
Factory 28, 85	Global	Field 55	Drums 42
Resume 196	Header Post Edit 161	Functions 85	M-FX 121
Fade 195	Parameters 55, 83, 195	MIDI 201	Song Chain 139
Fade In/Out 78	VariPhrase 81	Mode 34	Mark A/B 156
Faders (VariPhrase control) 49	Volume 113	Part 35	Marker 135
Family 105	GO To 109	Tone selection 37	Master
Fast 171, 181	GS Reset 199	Velocity 91	Page 24
Favorites 40	Н	Volume 114	Sw 79
FC-7 8, 54	Half	Keybrd Mixer 50, 114	Tune 55
FDD 111, 215	Bar 97, 194	Keyfollow 78	User Style Composer 165
Style Options 110	Speed On 84	Pan 79	Max 91
FFW 31, 135	Hall 124	L	MDR 35, 42
File Name 109, 139	Harmony 99	_	Measure 75
Fill 26	Header Post Edit 161	Layer 35	Medium 91
Half Bar 97, 194	Headphones 19	LCD Contrast 18	MEL INT 99
Rit value 104	High 202	Left 101	Melodic 30, 46
Ritardando 104		Legato 80	Melody Intelligence 99
To Previous 98	Key Touch 91	Legto Lock 82	Memorize 93
To Var/Or 187	Higher 148 Hold 182, 190, 198	Length 167, 176	MIDI Set 207
Filter 202, 204, 205		Level	One Touch 100
TVF Cutoff 126	Arranger 101 Footswitch 55	16-track 144	Super Tones 86
User Program 129		Effect 117	User Program 127
Find 109, 133	Lower (LWR) 90 LW2 (Lower 2 only) 192	Knob 57	Merge 154, 166
Only 109	VariPhrase 192	LFO 188	16-track 142
Fine	_	Pitch 189	Copy 154
Start/End 73	l	Rate 189	User Style 173
Upper2 88	Import 70	TVA 189	Metronome 56
Fine Tune, VariPhrase 78	Inc 153	TVF 189	Mode 56
Flamenco Roll 51	Init Value 153	Limit 202, 205	Output 56
Flanger 118, 124	Initialize 196	Listen 173	Recording 142
Floppy	13th Track 146	Load	Song Composer 66
Copy 214	16-track 145	MIDI Set 208	User Style 171
Disk User 61	Disk 213	Song 209	M-FX 120
Format 68	Input 19	User Program Set 210	Pedal 193
FO 98	Over 58	User Style 209	Selection Mode 121
Foot 83	Insert 68, 182	VariPhrase 210	Send 123
Pedal 55, 192	16-track 149	Local 201	Microphone 57
Switch 55	Microscope 182	Lock 104	Microscope 181
Footswitch 191	User Style 179	Auto/Man 107, 115	MIDI .
For 150, 179	Insertion Effect 120	Loop 135, 192	Filter 202
Formant	Int 206	VariPhrase 82	Macro 200
Control 49	+Mid 206	Looped patterns 164	Messages 197
Explanation 48	A/B 172	Low 202	Mode 197
Keyfollow 79	Metronome 56	Key Touch 91	Parameters 205
LFO 188	Intelligent 102	Lower 35, 148	Set 207
Sw 79	Internal 53, 204	Hold 90	Set, Load 208
Format 68, 132, 213	Interval (transposition) 53	Lower2, arpeggios 187	Set, Save 212
Free Panel 128	Into 154	LVC-1 204 LW 35	Style Select 205
Resume 196	User Style 173		Sync 203
From 153	Intro 26, 95, 97	LWR Hold 90	Synchronization 203
Full 132	Intro/Ending Alteration 106	Lyrics 134	Transpose option 53
FV 98	Inversion 102, 191	Edit 157	User Program link 131
G	K	M	Utilities 203
	KBD Mode 100	M (Master track) 141	MIDI Set
Gain 57	Key 156, 166	M.Bass 35	Automatic selection 207
Phrase 78	Assign 46	M.Drums 35	Ignore (in User Program) 130
Garage 124	Touch 91	Roll 43	Link to User Program 130
Gate 47	TOUCH 31	Macro 117	Min 91
Gate T		Settings 200	Minor 97
16-track 151		Major 97	Minus One 32, 136, 162
Microscope 182		Man 115	Solo sound 33
Gate Time 180, 183			
General MIDI 2 8, 44			

			D:11- 104
Mixer 113	Pan 198	Position 138	Ritardando 104
16-track 144	Delay 119	Post Edit 161	Rnd 115 Robot 82
User Style 175	LFO 188	Preferred Tone 40	Roll
Mode	VariPhrase 79	Preset tempo 176	16-track sequencer 143
Copy 154	Panel Info 24	Preview 72 Proceed 181	M.Drums 43
Portamento 80, 90	PanPot 114, 175	Punch In/Out 142, 144	Room 124
Recording 142	16-track 147	Footswitch 191	Rotary Slow/Fast 191
VariPhrase 82	PanPt 149		RX 201
Modul 149	Param 117, 196, 205 Parameters (MIDI) 205	Q	Velocity 206
Modulation 52, 125, 188, 198	Part 161, 165	Quantize	S
Mono 46, 90	Balance 113	16-track 151	-
Morphing 63, 98	Button 38	Recording 142	Sample 70
Move Mix 183 Music Style 95	Definition 35	Trigger 82	Save
Definiton 59	Field 44	User Style 166	MIDI Set 207, 212
Selecting 59	Mute 114	Quarter tone 92	Song 67, 145 Style 211
Start & Stop 95	Select (for Tone selection) 38	Quick (format) 132	User Program Set 211
Mute	Switch 206	R	User Style 170
16-track 147	Switch on/off 36	RAM 71	VariPhrase 76, 212
Arranger parts 114	Swtc 204	Random Pan 79	Without Lyrics 160
Song tracks 136	Patterns 163	Range, Pitch Bend 188	Scale 191
User Style parts 170	Pause 83	Rate, portamento 80	Tuning 92
M-Value 121, 193	PBend 149	Rec (field) 142	Setup 155
N	PC 153	REC (Tones, effects) 143	Seventh 97
	PChng 149	Recall 195	Share 176
Name 68, 128	Pedal 55	Record	Shared 168
Song 154	Performance Memory, see User	16-track 142, 147	Shift 205
User Style 170, 185 VariPhrase 76	Program	Again 66	16-track 151
New 138	Phrase	Erase 166	User Style 180
No Linear 124	Ctrl 78	Merge 166	Singing 57
Normal 80	Edit 72	Mode (User Stl) 166	Singl 176
Normalize 73	Encode 74	Recording 65 Redo 169	Single 168
Note 149	Gain 78	Reference 222	Part 50
To Arranger 205	Loop 192 Parameters 77	Registrations 127	Phrase 69
NRPN 149, 198	Set 212	Relative 205	Slow 171, 181
NTA 205	Source 71	Release 126	SMF 67, 132
Numeric Pad 49	Piano	Remote 204	Lyrics 157
0	Button 34	Rename 216	Soft 191, 194
	Style 102	Song 139	Thru 202, 206 Solo 135
Octave 54, 162, 205 Recording 142	Pitch	Replace 154, 216	16-track 147
User Style 166	Bend 52, 188	Copy 154	Song 53
One Touch 99	Change (aftertouch) 189	User Style 173	Chain 137
One-shot patterns 164	Down (D Beam) 186	Reset 125, 161, 189	Composer 132
Options 8	Drum Set Note 175	Play & Search 134, 140	Converting to Style 155
16-track 142	Edit (Scale Tune) 93	Recorder 135	Finder 133
Arranger 104	Keyfollow 78	Resonance 126	Header Edit 161
Keyboard 43, 87	Up (D Beam) 186	D Beam 186	Link to User Program 130
Song 139	VariPhrase 49, 77, 190	Retrigger 81	List 133
User Style 165	Plate 124	Retry 61	MIDI 201
Or 98	Play	Reverb 116, 118, 175	Options 139
Oriental Scales 92	Metronome 56	16-track 144	Part 161
Original 25	Song 134	VariPhrase 50, 124	Play 134
Key 74	Song Chain 138	Revolving Bass 102 Revrb 149	Position Pointer 203
OT 100	Trk 147, 171	Rhythmic 30, 46	Save 67, 145
Other 35	Play & Search 133, 140	Ribbon 52, 189	Sync 204
Sample Format 70	Play/Stop 191 Playback 81	Right 101	Song Composer
Output 19	Poly 90	RIT 104	Record 65
Assign 115	Portam Time 89	Rit	Tempo 135
P	Portamento 198	Fill (value) 104	Sort 110 Sostenuto 191, 194
P&S Input 140	Upper 1/2 89	Tempo 104	Sound Palette 125
Pad 54, 194	VariPhrase 79	Value 104	Sound selection 37
Palette 50			Joung Sciention 27

Source 71, 172	Tempo 27, 169	U	VariPhrase 29
Source pattern 153, 185	Arranger (options) 104		
Space 68	Change 104	Unpacking 7	Assign to Song 146 Clinic 45
Specifications 218	Ignore (in User Program) 130	Up 129	Effect 124
Speed Options 171, 181	Preset 176	or ranked to song 33	
Split	Rit 104	UP2	Faders (controllers) 49
Arranger 35	Song 145	Split 86	Hold 192
Keyboard Mode 36	Song Composer 135	to Left 88	Initialize Composer track 146
UP2 to Left 88	Tap 27, 194	Upper	Link to Styles 83
Upper2 86	Up/Down 187	1/2 35	Load 210
Standard 102	User Style 169	1-2 Portam 89	Modulation 188
MIDI File 67, 132	VariPhrase 75, 77	Parts 92	Pan 79
Start, portamento 80	Tick 100, 130	Upper2 Functions 87	Pitch 78
START/STOP 25	Time	User 85	Save 76, 212
Start/Stop 95	Keyfollow 79	Super Tones 28	Set 210
Startup 196	Portamento 80	VariPhrase 45, 69	Synchronization 84
MIDI Set 207	Shift 180	User Program 127	User 69
User Program 131		Automatic selection 131	Velocity
Status 182	Signature 75, 145, 167, 177	Cancel Options 129	Change (16-track) 150
Step 73, 81	Sw 80	Filter 129	Rx/Tx 206
Loop 192	Sync 81	Footswitch 191	Sensitivity 91
Stereo position 114	VariPhrase 49	Load 210	Switch 91
StlVolum 205	To 153	Name 128	User Style 179
Style	To Int 208	Program Change 204	Vibrato 125, 189
Button 59	Tone	Select 128	Virtual Band 22
	Arranger 107	Set 211	Autorun 196
Channel 204	Favorites 40	Song/MIDI Set Link 130	Vocals
Converter 155	Field (16-track) 143	Write 127	Live 57
Database 109	List 222	User Style 163	VariPhrase 45
Delete 111	Map 41, 153	Converter 155	Volume 198
Finder 109	New 42	Copy 209	16-track 144
Linked 83	New Super Tones 86	Delete 185	Arranger parts 113
MIDI 201, 205	Recall 195	Discard recording 169	Expression pedal 192
Mixer 114	Select (User Stl) 174	Edit 174, 177	Keyboard parts 113
Morphing 63	Selection 37	Microscope 181	Knob 19
Name 109	Super 28	Mode select 165	Pedal 55
Options 110	Variation 40	Name 170	VariPhrase 78
Part 35	Touch Control 52, 189	Programming 163	
PC 205	Track 163, 165, 168	Record mode 166	W
Programming Users 163	Erase 178	Save 170, 211	WahWah 189
Sync 204	Length 176	Tempo 169	WAV 70
Suitable Tempo 100	Transpose	Usr	Whole 35, 101
Super Tones 28, 85	16-track 150	MemPC 204	Words 134
Sustain 55	Arranger/Keyboard 53	_	Wrap 106
Switch 190	Octave steps 54	Prg 128	Write
Sync 96	Song Composer/Keyboard 137	Utility	MIDI Set 207
Adjust 84	User Style 179	16-track 152	User Program 127
Settings 84	Tremolo 189	Disk 213	X
VariPhrase 81	Trigger 47	User Style 184	XG 44
Synchro (Lyrics) 158	Truncate 72	V	
Synchronization 203	TSign 167	Value 150, 152, 179, 180	Z
T	Tune 55	Var 98	Zip
•	Upper2 88	Variation 25	Disk User 61
T. Quantize 82	TVF	Presets (change) 40	Eject 62
Tap Tempo 27, 194	Cutoff 126	Tone 40	Eject (field) 61
	Cutoff (aftertouch) 189	20	Format 68
	Resonance 126		Initialize 213
	TX 201		Save Song 67
	Octave 205		Song Finder 133
	· · · · · · · · · · · · · · · · · · ·		Style Finder 109
	Velocity 206		Style Options 110
	Type		Zone 205
	Insert 183		Lone Luj
	Portamento 80		

Information

When you need repair service, call your nearest Roland Service Center or authorized Roland distributor in your country as shown below.



EGYPT

Al Fanny Trading Office P.O. Box 2904, El Horrieh Heliopolos, Cairo, TEL: (02) 4185531

REUNION

Maison FO - YAM Marcel 25 Rue Jules Hermann, Chaudron - BP79 97 491 Ste Clotilde Cedex, REUNION ISLAND TEL: 28 29 16

SOUTH AFRICA

That Other Music Shop (PTY) Ltd. 11 Melle St., Braamfonteir Johannesbourg Republic of SOUTH AFRICA

P.O.Box 32918, Braamfontein 2017 Republic of SOUTH AFRICA TEL: (011) 403 4105

Paul Bothner (PTY) Ltd. 17 Werdmuller Contro Classics 7700 Republic of SOUTH AFRICA

P.O. Box 23032 Claremont, Cape Town SOUTH AFRICA, 7735 TEL: (021) 674 4030



CHINA

Beijing Xinghai Musical Instruments Co., Ltd. 6 Huangmuchang Chao Yang District, Beijing, CHINA TEL: (010) 6774 7491

HONG KONG

Tom Lee Music Co., Ltd. Service Division 22-32 Pun Shan Street, Tsuen Wan, New Territories, HONG KONG TEL: 2415 0911

INDIA

Rivera Digitec (India) Pvt. Ltd. 409, Nirman Kendra Mahalaymi Flats Compound Off. Dr. Edwin Moses Road, Mumbai-400011, INDIA TEL: (022) 498 3079

INDONESIA

PT Citra IntiRama J1. Cideng Timur No. 15J-150 Jakarta Pusat INDONESIA

KOREA

Cosmos Corporation 1461-9, Seocho-Dong, Seocho Ku, Seoul, KOREA TEL: (02) 3486-8855

MALAYSIA

Bentley Music SDN BHD 140 & 142, Jalan Bukit Bintang 55100 Kuala Lumpur, MALAYSIA TEL: (03) 2443333

PHILIPPINES

G.A. Yupangco & Co. Inc. 339 Gil J. Puyat Avenue Makati, Metro Manila 1200, PHILIPPINES TEL: (02) 899 9801

SINGAPORE

Swee Lee Company 150 Sims Drive, SINGAPORE 387381 TEL: 748-1669

CRISTOFORI MUSIC PTE

LTD Bik 3014, Bedok Industrial Park E, #02-2148, SINGAPORE 489980 TEL: 243 9555

TAIWAN

ROLAND TAIWAN ENTERPRISE CO., LTD. Room 5, 9fl. No. 112 Chung Shan N.Road Sec.2, Taipei, TAIWAN, TEL: (02) 2561 3339

THAILAND

Theera Music Co., Ltd. 330 Verng NakomKasem, Soi 2, Bangkok 10100, THAILAND TEL: (02) 2248821

VIETNAM

Saigon Music 138 Tran Quang Khai St., District 1 Ho Chi Minh City VIETNAM TEL: (08) 844-4068

AUSTRALIA/ **NEW ZEALAND**

AUSTRALIA

Roland Corporation Australia Pty., Ltd. 38 Campbell Avenue Dee Why West. NSW 2099 AUSTRALIA TEL: (02) 9982 8266

NEW ZEALAND

Roland Corporation (NZ) Ltd. 97 Mt. Eden Road, Mt. Eden, Auckland 3, NEW ZEALAND TEL: (09) 3098 715

CENTRAL/LATIN **AMERICA**

ARGENTINA

Instrumentos Musicales S.A. Florida 656 2nd Floor Office Number 206A Buenos Aires ARGENTINA, CP1005 TEL: (54-11) 4-393-6057

BRAZIL

Roland Brasil Ltda. R. Corunel Octaviano da Silveira 203 05522-010 Sao Paulo BRAZIL TEL: (011) 3743 9377

COSTA RICA

JUAN Bansbach Instrumentos Musicales Ave.l. Calle 11, Apartado 10237, San Jose, COSTA RICA TEL: (506)258-0211

CHILE

Comercial Fancy S.A. Avenida Rancagua #0330 Providencia Santiago, CHILE TEL: 56-2-373-9100

EL SALVADOR

OMNI MUSIC 75 Avenida Notre YY Alameda, Juan Pablo 2, No. 4010 San Salvador, EL SALVADOR TEL: (503) 262-0788

MEXICO

Casa Veerkamp, s.a. de c.v. Av. Toluca No. 323, Col. Olivar de los Padres 01780 Mexico D.F. MEXICO TEL: (525) 668 04 80

La Casa Wagner de

Guadalajara s.a. de c.v. Av. Corona No. 202 S.J. Guadalajara, Jalisco Mexico C.P.44100 MEXICO TEL: (3) 613 1414

PANAMA

SUPRO MUNDIAL, S.A. Boulevard Andrews, Albrook, Panama City, REP. DE PANAMA TEL: (507) 315-0101

PARAGUAY

Distribuidora De Distribuidora De Instrumentos Musicales J.E. Olear y ESQ. Manduvira Edeficio, El Dorado Planta Baja Asuncion PARAGUAY TEL: 595-21-492147

PERU

VIDEO Broadcast S.A. Portirari 199 (ESQ. HALS), San Borja, Lima 41, REP. OF PERU TEL: 51-14-758226

URUGUAY

Todo Musica S.A. Cuareim 1844, Montevideo, URUGUAY, CP11200 TEL: 5982-924-2335

VENEZUELA

Musicland Digital C.A. Av. Francisco de Miranda, Centro Parque de Cristal, Nivel C2 Local 20 Caracas VENEZUELA TEL: (02) 285 9218

EUROPE

AUSTRIA

Roland Austria GES.M.B.H. Siemensstrasse 4, P.O. Box 74, A-6063 RUM, AUSTRIA TEL: (0512) 26 44 260

BELGIUM/HOLLAND/ LUXEMBOURG

Roland Benelux N. V. Houtstraat 3, B-2260, Oevel (Westerlo) BELGIUM TEL: (014) 575811

DENMARK

Roland Scandinavia A/S Nordhavnsvej 7, Postbox 880, DK-2100 Copenhagen DENMARI TEL: (039)16 6200

FRANCE

Roland France SA 4, Rue Paul Henri SPAAK, Parc de l'Esplanade, F 77 462 St. Thibault, Lagny Cedex FRANCE TEL: 01 600 73 500

FINLAND

Roland Scandinavia As, Filial Finland Lauttasaarentie 54 B Fin-00201 Helsinki, FINLAND TEL: (9) 682 4020

GERMANY

Roland Elektronische Musikinstrumente HmbH. Oststrasse 96, 22844 Nordersted GERMANY TEL: (040) 52 60090

GREECE

STOLLAS S.A. Music Sound Light 155, New National Roa 26422 Patras, GREECE TEL: 061-435400

HUNGARY

Intermusica Ltd. Wareluuse Area 'DEPO' Pf.83 H-2046 Torokbalint, HUNGARY TEL: (23) 511811

IRELAND

Roland Ireland Audio House, Belmont Court, Donnybrook, Dublin 4. Republic of IRELAND TEL: (01) 2603501

ITALY

Roland Italy S. p. A. Viale delle Industrie 8, 20020 Arese, Milano, ITALY TEL: (02) 937-78300

NORWAY

Roland Scandinavia Avd. Kontor Norge Lilleakerveien 2 Postboks 95 Lilleaker N-0216 Osto NORWAY TEL: 273 0074

POLAND

P. P. H. Brzostowicz UL. Gibraltarska 4. PL-03664 Warszawa POLAND TEL: (022) 679 44 19

PORTUGAL

Tecnologias Musica e Audio, Roland Portugal, S.A. RUA DE SANTA CARARINA 131/133, 4000-450 PORTO PORTUGAL TEL: (022) 208 4456

ROMANIA

FBS LINES Plata Lihertatii 1. RO-4200 Cheorgheni TEL: (066) 164-609

RUSSIA

Slami Music Company Sadojava-Triumfalnaja st., 16 103006 Moscow, RUSSIA TEL: 095 209 2193

SPAIN

Roland Electronics de España, S. A. Calle Bolivia 239, 08020 Barcelona, SPAIN TEL: (93) 308 1000

SWEDEN

Roland Scandinavia A/S SWEDISH SALES OFFICE Danvik Center 28, 2 tr. S-131 30 Nacka SWEDEN TEL: (08) 702 0020

SWITZERLAND

Roland (Switzerland) AG Musitronic AG Gerberstrasse 5, Postfach, CH-4410 Liestal, SWITZERLAND TEL: (061) 921 1615

UKRAINE

TIC-TAC Mira Str. 19/108 P.O. Box 180 295400 Munkachevo, UKRAINE TEL: (03131) 414-40

UNITED KINGDOM

Roland (U.K.) Ltd.
Atlantic Close, Swansea
Enterprise Park, SWANSEA
SA7 9FJ,
UNITED KINGDOM
TEL: (01792) 700139

MIDDLE EAST

BAHRAIN

Moon Stores Bab Al Bahrain Road, State of BAHRAIN TEL: 211 005

CYPRUS

Radex Sound Equipment Ltd. 17 Diagorou St., P.O. Box 2046, Nicosia CYPRUS TEL: (02) 453 426

Halilit P. Greenspoon & Sons Ltd. 8 Retzif Ha'aliya Hashnya St. Tel-Aviv-Yafo ISRAEL TEL: (03) 6823666

JORDAN

AMMAN Trading Agency Prince Mohammed St. P.O. Box 825 Amman 11118 JORDAN TEL: (06) 4641200

KIRWAIT

Easa Husain Al-Yousifi Abdullah Salem Street, Safat KUWAIT TEL: 5719499

LEBANON

A. Chahine & Fils
P.O. Box 16-5857 Gergi Zeidan St.
Chahine Building, Achrafieh
Beirut, LEBANON
TEL: (01) 335799

QATAR

Al Emadi Co. (Badie Studio : Stores) P.O. Box 62, DOHA QATAR TEL: 4423-554

SAUDI ARABIA

aDawliah Universal Electronics APL
Corniche Road, Aldossary Bldg.,
1st Floor
SAUDI ARABIA

P.O.Box 2154, Alkhobar 31952 SAUDI ARABIA TEL: (03) 898 2081

SYRIA

Technical Light & Sound Center Khaled Ibn Al Walid St. P.O. Box 13520 Damascus - SYRIA TEL: (011) 2235 384

TURKEY

Barkat muzik aletleri ithalat ve ihracat Ltd Sti Siraselviler cad.Guney is hani 84-86/6, Taksim. Istanbul. TURKEY TEL: (0212) 2499324

Zak Electronics & Musical Lak Electronics & Musica Instruments Co. L.L.C. Zabeel Road, Al Sheroog Bldg., No. 14, Grand Floor DUBAI U.A.E. TEL: (04) 3360715

NORTH AMERICA

CANADA

Roland Canada Music Ltd. (Head Office) 5480 Parkwood Way Richmond B. C., V6V 2M4 CANADA TEL: (0604) 270 6626

Roland Canada Music Ltd. Koland Canada Music Ltd. (Toronto Office) Unit 2, 109 Woodbine Downs Blvd, Etobicoke, ON M9W 6Y1 CANADA TEL: (0416) 213 9707

Roland Corporation U.S. 5100 S. Eastern Avenue Los Angeles, CA 90040-2938, U. S. A. TEL: (323) 890 3700

As of November 1, 2000 (Roland)

-For EU Countries



This product complies with the requirements of European Directives EMC 89/336/EEC and LVD 73/23/EEC.

For the USA

FEDERAL COMMUNICATIONS COMMISSION RADIO FREQUENCY INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Unauthorized changes or modification to this system can void the users authority to operate this equipment. This equipment requires shielded interface cables in order to meet FCC class B Limit.

For Canada

NOTICE

This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

AVIS

Cet appareil numérique de la classe B respecte toutes les exigences du Règlement sur le matériel brouilleur du Canada.

K6018420

K6018420



