

# 



# SPECIAL MESSAGE SECTION

This product utilizes batteries or an external power supply (adapter). DO NOT connect this product to any power supply or adapter other than one described in the manual, on the name plate, or specifically recommended by Yamaha.

**WARNING:** Do not place this product in a position where anyone could walk on, trip over ,or roll anything over power or connecting cords of any kind. The use of an extension cord is not recommended! IF you must use an extension cord, the minimum wire size for a 25' cord (or less) is 18 AWG. NOTE: The smaller the AWG number, the larger the current handling capacity. For longer extension cords, consult a local electrician.

This product should be used only with the components supplied or; a cart, rack, or stand that is recommended by Yamaha. If a cart, etc., is used, please observe all safety markings and instructions that accompany the accessory product.

#### SPECIFICATIONS SUBJECT TO CHANGE:

The information contained in this manual is believed to be correct at the time of printing. However, Yamaha reserves the right to change or modify any of the specifications without notice or obligation to update existing units.

This product, either alone or in combination with an amplifier and headphones or speaker/s, may be capable of producing sound levels that could cause permanent hearing loss. DO NOT operate for long periods of time at a high volume level or at a level that is uncomfortable. If you experience any hearing loss or ringing in the ears, you should consult an audiologist.

IMPORTANT: The louder the sound, the shorter the time period before damage occurs.

Some Yamaha products may have benches and / or accessory mounting fixtures that are either supplied with the product or as optional accessories. Some of these items are designed to be dealer assembled or installed. Please make sure that benches are stable and any optional fixtures (where applicable) are well secured BEFORE using.

Benches supplied by Yamaha are designed for seating only. No other uses are recommended.

#### NOTICE:

Service charges incurred due to a lack of knowledge relating to how a function or effect works (when the unit is operating as designed) are not covered by the manufacturer's warranty, and are therefore the owners responsibility. Please study this manual carefully and consult your dealer before requesting service.

#### **ENVIRONMENTAL ISSUES:**

Yamaha strives to produce products that are both user safe and environmentally friendly. We sincerely believe that our products and the production methods used to produce them, meet these goals. In keeping with both the letter and the spirit of the law, we want you to be aware of the following:

#### **Battery Notice:**

This product MAY contain a small non-rechargeable battery which (if applicable) is soldered in place. The average life span of this type of battery is approximately five years. When replacement becomes necessary, contact a qualified service representative to perform the replacement.

This product may also use "household" type batteries. Some of these may be rechargeable. Make sure that the battery being charged is a rechargeable type and that the charger is intended for the battery being charged.

When installing batteries, do not mix batteries with new, or with batteries of a different type. Batteries MUST be installed correctly. Mismatches or incorrect installation may result in overheating and battery case rupture.

#### Warning:

Do not attempt to disassemble, or incinerate any battery. Keep all batteries away from children. Dispose of used batteries promptly and as regulated by the laws in your area. Note: Check with any retailer of household type batteries in your area for battery disposal information.

#### **Disposal Notice:**

Should this product become damaged beyond repair, or for some reason its useful life is considered to be at an end, please observe all local, state, and federal regulations that relate to the disposal of products that contain lead, batteries, plastics, etc. If your dealer is unable to assist you, please contact Yamaha directly.

#### NAME PLATE LOCATION:

The name plate is located on the bottom of the product. The model number, serial number, power requirements, etc., are located on this plate. You should record the model number, serial number, and the date of purchase in the spaces provided below and retain this manual as a permanent record of your purchase.

Model		
Serial No.		
Purchase Date		

# PLEASE KEEP THIS MANUAL

# **PRECAUTIONS**

#### PLEASE READ CAREFULLY BEFORE PROCEEDING

\* Please keep this manual in a safe place for future reference.



### **WARNING**

Always follow the basic precautions listed below to avoid the possibility of serious injury or even death from electrical shock, short-circuiting, damages, fire or other hazards. These precautions include, but are not limited to, the following:

#### Power supply/AC power adaptor

- Only use the voltage specified as correct for the instrument. The required voltage is printed on the name plate of the instrument.
- Use the specified adaptor (PA-300 or an equivalent recommended by Yamaha) only. Using the wrong adaptor can result in damage to the instrument or overheating.
- Check the electric plug periodically and remove any dirt or dust which may have accumulated on it.
- Do not place the AC adaptor cord near heat sources such as heaters or radiators, and do not excessively bend or otherwise damage the cord, place heavy objects on it, or place it in a position where anyone could walk on, trip over, or roll anything over it.

#### Do not open

 Do not open the instrument or attempt to disassemble the internal parts or modify them in any way. The instrument contains no user-serviceable parts. If it should appear to be malfunctioning, discontinue use immediately and have it inspected by qualified Yamaha service personnel.

#### Water warning

- Do not expose the instrument to rain, use it near water or in damp or wet conditions, or place containers on it containing liquids which might spill into any openings.
- Never insert or remove an electric plug with wet hands.

#### Fire warning

Do not put burning items, such as candles, on the unit.
 A burning item may fall over and cause a fire.

#### If you notice any abnormality

If the AC adaptor cord or plug becomes frayed or damaged, or if
there is a sudden loss of sound during use of the instrument, or if
any unusual smells or smoke should appear to be caused by it,
immediately turn off the power switch, disconnect the adaptor
plug from the outlet, and have the instrument inspected by qualified Yamaha service personnel.



### **CAUTION**

Always follow the basic precautions listed below to avoid the possibility of physical injury to you or others, or damage to the instrument or other property. These precautions include, but are not limited to, the following:

#### Power supply/AC power adaptor

- When removing the electric plug from the instrument or an outlet, always hold the plug itself and not the cord.
- Unplug the AC power adaptor when not using the instrument, or during electrical storms.
- Do not connect the instrument to an electrical outlet using a multiple-connector. Doing so can result in lower sound quality, or possibly cause overheating in the outlet.

#### Location

- Do not expose the instrument to excessive dust or vibrations, or extreme cold or heat (such as in direct sunlight, near a heater, or in a car during the day) to prevent the possibility of panel disfiguration or damage to the internal components.
- Do not use the instrument in the vicinity of a TV, radio, stereo equipment, mobile phone, or other electric devices. Otherwise, the instrument, TV, or radio may generate noise.
- Do not place the instrument in an unstable position where it might accidentally fall over.
- Before moving the instrument, remove all connected adaptor and other cables.
- Use only the stand specified for the instrument. When attaching the stand, use the provided screws only. Failure to do so could cause damage to the internal components or result in the instrument falling over.

#### **Connections**

Before connecting the instrument to other electronic components, turn off the power for all components. Before turning the power on or off for all components, set all volume levels to minimum. Also, be sure to set the volumes of all components at their minimum levels and gradually raise the volume controls while playing the instrument to set the desired listening level.

#### **Maintenance**

 When cleaning the instrument, use a soft, dry cloth. Do not use paint thinners, solvents, cleaning fluids, or chemical-impregnated wiping cloths.

#### **Handling caution**

- Do not insert a finger or hand in any gaps on the instrument.
- Never insert or drop paper, metallic, or other objects into the gaps on the panel or keyboard. If this happens, turn off the power immediately and unplug the power cord from the AC outlet. Then have the instrument inspected by qualified Yamaha service personnel.
- Do not place vinyl, plastic or rubber objects on the instrument, since this might discolor the panel or keyboard.
- Do not rest your weight on, or place heavy objects on the instrument, and do not use excessive force on the buttons, switches or connectors
- Do not operate the instrument for a long period of time at a high or uncomfortable volume level, since this can cause permanent hearing loss. If you experience any hearing loss or ringing in the ears, consult a physician.

#### Saving data

#### Saving and backing up your data

 Some of the current memory data (see page 42) is lost when you turn off the power to the instrument. Save the data to a floppy disk/the User Drive (see page 39, 47).
 Saved data may be lost due to malfunction or incorrect operation. Save important data to a floppy disk.

When you change settings in a display page and then exit from that page, System Setup data (listed in the Parameter Chart of the separate Data List booklet) is automatically stored. However, this edited data is lost if you turn off the power without properly exiting from the relevant display.

#### Backing up the floppy disk

 To protect against data loss through media damage, we recommend that you save your important data onto two floppy disks.

#### Caution for data operations

Make sure NEVER to turn the PSR-2100/1100's power off during any kind of data operation involving the USER/FLOPPY DISK drives — such as saving, deleting, or copying/pasting — until the operation is completely finished. (Make sure to wait until the alert message disappears.)

Turning the power off during the operation results in the loss of the data being saved or pasted to the respective drive. Keeping the power on during such operations is particularly important in regard to the USER drive. Turning off the power while performing a save/delete/paste operation with the USER drive may result in loss of ALL data on the USER drive (upon the next power on) — and not just the data in question. In other words, if you are performing a save/delete/paste operation on only the song data of the USER drive and you turn off the power before the operation is completed, you risk losing ALL your USER drive data — including all voices, styles, Multi Pad banks and Registration Memory presets you've saved to the USER drive.

This caution also applies to creating a new folder on the USER drive or using the factory reset operation (page 154).

Yamaha cannot be held responsible for damage caused by improper use or modifications to the instrument, or data that is lost or destroyed.

Always turn the power off when the instrument is not in use.

Even when the power switch is in the "STANDBY" position, electricity is still flowing to the instrument at the minimum level. When you are not using the instrument for a long time, make sure you unplug the AC power adaptor from the wall AC outlet.

Thank you for purchasing the Yamaha PSR-2100/1100! We recommend that you read this manual carefully so that you can fully take advantage of the advanced and convenient functions of the PSR-2100/1100. We also recommend that you keep this manual in a safe and handy place for future reference.

#### **Accessories**

- PA-300 AC Adaptor\*
- Floppy Disk (blank)
- Music Rest (page 17)
- Data List
- Owner's Manual
- \* May not be included in your area. Please check with your Yamaha dealer.

#### About this Owner's Manual and Data List

This manual consists of four main sections: Introduction, Quick Guide, Basic Operation, and Reference. Also, a separate Data List is provided.

**Introduction (page 2):** Please read this section first.

Quick Guide (page 20): This section explains how to use the basic functions.

**Basic Operation (page 38):** This section explains how to use the basic operations including display-based controls.

**Reference** (page 55): This section explains how to make detailed settings for the PSR-2100/1100's various functions.

Data List: Voice List, MIDI Data Format, etc.

- \* The illustrations and LCD screens as shown in this owner's manual are for instructional purposes only, and may appear somewhat different from those on your instrument.
- \* The example Operation Guide displays shown in this Manual are taken from the PSR-2100, and in English.
- \* This product (PSR-2100) is manufactured under license of U.S. Patents No.5231671, No.5301259, No.5428708, and No.5567901 from IVL Technologies Ltd.
- \* The bitmap fonts used in this instrument have been provided by and are the property of Ricoh Co., Ltd.
- \* Copying of the commercially available software is strictly prohibited except for your personal use.

#### **COPYRIGHT NOTICE**

This product incorporates and bundles computer programs and contents in which Yamaha owns copyrights or with respect to which it has license to use others' copyrights. Such copyrighted materials include, without limitation, all computer software, styles files, MIDI files, WAVE data and sound recordings. Any unauthorized use of such programs and contents outside of personal use is not permitted under relevant laws. Any violation of copyright has legal consequences. DON'T MAKE, DISTRIBUTE OR USE ILLEGAL COPIES.

#### Trademarks:

- Apple and Macintosh are trademarks of Apple Computer, Inc.
- IBM-PC/AT is a trademark of International Business Machines Corporation.
- Windows is the registered trademark of Microsoft® Corporation.
- · All other trademarks are the property of their respective holders.

# Handling the Floppy Disk Drive (FDD) and Floppy Disk

Be sure to handle floppy disks and treat the disk drive with care. Follow the important precautions below.

#### **Compatible Disk Type**

• 3.5" 2DD and 2HD type floppy disks can be used.


#### Inserting/Ejecting Floppy Disks

#### To insert a floppy disk into the disk drive:

 Hold the disk so that the label of the disk is facing upward and the sliding shutter is facing forward, towards the disk slot. Carefully insert the disk into the slot, slowly pushing it all the way in until it clicks into place and the eject button pops out.

#### Drive lamp

When the power is turned on, the drive lamp (at the bottom left of the drive) lights to indicate the drive can be used.




#### To eject a floppy disk:

Before ejecting the disk, be sure to confirm that data is not being written to the floppy disk.

If data is currently being written to the floppy disk in the following operations, the messages "Now executing," "Now copying," and "Now formatting" appears in the display.

- Moving, copying, pasting, saving, or deleting data (page 45 - 47).
- Naming files and folders (page 44); creating a new folder (page 47).
- Copying a disk to an another disk (page 153); formatting the disk (page 153).



- Never attempt to remove the disk or turn the power off
  when the data is being written to the floppy disk.
   Doing so can damage the disk and possibly the disk
  drive. Press the eject button slowly as far as it will go;
  the disk will automatically pop out. When the disk is
  fully ejected, carefully remove it by hand.
- If the eject button is pressed too quickly, or if it is not pressed in as far as it will go, the disk may not eject properly. The eject button may become stuck in a half-pressed position with the disk extending from the drive slot by only a few millimeters. If this happens, do not attempt to pull out the partially ejected disk, since using force in this situation can damage the disk drive mechanism or the floppy disk. To remove a partially ejected disk, try pressing the eject button once again, or push the disk back into the slot and then repeat the eject procedure.
- Be sure to remove the floppy disk from the disk drive before turning off the power. A floppy disk left in the drive for extended periods can easily pick up dust and dirt that can cause data read and write errors.

### Cleaning the Disk Drive Read/Write Head

- Clean the read/write head regularly. This instrument employs a precision magnetic read/write head which, after an extended period of use, will pick up a layer of magnetic particles from the disks used that will eventually cause read and write errors.
- To maintain the disk drive in optimum working order Yamaha recommends that you use a commerciallyavailable dry-type head cleaning disk to clean the head about once a month. Ask your Yamaha dealer about the availability of proper head-cleaning disks.
- Never insert anything but floppy disks into the disk drive. Other objects may cause damage to the disk drive or floppy disks.


#### About the Floppy Disks

#### To handle floppy disks with care:

- Do not place heavy objects on a disk or bend or apply pressure to the disk in any way. Always keep floppy disks in their protective cases when they are not in
- Do not expose the disk to direct sunlight, extremely high or low temperatures, or excessive humidity, dust or liquids.
- Do not open the sliding shutter and touch the exposed surface of the floppy disk inside.
- Do not expose the disk to magnetic fields, such as those produced by televisions, speakers, motors, etc., since magnetic fields can partially or completely erase data on the disk, rendering it unreadable.
- Never use a floppy disk with a deformed shutter or housing.
- Do not attach anything other than the provided labels to a floppy disk. Also make sure that labels are attached in the proper location.

#### To protect your data (Write-protect Tab):

 To prevent accidental erasure of important data, slide the disk's write-protect tab to the "protect" position (tab open).




#### Data backup

• For maximum data security Yamaha recommends that you keep two copies of important data on separate floppy disks. This gives you a backup if one disk is lost or damaged. To make a backup disk use the Disk to Disk function on page 153.

# **About the Display Messages**

A message (information or confirmation dialog) sometimes appears on the screen to facilitate operation. When such messages appear, simply follow the instructions as shown by pressing the corresponding button.



For this example, press the **[G] (YES)** button to execute formatting.

#### J NOTE

You can select the desired language from the Help display (page 52).

# **Table of Contents**

Introduction 2
PRECAUTIONS
Accessories
About this Owner's Manual and Data List
Handling the Floppy Disk Drive (FDD)
and Floppy Disk7
About the Display Messages8
Application Index
What can you do with the PSR-2100/1100? 14
Setting Up the PSR-2100/1100
Panel Controls and Terminals
railer Controls and Terminals 10
<b>Quick Guide20</b>
Playing the Demos
Song Playback
Playback of Songs21
Playing Voices
Playing a Voice25
Playing Two Voices Simultaneously
Playing Different Voices with the
Left and Right Hands27
Playing Styles 28
Playing a style28
Style Sections30
One Touch Setting32
Music Finder33
Using the Music Finder33
Searching the Music Finder Records34
Playing with the Songs36
Playing Along with the PSR-2100/110036
Recording37
Basic Operations
— Organizing Your Data 38
Contents shown in the Main Display 38
Open/Save Display39
Example — Open/Save display40
Selecting Files and Folders43
File/Folder-related Operations 44
Naming Files/Folders44
Moving Files/Folders
Copying Files/Folders
Deleting Files/Folders
Saving Files47 Organizing Files by Creating a New Folder47
Displaying Upper Level pages47
Entering Characters and Changing Icons47
Using the [DATA ENTRY] Dial
Direct Access — Instant Selection of Displays 50
Help Messages
Using the Metronome
Adjusting the Tempo
Tan Tempo 54

Reference Playing the Demos	55
Voices	57
Selecting a Voice  Layer/Left — Playing Several Sounds  Simultaneously	
Layer — Layering Two Different Voices  Left — Setting Separate Voices for the Left and Right Sections of the Keyboard	. 59 . 60
Applying Voice Effects PITCH BEND Wheel & MODULATION Wheel Adjusting the Octave setting	. 61
Styles	<b>62</b>
Playing a style	. <b>62</b> . 64 . 64
MAIN A/B/C/D, INTRO, ENDING, BREAK) Stopping the Style Playback While Releasing Keys (SYNC. STOP)	. 68 69
accompaniment sections — Auto Fill In	. 70
Registering the Panel Controls in One Touch Setting (ONE TOUCH SETTING)	g . 71
Searching the Ideal Setups — Music Finder Search. Editing Records — Music Finder Record Edit	. 73
The Multi Pads	76
Playing the Multi Pads  Chord Match  Multi Pad Edit	. 76
Song Playback	<b>78</b>
Compatible Song TypesSong Playback	
Playing the Internal Songs	. 81
— Track1/Track2/Extra Tracks	

Displaying Music Notation — Score 83	Creating Multi Pad
Displaying the Lyrics 86	— Multi Pad Creator121
Saving and Recalling	Operation 121
<b>Custom Panel Setups</b>	Multi Pad Realtime Recording — Record 122
-	Start recording
— Registration Memory 87	Stop recording
Registering Panel Setups — Registration Memory 87 Saving Your Registration Memory Setups88	
Recalling a Registration Memory Setup 89	Adjust the Volume Balance and Changing Voices
Editing Voices	— Mixing Console124
— Sound Creator 90	•
	Operation
Operation	Setting the Level Balance and Voice — Volume/Voice125
Regular Voice Parameters	Changing the Tone of the Voice — Filter 126
Organ Flutes (PSR-2100 only)94	Changing Pitch-related Settings — Tune 126
D	Adjusting the Effects127
Recording Your Performances	Effect Structure
and Creating Songs	Setting the Equalizer—EQ (PSR-2100 only) 130
— Song Creator 95	
_	Using a Microphone
About Song Recording	— MIC. (PSR-2100 only)131
Quick Recording   96     Multi Recording   97	— Mic. (1 3K-2 100 omy)131
Recording Individual Notes — Step Record 99	Selecting a Vocal Harmony Type 131
Operation99	Making Settings for the Vocal Harmony
Recording Melodies — Step Record (Note)101	and Microphone — MICROPHONE SETTING 133
Recording Chord Changes for the Auto Accompani-	Adjusting the Vocal Harmony Settings
ment — Step Record (Chord)102	and Microphone Effects — OVERALL SETTING 133
Select the Recording Options: Starting, Stopping,	Setting the Microphone Volume and Related Effects
Punching In/Out — Rec Mode104	— TALK SETTING 135
Editing a Recorded Song 105	
Editing Channel-related Parameters — Channel 105	Making Global and
Editing Note Events — 1 - 16	Other Important Settings
Editing Chord Events — CHD109	— Function136
Editing System Events — SYS/EX. (System Exclusive)109	— i diretion130
Inputting and Editing Lyrics110	Operation 136
Customizing the Event List — Filter110	Fine Tuning the Pitch/Selecting a Scale
<b>3</b> · · · · · · · · · · · · · · · · · · ·	— Master Tune/Scale Tune 138
Creating Accompaniment Styles	Tuning the Overall Pitch — Master Tune 138
Creating Accompaniment Styles	Selecting a Scale — Scale Tune
— Style Creator 111	Setting Song-related Parameters
About Creating Accompaniment Styles 111	— Song Settings140
Style File Format	Setting Auto Accompaniment-related Parameters
Operation 112	— Style Setting, Split Point,
Realtime Recording — Basic 113	and Chord Fingering141
Step Recording114	Setting Auto Accompaniment-related Parameters
Assembling an Accompaniment Style	<ul> <li>Style Setting and Split Point</li></ul>
—Assembly 115	Making Settings for the Pedals and Keyboard
Edit the Created Accompaniment Style 116	— Controller 142
Change the Rhythmic Feel	Making Settings for the Pedals
— Groove and Dynamics116	Changing the Touch Sensitivity Modulation
Editing the Channel Data118	and Transpose — Keyboard/Panel 144
Making Style File Format Settings — Parameter119	Setting the Registration Sequence, Freeze,
	and Voice Set

Specifying the Order for Calling Up Registration	
Memory Presets — Registration Sequence1	
Maintaining Panel Settings — Freeze1	45
Changing the Automatically Selected Voice Settings	
— Voice Set1	46
Setting Harmony and Echo1	46
Setting the MIDI Parameters1	
Making Overall System Settings (Local Control,	
Clock, etc.) — System1	1Ω
Transmitting MIDI Data — Transmit1	
•	
Receiving MIDI Data — Receive	
Setting Root Note Channels — Root	
Setting Chord Channels — Chord Detect	
Other Settings — Utility 1	51
Making Settings for Fade In/Out, Metronome,	
Parameter Lock, and Tap — CONFIG 11	51
Making Settings for the Display	
and Voice Number Indication — CONFIG 21	
Copying and Formatting Disks — Disk1	53
Entering Your Name and Language Preference	
— Owner1	54
Restoring the Factory-programmed Settings of the	
PSR-2100/1100 — System Reset1	54
•	
Heimer Vous DCD 2100/1100	
Using Your PSR-2100/1100	
with Other Devices 15	5
Using the Headphones (PHONES jack)1	55
Connecting the Microphone or Guitar	
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)1	
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)1 Playing the sounds of the PSR-2100/1100 through an	
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)1 Playing the sounds of the PSR-2100/1100 through an external audio system, and recording the sounds to	55
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)1 Playing the sounds of the PSR-2100/1100 through an	55
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)1 Playing the sounds of the PSR-2100/1100 through an external audio system, and recording the sounds to	55
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)	55 56
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)	55 56
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)	55 56
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)	55 56 56
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)	55 56 56
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)	<ul><li>55</li><li>56</li><li>56</li><li>56</li><li>57</li></ul>
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)	55 56 56 56 57 58
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)	55 56 56 56 57 58 60
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)	55 56 56 56 57 58 60 61
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)	55 56 56 57 58 60 61 61
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)	55 56 56 56 57 58 60 61 61 61
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)	55 56 56 56 57 58 60 61 61 61
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)	55 56 56 57 58 60 61 61 61 62
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)	55 56 56 57 58 60 61 61 61 62
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)	55 56 56 57 58 60 61 61 61 62
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)	55 56 56 57 58 60 61 61 61 62
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)	55 56 56 57 58 60 61 61 61 62
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)	55 56 56 57 58 60 61 61 61 62
Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only)	55 56 56 57 58 60 61 61 61 62

Introduction
Quick Guide
Basic Operations - Organizing Your Data
Playing the Demos
Voices
Styles
The Multi Pad
Song Playback
Saving and Recalling Custom Panel Setups - Registration Memory
Editing Voices - Sound Creator
Recording Your Performances and Creating Songs - Song Creator
Creating Accompaniment Styles - Style Creator
Creating Multi Pad - Multi Pad Creator
Adjust the Volume Balance and Changing Voices - Mixing Console
Using a Microphone - MIC. (PSR-2100 only)
Making Global and Other Important Settings - Function
Using Your PSR-2100/1100 with Other Devices
Appendix


# **Application Index**

Use this index to find reference pages that may be helpful for your particular application and situation.

Listening	
Listening to the internal songs  Listening to disk songs  Listening to demo songs  Listening to the demo of the selected voices  Listening to songs with the special voices of the PSR-2100/7	
Playing	
Playing an accompaniment that matches pitch	'Layer — Layering Two Different Voices" on page 59
Changing the sound	
Enhancing the sound with touch and other effects	
Playing the auto accompaniment	t
Playing the accompaniment automatically  Calling up ideal panel settings for your music	page 62
Practicing	
Practicing with an accurate and steady tempo	"Using the Metronome" on page 53
Recording	
Recording your performance  Creating a song by entering notes	. •
Creating your original settings	
Creating voices Creating accompaniment styles Creating multi pads	page 111

Using a microphone (PSR-2100 only)	
Connecting the microphone" "Connecting the Microphone or Guitar (MIC./LI Adding automatic harmonies to your singing	
Settings	
Registering Panel Setups  Tuning the pitch/Selecting a scale  Making detailed settings for playing back songs  Making detailed settings for the auto accompaniment  Making detailed settings for the keyboard voices  Making detailed settings for MIDI	page 138page 140page 141page 144page 144
Connecting the PSR-2100/1100 to other device	<u></u>
Basic information on MIDI	an external audio system, TPUT jacks)" on page 156 an external audio system, TPUT jacks)" on page 156
Quick solution	
Basic functions of the PSR-2100/1100 and how you can best use it	ystem Reset" on page 154 play Messages" on page 8

# What can you do with the PSR-2100/1100?



#### **LCD**

The large LCD (together with the various panel buttons) provides comprehensive and easy-to-understand control of the PSR-2100/1100's operations.

#### **MUSIC FINDER**


# Call up the perfect accompaniment style (page 33, 72)

If you know what song you want to play, but you don't know which style or voice would be right for it, let the Music Finder help you. Just select the song title, and the PSR-2100/1100 automatically calls up the most appropriate style and voice.

#### **VOICE**

# Enjoy a huge variety of realistic voices (page 25, 57)

The PSR-2100/1100 features a wealth of exceptionally authentic and dynamic voices — including piano, strings, woodwinds, and more!



#### Organ Flutes (PSR-2100 only)

# Craft your own organ voices (page 94)

This special function not only gives you a full set of rich and luscious organ sounds, it also lets you create your own original organ voices, just as on a traditional organ, by increasing and decreasing the flute footages, and adding percussive sounds.

#### **USB** terminal


# Make music with a computer — quickly and easily (page 157)

Dive in and take advantage of the wide world of computer music software. Connections and setup are exceptionally easy, and you can play back your computer recorded parts with different instrument sounds — all from a single PSR-2100/1100!

#### Vocal Harmony (PSR-2100 only)

#### Add automatic vocal backing to your singing (page 131)

The amazing Vocal Harmony feature (on the PSR-2100) automatically produces backup vocal harmonies for lead vocals that you sing into a microphone. You can even change the gender of the harmony voices — for example, letting you add female backup to your own male voice (or vice versa).




# Setting Up the PSR-2100/1100

# **Power Supply**

- **1** Make sure that the PSR-2100/1100's STANDBY/ON switch is at the STANDBY (off) position.
- ? Connect one end of the AC cable to the PA-300.



**3** Connect the PA-300's DC plug to the PSR-2100/1100's DC IN terminal on the instrument's rear panel.



Connect the other end (normal AC plug) to the nearest electrical outlet.

#### **!** WARNING

Do not attempt to use an AC adaptor other than the Yamaha PA-300 or an equivalent recommended by Yamaha. The use of an incompatible adaptor may cause irreparable damage to the PSR-2100/1100, and may even pose a serious shock hazard! ALWAYS UNPLUG THE AC ADAPTOR FROM THE AC POWER OUTLET WHEN THE PSR-2100/1100 IS NOT IN USE.

### **A** CAUTION

Never interrupt the power supply (e.g. unplug the AC adaptor) during any PSR-2100/1100 record operation! Doing so can result in a loss of data.


#### **A** CAUTION

Even when the switch is in the "STANDBY" position, electricity is still flowing to the instrument at a minimum level. When not using the PSR-2100/1100 for an extended period of time, be sure to unplug the AC power adaptor from the wall AC outlet.

### **Power-on Procedure**

When you have made all the necessary connections (page 155) between your PSR-2100/1100 and any other devices, make sure that all volume settings are turned down all the way to zero. Then turn on every device in your setup in the order of MIDI masters (senders), MIDI slaves (receivers), then the audio equipment (mixers, amplifiers, speakers, etc.). This ensures smooth MIDI operation and prevents speaker damage.

When powering down the setup, first turn down the volume for each audio device, then switch off each device in the reverse order (first audio devices, then MIDI).



Audio equipment (first mixer, then amplifier)

# Powering Up

#### **A** CAUTION

In order to avoid possible damage to the speakers or other connected electronic equipment, always switch on the power of the 2100/1100 before switching on the power of the amplified speakers or mixer and amplifier. Likewise, always switch off the power of the 2100/1100 after switching off the power of the amplified speakers or mixer and amplifier.

#### **A** CAUTION


Even when the switch is in the "STANDBY" position, electricity is still flowing to the instrument at a minimum level. When not using the PSR-2100/1100 for an extended period of time, be sure to unplug the AC power adaptor from the wall AC outlet.

#### J NOTE

Before you switch your 2100/1100 on or off, first turn down the volume of any connected audio equipment.

#### 1 Press the [STANDBY/ON] switch.

→ The main display appears in the display.




When you're ready to turn off the power, press the **[STANDBY/ON]** switch again.


- → Both the display and the drive lamp (at the bottom left of the drive) will turn off.
- **2** Adjusting the display contrast If the LCD is difficult to read, adjust the contrast with the [LCD CONTRAST] knob on the rear panel.



3 Setting the volume Use the [MASTER VOLUME] dial to adjust the volume to an appropriate level.



#### **Music Rest**



The PSR-2100/1100 is supplied with a music rest that can be attached to the instrument by inserting it into the slot at the rear of the control panel.

#### The Panel Logos

The logos printed on the PSR-2100/1100 panel indicate standards/formats it supports and special features it includes.

#### GM System Level 1

"GM System Level 1" is an addition to the MIDI standard which guarantees that any data conforming to the standard will play accurately on any GM-compatible tone generator or synthesizer from any manufacturer.

#### X XG Format

XG is a new Yamaha MIDI specification which significantly expands and improves on the "GM System Level 1" standard with greater voice handling capacity, expressive control, and effect capability while retaining full compatibility with GM. By using the PSR-2100/1100 XG voices, it is possible to record XG-compatible song files.

#### **A** XF Format

The Yamaha XF format enhances the SMF (Standard MIDI File) standard with greater functionality and open-ended expandability for the future. The PSR-2100/1100 is capable of displaying lyrics when an XF file containing lyric data is played. (SMF is the most common format used for MIDI sequence files. The PSR-2100/1100 is compatible with SMF Formats 0 and 1, and records "song" data using SMF Format 0.)

#### Vocal Harmony (PSR-2100 only)

Vocal Harmony employs state-of-the-art digital signal processing technology to automatically add appropriate vocal harmony to a lead vocal line sung by the user. Vocal Harmony can even change the character and gender of the lead voice as well as the added voices to produce a wide range of vocal harmony effects.

#### Disk Orchestra Collection

The DOC voice allocation format provides data playback compatibility with a wide range of Yamaha instruments and MIDI devices.


#### Style File Format


The Style File Format (SFF) is Yamaha's original style file format, which uses a unique conversion system to provide high-quality automatic accompaniment based on a wide range of chord types. The PSR-2100/1100 uses the SFF internally, reads optional SFF style disks, and creates SFF styles using the Style Creator feature.

#### ### USB

USB is an abbreviation for Universal Serial Bus. It is a serial interface for connecting a computer with peripheral devices. It allows "hot swapping" (connecting peripheral devices while the power to the computer is on).

# **Panel Controls and Terminals**








	WEIX	
0	[STANDBY/ON] switchP	17
Wŀ	HEEL	
	PITCH BEND P MODULATION (PSR-2100 only) P	
РΗ	IONES	
4	[PHONES] jackP.	55
ME	ETRONOME	
6	[METRONOME] button P	53
SO	DNG	
6	[EXTRA TRACKS (STYLE)] button P	82
	[TRACK 2 (L)] buttonP	
	[TRACK 1 (R)] buttonP	
	[REPEAT] buttonP	
	[REC] buttonP	
	[TOP] button	
	[START / STOP] button	
	[REW] button	
•		01
	YLE	
Ð	STYLE buttonsP	62
TR	ANSPOSE	
<b>©</b>	[ $\blacktriangleleft$ ] [ $\blacktriangleright$ ] buttons	44
ΤE	MPO	
_	[ ◀ ] [ ▶ ] buttons	

MA	ASTER VOLUME
	[MASTER VOLUME] dial
ΜL	ILTI PAD
	[1] - [4] buttons
ST	YLE CONTROL
<b>3</b>	[ACMP] buttonP. 63
Ø	[BREAK] button
Ø	[INTRO] button
<b>3</b>	MAIN [A] button
	MAIN [B] button
<b>3</b>	MAIN [C] button
49	MAIN [D] button
	[ENDING / rit.] button P. 31, 69
	[AUTO FILL IN] button
_	[SYNC.STOP] button
	[SYNC.START] button
	[START / STOP] button
•	GITAL STUDIO
33	[SOUND CREATOR] button
3	[DIGITAL RECORDING] button
€	[MIXING CONSOLE] button
ME	NU
<b>®</b>	[DEMO] button P. 55
	[HELP] button
	[FUNCTION] button

DOWED







DIS	SPLAY CONTROL	
88866666666666	[A] - [J] buttons  [DIRECT ACCESS] button  [BALANCE] button  [CHANNEL ON / OFF] button  [1▲▼] - [8▲▼] buttons  [BACK] button  [NEXT] button  VOICE PART ON / OFF [MAIN] button  VOICE PART ON / OFF [LAYER] button  VOICE PART ON / OFF [LEFT] button  [ENTER] button  [DATA ENTRY] dial  [EXIT] button  [LCD CONTRAST] knob	P. 50 P. 64, 81 P. 38 - 48 P. 43, 49 P. 43, 49 P. 59 P. 59 P. 59 P. 49 P. 49
0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	ICE EFFECT  [LEFT HOLD] button  [TOUCH] button  [SUSUTAIN] button  [HARMONY / ECHO] button  [MONO] button  [DSP] button  [VARIATION] button	P. 61 P. 60 P. 61 P. 61
® UP	VOICE buttons PPER OCTAVE [UPPER OCTAVE] button	
-		


MIC.		
<b>65</b> M	IIC. buttons (PSR-2100 only)P. 1	131
MUS	IC FINDER	
<b>6</b> 6 [N	MUSIC FINDER] button	72
ONE	TOUCH SETTING	
<b>(3)</b> [1	] - [4] buttons P.	70
REG	ISTRATION MEMORY	
_	FREEZE] buttonP.	
	I] – [8] buttons P.	
<b>(1)</b>	MEMORY] button P.	87
FLO	PPY DISK	
<b>7</b> F	loppy disk drive (3.5")I	P. 7
Microphone (PSR-2100 only)		
<b>@</b> [I	NPUT VOLUME] knobP. 1	155
<b>1</b> [N	MIC. LINE IN] jackP. 1	155
Coni	nectors	
<b>7</b> 0 [U	JSB] terminalP. 1	157
<b>₮</b> №	IIDI [OUT] [IN] terminalsP. 1	156
	FOOT PEDAL 1 (SWITCH)] jackP. 1	
	FOOT PEDAL 2] jack	
	UX OUT (LEVEL FIXED) [L] [R] jacks	
_	IC IN terminal	
w D		


# **Playing the Demos**

Reference on page 55


The PSR-2100/1100 features an extensive variety of Demo songs, that showcase its rich, authentic voices and its dynamic rhythms and styles.

What's more, there's a special selection of Demo functions. These take you through a hands-on journey of all the important features and functions of the instrument — letting you see firsthand how to effectively use the PSR-2100/1100 in your own music.





Press any of the [A] to [J] buttons or [8▼] (AUTO) button (FUNCTION page only) to select the Demo songs. For this example, press the [A] button to playback the Oboe demo.



Press the [EXIT] button to exit from the demo mode and return to the MAIN display when you've finished playing the demo songs.


When you're done with the Demos, you can get to know your PSR-2100/1100 even better with these functions:

- Song playback (page 21)
- Short demo playback of the selected voice (in the Voice Open display; page 26).

# Song Playback

Reference on page 78

Here's where all of the amazing voices, effects, rhythms, styles and other sophisticated features of the PSR-2100/1100 come together — in songs!



#### 1) NOTE

Make sure that the Language setting for the instrument (page 154) is the same as that of the file name of the song that you are playing back.

The following songs are compatible for playback on the PSR-2100/1100. Refer to pages 78, 161 for more details on the logos.



Disks bearing this logo contain song data for voices defined in the GM standard.



Disks bearing this logo contain song data using the XG format, an extension of the GM standard that provides a wider variety of voices and more comprehensive sonic control.




Disks bearing this logo contain song data for voices defined in Yamaha's DOC format.

#### - D NOTE

Songs containing a large amount of data may not be able to be read properly by the instrument, and as such you may not be able to select them. The maximum capacity is about 200–300KB, however this may differ depending on the data contents of each song.

### **Playback of Songs**

■ 1 If you want to play back a disk song, insert an appropriate disk containing song data into the disk drive.




#### **A** CAUTION

 Make sure to read the section "Using the Floppy Disk Drive (FDD) and Floppy Disks" on page 7.

# -2


#### Press the [A] button to call up the Song Open display.

If the MAIN screen is not displayed, press the [DIRECT ACCESS] button followed by the [EXIT] button.




In the example display at left, the PRESET page is selected; at right, FLOPPY DISK is selected.

Press the [A] - [C] button to select the Voice/Style/Function folder.




- Press one of the [A] to [J] buttons to select the song file.
- Press the SONG [START/STOP] button to start playback.




#### - NOTE -

- To rewind or fast forward to the playback point of the song, press the [REW] or [FF] button.
- With song data software (Standard MIDI format 0) that includes lyrics, you can view the lyrics on the display during playback. You can also view the score. See pages 83 and 86 for details
- While the song is playing, try using the Mute function to turn certain instrument channels off or on—letting you craft dynamic arrangements on the fly!
  - 1) Press the [CHANNEL ON/OFF] button.
  - 2) Press the  $[1 \triangle \nabla]$   $[8 \triangle \nabla]$  button corresponding to the channel you wish to turn on or off.



#### Song Playback


- Finally, take the producer's seat and try your hand at mixing. These Balance controls let you adjust the levels of the individual parts the song, the style, your singing (PSR-2100 only), and your playing.
  - 1) Press the **[BALANCE]** button.
  - 2) Press the  $[1 \triangle \nabla]$   $[8 \triangle \nabla]$  button corresponding to the part of which the volume you wish to adjust.



#### NOTE:

You can call up a full set of mixing controls by pressing the [MIXING CONSOLE] button (page 124).

Press the SONG [START/STOP] button to stop playback.




#### J NOTE

 The [FADE IN/OUT] button (page 68) can be used to produce smooth fadeins and fade-outs when starting and stopping the song, as well as the accompaniment.

# **Playing Voices**

Reference on page 57


The PSR-2100/1100 features a stunning variety of over 700 dynamic, rich and realistic voices. Try playing some of these voices now and hear what they can do for your music. Here, you'll learn how to select individual voices, combine two voices in a layer, and split two voices between your left and right hands.




## Playing a Voice

Press the [MAIN] button to turn the MAIN part on, then press the [F] button to call up the menu for selecting MAIN voice.


If the MAIN screen is not displayed, press the [DIRECT ACCESS] button followed by the [EXIT] button.



►2 Select a voice group.



# ►3 Select a voice.



Press the corresponding buttons to select the other pages — and discover even more voices.

#### J NOTE

- You can instantly jump back to the Main display by "double-clicking" on one of the [A] - [J] buttons.
- The voices displayed on the PSR-1100 are different from the example display at left; however, the operations are identical.

Press the [8▲] button to start the Demo for the selected voice. To stop the Demo, press this button again. There's more to the Demo features than just voices, though–for more information, see page 55.

# **4**

#### Play the voices.

Naturally, you can play the voice yourself from the keyboard, but you can also have the PSR-2100/1100 demonstrate the voice for you. Simply press the [8▲] button from the display above, and a Demo of the voice plays automatically.



## **Playing Two Voices Simultaneously**

- Press the VOICE PART ON/OFF [LAYER] button to turn the LAYER part on.
- ightharpoonup 2 Press the [G] button to select the LAYER part.
- ► 3 Select a voice group.

Here, we'll select a lush pad to fill out the sound. Call up the "CHOIR & PAD" group.

Select a voice.
For example, select "Gothic Vox."

Play the voices.

Now, you can play two different voices together in a rich sounding layer — the MAIN voice you selected in the previous section, plus the new LAYER voice you've selected here.



VOICE OPIANO & HARPSI	. C E.PIANO	ORGAN & OACCORDION	PERCUSSION
GUITAR	BASS	BRASS	OWOODWIND
STRINGS	CHOIR & PAD	SYNTH.	○ xg
O USER	ORGAN ES	-	




#### And that's just the beginning. Check out these other voice-related features:

- Create your own original voices quickly and easily by changing the settings of existing voices (page 90).
- Set up your favorite panel settings including voices, styles, and more and call them up whenever you need them (page 87).

# Playing Different Voices with the Left and Right Hands


Press the VOICE PART ON/OFF [LEFT] button to turn the LEFT part on.



Press the [H] button to select the LEFT part.

Select a voice group.


Here, we'll select the "STRINGS" group — so that you can play rich, orchestral chords with your left hand.




Select a voice, then press the [EXIT] button to return to the MAIN display.

For example, select "Symphon. Str."

Call up the SPLIT POINT display (page 141). From here, you can set the particular key on the keyboard that separates the two voices — called the Split Point. To do this, simultaneously hold down the [F] or [G] button and press the desired key on the keyboard. (For more information, see page 141.)






Play the voices.

The notes you play with your left hand sound one voice, while the notes you play with your right sound a different voice (or voices).

MAIN and LAYER voices are meant to be played with the right hand. The LEFT voice is played with the left hand.




Press the [EXIT] button to return to the MAIN display.



# **Playing Styles**


Reference on page 62

The PSR-2100/1100 has a huge variety of musical "styles" that you can call upon to back up your own performance. They give you anything from a simple, yet effective piano backing or percussion accompaniment to a full band or orchestra.




### Playing a style

► **1** Select a style group and a style.



### ►2 Turn ACMP on

The specified left-hand section of the keyboard becomes the "Auto Accompaniment" section, and chords played in this section are automatically detected and used as a basis for fully automatic accompaniment with the selected style.




#### J NOTE

 The point on the keyboard that separates the auto accompaniment section and the right-hand section of the keyboard is called the "split point." Refer to page 141 for instructions on setting the split point. **3** Turn SYNC.START on.



As soon as you play a chord with your left hand, the style starts. For this example, play a C major chord (as shown below).



- Change the tempo by using the TEMPO[◄] [▶] buttons if necessary.

  Simultaneously press the TEMPO [◄] [▶] buttons to return the tempo to its original setting. Press the [EXIT] button to leave the TEMPO display.
- Try playing other chords with your left hand.
  For information on how to enter chords, see "Chord Fingerings" on page 65.
- Press the STYLE [START/STOP] button to stop the style.

#### 1) NOTE

The Tempo can also be adjusted by using the [TAP TEMPO] button (page 54).


#### And there's much more. Check out these other style-related features:

- Easily create your own original styles (page 90).
- Set up your favorite panel settings including styles, voices, and more and call them up whenever you need them (page 87).

#### Embellish and enhance your melodies — with the automatic Harmony and Echo effects

This powerful performance feature lets you automatically add harmony notes to the melodies you play with your right hand — based on the chords you play with your left. Tremolo, Echo, and other effects are available, too.

1 Turn HARMONY/ECHO on.



- 2 Turn ACMP on (page 28).
- 3 Play a chord with your left hand and play some notes in the right-hand range of the keyboard.

The PSR-2100/1100 has various Harmony/Echo types (page 146). The Harmony/Echo type may change according to the selected MAIN voice.

• Harmony/Echo is just one of the many Voice Effects you can use. Try out some of the other effects and see how they can enhance your performance (page 60).

#### J) NOTE


For details about Harmony/ Echo types, refer to the separate Data List.

# **Style Sections**


Each style in the auto accompaniment is made up of "sections." Since each section is a rhythmic variation of the basic style, you can use them to add spice to your performance and mix up the beats — while you're playing. Intros, Endings, Main patterns, and Breaks — they're all here, giving you the dynamic elements you need to create professional-sounding arrangements.

INTRO	This is used for the beginning of the song. When the intro finishes playing, accompaniment shifts to the main section.
MAIN	This is used for playing the main part of the song. It plays an accompaniment pattern of several measures, and repeats indefinitely until another section's button is pressed.
BREAK	This lets you add dynamic variations and breaks in the rhythm of the accompaniment, to make your performance sound even more professional.
ENDING	This is used for the ending of the song. When the ending is finished, the auto accompaniment stops automatically.

- $\sim 1-3$  Use the same operations as in "Playing a style" on pages 28 and 29.
- ► 4 Press the [INTRO] button.



As soon as you play a chord with your left hand, the Intro starts. For this example, play a C major chord (as shown below).



When the playback of the intro is finished, it automatically leads into main section.

Press any of the MAIN [A] to [D] buttons or [BREAK] button as desired. (See the Accompaniment Structure on the next page.)




Press the [AUTO FILL IN] button to add a fill-in, if necessary.

Fill-in patterns play automatically between each change in the Main sections.




Press the [ENDING] button.

This switches to the ending section. When the ending is finished, the style automatically stops.



#### **■** Accompaniment Structure




#### J NOTE

- An Intro doesn't necessarily have to be at the beginning! If you want, you can play an Intro section in the middle of your performance by simply pressing the [INTRO] button at the desired point.
- Watch your timing with the Break sections. If you press a [BREAK] button too close to the end of the measure (i.e., after the final eighth note), the Break section starts playing from the next measure. This also applies to the Auto Fill-in.
- Mix up your intros and use any of the other sections to start the style, if you want.
- If you want to come back into the style right away after an Ending, simply press the [INTRO] button while the Ending section is playing.
- If you press the [BREAK] button while the ending is playing, the break will immediately start playing, continuing with the main section.

#### **Other Controls**

FADE IN/OUT	The <b>[FADE IN/OUT]</b> button can be used to produce smooth fade-ins and fade-outs (page 68)when starting and stopping the style.
TAP TEMPO  TAP TEMPO	The style can be started at any tempo you desire by "tapping" out the tempo with the <b>[TAP TEMPO]</b> button. For details, see page 54.
SYNC.STOP SYNC. STOP	When Synchro Stop is on, you can stop and start the style anytime you want by simply releasing or playing the keys (in the Auto Accompaniment section of the keyboard). This is a great way to add dramatic breaks and accents to your performance. For details, see page 68.




### **One Touch Setting**


One Touch Setting is a powerful and convenient feature that automatically calls up the most appropriate panel settings (voice number, etc.) for the currently selected style, with the touch of a single button. This is a wonderful way to instantly reconfigure all the settings on the PSR-2100/1100 to match the style you want to play.

- ► **1** Select a style (page 28).
- Press one of the [ONE TOUCH SETTING] buttons.

  Not only does this instantly call up all the settings (voices, effects, etc.) that match the current style (see page 70) it also automatically turns on ACMP and SYNC. START, so that you can immediately start playing the style.




- As soon as you play a chord with your left hand, the auto accompaniment starts.
- Play melodies with your right hand and play various chords with your left hand.



Try out other One Touch Setting setups.

You can also create your own One Touch Setting setups.


For details, refer to page 71.



• Here's another way to further automate musical changes and spice up your performance: Use the convenient OTS (One Touch Setting) Link function to automatically change One Touch Settings when you select a different Main section (page 71).

### **Music Finder**

Reference on page 72




If you want to play in a certain song but don't know which style and voice settings would be appropriate, the convenient Music Finder can help you out. Simply select the song name from the Music Finder and the PSR-2100/1100 automatically makes all appropriate panel settings to let you play in that music style!

### **Using the Music Finder**


► 1 Press the [MUSIC FINDER] button.



►2 Select a record.




Press the [BACK]/[NEXT] button to select the desired page of records. For this example, ALL is selected.



For this example, press the  $[1 \triangle \nabla]$  -  $[3 \triangle \nabla]$  buttons to select a record by song title.

Play along with the style playback.



Press the **[EXIT]** button to return to the MAIN display.

#### ♪ NOTE

You can also have the voice and other important settings change automatically with the style changes. To do this, turn on OTS LINK (page 71) and set the OTS LINK TIMING (page 141) to "REAL TIME"

### Searching the Music Finder Records

The Music Finder is also equipped with a convenient search function that lets you enter a song title or keyword — and instantly call up all the records that match your search criteria.


Press the [MUSIC FINDER] button.



Press the [I] button to call up the MUSIC FINDER SEARCH 1 display.

#### J) NOTE


The results of Search 1 and 2 appear in the correspondingly numbered SEARCH 1/ 2 displays.



Quick Guide •

**7** 

Select a record (see step #2 on page 33) and play along with the style playback.



Press the **[EXIT]** button to return to the MAIN display.

You can also create your own Music Finder setups and save them to floppy disk (pages 38 and 47). In this way, you can expand your Music Finder collection by exchanging them with other PSR-2100/1100 users. For details, refer to page 74.

#### **Saving and Recalling Music Finder Data**

To save your Music Finder data, call up the MUSIC FINDER Open/Save window from the SYSTEM RESET page (page 154) of the UTILITY display, and follow the same procedure as that in the Open/Save window for Voice (page 43, 47). To recall the saved data, execute the appropriate operation from the MUSIC FINDER's Open/Save window. Records can be replaced or added (page 74).

In the instructions above, all Music Finder data is handled together. Besides this, when you save or load style files, the Music Finder data that uses the relevant style file(s) is stored or added automatically. When you copy or move a style file on a floppy disk to the USER drive (page 45, 46), the record which was recorded when storing the relevant style is automatically added to the PSR-2100/1100.


#### -D NOTE

Music Finder data is compatible for both the PSR-2100 and the PSR-1100.

• In the example above, you specified a song title, but you can also look for relevant records by keyword or music genre — for example, Latin, 8-beat, etc. (page 73).

# Playing with the Songs

Reference on page 78



# Playing Along with the PSR-2100/1100

In this section, try using the PSR-2100/1100's song playback features to cancel or mute the right-hand melody while you play the part yourself. It's like having a very talented and versatile playing partner accompany you while you perform.

- ► 1 4 Use the same operations as in "Song Playback" on pages 21 23.
- Press the [TRACK 1] button to cancel the right hand melody part.




#### J NOTE

To cancel the left hand part, press the [TRACK 2] button.

If you want to have the notation displayed as you play, press the [C] button. If you want to see the lyrics, press the [B] button.

If the MAIN screen is not displayed, press the [DIRECT ACCESS] button followed by the [EXIT] button.




#### J NOTE

If the selected song does not contain lyric data, lyrics are not displayed.

Press the SONG [START/STOP] button and play the part.

If you want, you can adjust the tempo by pressing the TEMPO[◀] [▶] buttons.





Press the SONG [START/STOP] button to stop playback.




#### ♪ NOTE

- If you want to start the song right away without an intro, use the Sync Start function. To set Sync Start to standby, simultaneously hold down the [TOP] button and press the SONG [START/STOP] button. Song playback starts automatically the moment you start playing the melody.
- If you can hear the PSR-2100/1100 playing the melody part as well, check the channel setting for the melody part in the song data, and change the channel assigned to Track 1 (page 140). You can also change the song channel itself permanently (page 106).

## Recording

The PSR-2100/1100 lets you record, too — quickly and easily. Try out the Quick Recording feature now and capture your keyboard performance.

- $\sim 1-3$  Select a voice for recording. Use the same operations as in "Playing a Voice" on pages 25, 26.
- Press the [REC] and [TOP] buttons simultaneously to select "New Song" for recording.



► 5 Press the [REC] button.




Recording starts as soon as you start playing the keyboard.



When you've finished recording, press the [REC] button.



To hear your newly recorded performance, return the song to the beginning by using the [TOP] button and press the SONG [START/STOP] button.



 $\mathbf{9}$  Save the recorded data as required (pages 39, 47).



The recorded data will be lost if you turn off the power. To keep your important recordings, you'll need to save them to the User drive or floppy disk.

## **Basic Operations** — **Organizing Your Data**


## **Contents shown in the Main Display**

When the power is turned on, the **MAIN** Display appears, showing important and relevant operation information.

Pressing the [A]-[J] buttons when the MAIN Display appears calls up displays corresponding to each button. The displays called up by the buttons (with the exception of [B] and [C]) are called **Open/Save** displays (see following page). Pressing the [B] and [C] buttons calls up the **Lyrics** display and **Score** display respectively.

### J) NOTE

If the MAIN Display is not shown, press the [DIRECT ACCESS] button followed by the [EXIT] button.



1 Transpose (page 144)

The [TRANSPOSE] buttons allow the pitch of the keyboard and song to be shifted down or up in semitones. The transpose value by the semitone shifted is displayed here.

**2** Song (page 78)

The name of the currently selected song and other song information is displayed.

- Playback Position of Song (page 78) or Accompaniment Style (page 62)
  - The current position of the song or the accompaniment style being played is displayed.
- 4 Tempo (page 53)

When a song or a accompaniment style is playing, the tempo is displayed.

6 Chord (page 65)

When [ACMP] is on, the chord specified in the left hand section is displayed.

- 6 Accompaniment Style (page 62)
  - The name, beat, and tempo of the accompaniment style selected currently is displayed.
- 1 Intro and Ending (page 69)

The names of the intro and ending of the currently selected style are displayed.

Octave (page 61)

The [UPPER OCTAVE] buttons allow the pitch of the keyboard to be shifted down or up in octave steps. The octave value shifted is displayed here.

Split Point (page 141)

Split Points are specific positions on the keyboard that divide the keyboard into separate sections. There are two kinds of Split Points: "A", which separates the auto accompaniment from the rest of the keyboard, and "L", which divides the left-hand and right-hand sections.

® Registration Sequence (page 145)

You can save your custom panel settings as a Registration Memory preset and recall it at any time pressing the appropriate REGISTRATION MEMORY [1]-[8] button. You can also use the Registration Sequence function to program the Registration Memory presets to be selected in any specified order, and step through that order by using the [BACK]/[NEXT] buttons or the pedal. The Registration Sequence is displayed here (unless Registration Sequence mis set to OFF).

**1** Main Part (page 57)

The voice selected for the Main part is displayed.

Layer Part (page 59)

The voice selected for the Layer part is displayed.

(B) Left Part (page 60)

The voice selected for the Left part is displayed.

Multi Pad Bank (page 76)

The Multi Pads allow you to instantly play back special phrases (such as rhythmic fills and melodies) during your performance, by pressing the MULTI PAD [1]-[8] buttons. Multi Pad data is stored in banks (four pads to a bank), and both preset and user banks are available. The name of the currently selected Multi Pad bank is displayed here.

(B) Registration Memory Bank (page 88)

Registration Memory Bank (page 88)
Registration Memory presets are stored in banks, eight presets to a bank. The name of the currently selected Registration Memory bank is displayed here.

(B) Volume balance of the parts (page 64)

You can change the volume balance by pressing the [1▲▼]-[8▲▼] buttons under the LCD. The volume balance of each part is displayed.

## **Open/Save Display**

The PSR-2100/1100 utilizes a variety of data types — including voices, accompaniment styles, songs, multi pads and registration memory settings. Much of this data is already programmed and contained in the PSR-2100/1100; you can also create and edit your own data with some of the functions on the instrument.

All this data is stored in separate files — just as is done on a computer.

TRANS- O UPPER O

Twinkle Twinkle~

Lyrics BAR BEAT

Score CHORD

- HeartBeat

INTRO ENDING
4bar2 4bar

Here, we'll show you how to use the basic operations of the display controls in handling and organizing the data of the PSR-2100/1100 in files and folders.

Files can be opened, saved, named, moved, or deleted in their respective Open/Save displays. You can select these displays according to their respective file types, as well: Song, Voice, Style, etc. Moreover, you can organize your data efficiently by putting various files of the same type into a single folder.

The Open/Save displays for Song, Voice, Style, Multi Pad Bank and Registration Bank can be called up from the MAIN display (the display shown when the power is turned on) by pressing the appropriate [A] - [J] button.

### Open/Save display for Song (page 79)



handles the Song files.

### Open/Save display for Voice (page 57)



handles the Voice files.

POINT A

GrandPiano

🗱 Strings

■ GalaxyEP

Tom Flam

REGISTRATION NewBank

### Open/Save display for Multi Pads (page 76, 121)



handles the Multi Pad Bank

### J NOTE

The following Open/ Save display types are also available; however, these are selected from displays other than the MAIN display (page 154).

- SYSTEM SETUP
- **MIDI SETUP**
- **USER EFFECT**

### **MUSIC FINDER**

### Open/Save display for Style (page 62)



handles the Style files.

### Open/Save display for Registration Bank (page 88)



handles the Registration Bank files.

### NOTE

If the MAIN screen is not displayed, press the [DIRECT ACCESS] button followed by the [EXIT] button.

### Example — Open/Save display

Each **Open/Save** display consists of three kinds of drive pages: **PRESET**, **USER**, and **FLOPPY DISK**. In the examples given here, the Open/Save display for Voice is shown.

### PRESET drive


The files that are preprogrammed and installed internally to the PSR-2100/1100 are kept here. Preset files can be loaded but cannot be re-written. However, you can use a preset file as a basis for creating your own original file (which can be saved in the USER or FLOPPY DISK drive).

### **USER drive**

Files kept here are those containing your own original data, created or edited using the various functions of the PSR-2100/1100. They are stored internally to the PSR-2100/1100.

### **FLOPPY DISK drive**

You can also store your original data to floppy disk.
Commercially available disk software can also be called up here. Naturally, these files are available only when the appropriate disk is inserted in the floppy disk drive.



Changes drives among PRESET, USER and FLOPPY DISK.

Calls up the upper level directory page. In this example, the voice folder selection page can be called up.

### File


All data, both preprogrammed and your own original, are stored as "files."

### **Current Memory**

"Current Memory" is the area where the voice is called up when you select a voice. Also it is the area where you edit your voice using the SOUND CREATOR function. Your edited voice should then be saved as a file in the USER or FLOPPY DISK drive.

Recording songs (page 95) and creating accompaniment styles (page 111) are done within the current memory. Please make sure to properly save this data to the USER/FLOPPY DISK drive as a file or files. The data will be lost if you turn off the power without saving. For details, see page 42.


### **■** Files and Drives



### **■** Features and Memory Drives

Data not maintained when the power is turned off

Data maintained when the power is turned off



**A** CAUTION

The data in the USER/
FLOPPY DISK drive is maintained even when the power is turned off. However, currently active data in memory may be lost when you select another file or turn the power off. Make sure to save any necessary data in memory to the User drive or the Floppy Disk drive before selecting another file or turning the power off.

- \* The Save operation is executed from the Open/Save display.
- \*\*The corresponding Open/Save display can be called up from the [FUNCTION] → UTILITY → SYSTEM RESET display.

## **Selecting Files and Folders**


Select a file shown in the display. In this example, we'll select a voice file.

First, press the VOICE [PIANO & HARPSI.] button to call up the display containing the files.

This display ("Open/Save" display) is typical of those used to call up and store files (voice files).

The PSR-2100/1100 already contains a variety of voices in the **PRESET** section. You can store your own original voices created with the **Sound Creator** function to the **USER** or **FLOPPY DISK** section.

1 Select "PRESET," "USER," or "FLOPPY DISK" by using the [BACK][NEXT] button.




### NOTE -


Selecting a different language in the "LAN-GUAGE" display (page 52, 154) may cause the following problems.

- Some characters of the file names you entered may be garbled.
- Files may not be accessible.
   Restoring the original language solves the above problems.

Reading the files on the computer with a different language system may cause similar problems to those above.








NOTE

Double-clicking the appropriate [A] -[J] button calls up the corresponding file and returns to the MAIN display.

## 2 Use the [1▲] - [7▲] buttons to turn the pages.

When the amount of pages exceeds seven, the bottom of the display changes as shown below.



S

display shown above, the voice files are shown.)Use the [DATA ENTRY] dial and the

Select the file/folder.

Press the [A] - [J] button.

[ENTER] button. When you turn the [DATA ENTRY] dial, the highlight moves among the available files/ folders. Highlight the desired file or folder (voice files are shown in the example above) and press the [ENTER] button to call up the selected item.

There are two ways to select the file/folder:

Press the letter button corresponding to the

file/folder you wish to call up. (In the example

### - NOTE

Highlighting the desired file and double-clicking the [ENTER] button calls up the corresponding file and returns to the MAIN display.




# Press the [EXIT] button to go back to the MAIN display.

You can go back to the previous display by pressing the **[EXIT]** button.

## Exiting from small pop-up windows


You can also exit from small pop-up windows (such as in the illustration below) by pressing the **[EXIT]** button.



## File/Folder-related Operations

### Naming Files/Folders


You can assign names to files and folders. Any file/folder in the **USER** and **FLOPPY DISK** sections can be named or renamed. Execute the following steps when there is data in the User drive. If there are Preset files/folders you wish to rename, copy them beforehand (page 46) and use them as User files/folders.



To cancel, press the [8▼] (CANCEL) button.

### Moving Files/Folders

You can move files and folders as desired, for organizing your data. Any file/folder in the **USER** and **FLOPPY DISK** sections can be moved, using the cut-and-paste operation described below.



### Select the desired file/folder for moving.

Select the appropriate file/folder and press the [7▼](OK) button.

The currently selected file/folder is highlighted. To select another file/folder, press one of the [A] - [J] buttons.

Several files/folders can be selected together, even those from other pages. To release or cancel the selection, press the button of the selected file/folder again.

Press the [6▼] (ALL) button to select all the files/folders in the displayed page (USER/FLOPPY DISK). When the [6▼] (ALL) button is pressed the [6▼] button changes to "ALL OFF" button to release or cancel the selection.



Press the [7▼] (OK) button.

To stop the operation, press the [8▼] (CANCEL) button.



4 Call up the destination display.

Only the USER and FLOPPY DISK pages can be selected as the destination.





Press the  $[4\nabla]$  (PASTE) button.

The file/folder you cut is now pasted at the destination.

### J NOTE

This operation cannot be used to directly move a file/folder from one floppy disk to another. If you want to do this, cut and paste the file or folder from the first floppy disk to the USER page, then change disks and paste it to the FLOPPY DISK page.

### 1) NOTE

All files/folders in a floppy disk can be copied to another disk in one batch (page 153).

### ) NOTE

After being pasted, the files are automatically re-ordered in alphabetical order and displayed.

#### NOTE:


## About files/folders in a floppy disk

In the **FLOPPY DISK** page of the Open/Save display, only the files which can be handled in that Open/Save display will appear — even though a folder in a floppy disk can contain different kinds of files.

In the case of a folder cutand-paste operation (for floppy disk), an entire folder can be cut; however, only the specific files which can be handled in the current Open/ Save display will be pasted.

### Copying Files/Folders

You can also copy files and folders as desired, for organizing your data. Any file/folder in the **PRESET**, **USER** and **FLOPPY DISK** sections can be copied, using the copy-and-paste operation described below.




### **Deleting Files/Folders**

You can also delete files and folders as desired, for organizing your data. Any file/folder in the **USER** and **FLOPPY DISK** sections can be deleted, using the operation described below.

destination.


as the destination.



### **Saving Files**

This operation lets you save the data (such as song and voice) you created in current memory (page 40) to files. The files can be saved only to the USER and FLOPPY DISK

If the Open/Save display for the type of data you wish to save is not shown, first return to the MAIN display by pressing the [DIRECT ACCESS] button followed by the [EXIT] button. Then, press the appropriate button [A]-[J] from the MAIN display to call up the respective Open/Save display. Finally, call up the **USER** or **FLOPPY DISK** page (pages 38, 40).



NOTE

The internal memory capacity of the PSR-2100/1100 is about 580KB (PSR-2100) 260KB (PSR-1100). Memory capacity for 2DD and 2HD floppy disks is about 720KB and 1440KB, respectively. When you store data to these locations, all file types of the PSR-2100/1100 (Voice, Style, Song, Registration, etc.) are stored together.

### ♪ NOTE


The files of commercially available DOC software and Yamaha Disklavier software, and their edited files on the PSR-2100/1100, can be stored in the USER page, but cannot be copied to another floppy disk.


### ♪ NOTE

Folder directories can contain up to four levels. The maximum total number of files and folders which can be stored is 800 (PSR-2100) / 400 (PSR-1100), but this may differ depending on the length of the file names. The maximum number of files which can be stored in a folder will be 250.

## Organizing Files by Creating a New Folder

This operation lets you easily organize your various files into categories by creating a new folder for each category. Folders can only be created in the USER and FLOPPY DISK sections.






## **Displaying Upper Level pages**

Press the  $[8\nabla]$  (UP) button to call up the upper level pages. For example, you can call up the folder level pages from the file level pages.

### **Entering Characters and Changing Icons**



Change the type of character by using the [1▲] button.

If you select Japanese as the Language in the FUNCTION display (page 154), the following different types of characters and sizes can be entered:



Hiragana and kanji, marks (full size)

カナ (kana)

Katakana (normal size), marks (full size)

カナ (kana)

Katakana (half size), marks (half size)

ABC — Alphabet (capital and small letters, full size), numbers (full size), marks (full size)

NEWFolder NewFolder

at the left of the file name.

Call up the ICON SELECT display by pressing

the [1▼] button. This lets you change the icon

ABC — Alphabet (capital and small letters, half size), numbers (half size), marks (half size)

If you've selected a language other than Japanese in the FUNCTION display (page 154), the following types of characters are available:

**CASE** — Alphabet (capital letters, half size), numbers (half size), marks (half size)

case — Alphabet (lowercase letters, half size), numbers (half size), marks (half size)

### **Entering Characters**

The instructions that follow show you how to enter characters in naming your files and folders. The method is much the same as inputting names and numbers to your cell phone.

- 1 Move the cursor to the desired position by using the [DATA ENTRY] dial.
- Press the appropriate button, [2▲] [7▲] and [2▼]- [6▼], corresponding to the character you wish to enter. Several different characters are assigned to each button, and the characters change each time you press the button. To actually enter the selected character, move the cursor or press another letter-input button. If you've entered a character by mistake, move the cursor to the character letter you wish to erase and press the [7▼] (DELETE) button. If you want to delete all of the characters on the line at once, press and hold down the [7▼] (DELETE) button for a while. When the cursor appears in reverse display (highlight), only the reversed area is deleted.
- **To actually enter the new name, press the [8▲] (OK) button.** To cancel the operation, press the **[8▼] (CANCEL)** button.

### ■ Converting into Kanji (Japanese language)

This applies only if you are using the "力な漢 (kana-kan)" button (in Japanese). When the input "hiragana" characters are shown in reverse display (highlighted), press the **[ENTER]** button one or several times to convert the characters into the appropriate kanji. The reversed area can be changed by the **[DATA ENTRY]** dial. The converted area can be changed back to "hiragana" by the [7▼] (**DELETE**) button. The reversed area can be cleared at once by the **[8▼]** (**CANCEL**) button. To actually enter the change, press the **[8▲]** (**OK**) button or enter the next character. To enter the "hiragana" itself (without converting it), press the **[8▲]** (**OK**) button.

- Entering special character marks (umlaut, accent, Japanese " ∘ " and " ∘ ")

  Select a character to which a character mark is to be added and press the [6▼] button (before actual entry of the character.)
- Entering miscellaneous characters (marks)

You can call up the mark list by pressing the [6V] button, after actually entering a character by moving the cursor.



Move the cursor to the desired mark by using the [DATA ENTRY] dial, then press the  $[8\triangle]$  (OK) or [ENTER] button.

### **■** Entering numbers

First, select one of the following: "A B C" (full-size alphabet), "ABC" "CASE" (half-size capital alphabet) and "case" (half-size lowercase alphabet). Then, press and hold down the appropriate button,  $[2\Delta]$  -  $[7\Delta]$  and  $[2\nabla]$  -  $[5\nabla]$ , for a while, or press it repeatedly until the desired number is selected.

### J NOTE

The following half-size marks cannot be used in naming files and folders: \$\\/:\*?"<> |


### I NOTE

In the case of characters which are not accompanied by special character marks (with the exception of kanakan and half-size katakana), you can call up the mark list by pressing the [6▼] button after selecting a character (before actual entry of a character).

### **Changing the Icon**

You can also change the icon that appears at the left of the file name. Call up the **ICON SELECT** display by pressing the [1▼] (**ICON**) button from the character input display (page 48).

Select the desired icon by using the [A] - [J] buttons, or by using the  $[3 \blacktriangle \blacktriangledown]$  -  $[5 \blacktriangle \blacktriangledown]$  buttons, then enter the selected icon by pressing the  $[8 \blacktriangle]$  (OK) button.





## Using the [DATA ENTRY] Dial

This convenient control lets you easily select items in the display or quickly change parameter values. The actual function of the **[DATA ENTRY]** dial differs depending on the selected display.

### ■ Adjusting values

You can change parameter values by rotating the [DATA ENTRY] dial. In the example [BALANCE] display, turning the dial adjusts the volume of the part in reverse display (highlight). To adjust the volume of another part, first select the part by pressing the [▲▼] button corresponding to the part, then rotate the [DATA ENTRY] dial.






### ■ Selecting items


You can select the desired item or function in the display by rotating the [DATA ENTRY] dial. The selected item can then be called up or executed by using the [ENTER] button.

In the example **VOICE** display, you can select the desired voice file with the **[DATA ENTRY]** dial, and call up the selected item by pressing the **[ENTER]** button on the panel.






## Direct Access — Instant Selection of Displays



With the convenient Direct Access function, you can instantly call up the desired display — with just a single additional button press. Press the [DIRECT ACCESS] button and a message appears in the display prompting you to press the appropriate button. Then, simply press the button corresponding to the desired setting display to instantly call up that display. In the example below, Direct Access is used to call up the display for selecting the **Chord Fingering** (page 142).



Refer to the Direct Access Chart (page 51) for a list of the displays that can be called up with the Direct Access function.

### NOTE :


Here's a convenient way to return to the MAIN display from any other display: Simply press the [DIRECT ACCESS] button, then the [EXIT] button.


### **Direct Access Chart**


Oncombine (DIDECT ACCES)	N. b. attan. J. b. attan. Catan. b. alan.	1	Common dia a LCD dia da	and frantis	
SONG Operation: [DIRECT ACCESS	S] button + button listed below [TRACK1]		Corresponding LCD display	TRACK1 CHANNEL selection	See pages 140
	[TRACK1]	†	CONC CETTING	TRACKI CHANNEL selection	140
	[EXTRA TRACKS]	FUNCTION	SONG SETTING	•	140
	[REPEAT]				
	[METRONOME]		UTILITY	METRONOME settings	151
	[REC]		-		
	[START/STOP]			<u> </u>	
	[REW]		_		
	[FF]				
STYLE	[POP & ROCK]				
	[SWING & JAZZ] [BALLROOM]	4			
	[MARCH & WALTZ]	-	STYLE SETTING/SPLIT POINT	SPLIT POINT (ACMP) setting	
	[BALLAD]	FUNCTION			141
	[DANCE]	7			
	[LATIN]				
	[USER]				
TRANSPOSE	[4]	MIXING CONSOLE	CONTROLLER TUNE	TRANSPOSE assignment TRANSPOSE settings	144 126
TEMPO	[ <b>▶</b> ] [ <b>∢</b> ]	MIXING CONSOLE		-	
TEIVIII O	[ <b>&gt;</b> ]	┪	MIDI	MIDI CLOCK setting	148
[TAP TEMPO]	1.5	FUNCTION	UTILITY	TAP settings	152
[FADE IN/OUT]	T		OTILITY	FADE IN/OUT settings	151
MULTI PAD	[1]				
	[2]	MULTI PAD	MULTI PAD EDIT		77
	[3]	-			
	[STOP]	DIGITAL RECORDING	MULTI PAD CREATOR	REPEAT/CHORD MATCH settings	122
STYLE CONTROL	[ACMP]	FUNCTION	CHORD FINGERING	FINGERING TYPE selection	141
	[BREAK]			VOICE settings	
	[INTRO]	4	VOLUME/VOICE	PANPOT settings	125
	MAIN [A] MAIN [B]	4		VOLUME settings HARMONIC CONTENT settings	
	MAIN [C]	MIXING CONSOLE (STYLE PART)	FILTER	BRIGHTNESS settings	126
	MAIN [D]	1		REVERB settings	
	[ENDING/rit.]		EFFECT	CHORUS settings	127
	[AUTO FILL IN]			DSP settings	
	[OTS LINK] [SYNC. STOP]	FUNCTION	STYLE SETTING/SPLIT POINT	SYNC. STOP WINDOW setting	141
	[SYNC. STOP]		_		
	[START/STOP]				
DIGITAL STUDIO	[SOUND CREATOR]	FUNCTION	MAGTER TUNE (OCAL E TUNE	MASTER TUNING setting	400
	[DIGITAL RECORDING]	FUNCTION	MASTER TUNE/SCALE TUNE	SCALE TUNING setting	138
	[MIXING CONSOLE] PSR-210		EQ settings		130
MENUL	PSR-110		-	- LANCHACE selection	454
MENU	[DEMO] [HELP]	FUNCTION	UTILITY	LANGUAGE selection LCD BRIGHTNESS settings	154 152
	[FUNCTION]	- Toke now	MIDI	MIDI settings	148
[DIRECT ACCESS]	[ [ containing	Exit from the Direct Access mode			
[BALANCE]		MIXING CONSOLE (SONG PART)	VOLUME/VOICE	VOLUME settings	125
[CHANNEL ON/OFF]		MIXING CONSOLE (SONG PART)		VOICE settings	123
[NEXT]				_	
[BACK] VOICE PART	[MAIN]			_	
VOIGETAICE	[LAYER]	MIXING CONSOLE	TUNE	OCTAVE settings	126
	[LEFT]	7			
[MUSIC FINDER]		MUSIC FINDER	MUSIC FINDER SEARCH1 (Search	hing the records)	34
[EXIT] [ENTER]		Return to the MAIN display			
VOICE EFFECT	[LEFT HOLD]		STYLE SETTING/SPLIT POINT	SPLIT POINT (LEFT) setting	141
10.02 2. 1 20 .	[TOUCH]	FUNCTION	CONTROLLER	KEYBOARD TOUCH assignment	144
	[SUSTAIN]	MIXING CONSOLE	EFFECT	REVERB settings	127
	[HARMONY/ECHO]	FUNCTION	HARMONY/ECHO		146
	[MONO]	<b>_</b>	TUNE	PORTAMENTO TIME settings	126
	[DSP]	MIXING CONSOLE	EFFECT	DSP settings	127
VOICE	[VARIATION] [PIANO & HARPSI]			EFFECT TYPE selection	
VOIGE	[E.PIANO]	1			
	[ORGAN & ACCORDION]	1			
	[PERCUSSION]				
	[GUITAR]	1			
	[BASS]	FUNCTION	VOICE SET settings		
					4.40
	[BRASS] [WOODWIND]	<sup>1</sup> • · · · · · · · · · · · · · · · · · ·	VOICE SET Settings		146
	[WOODWIND] [STRINGS]		VOICE SET Settings		146
	[WOODWIND] [STRINGS] [CHOIR&PAD]		VOICE SET Settings		146
	[WOODWIND] [STRINGS] [CHOIR&PAD] [SYNTH.]		VOICE SET Settings		146
	[WOODWIND] [STRINGS] [CHOIR&PAD] [SYNTH.] [XG]		VOICE SET Settings		146
	[WOODWIND] [STRINGS] [CHOIR&PAD] [SYNTH.] [XG] [USER]	- - - -			
UPPER OCTAVE	[WOODWIND] [STRINGS] [CHOIREPAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only	- - - -	EQ settings	_	146
UPPER OCTAVE	[WOODWIND] [STRINGS] [CHOIR&PAD] [SYNTH.] [XG] [USER]	- - - -	EQ settings	- -	
UPPER OCTAVE MIC. (PSR-2100 only)	[WOODWIND] [STRINGS] [CHOIREPAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only) [	- - - -	EQ settings	he VOCAL HARMONY parameters)	
	[WOODWIND] [STRINGS] [CHOIRRPAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only  [◀] [▶] [VH TYPE SELECT] [MIC. SETTING]	) MIXING CONSOLE  VOCAL HARMONY	EQ settings	he VOCAL HARMONY parameters) MIC. EFFECT TYPE selection	130
	[WOODWIND] [STRINGS] [CHOIR&PAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only [I◀] [I▼] [VH TYPE SELECT] [MIC. SETTING] [VOCAL HARMONY]	) MIXING CONSOLE	EQ settings	He VOCAL HARMONY parameters)  MIC. EFFECT TYPE selection  MIC. REVERB setting	130
	[WOODWIND] [STRINGS] [CHOIREPAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only  [◀]  [IN] [VH TYPE SELECT] [MIC. SETTING] [VOCAL HARMONY] [EFFECT]	WIXING CONSOLE  VOCAL HARMONY  MIXING CONSOLE	EQ settings  VOCAL HARMONY EDIT (Editing to	he VOCAL HARMONY parameters) MIC. EFFECT TYPE selection	130
MIC. (PSR-2100 only)	[WOODWIND] [STRINGS] [CHOIREPAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only  [ ◀] [I▶] [VHTYPE SELECT] [MIC. SETTING] [VOCAL HARMONY] [EFFECT] [TALK]	) MIXING CONSOLE  VOCAL HARMONY	EQ settings	He VOCAL HARMONY parameters)  MIC. EFFECT TYPE selection  MIC. REVERB setting	130
	[WOODWIND] [STRINGS] [CHOIREPAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only  [◀] [I♠] [VH TYPE SELECT] [MIC. SETTING] [VOCAL HARMONY] [EFFECT] [TALK] [1] [2]	WIXING CONSOLE  VOCAL HARMONY  MIXING CONSOLE	EQ settings  VOCAL HARMONY EDIT (Editing to	MIC. EFFECT TYPE selection MIC. REVERB setting MIC. DSP setting	130
MIC. (PSR-2100 only)	[WOODWIND] [STRINGS] [CHOIREPAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only  [▼]  [VHTYPE SELECT] [MIC. SETTING] [VOCAL HARMONY] [EFFECT] [TALK] [1] [2] [3]	WIXING CONSOLE  VOCAL HARMONY  MIXING CONSOLE	EQ settings  VOCAL HARMONY EDIT (Editing the setting that the setting the setting that the setting that the setting that the setting the setting that the setting the setting that the setting the setting that the setting that the setting that the setting t	He VOCAL HARMONY parameters)  MIC. EFFECT TYPE selection  MIC. REVERB setting  MIC. DSP setting	130
MIC. (PSR-2100 only)  ONE TOUCH SETTING	[WOODWIND] [STRINGS] [CHOIREPAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only [I ◀] [I ▼] [VH TYPE SELECT] [MIC. SETTING] [VOCAL HARMONY] [EFFECT] [TALK] [1] [2] [3] [4]	) MIXING CONSOLE  VOCAL HARMONY  MIXING CONSOLE  MIC. SETTING	EQ settings  VOCAL HARMONY EDIT (Editing the EFFECT  TALK SETTING	MIC. EFFECT TYPE selection MIC. REVERB setting MIC. DSP setting	130 131 127 135
MIC. (PSR-2100 only)	[WOODWIND] [STRINGS] [CHOIREPAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only  [ ◀] [ NH TYPE SELECT] [MIC. SETTING] [VOCAL HARMONY] [EFFECT] [TALK] [1] [2] [3] [4] [FREEZE]	WIXING CONSOLE  VOCAL HARMONY  MIXING CONSOLE	EQ settings  VOCAL HARMONY EDIT (Editing the setting that the setting the setting that the setting that the setting that the setting the setting that the setting the setting that the setting the setting that the setting that the setting that the setting t	He VOCAL HARMONY parameters)  MIC. EFFECT TYPE selection  MIC. REVERB setting  MIC. DSP setting	130
MIC. (PSR-2100 only)  ONE TOUCH SETTING	[WOODWIND] [STRINGS] [CHOIREPAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only [	) MIXING CONSOLE  VOCAL HARMONY  MIXING CONSOLE  MIC. SETTING	EQ settings  VOCAL HARMONY EDIT (Editing the EFFECT  TALK SETTING	He VOCAL HARMONY parameters)  MIC. EFFECT TYPE selection  MIC. REVERB setting  MIC. DSP setting	130 131 127 135
MIC. (PSR-2100 only)  ONE TOUCH SETTING	[WOODWIND] [STRINGS] [CHOIREPAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only [◀] [I♠] [VH TYPE SELECT] [MIC. SETTING] [VOCAL HARMONY] [EFFECT] [TALK] [1] [2] [3] [4] [FREEZE] [1]	) MIXING CONSOLE  VOCAL HARMONY  MIXING CONSOLE  MIC. SETTING	EQ settings  VOCAL HARMONY EDIT (Editing the EFFECT  TALK SETTING	He VOCAL HARMONY parameters)  MIC. EFFECT TYPE selection  MIC. REVERB setting  MIC. DSP setting	130 131 127 135
MIC. (PSR-2100 only)  ONE TOUCH SETTING	[WOODWIND] [STRINGS] [CHOIREPAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only  [ ◀] [ ▶] [VH TYPE SELECT] [MIC. SETTING] [VOCAL HARMONY] [EFFECT] [TALK] [1] [2] [3] [4] [FREEZE] [1] [2] [3]	) MIXING CONSOLE  VOCAL HARMONY  MIXING CONSOLE  MIC. SETTING	EQ settings  VOCAL HARMONY EDIT (Editing the EFFECT  TALK SETTING  FREEZE	MIC. EFFECT TYPE selection MIC. REVERB setting MIC. DSP setting	130 131 127 135
MIC. (PSR-2100 only)  ONE TOUCH SETTING	[WOODWIND] [STRINGS] [CHOIREPAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only  [	) MIXING CONSOLE  VOCAL HARMONY  MIXING CONSOLE  MIC. SETTING	EQ settings  VOCAL HARMONY EDIT (Editing the EFFECT  TALK SETTING	MIC. EFFECT TYPE selection MIC. REVERB setting MIC. DSP setting	130 131 127 135
MIC. (PSR-2100 only)  ONE TOUCH SETTING	[WOODWIND] [STRINGS] [CHOIREPAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only [■] [VH TYPE SELECT] [MIC. SETTING] [VOCAL HARMONY] [EFFECT] [TALK] [1] [2] [3] [4] [FREEZE] [1] [2] [3] [4] [FREEZE] [1] [2]	) MIXING CONSOLE  VOCAL HARMONY  MIXING CONSOLE  MIC. SETTING	EQ settings  VOCAL HARMONY EDIT (Editing the EFFECT  TALK SETTING  FREEZE	MIC. EFFECT TYPE selection MIC. REVERB setting MIC. DSP setting	130 131 127 135
MIC. (PSR-2100 only)  ONE TOUCH SETTING	[WOODWIND] [STRINGS] [CHOIREPAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only  [	) MIXING CONSOLE  VOCAL HARMONY  MIXING CONSOLE  MIC. SETTING	EQ settings  VOCAL HARMONY EDIT (Editing the EFFECT  TALK SETTING  FREEZE	MIC. EFFECT TYPE selection MIC. REVERB setting MIC. DSP setting	130 131 127 135
MIC. (PSR-2100 only)  ONE TOUCH SETTING	[WOODWIND] [STRINGS] [CHOIREPAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only [■] [VH TYPE SELECT] [MIC. SETTING] [VOCAL HARMONY] [EFFECT] [TALK] [1] [2] [3] [4] [FREEZE] [1] [2] [3] [4] [5] [6] [7]	) MIXING CONSOLE  VOCAL HARMONY  MIXING CONSOLE  MIC. SETTING	EQ settings  VOCAL HARMONY EDIT (Editing the left)  EFFECT  TALK SETTING  FREEZE  REGISTRATION EDIT (Editing the left)	MIC. EFFECT TYPE selection MIC. REVERB setting MIC. DSP setting	130 131 127 135
MIC. (PSR-2100 only)  ONE TOUCH SETTING  REGISTRATION MEMORY	[WOODWIND] [STRINGS] [CHOIREPAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only  [	MIXING CONSOLE  VOCAL HARMONY  MIXING CONSOLE  MIC. SETTING  FUNCTION  REGISTRATION BANK	EQ settings  VOCAL HARMONY EDIT (Editing the left)  EFFECT  TALK SETTING  FREEZE  REGISTRATION EDIT (Editing the left)	MIC. EFFECT TYPE selection MIC. REVERB setting MIC. DSP setting	130 131 127 135
MIC. (PSR-2100 only)  ONE TOUCH SETTING	[WOODWIND] [STRINGS] [CHOIR&PAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only  [◀]  [VH TYPE SELECT] [MIC. SETTING] [VOCAL HARMONY] [EFFECT] [TALK] [1] [2] [3] [4] [FREEZE] [1] [2] [3] [4] [FREEZE] [1] [6] [7] [8] [MEMORY] [PEDAL1]	) MIXING CONSOLE  VOCAL HARMONY  MIXING CONSOLE  MIC. SETTING	EQ settings  VOCAL HARMONY EDIT (Editing the left)  EFFECT  TALK SETTING  FREEZE  REGISTRATION EDIT (Editing the left)	MIC. EFFECT TYPE selection MIC. REVERB setting MIC. DSP setting MIC. DSP setting  RAGISTRATION)  ating the REGISTRATION SEQUENCE) PEDAL1 function assignment	130 131 127 135 145
MIC. (PSR-2100 only)  ONE TOUCH SETTING  REGISTRATION MEMORY	[WOODWIND] [STRINGS] [CHOIREPAD] [SYNTH.] [XG] [USER] [ORGAN FLUTES] (PSR-2100 only  [	MIXING CONSOLE  VOCAL HARMONY  MIXING CONSOLE  MIC. SETTING  FUNCTION  REGISTRATION BANK	EQ settings  VOCAL HARMONY EDIT (Editing the set of the	MIC. EFFECT TYPE selection MIC. REVERB setting MIC. DSP setting	130 131 127 135 145 88

## Help Messages

The Help messages give you explanations and descriptions of all the main functions and features of the PSR-2100/1100.







### **NOTE**

Help messages can be displayed in any one of the following languages: ENGLISH JAPANESE GERMAN ERENCH

FRENCH SPANISH ITALIAN

### J NOTE


The language can also be selected in the FUNCTION "LANGUAGE" (page 154) display.


### 1) NOTE

Selecting a different language here may cause the following problems.

- Some characters of the file names you entered may be garbled.
- Files may not be accessible.
   Restoring the original language solves the above problems.
   Reading the files on the computer with a different language system may cause similar problems to those above.








## **Using the Metronome**

The **metronome** provides a click sound, giving you an accurate tempo guide when you practice, or letting you hear and check how a specific tempo sounds.




The **metronome** starts by pressing the **[METRONOME]** button. Adjust the tempo by using the **TEMPO[◄]** [▶] buttons (see below). To stop the **metronome**, press the **[METRONOME]** button again.


### J) NOTE

The sound, volume level, and the beat (time signature) of the metronome can all be changed (page 151).

## **Adjusting the Tempo**

This section shows you to adjust the playback tempo — which not only affects the metronome, but also the playback of a song or an accompaniment style.





Adjust the tempo by using either the TEMPO [◄] [▶] buttons or the [DATA ENTRY] dial.

The number in the display indicates how many quarter-note beats there are in one minute. The range is between 5 and 500. The higher the value, the faster the tempo.

When you change the tempo, both tempos of the


When you change the tempo, both tempos of the current song and style will be changed to the same tempo. To restore their respective default (initial) tempo settings, press both the **TEMPO** [◄] [►] buttons simultaneously. Also refer to the "Tempo Indications — MAIN display" (page 54) for more about tempo.

### J NOTE

Songs and accompaniment styles have been given default (initial) tempo settings, designed to best suit the song/style.


### **Tap Tempo**

This useful feature lets you tap out the tempo for a song or an accompaniment style. Simply tap the **[TAP TEMPO]** button at the desired speed, and the tempo of the song or the accompaniment style changes to match your tapping.



### ■ Tempo Indications — MAIN Display

There are three different tempo indications in the Main display, as shown below.



### - NOTE


Hitting the **[TAP TEMPO]** button produces a tapping sound. You can change this sound, if desired (page 152).


#### 1) NOTE


You can also use Tap Tempo to automatically start the song or accompaniment style at the desired tempo. While both the song and accompaniment style are stopped, tap the [TAP TEMPO] button several times, and the selected accompaniment style starts automatically at the tempo you tapped. While a song is set to Sync. Start stand-by (page 63, 79), tapping the [TAP TEMPO] button starts the song playback in the same manner. For songs and styles in 2/4 and 4/4 time, tap four times; for 3/4 time, tap three times; for 5/4 time, tap five times.

## **Playing the Demos**

The PSR-2100/1100 is an extraordinarily versatile and sophisticated instrument, featuring a wide variety of dynamic voices and rhythms, plus a wealth of advanced functions. Three different types of Demo songs have been specially prepared showcasing the stunning sound and features of the PSR-2100/1100.








For the Function demos, an introduction screen appears in the display and the Demo starts playing.


This example shows the Sound System in the FUNCTION demo.

Sound System

M



Select the desired word or item by using the [DATAENTRY] dial, then press the [ENTER] button or number buttons ([1 $\nabla$ ], [2 $\nabla$ ], etc.) to call it up.




### J NOTE

Use the [BACK][NEXT] buttons in the introduction screen to call up the previous or next page.


### 1) NOTE

Press the SONG [START/ STOP] button to stop the Demo song. To start the Demo again from the point at which it was stopped, press the SONG [START/ STOP] button again. Rewind and fast-forward can also be used with the Demo songs (page 81).




## **Voices**

The PSR-2100/1100 gives you an enormous selection of authentic voices, including various keyboard instruments, strings and brass — and many, many more.



## Selecting a Voice



2 Select the desired voice group.

VOICE

PIANO & HARPSI. O E.PIANO ACCORDION PERCUSSION


GUITAR BASS BRASS WOODWIND

STRINGS CHOIR & PAD SYNTH. XG

USER ORGAN FLUTES

**NOTE** 

When you select a voice group, the last selected voice will automatically be selected.



### **Voice Characteristics**

The voice type and its defining characteristics are indicated above the voice name.

### Live! (PSR-2100 only)

These acoustic instrument sounds were sampled in stereo, to produce a truly authentic, rich sound — full of atmosphere and ambience.

### Cool

These voices capture the dynamic textures and subtle nuances of electric instruments — thanks to a huge amount of memory and some very sophisticated programming.

### Sweet

These acoustic instrument sounds also benefit from Yamaha's sophisticated technology — and feature a sound so finely detailed and natural, you'll swear you're playing the real thing!

### Drum

Various drum and percussion sounds are assigned to individual keys, letting you play the sounds from the keyboard.

### **SFX**

Various special effect sounds are assigned to individual keys, letting you play the sounds from the keyboard.

### Organ Flutes! (PSR-2100 only)


This authentic organ voice lets you use the Sound Creator to adjust the various footages and craft your own original organ sounds.

### **Keyboard Percussion**

When one of the drum of SFX kits is selected in the PERCUSSION voice group, various drum, percussion, and special effect sounds are assigned to individual keys, letting you play the sounds from the keyboard. The various drums and percussion instruments of the Standard Kit are indicated by symbols below the assigned keys. Keep in mind that even though different kits feature different sounds, some same-named sounds in different kits are identical. Refer to the separate Data List (Drum/key Assignment List) for a listing of the sounds in each drum/SFX kit.

## Layer/Left — Playing Several Sounds Simultaneously


The PSR-2100/1100 lets you set three voices for simultaneous play: MAIN, LAYER, and LEFT. By effectively combining these three, you can create richly textured, multi-instrument setups for your performance.




LAYER part

Playing a layer of two voices


Playing two voices separately — on the left and right sections of the keyboard




Playing three different voices — one on the left section of the keyboard, plus a layer of two on the right



### **Layer** — **Layering Two Different Voices**




## Left — Setting Separate Voices for the Left and Right Sections of the Keyboard



## **Applying Voice Effects**

This section of the panel lets you add a variety of effects to the voices you play on the keyboard.



Press one of the effect buttons to turn the corresponding effects on. Press it again to turn the effect off. For explanations on each of the effects, see below.

### ■ TOUCH

This button turns the touch response of the keyboard on or off. When this is set to off, the same volume is produced no matter how strongly or softly you play the keyboard.

### ■ SUSTAIN

When this Sustain feature is on, all notes played on the keyboard (MAIN/LAYER parts only) have a longer sustain. You can also set the Sustain depth (page 93).

### **■** DSP

The PSR-2100/1100 features a variety of dynamic built-in digital effects, letting you process the sound in various ways. You can use DSP to enhance the voices in subtle ways — such as by applying chorus to add animation and depth, or using a symphonic effect to give the sound warmth and richness. DSP also has effects such as distortion that can completely change the character of the sound. DSP is set for the currently selected part (MAIN/LAYER/LEFT).

### ♪ NOTE

The **DSP** and **VARIATION** effect types and the their depth can be selected and adjusted in the **MIXING CONSOLE** display (page 127).

### **■ VARIATION**

This control changes the Variation effect settings, letting you alter some aspect of the effect, depending on the selected type. For example, when the Rotary Speaker effect is selected (page 127), this lets you switch the rotor speed between slow and fast.

### **■** HARMONY/ECHO

This control adds Harmony or Echo effects to the voices played on the right hand section of the keyboard (page 146).

### **■** MONO

This control determines whether the voice is played monophonically (only one note at a time) or polyphonically for each part (MAIN/LAYER/LEFT). This is set to MONO when the lamp is lit, and set to polyphonic when the lamp is off. When set to MONO, only the last note played will sound. This lets you play wind instrument voices more realistically. Depending on the selected voice, the MONO setting also lets you effectively use the Portamento effect, when playing in legato.

### **■ LEFT HOLD**

This function causes the left part voice to be held even when the keys are released — the same effect as when the sustain pedal is pressed. This function is especially effective when used with the auto accompaniment. For example, if you play and release a chord in the auto accompaniment section of the keyboard (with the left part on and the Left voice set to Strings), the strings part sustains, adding a natural richness to the overall accompaniment sound.

### **NOTE**

The Portamento effect creates a smooth pitch glide between successively played notes.

#### QE HINT

You can add special emphasis to melody lines you play over chords by using the Layer function with a monophonic voice. Set the Main voice to play polyphonically and set the Layer voice to play monophonically (MONO). In this case, the melody you play — including the top notes of any chords — sounds monophonically. Try this using the following voices.

**MAIN voice**: Brass Section (polyphonic) + **LAYER voice**: Sweet Trump (monophonic)

## PITCH BEND Wheel & MODULATION Wheel

Use the PSR-2100/1100 PITCH BEND wheel to bend notes up (roll the wheel away from you) or down (roll the wheel toward you) while playing the keyboard. The PITCH BEND wheel is self-centering and will automatically return to normal pitch when released.


The Modulation function applies a vibrato effect to notes played on the keyboard (PSR-2100). Moving the MODULATION wheel all the way towards yourself minimizes the depth of the effect, while rotating it away from yourself increases it.





### ♪ NOTE

The maximum pitch bend range can be changed (page 126).





### - NOTE

In order to avoid accidentally applying modulation set the depth to its minimum setting.

## **Adjusting the Octave setting**

The [UPPER OCTAVE] button allows the MAIN and LAYER parts to be simultaneously transposed up or down by one octave.




### J NOTE


More detailed octave-related settings for each part can be made by using the Mixing Console function (page 126).


## Styles

The PSR-2100/1100 features styles (accompaniment patterns) in a variety of different musical genres including pops, jazz, Latin and dance. To use it, all you have to do is play the chords with your left hand as you perform and the selected Accompaniment Style (style) matching your music will automatically play along, instantly following the chords you play. Try selecting some of the different styles (refer to separate Data List (Style List)) and play them.




## Playing a style





### J NOTE


For a list of the available accompaniment styles, refer to the separate Data List.



### ♪ NOTE

You can set the key range for auto accompaniment (page 141).





### NOTE

### Sync. Start


Enabling this lets you start the style simply by playing the keyboard.



As soon as you play a chord with the auto accompaniment section, the style starts. For details about chord fingerings, refer to page 65.


The Tempo can be adjusted using the TEMPO [◄][▶] or [TAP TEMPO] button.


If you tap the [TAP TEMPO] button, the tempo will adjust to the same speed that you tapped.



### NOTE

- You can begin the rhythm channels (tracks) of the Style by pressing the [START/STOP] button.
- The rhythm channels of the style can also be started by tapping the [TAP TEMPO] button.
   With the style stopped, tap the [TAP TEMPO] button three, four or five times (three for 3/4 time, four for 2/4 or 4/4 time, five for 5/4 time).





### - T) NOTE :

When you simultaneously play back accompaniment styles with a song, the accompaniment parts recorded to the song (channels 9 - 16) are temporarily replaced by the selected accompaniment style — letting you try out and use different accompaniment with the song (page 80).

### **Accompaniment Style Characteristics**

The defining characteristics of some of the accompaniment styles are indicated above the relevant style names in the Open/Save display.

### Session

These styles provide even greater realism and authentic backing by mixing in original chord types and changes, as well as special riffs with chord changes, with the Main sections. These have been programmed to add "spice" and a professional touch to your performances of certain songs and in certain genres. As a result, the styles may not necessarily be appropriate — or even harmonically correct — for all songs and for all chord playing. In some cases for example, playing a simple major triad may result in a seventh chord, or playing an on-bass chord may result in incorrect or unexpected accompaniment.


## Playing a Style's Rhythm Channels only

1 Select a style (page 62).

### -D NOTE

The Rhythm channels are part of the styles. Each style has different rhythm patterns.

## ₹



#### - t Note

You can also start the rhythm simply by playing a key on the keyboard, if Sync Start is enabled (turn on the [SYNC.START] button).



**?** Play along with the rhythm playback.

The Tempo can be adjusted using the **TEMPO** [◀][▶] or [**TAP TEMPO**] buttons. If you tap the [**TAP TEMPO**] button, the tempo will adjust to the same speed that you tapped.








Press the STYLE [START/STOP] button again to stop the rhythm playback.

## Adjusting the Volume Balance/Channel Muting

press the appropriate channel button again.



## **Chord Fingerings**

The style playback can be controlled by the chords you play in the keys to the left of the split point. There are 7 types of fingerings as described below. Go to the CHORD FINGERING page (page 142), and select the Chord Fingerings. The page shows how to play chords with your left hand.

### **SINGLE FINGER**

Single Finger accompaniment makes it simple to produce beautifully orchestrated accompaniment using major, seventh, minor and minor-seventh chords by pressing a minimum number of keys on the auto accompaniment section of the keyboard. The abbreviated chord fingerings described below are used.


For a major chord, press the root key only.

C



**For a minor chord,** simultaneously press the root key and a black key to its left.

Cm



**For a seventh chord,** simultaneously press the root key and a white key to its left.

**C7** 



**For a minor-seventh chord,** simultaneously press the root key and both a white and black key to its left.

Cm7



### **MULTI FINGER**

The Multi Finger mode automatically detects Single Finger or Fingered chord fingerings, so you can use either type of fingering without having to switch fingering modes. If you want to play minor, seventh, or minor-seventh chords using the SINGLE FINGER operation in the MULTI FINGER Mode, always press the closest white/black key(s) to the root of the chord.

### **FINGERED**

This mode lets you produce accompaniment by playing full chords on the auto accompaniment section of the keyboard. The Fingered mode recognizes the various chord types listed on the next page.

### **FINGERED ON BASS**

This mode accepts the same fingerings as the FINGERED mode, but the lowest note played in the auto accompaniment section of the keyboard is used as the bass note, allowing you to play "on bass" chords. For example, to indicate a C-on-E chord, play a C major chord with E as the lowest note (E, G, C).

### **FULL KEYBOARD**

This method detects chords in the entire key range. Chords are detected in a way similar to Fingered, even if you split the notes between your left and right hands — for example, playing a bass note with your left hand and a chord with your right, or by playing a chord with your left hand and a melody note with your right.

### AI FINGERED

This mode is basically the same as FINGERED, with the exception that less than three notes can be played to indicate the chords (based on the previously played chord, etc.).

### J NOTE

Chord detection in the AI Full Keyboard mode occurs at approximately 8th-note intervals. Extremely short chords — less than an 8th note in length — may not be detected.

### ♪ NOTE

In Full Keyboard mode, chords are detected based on the lowest and second lowest notes you play. If the two lowest notes fall within a single octave, those two notes determine the chord. If the lowest note and the second lowest note are separated by more than one octave, the lowest note becomes the bass and the chord is determined from the second lowest note and the other notes played in the same octave.

### **」NOTE**

| AI

Artificial Intelligence

### AI FULL KEYBOARD

When this advanced auto accompaniment mode is engaged, the PSR-2100/1100 will automatically create appropriate accompaniment while you play just about anything, anywhere on the keyboard using both hands. You don't have to worry about specifying the accompaniment chords. Although the AI Full Keyboard mode is designed to work with many songs, some arrangements may not be suitable for use with this feature.

This mode is similar to FULL KEYBOARD, with the exception that less than three notes can be played to indicate the chords (based on the previously played chord, etc.). 9<sup>th</sup> and 11<sup>th</sup> chords cannot be played.

### Chord Types Recognized in the Fingered Mode (Example for "C" chords)

С	C9	C6	C6 <sup>9</sup>	CM7	CM7 <sup>9</sup>	CM7 <sup>#11</sup>	C <sup>}</sup> 5	CM7 <sup> ,5</sup>
		• • •						
Csus4	Caug	CM7aug	Cm	Cm9	Cm6	Cm7	Cm7 <sup>9</sup>	Cm7 <sup>11</sup>
		• 9				• •	• • •	
	•	1	1 -				and the second s	and the second s
CmM7	CmM7 <sup>9</sup>	Cm7 <sup>♭</sup> 5	CmM7 <sup>♭5</sup>	Cdim	Cdim7	C7	C7 <sup>♭9</sup>	C7 <sup>,13</sup>
CMM7	• • •	Cm7 <sup>5</sup> 5			Cdim7	C7	C7 <sup>6</sup> 9	C7 <sup>5</sup> 13

Chord Name [Abbreviation]	Normal Voicing	Display for root "C"
Major [M]	1 - 3 - 5	С
Ninth [9]	1 - 2 - 3 - 5	C9
Sixth [6]	1 - (3) - 5 - 6	C6
Sixth ninth [6 <sup>9</sup> ]	1 - 2 - 3 - (5) - 6 or 3 - 6 - 2*	C6 <sup>9</sup>
Major seventh [M7]	1 - 3 - (5) - 7	CM7
Major seventh ninth [M7 <sup>9</sup> ]	1 - 2 - 3 - (5)j - 7	CM7 <sup>9</sup>
Major seventh add sharp eleventh [M7 <sup>‡11</sup> ]	1 - (2) - 3 - #4 - 5 - 7 or 1 - 2 - 3 - #4 - (5) - 7	CM7 <sup>#11</sup>
Flatted fifth [ <sup>1</sup> 5]	1 - 3 - 15	C <sup>↓</sup> 5
Major seventh flatted fifth [M7 <sup>↓5</sup> ]	1 - 3 - 15 - 7	CM7 <sup>↓5</sup>
Suspended fourth [sus4]	1 - 4 - 5	Csus4
Augmented [aug]	1 - 3 - ‡5	Caug
Major seventh augmented [M7aug]	1 - (3) - #5 - 7	CM7aug
Minor [m]	1 - 13 - 5	Cm
Minor ninth [m9]	1 - 2 - 13 - 5	Cm9
Minor sixth [m6]	1 - 3 - 5 - 6	Cm6
Minor seventh [m7]	1 - 3 - (5) - 7	Cm7
Minor seventh ninth [m7 <sup>9</sup> ]	1 - 2 - <sup>1</sup> 3 - (5) - <sup>1</sup> 7 or <sup>1</sup> 3 - <sup>1</sup> 7 - 2	Cm7 <sup>9</sup>
Minor seventh eleventh [m7 <sup>11</sup> ]	1 - (2) - 3 - 4 - 5 - (7)	Cm7 <sup>11</sup>
Minor major seventh [mM7]	1 - 3 - (5) - 7	CmM7
Minor major seventh ninth [mM7 <sup>9</sup> ]	1 - 2 - \( \bar{9} 3 - (5) - 7 \)	CmM7 <sup>9</sup>
Minor seventh flatted fifth [m7 <sup>1,5</sup> ]	1 - 3 - 5 - 7	Cm7 <sup>↓</sup> 5
Minor major seventh flatted fifth [mM7 <sup>♭5</sup> ]	1 - 3 - 5 - 7	CmM7 <sup>↓5</sup>
Diminished [dim]	1 - 3 - 5	Cdim
Diminished seventh [dim7]	1 - 3 - 5 - 6	Cdim7
Seventh [7]	1 - 3 - (5) - <sup>1</sup> 7 or 1 - (3) - 5 - <sup>1</sup> 7	C7
Seventh flatted ninth [7 <sup>,9</sup> ]	1 - 1/2 - 3 - (5) - 1/7	C7 <sup>,9</sup>
Seventh add flatted thirteenth [7 <sup>13</sup> ]	1 - 3 - 5 - 16 - 17	C7 <sup>13</sup>
Seventh ninth [7 <sup>9</sup> ]	1 - 2 - 3 - (5) - <sup>1</sup> 7 or 3 - <sup>1</sup> 7 - 2*	C7 <sup>9</sup>
Seventh add sharp eleventh [7 <sup>‡11</sup> ]	1 - (2) - 3 - #4 - 5 - \( 7 \) or 1 - 2 - 3 - #4 - (5) - \( 7 \)	C7 <sup>#11</sup>
Seventh add thirteenth [7 <sup>13</sup> ]	1 - 3 - (5) - 6 - <sup>1</sup> 7 or 3 - 6 - <sup>1</sup> 7	C7 <sup>13</sup>
Seventh sharp ninth [7 <sup>‡9</sup> ]	1 - #2 - 3 - (5) - 17	C7 <sup>#9</sup>
Seventh flatted fifth [7 <sup>,5</sup> ]	1 - 3 - 15 - 17	C7 <sup>,5</sup>
Seventh augmented [7aug]	1 - 3 - #5 - 1-7	C7aug
Seventh suspended fourth [7sus4]	1 - 4 - 5 - 7	C7sus4
Suspended second [sus2]	1 - 2 - 5	Csus2

### J NOTE


- Notes in parentheses can be omitted.
- For FINGERED, FINGERED ON BASS, and AI FINGERED, if you play any three adjacent keys (including black keys), the chord sound will be canceled and only the rhythm instruments will continue playing (Chord Cancel function). This let you play back only the rhythm.
- Playing two same root keys in the adjacent octaves produces accompaniment based only on the root.
- A perfect fifth (1 + 5) produces accompaniment based on the root and the fifth.
- The auto accompaniment Style will sometimes not change when related chords are played in sequence (e.g. some minor chords followed by the minor seventh).
- You can also have the PSR-2100/1100 "teach" you how to play Fingered chords. From the CHORD FINGERING display (page 142), specify the chord you want to learn, and the notes you should press are indicated in the display.

<sup>\*</sup> Only this voicing (inversion) is recognized. Other chords not marked with an asterisk can be played in any inversion.


## Arranging the Style Pattern (SECTIONS: MAIN A/B/C/D, INTRO, ENDING, BREAK)


The PSR-2100/1100 features various types of Auto Accompaniment Sections that allow you to vary the arrangement of the Style. They are: Intro, Main, Break and Ending. By switching among them as you play, you can easily produce the dynamic elements of a professional-sounding arrangement in your performance.

1 Select a style (page 62).



The Intro section starts as soon as you play a key in the Auto Accompaniment section of the keyboard, and changes to the Main section.






#### **NOTE**

You can also use this function to play only rhythms (page 64).

#### T NOTE

- If you press the [INTRO] button, you can play back an Intro section while an accompaniment is playing.
- Section button indications

   [BREAK], [INTRO],
  [MAIN], [ENDING] buttons
- LED is green
- The section is not selected.
- LED is red
- The section is currently selected.
- LED is off
- No section data; the section cannot be played.
- You can dynamically control the level of the accompaniment by how softly or strongly you play the keys in the Auto Accompaniment section of the keyboard (page 141).
- If you press the [SYNC. START] button while an accompaniment is playing, the accompaniment will stop and the PSR-2100/1100 will enter Synchronized Start standby status.
- You can also change style sections by using the pedal (page 142).
- The Break section lets you add dynamic variations and breaks in the rhythm of the accompaniment, to make your performance sound even more professional. If you press the [BREAK] button while an accompaniment is playing, the fill-in will play back for one measure.
- The indicator of the destination section (MAIN A/B/C/D) will flash while the Break is playing.
- When the [AUTO FILLIN] button is set to on and the MAIN [A][B] [C][D] button is pressed after the final half beat (eighth note) of the measure, the fill-in will begin from the next measure.



### Fade-in/Fade-out

The accompaniment style also include a convenient Fade-in/Fade-out function that gradually fades in and fades out the accompaniment. To start the style with a fade-in, press the **[FADE IN/OUT]** button, then turn SYNC. START on. To cancel the fade-in before starting the style, press the button again.


To fade out and stop the Style, press this button while the style is playing. The time of the fade-in/fade-out can also be set (page 151).

### Stopping the Style Playback While Releasing Keys (SYNC. STOP)

When the Synchro Stop function is engaged, accompaniment playback will stop completely when all keys in the Auto Accompaniment section of the keyboard are released. Accompaniment playback will start again as soon as the key in the Auto Accompaniment section is played.


1 Turn ACMP (Accompaniment) on.





As soon as you play a chord with your left hand, the auto accompaniment starts.

Split point



1

The auto accompaniment stops when you release your left hand from the keys.



Playing a chord with your left hand automatically restarts the auto accompaniment.



Press the [SYNC. STOP]/ [SYNC. START] button again to stop the accompaniment.

### J NOTE

- Styles can also be started by pressing the STYLE [START/STOP] button.
- You can select the Intro and Ending type by pressing the [E] button in the MAIN window (page 69).
- If you press the [INTRO] button while the ending is playing, the Intro section will begin playing after the ending is finished.
- When the [AUTO FILLIN] button is set to on and you press a MAIN button while the ending is playing, fill-in accompaniment will immediately start playing, continuing with the Main section.
- You can begin the accompaniment by using the Ending instead of the Intro section. In this case, the auto accompaniment doesn't stop when the ending is finished.
- If you select a different style while the style is not playing, the "default" tempo for that style is also selected. If the accompaniment is playing, the same tempo is maintained even if you select a different style.
- When STOP ACMP is set to on and the accompaniment is not playing, you can play both chords and bass in the Auto Accompaniment section in the keyboard (page 141).


### 1) NOTE

You can also use the SYNC. STOP function by pressing the auto accompaniment section/left-hand range briefly (page 141).

### **NOTE**


Synchro Stop cannot be set to on when the fingering mode is set to Full Keyboard/AI Full Keyboard or the auto accompaniment on the panel is set to off.

## **Selecting Intro and Ending Types (INTRO/ENDING)**



### J NOTE

To call up the **[MAIN]** display, first press the **[DIRECT ACCESS]** button, then press the **[EXIT]** button.




Play the style using the Intro or Ending section (page 30, 31).

# Playing Fill-in patterns automatically when changing accompaniment sections — Auto Fill In

### -♪ NOTE

Fil

A short phrase used to add variation to the style.





Play the style and switch among the accompaniment sections as they play (page 30, 31).

Fill-in patterns play automatically between each change in the Main sections.



You can also add a fill-in by pressing the selected MAIN button again.






To cancel the Auto Fill, press the [AUTO FILLIN] button again.

### NOTE:

You can temporarily disable Auto Fill In during a performance by pressing the next Main section's button twice quickly.

## Appropriate Panel Setting for the Selected Style (ONE TOUCH SETTING)

The convenient One Touch Setting function makes it easy for you to select voices and effects that are appropriate to the style you're playing. Each preset style has four pre-programmed panel setups that you can select by pressing a single button.




1 Select a style (page 62).




**?** Press one of the ONE TOUCH SETTING buttons ([1] - [4]).


**LED is red** — The One Touch Setting is currently selected.




LED is green — The One Touch Setting is not selected.

Various settings (such as voices, effects, etc.) that match the selected style can be instantly recalled. When the style is not playing, Auto Accompaniment and Sync. Start will automatically be turned on. For details about the One Touch Setting parameters, refer to the separate Data List (Parameter Chart).






Try out other One Touch Setting setups. You can also create your own One Touch Setting setups (page 71).





### Automatically Changing One Touch Settings with the Sections — OTS Link

The convenient OTS (One Touch Setting) Link function lets you automatically have One Touch Settings change when you select a different Main section (A - D).



When you switch among the Main sections (A - D), the corresponding One Touch Setting will be called up automatically.

The Main sections A, B, C, and D correspond to One Touch Settings 1, 2, 3, and 4, respectively.

### J) NOTE

The One Touch Settings can be set to change with the sections in one of two different timings (page 141):


- Immediately when you press a section button.
- At the next measure (in an accompaniment style), after you press a section button.



To cancel the OTS Link function, press the [OTS LINK] button again.

## Registering the Panel Controls in One Touch Setting (ONE TOUCH SETTING)

This section covers how to create your own One Touch Setting setups (four setups per style). For a list of One Touch Setting setup parameters, refer to the separate Data List (Parameter Chart).





The items you can register in a One Touch Setting are Voice, Harmony, Multi Pad and Pedal




A message prompting you to save the current style will appear. Select "YES" to call up the STYLE display, then save the panel settings (page 39, 47).

### ♪ NOTE

Unless you store the panel settings here, the registered settings will be deleted when you select a different accompaniment style.

## Calling Up Ideal Setups for Your Music — Music Finder

The Music Finder feature lets you instantly call up the appropriate settings for the instrument — including voice, style, and One Touch Settings — simply by selecting the desired song title. If you want to play a certain song but don't know which style and voice settings would be appropriate, the convenient Music Finder function will help you out. The recommended settings, which together make up a "record," can also be edited and stored. This lets you create and save your own Music Finder records for future recall.




### - NOTE

The MUSIC FINDER records and its contents is just one example of the recommended panel setups. You can also create your own Music Finder settings for your favorite songs and genres.

### - J NOTE

Keep in mind that Music Finder is a performance aid in that it automatically finds appropriate accompaniment styles and voices for your playing. Even though you can specify song titles, it does not actually contain song data.



Select a record. For example, select the top record by pressing the [1▲▼] button to call up All.....Show all records. the recommended setups. FAVORITE.....Show the records that have added to the "Favorite" page. The setting data shown here is referred to as a SEARCH1,2.....Show the results by SEARCH function (page 73). "record." Sorting the records MUSIC...... The record is sorted by song title. WUSIC FINIDER STYLE ......The record is sorted by style name. ALL FRUITTE SCARCHE SERBERZ BEAT..... The record is sorted by beat. TEMPO ..... The record is sorted by tempo. Feeling Of Love To 76 158 Change the order of the records Flowers Kiss? AcousticBall' 110 214 115 (ascending or descending). Select a A Nickel In The Nick A Nine Stone Cowbos A Sad Sons To Make A Sunshine Halk dernannarc DixieJazz Country8Bea RockBallad record by 76 194 120 72 124 song title. Add the selected record to "Favorite (Bookmark)" page DetroitPop1 SEARCH-When you press the [H] button, the "Add selected When sorting Above The Clouds Adeline's Ballad data to the favorite list? YES/NO" message will be records by NUMBER OF Records displayed. Select [YES] to add the selected page to song title, use 124 96 Asain, He Are Toset Asain, He're Whole "FAVORITE" page. the [1▲▼] but-Show the ton to skip up To delete the added record, select the record in the number of or down "FAVORITE" page and press the [H](DELETE records of FROM FAVORITE) button. through the each page. songs alphabetically. Search record(s). Enter the condition of the search in the Simulta-MUSIC FINDER SEARCH display (page 73). The results of neously press SEARCH 1 or 2 appear in the "SEARCH 1" or "SEARCH 2" the [▲▼] butpage respectively. tons to move the cursor to Call up the MUSIC FINDER RECORD EDIT (page 74) display (for the first Select a record by style name. When editing the selected record). record. sorting the records by style name, Turn TEMPO LOCK on/off. TEMPO LOCK function lets you avoid changing press these buttons to move the cursor to the next /previous style. the Tempo during style playback when selecting another record. The on/off setting affects all pages (ALL/FAVORITE/SEARCH 1/SEARCH 2). Simultaneously press the [▲▼] buttons



to move the cursor to the first record.

**2** Play the style (page 63).




### ♪ NOTE

Records can be selected by using the **[DATA ENTRY]** dial and pressing the **[ENTER]** button.

## Searching the Ideal Setups — Music Finder Search


You can search the record by music title or keywords. The results appears in the display.



### ■ [A] MUSIC

Searches by music or song title. Press this button to call up the display for inputting the song title.

When you enter the song title (page 48), the search function calls up all records that contain the entered word or words.



### ■ [B] KEYWORD

Searches by keyboard. Press this button to call up the display for inputting the keyword.



When you enter the keyword (page 48), the search function calls up all records that contain the entered word or words. You can search several different keywords simultaneously by inserting a separator (comma) between each. The search function finds and displays all records that contain at least one match in the keywords.

### ■ [C] STYLE

Searches by style name. Press this button to call up the **STYLE FILE SELECT** display. Press the **[A]** through **[J]** button in the display to select the desired accompaniment style. This convenient function lets you find all songs that use a certain accompaniment style.

## NOTE -

The STYLE FILE SELECT display can only be used to select the style name for searching; it cannot be used to call up the actual accompaniment style.

### ■ [D] BEAT

Searches by beat or rhythmic feel.

#### **■** [E] SEARCH AREA

Selects a specific location for searching. You can further narrow down your search by using the SEARCH 1 and 2 selections.

#### ■ [F]~[H] CLEAR

Clears the entered item at left.

#### ■ [1▲▼] TEMPO FROM

You can also narrow your search by specifying a tempo range. This lets you set the minimum tempo for the search. Press the  $[\blacktriangle \blacktriangledown]$  buttons simultaneously to instantly reset the tempo value to the minimum.

#### ■ [2▲▼]TEMPO TO

You can also narrow your search by specifying a tempo range. This lets you set the maximum tempo for the search. Press the  $[\blacktriangle \blacktriangledown]$  buttons simultaneously to instantly reset the tempo value to the maximum.

#### **■** [3▲▼]~[5▲▼] GENRE

Selects the specific music genre for searching. The available range includes all genres (ANY), the preset genres, and any genres you've entered yourself (page 72).

#### **■** [8**▼**] CANCEL

Press this to cancel the operation and return to the previous display.

## **Editing Records — Music Finder Record Edit**

From this display, you can call up existing records and edit them to suit your preferences. You can even use this to create your own Music Finder records.

1

Press the [8 ▲▼] (RECORD EDIT) button in the MUSIC FINDER display.



Change/clear the record data. You can also register new records. For details about all settings and operations, see below.

MUSIC FINDER REGORD EDIT

HUSIG:

STYLE:

#### J. NOTE

You can also change/clear a preset record. To avoid changing/clearing the record, register the record as a new record after editing.

#### J NOTE

All Music Finder records can be stored together as a single file (page 154). When calling up a stored file, a message appears prompting you to replace or append the records as desired.

#### · Replace:

All Music Finder records currently in the instrument are deleted and replaced with the records of the selected file.

#### Append:

The records called up are added to the vacant record numbers.

## ■ [A] MUSIC


Selects the music or song title for editing. Press the button to call up the display for inputting the music or song title, then edit the name as desired.

#### ■ [B] KEYWORD

Selects the keyword for editing. Press the button to call up the display for inputting the keyword, then edit it as desired.

You can enter several different keywords by inserting a separator (comma) between each.





### ■ [C] STYLE

Selects the style name for editing. Always enter the name when a new record is registered. Press the button to call up the **STYLE FILE SELECT** display. Press the [A] through [J] button in the display to select the desired file you want to change/clear/register.

### ■ [D] BEAT

Selects the beat (time signature) for editing. When another file is selected by pressing the **[C]** button, the current beat setting is replaced with the beat setting of the selected file.

### ■ [E] FAVORITE

Adds the selected record to the **FAVORITE** page (page 72).

### ■ [F]~[H] CLEAR

Clears the entered item at left.

## ■ [I] DELETE RECORD

Clears the selected record. The deleted record number becomes empty. When you press this button, a message appears prompting you to execute, abort or cancel the operation.

**YES** ..... Press this to clear the record and close the display.

**NO** ...... Press this to close the display without clearing the record.

**CANCEL**..... Press this to close the message box and return to the previous display.

#### NOTE:

The STYLE FILE SELECT display can only be used to select the style name for record editing; it cannot be used to call up the actual accompaniment style.

#### - J NOTE

Keep in mind that the Beat setting made here is only for the Music Finder search function; this does not affect the actual Beat setting of the accompaniment style itself.

### **■** [J] NEW RECORD

Registers a new record. The smallest available empty record number is used for registering. When you press this button, a message appears prompting you to execute, abort or cancel the operation.

YES ...... Press this to register the record and close the display.

**NO** ...... Press this to close the display without registering the record.

**CANCEL**..... Press this to close the message box and return to the previous display.

#### ) NOTE

The maximum number of records is 2500 (PSR-2100)/1200 (PSR-1100), including internal records.

### **■** [1**▼▲**] TEMPO


Determines the tempo for the selected style. When changing the style with the [C] button, the tempo is automatically changed to that of the changed style.

## **■** [3**▼▲**]~[5**▼▲**] GENRE

Indicates and changes the genre to which the selected record is assigned. The available range includes all preset genres as well as any you've entered yourself.

### **■** [6**▼**▲] GENRE NAME

For entering a genre name. Press the button to call up the display for inputting the genre name, then edit the name as desired. A maximum of 200 genre names can be stored.



The genre name you input becomes effective when the current record is edited (overwritten) by pressing the [8 $\blacktriangle$ ] (OK) button, or when a new record is registered by pressing the [J] (NEW RECORD) button.

If you exit from the MUSIC FINDER EDIT display without actually editing or registering a record, the input genre name is deleted.

### **■** [8▲] OK

Executes all editing and changes to the record. When you press this button, a message appears prompting you to execute, abort or cancel the operation.

**YES** ...... Press this to replace the record and close the display.

**NO** ...... Press this to close the display without replacing the record.

**CANCEL**..... Press this to close the message box and return to the previous display.

#### **■** [8**▼**] CANCEL


Press this to cancel the operation and return to the MUSIC FINDER display.

### - 🗥 CAUTION

To maintain the edited and registered data, make sure to save all Music Finder records as a file (page 154). If no saved, the data will be lost when another Music Finder file is called up or the factory-programmed settings are restored (page 154).


## The Multi Pads

The PSR-2100/1100 Multi Pads can be used to play a number of short pre-recorded rhythmic and melodic sequences that can be used to add impact and variety to your keyboard performances.



## **Playing the Multi Pads**

- Select the desired bank in the MULTI PAD Bank display (page 38).
- **?** Press any of the Multi Pads.



The corresponding phrase (in this case, for Pad 4) starts playing back in its entirety as soon as the pad is pressed.

The Multi Pad function provides two different ways to stop in the middle of the phrase:


- To stop all pads, press and release the [STOP] button.
- To stop specific pads, simultaneously hold down the **[STOP]** button and press the pad or pads you wish to stop.

#### ♪ NOTE

- Simply tap any of the Multi Pads at any time to play back the corresponding phrase at the currently set tempo.
- You can even play two, three, or four Multi Pads at the same time.
- Pressing the pad during its playback will stop playing and begin playing from the top again.

## **Chord Match**

- Turn ACMP on (page 63).
- ? Play a chord with your left hand and press any of the Multi Pads.



#### NOTE:


The Chord Match on/off status depends on the selected Multi Pad Bank.

In this example, the phrase for Pad 1 will be transposed into F major before playing back.

Try playing other chords and pressing the pads. Keep in mind that you can also change chords while a pad is playing back.

## Multi Pad Edit


This function lets you copy individual Multi Pad settings from one Multi Pad bank to another.



## Song Playback

Here you'll learn how to play back songs. Songs include the internal songs of the instrument, performances you've recorded yourself using the recording functions (page 95), and commercially available song data. You can use this highly versatile feature in a variety of ways — playing along on the keyboard with the recorded song. You can also display the music notation (PSR-2100 only) and lyrics in the LCD.

If you connect a microphone to the PSR-2100, you can sing along with the song or auto accompaniment and have vocal harmony parts added automatically (page 131).



## **Compatible Song Types**

• Commercially available song data



Disks having this logo mark feature song data compatible with GM (General MIDI).



Disks having this logo mark feature song data compatible with Yamaha's XG format. XG is a significant enhancement of the "GM system level 1" standard, providing more voices, greater editing control, and support for multiple effect sections and effect types.



Disks having this logo mark feature song data compatible with Yamaha's DOC (Disk Orchestra Collection) format.



Disks having this logo mark feature song data compatible with Yamaha's original MIDI file format.

• Songs you recorded (page 95) and stored to the PSR-2100/1100 or disk.

#### ♪ NOTE


Commercially available music data is subject to copyright restrictions, and is intended only for your own personal use.


#### NOTE:

For more information on the song file types compatible with the PSR-2100/1100, see page 161.

## Song Playback

## **Playing the Internal Songs**





#### J NOTE

If the MAIN screen (at left) is not displayed, press the [DIRECT ACCESS] button followed by the [EXIT] button.

#### 7 NOTE

You can also make a variety of other settings (such as tempo, voice selection, etc.) and have them automatically called up when you play back the song (page 107).


#### ♪ NOTE

You can enable the Synchro Start for the song by simultaneously pressing the [TOP] button and the SONG [START/STOP] button. The song starts as soon as you play the keyboard. You can also use this function along with the Style's Synchro Start function (page 63).

#### 1) NOTE

You can have the volume automatically fade in and fade out at the beginning and end of the song. Simply press the [FADEIN/OUT] button at the start of song playback to fade in the song, and press it again at the end of the song to fade out.

START/STOP



#### - 1) NOTE

Songs can also be played back continuously. Set SONG CHAIN PLAY to ON from the SONG SETTING display (page 140).



To stop the song immediately, press the button again.

Press the previous screen.

button in order to go back to the

#### - D NOTE

Make sure that the Language setting for the instrument (page 154) is the same as that of the file name of the song that you are playing back.

#### Simultaneously Playing a Song and an Accompaniment Style

When playing back a song and an accompaniment style at the same time, channels 9 - 16 of the song data are replaced with accompaniment style channels — allowing you to use the auto accompaniment styles and features in place of the accompaniment parts of the song. Make the settings below and play your own chord substitutions in place of the song's chord data.

- [ACMP] button .....ON
- [AUTO FILL IN] button .....ON
- **1** Select the song and start playback by pressing the SONG [START/STOP] button.
- Select the desired accompaniment style.
- **2** Start the style by pressing the STYLE [START/STOP] button.
- While the song is playing, insert a break or change sections (with the STYLE section buttons.)
  Fill-in patterns play when you switch sections.



The style automatically stops when the song finishes or is stopped.

#### J NOTE


Some of the internal songs have been created using the accompaniment styles. For these songs, the accompaniment styles are automatically started when starting song playback.

#### - NOTE

The accompaniment stops when you stop the song. If the accompaniment style is playing and you start the song, the accompaniment automatically stops. However, for internal songs that use accompaniment styles, the accompaniment style is not stopped.

## Playing Back Songs on Disk


Insert the disk into the drive.



The method for playing back is the same as in the "Playing the Internal Songs" instructions (page 79), except that you should select **FLOPPY DISK** page in the **SONG** display.

## **Other Playback-related Operations**


## ■ Repeat / Rewind / Fast forward



#### **SONG POSITION display**


When "BAR" is selected, you can specify a measure number (counted from the beginning of the song) by using the [REW] and [FF] buttons.

When "PHRASE MARK" is selected, specify the phrase mark number by using the [REW] and [FF] buttons.



"PHRASE MARK" is shown only when the song contains phrase marks. Press the [J] button to toggle between "BAR" and "PHRASE MARK," then use the [REW] and [FF] buttons to select the desired measure or phrase mark.

## ■ Adjusting the Volume Balance / Muting Specific Channels



#### **CHANNEL ON/OFF display**



Select the **[SONG]** tab with the **[CHANNEL ON/OFF]** button, and mute the desired channel by setting it to **[OFF]**. To **solo** a channel (only that channel will sound), hold down the appropriate button corresponding to the channel. To release the solo for the channel, press that channel's button again.

#### J NOTE

Before proceeding, make sure to read the section "Handling the Floppy Disk Drive (FDD) and Floppy Disk" (page 7).

#### J. NOTE

You can set whether or not the PSR-2100/1100 automatically calls up the first disk song when a disk is inserted (page 153).

#### ♪ NOTE

Some song data for the PSR-2100/1100 has been recorded with special "free tempo" settings. During playback of such song data, the measure numbers shown in the display will not correspond to the actual measure; this only serves as a reference as to how much of the song has been played back.

#### ) NOTE

Songs containing a large amount of data may not be able to be read properly by the instrument, and as such you may not be able to select them. The maximum capacity is about 200–300KB, however this may differ depending on the data contents of each song.

#### ♪ NOTE

#### Phrase Mark

This data specifies a certain location in the song data.

#### ♪ NOTE

#### Channel

Refers to the MIDI channel in the song data. The channels are assigned as shown below for the PSR-2100/1100.

#### Song


1 - 16

Accompaniment Style

9 - 16


## Muting Specific Parts — Track1/Track2/Extra Tracks

This feature lets you mute certain parts of the song (Track1, Track2, Extra Tracks), and play back only those parts you want to hear. For example, if you want to practice the melody of a song, you can mute just the right-hand part and play that part yourself.




## Repeat Playback of a Specific Range


This feature allows you to specify a certain range of the song (between Point A and Point B), and play it back repeatedly.



## **Displaying Music Notation — Score**

With this feature, you can have the notation automatically shown on the display as the song plays. This can be used with your own recordings as well as the internal Demo songs.





#### **NOTE**

If the **MAIN** screen (at left) is not displayed, press the **[DIRECT ACCESS]** button followed by the **[EXIT]** button.

#### ) NOTE

The displayed notation is generated by the PSR-2100/1100 based on the song data. As a result, it may not be exactly the same as commercially available sheet music of the same song — especially when displaying notation of complicated passages or many short notes.

#### 1 NOTE

Some song data for the PSR-2100/1100 has been recorded with special "free tempo" settings. For such song data, the tempo, beat, measure and music notation will not displayed correctly.

### ) NOTE

[RIGHT] and [LEFT] cannot be turned off at the same time.

#### ) NOTE

The note name is indicated at the left of the note. When the space between the notes is too small, the indication may be moved to the top left of the note.

#### ) NOTE

You can increase the number of measures that will be displayed by decreasing the other items to be displayed (parts, lyrics, chords, etc.).


#### ) NOTE


When accidentals (sharp and flats) and notes cannot be displayed on one line, they are displayed in the next line from the middle of the measure.

#### ) NOTE

The notation functions cannot be used to create song data by inputting notes. For information on creating song data, see page 99.

### **Detailed Settings for Notation**





#### 1) NOTE

When "LEFT" and "RIGHT" are set to the same channel, the notation of the right-hand notes and left-hand notes are displayed in piano format (two connected staves).

## ■ [1▲▼] LEFT CH/[2▲▼] RIGHT CH

This determines the Left channel (channel for the left-hand part) and Right channel (channel for the right-hand part). This setting returns to **AUTO** when a different song is selected.

AUTO ......The channels for the right- and left-hand parts are assigned automatically — setting the parts to the same channel as the channel which is specified in the **SONG SETTING** display of the **Function** menu (page 140).

**1-16**.....Assigns the part to the specified channel, 1- 16.

**OFF** (**LEFT CH only**)....No channel assignment.

### ■ $[3 \blacktriangle \blacktriangledown]$ , $[4 \blacktriangle \blacktriangledown]$ KEY SIGNATURE

This lets you enter key signature changes in the middle of a song, at the stopped position. This menu is useful when the selected song contains no key signature settings for displaying notation.

For a list of the key signatures, with their relative minor keys and accidentals, see the chart below.

#### **Key Signatures and Accidentals**



The o note indicates the root note of the major key, and the o note indicates the root of the relative minor.

#### ■ [5▲▼] QUANTIZE

This gives you control over the note resolution in the notation, letting you shift or correct the timing of all displayed notes so that they line up to a particular note value. Make sure to select the smallest note value which is used in the song.

#### **Note resolution:**

1/4 note, 1/8 note, 1/16 note, 1/32 note, 1/4 note triplet, 1/8 note triplet, 1/16 note triplet, 1/32 note triplet

#### ♪ NOTE

Short notes and ornamented notes (such as trills and grace notes) which are shorter than the Note resolution will not be displayed in the notation.

## ■ [6▲▼] NOTE NAME

Select the Note Name type when "NOTE" (page 83) is set to ON.

ABC ...... Note names are indicated as letters (C, D, E, F, G, A, B).

Fixed Do....... Note names are indicated in solfeggio and differ depending on the selected language (page 52).

English............ Do Re Mi Fa Sol La Ti French............ Ut Re Mi Fa Sol La Si Italian........... Do Re Mi Fa Sol La Si German.......... Do Re Mi Fa Sol La Si Spanish.......... Do re Mi Fa Sol La Si Japanese........ドレミファソラシ

**Movable Do**..... Note names are indicated in solfeggio according to the scale intervals, and as such are relative to the key. The root note is indicated as Do. For example, in the key of G major the root note of Sol

would be indicated as Do.

As with "Fixed Do," the indication differs depending on the selected language.

## **■** [8▲] OK

This closes the detailed setting display and starts generating the notation. You can also execute this by pressing the **[ENTER]** button on the panel.

## **■** [8**▼**] CANCEL

This closes the detailed setting display without changing the settings. You can also execute this by pressing the **[EXIT]** button on the panel.


#### ♪ NOTE

You can select the display pages (one before and after) by the using the [BACK]/ [NEXT] buttons or the pedal (page 142).

## **Displaying the Lyrics**


This function lets you display the lyrics while the song is playing back — making it easy to sing along with your performance or song playback.

\* Microphone input is available only on the PSR-2100.




## Saving and Recalling Custom Panel Setups — Registration Memory

Registration Memory is a powerful feature that lets you set up the PSR-2100/1100 just as you want — selecting specific voices, styles, effect settings etc. — and save your custom panel setup for future recall. Then, when you need those settings, simply press the appropriate REGISTRATION MEMORY button.




## Registering Panel Setups — Registration Memory

This shows you how to register your custom panel settings to the REGISTRATION MEMORY buttons. Make all the settings you want with the panel controls, and Registration Memory will "remember" them for you.





Press the desired number button for registering the settings.



**Indicator is green** ..... The panel setting is registered, but not selected.

**Indicator is red**.......The panel setting is registered and is currently selected. **Indicator is off**......The panel setting is not registered.


For information on saving the settings registered here, refer to the next page.

#### J NOTE

To delete all currently registered settings at one time, simultaneously hold down the highest B key on the keyboard and turn on the power.

## **Saving Your Registration Memory Setups**


The settings registered to the **REGISTRATION MEMORY** [1]-[8] buttons are saved as a single file.



All settings registered to buttons [1][8] are referred to as a "bank." The banks can be saved to "USER" or "FLOPPY DISK" as Registration bank files.


#### J) NOTE

Keep in mind that the size of the Registration bank files and the memory space they occupy depends on the amount of functions set in each.



Press the [DIRECT ACCESS] button and [EXIT] button to call up the MAIN display.

2 Save the settings you've made to the Registration Memory buttons as a single Registration bank file (page 47).



The **REGISTRATION EDIT** display appears. For details on this display, see below.

### **REGISTRATION EDIT display**

The contents of the current Registration Memory bank (REGIST.) are listed in the **REGISTRATION EDIT** screen. The names of the stored Registration Memory presets are shown in the display and the indicators of the relevant REGISTRATION MEMORY buttons are lit in green.

From this screen, you can select, name, or delete the Registration Memory presets.

**Select** .......Press the **[A] - [J]** buttons. The REGIST. display is linked to the REGISTRATION MEMORY **[1] - [8]** buttons. When you select the Registration Memory preset in the display, the related button turns on (indicator is red).

Name .......This operation is the same as that in "Naming Files and Folders" (page 44) in "Basic Operations — Organizing Your Data."

**Delete** .......This operation is the same as that in "Deleting Files/Folders" (page 46) in "Basic Operations — Organizing Your Data."


Save the result of the Name/Delete operation by returning to the REGISTRATION BANK display and pressing the  $[8\nabla]$  (UP) button.

## **Recalling a Registration Memory Setup**

You can recall all of the panel settings you've made — or only those you specifically want or need. For example, if you de-select "STYLE" in the **REGISTRATION MEMORY** display, you can keep the currently selected style even when you change the Registration Memory preset.

## **Recalling the Registered Settings**


Select the desired bank in the REGISTRATION BANK display (page 88). Press the appropriate REGISTRATION MEMORY button (any whose indicators are green) to recall the desired settings.



#### **NOTE**


You can program your Registration Memory presets to be called up in sequence, in any order you desire. Once programmed, the presets 1 - 8 can be selected in sequence with the [BACK][NEXT] buttons or the pedal (page 145).

## **Selecting the Freeze Settings**



## **Editing Voices — Sound Creator**

The PSR-2100/1100 has a Sound Creator feature that allows you to create your own voices by editing some parameters of the existing voices. Once you've created a voice, you can save it as a USER voice for future recall.




#### ♪ NOTE


- The Voice can be edited in realtime while playing back a song/style.
- Keep in mind that adjustments made to the parameters may not make much change in the actual sound depending on the original settings of the voice.

## Operation

Press the [F], [G] or [H] button to select the Part (MAIN, LAYER or LEFT) containing the voice you wish to edit.



Press the **[SOUND** CREATOR] button.




NOTE

The voice can also be selected in the SOUND CREATOR display.

## **CAUTION**

The settings are lost if the edited part's voice is switched to another voice. Important data should be saved to User Drive or floppy disk.





Save the edited voice to the USER drive (Flash ROM) as a USER voice (page 47).



the edited voice as a User voice (page 47)

Press the [USER] button to select the edited voice, and play the keyboard.

## **Regular Voice Parameters**

COMMON	Determines the common settings such as voice volume or octave.
SOUND	Determines the timbre/EG (Envelope Generator)/vibrato of the voice.
EFFECT/EQ (PSR-2100) EFFECT (PSR-1100)	Determines the effect depth/type and equalizer settings.
HARMONY	Determines the Harmony/Echo settings.

D NOTE

Keep in mind that there are certain parameters whose Sound Creator settings affect only the Main part's voice.


The parameter for Organ Flute, see page 94

The following parameters are linked to the ones in each display.

Common parameter	Other location	
MONO	VOICE EFFECT (TOP PANEL)	page 61
PORTAMENTO TIME	MIXING CONSOLE	page 126
FILTER BRIGHTNESS	MIXING CONSOLE	page 126
FILTER HARMONIC CONTENT	MIXING CONSOLE	page 126
REVERB DEPTH	MIXING CONSOLE	page 127
CHORUS DEPTH	MIXING CONSOLE	page 127
DSP ON/OFF	VOICE EFFECT (TOP PANEL)	page 60
DSP DEPTH	MIXING CONSOLE	page 127
DSP TYPE/VARIATION	MIXING CONSOLE/VOICE EFFECT (TOP PANEL)	page 61,127
EQ LOW/GAIN	MIXING CONSOLE	page 124
EQ HIGH/GAIN	MIXING CONSOLE	page 124
HARMONY/ECHO TYPE	HARMONY/ECHO (FUNCTION)	page 146
HARMONY/ECHO VOLUME	HARMONY/ECHO (FUNCTION)	page 146
HARMONY/ECHO SPEED	HARMONY/ECHO (FUNCTION)	page 146
HARMONY/ECHO ASSIGN	HARMONY/ECHO (FUNCTION)	page 146
HARMONY/ECHO CHORD NOTE ONLY	HARMONY/ECHO (FUNCTION)	page 146
HARMONY/ECHO TOUCH LIMIT	HARMONY/ECHO (FUNCTION)	page 146


#### **COMMON**


The explanations here apply to step #3 on page 90.



### **SOUND**

The explanations here apply to step #3 on page 90.






Determines the filter, EG, and vibrato settings (see below).

#### **■** FILTER

FILTER settings determine the overall timbre of the sound by boosting or cutting a certain frequency range.

#### BRIGHTNESS


Determines the cutoff frequency or effective frequency (resonance) range of the filter (see diagram). Higher values result in a brighter sound.



In addition to making the sound either brighter or more mellow, Filter can be used to produce electronic, synthesizer-like effects.

#### • Harmonic Content


Determines the emphasis given to the cutoff frequency, set in BRIGHTNESS above (see diagram). Higher values result in a more pronounced effect.



#### **■** EG

The EG (Envelope Generator) settings determine how the level of the sound changes in time. This lets you reproduce many sound characteristics of natural acoustic instruments — such as the quick attack and decay of percussion sounds, or the long release of a sustained piano tone.

- ATTACK ...... Determines how quickly the sound reaches its maximum level after the key is played. The higher the value, the slower the attack.
- **DECAY**...... Determines how quickly the sound reaches its sustain level (a slightly lower level than maximum). The higher the value, the slower the decay.
- **RELEASE** ..... Determines how quickly the sound decays to silence after the key is released. The higher the value, the slower the release.



If RELEASE is set to a large value, the sustain becomes long.


#### ■ VIBRATO

• **DEPTH**...... Determines the intensity of the Vibrato effect (see diagram). Higher settings result in a more pronounced Vibrato.

• **SPEED**...... Determines the speed of the Vibrato effect (see diagram).


• **DELAY** ...... Determines the amount of time that elapses between the playing of a key and the start of the Vibrato effect (see diagram). Higher settings increase the delay of the Vibrato onset.

VIBRATO
Creates a wavering in the sound by periodically changing the pitch.




### **EFFECT/EQ**

The explanations here apply to step #3 on page 90.



### **HARMONY**


The explanations here apply to step #3 on page 90.



The parameters are the same as for HARMONY/ECHO display of FUNCTION. For details, see page 147.

## **Organ Flutes (PSR-2100 only)**

In addition to the many organ voices in the ORGAN voice category, the PSR-2100/1100 has an ORGAN FLUTES voice. The explanations here apply to step #3 on page 90.




#### ■ Parameters

Organ Type		This parameter specifies the type of organ tone generation to be simulated: Sine or Vintage.			
Rotary SP Speed		The Rotary SP Speed ([C]) button alternately switches between the slow and fast rotary speaker speeds when a rotary speaker effect is selected for the Organ Flutes (see "DSP Type" below), and the VOICE EFFECT [DSP] button is turned on (the Rotary SP Speed button has the same effect as the VOICE EFFECT [VARIATION] button).			
Vibrato On/Off		This ([G]) button alternately turns the vibrato effect for the Organ Flutes voice ON or OFF.			
Vibrato Depth		Can be set to any of three levels via the Vibrato Depth ([H]) button. The button sequentially selects a depth of "1", "2", or "3".			
Footage		The footage settings determine the basic sound of the organ flutes.  The term "footage" is a reference to the sound generation of traditional pipe organs, in which the sound is produced by pipes of different lengths (in feet). The longer the pipe, the lower the pitch of the sound. Hence, the 16' setting determines the lowest pitched component of the voice, while the 1' setting determines the highest pitched component. The higher the value of the setting, the greater the volume of the corresponding footage. Mixing various volumes of the footages lets you create your own distinctive organ sounds.			
Volume (VOL)		Adjusts the overall volume of the Organ Flutes. The longer the graphic bar, the greater the volume.			
Response (RESP)		The Response control affects both the attack and sustain portion of the sound, increasing or decreasing the response time of the initial swell and release, based on the FOOTAGE controls. The higher the value the slower the swell and release.			
Vibrato Speed (VIB. SPEED)		Determines the speed of the vibrato effect controlled by the Vibrato On/Off and Vibrato Depth above.			
Mode		The MODE control selects between two modes: FIRST and EACH. In the FIRST mode, attack is applied only to the first notes played and held simultaneously; while the first notes are held, any subsequently played notes have no attack applied. In the EACH mode, attack is applied equally to all notes.			
Attack (4', 2 2/3', 2')		The ATTACK controls adjust the attack sound of the ORGAN FLUTE voice. The 4', 2 2/3 'and 2' controls increase or reduce the amount of attack sound at the corresponding footages. The longer the graphic bar the greater the attack sound.			
Length (LENG)		The LENGTH control affects the attack portion of the sound producing a longer or shorter decay immediately after the initial attack. The longer the graphic bar the longer the decay.			
Reverb Depth Chorus Depth DSP on/off DSP Depth		For details about the digital effects, see pages 60, 127.			
DSP Type		Determines the DSP effect type to be applied to the Organ Flutes voice. Normally this will be one seven available Rotary Speaker effects. If any other type of effect is selected, the Rotary SP Spe ([C]) button in the FOOTAGE/VOL/ATTACK display will not control rotary speaker speed. Instead, have the same effect as the VOICE EFFECT [VARIATION] button.			
Variation Variation		Determines whether the DSP variation will be set to Slow or Fast when the Organ Flutes voice is selected (when the Voice Set function is ON — page 146).			
	Value	Sets the DSP variation parameter value (e.g., "LFO Freq" for a Rotary Speaker effect) when the DSP variation is turned on.			
EQ Low EQ High		The EQ parameters determine the Frequency and Gain of the Low and High EQ bands.			

## **Recording Your Performances and Creating Songs**

# — Song Creator

With these powerful yet easy-to-use song creating features, you can record your own keyboard performances and store them for future recall. Several different recording methods are available: Quick Recording (page 96), which lets you record easily and quickly; Multi Recording (page 97), which lets you record several different parts; and Step Recording (page 99), which lets you enter notes one by one. Songs can include not only the voice settings for the keyboard performance (Main, Layer, Left), but also the effects, vocal harmony and auto accompaniment parts. The recorded song can be stored to internal memory or floppy disk (page 38, 47).



## **About Song Recording**

There are two methods of recording songs: realtime recording and step recording.

### **■** Realtime Recording

This method lets you record performance data in real time. There are two ways to use realtime recording: **Quick** and **Multi**.

### **Quick Recording (page 96)**

This is the easiest recording method, and lets you quickly record the piano song you are practicing. You can select from four parts: right hand, left hand and auto accompaniment/multi pad. For example, you can record only your right hand performance, or you can simultaneously record both your right hand and the auto accompaniment.

#### Multi Recording (page 97)

This lets you record a song with several different instrument sounds, and create the sound of a full band or orchestra. Record the performance of each instrument individually and create fully orchestrated compositions. You can also record over an existing part on an internal song or a song on disk with your own performance.

### ■ Step Recording (page 99)

This method lets you compose your performance by "writing" it down one event at a time. This is a non-realtime, manual recording method — similar to writing music notation onto paper. By using the Event List (page 108-110), you can input notes, chords and other events one by one.

#### ■ Song Editing (page 105)

The PSR-2100/1100 also lets you edit the songs you've recorded by the Quick Recording, Multi Recording and Step Recording methods.

When re-recording a specific section of an already-recorded song, use the Pung

When re-recording a specific section of an already-recorded song, use the Punch IN/OUT function (page 104).

#### ♪ NOTE

- The internal memory capacity of the PSR-2100/1100 is about 1520KB (PSR-2100)/700KB (PSR-1100). Memory capacity for 2DD and 2HD floppy disks is about 720KB and 1.44MB, respectively. When you store data to these locations, all file types of the PSR-2100/ 1100 (Voice, Style, Song, Registration, etc.) are stored together.
- The microphone input signal (PSR-2100 only) cannot be recorded.
- Songs recorded on the PSR-2100/ 1100 are automatically recorded as SMF (Standard MIDI File format 0) data. For details on SMF, see page 161.
- Playback of the recorded song data can be transmitted from MIDI OUT, letting you play the sounds of a connected external tone generator (page 149).
- The volume level of each channel of the song can be adjusted from the Mixing Console and the settings can be saved. Moreover, even after you've set a voice for your keyboard play during recording, you can record voice selections, so that the voice changes automatically during playback (page 107).

## **Quick Recording**


This is the easiest recording method — perfect for quickly recording and playing back a piano song you're practicing, so you can check your progress.

#### A CAUTION

If you wish to save the recording, make sure to store it to internal memory (USER drive) or floppy disk (page 39, 47).

If you turn off the power or re-record over an existing track before you save the performance, any previous recording will be erased.

### ■ When creating a new song:



■ When recording over the part of an internal song or a song on disk with your own performance:

Select the desired song (page 79, 81).

J) NOTE

J. NOTE

1) NOTE

1) NOTE

ton again.

NOTE

ferent channels.

If the "LAYER" or "LEFT" but-

ton is on before pressing the REC button, the correspond-

ing Layer and Left parts are

automatically recorded to dif-

The performance of track 1/2

is recorded to the channel

specified in the SONG SET-TING display (page 140).

You can overdub a second right-hand performance onto Track 2 after recording the

first right-hand performance

(including the layer voices) on Track 1. To do this, set the **[LEFT]** button to OFF and repeat steps 2 and 3.

To pause, press the SONG


[START/STOP] button. To

resume recording, press the

SONG [START/STOP] but-

? Select the voice and accompaniment style you want to use in the song.

If you want to record to the MAIN/Layer/Left voices, make sure to set the [MAIN]/[LAYER]/[LEFT] buttons to ON. Make any other desired settings (Reverb, Chorus, etc.) as well.



In this case, your performance will be recorded automatically to TRACK 1. To specify the track for recording, simultaneously hold down the [REC] button and press the button corresponding to the track you want to record.

You can select TRACK 1 or TRACK 2 and the EXTRA TRACKS for recording at the same time.

• Specifying the recording track


To record your keyboard performance:

Press either the [TRACK 1] or [TRACK 2] button.

To record the auto accompaniment and multi pad performance:

Press the [EXTRA TRACKS] button.

To stop recording, press the [REC] button again.





## Recording starts as soon as you play the keyboard.

You can also start recording by pressing the SONG/STYLE [START/STOP] button. Recording can also be started by pressing down the foot pedal, if the song start/stop function is properly assigned to the pedal (page 142).





## END

#### To stop recording, press the [REC] button again.

Recording can also be stopped by pressing down the foot pedal, if the song start/stop function is properly assigned to the pedal (page 142).

### You

You can also use the metronome click as a guide while recording.

The sound of the metronome is not recorded.

### ■ Play back your new song

To play back the performance you just recorded, return the song to the beginning by using the [TOP] button and press the SONG [START/STOP] button.

Playback stops automatically at the end of the song, and returns to the beginning of the song. You can edit the recorded song data from the **SONG CREATOR** (1 - 16) displays (page 108).

Press the [6▼] button from the Open/Save display for Song to store the recorded data (page 38, 47).

## **Multi Recording**

This lets you record a song with several different instrument sounds on up to sixteen channels, and create the sound of a full band or orchestra.

The structure of the channels and parts are shown in the chart below.

Channels	Parts (default settings)	Available parts
1	Voice MAIN	Voice MAIN, LAYER, LEFT Multi Pad1
2	Voice MAIN	Multi Pad2 Multi Pad3
3	Voice MAIN	Multi Pad4 Accompaniment style RHYTHM 1 Accompaniment style RHYTHM 2
4	Voice MAIN	Accompaniment style BASS Accompaniment style CHORD1
5	Voice MAIN	Accompaniment style CHORD2 Accompaniment style PAD
6	Voice MAIN	Accompaniment style PHRASE1 Accompaniment style PHRASE2
7	Voice MAIN	MIDI
8	Voice MAIN	

Channels	Parts (default settings)	Available parts
9	Accompaniment style RHYTHM 1	Voice MAIN, LAYER, LEFT Multi Pad1
10	Accompaniment style RHYTHM 2	Multi Pad2 Multi Pad3
11	Accompaniment style BASS	Multi Pad4  Accompaniment style RHYTHM 1
12	Accompaniment style CHORD1	Accompaniment style RHYTHM 2 Accompaniment style BASS Accompaniment style CHORD1
13	Accompaniment style CHORD2	Accompaniment style CHORD2 Accompaniment style PAD
14	Accompaniment style PAD	Accompaniment style PHRASE1 Accompaniment style PHRASE2
15	Accompaniment style PHRASE1	MIDI
16	Accompaniment style PHRASE2	

#### About the accompaniment style parts

Rhythm ..... This is the basis for the accompaniment, containing the drum and percussion rhythm patterns. Usually one of the drum kits is used.

Bass.......The Bass part uses various appropriate instrument sounds to match the style, such as acoustic bass, synth bass, and others.

Chord.......This is the rhythmic chord backing, commonly used with piano or guitar voices.


Pad ......This part features sustained chords and commonly uses lush sounds such as strings, organ, and choir.

Phrase ......This part is used for various embellishments and riffs that enhance the song, such as brass section accents and chord arpeggios.



If you wish to save the recording, make sure to store it to internal memory (USER drive) or floppy disk (page 39, 47). If you turn off the power or re-record over an existing track before you save the performance, any previous recording will be erased.

## ■ When creating a new song:



■ When recording over the part of an internal song or a song on disk with your own performance:

Select the desired song (page 79, 81).

2 Select the desired channel for recording (set it to "REC") simultaneously holding down the [REC] button and pressing the appropriate button  $[1 \blacktriangle \nabla]$  -

[8▲▼]. Several channels can be selected at the same time.

**REC**..... Enables recording for the channel


ON ..... Enables playback of the channel


OFF..... Mutes the channel

To cancel or disable recording, press the [REC] button once

again.







#### J NOTE

The part is automatically selected when setting the several channels to "REC" at the same time.

**3** Select the part you want to assign to the channel to be recorded.

This determines which of the keyboard-played parts (Main/Layer/Left) and the accompaniment style parts (RHYTHM 1/2, BASS, etc.) are recorded to the

recording channels selected in step #2. For a list of the initial default assignments, see page 97.







Recording starts as soon as you play the keyboard.

You can also start recording by pressing the SONG/STYLE [START/STOP] button. The recording can be started/stopped by pressing the foot pedal if the recording punch in/out function is set to the pedal (page 104).





5

To stop recording, press the [REC] button again.

You can also use the foot pedal to stop recording by releasing it, if the recording punch in/out function has been assigned to the pedal (page 104).





Play back your new song.

To play back the performance you just recorded, return the song to the beginning by using the [TOP] button and press the SONG **[START/STOP]** button.

Playback stops automatically at the end of the song, and returns to the beginning of the song.





To record a new part, repeat steps 2 - 6 above.

You can set previously recorded parts to play back, and monitor them while you record a new part. Continue in this way until you have a finished song.

You can edit the recorded song data from the **SONG CREATOR (1 - 16)** displays (page 108).

Press the  $[6\nabla]$  button from the Open/Save display for Song to store the recorded data (page 38, 47).

#### - D NOTE

When selecting the MIDI part

Setting a single channel to MIDI

All incoming data received via any of the MIDI channels 1 - 16 is recorded. When using an external MIDI keyboard or controller to record, this lets you record without having to set the MIDI transmit channel on the external device.

Setting several channels to MIDI

When using an external MIDI keyboard or controller to record, this records data only over the set MIDI channel — meaning the external device must also be set to the same channel.

#### ) NOTE

A single part (with the exception of MIDI parts) cannot be assigned to several channels.

#### ♪ NOTE

The settings of the recorded parts is stored temporarily until you execute Quick Recording, select a song, or turn the power off.

### J) NOTE

To pause, press the SONG [START/STOP] button. To resume recording, press the SONG [START/STOP] button again.

#### ♪ NOTE

You can also use the metronome click as a guide while recording.

The sound of the metronome is not recorded.

## Recording Individual Notes — Step Record


This method lets you create a song by entering notes one by one, without having to perform them in real time. This is also convenient for recording the chords and the melody separately.

## **Operation**


Select an existing song (page 79, 81) to which you want to add parts or re-record. If you want to create a new song, simultaneously press the [REC] button and the [TOP] button.



Press the [DIGITAL RECORDING] button.




**3** Press the [A] button to call up the Song Creator display.




Using the [BACK]/[NEXT] buttons, select the "1-16" tab for recording melodies and other parts, or select the "CHD" (Chord) tab for recording chords, and after selecting the "1 - 16" tab, select a record channel

with the [F] (CH) button.





Call up the Step Record display by pressing the [G] button.




#### J NOTE

Any voice, effect and other settings you make in the Mixing Console are automatically cancelled when you call up the CHD (Chord) page.

#### 'Y NOTE -

The voices in the USER and FLOPPY DISK pages cannot be selected for Step recording. You can select voices from the PRESET page; however, these may sound slightly different from the original voice.










To close the STEP RECORD display, press the [EXIT] button. Make sure to store the recorded data by pressing the [I] (SAVE) button (page 47).

#### ■ Bar/Beat/Clock



### **■** Velocity

The table below shows the available settings and the corresponding velocity values.

ı	Kbd. Vel	fff	ff	f	mf	mp	р	pp	ppp
	Actual playing strength	127	111	95	79	63	47	31	15

#### **■** Gate Time


The following settings are available:

Normal	80%
Tenuto	] 99%
Staccato	40%
Staccatissimo	20%

## **Recording Melodies** — Step Record (Note)

In this section, we'll show you how to use Step Recording by guiding you through this actual music example, shown at right. The operations here apply to step 6 on page 100.





#### ■ Play back the newly created melody

♪ NOTE

Use the **[C]** (**\( )**) button to move the cursor to the beginning of the song, and press the SONG **[START/STOP]** button to hear the newly entered notes. To actually enter the recorded data, press the **[EXIT]** button. The entered data can be edited from the **SONG CREATOR** (**1 - 16**) display (page 108).

To input rests, simply move the measure/beat/clock location for the desired rest time, then input the next note.


# Recording Chord Changes for the Auto Accompaniment — Step Record (Chord)

The Chord Step recording feature makes it possible to record auto accompaniment chord changes one at a time with precise timing. Since the changes don't have to be played in real time, you can easily create complex, tight chord changes — over which you can record the melody in normal fashion.

The operations here apply to step 6 on page 100.


## **Entering Chords and Sections (Chord Step)**

For example, you can input the following chord progression by the procedure described below.





Enter the chords by using the currently selected chord fingering method in the Auto

Accompaniment section of the keyboard.









### ■ Play back the newly created chord progression

Use the **[C]** (**A**) button to move the cursor to the beginning of the song, and press the SONG **[START/STOP]** button to hear the newly entered notes. To actually enter the recorded data, press the **[EXIT]** button. The entered data can be edited from the **SONG CREATOR** (**CHD**) display (page 109). Finally, press the **[F]** (**EXPAND**) button from the **SONG CREATOR** (**CHD**) display in order to convert the input data into song data.

#### -D NOTE

To enter a fill-in, press the **[AUTO FILL IN]** button and press one of the **MAIN [A]**–**[D]** buttons.

#### J NOTE

#### **END Mark**

An "END" mark is shown in the display, indicating the end of the song data.

The actual position of the End mark differs depending on the section that is input at the end of the song. When an Ending section is input, the End mark automatically follows the Ending data. When a section other than Ending is input, the End mark is set two measures after the final section.

The End mark can be freely set to any position desired.

# Select the Recording Options: Starting, Stopping, Punching In/Out — Rec Mode

From this display you can set up how recording is started and stopped for either Quick Recording or Multi Recording. To call up these settings, select the REC MODE display by using the **[BACK][NEXT]** button, after performing operation steps 1 - 3 on page 99.

These settings determine how recording will start.

#### Normal

Overwrite recording starts when you press the SONG [START/STOP] button or when you play the keyboard with Synchro standby set to ON.

#### First Key On

Overwrite recording starts as soon as you start playing the keyboard. This setting also preserves the previous lead-in data, letting you record over the original lead-in without erasing it.

#### Punch In At

The song plays back normally up to the indicated Punch In measure (set by the [3▲▼] buttons), then starts overwrite recording at that Punch In measure.

Determines the measure at which Punch In overwrite recording starts (when "PUNCH IN AT" is selected).

Calls up the **SONG** display, from which you can save the edited data.

Determines the Punch Out measure — the measure at which Punch In overwrite recording stops (when "PUNCH OUT AT" is selected).

When this is set to ON, you can use the foot pedal 2 to control the punch-in and punch-out points. (The current function assignment of the foot pedal is cancelled.) Press and hold down the foot pedal to record. Recording stops when you release the pedal.

These settings determine how recording will stop as well as what happens to previously recorded data.

This deletes all data following the point at which recording is stopped.

#### **Punch Out**


This maintains all data following the point at which recording is stopped.

#### **Punch Out At**

Overwrite recording continues until the indicated Punch Out measure (set by the **[6 V**] buttons), then stops at that Punch Out measure, after which song playback continues normally.

### **About Punch In/Out**

This feature is useful primarily for re-recording or replacing a specific section of an already recorded channel. The illustrations below indicate a variety of situations in which selected measures in an eight-measure phrase are re-recorded.



- \*1 When measures 1 2 are not overwritten, recording starts from measure 3.
- \*2 You'll have to press the [REC] button at the end of 5 measures.

Previously recorded data

Newly recorded data

Deleted data

## **Editing a Recorded Song**

Whether you've recorded a song using Quick Recording, Multi Recording, or Step Recording, you can use the editing features to change the song data.

## **Editing Channel-related Parameters — Channel**


Calling up the operations here apply to step 4 on page 99. To call up the display shown below, use the **[BACK]/[NEXT]** buttons.

### Quantize

Quantize lets you "clean up" or tighten the timing of a previously recorded channel. For example, the following musical passage has been written with exact quarter-note and eighth-note values.




Even though you think you may have recorded the passage accurately, your actual performance may be slightly ahead of or behind the beat. Quantize allows you to align all the notes in a channel so that the timing is absolutely accurate to the specified note value (see below).




#### ■ About Quantize Size

Set the Quantize size to correspond to the smallest notes in the channel you are working with. For example, if the data was recorded with both quarter notes and eighth notes, use 1/8 note for the Quantize size. If you apply a 1/4 note Quantize size, the eighth notes would be moved on top of the quarter notes.




### **Delete**

This lets you delete recorded data in the specified channel.




### Mix

This function lets you mix the data of two channels and place the results in a different channel. It also lets you copy the data from one channel to another.




## **Channel Transpose**

This allows you to transpose the recorded data of individual channels up or down by a maximum of two octaves in semitone increments.



## Set Up

You can change the initial settings of the song — such as voice, level, and tempo — to the current settings of the mixing console or panel controls.




Determines which playback features and functions will be automatically called up along with the selected song. All events, with the exception of "KEYBOARD VOICE," can be recorded only at the beginning of the song.

Before you select or checkmark any of these items (other than Keyboard Voice), make sure to return the song to the beginning by using the **[TOP]** button, and stop playback.

•	Stores the tempo setting and all settings made from the Mixing Console This lets you automatically set the voice of the keyboard-played parts (Main/Layer/Left) when playing back the song. Stores the keyboard-played voice and the part ON/OFF settings. To record a voice change for the keyboard-played part in the middle of a song, stop the song at the desired point, make the voice change, and press the [D] (EXECUTE) button.
Score Setting	Stores the settings of the Lyrics display Stores the settings of the Score display (PSR-2100 only) Stores the microphone settings in the mixing console (PSR-2100 only).

## Editing Note Events — 1 - 16

From this display, you can edit individual note events (see below). Calling up operations here apply to step 4 on page 99. Use the **[BACK]/[NEXT]** buttons to call up the display below.



#### **Note Events**

Parameter	Description
Note	Determines the pitch, velocity (volume) and length of the note.
Ctrl (Control change)	Determines the control change number and value. For details on control change messages, refer to the separate Data List booklet (MIDI Data Format).
Prog (Program change)	Determines the voice (program) number. For details on program change messages and how to set them, refer to the separate Data List booklet (Voice List).
P.Bnd (Pitch bend)	Determines the pitch bend value.
A.T. (After touch)	Determines the after touch value.


#### 1) NOTE

The sound of the voices recorded with Step recording may sound slightly different from the original.

## **Editing Chord Events — CHD**

From this display, you can edit the chord events you've recorded to the song.

Calling up operations here apply to step 4 on page 99. Use the **[BACK]/[NEXT]** buttons to call up the display below. With the exception of the **[F] (EXPAND)** button, the operations here are the same as those in Editing Note Events (page 108).




#### **Chord Events**

Parameter	Description
Style (Accompaniment style)	Displays the accompaniment style name. To enter an accompaniment style, call up the <b>STYLE</b> display and select the desired style.
Tempo	Determines the tempo value.
Chord	Specifies the chord — its root note, chord type, and on-bass note.
Sect (Section)	Specifies the section — its name and variation.
OnOff (Channel on/off)	Determines whether specific channels (rhythm, bass, etc.) are turned on/off.
CH.Vol (Channel volume)	Determines the level of specific channels (rhythm, bass, etc.).
S.Vol (Style volume)	Determines the level of the entire accompaniment style.

## Editing System Events — SYS/EX. (System Exclusive)

From this display, you can edit recorded System events.

Calling up operations here apply to step 4 on page 99. Use the **[BACK]/[NEXT]** buttons to call up the display below. The operations here are the same as those in Editing Note Events (page 108).




#### **System Events**

Parameter	Description
ScBar (Score initial measure)	This determines the number of the top measure. The measure number is indicated in the MAIN display or in the music notation. Only one value can be specified at the beginning of the song data.
Tempo	Determines the tempo value.
Time (Time signature)	Determines the time signature.
Key	Determines the key, as well as the major/minor setting.
XG Prm (XG parameters)	Allows you to make various detailed changes to the data. For more information on XG parameters, refer to the separate Data List booklet (MIDI Data Format).
SYS/EX. (System Exclusive)	Displays the System Exclusive data in the song. This does not let you change the actual contents of the data; however, it lets you delete, cut, copy, and paste the data.
Meta (Meta event)	Displays the SMF meta events in the song. This does not let you change the actual contents of the data; however, it lets you delete, cut, copy, and paste the data.

## Inputting and Editing Lyrics

This convenient function lets you enter the song name and the lyrics for the song. It also lets you change or correct already existing lyrics. For more information on lyric events, see the chart below. Calling up operations here apply to step 4 on page 99. Use the **[BACK]/[NEXT]** buttons to call up the display below. The operations here are the same as those in Editing Note Events (page 108).

In the following example, we'll rewrite a portion of the lyrics to one of the songs, "Twinkle Twinkle Little Star." Select the internal song "Twinkle Twinkle Little Star." The method for selection is the same as described on pages 79 and 86.




#### **Lyrics Events**

Parameter	Description
Name (Song name)	Determines the song name. This calls up the NAME display, from which you can enter the name.
Lyrics	Allows you to enter lyrics.
Code (Other controls)	CR: Enters a line break in the lyrics text.
	LF: Deletes the currently displayed lyrics and displays the next set of lyrics.

## **Customizing the Event List — Filter**


This function lets you determine which event types will be shown in the event editing displays. To select an event for display, checkmark the box corresponding to the event name. To filter out an event so that it is not shown on the list, remove the checkmark so that the box is empty.

To call up the display below, press the **[H]** (**FILTER**) button from any of the following displays: CHD, 1 - 16, SysEX, or LYRICS (page 108 - page 110).



## Creating Accompaniment Styles — Style Creator

This powerful feature lets you create your own original styles, which can then be used for auto accompaniment — just as with the preset styles.



## **About Creating Accompaniment Styles**

The chart at right shows the basic parts (or "channels") that make up each section of an accompaniment style. To create an accompaniment style, record patterns to the various channels one by one, for each of the sections you want to create.

#### ■ Realtime Recording (page 113)

You can record accompaniment styles by simply playing the parts from the keyboard in real time. However, you don't have to record every part yourself — you can choose an existing preset accompaniment style that is close to the style you want, then add or replace parts in that style as needed to create your own custom style.

Section	Channel
INTRO A - D	
MAIN A - D	RHYTHM 1, RHYTHM 2,
FILL IN A - D	BASS, CHORD 1, CHORD 2, PAD,
BREAK	PHRASE 1, PHRASE 2
ENDING A - D	

#### 1) NOTE

For information on the part structure of accompaniment styles, see page 97.

#### **Realtime Recording Characteristics**

#### Loop recording

Since auto accompaniment playback repeats the accompaniment patterns of several measures in a "loop," you can also record patterns in a loop. For example, if you start recording with a two-measure Main section, the two measures are repeatedly recorded. Notes that you record will play back from the next loop (repetition), letting you record new material while hearing the parts you previously recorded.

#### Overdub recording

This feature lets you record new material to a channel already containing recorded data, without deleting the original data. In style recording, the recorded data remains intact, unless you specifically delete it yourself. For example, if you start recording with a two-measure Main section, the two measures are repeated. As you record notes to each pass of the loop (repetition), those notes play back from the next loop, letting you overdub new material while hearing the previous parts.

#### ■ Step Recording (page 114)


This method is like writing music notation on paper, since it allows you to enter each note or individually, and specify its length. This is ideal for making precise recordings, or for recording parts that are difficult to play.

#### ■ Assembling an Accompaniment Style (page 115)

This convenient feature lets you create composite styles by combining various patterns from the internal preset accompaniment styles. For example, if you want to create your own original 8-beat style, you could take rhythm patterns from the "8 Beat 1" style, use the bass pattern from "8 Beat 2," and import the chord patterns from the "60's 8 Beat" style — combining the various elements to create one accompaniment style.

#### ■ Editing the created Accompaniment Style (page 116)


With the editing features, you can custom edit the styles you've created by real time recording, step recording, and assembling from other styles.




## Style File Format


The Style File Format (SFF) combines all of Yamaha's auto accompaniment know-how into a single unified format. By using the edit functions, you can take full advantage of the SFF format and freely create your own styles. The chart at right indicates the process by which the accompaniment is played back. (This does not apply to the rhythm channels.) The basic or "source" pattern in the chart is the original style data. This source pattern is recorded using accompaniment style recording (see below).

As shown in the chart at right, the actual output of the accompaniment is determined by various parameter settings and chord changes (played in Auto Accompaniment section of the keyboard) entered to this source pattern.









5 Call up the Style display by pressing the [I] (SAVE) button (in Assembly page: [J] button), then save the recorded / edited data to the USER or FLOPPY DISK page.





Press the [EXIT] button to close the STYLE CREATOR display.

## Realtime Recording — Basic

You can use the Realtime Recording features to create your own accompaniment style — either from scratch or based on the preset accompaniment data. The operations here apply to step 4 on page 112.

Select the desired channel for recording by simultaneously holding down the [F] (REC CH) button and pressing the appropriate [1▲▼] - [8▲▼] button.

Before recording to one of the non-rhythm channels (BASS - PHR 2), make sure to delete the existing data of the appropriate channel. You can make other settings (see the box "Other Parameters in the BASIC page" on page 114) after closing the REC CHANNEL display by pressing the [EXIT] button. To call up the REC CHANNEL display again, press the [F] (REC CH) button.

Calls up the display for changing the **tempo** or **beat** (time signature).

Selects an empty style,

allowing you to create a

new style from scratch.

Available only when the channel is set to

recording. Simultaneously hold down this

button and press the key corresponding to

[RHY1] or [RHY2], this lets you delete

specific percussion sounds during

the instrument you want to delete.

When this button is pressed, "DELETE" will appear over channels containing data. To delete data from a specific channel, simultaneously hold down this button and press the appropriate [1 $\triangle$ ] - [8 $\triangle$ ] button. To release or cancel the

STYLE CREATOR: HeartBeat

BASIC (INSENDER) CHINNEL PARAMETER EDIT

SECTION: HAIN A
PATTERN LENGTH:4

TEMPO: 148

BEAT: 4/4

BEAT: 4/4

BEAR: 1

REG CHANNEL

RHY20 BASSO CHD10 CHD20 PAD0 PHR10 PHR20

RRY20 BASSO CHD10 CHD20 PAD0 PHR10 PHR20

selection, press the [1▼] [8▼] button corresponding to the channel you wish to cancel. As long as you continue to hold down the [J] button, you can toggle between deleting and restoring the selected data. Releasing the [J] button permanently deletes the data. Before recording to one of the non-rhythm channels (BASS - PHR 2). make sure to delete the existing data of the appropriate channel.

**REC**.... Channel is enabled for recording. **ON**..... Channel is enabled for playback.

OFF .... Channel is muted.



**2** First, select the desired voice. Start recording by pressing the STYLE [START/STOP] button.

The selected section of the style starts playing back. Since the rhythm pattern loops repeatedly, you can record new sounds and notes on each pass while listening to the pattern. Icons above the keys conveniently indicate the percussion instruments assigned to the keys.

#### J NOTE

If you've enabled Sync Start (by pressing the **SYNC**. **START** button), you can start recording by simply pressing a key on the keyboard.



**3** Stop recording by pressing the STYLE [START/STOP] button again.





With the REC CHANNEL display shown, close the display by pressing the [EXIT] button.

#### J. NOTE

- Only Drum Kit/SFX Kit can be selected for the RHY 2 channel.
- For the non-rhythm channels (BASS - PHR 2), allvoices with the exception of the Organ Fultes voice/ Drum Kit/SFX Kit can be selected.

#### Other Parameters in the Basic Display

#### [I] (SAVE) button

Calls up the Style display for saving the accompaniment style data.

#### $[3 \blacktriangle \blacktriangledown][4 \blacktriangle \blacktriangledown]$ (Section) buttons

Determines the section to be recorded.

#### $[5 \blacktriangle \blacktriangledown][6 \blacktriangle \blacktriangledown]$ (Pattern Length) buttons

Determines the length of the selected section's pattern in measures (1 - 32). The Fill In/Break section is fixed at a length of one measure.

#### [D] (Execute) button

Executes the Pattern Length change.

#### D NOTE

You can also select the desired section for recording by pressing appropriate panel button. Pressing one of the Section buttons calls up the SECTION display, from which you can change sections by using the [6▲▼]/
[7▲▼] buttons. To actually enter the change, press the [8▲] button.To select the Fill In section, press the [AUTO FILL IN] button.

#### **Recording** — **Precautions**

• The basic chord used for the accompaniment style is called the source chord. All chords that play and the pitches that sound are derived from the source chord. When recording the Main and Fill In sections (for a source chord of CM7), keep the following points in mind:




- C = chord note C, R = recommended note
- \* When recording to the Bass or Phrase channels, try to use only the recommended notes; this will ensure that you can play various chords with the accompaniment style and get optimum results. (Other notes may work, providing you use them as short passing tones.)
- \* When recording to the Chord or Pad channels, use only the notes of the CM7 chord; this will ensure that you can play various chords with the accompaniment style and get optimum results. (Other notes may work, providing you use them as short passing tones.)

The source chord is set by default to CM7; however, you can change this to any chord you prefer. Refer to the section "Making Style File Format Settings – Parameter" on page 119.

• When recording Intro and Ending sections, you can ignore the source chord and use any notes or chord progressions you like. In this case, if you set the NTR parameter to "ROOT TRANSPOSE" and NTT to "HARMONIC MINOR" or "MELODIC MINOR" (in the PARAMETER page), the normal pitch conversions that would result from playing different chords are cancelled (for playback) — meaning that the accompaniment pitch conversion will only occur for changes in the root note or major/minor shifts.

## **Step Recording**

With this method, you can create a style pattern by entering notes and other data individually, without having to perform them in real time. The operations here apply to step 4 on page 112.



The actual recording process is the same as in Step Recording of songs (page 99), with the exception of the points described below. You can also edit each event from the Edit page, and the editing process the same as in editing songs (page 108).

- In song recording, the end mark position can be changed freely. However, it cannot be changed when creating accompaniment styles. This is because the length of the accompaniment style is automatically fixed according to the selected section. For example, when creating an accompaniment style based on a four-measure section, the end mark position is automatically set to the end of the fourth measure, and cannot be changed from the Step Record screen.
- When editing the data recorded on the Edit page, you can switch between the type of data you want to edit (event data or control data). Press the [F] (TRACK EVT) button to switch between the Event display (Note, Control Change, etc.) and the Control display (System Exclusive, etc.).


Make sure to set the record channel from another display (e.g., BASIC display; page 112) beforehand.


## Assembling an Accompaniment Style —Assembly

This convenient function lets you combine accompaniment elements — such as rhythm, bass, and chord patterns — from existing styles, and use them to create your own original accompaniment styles. The operations here apply to step 4 on page 112.

These let you select the accompaniment style that will be used for each channel of your original style. Select the desired channel by pressing the [A] – [D], [F] – [I] buttons and press the same button to call up the **Style** screen, from which you can select the accompaniment style.

After repeating steps 1 and 2 as desired, press the [J] (SAVE) button to save the assembled style data. From here, you can store the settings of all channels (RHYTHM 1, RHYTHM 2, BASS, etc.) to a single accompaniment style.





2 Selects the style section and channel that will be copied to the corresponding channels, selected with the [A]-[D] and [F]-[I] buttons above.

#### ) NOTE

If you change the section and channel in steps #1 and #2, the currently specified section and channel are also changed. The channels being recorded are also changed and recording is stopped automatically.

#### J NOTE

The PLAY TYPE parameter affects only the playback, and does not change the actual accompaniment style data.

Determines the playback settings for each channel. You can assemble the accompaniment style while the style section and channel that will be copied are playing.

SOLO .......Mutes all but the selected channel. RHYTHM channels set to REC in the REC CHANNEL display (page 114) are played back simultaneously.


**ON** ......Plays back the selected channels. Any channels set to ON in the REC CHANNEL display (page 113) are played back simultaneously.

## **Edit the Created Accompaniment Style**

## Change the Rhythmic Feel — Groove and Dynamics

These versatile features give you a wide variety of tools for changing the rhythmic feel of your created accompaniment style. The operations here apply to step 4 on page 112.


#### **■** Groove



#### **Groove parameters**

Original Beat	Specifies the beats to which Groove timing is to be applied. In other words, if "8 Beat" is selected, Groove timing is applied to the 8th notes; if "12 Beat" is selected, Groove timing is applied to 8th-note triplets.
Beat Converter	Actually changes the timing of the beats (specified in the ORIGINAL BEAT parameter above) to the selected value. For example, when ORIGINAL BEAT is set to "8 Beat" and BEAT CONVERTER is set to "12," all 8th notes in the section are shifted to 8th-note triplet timing. The "16A" and "16B" Beat Converter which appear when ORIGINAL BEAT is set to "12 Beat" are variations on a basic 16th-note setting.
Swing	Produces a "swing" feel by shifting the timing of the back beats, depending on the ORIGINAL BEAT parameter above. For example, if the specified ORIGINAL BEAT value is 8th notes, the Swing parameter will selectively delay the 2nd, 4th, 6th, and 8th beats of each measure to create a swing feel. The settings "A" through "E" produce different degrees of swing, with "A" being the most subtle and "E" being the most pronounced.
Fine	Selects a variety of Groove "templates" to be applied to the selected section. The "PUSH" settings cause certain beats to be played early, while "HEAVY" settings delay the timing of certain beats. The numbered settings (2, 3, 4, 5) determine which beats are to be affected. All beats up to the specified beat —but not including the first beat — will be played early or delayed (for example, the 2nd and 3rd beats, if "3" is selected). In all cases, "A" types produce minimum effect, "B" types produce medium effect, and "C" types produce maximum effect.

#### **■** Dynamics



#### **Dynamics parameters**

Accent Type	Selects the type of accent.
Strength	Determines how strongly the selected Accent Type (above) will be applied. The higher the value, the stronger the effect.
Expand/Compress	Expands or compresses the range of velocity values, around a central velocity value "64." Values higher than 100% expand the dynamic range, while values lower than 100% compress it.
Boost/Cut	Boosts or cuts all velocity values in the selected section/channel. Values above 100% boost the overall velocity, while values below 100% reduce it.

#### 1) NOTE


**Velocity** is determined by how strongly you play the keyboard.

The more strongly you play the keyboard, the higher the velocity value and, hence, the louder the sound.

## **Editing the Channel Data**

In this display, there are five different channel-related edit functions, including Quantize, for editing the recorded accompaniment style data. The operations here apply to step 4 on page 112.

See the explanations below.



Preset channel BASS-PHRASE 2 can not be edited.

#### **■** Quantize

Refer to page 105.

#### **■** Velocity Change

Boosts or cuts the velocity of all notes in the specified channel (selected with the  $[1 \triangle \nabla]/[2 \triangle \nabla]$  (CHANNEL) buttons), according to the specified percentage (selected with the  $[4 \triangle \nabla]/[5 \triangle \nabla]$  (BOOST/CUT) buttons).

#### **■** Bar Copy

This function allows data to be copied from one measure or group of measures to another location within the specified channel. Use the  $[4\Delta \nabla]$  (TOP) and  $[5\Delta \nabla]$  (LAST) buttons to specify the first and last measures in the region to be copied. Use the  $[6\Delta \nabla]$  (DEST) button to specify the first measure of the destination location, to which the data is to be copied.

#### ■ Bar Clear


This function clears all data from the specified range of measures within the selected channel. Use the  $[4 \triangle \nabla]$  (TOP) and  $[5 \triangle \nabla]$  (LAST) buttons to specify the first and last measures in the region to be cleared.

#### ■ Remove Event

This function lets you remove specific events from the selected channel. Use the  $[4 \triangle \nabla]$  -  $[6 \triangle \nabla]$  (EVENT) buttons to select the desired event type to be removed.

## Making Style File Format Settings — Parameter

This display provides a variety of style controls—such as determining how the pitch and sound of the recorded style change when playing the chords in the left-hand range of the keyboard. For details about the relationship between the parameters, refer to "Style File Format" on page 112. The operations here are the same as described in step 4 on page 112.




When NTR is set to "Root Fixed" and NTT is set to "Bypass," the "Source Root" and "Source Chord" parameters are changed to "Play Root" and "Play Chord," respectively. In this case, you can change chords and hear the resulting sound for all channels.

#### ■ Source Root/Chord

These settings determine the original key of the source pattern (i.e., the key used when recording the pattern). The default setting of CM7 (with a Source Root of "C" and a Source Type of "M7"), is automatically selected whenever the preset data is deleted prior to recording a new style, regardless of the Source Root and Chord included in the preset data. When you change Source Root / Chord from the default CM7 to another chord, the chord notes and recommended notes will also change, depending on the newly selected chord type. For details on chord notes and recommended notes, see page 114.

#### When the Source Root is C:



#### ■ NTR (Note Transposition Rule) and NTT (Note Transposition Table)

• NTR (Note Transposition Rule)

This determines the system for pitch conversion of the source pattern. Two settings are available.

#### **Root Trans (Root Transpose)**

When the root note is transposed, the pitch relationship between notes is maintained. For example, the notes C3, E3 and G3 in the key of C become F3, A3 and C4 when they are transposed to F. Use this setting for channels that contain melody lines.



#### **Root Fixed**

The note is kept as close as possible to the previous note range. For example, the notes C3, E3 and G3 in the key of C become C3, F3 and A3 when they are transposed to F. Use this setting for channels that contain chord parts.



#### • NTT (Note Transposition Table)

This sets the note transposition table for the source pattern. Six transposition types are available.

#### **Bypass**

No transposition.

#### Melody

Suitable for melody line transposition. Use this for melody channels such as **Phrase 1** and **Phrase 2**.

#### Chord

Suitable for chord transposition. Use for the **Chord 1** and **Chord 2** channels, especially when they contain piano or guitar-like chordal parts.

#### **Bass**

Suitable for bass line transposition. This table is basically similar to the Melody table above, but recognizes on-bass chords allowed in the **FINGERED ON BASS** fingering mode. Use this primarily for bass lines.

#### **Melodic Minor**

When the played chord changes from a major to a minor chord, this table lowers the third interval in the scale by a semitone. When the chord changes from a minor to a major chord, the minor third interval is raised by a semitone. Other notes are not changed.

#### **Harmonic Minor**

When the played chord changes from a major to a minor chord, this table lowers the third and sixth intervals in the scale by a semitone. When the chord changes from a minor to a major chord, the minor third and flatted sixth intervals are raised by a semitone. Other notes are not changed.

#### **■** High Key/Note Limit

#### • High Key


This sets the highest key (upper octave limit) of the note transposition for the chord root change. Any notes calculated to be higher than the highest key are transposed down to the octave just below the highest key. This setting is effective only when the NTR parameter (page 119) is set to "Root Trans."

# Example — When the highest key is F Root changes CM C<sup>†</sup>M · · · FM F<sup>†</sup>M · · · Notes played C3-E3-G3 C<sup>†</sup>3-F3-G<sup>†</sup>3 F3-A3-C4 F<sup>†</sup>2-A<sup>†</sup>2-C<sup>†</sup>3 \*\*#\$

#### • Note Limit

This sets the note range (highest and lowest notes) for voices recorded to the style channels. By judicious setting of this range, you can ensure that the voices sound as realistic as possible — in other words, that no notes outside the natural range are sounded (e.g., high bass sounds or low piccolo sound). The actual notes that sound are automatically shifted to the set range.

#### Example — When the lowest note is C3 and the highest is D4



#### ■ RTR (Retrigger Rule)

These settings determine whether notes stop sounding or not and how they change pitch in response to chord changes.

#### Stop

The notes stop sounding.

#### **Pitch Shift**

The pitch of the note will bend without a new attack to match the type of the new chord.

#### **Pitch Shift to Root**

The pitch of the note will bend without a new attack to match the root of the new chord.

#### Retrigger


The note is retriggered with a new attack at a new pitch corresponding to the next chord.

#### **Retrigger To Root**

The note is retriggered with a new attack at the root note of the next chord. However, the octave of the new note remains the same.


## Creating Multi Pad — Multi Pad Creator


The PSR-2100/1100 lets you create your own original Multi Pad phrases — which you can use in your performances in the same way as the preset Multi Pads.




## **Operation**

1 Select the desired Multi Pad Bank for editing. To record a new Multi Pad from scratch, call up the RECORD page in the Multi Pad Creator display and select "New Bank" by pressing the [C] (NEW BANK) button.





Record and Edit the Multi Pad. For details on the operations for each display, refer to the explanations starting on the next page.



Call up the Multi Pad display by pressing the [I] (SAVE) button, then save the recorded / edited data to the USER or FLOPPY DISK page.






Press the **[EXIT]** button to close the **MULTI PAD** display.

## Multi Pad Realtime Recording — Record

The operations here apply to step 4 on page 121.



## Start recording

First, select the desired voice. Press the **[H]** (**REC**) button to set the Record standby mode. Recording begins automatically as soon as you play on the keyboard. You can also start recording by pressing the **STYLE** [**START**] button. If Chord Match (see below) is set to on for the Multi Pad to be recorded, you should record using the notes of the C major seventh scale (C, D, E, G, A and B).



C = chord note
C, R = recommended note
Others: non-recommended note

#### J NOTE

- Other notes besides those of the C major seventh scale can be recorded; however, this may result in the recorded phrase not matching the chord when being played back.
- The rhythm part of the currently selected style is used as a rhythmic guide (in place of a metronome), playing back during recording. However, it is not recorded to the Multi Pad

## Stop recording

Press the [H] (STOP) button or the panel STYLE/MULTI PAD [STOP] button to stop recording when you've finished playing the phrase.

#### Turning Chord Match and Repeat On/Off

#### ■ Repeat


Unless the Repeat function is on for the selected pad, playback will end automatically as soon as the end of the phrase is reached. A phrase can be stopped while it is playing by pressing the MULTI PAD [STOP] button.

#### Chord Match

If a Multi Pad is played while Style is playing and the Chord Match function for that pad is ON, the phrase will be automatically re-harmonized to match the accompaniment chords.

## Step Recording or Editing Multi Pads — Edit

With this method, you can create a Multi Pad by entering notes and other data individually, without having to perform them in real time. The operations here apply to step 4 on page 121.




The actual recording process is the same as in Step Recording of songs (page 99), with the exception of the points described below. You can also edit each event from the Edit page, and the editing process the same as in editing songs (page 108).

- Just as with Song Recording, the End Mark position can be changed freely in the Multi Pad Creator. This allows you to finely adjust the phrase length for the Pad. This would be convenient, for example, in synchronizing repeat playback of a Pad (set to Repeat On) with the keyboard and auto accompaniment playback.
- Since the Multi Pads have only one track (channel), the track (channel) cannot be changed.

# Adjust the Volume Balance and Changing Voices — Mixing Console

Set up just like a real mixing console, this display gives you comprehensive control over the sound.



#### 1) NOTE

#### **Mixing Console**

This set of controls lets you adjust the balance of the voices and their stereo position, as well as the amount of effect that is applied to each voice.

You can call up additional basic mixing controls by using the [BALANCE] button and the [CHANNEL ON/OFF] button (page 64).

## **Operation**

1



From the MIXING CONSOLE display, press the button repeatedly until the desired display is called up. Each press of the button switches among the displays listed below.

#### **PANEL PART**

Includes the keyboard-played parts (Main/ Layer, Left), accompaniment parts, song, microphone input (PSR-2100 only)

#### STYLE PART


Accompaniment parts

**SONG CH 1 - 8** 

Channels 1 - 8 of song playback

**SONG CH 9-16** 

Channels 9 - 16 of song playback



#### 1) NOTE

You can quickly and easily set all parts to the same value for the same parameter (except for the VOICE parameter). Simultaneously hold down the [A] -[J] button that corresponds to the parameter you want to change and use the [1] -[8] buttons or the [DATA ENTRY] dial to change the value.

#### ↑ NOTE

For details on parameters related to the **Sound Creator**, see page 91.



2

Select the other Mixing Console pages by using the [BACK]/[NEXT] buttons and set the desired parameters.

For information on the various parameters and settings and how to use them, refer to the explanations starting on page 125.





Close the **Mixing Console** display by pressing the **[EXIT]** button.

#### ■ About the parameters

VOL/VOICE (Volume/Voice) (page 125)

This contains settings related to the volume and voice of each part/channel. Here you can also enable the Auto Revoice feature — which automatically plays XG-compatible songs (page 162) with the rich and dynamic voices that are exclusive to the PSR-2100/1100. This gives you much more authentic and realistic instrument sounds for your song playback.

• FILTER (page 126)

These controls affect the tone quality of the voice, letting you add power, punch, or brightness to the sound.

• TUNE (page 126)

These give you various tuning controls.

• EFFECT (page 127)


These control the amount of effect applied to the sound.

• EQ (Equalizer) (PSR-2100 only) (page 130)

Determines the overall tone quality of the instrument, letting you adjust the sound to match the particular performance space. Also you can adjust the volume or tone quality for each part.

## Setting the Level Balance and Voice — Volume/Voice

The operations for this page apply to step 2 of the procedure on page 124.



#### D NOTE

The [RHY2] categories in the STYLE PART display are only for the Drum Kit/SFX Kit (percussion) voice.

#### J) NOTE

The [RHY1] channel in the STYLE PART display can be assigned to any voice except for the Organ Flutes voice.

#### ♪ NOTE


When playing GM song data, channel 10 (in the **SONG CH 9 - 16** page) can only be used for a Drum Kit voice.

#### D NOTE

When changing the rhythm/ percussion voices (drum kits, etc.) of the accompaniment style and song from the VOICE parameter, the detailed settings related to the drum voice are reset, and in some cases you may be unable to restore the original sound. In the case of song playback, you can restore the original sound by returning to the beginning of the song and playing back from that point. In the case of accompaniment style play, you can restore the original sound by selecting the same style again.




Keep in mind that using the Revoice function may result in unnatural or unexpected sound, depending on the particular song data.



## Changing the Tone of the Voice —

The operations for this page apply to step 2 of the procedure on page 124.




#### ♪ NOTE

For details about the Filter, see page 92.

#### J. NOTE


Be careful with these controls. Depending on the selected voice, extreme settings may result in noise or distortion.




HARMONIC ...... Allows you to adjust the resonance effect (see "Harmonic Content" on page 92). BRIGHTNESS .... Determines the brightness of the sound by adjusting the cutoff frequency (page 92).

## Changing Pitch-related Settings — Tune

The operations for this page apply to step 2 of the procedure on page 124.



Portamento is used to create a smooth transition in pitch from one note to the



These increase/decrease (transpose) the pitch in semitone units.

MASTER ... Transposes both the pitch of the keyboard and that of the song playback.


SONG...... Transposes the pitch of the song playback.

KBD ...... Transposes the pitch of the keyboard.

**PORTAMENTO TIME** ..............When the part is set to Mono (page 61, 91), this determines the Portamento time. The higher the value, the longer the time it takes for the pitch to change. Portamento is only applied when you play legato (playing the next note before releasing the previous one). PITCH BEND RANGE ...... Determines the range of the PITCH BEND wheel for the corresponding part. The range is from "0" to "12" with each step corresponding to one semitone. OCTAVE...... Determines the range of the pitch change in octaves, over two octaves up or down. The value of this parameter is added to the value set via the [UPPER OCTAVE] button. **TUNING**......Determines the pitch of the instrument.


## **Adjusting the Effects**


The operations for this page apply to step 2 of the procedure on page 124.




#### J) NOTE

There are three effect sections: Reverb, Chorus, and DSP (which contains a variety of effect types). For details, refer to the Effect Block list (page 128).







#### J NOTE

Keep in mind that in some cases noise may result if you adjust the effect parameters while playing the instrument.

#### **Effect Block**

Block	Parts	Characteristics	Number of User Effect
REVERB	All parts	Reproduces the warm ambience of playing in a concert hall or jazz club.	3
CHORUS	All parts	Produces a rich "fat" sound as if several parts are being played simultaneously.	3
DSP 1 (PSR-2100) DSP(PSR-1100)	Main, Layer, Left, Song (Ch. 1 - 16), MIC (PSR-2100 only), Style	In addition to reverb and chorus effects, this section features a variety of special effects, including distortion.	3
DSP2 - 4 (PSR-2100 only)	Main, Layer, Left, Song (Ch. 1 - 16), MIC (automatically assigned)	Any unused DSP blocks are automatically assigned to the remaining active parts.	10


## **Effect Structure**


The PSR-2100/1100 features the following digital effect systems. The effect type, depth, and various parameters can be set with the panel controls.

#### About the Effect Connections - System and Insertion

All the effect blocks are connected or routed in one of two ways: System or Insertion. System applies the selected effect to all parts, while Insertion applies the selected effect to one specific part. Reverb and Chorus are System effects, and DSP 2 - DSP 4 (PSR-2100 only) are Insertion effects. The DSP1/DSP effect, on the other hand, can be configured for either System or Insertion routing.

The illustration below shows how the various effect blocks are set up and traces the signal flow for the send/return controls set on the PSR-2100/1100.







## Setting the Equalizer—EQ (PSR-2100 only)

Usually an equalizer is used to correct the sound output from amps or speakers to match the special character of the room. The sound is divided into several frequency bands, allowing you to correct the sound by raising or lowering the level for each band. The equalizer allows you to adjust the tone or timbre of the sound to match the performance space, or to compensate for certain acoustic characteristics in your room. For example, you can cut some of the low range frequencies when playing on stages or in large studio spaces where the sound is too "boomy," or boost the high frequencies in rooms and close spaces where the sound is relatively "dead" and free of echoes. The PSR-2100 possesses a high grade five-band digital equalizer function. With this function, a final effect —tone control— can be added to the output of your instrument.

The operations for this page apply to step 2 of the procedure on page 124.










## Using a Microphone — MIC. (PSR-2100 only)

This extraordinarily powerful feature uses advanced voice-processing technology to automatically produce vocal harmony based on a single lead vocal. Four distinct harmony modes as well as an extensive selection of preset harmony types are provided. In addition to straightforward harmony, the PSR-2100 also lets you change the apparent gender of the harmony and/or lead vocal sound. For example, if you are a male singer, you can have the PSR-2100 automatically generate a two-part female backup. A comprehensive set of parameters gives you exceptionally precise and flexible control over the vocal harmony sound.



## Selecting a Vocal Harmony Type









Press the **[EXIT]** button to return to the previous display.

#### - NOTE


The saved settings can be named (page 44) or deleted (page 46) in the USER page.

#### **Vocal Harmony Parameter List**

Chordal Type/Vocoder Type	Determines how the harmony notes are applied.
Harmony Gender Type	Can be set to "Off" or "Auto". When "Auto", the gender of the harmony sound is changed automatically.
Lead Gender Type	Determines whether and how the gender of the lead vocal sound (i.e., the direct microphone sound) will be changed. When "Off" no gender change occurs. When "Unison", "Male" or "Female" is selected the corresponding gender change is applied to the lead vocal. (In this case the number of harmony notes which can be produced in addition to the lead vocal is reduced to one.)
Lead Gender Depth	Adjusts the degree of lead vocal gender change produced when one of the Lead Gender Types (above) is selected.
Lead Pitch Correction	When "Correct" is selected the pitch of the lead vocal is shifted in precise semitone steps. This parameter is only effective when one of the Lead Gender Types is selected.
Auto Upper Gender Threshold	Gender change will occur when the harmony pitch reaches or exceeds the specified number of semitones above the lead vocal pitch.
Auto Lower Gender Threshold	Gender change will occur when the harmony pitch reaches or exceeds the specified number of semitones below the lead vocal pitch.
Upper Gender Depth	Adjusts the degree of gender change applied to harmony notes higher than the Auto Upper Gender Threshold.
Lower Gender Depth	Adjusts the degree of gender change applied to harmony notes lower than the Auto Lower Gender Threshold.
Vibrato Depth	Sets the depth of vibrato applied to the harmony sound. Also affects the lead vocal sound if a Lead Gender Type is selected.
Vibrato Rate	Sets the speed of the vibrato effect.
Vibrato Delay	Specifies the length of the delay before the vibrato effect begins when a note is produced.
Harmony1 Volume	Sets the volume of the first harmony note.
Harmony2 Volume	Sets the volume of the second harmony note.
Harmony1 Pan	Specifies the stereo (pan) position of the first harmony note. When "Random" is selected the stereo position of the sound will change randomly whenever the keyboard is played.
Harmony2 Pan	Specifies the stereo (pan) position of the second harmony note. When "Random" is selected the stereo position of the sound will change randomly whenever the keyboard is played.
Harmony1 Detune	Detunes the first harmony note by the specified number of cents.
Harmony2 Detune	Detunes the second harmony note by the specified number of cents.
Pitch to Note	When "ON" the lead vocal sound "plays" the PSR-2100 tone generator system. (However, dynamic changes in the vocal sound do not affect the volume of the tone generator.)
Pitch to Note Part	Determines which of the PSR-2100 parts will be controlled by the lead vocal when the Pitch to Note parameter is "ON".


## Making Settings for the Vocal Harmony and Microphone — MICROPHONE SETTING

### **Operation**



## Adjusting the Vocal Harmony Settings and Microphone Effects — OVERALL SETTING

The explanations here apply to step 2 above.



#### ■ 3BAND EQ (3-BAND EQUALIZER)

Usually an equalizer is used to correct the sound output from amps or speakers to match the special character of the room. The sound is divided into several frequency bands, allowing you to correct the sound by raising or lowering the level for each band. The PSR-2100 features a high grade three-band digital equalizer function for the microphone sound.

**Hz** ...... Adjusts the center frequency of the corresponding band.

**dB**......Boosts or cuts the level of the corresponding band by up to 12 dB.

#### **■ NOISE GATE**

This effect mutes the input signal when the input from the microphone falls below a specified level. This effectively cuts off extraneous noise, allowing the desired signal (vocal, etc.) to pass.

**SW**.............. "SW" is the abbreviation of Switch. This turns Noise Gate on or off.

**TH.** "TH." is the abbreviation of Threshold. This adjusts the input level at which the gate begins to open.

#### **■** COMPRESSOR

This effect holds down the output when the input signal from the microphone exceeds a specified level. This is useful when recording a signal with widely varying dynamics. It effectively "compresses" the signal, making soft parts louder and loud parts softer.

**SW**......" "SW" is the abbreviation of Switch. This turns Compressor on or off.

**TH.** "TH." is the abbreviation of Threshold. This adjusts the input level at which compression begins to be applied.

**RATIO** ...... This adjusts the compression ratio.

**OUT** ..... Adjusts the final output level.

#### ■ VOCAL HARMONY CONTROL

The following parameters determine how the harmony is controlled.

#### **VOCODER CONTROL**

The Vocal Harmony effect is controlled by note data — the notes you play on the keyboard and/or the notes of the song data. This parameter lets you determine which notes are used to control the harmony.

#### SONG CHANNEL

#### **MUTE/PLAY:**

When set to "MUTE," the channel selected below is muted (turned off) during keyboard performance or song playback.

#### OFF:

Song data control over harmony is turned off.

#### 1-16:

When playing back a song from disk or external MIDI sequencer, the note data recorded to the assigned song channel controls the harmony.

#### • KEYBOARD

**OFF:** Keyboard control over harmony is turned off.

**UPPER:** Notes played to the right of the split point control the harmony.

**LOWER:** Notes played to the left of the split point control the harmony.

#### **BALANCE**

This lets you set the balance between the lead vocal (your own voice) and Vocal Harmony. Raising this value increases the volume of the Vocal Harmony and decreases that of the lead vocal. When this is set to L<H63 (L: Lead Vocal, H: Vocal Harmony), only the Vocal Harmony is output; when it is set to L63>H, only the lead vocal is output.

#### MODE

All of the Vocal Harmony types fall into one of three modes which produce harmony in different ways. The harmony effect is dependent on the selected Vocal Harmony Mode and Track, and this parameter determines how the harmony is applied to your voice. The three modes are described below.

#### **VOCODER:**

The harmony notes are determined by the notes you play on the keyboard (Main, Layer and Left) and/ or song data which includes Vocal Harmony tracks.

#### CHORDAL:

During accompaniment playback, chords played in the auto accompaniment section of the keyboard control the harmony. During song playback, chords contained in song data control the harmony. (Not available if the song does not contain any chord data.)

#### **AUTO:**

When the auto accompaniment or Left part is set to ON and if chord data exists in the song, the mode is automatically set to CHORDAL. In all other cases, the mode is set to VOCODER.

#### **CHORD**

The following parameters specify the song data which will be used for chord detection.

**OFF:** Chords are not detected.

**XF:** Chords of XF format are detected.

**1-16:** Chords are detected from note data in the specified song channel.

#### ■ MIC (MICROPHONE)

The following parameters determine how the microphone sound is controlled.


MUTE ...... When set to OFF, the microphone sound is turned off.

**VOLUME** ...... Adjusts the volume of the microphone sound.


## Setting the Microphone Volume and Related Effects — TALK SETTING

Determines the settings when the [TALK] button is on. The explanations here apply to step 2 on page 133.

#### VOLUME/PAN/REVERB DEPTH/CHORUS DEPTH/TOTAL VOLUME ATTENUATOR





#### **DSP/TYPE/DEPTH**



## Making Global and Other Important Settings — Function

The Function mode gives you access to various advanced functions related to the instrument as a whole. These sophisticated functions let you customize the PSR-2100/1100 to your own musical needs and preferences.





#### Adjusting the Pitch and Tuning — Master Tune and Scale Tune

#### ■ Master Tune (page 138)

This allows you to make fine adjustments to the overall pitch of the instrument — letting you accurately match the tuning with that of other instruments.

#### ■ Scale Tune (page 138)

This determines the particular tuning system (or temperament) for the instrument. This is especially useful for playing period pieces, to match the tuning system used during specific musical eras.

#### Setting Song-related Parameters — Song Settings (page 140)

These allow you to set parameters related to song playback.

## Setting Auto Accompaniment-related Parameters — Style Setting, Split Point, and Chord Fingering

#### ■ Style Setting / Split Point (page 141)

These determine the auto accompaniment-related settings, and let you set the split point.

#### ■ Chord Fingering (page 142)

This determines the method for playing/indicating chords when using the auto accompaniment features. You can even check how to play the chord, since the individual notes are indicated in the display.

## Making Settings for the Pedals and Keyboard — Controller

#### ■ Pedal (page 142)

These settings determine how the connected foot pedals (including foot controllers and footswitches) are used. They can be assigned to a variety of functions, letting you control operations with your feet — such as turning the accompaniment style on/off, or triggering Fill In patterns.

#### ■ Keyboard / Panel (page 144)

These settings determine the touch sensitivity of the keyboard (how touch affects volume), the on/off status of the Modulation wheel (PSR-2100 only), and the pitch transpose settings (for the keyboard, song data, and entire instrument).

## Setting the Registration Sequence, Freeze, and Voice Set

#### ■ Registration Sequence (page 145)

This determines the order in which the Registration Memory presets (1 - 8) are called up — by using the [BACK][NEXT] buttons or the pedal.

#### ■ Freeze (page 145)

This lets you specify the settings you want to be maintained or left unchanged, even when changing Registration Memory presets.

#### ■ Voice Set (page 146)

This lets you determine whether certain voice-related settings (such as Effects, EQ, Harmony, etc.) are automatically called up or not when you select a voice.

#### Setting Harmony and Echo (page 146)

These let you set the type of Harmony or Echo effect applied to the keyboard-played voices, as well as the amount of effect.

#### **Making MIDI Settings**

#### ■ System (page 148)

These determine various system messages settings (such as Clock, Start/Stop, System Exclusive), as well as Local Control on/off.

#### ■ Transmit (page 149)

This determines how playback data is sent to connected MIDI devices — i.e., which parts are assigned to which MIDI Transmit channels. This also lets you specify the type of data to be transmitted over each channel.

#### ■ Receive (page 150)

This determines how the parts of the PSR-2100/1100 respond to data from connected MIDI devices — i.e., which parts are assigned to which MIDI Receive channels. This also lets you specify the type of data to be received over each channel.

#### **■** Root (page 150)

This determines the channel(s) recognized for the root notes, for use with the auto accompaniment.

#### ■ Chord Detect (page 150)

This determines the channel(s) recognized for the chords, for use with the auto accompaniment.

#### Other Settings — Utility

#### **■** Config 1 (page 151)

This page contains settings for Fade In/Out, Metronome, Parameter Lock, and the Tap sound.

#### **■** Config 2 (page 152)

From this page, you can adjust the display, and change the voice number indication.

#### ■ Disk (page 153)

From this page, you can format disks, and copy from disk to disk.

#### **■** Owner (page 154)

From this page, you can set the language of the instrument, and input your own name — which is shown automatically every time the power is turned on.


#### ■ System Reset (page 154)

This function restores the PSR-2100/1100 to its original factory settings. You can also specify which types of settings are to be restored, as well as store your own original settings for future recall.

## Fine Tuning the Pitch/Selecting a Scale — Master Tune/Scale Tune

The explanations here apply to step #3 of the procedure on page 136.

## Tuning the Overall Pitch — Master Tune





Determines the overall pitch of the PSR-2100/1100, from 414.8 - 466.8 Hz. Press the 4 or 5 [▲▼] buttons simultaneously to instantly reset the value to the factory setting of 440.0 Hz.

#### NOTE :

#### Hz (Hertz)


This unit of measurement refers to the frequency of a sound, and represents the number of times a sound wave vibrates in a second.

#### ) NOTE


The Tune function does not affect the Drum Kit or SFX Kit voices.

## Selecting a Scale — Scale Tune

Select the desired scale template.



Determines the base note for each scale. When the base note is changed, the pitch of the keyboard is transposed, yet maintains the original pitch relationship between the notes.



) NOTE

#### Cen

A unit of pitch equal to 1/100 of a semitone (100 cents = 1 semitone).

#### T) NOTE

You can register your original scale tunings to a REG-ISTRATION MEMORY button. To do this, checkmark "SCALE" in the REG-ISTRATION MEMORY display (page 87).

Selects which parts should be affected by the scale setting.

Select the part to be set by pressing 6 or 7 [▲▼] and set the function ON or OFF by pressing [▲▼]. Parts that are set to OFF remain in Equal Temperament

Determines the fine tuning of the selected note in 1-cent steps. Press the 4 or 5  $[\blacktriangle \blacktriangledown]$  buttons simultaneously to instantly reset the value to the factory setting.

Determines the note to be tuned and the amount of tuning. The tuning range is from "-64" through "0" to "+63." Each increment equals one cent (one "cent" is one hundredth of a semitone).

#### **Scale**

#### **■** Equal Temperament

The pitch range of each octave is divided equally into twelve parts, with each half-step evenly spaced in pitch. This is the most commonly used tuning in music today.

#### **■** Pure Major/Pure Minor

These tunings preserve the pure mathematical intervals of each scale, especially for triad chords (root, third, fifth). You can hear this best in actual vocal harmonies — such as choirs and acapella singing.

#### **■** Pythagorean

This scale was devised by the famous Greek philosopher and is created from a series of perfect fifths, which are collapsed into a single octave. The 3rd in this tuning are slightly unstable, but the 4th and 5th are beautiful and suitable for some leads.

#### ■ Mean-Tone

This scale was created as an improvement on the Pythagorean scale, by making the major third interval more "in tune." It was especially popular from the 16th century to the 18th century. Handel, among others, used this scale.

#### ■ Werckmeister/Kirnberger

This composite scale combines the Werckmeister and Kirnberger systems, which were themselves improvements on the mean-tone and Pythagorean scales. The main feature of this scale is that each key has its own unique character. The scale was used extensively during the time of Bach and Beethoven, and even now it is often used when performing period music on the harpsichord.

#### ■ Arabic

Use these tunings when playing Arabic music.


#### Pitch settings for each scale (in cents; example scale of C)

The values shown in this chart are actually rounded off to the nearest whole number for use on the instrument.

	С	C <sup>‡</sup>	D	E♭	E	F	F <sup>‡</sup>	G	<b>A</b> ,	Α	B <sup>,</sup>	В
Equal Temperament	0	0	0	0	0	0	0	0	0	0	0	0
Pure Major	0	-29.7	3.9	15.6	-14.1	-2.3	-9.4	2.3	-27.3	-15.6	18.0	-11.7
Pure Minor	0	33.6	3.9	15.6	-14.1	-2.3	31.3	2.3	14.1	-15.6	18.0	-11.7
Pythagorean	0	14.1	3.9	-6.3	7.8	-2.3	11.7	2.3	15.6	6.3	-3.9	10.2
Mean-Tone	0	-24.2	-7.0	10.2	-14.1	3.1	-20.3	-3.1	-27.3	-10.2	7.0	-17.2
Werckmeister	0	-10.2	-7.8	-6.3	-10.2	-2.3	-11.7	-3.9	-7.8	-11.7	-3.9	-7.8
Kirnberger	0	-10.2	-7.0	-6.3	-14.1	-2.3	-10.2	-3.1	-7.8	-10.2	-3.9	-11.7
Arabic1	0	0	-50	0	0	0	0	0	0	-50	0	0
Arabic2	0	0	0	0	-50	0	0	0	0	0	0	-50

## Setting Song-related Parameters — Song Settings

The explanations here apply to step #3 of the procedure on page 136.



#### NOTE:

#### **Quick Start**

On some commercially available song data, certain settings related to the song (such as voice selection, volume, etc.) are recorded to the first measure, before the actual note data. When Quick Start is set to "ON." the PSR-2100/1100 reads all initial non-note data of the song at the highest possible speed, then automatically slows down to the appropriate tempo at the first note. This allows you to start playback as quickly as possible, with a minimum pause for reading of data.

#### 1) NOTE

#### Channel

Refers to the MIDI channel (page 160). The channels are assigned as follows:

Song

1 - 16

Accompaniment Style 9 - 16

#### J NOTE


#### Phrase Mark

This data specifies a certain location in the song data.

## Setting Auto Accompaniment-related Parameters — Style Setting, Split Point, and Chord Fingering

The explanations here apply to step #3 of the procedure on page 136.

## Setting Auto Accompaniment-related Parameters — Style Setting and Split Point



These select the part to which the split point setting is applied: accompaniment, left-hand range, or both. Press the desired key for the split point while holding down one of these buttons. The pressed key is included in the range for the Auto Accompaniment section of the keyboard (ACMP) or the left-hand range (LEFT).

#### A+L (ACMP + LEFT)

Allows you to simultaneously set the split point for both the left-hand range and the Auto Accompaniment section of the keyboard.

#### NOTE:

#### **About Section Set**

When any of the Main A-D sections is not included in the accompaniment style data, the nearest section is automatically selected. For example, when Main D is not contained in the selected accompaniment style, Main C will be called up.



Allows you to set the split point for the left-hand range of the keyboard. A (ACMP)


Allows you to set the split point for the Auto Accompaniment section of the keyboard.

Determines the split points for the auto accompaniment (ACMP) and the left-hand range (LEFT). The same value can be set for both or for each independently, using buttons [F], [G], and [H] (see above). You can use these buttons by themselves to set the split point value.

Determines the default section that is automatically called up when selecting different accompaniment styles (when accompaniment is stopped).

Turns touch response for the accompaniment on/off. When this is set to "ON," the accompaniment volume changes in response to your playing strength (in the Auto Accompaniment section of the keyboard).

The PSR-2100/1100 lets you automatically enable Sync Stop (page 68) simply by quickly pressing/releasing keys in the Auto Accompaniment section of the keyboard. This parameter lets you set the length of the key-hold time.



#### Real Time

One Touch Setting is immediately called up when you press a section button.

#### **Next Bar**

One Touch Setting is called up at the next measure, after you press a section button.

You can determine whether the chord played in the chord section will sound or not in the Stop Accompaniment condition.

When this is set to "OFF," you can use the Chord Match function (page 122) with the Multi Pads or the Harmony effect (page 61) without having to playback a style.


#### NOTE:

#### Stop Accompaniment

When auto accompaniment is turned on and Synchro Start is off, you can play chords in the left-hand (accompaniment) section of the keyboard with the style stopped, and still hear the accompaniment chords.


#### **About Split Point**

Split point is the position on keyboard that separates the Auto Accompaniment section (ACMP) and left-hand section (LEFT) from the right-hand section (MAIN). The LEFT split point cannot be set lower than the ACMP split point, and the ACMP split point cannot be set higher than the LEFT split point.



## Setting the Fingering Method — Chord Fingering

This determines how the notes you play on the keyboard indicate or play the chords of the accompaniment. To learn how to play certain chords, use the convenient Chord Tutor function (see note below).



#### ♪ NOTE

The chord indication in the display applies to the Fingered method, regardless if another method is actually selected.

#### D NOTE


#### **Chord Tutor**

The Chord Tutor feature is essentially an electronic "chord book" that shows you appropriate fingerings for chords; it is useful when you want to play certain chords. Simply specify the desired chord via the [6▲▼] - [8▲▼] buttons, and the fingerings for the Fingered method are indicated in the display.

## Making Settings for the Pedals and Keyboard — Controller

The explanations here apply to step #3 of the procedure on page 136.

## Making Settings for the Pedals



#### **Pedal-controllable Functions**

VOLUME*	Allows you to use a foot controller (FOOT PEDAL 2 only) to control the volume.
SUSTAIN	When the pedal is pressed notes played have a long sustain. Releasing the pedal immediately stops (damps) any sustained notes.
SOSTENUTO	If you press and hold the pedal here, only the first note will be sustained (the note that you played and held when pressing the pedal). This makes it possible to sustain a chord, for example, while other notes are played staccato.
SOFT	Pressing the pedal subtly reduces the volume and slightly changes the timbre of notes played. It only applies to certain voices — PIANO, for example.
GLIDE	When the pedal is pressed the pitch changes, and then back to normal pitch when the pedal is released.
PORTAMENTO	The portamento effect (a smooth slide between notes) can be produced while the pedal is pressed. Portamento is produced when notes are played legato style (i.e., a note is played while the preceding note is still held). The portamento time can be set via the Mixing Console display (page 126).
PITCHBEND*	Bend notes up or down while pedal is pressed (FOOT PEDAL 2 only). Same as the PITCH BEND wheel.
MODULATION*	Applies a vibrato effect to notes played on the keyboard. The depth of the effect increases while pedal is pressed (FOOT PEDAL 2 only). Same as the MODULATION wheel.
DSP VARIATION	Same as the [VARIATION] button.
HARMONY/ECHO	Same as the [HARMONY/ECHO] button.
VOCAL HARMONY (PSR-2100 only)	Same as the [VOCAL HARMONY] button
TALK (PSR-2100 only)	Same as the [TALK] button.
SCORE PAGE+ (PSR-2100 only)	While the song is stopped, you can turn to the previous score page (one page only).
SCORE PAGE- (PSR-2100 only)	While the song is stopped, you can turn to the next score page (one page only).
SONG START/STOP	Same as the SONG [START/STOP] button.
STYLE START/STOP	Same as the STYLE [START/STOP] button.
ТАР ТЕМРО	Same as the [TAP TEMPO] button.
SYNCHRO START	Same as the [SYNC. START] button.
SYNCHRO STOP	Same as the [SYNC. STOP] button.
INTRO	Same as the [INTRO] button.
MAIN A	Same as the [MAIN A] button.
MAIN B	Same as the [MAIN B] button.
MAIN C	Same as the [MAIN C] button.
MAIN D	Same as the [MAIN D] button.
FILL DOWN	A fill-in plays, automatically followed by the Main section of the button on the immediate left.
FILL SELF	Fill-in starts playing.
FILL BREAK	Break starts playing.
FILL UP	A fill-in plays, automatically followed by the Main section of the button on the immediate right.
ENDING	Same as the [ENDING/rit.] button.
FADE IN/OUT	Same as the [FADE IN/OUT] button.
FING/ON BASS	The pedal alternately switches between the Fingered and On Bass modes (page 65).
BASS HOLD	While the pedal is pressed, the Accompaniment Style bass note will be held even if the chord is changed. If the fingering is set to "FULL KEYBOARD," the function does not work.
PERCUSSION	The pedal plays a percussion instrument selected by the [4▲▼] - [8▲▼] buttons. You can use the keyboard to select the desired percussion instrument.
MAIN ON/OFF	Same as the [MAIN] button.
LAYER ON/OFF	Same as the [LAYER] button.
LEFT ON/OFF	Same as the [LEFT] button.
OTS+	Calls up the next One Touch Setting.
OTS-	Calls up the previous One Touch Setting.
* For boot recults, use the entional	· · ·

 $<sup>\</sup>ensuremath{^{*}}$  For best results, use the optional Yamaha FC7 Foot Controller.

The parameters below correspond to buttons [2▲▼] - [8▲▼], and their availability depends on the selected control Type. For example, if SUSTAIN is selected as the Type, the parameters "HALF PEDAL POINT", "MAIN", "LAYER" and "LEFT" automatically appear in the display.


SONG, STYLE, M.PAD, MIC (PSR-2100 only), LEFT, LAYER, MAIN	These specify the part(s) that will be affected by the pedal.
HALF PEDAL POINT*	You can specify how far down you should press on the foot pedal until the damper effect starts working. This can be set for certain kinds of pedals, such as the foot pedal (YAMAHA FC7) (FOOT PEDAL 2 only).
UP/DOWN	When GLIDE or PITCH BEND is selected, this determines whether the pitch change goes up (is raised) or down (is lowered).
RANGE	When GLIDE or PITCH BEND is selected, this determines the range of the pitch change, in semitones.
ON SPEED	When GLIDE is selected, this determines the speed of the pitch change, when the pedal is pressed.
OFF SPEED	When GLIDE is selected, this determines the speed of the pitch change, when the pedal is released.
KIT	When PERCUSSION is assigned to the pedal, all available drum kits are shown here, letting you select the particular drum kit used for the pedal.
PERCUSSION	When PERCUSSION is assigned to the pedal, all sounds of the selected drum kit (in KIT above) are shown here. This determines the particular instrument sound assigned to the pedal.

<sup>\*</sup> For best results, use the optional Yamaha FC7 Foot Controller.

## Changing the Touch Sensitivity Modulation and Transpose — Keyboard/Panel

#### **Keyboard Touch/Modulation Wheel**

The Touch feature lets you control the volume of the voices by your playing strength. These settings allow you to customize the keyboard's touch response (sensitivity) to your personal playing preferences. You can also set whether the Modulation wheel is effective or not — for each individual keyboard part.



HARD 2	Requires strong playing to produce high volume. Best for players with a heavy touch.
HARD 1	Requires moderately strong playing for higher volume.
NORMAL	Standard touch response.
SOFT 1	Produces high volume with moderate playing strength.
SOFT 2	Produces relatively high volume even with light playing strength. Best for players with a light touch.


#### NOTE


The TOUCH setting affects all voices globally. Keep in mind that you can set each voice to a different touch sensitivity (TOUCH SENSE). For example, to play a pipe organ voice most authentically, you can set this so that the voice is not affected by touch (page 91).

Determines whether Touch and Modulation Wheel controls are on or not for the corresponding parts.

#### **Transpose Assign**

This determines which aspect of the instrument is affected by the [TRANSPOSE] button.





#### **KEYBOARD**

For this setting, Transpose affects the pitch of the keyboard-played voices (Main, Layer, and Left) and the accompaniment styles.

#### SONG

For this setting, Transpose affects only the pitch of the songs.

#### **MASTER**

For this setting, Transpose affects the pitch of the entire instrument (keyboard voices, accompaniment styles, and songs).

#### ♪ NOTE

The transpose function does not affect the Drum Kit or SFX Kit voices.

#### **Transpose**

Allows you to shift the pitch of the keyboard-played voices, accompaniment style playback, and song data in semitone units.

Press one of the [TRANSPOSE] buttons.



**2** A TRANSPOSE pop-up window, selected via TRANSPOSE ASSIGN, appears.







Adjust the value by using the [TRANSPOSE] buttons.



Close the TRANSPOSE windows by pressing the [EXIT] button.

#### Selectively Transposing Keyboard/Song


These settings can be used to match both the song and your keyboard performance to a certain key. For example, let's say you wish to play and sing along with a certain recorded song. The song data is in F, but you feel most comfortable singing in D, and you are accustomed to playing the keyboard part in C. To match up the keys, keep the Master Transpose setting at "0," set the Keyboard Transpose to "2," and set Song Transpose to "-3." This brings the keyboard part up in pitch and the song data down to your comfortable singing key.

#### Setting the Registration Sequence, Freeze, and Voice Set

The explanations here apply to step #3 of the procedure on page 136.

#### Specifying the Order for Calling Up Registration Memory Presets — **Registration Sequence**

You can save your custom panel settings to the Registration Memory presets, and call them up by pressing the appropriate REGISTRATION MEMORY buttons [1] - [8]. The convenient Registration Sequence function lets you call up the presets in any order you specify, by simply using the [BACK]/[NEXT] buttons or the pedal as you play.



When you are using the pedal to call up specified presets, you can easily reset the Registration Sequence and go back to the first entry by holding down the pedal for a few seconds (the red box indicator at the top right of the MAIN display goes out). Press and release the foot pedal to re-select the first entry

Setting Registration Sequence Enable to "ON" overrides any other Pedal settings (for pedals assigned to "Regist (+) Pedal" and "Regist (-) Pedal" here). These include the pedal settings on page 142, and in

When both "Regist (+) Pedal" and "Regist (-) Pedal" are set to "OFF," the pedals cannot be used to step through the Registration Sequence; only the [BACK]/[NEXT] buttons can be used in the MAIN display.

When both "Regist (+) Pedal" and "Regist (-) Pedal" are set to the same pedal, "Regist (+) Pedal" takes priority.

Registration Sequence data is included as part of the Registration Memory bank file. To save your newly programmed Registration Sequence, store the current Registration Memory bank file (page 38, 47). Any Registration Sequence data is lost when changing Registration Memory banks, unless you've stored it with the Registration Memory bank file.

Execute the settings by pressing the [EXIT] button.


currently selected Registration Memory number.

#### Maintaining Panel Settings — Freeze

This lets you specify the settings you want to be maintained or left unchanged, even when changing Registration Memory presets. For details, see page 89.

#### Changing the Automatically Selected Voice Settings — Voice Set

When changing voices (selecting a voice file), the settings best matching the voice — the same as those set in the Sound Creator — are always and automatically called up. From this page, you can set the on/off status for each part. For example, each of the preset voices has its own LEFT PEDAL setting; however, even changing voices will not change the LEFT PEDAL setting, if it is set to "OFF" in this page.



Normally, these should all be set to "ON."


## Harmony/echo cannot be set for the Layer and Left parts.

HARMONY / ECHO

These determine whether the corresponding voice-related settings (Voice selection, Effects, EQ (PSR-2100 only) and Harmony/echo assignment) are automatically called up or not when you select a voice. These settings can be turned on or off independently for each part.

#### **Setting Harmony and Echo**

The explanations here apply to step #3 of the procedure on page 136.



Determines the lowest velocity value at which the harmony note will sound. This allows you to selectively apply the harmony by your playing strength, letting you create harmony accents in the melody. The harmony effect is applied when you play the key strongly (above the set value).

When this is set to "ON," the Harmony effect is applied only to the note that belongs to a chord played in the Auto Accompaniment section of the keyboard. This parameter is not available when Multi Assign, Echo, Tremolo, or Trill is selected in Type above.

This lets you assign the Harmony effect to various parts. For details, see page 147.

#### **About the Harmony Types**

#### When a normal Harmony type ("Standard Duet" through "Strum") is selected

Chords played to the left of the split point control the harmony.

Harmony notes (based on the chord and the selected type) are automatically added to the melody played to the right of the split point.

#### When "Multi Assign" is selected

Multi Assign automatically assigns notes played simultaneously on the right-hand section of the keyboard to separate parts (voices). For example, if you play two consecutive notes, the first is played by the Main voice and the second by the Layer voice.

#### When "Echo" is selected

An echo effect is applied to the note played on the keyboard, in time with the currently set tempo.

#### When "Tremolo" is selected

A tremolo effect is applied to the note played on the keyboard, in time with the currently set tempo.

#### When "Trill" is selected

Two notes held on the keyboard are played alternately, in time with the currently set tempo.

#### **About the Harmony Assignments**

#### **AUTO**

Harmony notes are automatically assigned the MAIN and LAYER parts.

#### Multi

This automatically assigns the 1st, 2nd, 3rd, and 4th added harmony notes to different parts (voices). For example, if the Main and Layer parts are turned on and the "Standard Duet" type is selected, the note you play on the keyboard will be played by the Main voice, and the added harmony note will be played by the Layer voice.

#### Main


Harmony is applied only to the Main part. When the Main part is turned off, Harmony is not applied.


#### Layer

Harmony is applied only to the Layer part. When the Layer part is turned off, Harmony is not applied.

#### **Setting the MIDI Parameters**

In this section, you can make MIDI-related settings for the instrument. These settings can be stored all together from the USER display, for future recall. For general information and details about MIDI, see "What is MIDI?" (page 158). The explanations here apply to step #3 of the procedure on page 136.





Call up the User display and press this button to save the newly edited MIDI settings.

Up to ten setups can be saved.

2 Call up the Edit display, then select and set the desired functions/parameters.

For details about each of the MIDI edit displays, see the following pages.

#### **Preset MIDI Templates (Factory Set)**

All Parts	Transmit all parts including Main, Layer and Left.
Master KBD	The PSR-2100/1100 functions as a master keyboard for controlling external tone generators or other devices.
KBD & Style	Transmit Upper and Lower keyboard play instead of the individual parts (Main/Layer/Left).
Song	All Transmit channels are set to correspond to the Song channels 1-16. Use this to play the PSR-2100/1100 song data with an external tone generator, or to record your entire performance to an external sequencer.
Clock Ext.	MIDI IN terminal receives MIDI clock and PSR-2100/1100 synchronizes with a external MIDI device.
MIDI Accord 1	An ideal setup for controlling the keyboard voice and accompaniment style with a MIDI accordion.
MIDI Accord 2	Chord and bass buttons on a MIDI accordion control the accompaniment style, as well as play the chord and bass parts.
MIDI Pedal 1	The MIDI pedal connected to MIDI IN terminal controls the bass note of the accompaniment.
MIDI Pedal 2	The MIDI pedal connected to MIDI IN terminal plays the bass part.
MIDI OFF	MIDI signals are neither sent nor received.

#### <u> 2) NOTE</u>

The saved settings can be named (page 44) or deleted (page 46) in the User page.




Press the [EXIT] button to return to the previous display.

#### Making Overall System Settings (Local Control, Clock, etc.) — System

Call up the display as described in step 2 above.

For editing the Clock, Transmit Clock, Receive Transpose, and Start/Stop parameters.



#### **Local Control**

Turns the Local Control for each part on or off. When Local Control is set to "ON," the keyboard of the PSR-2100/1100 controls its own (local) internal tone generator, allowing the internal voices to be played directly from the keyboard. If you set Local to "OFF," the keyboard and controllers are internally disconnected from the PSR-2100/1100's tone generator section so that no sound is output when you play the keyboard or use the controllers. For example, this allows you to use an external MIDI sequencer to play the PSR-2100/1100's internal voices, and use the PSR-2100/1100 keyboard to record notes to the external sequencer and/or play an external tone generator.

#### Clock, Transmit Clock, Receive Transpose, Start/Stop

#### ■ Clock

Determines whether the PSR-2100/1100 is controlled by its own internal clock or a MIDI clock signal received from an external device. "INTERNAL" is the normal Clock setting when the PSR-2100/1100 is being used alone. If you are using the PSR-2100/1100 with an external sequencer, MIDI computer, or other MIDI device, and you want the PSR-2100/1100 to be synchronized to the external device, set this function to "EXTERNAL." In the latter case, the external device must be connected to the PSR-2100/1100 MIDI IN terminal, and must be transmitting an appropriate MIDI clock signal.

#### **■** Transmit Clock

Turns MIDI clock transmission on or off. When this is set to "OFF," no MIDI clock or START/STOP data is transmitted.

#### **■** Receive Transpose

When this parameter is set to "OFF," note data received by the PSR-2100/1100 is not transposed, and when it is set to "ON," the received note data is transposed according to the current PSR-2100/1100 keyboard transpose (page 144) setting.

#### ■ Start/Stop

Determines whether incoming FA (start) and FC (stop) messages affect song or style playback.

#### ♪ NOTE


#### FA, FC

MIDI messages for starting/stopping the song or style. The "FA" message corresponds to start, and "FC" corresponds to stop.

#### Message Switch

#### Transmitting MIDI Data — Transmit

This determines which parts will send MIDI data and over which MIDI channel the data will be sent.




#### Data Types in the MIDI TRANSMIT/RECEIVE Display

Note	Messages which are generated when the keyboard is played. Each message includes a specific note number which corresponds to the key which is pressed, plus a velocity value based on how hard the key is played.		
Control Change (CC)	Control change data includes pedal and any other controller data.		
Program Change (PC)	Program change data corresponds to voice or "patch" numbers.		
Pitch Bend (PB)	See page 143.		
After Touch (AT)*	With this function, the PSR-2100/1100 senses how much pressure you apply to the keys while playing, and uses that pressure to affect the sound in various ways, depending on the selected voice. This allows you to play with greater expressiveness and add effects with your playing technique.		

<sup>\*</sup> Available in RECEIVE display only (page 150).

#### Receiving MIDI Data — Receive

This determines which parts will receive MIDI data and over which MIDI channel the data will be received.



#### **MIDI Receive Parts**


details about the receive parts.

OFF	No MIDI data is received.
SONG	Normally, the part receiving the MIDI data corresponds to the part/voice used in playing back the song data. Channels 1 - 16 correspond to song channels 1 - 16, respectively.
MAIN	The MAIN part is controlled by the MIDI data received on the corresponding channel.
LAYER	The LAYER part is controlled by the MIDI data received on the corresponding channel.
LEFT	The LEFT part is controlled by the MIDI data received on the corresponding channel.
KEYBOARD	MIDI note data received by the PSR-2100/1100 plays the corresponding notes in the same way as if they are played on the keyboard
ACMP RHYTHM1-2	The received notes are used as the accompaniment RHYTHM 1 and RHYTHM 2.
ACMP BASS	The received notes are used as the accompaniment BASS.
ACMP CHORD1-2	The received notes are used as the accompaniment CHORD 1 and CHORD 2.
ACMP PAD	The received notes are used as the accompaniment PAD.
ACMP PHRASE1-2	The received notes are used as the accompaniment PHRASE 1 and PHRASE 2.
EXTRA PART1-5	There are five parts specially reserved for receiving and playing MIDI data. Normally, these parts are not used by the instrument itself. When these five channels are enabled, you can use the instrument as a 32-channel multi-timbral tone generator.

for details on the data types.

#### **Setting Root Note Channels — Root**

The note ON/OFF messages received at the channel(s) set to "ON" are recognized as the root notes in the accompaniment section. The root notes will be detected regardless of the accompaniment ON/OFF and split point settings.



#### **Setting Chord Channels — Chord Detect**

The note ON/OFF messages received at the channel(s) set to "ON" are recognized as the chord notes in the accompaniment section. The chords to be detected depend on the fingering type. The root notes will be detected regardless of the accompaniment ON/OFF and split point settings. The operation procedure is basically the same as that of the ROOT display above.


#### Other Settings — Utility

The explanations here apply to step #3 of the procedure on page 136.

# Making Settings for Fade In/Out, Metronome, Parameter Lock, and Tap — CONFIG 1

#### Fade In Time, Fade Out Time, Fade Out Hold Time

These determine how long it takes for the accompaniment style and song to fade in or fade out.




Determines the time it takes for the volume to fade in, or go from minimum to maximum (range of 0 - 20.0 seconds).

Determines the time the volume is held at 0 following the fade out (range of 0 - 5.0 seconds).

Determines the time it takes for the volume to fade out, or go from maximum to minimum (range of 0 - 20.0 seconds).

#### Metronome

These let you make settings for the metronome-related parameters.



Determines the level of the metronome sound.

Determines which sound is used for the metronome.

Bell Off ...... Conventional metronome sound, with no bell.


Bell On..... Conventional metronome sound, with bell.

Determines the time signature of the metronome sound.

When you start the song or accompaniment style, the values matching to them are automatically set.


#### **Parameter Lock**

This function is used to "lock" the specified parameters so that they can only be changed directly via the panel controls — in other words, instead of via Registration Memory, One Touch Setting, Music Finder, or song and sequence data.




#### **Tap Count**

This lets you change settings of the tap sound, used for the Tap Start function (page 54).




# Making Settings for the Display and Voice Number Indication — CONFIG 2



Determines whether or not the voice bank and number are shown in the PRESET page of the VOICE display (page 57). This is useful when you want to check the proper bank select MSB/LSB values and program number to specify when selecting the voice from an external MIDI device.

#### Copying and Formatting Disks — Disk



#### L NOTE

- Copying cannot be done between a 2DD disk and 2HD disk. When copying, make sure both disk are the same type.
- Depending on the amount of data contained in the original source disk, you may have to swap the two disks several times until all of the data is properly copied.
- Make sure to read the section "Using the Floppy Disk Drive (FDD) and Floppy Disks" on page 7.

#### Copying from Disk to Disk

As shown below, first copy the data of the original (source) disk to the PSR-2100/1100, then copy the data to the backup (destination) disk.

Press the [F] button. A message appears, prompting you to insert the source disk.


At the "Please insert a destination disk and press the OK button" prompt, eject the source disk and replace it with a blank, formatted disk, then press "OK." To abort the operation, press "CANCEL."

Insert the disk containing the original data into the drive and press "OK."

A "Now copying" message appears, and the PSR-2100/1100 begins copying data to internal memory. To abort the operation, press "CANCEL."

When the operation is finished (or when prompted), eject the destination disk.





#### J NOTE


Commercially available music data is subject to protection by copyright laws. Copying commercially available data is strictly prohibited, except for your own personal use. Some music software is purposely copy-protected and cannot be copied.

#### Formatting a Disk

When using an unformatted disk for the first time, make sure to properly format it on the PSR-2100/1100. This includes blank disks as well as disks already initialized in a different format. Formatting erases all data on the disk.

#### Disk Lamp

When the power is turned on, the disk lamp (at the bottom left of the drive) lights to indicate the drive can be used.



Insert the disk with shutter facing away from you and the label side up. To start the Format operation, press the **[H]** (**DISK FORMAT**) button, in the DISK page above.


#### **JOTE**

The Format operation initializes a disk with a specific file system, allowing the corresponding device (in this case, the PSR-2100/1100) to access it properly. Since there are several types of formats and disks available, you should know which ones to use with the PSR-2100/1100. 2DD disks are formatted to a capacity of 720 KB, and 2HD disks are formatted to a capacity of 1.44 MB.

#### **A** CAUTION -

Formatting a disk completely erases all data on the disk. Make sure that the disk you're formatting does not contain important data!

#### **Entering Your Name and Language Preference — Owner**



#### - D NOTE


Selecting a different language here may cause the following problems.

- Some characters of the file names you entered may be garbled.
- Files may not be accessible.
   Restoring the original language solves the above problems.

Reading the files on the computer with a different language system may cause similar problems to those above.

# Restoring the Factory-programmed Settings of the PSR-2100/1100 — System Reset

This operation lets you restore the PSR-2100/1100 to its original factory settings. These settings include System Setup, MIDI Setup, User Effect, Music Finder, and Files & Folders.



#### **NOTE**

The functions and settings below do not apply to the Factory Reset operation. However, you can restore these to their original settings by calling up the preset System Setup files, using the Open/Save System Files function.

Language
Owner Name

#### - DI NOTE

LCD Brightness

All Music Finder records can be stored together as a single file. When calling up a stored file, a message appears prompting you to replace or append the records as desired.

#### Replace:

All Music Finder records currently in the instrument are deleted and replaced with the records of the selected


#### Append:

The records called up are added to the vacant record numbers.

### Using Your PSR-2100/1100 with Other Devices

#### A CAUTION

Before connecting the PSR-2100/1100 to other electronic components, turn off the power to all the components. Before turning the power on or off to all components, set all volume levels to minimum (0). Otherwise, electrical shock or damage to the components may occur.



# **1** Using the Headphones (PHONES jack).

A standard pair of stereo headphones can be plugged in here for private practice or late-night playing. The internal stereo speaker system is automatically shut off when a pair of headphones is plugged into the PHONES jack (page 152).

# **2** Connecting the Microphone or Guitar (MIC./LINE IN jack) (PSR-2100 only).

By connecting a microphone to the PSR-2100, you can enjoy singing along with your own performance or song playback. (A dynamic microphone is recommended.) The PSR-2100 outputs your vocals or guitar sounds through the built-in speakers.

Connect your microphone to the MIC./LINE IN jack (standard 1/4" phone jack).

#### 1) NOTE

Use an unidirectional microphone for best results.

2 Set the [MIC. LINE] switch (located next to the MIC./ LINE IN jack) to the MIC. position.



When connecting a microphone



When connecting a guitar

#### J NOTE


You should set the [MIC. LINE] switch to the LINE position when connecting an audio source with line-level output to the MIC./LINE IN iack.


We the [INPUT VOLUME] knob (located next to the MIC./LINE IN jack) to set the microphone volume then trying singing into the

microphone.



The volume should be set high enough that the SIGNAL lamp on the top panel lights steadily when you sing, but not so high that the OVER lamp lights (page 131).





# 3 Playing the sounds of the PSR-2100/1100 through an external audio system, and recording the sounds to an external recorder (AUX OUT/OUTPUT jacks)

You can connect the PSR-2100/1100 to a wide range of audio equipment by using the AUX OUT and OUTPUT iacks.


Connect as shown in the illustrations below using standard audio cables.

#### **♪ NOTE**

Use audio cables and adaptor plugs with no resistance.

#### A CAUTION

When the PSR-2100/1100 AUX OUT and OUTPUT jacks are connected to an external audio system, first turn on the power to the PSR-2100/1100, then to the external audio system. Reverse this order when you turn the power off.



When these are connected (with RCA pin plug; LEVEL FIXED), the sound is output to the external device at a fixed level, regardless of the [MASTER VOLUME] control setting.

When these are connected (with standard phone plugs), you can use the [MASTER VOLUME] control to adjust the volume of the sound output to the external device.

#### J) NOTE

 If you connect the PSR-2100/1100 to a monaural device, use only the OUTPUT L/L+R jack.

# **4** Using the Pedal (footswitch) or Foot Controller (FOOT PEDAL 1/2 jack)

By connecting a Foot Switch (the FC4 or FC5) to one of the FOOT PEDAL jacks, you can replicate the function of some panel buttons, doing things like starting and stopping accompaniment.

By connecting an optional Foot Controller (such as the FC7) to the FOOT PEDAL 2 jack, you can control any one of a variety of important functions with your foot — such as dynamically adjusting the volume as you play (page 142).

#### J NOTE

The polarity of the foot switch (normal or reverse) can also be changed (page 142).

#### **A** CAUTIOI

Make sure to connect or disconnect the pedal only when the power is turned off.

# **5** Connecting external MIDI devices (MIDI terminals)

Use the built-in MIDI terminals and standard MIDI cables to connect external MIDI devices. For more information about MIDI connections, see "What You Can Do With MIDI" on page 160.

The MIDI terminals cannot be used when the USB terminal is connected to a computer and active.

MIDI IN ......Receives MIDI messages from an external MIDI device

MIDI OUT......Sends out MIDI messages generated by the PSR-2100/1100

For a general overview of MIDI and how you can effectively use it, refer to the following sections:

- What's MIDI? (page 158)
- What You Can Do With MIDI (page 160)
- MIDI functions (page 148)

#### J NOTE

• Never use MIDI cables longer than 15 meters.

# **6** Connecting to a Computer (USB terminal, MIDI terminal)

Connecting your PSR-2100/1100 to a computer allows you to transfer data back and forth between the two and take advantage of the powerful and versatile music software available. You can connect the devices in one of two ways:

- Using the USB terminal
- Using the MIDI terminals

The MIDI terminals cannot be used when the USB terminal is in use.

An appropriate MIDI application for your computer platform is required.

For details about the necessary MIDI settings for computer and sequence software you are using, refer to the relevant owner's manuals.

#### Using the USB terminal

Connect the USB terminal of a computer to the USB terminal of the PSR-2100/1100 using a USB cable. Make sure to use a standard USB cable with the USB logo.



#### About the USB driver

You must install the specified USB driver (YAMAHA USB MIDI Driver) to your computer before you can transfer data between the computer and the PSR-2100/1100.

You can download a copy of the YAMAHA USB MIDI Driver free of charge from the XG Library on the Yamaha Web site (http://www.yamaha-xg.com/).

#### A CAUTION

If you are using a USB cable to connect the PSR-2100/1100 to your computer, you must connect the USB cable before turning on the power of the instrument.

Also, do not turn the power of the PSR-2100/1100 on/off while any application software that uses USB or MIDI is running. If you turn the power of the PSR-2100/1100 on or off or connect/disconnect the USB cable in the following states, problems will occur in the computer system, possibly causing it to "freeze" (hang up), or causing the PSR-2100/1100 to stop functioning.

- · While installing the driver.
- While starting or shutting down the operating system.
- · While the computer is in an energy-save or sleep mode.
- When a MIDI application program is starting.

Make sure NOT to perform any of the following operations. Otherwise, the computer may lock up or the PSR-2100/1100 functions may be disabled.

- Turning the power on/off, or connecting/disconnecting the cable too often.
- Shifting to energy-save or sleep mode while MIDI data is being transferred, or returning from sleep mode.
- Disconnecting/connecting the cable while the PSR-2100/1100 is on
- Turning the power of the PSR-2100/1100 on/off, starting up your computer, or installing the driver while a large amount of data is being transferred.

#### 1) NOTE

- The PSR-2100/1100 will begin transmission a short time after the USB connection is made.
- When using a USB cable to connect PSR-2100/1100 to your computer, make the connection directly without passing through a USB hub.
- Depending on the state of your computer, the operating state of PSR-2100/1100 may become unstable. Do not use your computer in a way that causes it to enter an unstable state.

#### Using the MIDI terminals


When using a MIDI interface device installed in the personal computer, connect the MIDI terminals of the personal computer and the PSR-2100/1100 with standard MIDI cables.

#### **♪ NOTE**


When connecting the PSR-2100/1100 to a personal computer, first turn off the power to both the PSR-2100/1100 and the computer before connecting any cables.

After making the proper connections and settings, turn on the power of the computer first, then that of the PSR-2100/1100.

 When the computer has a MIDI interface installed, connect the MIDI OUT terminal of the personal computer to the MIDI IN terminal.



 When using a MIDI interface with a Macintosh series computer, connect the RS-422 terminal of the computer (modem or printer terminal) to the MIDI interface, then connect the MIDI OUT terminal on the MIDI interface to the MIDI IN terminal of the PSR-2100/1100, as shown in the diagram below.




 When using a Macintosh series computer, set the MIDI interface clock setting in the application software to match the setting of the MIDI interface you are using. For details, refer to the owner's manual for the particular software you are using.

#### What's MIDI?

Let's consider an acoustic piano and a classical guitar as representative acoustic instruments. With the piano, you strike a key, and a hammer inside hits some strings and plays a note. With the guitar, you directly pluck a string and the note sounds.


But how does a digital instrument go about playing a note?



As shown in the illustration above, in an electronic instrument, the sampled note (previously recorded note) stored in the **tone generator section** (electronic circuit) is played based on information received from the keyboard, and output through the speakers.


Now let's examine what happens when we play back a recording. When you playback a music CD (for example, a solo piano recording), you're hearing the actual sound (vibrations in air) of the acoustic instrument. This is called audio data, to distinguish it from MIDI data.

Recording and playing back the performance of an acoustic instrument (audio data)



In the above example, the actual acoustic sounds of the pianist's performance are captured in the recording as audio data, and this is recorded to CD. When you play back that CD on your audio system, you can hear the actual piano performance. The piano itself is not necessary, since the recording contains the actual sounds of the piano, and your speakers reproduce them.


Recording and playing back the performance of a digital instrument (MIDI data)



#### J NOTE

In the case of digital instruments, the audio signals are sent through output jacks (such as AUX OUT) on the instrument.

The "controller" and "tone generator" in the illustration above are equivalent to the piano in our acoustic example. Here, the player's performance on the keyboard is captured as MIDI song data (see illustration below). In order to record the audio performance on an acoustic piano, special recording equipment is needed. However, since the PSR-2100/1100 features a built-in **sequencer** that lets you record performance data, this recording equipment is unnecessary. Instead, your digital instrument — the PSR-2100/1100 — allows you to both record and play back the data.



However, we also need a sound source to produce the audio, which eventually comes from your speakers. The **tone generator** of the PSR-2100/1100 fills this function. The recorded performance is reproduced by the sequencer, playing back the song data, using a tone generator capable of accurately producing various instrument sounds — including that of a piano. Looked at in another way, the relation of the sequencer and the tone generator is similar to that of the pianist and the piano — one plays the other. Since digital instruments handle playback data and the actual sounds independently, we can hear our piano performance played by another instrument, such as guitar or violin.

#### **♪ NOTE**

Even though it is a single musical instrument, the PSR-2100/1100 can be thought of as containing several electronic components: a controller, a tone generator, and a sequencer.

Finally, we'll take a look at the actual data that gets recorded and that serves as the basis for playing the sounds. For example, let's say you play a "C" quarter note using the grand piano sound on the PSR-2100/1100 keyboard. Unlike an acoustic instrument that puts out a resonated note, the electronic instrument puts out information from the keyboard such as "with what voice," "with which key," "about how strong," "when was it pressed" and "when was it released." Then each piece of information is changed into a number value and sent to the tone generator. Using these numbers as a basis, the tone generator plays the stored sampled note.

#### **■** Example Keyboard Data

Voice number (with what voice)	01 (grand piano)
Note number (with which key)	60 (C3)
Note on (when was it pressed) and note off (when was it released)	Timing expressed numerically (quarter note)
Velocity (about how strong)	120 (strong)

Panel operations on the PSR-2100/1100, such as playing the keyboard and selecting voices, are processed and stored as MIDI data. The auto accompaniment styles and songs also consist of MIDI data.

MIDI is an acronym that stands for Musical Instrument Digital Interface, which allows electronic musical instruments to communicate with each other, by sending and receiving compatible Note, Control Change, Program Change and various other types of MIDI data, or messages.

The PSR-2100/1100 can control a MIDI device by transmitting note related data and various types of controller data. The PSR-2100/1100 can be controlled by incoming MIDI messages which automatically determine the tone generator mode, select MIDI channels, voices and effects, change parameter values and of course play the voices specified for the various parts.

#### **NOTE**

MIDI data has the following advantages over audio data:

- The amount of data is much less, letting you easily store MIDI songs to floppy disk.
- The data can be effectively and easily edited, even to the point of changing voices and transforming the data.

MIDI messages can be divided into two groups: Channel messages and System messages.

#### ■ Channel Messages

The PSR-2100/1100 is an electronic instrument that can handle 16 channels (or 32 channels, when using the USB terminal). This is usually expressed as "it can play 16 instruments at the same time." Channel messages transmit information such as Note ON/OFF, Program Change, for each of the 16 channels.

Message Name	PSR-2100/1100 Operation/Panel Setting
Note ON/OFF	Messages which are generated when the keyboard is played. Each message includes a specific note number which corresponds to the key which is pressed, plus a velocity value based on how hard the key is played.
Program Change	Voice selecting (control change bank select MSB/LSB setting)
Control Change	Volume, panpot (Mixing Console), etc.


#### J NOTE

The performance data of all songs and styles is handled as MIDI data.


#### MIDI channels

MIDI performance data is assigned to one of sixteen MIDI channels. Using these channels, 1 - 16, the performance data for sixteen different instrument parts can be simultaneously sent over one MIDI cable.

Think of the MIDI channels as TV channels. Each TV station transmits its broadcasts over a specific channel. Your home TV set receives many different programs simultaneously from several TV stations and you select the appropriate channel to watch the desired program.



MIDI operates on the same basic principle. The transmitting instrument sends MIDI data on a specific MIDI channel (MIDI Transmit Channel) via a single MIDI cable to the receiving instrument. If the receiving instrument's MIDI channel (MIDI Receive Channel) matches the Transmit Channel, the receiving instrument will sound according to the data sent by the transmitting instrument.




#### ) NOTE

The PSR-2100/1100's keyboard and internal tone generator are also connected by MIDI (page 148).

For example, several tracks (channels) can be transmitted simultaneously, including the style data (as shown below).

Example: Recording the auto accompaniment of the PSR-2100/1100 to an external sequencer



As you can see, it is essential to determine which data is to be sent over which MIDI channel when transmitting MIDI data (page 149). The PSR-2100/1100 also allows you to determine how the received data is played back. (page 150).

#### ■ System Messages

This is data that is used in common by the entire MIDI system. System messages include messages like Exclusive Messages that transmit data unique to each instrument manufacturer and Realtime Messages that control the MIDI device.


Message Name	PSR-2100/1100 Operation/Panel Setting	
System Exclusive Message	Effect type settings (Mixing Console), etc.	
Realtime Messages	Clock setting, Start/stop operation	

The messages transmitted/received by the PSR-2100/1100 are shown in the MIDI Data Format and MIDI Implementation Chart in the separate Data List.

#### What You Can Do With MIDI


The following MIDI settings can be made on the PSR-2100/1100:

- MIDI templates (preset MIDI setups for various applications) (page 148)
- Transmit (page 149)
- Receive (page 150)
- Local Control (page 148)
- Clock (page 149)
- Record performance data (1-16 channels) using the PSR-2100/1100 Auto Accompaniment features on a external sequencer (such as a personal computer). After recording, edit the data with the sequencer, then play it again on the PSR-2100/1100 (playback).



When you want to use the PSR-2100/1100 as an XG-compatible multi-timbral tone generator, set the receive part for MIDI channels 1 to 16 to "SONG" in MIDI Receive (page 150).

■ Play and control the PSR-2100/1100 from a separate keyboard



#### **MIDI Data Compatibility**

This section covers basic information on data compatibility: whether or not other MIDI devices can playback the data recorded by PSR-2100/1100, and whether or not the PSR-2100/1100 can playback commercially available song data or song data created for other instruments or on a computer. Depending on the MIDI device or data characteristics, you may be able to play back the data without any problem, or you may have to perform some special operations before the data can be played back. If you run into problems playing back data, please refer to the information below.

#### Disk format

Floppy disks are the main storage medium for data used with various devices, including computers. Different devices have different systems of storing data, therefore it is necessary to first configure the floppy disk to the system of the device being used. This operation is called "formatting."

- There are two types of floppy disks: MF2DD (double sided, double density) and MF2HD (double sided, high density), and each type has different formatting systems.
- PSR-2100/1100 can record and playback with both types of floppy disks.
- When formatted by the PSR-2100/1100, a 2DD disk stores up to 720 KB (kilobytes) and a 2HD disk stores up to1.44 MB (megabytes). (The figures "720 KB" and "1.44MB" indicate the data memory capacity. They are also used to indicate the format type of disk.)
- Playback is only possible when the MIDI device to be used is compatible with the format of the disk.

#### **Sequence Format**

The system which records song data is called "sequence format."

Playback is only possible when the sequence format of the disk matches that of the MIDI device. The PSR-2100/ 1100 is compatible with the following formats.

#### ■ SMF (Standard MIDI File)

This is the most common sequence format. Standard MIDI Files are generally available as one of two types: Format 0 or Format 1. Many MIDI devices are compatible with Format 0, and most commercially available software is recorded as Format 0.

- The PSR-2100/1100 is compatible with both Format 0 and Format 1.
- Song data recorded on the PSR-2100/1100 is automatically recorded as SMF Format 0.
- Song data loaded to the PSR-2100/1100 is automatically saved as SMF Format 0 regardless of the original format.

#### **■** ESEQ

This sequence format is compatible with many of Yamaha's MIDI devices, including the PSR-2100/1100 series instruments. This is a common format used with various Yamaha software.

#### **■** XF

The Yamaha XF format enhances the SMF (Standard MIDI File) format with greater functionality and open-ended expandability for the future.

 The PSR-2100/1100 is capable of displaying lyrics when an XF file containing lyric data is played.

#### ■ Style File

The Style File Format – SFF – is Yamaha's original style file format which uses a unique conversion system to provide high-quality automatic accompaniment based on a wide range of chord types.

#### **Voice Allocation Format**

With MIDI, voices are assigned to specific numbers, called "program numbers." The numbering standard (order of voice allocation) is referred to as the "voice allocation format."

Voices may not play back as expected unless the voice allocation format of the song data matches that of the compatible MIDI device used for playback.

The PSR-2100/1100 is compatible with the following formats.

#### J NOTE

Even if the devices and data used satisfy all the conditions above, the data may still not be completely compatible, depending on the specifications of the devices and particular data recording methods.

#### ■ GM System Level 1

This is one of the most common voice allocation formats.

• Many MIDI devices are compatible with GM System Level1, as is most commercially available software.

#### **■** XG

XG is a major enhancement of the GM System Level 1 format, and was developed by Yamaha specifically to provide more voices and variations, as well as greater expressive control over voices and effects, and to ensure compatibility of data well into the future.

• Song data recorded on the PSR-2100/1100 using voices in the [XG] category is XG-compatible.

#### **■** DOC

This voice allocation format is compatible with many of Yamaha's MIDI devices, including the PSR series instruments. This is also a common format used with various Yamaha software.

# Troubleshooting

Problem	Possible Cause and Solution
The PSR-2100/1100 does not turn on; there is no power.	Make sure that the PSR-2100/1100 has been plugged in properly (page 16).
A click or pop is heard when the power is turned on or off.	This is normal when electrical current is applied to the instrument.
Noise is heard from the PSR-2100/1100's speakers.	Using a mobile phone in close proximity to the PSR-2100/1100 may produce interference. To prevent this, turn off the mobile phone, or use it further away from the PSR-2100/1100.
The display is too bright or too dark to read.	The brightness of the display may be affected by the surrounding temperature; try adjusting the contrast (page 17).
The keyboard volume is low compared to that of the Auto Accompaniment or song playback.	The overall keyboard volume or the independent volume level of the keyboard part may be set too low. Raise the MAIN/LAYER/LEFT volume voices or lower the STYLE/SONG volume in the BALANCE display (page 64).
The volume of the Auto Accompaniment or song playback is low compared to that of the keyboard.	The volume level of one or more accompaniment parts or song channels is set too low. Raise the part or channel level(s) in the appropriate MIXER display (page 125).
The overall volume is low, or no sound is heard.	<ul> <li>The Master Volume is set too low; set it to an appropriate level with the [MASTER VOLUME] dial.</li> <li>The volume of the individual parts may be set too low. Raise the volume of MAIN, LAYER, LEFT, STYLE, and SONG in the BALANCE display (page 64).</li> <li>Make sure the desired channel is set to ON (page 64, 81).</li> <li>Headphones are connected, disabling the speaker output. Unplug the headphones.</li> <li>Make sure the Local Control function is set to ON (page 148).</li> </ul>
Not all simultaneously-played notes sound.	You may be exceeding the maximum polyphony of the PSR-2100/1100. When this happens, the earliest played notes will stop sounding, letting the latest played notes sound. See page 165 for information on the maximum polyphony.
Accompaniment style or Song playback does not start.	<ul> <li>MIDI Clock may be set to "EXTERNAL." Make sure this is set to "INTERNAL" (page 149).</li> <li>Make sure to press the appropriate [START/STOP] button. To play an accompaniment style, press the STYLE [START/STOP] button (page 64); to playback a song, press the SONG [START/STOP] button (page 79).</li> <li>"New Song" (a blank song) has been selected. Make sure to select an appropriate song in the SONG display (page 79).</li> <li>The song has been stopped at the end of the song data. Return to the beginning of the song by pressing the [TOP] button (page 81).</li> </ul>
The Multi Pads do not play back, even when one of the MULTI PAD buttons is pressed.	MIDI Clock may be set to "EXTERNAL." Make sure this is set to "INTERNAL" (page 149).
Only the rhythm channel plays.	Make sure the Auto Accompaniment function is turned on; press the [ACMP] button.
The accompaniment style does not start, even when Synchro Start is in standby condition and a key is pressed.	You may be trying to start accompaniment by playing a key in the right hand range of the keyboard. Make sure to play a key in the left-hand (accompaniment) range of the keyboard.
The desired chord is not recognized or output by the auto accompaniment.	<ul> <li>You may not be playing the correct keys to indicate the chord. Refer to "Chord Types Recognized in the Fingered Mode" (page 66).</li> <li>You may be playing the keys according to a different fingering mode, and not the one currently selected. Check the accompaniment mode, and play the keys according to the selected mode (page 65).</li> </ul>
An unexpected result or malfunction occurred during an operation.	If, during execution of an operation, you simultaneously press three or more buttons that are unrelated to the operation or normal procedure, unexpected or unusual results may occur.
Auto accompaniment chords are recognized regardless of the split point or where chords are played on the keyboard.	This is normal if the fingering mode is set to "Full Keyboard" or "Al Full Keyboard." If either of these is selected, chords are recognized over the entire range of the keyboard, irrespective of the split point setting. If desired, select a different fingering mode (page 65).

Problem	Possible Cause and Solution
Certain notes sound at the wrong pitch.	The Scale parameter has probably been set to something other than "Equal," changing the tuning system of the keyboard. Make sure "Equal" is selected as the Scale in the Scale Tune page (page 138).
Some channels do not properly play back when playing back song data.	Make sure that playback of the relevant channel(s) is turned on (page 81).
If you experience distorted or out-of-tune sound from the Vocal Harmony feature, your	The solution to this problem is to ensure that as little extraneous sound as possible is picked up by your vocal microphone:
vocal microphone may be picking up extraneous sounds (other than your voice) — the Auto Accompaniment sound from the PSR-2100/1100, for example. In particular, bass sounds can cause mistracking of the Vocal Harmony feature (PSR-2100 only).	<ul> <li>Sing as closely to the microphone as possible.</li> <li>Use a directional microphone.</li> <li>Turn down the MASTER VOLUME or volume for each part.</li> <li>Separate the microphone from the instrument's speakers as much as possible.</li> <li>Cut the Low band via the 3 Band EQ function in the MICROPHONE SETTING display (page 133).</li> <li>Increase the microphone input level ("TH.") in the Compressor function from the MICROPHONE SETTING display (page 133).</li> </ul>
Appropriate harmony notes are not produced by the Vocal Harmony feature (PSR-2100 only).	Make sure you are using the appropriate method to specify the harmony notes for the current Vocal Harmony mode. See page 134.
The Harmony function does not operate.	Harmony cannot be used with the Full Keyboard or Al Full Keyboard fingering modes. Select an appropriate fingering mode (page 65).
The microphone input signal and Vocal Harmony sound (PSR-2100 only) cannot be recorded.	This is normal; recording the audio input of the microphone is not possible.
MIDI data is not transmitted or received via the MIDI terminals, even when MIDI cables are connected properly.	Remove the USB cable from the PSR-2100/1100's USB terminal.
When a voice is changed, the previously selected effect is changed.	Each voice has its own suitable preset values which are automatically recalled when the corresponding Voice Set parameters are turned on (page 146).
<ul> <li>There is a slight difference in sound quality between notes played on the keyboard.</li> <li>Some voices have a looping sound.</li> <li>Some noise or vibrato is noticeable at higher pitches, depending upon the voice.</li> </ul>	This is normal and is a result of the PSR-2100/1100's sampling system.
Some voices will jump an octave in pitch when played in the upper or lower registers.	This is normal. Some voices have a pitch limit which, when reached, causes this type of pitch shift.
Even though a Registration Memory setting containing a User voice is selected, the Open/ Save display shows a Preset voice.	This is normal; even with the Preset voice shown, the actual sounding voice is the selected User voice.  When a User voice is registered to the User drive or floppy disk, the actual registered is: 1) the source Preset voice, and 2) the parameter settings as set in the Sound Creator. When you recall a Registration Memory setting containing a User voice, the PSR-2100/1100 selects the Preset voice (on which the User voice is based), then applies the relevant parameter settings to it – so that your original User voice is sounded.
Disk save operations take a long time.	This is normal. Keep in mind that it takes approximately 1 minute to save 1 megabyte of data to a floppy disk.
The voice produces excessive noise.	Certain voices may produce noise, depending on the Harmonic Content and/or Brightness settings in the FILTER page of the Mixing Console display (page 126).
The sound is distorted or noisy.	<ul> <li>The volume may be turned up too high. Make sure all relevant volume settings are appropriate.</li> <li>This may be caused by the effects. Try canceling all unnecessary effects, especially distortion-type effects (page 127).</li> <li>Some filter resonance settings in the Custom Voice Creator display (page 92) can result in distorted sound. Adjust these settings if necessary.</li> <li>Is the gain of the Low band set too high in the Master Equalizer display (Mixing Console — page 130)? (PSR-2100 only)</li> </ul>
A strange "flanging" or "doubling" sound occurs. Also, the sound is slightly different each time the keys are played.	Both the Main and Layer parts are set to "ON," and both parts are set to play the same voice. Set the Layer part to "OFF" (page 59) or change the voice for each part (page 57).

# **Specifications**

: available

	Model Name		PSR-2100	PSR-1100
Sound Source			AWM Dynamic Stereo Sampling	
Display			320 X 240 dots b	acklit graphic LCD
Keyboard			61 keys (C1 - C6 with Initial Touch)	
Voice	Polyphony (max)		64	32
	Voice Selection		338 voices + 480 XG voices + 16 Drum Kits	287 voices + 480 XG voices + 16 Drum Kits
		Regular Voice	328	287
		Sweet Voice	14	8
		Cool Voice	6	2
		Live Voice	12	1
		Others	296	276
		Organ Flutes	10 (8 Footages)	_
	Sound creator	-		$\dot{\Box}$
Effects		Reverb		1
	Effect Blocks	Chorus		1
	Effect Blocks	DSP	4	1
		Microphone	1	_
		REVERB	29 Preset+3 User	23 Preset+3 User
		CHORUS	25 Preset+3 User	15 Preset+3 User
	E#aat Timaa	DSP1/DSP	164 Preset+3 User	92 Preset+3 User
	Effect Types	DSP2, 3, 4	88 Preset +10 User	_
		Master EQ	5 Preset + 2 User	_
		Part EQ	27 Parts	_
	Vocal Harmony		49 Preset +10 User	_
Accompaniment	Number of Accompaniment Styles		197	181
Style	Number of Ses	sion Styles		6
	Fingering		Single Finger, Fingered, Fingered On Bass, Multi Finger, Al Fingered, Full Keyboard, Al Full Keyboard	
	Style Creator		0	
	OTS (One Touch	Setting)	4/Accompaniment Style	
	OTS link		0	
	Music Finder		2500 (max.)	1200 (max.)
		Edit		
Song	Format	·	SMF (Format 0,1), ESEQ	
	Preset Songs		0	
	Lyrics		0	
	Score		0	
	Recording		Quick Recording, Multi Recording, Step Recording, Song Editing	
		Record Channels	1	6
Multi Pad	Preset		4 Pads X	54 Banks
Memory	Floppy Disk (2HD, 2DD)		0	
Device	Flash Memory (in	nternal)	1524KB 698KB	
	Flash Availability		Song (SMF), Style (SFF), Registration, Voice, etc.	
Tempo	Tempo Range		5 - 500	
	Tap Tempo		0	
	Metronome		0	
		Sound	Bell on/off	

Model Name		PSR-2100	PSR-1100		
Registration Buttons		8			
Memory	Regist Sequence	0	0		
	Freeze	0			
Others	Demo	Function, Vo	Function, Voice, Style		
	Language	6 languages (English, Japanese, Ge	6 languages (English, Japanese, German, French, Spanish, Italian)		
	Help	0			
	Direct Access	0			
	Master Volume	0			
	Fade In/Out	0			
	Transpose	Keyboard/Sor	ng/Master		
	Tuning	0			
	Scale		Equal Temperament, Pure Major/Pure Minor, Pythagorean, Mean-Tone, Werckmeister/Kirnberger, Arabic 1/2		
	Touch Response	5 leve	5 level		
Jacks/Connectors		FOOT PEDAL1 (SWITC	DC IN, PHONES, MIDI (OUT, IN), USB, FOOT PEDAL1 (SWITCH), FOOT PEDAL2, AUX OUT (LEVEL FIXED) (L/R), OUTPUT (L/L+R)		
		MIC (INPUT VOLUME, MIC./ LINE)	_		
Pedal Functions		VOLUME, SUSTAIN, SOSTENUTO, SOFT, GLIDE, PORTAMEN' PITCHBEND, MODULATION, DSP VARIATION, SONG START/S' STYLE START/STOP, etc.			
Amplifiers/	Amplifiers	12 W >	<b>K</b> 2		
Speakers	Speakers	[12 cm + 4 cm (dome)] X 2	(12 cm + 5 cm) X 2		
Power Consump	otion	31 W	31 W		
Power supply  Yamaha AC adaptor PA-300 (included)  *May not be included in your area. Please check with you					
Dimensions [W X D X H] (without Music Rest)			973 × 399 × 161 mm [38-5/16" × 15-11/16" × 6-5/16"]		
Weight		10.5 Kg (23 lbs., 2 oz)	10.0 Kg (22 lbs., 1 oz)		
Optional	Headphones	HPE-1	50		
accessories	Foot Switch	FC4 / F	FC5		
	Foot Controller	FC7	FC7		
	Keyboard Stand	L-6, L-	L-6, L-7s		

<sup>\*</sup> Specifications and descriptions in this owner's manual are for information purposes only. Yamaha Corp. reserves the right to change or modify products or specifications at any time without prior notice. Since specifications, equipment or options may not be the same in every locale, please check with your Yamaha dealer.

#### Index

Numerics	Cent138
1 - 16	Change the Rhythmic Feel116
[1▲▼] - [8▲▼] buttons	Changing Pitch-related Settings126
3BAND EQ (3-BAND EQUALIZER)	Changing the Automatically Selected Voice Settings146
3DAIND EQ (3-DAIND EQONEIZER)133	Changing the Icon49
A	Changing the Tone of the Voice
	Changing the Touch Sensitivity Modulation and Transpose 144
A (ACMP)	Channel
[A] - [J] buttons	Channel Messages160
Accent Type117	Channel Muting64
Accessories	CHANNEL ON/OFF
Accompaniment style parts	[CHANNEL ON / OFF] button19, 64, 81
[ACMP] button	Channel Transpose
ACMP TOUCH	CHD109
ADD TO FAVORITE	Chord
Adjust the Volume Balance and Changing Voices	Chord Detect
Adjusting the display contrast	Chard Financia (5, 142)
Adjusting the Effects	Chord Fingering
Adjusting the Vessel Harmony Settings	CHORD NOTE ONLY (HARMONY)93
Adjusting the Vocal Harmony Settings	Chord Tutor
and Microphone Effects	Chord Types Recognized in the Fingered Mode
Adjusting the Volume Balance	Chorus
Adjusting the Volume Balance / Muting Specific Channels 81 Adjusting values	
Al	Chorus Depth (Organ Flutes)
AI FINGERED	CHORUS DEPTH (Sound Creator)93 Clock149
AI FULL KEYBOARD65	COMMON91
A+L (ACMP + LEFT)	COMPARE90
Append	Compatible Song Types
Applying Voice Effects	COMPRESSOR
Appropriate Panel Setting for the Selected Style	CONFIG 1
Arabic	CONFIG 2
Arranging the Style Pattern	Connecting external MIDI devices
Assembling an Accompaniment Style	Connecting the Microphone or Guitar (PSR-2100 only)155
ASSIGN (HARMONY)	Connecting to a Computer
Attack (Organ Flutes) 94	Controller
ATTACK (Regular Voice)	Converting into Kanji (Japanese language)48
AUTO	Cool!
AUTO CH SET140	COPY
[AUTO FILL IN] button	Copying and Formatting Disks153
Auto Revoice	Copying Files/Folders46
Automatically Changing One Touch Settings	Copying from Disk to Disk153
with the Sections71	Creating Accompaniment Styles111
AUX OUT (LEVEL FIXED) [L] [R] jacks	Current Memory40
,	Customizing the Event List — Filter110
В	CUT45
BACK  button	
BALANCE	D
[BALANCE] button	Data Compatibility161
Bar Clear	[DATA ENTRY] dial
Bar Copy	Data Types in the MIDI TRANSMIT/RECEIVE Display149
Bar/Beat/Clock	DC IN terminal
Basic Operations — Organizing Your Data	DECAY
Bass	DELETE (Basic Operations)
BEAT	Delete (Song Creator)
Beat Converter	DELETE RECORD
Boost/Cut	Deleting Files/Folders
[BREAK] button	[DEMO] button
BRIGHTNESS	DEPTH93
	DESTINATION 106
C	Detailed Settings for Notation84
	[DIGITAL RECORDING] button14, 18, 95, 111
Calling Up Ideal Setups for Your Music72	1

1

[DIRECT ACCESS] button		F	
Direct Access Chart		Fade In Time, Fade Out Time, Fade Out Hold	Time 15
Disk		[FADE IN / OUT] button	
Disk drive		FAVORITE	
Disk format		[FF] button	
Disk Orchestra Collection		File	
DISPLAY VOICE NUMBER		File/Folder-related Operations	
Displaying Music Notation		Files/folders in a floppy disk	
Displaying the Lyrics		Fill	
Displaying Upper Level pages		Filter	
DOC		FILTER BRIGHT (Sound Creator)	
Drum		FILTER HARMO. (Sound Creator)	
[DSP] button		Fine	
DSP Depth (Organ Flutes)		FINGERED	
DSP DEPTH (Sound Creator)		FINGERED ON BASS	
DSP on/off (Organ Flutes)		First Key On	
DSP Type (Organ Flutes)		FLOPPY DISK drive	
Dynamics	11/	FLOPPY DISK SONG AUTO OPEN	
<b>.</b>		Floppy disk drive	
<u> </u>		FOOT PEDAL 1/2 jack	
ECHO	61, 146	FOOTAGE (Organ Flutes)	
Edit	114	Footage (Organ Flutes)	
Edit the Created Accompaniment Style	116	[FOOT PEDAL 1 (SWITCH)] jack	19, 156
Editing a Recorded Song	105	[FOOT PEDAL 2] jack	
Editing Channel-related Parameters	105	Formatting a Disk	
Editing Chord Events	109	[FREEZE] button	
Editing Note Events	108	Freeze	89, 145
Editing Records	74	FULL KEYBOARD	6!
Editing System Events	109	[FUNCTION] button	18, 136
Editing the Channel Data	118		
Editing Voices	90	G	
[EFFECT] button		Gate Time	100
Effect Block		GENRE	
Effect Connections		GENRE NAME	,
Effect Structure		GM System Level 1	
EFFECT/EQ		Groove	
EFFECT/EQ (Organ Flutes)		Groove parameters	
Effects		GROUP SELECT	
EG		GROOT SELECT	
EG ATTACK (Sound Creator)		Н	
EG DECAY (Sound Creator)			
EG RELES. (Sound Creator)	92	Handling the Floppy Disk Drive (FDD) and Flo	
Embellish and enhance your melodies		Harmonic Content	
— with the automatic Harmony and Echo effects		HARMONY	
END Mark		Harmony Assignments	
ENDING		Harmony Types	
[ENDING / rit.] button		[HARMONY / ECHO] button	
[ENTER] button		Headphones	
Entering Characters		Help messages can be displayed in any one of	
Entering Chords and Sections (Chord Step)		following languages	
Entering miscellaneous characters (marks)		[HELP] button	
Entering numbers	48	High Key	
Entering special character marks	40	Hz	138
(umlaut, accent, Japanese " " and " o ")			
Entering Your Name and Language Preference		<u> </u>	
EQ		ICON	49
EQ High (Organ Flutes)		ICON SELECT	49
EQ Low (Organ Flutes)		[INPUT VOLUME] knob	19, 155
Equal Temperament		Inputting and Editing Lyrics	
ESEQ		Instant Selection of Displays	
Example Keyboard Data		INTRO	69
[EXIT] button		[INTRO] button	18, 31, 67
Exit from Small Pop-up Windows			
Expand/Compress		K	
[EXTRA TRACKS (STYLE)] button	10, 82	Kbd.Vel	100
		KEY SIGNATURE	
			,

Keyboard Percussion	MULTI FINGER6	65
Keyboard Touch144	MULTI PAD [1] - [4] buttons	
Keyboard/Panel144	Multi Pads1	
KEYWORD73, 74	Multi Recording	
Kirnberger	[MUSIC FINDER] button15, 19, 33, 7	
Ü	Music Finder Record Edit	74
L	Music Finder Search	73
	Music Rest1	
Layer	Muting Specific Parts	32
Layering Two Different Voices59		
LCD	N	
[LCD CONTRAST] knob	NAME	 17
Left	Naming Files and Folders4	
LEFT CH84	NEW (Folder)4	
[LEFT HOLD] button	NEW RECORD	
Length (LENG) (Organ Flutes)	[NEXT] button	
Live!	NOISE GATE	
Local Control148	Normal10	
Loop recording111	Note Events10	
Lyrics86, 110	Note Limit	
LÝRICS LANGUAGE140	NOTE NAME	35
	Nrm10	00
M	NTR (Note Transposition Rule)11	19
MAIN A/B/C/D	NTT (Note Transposition Table)12	20
MAIN [A] button	NUMBER OF RECORDS	72
MAIN [B] button		
MAIN [D] button	0	
MAIN [D] button	OCTAVE	26
Maintaining Panel Settings	OCTAVE LEFT (Sound Creator)	
Making Global and Other Important Settings	OCTAVE MLYR (Sound Creator)	
Making Overall System Settings (Local Control, Clock, etc.)148	One Touch Setting	
Making Settings for Fade In/Out, Metronome,	ONE TOUCH SETTING [1] - [4] buttons	
Parameter Lock, and Tap151	Open/Save displays	
Making Settings for the Display	Organ Flutes15, 58, 9	
and Voice Number Indication152	Organ Type (Organ Flutes)	
Making Settings for the Pedals and Keyboard142	Organizing Files by Creating a New Folder4	
Making Settings for the Vocal Harmony and Microphone 133	Original Beat11	
Making Style File Format Settings119	Other Parameters in the Basic Display11	
Master Tune	Other Playback-related Operations	
[MASTER VOLUME] dial18, 17	Other Settings15	51
Mean-Tone139	OTS LINK TIMING14	41
[MEMORY] button19, 87	[OTS LINK] button18, 7	71
Message Switch149	OUTPUT [L / L+R] [R] jacks19, 15	
Messages8	OVERALL SETTING13	
Metronome	Overdub recording11	
[METRONOME] button	Owner	54
MIC	_	
MIC. buttons (PSR-2100 only)	P	
[MIC. LINE IN] jack	Pad	<u></u>
MICROPHONE SETTING	PAN (MIC.)	35
[MIC. SETTING] button	PANEL SUSTAIN (Sound Creator)	93
MIDI	Parameter11	19
MIDI [OUT] [IN] terminals	Parameter Lock15	
MIDI channels	PASTE45, 4	46
MIDI IN	Pedal14	
MIDI Receive Parts	PEDAL 1/2 POLARITY14	
MIDI SET UP	PEDAL PUNCH IN/OUT10	
MIDI terminals	Pedal-controllable Functions14	
Mix	[PHONES] jack	
[MIXING CONSOLE] button	Phrase	
Mode (Organ Flutes)94	Phrase Mark	
MODULATION	PHRASE MARK REPEAT14	
[MONO] button	PITCH BEND18, 6	
MONO POLY (Sound Creator)91	PITCH BEND RANGE	
Moving Files/Folders45	Pitch settings for each scale	
	Playback of Songs	<b>4</b> I

Playing a style28,		Repeat Playback of a Specific Range	
Playing a Style's Rhythm Channels only		[REPEAT] button1	
Playing Along with the PSR-2100/1100		Replace	
Playing Back Songs on Disk	.81	Resonance	92
Playing Different Voices with the Left and Right Hands	.27	Response (RESP) (Organ Flutes)	94
Playing Fill-in patterns automatically		Restoring the Factory-programmed Settings	
when changing accompaniment sections	.69	of the PSR-2100/1100	154
Playing Several Sounds Simultaneously		Reverb	129
Playing Styles		REVERB DEPTH (MIC.)	
Playing the Demos20,		Reverb Depth (Organ Flutes)	
Playing the Internal Songs		REVERB DEPTH (Sound Creator)	93
Playing the sounds of the PSR-2100/1100 through	., ,	[REW] button	
an external audio system, and recording the sounds		Rhythm	,
to an external recorder	156	RIGHT CH	
Playing Two Voices Simultaneously		Root	
Playing Voices		Rotary SP Speed (Organ Flutes)	
Playing with the Songs		RTR (Retrigger Rule)	120
PORTAMENT TIME (Sound Creator)		•	
PORTAMENTO TIME (Mixing Console)1		S	
Power Supply		S.STOP WINDOW	141
Powering Up		SAVE	
Power-on Procedure	.16	Save	
PRESET drive40,	41	Saving Files	
Preset MIDI Templates1	48	Saving Your Registration Memory Setups	
Punch In/Out1			
Pure Major1	39	Scale	
Pure Minor1		Scale Tune	
Pythagorean1		Score (PSR-2100 only)	
, triagorean		Searching the Ideal Setups	
n		Searching the Music Finder Records	34
<del></del>		Section button indications	
QUANTIZE		— [BREAK], [INTRO], [MAIN], [ENDING] buttons	67
Quantize105, 1	18	SECTION SET	141
Quantize Size1	05	Sections	30
Quick Recording	.96	Select the Recording Options: Starting, Stopping,	
QUICK START1		Punching In/Out	104
Quick Start1		Selecting a Scale	
•		Selecting a Voice	
R		Selecting Files and Folders	
		Selecting Intro and Ending Types	
Realtime Recording1		Selecting items	
Realtime Recording Characteristics1	11	Selecting the Freeze Settings	
REC] button18,		SEQUENCE END	
REC END1	04		
Rec Mode1	04	Sequence Format	
REC START1	04	Sequencer	
Recalling a Registration Memory Setup	.89	Set Up	
Recalling the Registered Settings		Setting Auto Accompaniment-related Parameters	
Receive1		Setting Chord Channels	
Receive Transpose1		Setting Harmony and Echo	
Receiving MIDI Data		Setting Root Note Channels	150
Record		Setting Separate Voices for the Left and Right Sections	
RECORD EDIT		of the Keyboard	60
		Setting Song-related Parameters	140
Recording		Setting the Fingering Method	
Recording Chord Changes for the Auto Accompaniment 1		Setting the Level Balance and Voice	
Recording Individual Notes		Setting the Microphone Volume and Related Effects	
Recording Melodies1		Setting the MIDI Parameters	
Recording Your Performances and Creating Songs		Setting the Registration Sequence, Freeze, and Voice Set	
Registering Panel Setups		Setting the volume	
Registering the Panel Controls in One Touch Setting		SFX	
REGISTRATION EDIT display	.88		
Registration Memory		Simultaneously Playing a Song and an Accompaniment Style	
REGISTRATION MEMORY [1] – [8] buttons19,		SINGLE FINGER	
REGISTRATION MEMORY CONTENTS		SMF (Standard MIDI File)	
Registration Sequence1		Song	
Regular Voice Parameters		SONG [START / STOP] button1	
RELEASE		SONG AUTO REVOICE	
Remove Event		SONG CHAIN PLAY	
10111010 E10111		Song Croator	O.F.

Song Playback	
3011g 1 1ay back	.21, 78, 79
Song Recording	
Song Settings	
SORT BY	
SORT ORDER	
SOUND (SOUND CREATOR)	
[SOUND CREATOR] button	18 90
Source Root/Chord	
SOURCE1	
SOURCE2	
Specifying the Order for Calling Up Registration Me	
Presets	
SPEED	
SPEED (HARMONY)	
Split Point	
[STANDBY/ON] switch	
START SEARCH	73
Step Record	
Step Record (Chord)	102
Step Record (Note)	101
Step Recording	
STOP ACMP	
[STOP] button (MULTI PAD)	
Stopping the Style Playback While Releasing Keys	68
Strength	117
Style	14, 62
STYLE [START / STOP] button	18, 63
STYLE buttons	
Style Creator	
Style File	17 162
Style File Format	
Style Sections	
Style Setting	
Sustain	
[SUSUTAIN] button	
Sweet!	
SWING	
ICVAIC CTARTI I	116
[SYNC.START] button	18, 63
[SYNC.START] button	18, 63 18, 68
[SYNC.START] button	18, 63 18, 68 109
[SYNC.START] button	18, 63 18, 68 109 148
[SYNC.START] button	18, 63 18, 68 109 148 129
[SYNC.START] button	18, 63 18, 68 109 148 129 109
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System. System and Insertion System Events System Messages	18, 63 18, 68 109 148 129 109
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System. System and Insertion System Events System Messages System Reset.	18, 63 18, 68 109 148 129 109 151
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System. System and Insertion System Events System Messages	18, 63 18, 68 109 148 129 109 151
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System. System and Insertion System Events System Messages System Reset. SYSTEM SET UP	18, 63 18, 68 109 148 129 109 151
[SYNC.START] button	18, 63 18, 68 109 148 129 109 151
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive) System System and Insertion System Events System Messages System Reset SYSTEM SET UP  T	18, 63 18, 68 109 148 129 161 154
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive) System System and Insertion System Events System Messages System Reset SYSTEM SET UP  T  [TALK] button	18, 63 18, 68 109 148 129 161 154 154
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System. System and Insertion System Events. System Messages System Reset. SYSTEM SET UP.  T [TALK] button. TALK SETTING.	18, 6318, 68109148109161154154
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System. System and Insertion System Events System Messages System Reset. SYSTEM SET UP.  T  [TALK] button. TALK SETTING. Tap Count.	18, 6318, 68109129161154154154
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System. System and Insertion System Events System Messages System Reset. SYSTEM SET UP.  T  [TALK] button. TALK SETTING. Tap Count. [TAP TEMPO] button.	18, 6318, 68109129161154154154
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System. System and Insertion System Events System Messages System Reset. SYSTEM SET UP   T  [TALK] button TALK SETTING Tap Count [TAP TEMPO] button TEMPO [◀] [▶] buttons	18, 6318, 6810912916115415415, 13518, 5418, 53
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System. System and Insertion System Events System Messages System Reset. SYSTEM SET UP.   T  [TALK] button TALK SETTING Tap Count [TAP TEMPO] button TEMPO [ ◀ ] [ ▶] buttons TEMPO FROM	18, 6318, 68109148109161154154154174
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive).  System.  System and Insertion System Events System Messages System Reset. SYSTEM SET UP   [TALK] button. TALK SETTING Tap Count [TAP TEMPO] button. TEMPO [ ◀ ] [ ▶] buttons TEMPO FROM Tempo Indications — MAIN Display.	18, 6318, 6810912916115415415, 13518, 53
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System. System and Insertion System Events. System Messages System Reset. SYSTEM SET UP   T  [TALK] button. TALK SETTING Tap Count [TAP TEMPO] button. TEMPO [ ◀ ] [ ▶ ] buttons TEMPO FROM. Tempo Indications — MAIN Display. TEMPO TO	18, 6318, 6810912910915415415415, 13515, 13515, 135
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System. System and Insertion System Events System Messages System Reset. SYSTEM SET UP   T  [TALK] button TALK SETTING Tap Count [TAP TEMPO] button TEMPO [ ◀ ] [ ▶] buttons TEMPO FROM Tempo Indications — MAIN Display TEMPO TO [TOP] button	18, 6318, 6819910910915415415415, 13115, 13518, 5418, 53
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System System and Insertion System Events System Messages System Reset SYSTEM SET UP   T  [TALK] button TALK SETTING Tap Count [TAP TEMPO] button TEMPO [ ◀ ] [ ▶ ] buttons TEMPO FROM Tempo Indications — MAIN Display TEMPO TO [TOP] button TOTAL VOLUME ATTENUATOR (MIC.)	18, 6318, 6810912916115415415518, 5318, 537318, 81135
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System System and Insertion System Events System Messages System Reset SYSTEM SET UP   T  [TALK] button TALK SETTING Tap Count [TAP TEMPO] button TEMPO [ ◀ ] [ ▶ ] buttons TEMPO FROM Tempo Indications — MAIN Display TEMPO TO [TOP] button TOTAL VOLUME ATTENUATOR (MIC.) TOUCH LIMIT (HARMONY)	18, 6318, 6810912910915415415415515518, 537318, 81
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System. System and Insertion System Events. System Messages System Reset. SYSTEM SET UP   T  [TALK] button. TALK SETTING. Tap Count. [TAP TEMPO] button. TEMPO [ ◀ ] [ ▶ ] buttons TEMPO FROM. TEMPO TO. [TOP] button. TOTAL VOLUME ATTENUATOR (MIC.) TOUCH LIMIT (HARMONY). TOUCH SENSE (Sound Creator)	18, 6318, 6810912910915415415415515218, 5318, 535418, 53
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System System and Insertion System Events. System Messages System Reset. SYSTEM SET UP    T  [TALK] button. TALK SETTING Tap Count [TAP TEMPO] button. TEMPO [ ◀ ] [ ▶ ] buttons TEMPO FROM Tempo Indications — MAIN Display. TEMPO TO [TOP] button.  TOTAL VOLUME ATTENUATOR (MIC.) TOUCH SENSE (Sound Creator) [TOUCH] button.	18, 6318, 6810914812916115415415515218, 5318, 5318, 53
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System System and Insertion System Events. System Messages System Reset. SYSTEM SET UP   T  [TALK] button. TALK SETTING Tap Count [TAP TEMPO] button. TEMPO [ ◀ ] [ ▶ ] buttons TEMPO FROM Tempo Indications — MAIN Display. TEMPO TO [TOP] button TOTAL VOLUME ATTENUATOR (MIC.) TOUCH LIMIT (HARMONY). TOUCH SENSE (Sound Creator) [TOUCH] button [TRACK 1 (R)] button.	18, 6318, 6810914812910915415415418, 5318, 5318, 53135135135135
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System System and Insertion System Events. System Messages System Reset. SYSTEM SET UP   T  [TALK] button. TALK SETTING. Tap Count [TAP TEMPO] button. TEMPO [ ◀ ] [ ▶ ] buttons TEMPO FROM. Tempo Indications — MAIN Display. TEMPO TO [TOP] button. TOTAL VOLUME ATTENUATOR (MIC.) TOUCH LIMIT (HARMONY). TOUCH SENSE (Sound Creator) [TOUCH] button. [TRACK 1 (R)] button. [TRACK 2 (L)] button.	18, 6318, 6810914812916115415418, 5318, 537318, 5413554
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System System and Insertion System Events. System Messages System Reset. SYSTEM SET UP   T  [TALK] button. TALK SETTING Tap Count [TAP TEMPO] button. TEMPO [ ◀ ] [ ▶ ] buttons TEMPO FROM Tempo Indications — MAIN Display. TEMPO TO [TOP] button TOTAL VOLUME ATTENUATOR (MIC.) TOUCH LIMIT (HARMONY). TOUCH SENSE (Sound Creator) [TOUCH] button [TRACK 1 (R)] button. TTRACK 2 (L)] button. Transmit	18, 6318, 6810914812916115415415515218, 5318, 5354
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System System and Insertion System Events. System Messages System Reset. SYSTEM SET UP   T  [TALK] button. TALK SETTING. Tap Count [TAP TEMPO] button. TEMPO [◀] [▶] buttons TEMPO FROM Tempo Indications — MAIN Display. TEMPO TO. [TOP] button. TOTAL VOLUME ATTENUATOR (MIC.) TOUCH LIMIT (HARMONY). TOUCH SENSE (Sound Creator) [TOUCH] button. [TRACK 1 (R)] button. Transmit. Transmit. Transmit Clock.	18, 6318, 6810914812916115415415415518, 5354
[SYNC.START] button [SYNC.STOP] button SYS/EX. (System Exclusive). System System and Insertion System Events. System Messages System Reset. SYSTEM SET UP   T  [TALK] button. TALK SETTING Tap Count [TAP TEMPO] button. TEMPO [ ◀ ] [ ▶ ] buttons TEMPO FROM Tempo Indications — MAIN Display. TEMPO TO [TOP] button TOTAL VOLUME ATTENUATOR (MIC.) TOUCH LIMIT (HARMONY). TOUCH SENSE (Sound Creator) [TOUCH] button [TRACK 1 (R)] button. TTRACK 2 (L)] button. Transmit	18, 6318, 6810914812916115415415518, 5418, 53547318, 8113513518, 81135149149

Transpose Assign	144
Tune	126
TUNING	
Tuning the Overall Pitch	138
TYPE (HARMONY)	93
U	
[UPPER OCTAVE] button	
USB	17
[USB] terminal	
USER drive	
USER EFFECT (Function)	154
User Effect (Mixing Console)	
Using a Microphone	
Using the Music Finder	33
Using Your PSR-2100/1100 with Other Devices	155
Utility	151
V	
[VARIATION] button	
Variation (Organ Flutes)	
Velocity	
Velocity Change	10 121
	,
VIBRATO DELAY (Saved Constant)	
VIBRATO DELAY (Sound Creator)	92
Vibrato Depth (Organ Flutes)	
VIBRATO DEPTH (Sound Creator)	
Vibrato On/Off (Organ Flutes)	94
VIBRATO SPEED (Sound Creator)	
Vibrato Speed (VIB. SPEED) (Organ Flutes)	
[VOCAL HARMONY] button	
Vocal Harmony	
VOCAL HARMONY CONTROL	
Vocal Harmony Type	
Voice Allocation Format	
VOICE buttons	
Voice Characteristics	
Voice Effects	
VOICE PART ON / OFF [LAYER] button	
VOICE PART ON / OFF [LEFT] button	
VOICE PART ON / OFF [MAIN] button	,
Voice Set	
VOL/ATTACK (Organ Flutes)	
VOLUME (HARMONY)	
VOLUME (MIC.)	
VOLUME (Sound Creator)	
Volume (VOL) (Organ Flutes)	
Volume/Voice	125
W	
Werckmeister	139
What You Can Do With MIDI	161
What's MIDI?	158
X	
XF	17, 162
XG	17, 162

MEMO

## Limited Warranty

#### 90 DAYS LABOR

#### 1 YEAR PARTS

Yamaha Corporation of America, hereafter referred to as Yamaha, warrants to the original consumer of a product included in the categories listed below, that the product will be free of defects in materials and/or workmanship for the periods indicated. This warranty is applicable to all models included in the following series of products:

#### **PSR SERIES OF PORTATONE ELECTRONIC KEYBOARDS**

If during the first 90 days that immediately follows the purchase date, your new Yamaha product covered by this warranty is found to have a defect in material and/or workmanship, Yamaha and/or its authorized representative will repair such defect without charge for parts or labor.

If parts should be required after this 90 day period but within the one year period that immediately follows the purchase date, Yamaha will, subject to the terms of this warranty, supply these parts without charge. However, charges for labor, and/or any miscellaneous expenses incurred are the consumers responsibility. Yamaha reserves the right to utilize reconditioned parts in repairing these products and/or to use reconditioned units as warranty replacements.

THIS WARRANTY IS THE ONLY EXPRESS WARRANTY WHICH YAMAHA MAKES IN CONNECTION WITH THESE PRODUCTS. ANY IMPLIED WARRANTY APPLICABLE TO THE PRODUCT, INCLUDING THE WARRANTY OF MERCHANT ABILITY IS LIMITED TO THE DURATION OF THE EXPRESS WARRANTY. YAMAHA EXCLUDES AND SHALL NOT BE LIABLE IN ANY EVENT FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Some states do not allow limitations that relate to implied warranties and/or the exclusion of incidental or consequential damages. Therefore, these limitations and exclusions may not apply to you.

This warranty gives you specific legal rights. You may also have other rights which vary from state to state.

#### **CONSUMERS RESPONSIBILITIES**

If warranty service should be required, it is necessary that the consumer assume certain responsibilities:

- 1. Contact the Customer Service Department of the retailer selling the product, or any retail outlet authorized by Yamaha to sell the product for assistance. You may also contact Yamaha directly at the address provided below.
- 2. Deliver the unit to be serviced under warranty to: the retailer selling the product, an authorized service center, or to Yamaha with an explanation of the problem. Please be prepared to provide proof purchase date (sales receipt, credit card copy, etc.) when requesting service and/or parts under warranty.
- 3. Shipping and/or insurance costs are the consumers responsibility.\* Units shipped for service should be packed securely.
  - \*Repaired units will be returned PREPAID if warranty service is required within the first 90 days.
  - **IMPORTANT:** Do NOT ship anything to ANY location without prior authorization. A Return Authorization (RA) will be issued that has a tracking number assigned that will expedite the servicing of your unit and provide a tracking system if needed.
- 4. Your owners manual contains important safety and operating instructions. It is your responsibility to be aware of the contents of this manual and to follow all safety precautions.

#### **EXCLUSIONS**

This warranty does not apply to units whose trade name, trademark, and/or ID numbers have been altered, defaced, exchanged removed, or to failures and/or damages that may occur as a result of:

- 1. Neglect, abuse, abnormal strain, modification or exposure to extremes in temperature or humidity.
- 2. Improper repair or maintenance by any person who is not a service representative of a retail outlet authorized by Yamaha to sell the product, an authorized service center, or an authorized service representative of Yamaha.
- 3. This warranty is applicable only to units sold by retailers authorized by Yamaha to sell these products in the U.S.A., the District of Columbia, and Puerto Rico. This warranty is not applicable in other possessions or territories of the U.S.A. or in any other country.

Please record the model and serial number of the product you have purchased in the spaces provided below.

Model	Serial #	Sales Slip #
		_
Purchased from		Date
(Retailer)		

YAMAHA CORPORATION OF AMERICA

Electronic Service Division 6600 Orangethorpe Avenue Buena Park, CA 90620

**KEEP THIS DOCUMENT FOR YOUR RECORDS. DO NOT MAIL!** 

#### **FCC INFORMATION (U.S.A.)**

#### 1. IMPORTANT NOTICE: DO NOT MODIFY THIS UNIT!

This product, when installed as indicated in the instructions contained in this manual, meets FCC requirements. Modifications not expressly approved by Yamaha may void your authority, granted by the FCC, to use the product.

- IMPORTANT: When connecting this product to accessories and/or another product use only high quality shielded cables. Cable/s supplied with this product MUST be used. Follow all installation instructions. Failure to follow instructions could void your FCC authorization to use this product in the USA.
- 3. **NOTE:** This product has been tested and found to comply with the requirements listed in FCC Regulations, Part 15 for Class "B" digital devices. Compliance with these requirements provides a reasonable level of assurance that your use of this product in a residential environment will not result in harmful interference with other electronic devices. This equipment generates/ uses radio frequencies and, if not installed and used according to the instructions found in the users manual, may cause interference harmful to the operation of

other electronic devices. Compliance with FCC regulations does not guarantee that interference will not occur in all installations. If this product is found to be the source of interference, which can be determined by turning the unit "OFF" and "ON", please try to eliminate the problem by using one of the following measures: Relocate either this product or the device that is being affected by the interference.

Utilize power outlets that are on different branch (circuit breaker or fuse) circuits or install AC line filter/s.

In the case of radio or TV interference, relocate/reorient the antenna. If the antenna lead-in is 300 ohm ribbon lead, change the lead-in to co-axial type cable.

If these corrective measures do not produce satisfactory results, please contact the local retailer authorized to distribute this type of product. If you can not locate the appropriate retailer, please contact Yamaha Corporation of America, Electronic Service Division, 6600 Orangethorpe Ave, Buena Park, CA90620

The above statements apply ONLY to those products distributed by Yamaha Corporation of America or its subsidiaries.

(class B)

#### **OBSERVERA!**

Apparaten kopplas inte ur växelströmskällan (nätet) så länge som den ar ansluten till vägguttaget, även om själva apparaten har stängts av.

**ADVARSEL:** Netspæendingen til dette apparat er IKKE afbrudt, sálæenge netledningen siddr i en stikkontakt, som er t endt — også selvom der or slukket på apparatets afbryder.

**VAROITUS:** Laitteen toisiopiiriin kytketty käyttökytkin ei irroita koko laitetta verkosta.

(standby)

<sup>\*</sup> This applies only to products distributed by YAMAHA CORPORATION OF AMERICA.

For details of products, please contact your nearest Yamaha representative or the authorized distributor listed below.

Pour plus de détails sur les produits, veuillez-vous adresser à Yamaha ou au distributeur le plus proche de vous figurant dans la liste suivante.

Die Einzelheiten zu Produkten sind bei Ihrer unten aufgeführten Niederlassung und bei Yamaha Vertragshändlern in den jeweiligen Bestimmungsländern erhältlich.

Para detalles sobre productos, contacte su tienda Yamaha más cercana o el distribuidor autorizado que se lista debajo.

#### **NORTH AMERICA**

#### **CANADA**

Yamaha Canada Music Ltd.

135 Milner Avenue, Scarborough, Ontario, M1S 3R1, Canada Tel: 416-298-1311

Yamaha Corporation of America

6600 Orangethorpe Ave., Buena Park, Calif. 90620, U.S.A

Tel: 714-522-9011

#### **CENTRAL & SOUTH AMERICA**

#### MEXICO

Yamaha de Mexico S.A. De C.V., Departamento de ventas

Javier Rojo Gomez No.1149, Col. Gpe Del Moral, Deleg. Iztapalapa, 09300 Mexico, D.F. Tel: 686-00-33

Yamaha Musical do Brasil LTDA.

Av. Rebouças 2636, São Paulo, Brasil Tel: 011-853-1377

#### **ARGENTINA**

Yamaha de Panamá S.A. Sucursal de Argentina

Viamonte 1145 Piso2-B 1053, Buenos Aires, Argentina Tel: 1-4371-7021

#### PANAMA AND OTHER LATIN AMERICAN COUNTRIES CARIBBEAN COUNTRIES

Yamaha de Panamá S.A.

Torre Banco General, Piso 7, Urbanización Marbella, Calle 47 y Aquilino de la Guardia, Ciudad de Panamá, Panamá Tel: +507-269-5311

#### **EUROPE**

#### THE UNITED KINGDOM

Yamaha-Kemble Music (U.K.) Ltd.

Sherbourne Drive, Tilbrook, Milton Keynes, MK7 8BL, England Tel: 01908-366700

#### **IRELAND**

Danfay Ltd.

61D, Sallynoggin Road, Dun Laoghaire, Co. Dublin Tel: 01-2859177

Yamaha Music Central Europe GmbH

Siemensstraße 22-34, 25462 Rellingen, Germany Tel: 04101-3030

#### SWITZERLAND/LIECHTENSTEIN

Yamaha Music Central Europe GmbH, **Branch Switzerland** 

Seefeldstrasse 94, 8008 Zürich, Switzerland Tel: 01-383 3990

#### **AUSTRIA**

Yamaha Music Central Europe GmbH, **Branch Austria** 

Schleiergasse 20, A-1100 Wien, Austria Tel: 01-60203900

#### THE NETHERLANDS

Yamaha Music Central Europe Branch Nederland

Clarissenhof 5-b, 4133 AB Vianen, The Netherlands Tel: 0347-358 040

#### BELGIUM/LUXEMBOURG

Yamaha Music Central Europe GmbH,

Branch Belgium

Rue de Geneve (Genevastraat) 10, 1140 - Brussels, Belgium Tel: 02-726 6032

#### Yamaha Musica Italia S.P.A. Combo Division

Viale Italia 88, 20020 Lainate (Milano), Italy Tel: 02-935-771

**Division Professionnelle** 

Tel: 01-64-61-4000

#### SPAIN/PORTUGAL

Yamaha-Hazen Música, S.A.

Yamaha Musique France, S.A.

BP 70-77312 Marne-la-Vallée Cedex 2, France

Ctra. de la Coruna km. 17, 200, 28230 Las Rozas (Madrid), Spain Tel: 91-201-0700

#### GREECE

**FRANCE** 

Philippos Nakas S.A. The Music House

147 Skiathou Street, 112-55 Athens, Greece Tel: 01-228 2160

#### **SWEDEN**

Yamaha Scandinavia AB

J. A. Wettergrens Gata 1 Box 30053 S-400 43 Göteborg, Sweden Tel: 031 89 34 00

#### DENMARK

YS Copenhagen Liaison Office

Generatorvej 8B DK-2730 Herley, Denmark Tel: 44 92 49 00

#### FINLAND

F-Musiikki Oy

Kluuvikatu 6, P.O. Box 260, SF-00101 Helsinki, Finland Tel: 09 618511

#### NORWAY

Norsk filial av Yamaha Scandinavia AB

Grini Næringspark 1 N-1345 Østerås, Norway Tel: 67 16 77 70

#### **ICELAND**

Skifan HF

Skeifan 17 P.O. Box 8120 IS-128 Reykjavik, Iceland Tel: 525 5000

#### OTHER EUROPEAN COUNTRIES

Yamaha Music Central Europe GmbH

Siemensstraße 22-34, 25462 Rellingen, Germany Tel: +49-4101-3030

#### **AFRICA**

Yamaha Corporation,

Asia-Pacific Music Marketing Group Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650

Tel: +81-53-460-2312

#### MIDDLE EAST

#### TURKEY/CYPRUS

Yamaha Music Central Europe GmbH

Siemensstraße 22-34, 25462 Rellingen, Germany Tel: 04101-3030

#### OTHER COUNTRIES

Yamaha Music Gulf FZE

LB21-128 Jebel Ali Freezone P.O.Box 17328, Dubai, U.A.E. Tel: +971-4-881-5868

#### **ASIA**

#### HONG KONG

Tom Lee Music Co., Ltd.

11/F., Silvercord Tower 1, 30 Canton Road, Tsimshatsui, Kowloon, Hong Kong Tel: 2737-7688

#### INDONESIA

PT. Yamaha Music Indonesia (Distributor) PT. Nusantik

Gedung Yamaha Music Center, Jalan Jend, Gatot Subroto Kav. 4, Jakarta 12930, Indonesia Tel: 21-520-2577

Yamaha Music Korea Ltd.

Tong-Yang Securities Bldg. 16F 23-8 Yoido-dong, Youngdungpo-ku, Seoul, Korea Tel: 02-3770-0661

Yamaha Music Malaysia, Sdn., Bhd.

Lot 8, Jalan Perbandaran, 47301 Kelana Jaya, Petaling Jaya, Selangor, Malaysia Tel: 3-703-0900

#### PHILIPPINES

Yupangco Music Corporation

339 Gil J. Puyat Avenue, P.O. Box 885 MCPO, Makati, Metro Manila, Philippines Tel: 819-7551

#### SINGAPORE

Yamaha Music Asia Pte., Ltd.

11 Ubi Road #06-00, Meiban Industrial Building, Singapore Tel: 65-747-4374

#### TAIWAN

Yamaha KHS Music Co., Ltd.

3F, #6, Sec.2, Nan Jing E. Rd. Taipei. Taiwan 104, R.O.C. Tel: 02-2511-8688

#### THAILAND

Siam Music Yamaha Co., Ltd.

121/60-61 RS Tower 17th Floor, Ratchadaphisek RD., Dindaeng, Bangkok 10320, Thailand Tel: 02-641-2951

#### THE PEOPLE'S REPUBLIC OF CHINA AND OTHER ASIAN COUNTRIES

Yamaha Corporation, Asia-Pacific Music Marketing Group

Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650 Tel: +81-53-460-2317

#### **OCEANIA**

#### **AUSTRALIA**

Yamaha Music Australia Pty. Ltd.

Level 1, 99 Queensbridge Street, Southbank, Victoria 3006, Australia Tel: 3-9693-5111

#### **NEW ZEALAND**

Music Houses of N.Z. Ltd.

146/148 Captain Springs Road, Te Papapa, Auckland, New Zealand Tel: 9-634-0099

#### COUNTRIES AND TRUST TERRITORIES IN PACIFIC OCEAN

Yamaha Corporation,

Asia-Pacific Music Marketing Group

Nakazawa-cho 10-1, Hamamatsu, Japan 430-8650 Tel: +81-53-460-2312



Yamaha PK CLUB (Portable Keyboard Home Page, English only) http://www.yamahaPKclub.com/

Yamaha Manual Library

http://www2.yamaha.co.jp/manual/english/