

ご 注 意

フレーズのあるトラック（LOOP/ONE SHOT インジケーターが点灯するトラック）が選ばれている状態で電源を投入すると、LOOP/ONE SHOT インジケーターがしばらくの間、高速点滅します。

LOOP/ONE SHOT インジケーターの高速点滅中に電源を切ると、保存しているデータがすべて失われる場合があります。

LOOP/ONE SHOT インジケーターの高速点滅中には、絶対に電源を切らないでください。

トラブル防止のため、空のフレーズ・トラックがある場合には、空のフレーズ・トラックが選ばれている状態で電源を切る／入れるようにしてください。

■ 電源を切るときの注意

電源を切る（OUTPUT ジャックからプラグを抜く）ときは、以下の状態であることを必ず確認してください。

不用意に電源を切ると、保存しているデータがすべて失われる場合があります。

- フレーズの録音／再生／オーバーダビングをしていない（REC/PLAY/DUB のインジケーターが消灯している）
- MODE つまみが AUTO、●/▶、♪ いずれかの位置にある
- LOOP/ONE SHOT インジケーターが高速点滅していない

NOTES

When turning on the power while a recorded track is being selected (the LOOP/ONE SHOT indicator is lit), the indicators on the front panel flash in a sequential order, and the LOOP/ONE SHOT indicator flashes rapidly for a few seconds.

Turning off the power while the LOOP/ONE SHOT indicator is still flashing rapidly may result in the loss of all saved data.

Never turn off the power while the LOOP/ONE SHOT indicator is flashing rapidly.

To avoid problems, select an empty phrase track whenever possible before turning the power on/off.

■ **Caution when turning off the power**

Before you turn off the power (disconnect the plug from the OUTPUT jack), make sure that all of the following conditions are satisfied.

All saved data may be lost if the power is turned off inappropriately.

- You must not be recording/playing/overdubbing a phrase (The REC/PLAY/DUB indicators must not be lit)
- The MODE knob is set to either AUTO, ●/▶, or ♪
- The LOOP/ONE SHOT indicator is not flashing rapidly