

# WARNING BEFORE PLAYING

The tension of the head was loosened before this instrument left the factory. DO NOT strike the head while it remains in this loosened state; you risk damaging the sensor if you do so. Make sure to adjust the head tension before use.

Using the tuning key included with the instrument, tighten the head evenly until the desired feel is achieved. With appropriate tension, the response should be about the same as that of an acoustic drum (as a rough guide, tighten the tuning bolts about one-half to three-quarters of a turn from their positions as shipped).

For details, refer to the Owner's Manual.

## 演奏前のご注意

この楽器はヘッドの張り具合をゆるめた状態で出荷されています。ヘッドの張りがゆるんだ状態でヘッドをたたくと、センサーを破損する事がありますので、ご使用になる前に必ずヘッドの張り具合を調節してください。付属のチューニング・キーを使って好みの打感触が得られるように均一に締めます。張り具合はアコースティック・ドラムの打感触と同じくらいが適当です。(目安としては、出荷時の状態から 1/2 周 ~ 3/4 周程度です。) 詳しくは、取扱説明書をご覧ください。

© 2005 ローランド株式会社

本書の一部、もしくは全部を無断で複写・転載することを禁じます。

Copyright © 2005 ROLAND CORPORATION

All rights reserved. No part of this publication may be reproduced in any form  
without the written permission of ROLAND CORPORATION.