


Assemble the BKT-8




- Should you remove knob bolt, make sure to put them in a safe place out of children's reach, so there is no chance of them being swallowed accidentally.
- When turning the unit upside-down, get a bunch of newspapers or magazines, and place them under the four corners or at both ends to prevent damage to the buttons and controls. Also, you should try to orient the unit so no buttons or controls get damaged.
- When attaching the VK-8M to the stand (PDS-15), be sure to spread the legs of the stand (PDS-15) completely.

■ Attaching the BKT-8 to the VK-8M


- 1 Remove the screws indicated by the arrows on the underside of the VK-8M.



- 2 Fit the BKT-8's tabs onto the VK-8M's bottom panel.




- 3 Align the screw holes of the BKT-8 with those of the VK-8M.
- 4 Fasten the BKT-8 and VK-8M using the screws removed in Step 1.




■ Attaching the VK-8M to the Stand (PDS-15)

- 5 Align the VK-8M's screw holes with the screw holes in the PDS-15 stand holder.



- 6 Use the knob bolt included with the BKT-8 to secure the VK-8M to the PDS-15 stand holder.




BKT-8 の取り付けかた




- ・ ノブ・ボルトを外した場合は、小さなお子様が悪く飲んで飲み込んでしまうことのないようお子様の手の届かないところへ保管してください。
- ・ 本体を裏返す際は、ボタン、つまみなどを破損しないように、新聞や雑誌などを重ねて本体の四隅や両端に敷いてください。また、その際、ボタン、つまみなどが破損しないような位置に配置してください。
- ・ VK-8Mをスタンド (PDS-15) に取り付ける場合は、スタンド (PDS-15) の脚をいっぱいまで開いてください。

■ VK-8M に BKT-8 を取り付ける

1. VK-8M 底面の↑マークがついている位置のネジを取り外します。




2. BKT-8 のつめを VK-8M の底板に引っかけます。




3. BKT-8 と VK-8M のネジ穴を合わせます。

4. 操作 1 で取り外したネジで、BKT-8 と VK-8M を固定します。



■ VK-8M をスタンド (PDS-15) に取り付ける

5. VK-8M のネジ穴と PDS-15 のスタンド・ホルダーにあるネジ穴を合わせます。



6. BKT-8 に付属されているノブ・ボルトで、VK-8M と PDS-15 のスタンド・ホルダーを固定します。

