

Before using this unit, carefully read the sections entitled: "USING THE UNIT SAFELY" and "IMPORTANT NOTES" (p. 2; p. 4). These sections provide important information concerning the proper operation of the unit. Additionally, in order to feel assured that you have gained a good grasp of every feature provided by your new unit, Owner's manual should be read in its entirety. The manual should be saved and kept on hand as a convenient reference.

この機器を正しくお使いいただくために、ご使用前に「安全上のご注意」(P.3) と「使用上のご注意」(P.4) をよくお読みください。また、この機器の優れた機能を十分ご理解いただくためにも、この取扱説明書をよくお読みください。取扱説明書は必要なときにすぐに見ることができるよう、手元に置いてください。

Thank you, and congratulations on your choice of the SRX-09 "SR-JV80 Collection Vol.4 World Collection" Wave Expansion Board.

This expansion board contains all of the waveforms in the SR-JV80-05 World, SR-JV80-14 World Collection "Asia," and SR-JV80-18 World Collection "LATIN," along with specially selected titles from waveforms contained in the 17 Country Collection. This board contains new Patches and Rhythm Sets which combine the waveforms in a manner that highlights the benefits of SRX Effects and Matrix Control. This board contains all kinds of unique string, wind, and percussion instrument sounds, used in ethnic music from Africa, Asia, the Middle East, South and North America, Australia, and Europe.

- Patches: 414
- Rhythm Sets: 12
- Waveforms: 873

Some of the waveforms used on this board are specially selected from waveforms found on the CD-ROM "Whole Lotta Country," produced by SAMPLEHEADS, creator of many high-quality sound libraries.

- * The parameter settings for Patches and Rhythm Sets are optimized for the Fantom series, XV series, MX-200, RD series with SRX slots, MC-909, VR-760, and G-70 models, so there are some minor differences in the sounds each instrument produces.

The included CD-ROM contains data reproducing the original sounds of the SR-JV80-05, SR-JV80-14, and SR-JV80-18. (Compatible models: Fantom (FA-76), XV-5080, XV-5050, XV-3080, XV-88, XV-2020)

This expansion board utilizes a new format. Check the system program version for your instrument, and if a relevant upgrade is available, upgrade your instrument using the appropriate system update program on the included CD-ROM. (See p. 23.)
This program applies to the SRX-01~09.

このたびは、ウェーブ・エクスパンション・ボード SRX-09 「SR-JV80 Collection Vol.4 World Collection」をお買い上げいただき、まことにありがとうございます。

このエクスパンション・ボードは SR-JV80-05 World、14 World Collection "Asia"、18 World Collection "LATIN" に搭載されていたウェーブフォームを完全収録、17 Country Collection に搭載されていたウェーブフォームから一部タイトルを厳選して収録しています。これらのウェーブフォームを組み合わせた SRX 仕様の Effect、Matrix Control を生かした新規 パッチ、リズム・セットを搭載しています。

アフリカ、アジア、中近東、南米、北米、オーストラリア、ヨーロッパ等、世界中のユニークで様々な弦楽器、管楽器、打楽器などの各種民族楽器の音色を収録しています。

- パッチ 414 種類
- リズム・セット 12 種類
- ウェーブフォーム 873 種類

本製品のウェーブフォームの一部は高品位なサウンドライブラリーを数多く製作している SAMPLEHEADS 社の CD-ROM 「Whole Lotta Country」の中からセレクトしたウェーブフォームを使用しています。

※ 各パッチ／リズム・セットは Fantom シリーズ、XV シリーズ、MX-200、SRX 対応の RD シリーズ、MC-909、VR-760 の各機種ごとに最適なパラメーター設定を行っていますので、それぞれ出音が異なることがあります。

付属の CD-ROM に SR-JV80-05、14、18 のオリジナル音色を再現するデータが収録されています。(対応機種: Fantom (FA-76)、XV-5080、XV-5050、XV-3080、XV-88、XV-2020)

このエクスパンション・ボードは新フォーマットを採用しています。お使いの機種のシステム・プログラム・バージョンをご確認の上、バージョン・アップ対象の場合は、付属 CD-ROM に収録されているシステム・アップデート・プログラムでバージョン・アップしてからご使用ください。(P.23 をご覧ください。) このアップデートプログラムは SRX-01 ~ 09 で使用出来ます。

USING THE UNIT SAFELY

INSTRUCTIONS FOR THE PREVENTION OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

About WARNING and CAUTION Notices

 WARNING	Used for instructions intended to alert the user to the risk of death or severe injury should the unit be used improperly.
 CAUTION	Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. * Material damage refers to damage or other adverse effects caused with respect to the home and all its furnishings, as well to domestic animals or pets.

About the Symbols

	The  symbol alerts the user to important instructions or warnings. The specific meaning of the symbol is determined by the design contained within the triangle. In the case of the symbol at left, it is used for general cautions, warnings, or alerts to danger.
	The  symbol alerts the user to items that must never be carried out (are forbidden). The specific thing that must not be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the unit must never be disassembled.
	The  symbol alerts the user to things that must be carried out. The specific thing that must be done is indicated by the design contained within the circle. In the case of the symbol at left, it means that the power-cord plug must be unplugged from the outlet.

ALWAYS OBSERVE THE FOLLOWING

WARNING

- Before using this unit, make sure to read the instructions below, and the Owner's Manual.



- Do not open or perform any internal modifications on the unit.



- Do not attempt to repair the unit, or replace parts within it (except when this manual provides specific instructions directing you to do so). Refer all servicing to your retailer, the nearest Roland Service Center, or an authorized Roland distributor, as listed on the "Information" page.



- Never use or store the unit in places that are:
 - Subject to temperature extremes (e.g., direct sunlight in an enclosed vehicle, near a heating duct, on top of heat-generating equipment); or are
 - Damp (e.g., baths, washrooms, on wet floors); or are
 - Humid; or are
 - Exposed to rain; or are
 - Dusty; or are
 - Subject to high levels of vibration.



- Do not allow any objects (e.g., flammable material, coins, pins); or liquids of any kind (water, soft drinks, etc.) to penetrate the unit.



WARNING

- In households with small children, an adult should provide supervision until the child is capable of following all the rules essential for the safe operation of the unit.



- Protect the unit from strong impact.
(Do not drop it!)



- Before installing the SRX-09, you must first always turn off the Fantom series/XV series/MX-200/RD series with SRX slots/MC-909/VR-760/G-70 and unplug its power cord.



- DO NOT play a CD-ROM disc on a conventional audio CD player. The resulting sound may be of a level that could cause permanent hearing loss. Damage to speakers or other system components may result.



CAUTION

- Never climb on top of, nor place heavy objects on the unit.



- Install the circuit board only into the specified unit (Fantom series/XV series/MX-200/RD series with SRX slots/MC-909/VR-760/G-70). Remove only the specified screws during the installation.



- Should you remove screws, make sure to put them in a safe place out of children's reach, so there is no chance of them being swallowed accidentally.



* In the interest of product improvement, the specifications and/or contents of this package are subject to change without prior notice.

安全上のご注意

火災・感電・傷害を防止するには

△警告と△注意の意味について

 警告	取扱いを誤った場合に、使用者が死亡または重傷を負う可能性が想定される内容を表わしています。
 注意	取扱いを誤った場合に、使用者が傷害を負う危険が想定される場合および物的損害のみの発生が想定される内容を表わしています。 ※物的損害とは、家屋・家財および家畜・ペットにかかる拡大損害を表わしています。

図記号の例

	△は、注意（危険、警告を含む）を表わしています。 具体的な注意内容は、△の中に描かれています。左図の場合は、「一般的な注意、警告、危険」を表わしています。
	○は、禁止（してはいけないこと）を表わしています。 具体的な禁止内容は、○の中に描かれています。左図の場合は、「分解禁止」を表わしています。
	●は、強制（必ずすること）を表わしています。 具体的な強制内容は、●の中に描かれています。左図の場合は、「電源プラグをコンセントから抜くこと」を表わしています。

-----以下の指示を必ず守ってください-----

△ 警告

- この機器を使用する前に、以下の指示と取扱説明書をよく読んでください。



- この機器を分解したり、改造したりしないでください。



- 修理／部品の交換などで、取扱説明書に書かれていらないことは、絶対にしないでください。必ずお買い上げ店またはローランド・サービスに相談してください。



- 次のような場所での使用や保存はしないでください。
 - 温度が極端に高い場所（直射日光の当たる場所、暖房機器の近く、発熱する機器の上など）
 - 水気の近く（風呂場、洗面台、濡れた床など）や湿度の高い場所
 - 雨に漏れる場所
 - ホコリの多い場所
 - 振動の多い場所



- この機器に、異物（燃えやすいもの、硬貨、針金など）や液体（水、ジュースなど）を絶対に入れないでください。



※ 製品の仕様および内容は、改良のため予告なく変更することがあります。

△ 注意

- お子様のいるご家庭で使用する場合、お子様の取り扱いやいたずらに注意してください。必ず大人のかたが、監視／指導してあげてください。



- この機器を落としたり、この機器に強い衝撃を与えないでください。



- SRX-09を取り付ける前に、Fantomシリーズ、XVシリーズ、MX-200、SRX対応のRDシリーズ、MC-909、VR-760の電源を切って電源プラグをコンセントから外してください。



- CD-ROMを、一般のオーディオCDプレーヤーで再生しないで下さい。大音量によって耳を痛めたり、スピーカーを破損する恐れがあります。



△ 注意

- この機器の上に乗ったり、機器の上に重いものを置かないでください。



- 指定の機器（Fantomシリーズ、XVシリーズ、MX-200、SRX対応のRDシリーズ、MC-909、VR-760）だけに取り付け、取り付け時には指定されたネジだけを外してください。



- ネジを外した場合は、小さなお子様が誤って飲み込んだりすることのないようお子様の手の届かないところへ保管してください。



IMPORTANT NOTES

When you purchase the SRX-09 expansion board from an authorized Roland dealer, the included sounds and samples are licensed, not sold, to you by Roland Corporation, for commercial use in music production, public performance, broadcast, etc.

You may use any of the included phrases and/or samples in a commercial or non-commercial recording without paying any additional license fees. However, you must strictly adhere to the following crediting guidelines on any music recording that utilize material from SRX-09.

Reproduction or duplication of this collection or any of the sound recording contained in the SRX-09, either as they exist on this expansion board or by any means of reformatting, mixing, filtering, re-synthesizing, processing or otherwise editing for use in another product or for re-sale, is strictly prohibited without the express written consent of Roland. All unauthorized giving, trading, lending, renting, re-issue, redistribution or re-sale of the sounds included in the SRX-09 are expressly prohibited.

In Plain English: Be creative in your application of the SRX-09 sounds, and keep this library for your use only. DO NOT COPY IT. Roland constantly monitors other Soundware releases to check for copyright infringements, and will prosecute all piracy and copyright violations to the fullest extent of the law. THIS LIBRARY IS GUARANTEED TO BE 100% COPYRIGHT CLEAN.

In addition to the items listed under "USING THE UNIT SAFELY" on page 2, please read and observe the following:

Handling CD-ROMs

- * *Avoid touching or scratching the shiny underside (encoded surface) of the disc. Damaged or dirty CD-ROM discs may not be read properly. Keep your discs clean using a commercially available CD cleaner.*

Handling the Board

To avoid the risk of damage to internal components that can be caused by static electricity, please carefully observe the following whenever you handle the board.

- * *Before you touch the board, always first grasp a metal object (such as a water pipe), so you are sure that any static electricity you might have been carrying has been discharged.*
- * *When handling the board, grasp it only by its edges. Avoid touching any of the electronic components or connectors.*
- * *Save the bag in which the board was originally shipped, and put the board back into it whenever you need to store or transport it.*

French language

for Canadian Safety Standard

Veuillez suivre attentivement les instructions suivantes quand vous manipulez la carte afin d'éviter tout risque d'endommagement des pièces internes par l'électricité statique.

- * *Toujours toucher un objet métallique relié à la terre (comme un tuyau par exemple) avant de manipuler la carte pour vous décharger de l'électricité statique que vous auriez pu accumuler.*
- * *Lorsque vous manipulez la carte, la tenir par les côtés. Évitez de toucher aux composants ou aux connecteurs.*
- * *Conservez le sachet d'origine dans lequel était la carte lors de l'envoi et remettez la carte dedans si vous devez la ranger ou la transporter.*

使用上の注意

お客様がSRX-09 エクスパンション・ボード（以下、「本製品」といいます）をローランドの正規販売店からお買い上げになった時点で、本製品に含まれる音やサンプルは、ローランド株式会社から、お客様に対して、音楽制作、公共の場での演奏、放送などの商用目的のための使用を許諾したものであって、著作権を譲渡したものではありません。

お客様は、いかなる追加料金を支払うこともなく、本製品に含まれるあらゆるフレーズやサンプルを、商用あるいは非商用目的の録音に使用できます。ただし、お客様が本製品を使用して音楽の録音を行つ際は、以下のことにご注意ください。

本製品に含まれるいかなる録音物も、そのままの状態であれ、いかなる手段によって再構成、ミキシング、フィルター加工、再合成、加工処理、その他の編集作業をした状態であれ、ローランドの書面による許可なく、他の製品に含めたり再販売するために複製・複写することを禁止します。また、本製品に含まれるいかなる音も、許可なく贈与、取引、貸与、賃貸、再発行、再配布、再販売することを禁止します。

従って、本製品の音色は音楽制作の範囲でお使いいただくようお願いします。そして、本製品のライブラリーはお客様ご自身の個人的使用的目的の範囲でお使いください。本製品の音色データの複製・複写は禁止します。

ローランドは、著作権侵害がないかどうか、常時他のサウンド・ライブラリーの発売を把握しており、著作権侵害に対しては法的手段を行使する場合があります。

なお、本製品のライブラリーは第三者の著作権を一切侵害していないことを保証します。

3ページに記載されている「安全上の注意」以外に、次のことに注意してください。

修理について

- ※ お客様がこの機器を分解、改造された場合、以後の性能について保証できなくなります。また、修理をお断りする場合もあります。
- ※ 当社では、この製品の補修用性能部品（製品の機能を維持するために必要な部品）を、製造打切後6年間保有しています。この部品保有期間を修理可能の期間とさせていただきます。なお、保有期間が経過した後も、故障箇所によっては修理可能の場合がありますので、お買い上げ店、または最寄りのローランド・サービスにご相談ください。

CD-ROM の取り扱い

- ※ ディスクの裏面（信号面）に触れたり、傷をつけたりしないでください。データの読み出しがうまくいかないことがあります。ディスクの汚れは、市販のCD専用クリーナーでクリーニングしてください。

基板の取り扱い

この基板は、静電気により部品が破壊される恐れがあります。基板を取り扱うときは、次の点に注意してください。

- ※ 基板を持つときは、あらかじめ何らかの金属に触れて、体や衣類にたまっている静電気を放電してください。
- ※ 基板を持つときは、基板の縁を持ち、部品やコネクターの部分に直接手を触れないでください。
- ※ 基板を保管するとき、または輸送するときなどは、購入時に基板が入っていた袋（導電袋）に入れてください。




INSTALLING THE WAVE EXPANSION BOARD

- * Turn off your instrument.
1. Remove the cover located on the top (or rear) of your instrument.
 - * When turning the unit upside-down, get a bunch of newspapers or magazines, and place them under the four corners or at both ends to prevent damage to the buttons and controls. Also, you should try to orient the unit so no buttons or controls get damaged.
 - * When turning the unit upside-down, handle with care to avoid dropping it, or allowing it to fall or tip over.
 2. Insert the Wave Expansion Board connector into a connector for an SRX Series slot, while simultaneously inserting the board holders into the holes in the Wave Expansion Board.
 - * Do not touch any of the printed circuit pathways or connection terminals.
 - * Never use excessive force when installing a circuit board. If it doesn't fit properly on the first attempt, remove the board and try again.
 3. Use the supplied Installation Tool to turn the holders in the LOCK direction, so the board will be fastened in place.
(To remove the Wave Expansion Board, turn the board holders in the UNLOCK direction, and lift up the board.)
 - * When circuit board installation is complete, double-check your work.
 4. Using the screws removed in Step 1, refasten the cover in its original position.
 5. Check if the Wave Expansion Board is correctly installed.
 - * If the "EXP" display cannot be selected (doesn't appear) in the Waveform Selection Screen (refer to the owner's manual of the instrument you use), remove the Wave Expansion Board and install it properly.

French language

for Canadian Safety Standard

- * Éteindre l'instrument.
1. Retirer le couvercle situé sur le dessus (ou à l'arrière) de l'instrument.
 2. Inserer le connecteur de la carte dans un des creneaux pour la série SRX tout en enfonçant les supports à carte dans les trous de celle-ci.
 - * Ne pas toucher aux circuits imprimés ou aux connecteurs.
 - * Ne jamais forcer lors de l'installation de la carte de circuits imprimés. Si la carte s'ajuste mal au premier essai, enlevez la carte et recommencez l'installation.
 3. Utiliser l'outil d'installation fourni pour tourner les clips de retenue vers la position de blocage (LOCK) de façon à ce que la carte soit retenue en place.
(Pour retirer la carte d'expansion Wave, tourner les clips de retenue de la carte vers la position déblocage (UNLOCK) et retirer la carte en la soulevant.)
 - * Quand l'installation de la carte de circuits imprimés est terminée, vérifiez si tout est bien installé.
 4. Remettre la plaque à sa place et la fixer à l'aide des vis enlevées à l'étape 1.
 5. S'assurer que la carte d'expansion Wave est installée correctement.
 - * S'il est impossible de sélectionner l'affichage "EXP" (il n'apparaît pas) à l'écran de sélection Waveform (se reporter au guide du propriétaire de l'instrument utilisé), retirer la carte d'expansion Wave et la réinstaller correctement.



Position them as shown before you install the board.
Avant l'installation, orienter les supports à carte tel qu'indiqué sur le schéma.
取り付ける前に図のような向きに合わせます

ウェーブ・エクスパンション・ボードの取り付けかた

- ※ 使用機器の電源スイッチをオフにしてください。
1. 使用機器の上部、または背面にあるカバーをはずします。
 - ※ 本体を裏返す際は、ボタン、つまみなどを破損しないように、新聞や雑誌などを重ねて本体の四隅や両端に敷いてください。また、その際、ボタン、つまみなどが破損しないような位置に配置してください。
 - ※ 本体を裏返す際は、落下や転倒を引き起こさないよう扱いにご注意ください。
 2. SRX シリーズ用のスロットのコネクターにウェーブ・エクスパンション・ボードのコネクターを差し込み、同時に基板ホルダーをウェーブ・エクスパンション・ボードの穴にはめ込みます。
 - ※ 回路部やコネクター部には手を触れないでください。
 - ※ 基板を無理に押し込まないでください。装着しにくい場合、いったん基板を外してやり直してください。
 3. 付属の固定用具で基板ホルダーをLOCK 方向に回し、ウェーブ・エクスパンション・ボードを固定します。
(ウェーブ・エクスパンション・ボードを取り外すには、基板ホルダーをUNLOCK 方向に回してから取り外します。)
 - ※ 取り付けを終えたら、正しく取り付けられていることを再度確認してください。
 4. 手順 1 で外したネジで、カバーを元通りに取り付けます。
 5. ウェーブ・エクスパンション・ボードの取り付けが正しく行われたかを確認します。
 - ※ ウェーブフォームの選択画面（使用機器の取扱説明書参照）で“EXP”が選べない（表示されない）ときは、もう一度ウェーブ・エクスパンション・ボードをつけ直してください。

Patch List (1)

For Fantom series/XV series/MX-200

(BANK SELECT MSB : 93; LSB : 19 [No.001-128], LSB : 20 [No.129-256], LSB ; 21 [No.257-384], LSB;22 [No.385-414])

No.	Name	Voices	Category
1	World Sounds	1	BEAT&GROOVE
2	Go2China /C2	2	COMBINATION #
3	Go2India /C2	2	COMBINATION #
4	The Great W	6	FLUTE
5	Yuehchin+	4	PLUCKED
6	Sweet Nylon	2	AC.GUITAR
7	Tele R&F	3	EL.GUITAR
8	Tubby Baby	3	BASS
9	HeavenGender	5	BELL
10	Gamelan Ems	4	MALLETS
11	Childwood	4	MALLETS
12	La Musette	1	ACCORDION
13	Essence	4	WIND
14	Zampona /	1	FLUTE
15	GipsyTrumpt/	1	AC.BRASS
16	We Dream {}	4	SOFT PAD
17	Fun WithPerc	1	PERCUSSION
18	GuZheng arp	2	SYNTH FX
19	Feets	4	SOUND FX
20	World Radio	5	BEAT&GROOVE
21	ClanAdvances	3	BEAT&GROOVE
22	Eastern Tour	4	BEAT&GROOVE
23	Enough!STOP!	3	BEAT&GROOVE
24	Banjo Phrs	1	BEAT&GROOVE
25	Guitar Phrs1	1	BEAT&GROOVE
26	Guitar Phrs2	1	BEAT&GROOVE
27	PdlStl Phrs	1	BEAT&GROOVE
28	Asia UFO	4	BEAT&GROOVE
29	UBeenSoBaa	8	BEAT&GROOVE
30	Didgeri /	1	BEAT&GROOVE
31	WorldGroove	3	BEAT&GROOVE #
32	LoopPhrase 1	5	BEAT&GROOVE #
33	LoopPhrase 2	5	BEAT&GROOVE #
34	TABLA groove	2	BEAT&GROOVE
35	JasonGoEast	5	COMBINATION #
36	Flu&AcompSRX	3	COMBINATION
37	Split Floop	2	COMBINATION #
38	Hot Salsa	2	COMBINATION #
39	TempBassSolo	2	COMBINATION #
40	CherryFlower	4	COMBINATION
41	SplitThisSRX	1	COMBINATION
42	Crane Dance	4	COMBINATION
43	LostInMists	1	COMBINATION
44	Qui DiEnsembl	3	COMBINATION
45	NasalBlossom	6	COMBINATION
46	Meditation 1	4	PLUCKED
47	Art Of Feng	4	PLUCKED
48	Orient xPres	4	PLUCKED
49	Padded Sitar	5	PLUCKED
50	No Worries	4	PLUCKED
51	IntarMel SRX	4	PLUCKED
52	Ode 2 An Oud	5	PLUCKED
53	Fugi-man	6	PLUCKED
54	China pluck	2	PLUCKED
55	Yuehchin SRX	1	PLUCKED
56	Kayakeum	1	PLUCKED
57	Asian Pizz	3	PLUCKED
58	PiPa SRX	3	PLUCKED
59	Koto SRX	1	PLUCKED
60	Shamisen SRX	2	PLUCKED
61	Sanshin SRX	1	PLUCKED
62	Yang Qin trm	1	PLUCKED
63	Yang Qin/Mod	3	PLUCKED
64	SultanPalace	4	PLUCKED
65	Marc Polo	3	PLUCKED
66	Bandolim SRX	1	PLUCKED
67	K.Bandolim	2	PLUCKED
68	Afro Harp	3	PLUCKED
69	Ethnhit!	8	PLUCKED
70	OctaHarp+	2	PLUCKED
71	St.GuZhngSRX	2	PLUCKED
72	Zheng Zither	4	PLUCKED
73	Distance	5	PLUCKED
74	Mandolin/Mod	4	PLUCKED
75	Mandolin	2	PLUCKED
76	Mando Club	3	PLUCKED
77	MdlnTrmSRSRX	4	PLUCKED
78	Drone Sitar	1	PLUCKED
79	Conch&Sitar	6	PLUCKED
80	Punjab Rocks	4	PLUCKED
81	Pas2IndiaSRX	3	PLUCKED
82	Rain Drone	3	PLUCKED
83	SitarGlissSRX	1	PLUCKED
84	Tambura SRX	2	PLUCKED
85	TambDroneSRX	1	PLUCKED
86	St.SanturSRX	2	PLUCKED
87	SanturTrmSRX	1	PLUCKED
88	Santur /Mod	2	PLUCKED
89	Canton	3	PLUCKED
90	HamrDulcimer	2	PLUCKED

No.	Name	Voices	Category
91	3D Dulcimer	3	PLUCKED
92	Zither	1	PLUCKED
93	Magic Pluck	3	PLUCKED
94	Biwa SRX	2	PLUCKED
95	Biwa Menu	1	PLUCKED
96	BerimbauMenu	1	PLUCKED
97	Berimbau	2	PLUCKED
98	JawHarp Menu	1	PLUCKED
99	Steel Rhythm	1	AC.GUITAR
100	SoloSteelGtr	3	AC.GUITAR
101	N'Ville Soft	3	AC.GUITAR
102	Spruce Top	2	AC.GUITAR
103	Procssd AGtr	4	AC.GUITAR
104	High Strung	1	AC.GUITAR
105	Comprsed D18	1	AC.GUITAR
106	12 String	2	AC.GUITAR
107	Mixed 12Str1	2	AC.GUITAR
108	Mixed 12Str2	3	AC.GUITAR
109	Ac Gtr 12stg	2	AC.GUITAR
110	No Borders	4	AC.GUITAR
111	Loose 12str	3	AC.GUITAR
112	Living R.Gtr	4	AC.GUITAR
113	Dobro Modro	2	AC.GUITAR
114	ResonatorGtr	2	AC.GUITAR
115	Ac.Gtrs SRX	2	AC.GUITAR
116	2 Players	4	AC.GUITAR
117	Solo RequGtr	4	AC.GUITAR
118	Loose Nylon	4	AC.GUITAR
119	AcousticBros	4	AC.GUITAR
120	So Sad Nylon	5	AC.GUITAR
121	Chinese Duo	4	AC.GUITAR
122	ChugRunTrSRX	3	AC.GUITAR
123	Chung Ruan	1	AC.GUITAR
124	ChungRuanSRX	1	AC.GUITAR
125	Bottom Ruan	2	AC.GUITAR
126	RuangGtr SRX	3	AC.GUITAR
127	Oud SRX	1	AC.GUITAR
128	BlugrsSldSRX	1	AC.GUITAR
129	Guitaro SRX	2	AC.GUITAR
130	Natural Tele	2	EL.GUITAR
131	Psyche Tele	1	EL.GUITAR
132	Coral	2	EL.GUITAR
133	Chorus Twang	4	EL.GUITAR
134	Pick Licker	3	EL.GUITAR
135	CleanStrtSRX	2	EL.GUITAR
136	Velo 335 SRX	2	EL.GUITAR
137	Right Funky	4	EL.GUITAR
138	Comp Muted	2	EL.GUITAR
139	E.GtrMt SRX	1	EL.GUITAR
140	335VelMt SRX	2	EL.GUITAR
141	Wide Guitar	1	EL.GUITAR
142	Dob-Compress	2	EL.GUITAR
143	Nice Twelvey	4	EL.GUITAR
144	RotaryCrunch	2	EL.GUITAR
145	FastRotrySRX	3	EL.GUITAR
146	EGDynaPikSRX	2	EL.GUITAR
147	BackingEGSRX	2	EL.GUITAR
148	Room Slide	1	EL.GUITAR
149	Pedal Steel	1	EL.GUITAR
150	Phased P.Stl	3	EL.GUITAR
151	PureSteelSRX	1	EL.GUITAR
152	MutedAmbient	4	EL.GUITAR
153	GtrFX Menu	1	EL.GUITAR
154	LP Gtr SRX	1	DIST.GUITAR
155	Tele-Funkfen	2	DIST.GUITAR
156	335 &Cabinet	3	DIST.GUITAR
157	Tele Licker	3	DIST.GUITAR
158	Short & Long	2	DIST.GUITAR
159	NewBeginning	4	FRETTED
160	Bouzouki	2	FRETTED
161	Bousoukhit!	8	FRETTED
162	3ChdStrumSRX	1	FRETTED
163	Strum Poetic	4	FRETTED
164	Strum Away	4	FRETTED
165	Banjo-Mando	3	FRETTED
166	5StringBanjo	1	FRETTED
167	Banjo SRX 1	2	FRETTED
168	Banjo SRX 2	1	FRETTED
169	Banjo SRX 3	1	FRETTED
170	Fiddle	2	STRINGS
171	Fiddle 2002	2	STRINGS
172	FiddleSwitch	1	STRINGS
173	Fiddle Sect.	4	STRINGS
174	FiddleStacto	4	STRINGS
175	AsianOrcPizz	6	STRINGS
176	AjapaneseInn	3	STRINGS
177	Deep Blue	4	STRINGS
178	Ethnic Ens	4	STRINGS
179	ChinesOrcSRX	4	STRINGS
180	ErHu / SRX	1	STRINGS

No.	Name	Voices	Category
181	ErHuSolo SRX	1	STRINGS
182	ErHu Ld SRX	2	STRINGS
183	FiddleFXmenu	1	STRINGS
184	ViolnSoloSRX	1	STRINGS
185	Comp BabyBss	2	BASS
186	Baby Bass	1	BASS
187	Comp Fingerd	2	BASS
188	Jazz Fing.BS	1	BASS
189	Live Bass	2	BASS
190	Flango Bass	3	BASS
191	Bass Oddesy	2	BASS
192	6Str Bs SRX1	1	BASS
193	Muted Bass	1	BASS
194	6Str /Mt SRX	3	BASS
195	PickBsHd SRX	1	BASS
196	PickedBs SRX	1	BASS
197	Tub Bass	2	BASS
198	GuitarnBsSRX	2	BASS
199	GtrnOct SRX	3	BASS
200	PacificDream	4	BELL
201	Meditation 2	3	BELL
202	HybridKemong	3	BELL
203	Purify	4	BELL
204	Asia Bells	2	BELL
205	Rama Cym SRX	2	BELL
206	BelOrchest	5	BELL
207	Sacred Bells	2	BELL
208	Spokes	3	BELL
209	Winter Bells	2	BELL
210	Wind Bells	1	BELL
211	BelAngk SRX	2	MALLETS
212	Tcheekolyna	2	MALLETS
213	Wood EPiano	3	MALLETS
214	Kalimba	3	MALLETS
215	Kalimbatch	2	MALLETS
216	VelAfro SRX1	2	MALLETS
217	BsKalimbaSRX	3	MALLETS
218	LogDetunrSRX	2	MALLETS
219	Baateri SRX	3	MALLETS
220	Balafoon SRX	3	MALLETS
221	Asian Wood	2	MALLETS
222	Mellow tone	2	MALLETS
223	Glas Mlt SRX	2	MALLETS
224	SteelDr SRX1	1	MALLETS
225	SteelDr SRX2	2	MALLETS
226	Gendrous SRX	3	MALLETS
227	BonangGamSRX	1	MALLETS
228	VelAfro SRX2	2	MALLETS
229	TempleMetlSRX	3	MALLETS
230	Kemong / SRX	3	MALLETS
231	Kane / SRX	1	MALLETS
232	JeGong / SRX	3	MALLETS
233	Jegogn / SRX	1	MALLETS
234	Jublag / SRX	1	MALLETS
235	Reyong / SRX	1	MALLETS
236	Pemade / SRX	1	MALLETS
237	Cajun	2	ACCORDION
238	D.Accordion	4	ACCORDION
239	SqueezeBoxSRX	2	ACCORDION
240	Squeeze Box	2	ACCORDION
241	St.AcdOp SRX	2	ACCORDION
242	AccionOp SRX	1	ACCORDION
243	Acd ffOp SRX	2	ACCORDION
244	St.AcdCI SRX	2	ACCORDION
245	Bluesy	1	HARMONICA
246	HarmonicaSRX	2	HARMONICA
247	CuntryHrpSRX	2	HARMONICA
248	Sessn HrpSRX	1	HARMONICA
249	Esraj&Mizmar	3	WIND
250	Before Time	1	WIND
251	Gagaku Emz	4	WIND
252	Mizmar solo	1	WIND
253	PiriSolo SRX	2	WIND
254	Shahmai SRX	1	WIND
255	HichirikSRX	2	WIND
256	Bagpipes SRX	2	WIND
257	Sheng / SRX	1	WIND
258	Suona / SRX	1	WIND
259	VillageDance	4	FLUTE
260	Indian Ens	4	FLUTE
261	Nature Loves	4	FLUTE
262	PanPipes SRX	2	FLUTE
263	Sad Pipe	1	FLUTE
264	Shell blow	1	FLUTE
265	Desert Flute	2	FLUTE
266	Zampona	2	FLUTE
267	Isolation	2	FLUTE
268	Ocarina	2	FLUTE
269	New IndFlute	1	FLUTE
270	Qu Di Vib	2	FLUTE

Patch List (2)

For Fantom series/XV series/MX-200

(BANK SELECT MSB : 93; LSB : 19 [No.001-128], LSB : 20 [No.129-256], LSB ; 21 [No.257-384], LSB;22 [No.385-414])

No.	Name	Voices	Category
271	Bang Di Vib	2	FLUTE
272	New Kawala	1	FLUTE
273	BreathyIndia	3	FLUTE
274	New Shaku	2	FLUTE
275	Shakuhachi	2	FLUTE
276	DreamInColor	4	FLUTE
277	TwintHillyLd	2	FLUTE
278	Snake Eyes	3	AC.BRASS
279	Latin Trumpet	1	AC.BRASS
280	MariachiTpts	3	AC.BRASS
281	Trumpets	3	AC.BRASS
282	GrowlWah/Mod	2	AC.BRASS
283	Muted-Gw /	1	AC.BRASS
284	SoloTuba SRX	1	AC.BRASS
285	LatinTubaSRX	1	AC.BRASS
286	World Orch	7	AC.BRASS
287	Stab&Hold	4	AC.BRASS
288	Indian Radio	8	AC.BRASS
289	Wide Brass	3	AC.BRASS
290	Trombones	4	AC.BRASS
291	Brass Snapz	4	AC.BRASS
292	Brass sfzzZZ	6	AC.BRASS
293	2Tp+Tbn SRX	1	AC.BRASS
294	MemphisHORNS	1	AC.BRASS
295	SectStactSRX	1	AC.BRASS
296	LatinBrasses	2	AC.BRASS
297	Hit & Fall	2	AC.BRASS
298	BrsChd13 SRX	3	AC.BRASS
299	BrsChdMj9SRX	3	AC.BRASS
300	BrsChdMj9SRX	3	AC.BRASS
301	Blow Pad	2	BRIGHT PAD
302	Ceremony	4	BRIGHT PAD
303	Glasses	3	BRIGHT PAD
304	Ambicordian	6	BRIGHT PAD
305	DroneFlanger	3	BRIGHT PAD
306	Rock Gods	5	BRIGHT PAD
307	ScotlandLass	4	BRIGHT PAD
308	Dry Fishes	6	BRIGHT PAD
309	SteroidBrass	4	BRIGHT PAD
310	Soul revived	4	SOFT PAD
311	Rain Pad	3	SOFT PAD
312	Rising Sun	4	SOFT PAD
313	Ethnopad	3	SOFT PAD
314	Ethno Strngs	6	SOFT PAD
315	& 40 Thieves	5	SOFT PAD
316	TromboSynth	5	OTHER SYNTH
317	GrandExaltd1	3	OTHER SYNTH
318	Sun Dog	4	OTHER SYNTH
319	TechnoSpirit	4	TECHNO SYNTH
320	Play Softly	4	TECHNO SYNTH
321	WorkerBeetle	3	TECHNO SYNTH
322	Glass Cut	3	TECHNO SYNTH
323	GuruTronics	4	PULSATING
324	DubJazz Trip	4	PULSATING
325	Meditation 2	4	PULSATING
326	Political	4	PULSATING
327	G'day Mate	4	PULSATING
328	Mission	4	ORGAN
329	Jegorgan	3	ORGAN
330	Dyno Conga 1	1	PERCUSSION

No.	Name	Voices	Category
331	Dyno Conga 2	1	PERCUSSION
332	Congas+Bongo	1	PERCUSSION
333	DynTimbale 1	1	PERCUSSION
334	DynTimbale 2	1	PERCUSSION
335	TimbaleCuica	1	PERCUSSION
336	Dyno Surdo	1	PERCUSSION
337	Rhythym Sect	4	PERCUSSION
338	Rainstick	1	PERCUSSION
339	Clap & Snap	4	PERCUSSION
340	CowbellRandm	1	PERCUSSION
341	Karachi-Man	4	PERCUSSION
342	That Was Zen	4	PERCUSSION
343	StreetParade	4	PERCUSSION
344	BUK	1	PERCUSSION
345	Gongs	2	PERCUSSION
346	Chenchens /	2	PERCUSSION
347	WisdomWithin	4	PERCUSSION
348	Tabla+	4	PERCUSSION
349	DrumsScene	3	PERCUSSION
350	Doholla Fun	1	PERCUSSION
351	AfricanRhtms	2	PERCUSSION
352	Big Logs SRX	2	PERCUSSION
353	WarDrums SRX	4	PERCUSSION
354	Samba Menu	1	PERCUSSION
355	Shaker Menu	1	PERCUSSION
356	Caixa Menu	1	PERCUSSION
357	Cowbell Menu	1	PERCUSSION
358	JapanPrcMenu	1	PERCUSSION
359	Kabuki Menu	1	PERCUSSION
360	KwangwariSRX	2	PERCUSSION
361	Tuzumi / SRX	1	PERCUSSION
362	KoreaPrcMenu	1	PERCUSSION
363	ChinaPrcMenu	1	PERCUSSION
364	China Menu	1	PERCUSSION
365	ChinaGongSRX	3	PERCUSSION
366	Sanba / SRX	3	PERCUSSION
367	St.ShouBoSRX	4	PERCUSSION
368	AsiaCym Menu	1	PERCUSSION
369	Gong Menu	1	PERCUSSION
370	Gamelan Menu	1	PERCUSSION
371	GamlnPrcMenu	1	PERCUSSION
372	BigBazar SRX	1	PERCUSSION
373	Udu Pot Menu	1	PERCUSSION
374	TablaBy Menu	1	PERCUSSION
375	Rek Menu	1	PERCUSSION
376	Dholak Menu1	1	PERCUSSION
377	Dholak Menu2	1	PERCUSSION
378	Dhol Menu	1	PERCUSSION
379	Egypt Tablah	1	PERCUSSION
380	Madal Menu	1	PERCUSSION
381	AfropercMenu	1	PERCUSSION
382	CommSatelite	6	SYNTH FX
383	Amazonze	1	SYNTH FX
384	Tasman Sea	3	SYNTH FX
385	Ethnic FX 1	4	SYNTH FX
386	Ethnic FX 2	4	SYNTH FX
387	SpacetalBoy	4	SYNTH FX
388	Crystal	1	SYNTH FX
389	SpaceLuvSick	6	SYNTH FX
390	HitAscension	4	SYNTH FX

No.	Name	Voices	Category
391	Nervous Man	1	SYNTH FX
392	Silk Stream	1	SYNTH FX
393	DerangedMind	3	SYNTH FX
394	PolyDrone	4	SYNTH FX
395	TequilaWorm	5	SYNTH FX
396	GlistenToYou	4	SYNTH FX
397	Dream Harp	2	SYNTH FX
398	Waterfall	2	SYNTH FX
399	Gender 3D	4	SYNTH FX
400	Doom Drum	5	SYNTH FX
401	Stalker	3	SYNTH FX
402	PlasticBones	4	SYNTH FX
403	PakistanVibe	4	SYNTH FX
404	ThusSpokeZtr	5	SYNTH FX
405	Kalissando	4	SYNTH FX
406	Rain Forest	2	SOUND FX
407	AfropunchSRX	4	SOUND FX
408	Dance Tape	8	SOUND FX
409	Zaghruha SRX	2	VOX
410	1,2,3! SRX	4	VOX
411	Voces SRX	2	VOX
412	Voice Menu 1	1	VOX
413	Voice Menu 2	1	VOX
414	Voice Menu 3	1	VOX

/: Alternate sound obtained with Key Velocity
/Mod: Alternate sound obtained with Modulation (CC:01)

#: Patches using Phrase Loop Waveforms. The numbers included in the Patch name represent the recommended tempo (B.P.M.).

When playing patches on the expansion board, we recommend that you set all the EFFECTS ON/OFF settings on the Fantom series/XV series to "ON." If such settings are set to "OFF," you may not obtain the intended sound.

- * Note that the Release Time has been set to a fairly long value for some of the patches. As a result, if your sound generator has been set so "Patch Remain" is "ON," the release portion of a previously sounding patch may continue to be heard even after switching to a new patch.
- * Some of the patches use waveforms of the SR-JV80 series. For this reason, the upper end of the keyboard may not sound because of key range restrictions.
- * Refer to the owner's manual for your instrument for specific instructions on how to play Patches on the expansion board.
- * On the Fantom series/XV series/MX-200, you can not select only the patches which are designed to be used with the RD series (with SRX slots)/MC-909/VR-760/G-70.

/: Key Velocity による切替え音色
/Mod: Modulation (CC:01) による切替え音色

#: フレーズ・ループのウェーブフォームを使用したパッチです。パッチ・ネームに付いている数字は推奨テンポ (B.P.M.) です。

エクスパンション・ボードのパッチを発音させるときは、Fantom シリーズ/XV シリーズの EFFECTS ON/OFF の設定をすべて ON にして使用することをお勧めいたします。OFF に設定した場合、意図した音色にならないことがあります。

- * パッチの中にはリリース・タイムが長く設定してあるパッチもありますので、音源のパッチ・リメインが ON になっていると音色を切り替えても前のパッチのリリースが残る場合があります。
- * パッチの中には SR-JV80 シリーズのウェーブフォームを使用しているため、上鍵域で発音の制限があり発音しない部分があります。
- * エクスパンション・ボードのパッチを発音させるときは、使用機器の取扱説明書にしたがって、実行してください。
- * Fantom シリーズ/XV シリーズ/MX-200 では、RD シリーズ (SRX 対応) /MC-909/VR-760 専用のパッチを選ぶことはできません。

Patch List (3)

For RD series (with SRX slots)/MC-909/VR-760/G-70

(BANK SELECT MSB : 93; LSB : 19 [No.001-128], LSB : 20 [No.129-256], LSB ; 21 [No.257-384], LSB;22 [No.385-414])

No.	Name	Voices	Category
1	World Sounds	1	BEAT&GROOVE
2	Go2China /C2	2	COMBINATION #
3	Go2India /C2	2	COMBINATION #
4	The Great W	6	FLUTE
5	Yuehchin+	4	PLUCKED
6	Sweet Nylon	2	AC.GUITAR
7	Tele R&F	3	EL.GUITAR
8	Tubby Baby	3	BASS
9	HeavenGender	5	BELL
10	Gamelan Ems	4	MALLETS
11	Childwood	4	MALLETS
12	La Musette	1	ACCORDION
13	Essence	4	WIND
14	Zampona /	1	FLUTE
15	GipsyTrumpt/	1	AC.BRASS
16	We Dream {}	4	SOFT PAD
17	Fun WithPerc	1	PERCUSSION
18	GuZheng arp	2	SYNTH FX
19	Feets	4	SOUND FX
20	World Radio	5	BEAT&GROOVE
21	ClanAdvances	3	BEAT&GROOVE
22	Eastern Tour	4	BEAT&GROOVE
23	Enough!STOP!	2	BEAT&GROOVE
24	Banjo Phrs	1	BEAT&GROOVE
25	Guitar Phrs1	1	BEAT&GROOVE
26	Guitar Phrs2	1	BEAT&GROOVE
27	PdlStl Phrs	1	BEAT&GROOVE
28	Asia UFO	4	BEAT&GROOVE
29	UBeenSoBaa	7	BEAT&GROOVE
30	Didgeri /	1	BEAT&GROOVE
31	WorldGroove	3	BEAT&GROOVE #
32	LoopPhrase 1	5	BEAT&GROOVE #
33	LoopPhrase 2	5	BEAT&GROOVE #
34	TABLA groove	2	BEAT&GROOVE
35	JasonGoEast	6	COMBINATION #
36	Flu&AcompSRX	4	COMBINATION
37	Split Floop	2	COMBINATION #
38	Hot Salsa	2	COMBINATION #
39	TempBassSolo	2	COMBINATION #
40	CherryFlower	4	COMBINATION
41	SplitThisSRX	1	COMBINATION
42	Crane Dance	5	COMBINATION
43	LostInMists	2	COMBINATION
44	Qui DiEnsembl	3	COMBINATION
45	NasalBlossom	6	COMBINATION
46	Meditation 1	4	PLUCKED
47	Art Of Feng	4	PLUCKED
48	Orient xPres	4	PLUCKED
49	Padded Sitar	5	PLUCKED
50	No Worries	4	PLUCKED
51	IntarMel SRX	4	PLUCKED
52	Ode 2 An Oud	5	PLUCKED
53	Fugi-man	6	PLUCKED
54	China pluck	2	PLUCKED
55	Yuehchin SRX	1	PLUCKED
56	Kayakeum	1	PLUCKED
57	Asian Pizz	3	PLUCKED
58	PiPa SRX	3	PLUCKED
59	Koto SRX	1	PLUCKED
60	Shamisen SRX	2	PLUCKED
61	Sanshin SRX	1	PLUCKED
62	Yang Qin trm	1	PLUCKED
63	Yang Qin/Mod	3	PLUCKED
64	SultanPalace	4	PLUCKED
65	Marc Polo	3	PLUCKED
66	Bandolim SRX	1	PLUCKED
67	K.Bandolim	2	PLUCKED
68	Afro Harp	3	PLUCKED
69	Ethnhit!	8	PLUCKED
70	OctaHarp+	3	PLUCKED
71	St.GuZhngSRX	2	PLUCKED
72	Zheng Zither	4	PLUCKED
73	Distance	5	PLUCKED
74	Mandolin/Mod	4	PLUCKED
75	Mandolin	2	PLUCKED
76	Mando Club	3	PLUCKED
77	MdlnTrmSRX	4	PLUCKED
78	Drone Sitar	1	PLUCKED
79	Conch&Sitar	6	PLUCKED
80	Punjab Rocks	4	PLUCKED
81	Pas2IndiaSRX	3	PLUCKED
82	Rain Drone	3	PLUCKED
83	SitarGlisSRX	1	PLUCKED
84	Tambura SRX	2	PLUCKED
85	TambDroneSRX	1	PLUCKED
86	St.SanturSRX	2	PLUCKED
87	SanturTrmSRX	1	PLUCKED
88	Santur /Mod	2	PLUCKED
89	Canton	3	PLUCKED
90	HamrDulcimer	2	PLUCKED

No.	Name	Voices	Category
91	3D Dulcimer	3	PLUCKED
92	Zither	1	PLUCKED
93	Magic Pluck	3	PLUCKED
94	Biwa SRX	2	PLUCKED
95	Biwa Menu	1	PLUCKED
96	BerimbauMenu	1	PLUCKED
97	Berimbau	2	PLUCKED
98	JawHarp Menu	1	PLUCKED
99	Steel Rhythm	1	AC.GUITAR
100	SoloSteelGtr	3	AC.GUITAR
101	N'Ville Soft	3	AC.GUITAR
102	Spruce Top	2	AC.GUITAR
103	Procssd AGtr	4	AC.GUITAR
104	High Strung	1	AC.GUITAR
105	Comprsed D18	1	AC.GUITAR
106	12 String	2	AC.GUITAR
107	Mixed 12Str1	2	AC.GUITAR
108	Mixed 12Str2	3	AC.GUITAR
109	Ac Gtr 12stg	2	AC.GUITAR
110	No Borders	4	AC.GUITAR
111	Loose 12str	3	AC.GUITAR
112	Living R.Gtr	4	AC.GUITAR
113	Dobro Modro	2	AC.GUITAR
114	ResonatorGtr	2	AC.GUITAR
115	Ac.Gtrs SRX	2	AC.GUITAR
116	2 Players	4	AC.GUITAR
117	Solo RequGtr	4	AC.GUITAR
118	Loose Nylon	4	AC.GUITAR
119	AcousticBros	4	AC.GUITAR
120	So Sad Nylon	5	AC.GUITAR
121	Chinese Duo	4	AC.GUITAR
122	ChugRunTrSRX	3	AC.GUITAR
123	Chung Ruan	1	AC.GUITAR
124	ChungRuanSRX	1	AC.GUITAR
125	Bottom Ruan	2	AC.GUITAR
126	RuangGtr SRX	2	AC.GUITAR
127	Oud SRX	1	AC.GUITAR
128	BlugrsSldSRX	1	AC.GUITAR
129	Guitaro SRX	2	AC.GUITAR
130	Natural Tele	2	EL.GUITAR
131	Psyche Tele	1	EL.GUITAR
132	Coral	2	EL.GUITAR
133	Chorus Twang	4	EL.GUITAR
134	Pick Licker	3	EL.GUITAR
135	CleanStrtSRX	1	EL.GUITAR
136	Velo 335 SRX	2	EL.GUITAR
137	Right Funky	4	EL.GUITAR
138	Comp Muted	2	EL.GUITAR
139	E.GtrMt SRX	1	EL.GUITAR
140	335VelMt SRX	2	EL.GUITAR
141	Wide Guitar	1	EL.GUITAR
142	Dob-Compress	2	EL.GUITAR
143	Nice Twelvey	4	EL.GUITAR
144	RotaryCrunch	2	EL.GUITAR
145	FastRotrySRX	3	EL.GUITAR
146	EGDynaPikSRX	2	EL.GUITAR
147	BackingEGSRX	2	EL.GUITAR
148	Room Slide	1	EL.GUITAR
149	Pedal Steel	1	EL.GUITAR
150	Phased P.Stl	3	EL.GUITAR
151	PureSteelSRX	1	EL.GUITAR
152	MutedAmbient	4	EL.GUITAR
153	GtrFX Menu	1	EL.GUITAR
154	LP Gtr SRX	1	DIST.GUITAR
155	Tele-Funkens	2	DIST.GUITAR
156	335 &Cabinet	3	DIST.GUITAR
157	Tele Licker	3	DIST.GUITAR
158	Short & Long	2	DIST.GUITAR
159	NewBeginning	4	FRETTED
160	Bouzouki	2	FRETTED
161	Bousoukhit!	8	FRETTED
162	3ChdStrumSRX	1	FRETTED
163	Strum Poetic	4	FRETTED
164	Strum Away	4	FRETTED
165	Banjo-Mando	3	FRETTED
166	5StringBanjo	1	FRETTED
167	Banjo SRX 1	2	FRETTED
168	Banjo SRX 2	1	FRETTED
169	Banjo SRX 3	1	FRETTED
170	Fiddle	2	STRINGS
171	Fiddle 2002	2	STRINGS
172	FiddleSwitch	1	STRINGS
173	Fiddle Sect.	4	STRINGS
174	FiddleStacto	4	STRINGS
175	AsianOrcPizz	6	STRINGS
176	AjapaneseInn	3	STRINGS
177	Deep Blue	4	STRINGS
178	Ethnic Ens	4	STRINGS
179	ChinesOrcSRX	4	STRINGS
180	ErHu / SRX	1	STRINGS

No.	Name	Voices	Category
181	ErHuSolo SRX	1	STRINGS
182	ErHu Ld SRX	2	STRINGS
183	FiddleFXmenu	1	STRINGS
184	ViolnSoloSRX	1	STRINGS
185	Comp BabyBss	2	BASS
186	Baby Bass	1	BASS
187	Comp Fingerd	2	BASS
188	Jazz Fing.BS	1	BASS
189	Live Bass	2	BASS
190	Flango Bass	3	BASS
191	Bass Oddesy	2	BASS
192	6Str Bs SRX1	1	BASS
193	Muted Bass	1	BASS
194	6Str/Mt SRX	3	BASS
195	PickBsHd SRX	1	BASS
196	PickedBs SRX	1	BASS
197	Tub Bass	2	BASS
198	GuitarnBsSRX	2	BASS
199	GtrnOct SRX	3	BASS
200	PacificDream	4	BELL
201	Meditation 2	3	BELL
202	HybridKemong	3	BELL
203	Purify	4	BELL
204	Asia Bells	2	BELL
205	Rama Cym SRX	2	BELL
206	BelOrchest	5	BELL
207	Sacred Bells	2	BELL
208	Spokes	3	BELL
209	Winter Bells	2	BELL
210	Wind Bells	1	BELL
211	BelAngk SRX	2	MALLETS
212	Tcheekolyna	2	MALLETS
213	Wood EPiano	3	MALLETS
214	Kalimba	3	MALLETS
215	Kalimbatch	2	MALLETS
216	VelAfro SRX1	2	MALLETS
217	BsKalimbaSRX	3	MALLETS
218	LogDetunrSRX	2	MALLETS
219	Baateri SRX	3	MALLETS
220	Balafoon SRX	3	MALLETS
221	Asian Wood	2	MALLETS
222	Mellow tone	2	MALLETS
223	Glas Mt SRX	2	MALLETS
224	SteelDr SRX1	1	MALLETS
225	SteelDr SRX2	2	MALLETS
226	Gendrous SRX	3	MALLETS
227	BonangGamSRX	1	MALLETS
228	VelAfro SRX2	2	MALLETS
229	TempleMetlSRX	3	MALLETS
230	Kemong / SRX	3	MALLETS
231	Kane / SRX	1	MALLETS
232	JeGong / SRX	3	MALLETS
233	Geogon / SRX	1	MALLETS
234	Jublag / SRX	1	MALLETS
235	Reyong / SRX	1	MALLETS
236	Pemade / SRX	1	MALLETS
237	Cajun	2	ACCORDION
238	D.Accordion	4	ACCORDION
239	SqueezeBoxSRX	2	ACCORDION
240	Squeeze Box	2	ACCORDION
241	St.AcdOp SRX	2	ACCORDION
242	AccionOp SRX	1	ACCORDION
243	Acd ffOp SRX	2	ACCORDION
244	St.AcdCI SRX	2	ACCORDION
245	Bluesy	1	HARMONICA
246	HarmonicaSRX	2	HARMONICA
247	CuntryHrpSRX	2	HARMONICA
248	Sessn HrpSRX	1	HARMONICA
249	Esraj&Mizmar	3	WIND
250	Before Time	1	WIND
251	Gagaku Emz	4	WIND
252	Mizmar solo	1	WIND
253	PiriSolo SRX	2	WIND
254	Shahhai SRX	1	WIND
255	HichirikSRX	2	WIND
256	Bagpipes SRX	2	WIND
257	Sheng / SRX	1	WIND
258	Suona / SRX	1	WIND
259	VillageDance	4	FLUTE
260	Indian Ens	4	FLUTE
261	Nature Loves	4	FLUTE
262	PanPipes SRX	2	FLUTE
263	Sad Pipe	1	FLUTE
264	Shell blow	1	FLUTE
265	Desert Flute	2	FLUTE
266	Zampona	2	FLUTE
267	Isolation	3	FLUTE
268	Ocarina	2	FLUTE
269	New IndFlute	1	FLUTE
270	Qu Di Vib	2	FLUTE

Patch List (4)

For RD series (with SRX slots)/MC-909/VR-760/G-70

(BANK SELECT MSB : 93; LSB : 19 [No.001-128], LSB : 20 [No.129-256], LSB ; 21 [No.257-384], LSB;22 [No.385-414])

No.	Name	Voices	Category
271	Bang Di Vib	2	FLUTE
272	New Kawala	1	FLUTE
273	BreathyIndia	3	FLUTE
274	New Shaku	2	FLUTE
275	Shakuhachi	2	FLUTE
276	DreamInColor	4	FLUTE
277	TwinTillyLd	2	FLUTE
278	Snake Eyes	3	AC.BRASS
279	Latin Trumpet	1	AC.BRASS
280	MariachiTpts	3	AC.BRASS
281	Trumpets	3	AC.BRASS
282	GrowlWah/Mod	2	AC.BRASS
283	Muted-Gw /	1	AC.BRASS
284	SoloTuba SRX	1	AC.BRASS
285	LatinTubaSRX	1	AC.BRASS
286	World Orch	7	AC.BRASS
287	Stab&Hold	5	AC.BRASS
288	Indian Radio	8	AC.BRASS
289	Wide Brass	3	AC.BRASS
290	Trombones	4	AC.BRASS
291	Brass Snapz	4	AC.BRASS
292	Brass sfzzZ	6	AC.BRASS
293	2Tp+Tbn SRX	1	AC.BRASS
294	MemphisHORNS	1	AC.BRASS
295	SectStactSRX	1	AC.BRASS
296	LatinBrasses	2	AC.BRASS
297	Hit & Fall	2	AC.BRASS
298	BrsChd13 SRX	3	AC.BRASS
299	BrsChdMj9SRX	3	AC.BRASS
300	BrsChdMj9SRX	3	AC.BRASS
301	Blow Pad	2	BRIGHT PAD
302	Ceremony	4	BRIGHT PAD
303	Glasses	3	BRIGHT PAD
304	Ambicordian	6	BRIGHT PAD
305	DroneFlanger	3	BRIGHT PAD
306	Rock Gods	5	BRIGHT PAD
307	ScotlandLass	4	BRIGHT PAD
308	Dry Fishes	6	BRIGHT PAD
309	SteroidBrass	4	BRIGHT PAD
310	Soul revived	4	SOFT PAD
311	Rain Pad	3	SOFT PAD
312	Rising Sun	4	SOFT PAD
313	Ethnopal	3	SOFT PAD
314	Ethno Strings	6	SOFT PAD
315	& 40 Thieves	5	SOFT PAD
316	TromboSynth	3	OTHER SYNTH
317	GrandExaltd1	2	OTHER SYNTH
318	Sun Dog	4	OTHER SYNTH
319	TechnoSpirit	4	TECHNO SYNTH
320	Play Softly	4	TECHNO SYNTH

/: Alternate sound obtained with Key Velocity

/Mod: Alternate sound obtained with Modulation (CC:01)

#: Patches using Phrase Loop Waveforms. The numbers included in the Patch name represent the recommended tempo (B.P.M.).

- * With some tones, tempos may change suddenly or noise may be produced. This occurs when the tempo is being synchronized, for example to multi-effects or chorus delay times. If the noise becomes noticeable, change the delay time value settings to something other than times corresponding to beats.
- * Some of the patches use waveforms of the SR-JV80 series. For this reason, the upper end of the keyboard may not sound because of key range restrictions.
- * On the RD series (with SRX slots)/MC-909/VR-760/G-70, you can not select only the patches which are designed to be used with the Fantom series/XV series/MX-200.

No.	Name	Voices	Category
321	WorkerBeetle	3	TECHNO SYNTH
322	Glass Cut	3	TECHNO SYNTH
323	GuruTronics	4	PULSATING
324	DubJazz Trip	4	PULSATING
325	Meditation 2	4	PULSATING
326	Political	4	PULSATING
327	G'day Mate	4	PULSATING
328	Mission	4	ORGAN
329	Jegorgan	3	ORGAN
330	Dyno Conga 1	1	PERCUSSION
331	Dyno Conga 2	1	PERCUSSION
332	Congas+Bongo	1	PERCUSSION
333	DynTimbale 1	1	PERCUSSION
334	DynTimbale 2	1	PERCUSSION
335	TimbaleCuica	1	PERCUSSION
336	Dyno Surdo	1	PERCUSSION
337	Rhythm Sect	4	PERCUSSION
338	Rainstick	1	PERCUSSION
339	Clap & Snap	4	PERCUSSION
340	CowbellRandm	1	PERCUSSION
341	Karachi-Man	4	PERCUSSION
342	That Was Zen	4	PERCUSSION
343	StreetParade	4	PERCUSSION
344	BUK	1	PERCUSSION
345	Gongs	2	PERCUSSION
346	Chenchen /	2	PERCUSSION
347	WisdomWithin	4	PERCUSSION
348	Tabla+	4	PERCUSSION
349	DrumsScene	3	PERCUSSION
350	Doholla Fun	1	PERCUSSION
351	AfricanRhtms	2	PERCUSSION
352	Big Logs SRX	2	PERCUSSION
353	WarDrums SRX	4	PERCUSSION
354	Samba Menu	1	PERCUSSION
355	Shaker Menu	1	PERCUSSION
356	Caixa Menu	1	PERCUSSION
357	Cowbell Menu	1	PERCUSSION
358	JapanPrcMenu	1	PERCUSSION
359	Kabuki Menu	1	PERCUSSION
360	KwangwariSRX	2	PERCUSSION
361	Tuzumi / SRX	1	PERCUSSION
362	KoreaPrcMenu	1	PERCUSSION
363	ChinaPrcMenu	1	PERCUSSION
364	China Menu	1	PERCUSSION
365	ChinaGongSRX	3	PERCUSSION
366	Sanba / SRX	3	PERCUSSION
367	St.ShouBoSRX	4	PERCUSSION
368	AsiaCym Menu	1	PERCUSSION
369	Gong Menu	1	PERCUSSION
370	Gamelan Menu	1	PERCUSSION

No.	Name	Voices	Category
371	GamlnPrcMenu	1	PERCUSSION
372	BigBazar SRX	1	PERCUSSION
373	Udu Pot Menu	1	PERCUSSION
374	TablaBy Menu	1	PERCUSSION
375	Rek Menu	1	PERCUSSION
376	Dholak Menu1	1	PERCUSSION
377	Dholak Menu2	1	PERCUSSION
378	Dhol Menu	1	PERCUSSION
379	Egypt Tablah	1	PERCUSSION
380	Madal Menu	1	PERCUSSION
381	AfropercMenu	1	PERCUSSION
382	CommSatelite	6	SYNTH FX
383	Amazone	1	SYNTH FX
384	Tasman Sea	4	SYNTH FX
385	Ethnic FX 1	4	SYNTH FX
386	Ethnic FX 2	4	SYNTH FX
387	SpacetalBoy	3	SYNTH FX
388	Crystal	1	SYNTH FX
389	SpaceLuvSick	6	SYNTH FX
390	HitAscension	3	SYNTH FX
391	Nervous Man	1	SYNTH FX
392	Silk Stream	1	SYNTH FX
393	DerangedMind	3	SYNTH FX
394	PolyDrone	5	SYNTH FX
395	TequilaWorm	4	SYNTH FX
396	GlistenToYou	5	SYNTH FX
397	Dream Harp	2	SYNTH FX
398	Waterfall	2	SYNTH FX
399	Gender 3D	4	SYNTH FX
400	Doom Drum	5	SYNTH FX
401	Stalker	3	SYNTH FX
402	PlasticBones	4	SYNTH FX
403	PakistanVibe	4	SYNTH FX
404	ThusSpokeZtr	6	SYNTH FX
405	Kalissando	4	SYNTH FX
406	Rain Forest	2	SOUND FX
407	AfropunchSRX	4	SOUND FX
408	Dance Tape	8	SOUND FX
409	Zaghruata SRX	2	VOX
410	1,2,3,! SRX	4	VOX
411	Voices SRX	2	VOX
412	Voice Menu 1	1	VOX
413	Voice Menu 2	1	VOX
414	Voice Menu 3	1	VOX

/: Key Velocity による切替え音色

/Mod : Modulation (CC:01) による切替え音色

: フレーズ・ループのウェーブフォームを使用したパッチです。パッチ・ネームに付いている数字は推奨テンポ (B.P.M.) です。

- * 音色によっては、テンポを急激に変化させるとノイズが出る場合があります。これは、マルチエフェクトやコーラスのディレイ・タイムなどがテンポに同期している場合に発生します。ノイズが気になる場合は、ディレイ・タイムなどの設定を音符以外の値に変更してください。
- * パッチの中には SR-JV80 シリーズのウェーブフォームを使用しているため、上鍵域で発音の制限があり発音しない部分があります。
- * SRX 対応の RD シリーズ /MC-909/VR-760 では、Fantom シリーズ /XV シリーズ /MX-200 専用のパッチを選ぶことはできません。

Rhythm Set List

For All Instruments

(BANK SELECT MSB: 92; LSB: 19)

No.	RhythmName
1	LatinDrmKit
2	AsiaDrm Kit
3	IndiaDrmKit
4	MidEastDrKit

No.	RhythmName
5	World Phrase
6	Gtr Phrase
7	Latin Menu1
8	Latin Menu2

No.	RhythmName
9	Latin Menu3
10	Asia Menu
11	India Menu
12	MidEast Menu

Rhythm Set Key Assign (1)

For Fantom series/XV series/MX-200

Note No.	1. LatinDrmKit	2. AsiaDrm Kit	3. IndiaDrmKit	4. MidEastDrKit	5. World Phrase	6. Gtr Phrase
28	SectChd m9	Tsuzumi 2 Hi	--	--	--	--
29	SectChd Mj9	Tsuzumi 2 mf	--	--	--	--
30	TimbalesFil4	Tsuzumi 2 p	--	--	--	--
31	TimbalesFil3	Tsuzumi Hi	--	--	--	--
32	TimbalesFil2	Tsuzumi Lo	--	--	--	--
33	TimbalesFil1	Hyoshigi 2	--	--	--	--
34	Dixie HH Hlf	Dixie HH Hlf	Dixie HH Hlf	--	--	--
35	Fat BD	Maple Kick	Fat BD	Maple Kick	--	--
C2	Room Kick 2	Warm Kick	Room Kick 2	Warm Kick	180:LatinPt2	120:Bnjo G
36	Cross Stick2	Cross Stick2	Cross Stick2	192:LatinPt1	120:Bnjo A	120:Bnjo A
37	Maple Lo Snr	NaturlHardSN	Maple Lo Snr	96:Cng6/8 1	120:Bnjo B	120:Bnjo B
38	Hand Clap 2	Claps Real	Claps Real	96:Cng6/8 2	120:Bnjo Cm	120:Bnjo Cm
39	MapleSoft SN	NaturlRimSht	MapleSoft SN	144:CgBolero	120:Bnjo Cm+	120:Bnjo Cm+
40	Studio Tom 4	Studio Tom 4	Studio Tom 4	88:CgCumbia	120:Bnjo G-C	120:Bnjo G-C
41	Dixie HH Cls	Dixie HH Cls	Dixie HH Cls	168:CgChacha	120:BnjoG-C+	120:BnjoG-C+
42	Studio Tom 3	Studio Tom 3	Studio Tom 3	160:CgMambo	95:EGtr1 G	95:EGtr1 G
43	Dixie HH Pdl	Dixie HH Pdl	Dixie HH Pdl	104:CgMriach	95:EGtr1 C	95:EGtr1 C
44	Studio Tom 2	Studio Tom 2	Studio Tom 2	138:CgMarinr	95:EGtr1 D	95:EGtr1 D
45	Dixie HH Opn	Dixie HH Opn	Dixie HH Opn	126:CgWonwn	95:EGtr2 G	95:EGtr2 G
46	Studio Tom 2	Studio Tom 2	Studio Tom 2	100:TmbIPtn3	95:EGtr2 D	95:EGtr2 D
C3	Studio Tom 1	Studio Tom 1	Studio Tom 1	120:TmbIPtn4	140:EGtr3 G	140:EGtr3 G
47	Crash Cymbal	Crash Cymbal	Crash Cymbal	132:TmbIPtn1	140:EGtr3 C	140:EGtr3 C
48	Studio Tom 1	Studio Tom 1	Studio Tom 1	132:TmbIPtn2	140:EGtr3 D	140:EGtr3 D
49	Rock RdCym1	Rock RdCym1	Rock RdCym1	80:PndrPtn1	140:EGtr3 G+	140:EGtr3 G+
50	Crash 1	Crash 1	Crash 1	108:PndrPtn2	140:EGtr3 C+	140:EGtr3 C+
51	Bongo 1 Hi	Ban Gu 1	Dhol 2	138:PndrPtn3	140:EGtr3 D+	140:EGtr3 D+
52	Tambrin Hit	Asian Gong 3	R8 Tamb	132:AgogoPtn	120:PdSt1 C	120:PdSt1 C
53	Bongo 1 Lo	Ban Gu 2	Dholak 1	132:BotlePtn	120:PdSt1 D	120:PdSt1 D
54	Cowbell Op 1	Mokugyo 1	VDrm Cowbell	104:BomboPtn	120:PdSt1 G	120:PdSt1 G
55	BongoHiSlap1	Ban Gu 3	Dholak 8	126:SurdoPt1	140:PdSt2 D	140:PdSt2 D
56	Cowbell 3	Mokugyo 2	VDrm Cowbell	108:SurdoPt2	140:PdSt2 G	140:PdSt2 G
57	Bongo LoSlap	Ban Gu 4	Dholak 9	138:CaixaPtn	140:PdSt2 D+	140:PdSt2 D+
C4	Conga Hi Mt	Wadaiko	TablaBay 1	Afro Feet 1	Samba 1	140:PdSt2 G+
60	Conga Lo Mt	Wadaiko Rim	TablaBayA Sld	Slit Drum	Samba 2	Gtr Strum 1
61	Conga Slap	Shimedaiko 2	TablaBay 3	Afro Feet 2	132:TabbrmPt	Gtr Strum 2
62	Conga Hi Op	Sime Taiko	TablaBay 6	Afro Clap	108:RepnqPt1	Nyln GtrNz 1
63	CongaLoOp f	Taiko	TablaBay 5	Bendir 1	144:RepnqPt2	Nyln GtrNz 2
64	Timbles HiMt	Tang Gu Mt	TablaBay Na	Bendir 2	96:Salsa	Bouzki Chd 1
65	Timbles LoOp	Tang Gu Op	TablaBayTin	Dawul	96:Cumbia	Bouzki Chd 2
66	Agogo 2 Hi	Buk	TablaBayTun	Sagat Close	116:Mariachi	Bouzki Chd 3
67	Agogo 2 Lo	Buk Rim	TablaBay 8	Sagat Open	Cuica 2	EG C Bend 1
68	Real Cabasa2	Changgo	VDrmCabasaUp	VDrmCabasaUp	Shaker 1	EG C Bend 2
69	Maracas 2	Ohkawa	VDrm Maracas	VDrm Maracas	Shaker 2	EG D Bend 1
70	ApitoHiShort	Ohkawa 2	VDrmCabasDwn	VDrmCabasDwn	104:Shakin'	EG D Bend 2
C5	ApitoLcShort	Kwaengwari f	Madal Da	AfroDrum Flm	Shaker 3	EG D Bend 3
72	Guiro Short2	HuYinLuoH Op	Madal Din	AfroDrum Op1	Didgeridoo 1	EG E Bend 1
73	Guiro Long2	HuYinLuoL Op	Madal Ta	AfroDrum Op2	Didgeridoo 3	EG E Bend 2
74	Claves Lo 2	Shou Luo 1	VDrm Claves	AfroDrum Rat	78:Korea Ph	EG E Bend 3
75	Berimbau Up	Shou Luo 2	VDrm Woodblk	VDrm Woodblk	Korean Ens	EG Slide 1
76	Berimbau Dn	BaliCym Opn	VDrm Woodblk	VDrm Woodblk	Er Hu Phrase	EG Slide 2
77	Cuica Hi 1	BaliCym Cls	FingerSnaps4	TalkingDr Dn	GuZhengArpUp	EG Slide 3
78	Cuica Lo 2	Chenchen Cls	Udu Pot1 Acc	TalkingDr Up	GuZhengArpDn	EG Slide 4
79	Caixa Mute	Chenchen Opn	Udu Pot1 Hi	Doholla Dom	118:ChinaPh1	EG Slide 5
80	Caixa Open2	Kopyak Op	Udu Pot1 Lo	Doholla Roll	132:ChinaPh2	EG Slide 6
81	Caixa Rim	Finger Cym	Udu Pot1 Slp	Doholla Sak	78:GamelnP2	EG Slide 7
82	Caixa Roll2	Ramacymbal	Udu Pot2 Lng	Doholla Stop	122:GamelnP1	EG Rake 1
C6	Cajon Rol Hi	Gameran 1	Udu Pot2 Mut	Doholla Tak	Chenchen Ptn	EG Rake 2
84	Cajon Rol Lo	Gameran 2	Udu Pot2 Sht	Doira Dun	Udu Pot MENU	EG Mute
85	Surdo Mute2	Gameran 3	Udu Pot MENU	Doira Tik	92:DholakPh	Fdl 5th 1
86	Surdo Open2	Gameran 4	118:TablaByP	Sarna Bell	118:TablaByP	Fdl 5th 2
87	PandeiroL Hi	Gameran 5	TablaBY 3	Sitar Gliss	Tablah 1	Fdl Riff 1
88	PandeiroL Lo	Gameran 6	Tablah 1	ZaghruataStop	Tablah 2	Fdl Riff 2
89	PandeiroOpen	Gameran 7	Tablah 2	Yoh Tribe	Tablah 3	--
90	PandeiroMute	Gameran 8	Tablah 3	How Tribe	Tablah 4	--
91	PandeiroL Rm	Gameran 9	Tablah 4	92:DholakPh	Tablah Bend	--
92	PandeiroL Sp	Gameran 10	TablaBY 1	120:Dhol Ph	TablaBY 1	--
93	Quijada	Gameran 11	TablaBY 2	African Ens	TablaBY 2	--
94	Rainstick	Gameran 12	Tablah Bend	Morocco Ens	TablaBY 3	--
C7	Metronome 2	Metronome 2	Metronome 2	Metronome 2	120:Dhol Ph	--
95	R8 Click	R8 Click	R8 Click	R8 Click	African Ens	--
96	Metronome 1	Metronome 1	Metronome 1	Metronome 1	Morocco Ens	--
97	180:LatinPt2	78:Korea Ph	--	--	--	--
98	160:CgMambo	132:ChinaPh2	--	--	--	--
99	132:TmbIPtn1	78:GamelnP2	--	--	--	--
100	132:AgogoPtn	122:GamelnP1	--	--	--	--
101	104:Shakin'	Chenchen Ptn	--	--	--	--
102						
103						

* On the Fantom series/XV series/MX-200, you can not select only the rhythm sets which are designed to be used with the RD series (with SRX slots)/MC-909/VR-760/G-70.

※ Fantom シリーズ/XV シリーズ/MX-200 では、RD シリーズ(SRX 対応) /MC-909/VR-760 専用のリズム・セットを選ぶことはできません。

Rhythm Set Key Assign (2)

For Fantom series/XV series/MX-200

Note No.	7. Latin Menu1	8. Latin Menu2	9. Latin Menu3	10. Asia Menu	11. India Menu	12. MidEast Menu
28	--	--	--	--	--	--
29	[30]	--	--	--	--	--
31	[32]	--	--	--	--	--
33	[34]	--	--	--	--	--
35	[35]	--	--	--	--	--
C2	Agogo 2 Hi Agogo 2 Lo Agogo 3 Hi Agogo 3 Lo ApitoHiShort ApitoLoShort Berimbau Dn Berimbau Mut Berimbau Opn Berimbau Up Bongo 1 Hi Bongo 1 Lo	Cuica 3 Cuica Hi 1 Cuica Hi 2 Cuica Lo 1 Cuica Lo 2 Ganza Hard Ganza Soft Guiro Long Guiro Long2 Guiro Short Guiro Short2 Hand Clap 2	Surdo Hard Surdo Mute Surdo Mute2 Surdo Open H Surdo Open L Surdo Open1 Surdo Open2 Surdo Rim Surdo Rim 2 Surdo Soft Tamborim Mut Tamborim Opn	Hyoshigi Hyoshigi 2 Kane Kane Side Atarigane Kwaengwari f Kwaengwari p KwaengwariMt	Bebarongan 1 Bebarongan 2 Bebarongan 3 Pelegongan 1 Pelegongan 2 Pelegongan 3	Boomerang Clapstick Afro Zither Afro Clap Afro Feet 1 Afro Feet 2 AfroDrum Flm AfroDrum Op1 AfroDrum Op2 AfroDrum Rat Slit Drum TalkingDr Dn
C3	Bongo 2 Hi Bongo 2 Lo Bongo Hi Hrd Bongo HiOp f Bongo Lo Hrd Bongo Lo Sft Bongo LoOp f Bongo LoOpmf Bongo LoSlap BongoBell Mt BongoBell Op BongoHiSlap1	MamboBell Mt MamboBell Op Maracas 2 MaracasUpDwn MtlGuiloLng MtlGuiroSht PandeiroCrsh PandeiroHit PandeiroL Hi PandeiroL Lo PandeiroL Rm PandeiroL Sp	TamborimSlp TamborimMute TamborimOpen TamborimRim TamborimRoll Tambrin Hit TambriShake Timbale Hi Timbale Lo Timbale Side Timbales Rim TimbalesFil1	Shimedaiko 2 Sime Taiko Taiko Tsuzumi 2 Hi Tsuzumi 2 mf Tsuzumi 2 p Tsuzumi Hi Tsuzumi Lo Wadaiko Wadaiko Rim Ho Yoh	Wadon 7 Dhol 1 Dhol 2 Dhol 3 Dhol 4 Dhol 5 Dholak 1 Dholak 2 Dholak 3 Dholak 4 Dholak 5 Dholak 6	TalkingDr Up Yoh Tribe How Tribe Bendir 1 Bendir 2 Dawul Doholla Dom Doholla Roll Doholla Sak Doholla Stop Doholla Tak Doira Dun
C4	BongoHiSlap2 Cabasa Roll Caixa Mute Caixa Mute2 Caixa Open1 Caixa Open2 Caixa Open3 Caixa Rim Caixa Roll Caixa Roll2 Cajon Hi Cajon Lo	PandeiroMute PandeiroOpen PandeiroRim PandeiroRoll Pandeiros Op Pandeiros Rm Pandeiros Sp Quide Long Quide Short Quijada Rainstick Real Cabasa1	TimbalesFil2 TimbalesFil3 TimbalesFil4 TimbalesHand Timbles HiMt Timbles HiOp Timbles LoMt Timbles LoOp TmbSideStick SectChd 13th SectChd m9 SectChd Mj9	iYooh Yyoo Dude Buk Buk Rim Changgo Asian Gong 1 Asian Gong 2 Dholak Tun Asian Gong 2 Dholak Ta Dholak Tun Gamelan Gong Asian Gong 3 Asian Gong 4 Asian Gong 6 Asian Gong 7	Dholak 7 Dholak 8 Dholak 9 Dholak Ga Dholak Na Dholak Ta Sagat Close Sagat Open Madal Da Sarna Bell Sitar Gliss Tablah Dom Tablah Rim Tablah Roll	Doira Tik Rek Dom Rek Open Rek Tek Rek Trill Sagat Close Sagat Open Madal Din Madal Ta Tablah Baya 1 Tablah Baya 2
C5	Cajon Rol Hi Cajon Rol Lo Caxixi Chekere 1 Chekere 2 Chekere 3 Clave! Claves Lo 2 Conga Hi Mt Conga Hi Op Conga Link Conga Lo Mt	Real Cabasa2 RecoRecoLng RecoRecoSht Repiniqe1 Repiniqe2 RepiniqeHrd RepiniqeSft Repique Open Repique Rim Repique Roll SambaBateria SambaWhistle	Sabor! Arriba! Ole! Uno! Dos! Tres! Quatro! Grito-Hahaha Grito-Ahaha! Grito-Haahai Grito-Rrrr! Tiquitito!	Ban Gu 1 Ban Gu 2 Ban Gu 3 Ban Gu 4 Gu Hi Gu Roll HuYinLuoH Mt HuYinLuoH Op HuYinLuoL Mt HuYinLuoL Op Nao Bo Xiao Bo	TablaBaya 3 TablaBaya 4 TablaBaya 5 TablaBaya 6 TablaBaya 7 TablaBaya 8 TablaBaya Ge TablaBaya Ka TablaBaya Na TablaBaya Te TablaBaya Ti TablaBayaGin	Tablah Tak ZaghruLoop ZaghruStop Bull Scream --
C6	Conga Roll Conga Slap Conga Thumb CongaLoOp f CongaLoOp mf	Shaker 1 Shaker 2 Shaker Long Shaker Short	Grito-Oa Oa! Grito-Eh Eh! Ama ya ahi! Fuego! Hey Brazil	Asian Gong 5 Shou Luo 1 Shou Luo 2 Shu Ban 1 Shu Ban 2 Shu Gu Shu Gu Rim Tang Gu Mt Tang Gu Op BaliCym Cls BaliCym Opn	TablaBayaSld TablaBayaTin TablaBayaTun Udu Pot1 Acc Udu Pot1 Hi Udu Pot1 Lo Udu Pot1 Slp Udu Pot2 Lng Udu Pot2 Mut Udu Pot2 Sht	--
C7	Cowbell 1 Cowbell 2 Cowbell 3 Cowbell Mt 1 Cowbell Mt 2 Cowbell Op 1 Cowbell Op 2	-- -- -- -- -- -- --	-- -- -- -- -- -- --	Ceng Ceng Chenchen Cls Chenchen Opn Kopyak Mt Kopyak Op Finger Cym Ramacymbal Jaw Harp Op Jaw Harp Wow	-- -- -- -- -- -- --	--
96	--	--	--	Chenchen Cls	--	--
97	[97]	--	--	Chenchen Opn	--	--
98	--	--	--	Kopyak Mt	--	--
99	[99]	--	--	Kopyak Op	--	--
100	--	--	--	Finger Cym	--	--
101	[102]	--	--	Ramacymbal	--	--
103	--	--	--	Jaw Harp Op	--	--

* On the Fantom series/XV series/MX-200, you can not select only the rhythm sets which are designed to be used with the RD series (with SRX slots)/MC-909/VR-760/G-70.

- ※ Fantom シリーズ / XV シリーズ / MX-200 では、RD シリーズ (SRX 対応) / MC-909 / VR-760 専用のリズム・セットを選ぶことはできません。

Rhythm Set Key Assign (3)

For RD series (with SRX slots)/MC-909/VR-760/G-70

Note No.	1. LatinDrmKit	2. AsiaDrm Kit	3. IndiaDrmKit	4. MidEastDrKit	5. World Phrase	6. Gtr Phrase
28	SectChd m9	Tsuzumi 2 Hi	--	--	--	--
29	SectChd Mj9	Tsuzumi 2 mf	--	--	--	--
30	TimbalesFil4	Tsuzumi 2 p	--	--	--	--
31	TimbalesFil3	Tsuzumi Hi	--	--	--	--
32	TimbalesFil2	Tsuzumi Lo	--	--	--	--
33	TimbalesFil1	Hyoshigi 2	--	--	--	--
34	Dixie HH Hlf	Dixie HH Hlf	Dixie HH Hlf	--	--	--
35	Fat BD	Maple Kick	Fat BD	Maple Kick	--	--
C2	Room Kick 2	Warm Kick	Room Kick 2	Warm Kick	180:LatinPt2	120:Bnjo G
36	Cross Stick2	Cross Stick2	Cross Stick2	Cross Stick2	192:LatinPt1	120:Bnjo A
37	Maple Lo Snr	NaturlHardSN	Maple Lo Snr	NaturlHardSN	96:Cng6/8 1	120:Bnjo B
38	Hand Clap 2	Claps Real	Claps Real	Claps Real	96:Cng6/8 2	120:Bnjo Cm
39	MapleSoft SN	NaturlRimSht	MapleSoft SN	NaturlRimSht	144:CgBolero	120:Bnjo Cm+
40	Studio Tom 4	Studio Tom 4	Studio Tom 4	Studio Tom 4	88:CgCumbia	120:Bnjo G-C
41	Dixie HH Cls	Dixie HH Cls	Dixie HH Cls	Dixie HH Cls	168:CgChacha	120:BnjoG-C+
42	Studio Tom 3	Studio Tom 3	Studio Tom 3	Studio Tom 3	160:CgMambo	95:EGtr1 G
43	Dixie HH Pdl	Dixie HH Pdl	Dixie HH Pdl	Dixie HH Pdl	104:CgMriach	95:EGtr1 C
44	Studio Tom 2	Studio Tom 2	Studio Tom 2	Studio Tom 2	138:CgMarinr	95:EGtr1 D
45	Dixie HH Opn	Dixie HH Opn	Dixie HH Opn	Dixie HH Opn	126:CgWonwn	95:EGtr2 G
46	Studio Tom 2	Studio Tom 2	Studio Tom 2	Studio Tom 2	100:TmbIPtn3	95:EGtr2 D
C3	Studio Tom 1	Studio Tom 1	Studio Tom 1	Studio Tom 1	120:TmbIPtn4	140:EGtr3 G
47	--	--	--	--	132:TmbIPtn1	140:EGtr3 C
48	Studio Tom 1	Studio Tom 1	Studio Tom 1	Studio Tom 1	132:TmbIPtn2	140:EGtr3 D
49	--	--	--	--	80:PndrPtn1	140:EGtr3 G+
50	--	--	--	--	108:PndrPtn2	140:EGtr3 C+
51	--	--	--	--	--	--
52	--	--	--	--	--	--
53	Bongo 1 Hi	Ban Gu 1	Dhol 2	Rek Dom	138:PndrPtn3	140:EGtr3 D+
54	Tambrin Hit	Asian Gong 3	R8 Tamb	R8 Tamb	132:AgogoPtn	120:PdSt1 C
55	Bongo 1 Lo	Ban Gu 2	Dholak 1	Rek Open	132:BotlePtn	120:PdSt1 D
56	Cowbell Op 1	Mokugyo 1	VDrm Cowbell	VDrm Cowbell	104:BomboPtn	120:PdSt1 G
57	BongoHiSlap1	Ban Gu 3	Dholak 8	Rek Tek	126:SurdoPt1	140:PdSt2 D
58	Cowbell 3	Mokugyo 2	VDrm Cowbell	VDrm Cowbell	108:SurdoPt2	140:PdSt2 G
59	Bongo LoSlap	Ban Gu 4	Dholak 9	Rek Trill	138:CaixaPtn	140:PdSt2 D+
C4	Conga Hi Mt	Wadaiko	TablaBay 1	Afro Feet 1	Samba 1	140:PdSt2 G+
60	Conga Lo Mt	Wadaiko Rim	TablaBayASld	Slit Drum	Samba 2	Gtr Strum 1
61	Conga Slap	Shimedaiko 2	TablaBay 3	Afro Feet 2	132:TabbrmPt	Gtr Strum 2
62	Conga Hi Op	Sime Taiko	TablaBay 6	Afro Clap	108:RepnqPt1	Nyln GtrNz 1
63	CongaLoOp f	Taiko	TablaBay 5	Bendir 1	144:RepnqPt2	Nyln GtrNz 2
64	Timbles HiMt	Tang Gu Mt	TablaBay Na	Bendir 2	96:Salsa	Bouzki Chd 1
65	Timbles LoOp	Tang Gu Op	TablaBayTin	Dawul	96:Cumbia	Bouzki Chd 2
66	Agogo 2 Hi	Buk	TablaBayTun	Sagat Close	116:Mariachi	Bouzki Chd 3
67	Agogo 2 Lo	Buk Rim	TablaBay 8	Sagat Open	Cuica 2	EG C Bend 1
68	Real Cabasa2	Changgo	VDrmCabasaUp	VDrmCabasaUp	Shaker 1	EG C Bend 2
69	Maracas 2	Ohkawa	VDrm Maracas	VDrm Maracas	Shaker 2	EG D Bend 1
70	ApitoHiShort	Ohkawa 2	VDrmCabasDwn	VDrmCabasDwn	104:Shakin'	EG D Bend 2
C5	ApitoLoShort	Kwaengwari f	Madal Da	AfroDrum Flm	Shaker 3	EG D Bend 3
72	Guiro Short2	HuYinLuoH Op	Madal Din	AfroDrum Op1	Didgeridoo 1	EG E Bend 1
73	Guiro Long2	HuYinLuoL Op	Madal Ta	AfroDrum Op2	Didgeridoo 3	EG E Bend 2
74	Claves Lo 2	Shou Luo 1	VDrm Claves	AfroDrum Rat	78:Korea Ph	EG E Bend 3
75	Berimbau Up	Shou Luo 2	VDrm Woodblk	VDrm Woodblk	Korean Ens	EG Slide 1
76	Berimbau Dn	BaliCym Opn	VDrm Woodblk	VDrm Woodblk	Er Hu Phrase	EG Slide 2
77	Cuica Hi 1	BaliCym Cls	FingerSnaps4	TalkingDr Dn	GuZhengArpUp	EG Slide 3
78	Cuica Lo 2	Chenchen Cls	Udu Pot1 Acc	TalkingDr Up	GuZhengArpDn	EG Slide 4
79	Caixa Mute	Chenchen Opn	Udu Pot1 Hi	Doholla Dom	118:ChinaPh1	EG Slide 5
80	Caixa Open2	Kopyak Op	Udu Pot1 Lo	Doholla Roll	132:ChinaPh2	EG Slide 6
81	Caixa Rim	Finger Cym	Udu Pot1 Slp	Doholla Sak	78:GamelnP2	EG Slide 7
82	Caixa Roll2	Ramacymbal	Udu Pot2 Lng	Doholla Stop	122:GamelnP1	EG Rake 1
C6	Cajon Rol Hi	Gameran 1	Udu Pot2 Mut	Doholla Tak	Chenchen Ptn	EG Rake 2
84	Cajon Rol Lo	Gameran 2	Udu Pot2 Sht	Doira Dun	Udu Pot MENU	EG Mute
85	Surdo Mute2	Gameran 3	Udu Pot MENU	Doira Tik	92:DholakPh	Fdl 5th 1
86	Surdo Open2	Gameran 4	118:TablaByP	Sarna Bell	118:TablaByP	Fdl 5th 2
87	PandeiroL Hi	Gameran 5	TablaBY 3	Sitar Gliss	Tablah 1	Fdl Riff 1
88	PandeiroL Lo	Gameran 6	Tablah 1	ZaghruataStop	Tablah 2	Fdl Riff 2
89	PandeiroOpen	Gameran 7	Tablah 2	Yoh Tribe	Tablah 3	--
90	PandeiroMute	Gameran 8	Tablah 3	How Tribe	Tablah 4	--
91	PandeiroL Rm	Gameran 9	Tablah 4	92:DholakPh	Tablah Bend	--
92	PandeiroL Sp	Gameran 10	TablaBY 1	120:Dhol Ph	TablaBY 1	--
93	Quijada	Gameran 11	TablaBY 2	African Ens	TablaBY 2	--
94	Rainstick	Gameran 12	Tablah Bend	Morocco Ens	TablaBY 3	--
C7	--	--	--	--	120:Dhol Ph	--
96	--	--	--	--	African Ens	--
97	--	--	--	--	Morocco Ens	--
98	--	--	--	--	--	--
99	180:LatinPt2	78:Korea Ph	--	--	--	--
100	160:CgMambo	132:ChinaPh2	--	--	--	--
101	132:TmbIPtn1	78:GamelnP2	--	--	--	--
102	132:AgogoPtn	122:GamelnP1	--	--	--	--
103	104:Shakin'	Chenchen Ptn	--	--	--	--

* On the RD series (with SRX slots)/MC-909/VR-760/G-70, you can not select only the rhythm sets which are designed to be used with the Fantom series/XV series/MX-200.

* On the MC-909, you can use only the rhythm tones for the sixteen keys from note numbers 35 (B1) through 50 (D3).

※ SRX 対応のRD シリーズ /MC-909/VR-760 では、Fantomシリーズ / XV シリーズ /MX-200 専用のリズム・セットを選ぶことはできません。

※ MC-909 では、Note No. 35 (B1) から 50 (D3) までの 16 鍵分のリズム・トーンのみ使用できます。

Rhythm Set Key Assign (4)

For RD series (with SRX slots)/MC-909/VR-760/G-70

* On the RD series (with SRX slots)/MC-909/VR-760/G-70, you can not select only the rhythm sets which are designed to be used with the Fantom series/XV series/MX-200.

* On the MC-909, you can use only the rhythm tones for the sixteen keys from note numbers 35 (B1) through 50 (D3).

- ※ SRX 対応の RD シリーズ / MC-909 / VR-760 では、Fantom シリーズ / XV シリーズ / MX-200 専用のリズム・セットを選ぶことはできません。
- ※ MC-909 では、Note No. 35 (B1) から 50 (D3) までの 16 鍵分のリ

MC-305 では、NOTE NO. 33 (D1) から 36 (D3) までの 16 錠分のアズム・トーンのみ使用できます。

Waveform List (1)

No. Name	No. Name	No. Name	No. Name
1 World Tour	61 140:EGtr3 G+ # **	121 Ac.Guitar B	181 Yang Qin 2 B
2 Korean Ens	62 140:EGtr3 G # **	122 Ac.Guitar C	182 Yang Qin 2 C
3 Morocco Ens	63 140:EGtr3 C+ # **	123 Reso.Gtr 2 A #	183 YangQinTrm A
4 African Ens	64 140:EGtr3 C # **	124 Reso.Gtr 2 B #	184 YangQinTrm B
5 Asia Phrase	65 140:EGtr3 D+ # **	125 Reso.Gtr 2 C #	185 YangQinTrm C
6 122:GamelnP1 **	66 140:EGtr3 D # **	126 Reso.Gtr 3pA	186 Chung Ruan A
7 78:GamelnP2 **	67 PdlSteelMenu # *	127 Reso.Gtr 3pB	187 Chung Ruan B
8 78:Korea Ph **	68 120:PdSt1 C # **	128 Reso.Gtr 3pC	188 Chung Ruan C
9 118:ChinaPh1 **	69 120:PdSt1 D # **	129 Reso.Gtr 3fA	189 Gu Zheng A
10 132:ChinaPh2 **	70 120:PdSt1 G # **	130 Reso.Gtr 3fB	190 Gu Zheng B
11 118:TablaByP **	71 140:PdSt2 D # **	131 Reso.Gtr 3fC	191 Gu Zheng C
12 92:DholakPh **	72 140:PdSt2 D+ # **	132 MandolinDn A #	192 Kanoun
13 120:Dhol Ph **	73 140:PdSt2 G # **	133 MandolinDn B #	193 Koto
14 96:Salsa **	74 140:PdSt2 G+ # **	134 MandolinDn C #	194 Kayakeum
15 116:Mariachi **	75 E.Gtr Sus A #	135 MandolinUp A #	195 Sanshin A
16 96:Cumbia **	76 E.Gtr Sus B #	136 MandolinUp B #	196 Sanshin B
17 192:LatinPt1 **	77 E.Gtr Sus C #	137 MandolinUp C #	197 Sanshin C
18 180:LatinPt2 **	78 Strat Rear A	138 MandlnTrem A #	198 Pi Pa A
19 96:Cng6/8 1 **	79 Strat Rear B	139 MandlnTrem B #	199 Pi Pa B
20 96:Cng6/8 2 **	80 Strat Rear C	140 MandlnTrem C #	200 Pi Pa C
21 144:CgBolero **	81 LP Clean A	141 Banjo 2 A	201 Biwa MENU *
22 168:CgChacha **	82 LP Clean B	142 Banjo 2 B	202 Biwa 1
23 88:CgCumbia **	83 LP Clean C	143 Banjo 2 C	203 Biwa 2
24 160:CgMambo **	84 Tele Front A	144 Banjo 3 A	204 Biwa 3
25 104:CgMriach **	85 Tele Front B	145 Banjo 3 B	205 Shamisen 2
26 138:CgMarinr **	86 Tele Front C	146 Banjo 3 C	206 Shami Attack
27 126:CgWonwn **	87 Tele Rear A	147 Bouzouki 2fA	207 BerimbauMENU *
28 132:TmbIPtn1 **	88 Tele Rear B	148 Bouzouki 2fB	208 Berimbau Opn
29 132:TmbIPtn2 **	89 Tele Rear C	149 Bouzouki 2fC	209 Berimbau Up
30 100:TmbIPtn3 **	90 335Pick A	150 Bandolim	210 Berimbau Dn
31 120:TmbIPtn4 **	91 335Pick B	151 Cavaquinho	211 Berimbau Mut
32 104:Shakin' **	92 335Pick C	152 Oud A	212 Oct Harp
33 80:PndrPtn1 **	93 E.Gtr Mute A #	153 Oud B	213 Afro Harp
34 108:PndrPtn2 **	94 E.Gtr Mute B #	154 Oud C	214 JawHarp MENU *
35 138:PndrPtn3 **	95 E.Gtr Mute C #	155 Sitar/Drone	215 Jaw Harp Opn
36 132:AgogoPtn **	96 335Mute A	156 Sitar A	216 Jaw Harp Wow
37 132:BottlePtn **	97 335Mute B	157 Sitar B	217 Gtr Strum 1
38 104:BomboPtn **	98 335Mute C	158 Sitar C	218 Gtr Strum 2
39 126:SurdoPtn1 **	99 PdlSteel 1 A #	159 Sitar 2 A	219 Nyln GtrNz 1
40 108:SurdoPtn2 **	100 PdlSteel 1 B #	160 Sitar 2 B	220 Nyln GtrNz 2
41 138:CaixaPtn **	101 PdlSteel 1 C #	161 Sitar 2 C	221 Guitarron Nz
42 132:TambrmPtn **	102 PdlSteel 2 A	162 SitarDrone	222 EG Bend Menu # *
43 108:RepnqPtn1 **	103 PdlSteel 2 B	163 Tambura A	223 EG C Bend 1 #
44 144:RepnqPtn2 **	104 PdlSteel 2 C	164 Tambura B	224 EG C Bend 2 #
45 Samba MENU *	105 PdlSteel 3 A	165 Tambura C	225 EG D Bend 1 #
46 BnjoPhs Menu # *	106 PdlSteel 3 B	166 TamburaDrone	226 EG D Bend 2 #
47 120:Bnjo G # **	107 PdlSteel 3 C	167 Zither A	227 EG D Bend 3 #
48 120:Bnjo A # **	108 RequintoGtrA	168 Zither B	228 EG E Bend 1 #
49 120:Bnjo B # **	109 RequintoGtrB	169 Zither C	229 EG E Bend 2 #
50 120:Bnjo Cm # **	110 RequintoGtrC	170 Santur 2 A	230 EG E Bend 3 #
51 120:Bnjo Cm+ # **	111 Nylon Gtr 3A	171 Santur 2 B	231 EG SlideMenu # *
52 120:Bnjo G-C # **	112 Nylon Gtr 3B	172 Santur 2 C	232 EG Slide 1 #
53 120:BnjoG-C+ # **	113 Nylon Gtr 3C	173 Santur Trm A	233 EG Slide 2 #
54 EG Phs Menu1 # *	114 AcGtr Pick A #	174 Santur Trm B	234 EG Slide 3 #
55 95:EGtr1 G # **	115 AcGtr Pick B #	175 Santur Trm C	235 EG Slide 4 #
56 95:EGtr1 C # **	116 AcGtr Pick C #	176 HmrDulcimer	236 EG Slide 5 #
57 95:EGtr1 D # **	117 AcGtr Fngr A #	177 Afro Zither	237 EG Slide 6 #
58 95:EGtr2 G # **	118 AcGtr Fngr B #	178 Yuechin	238 EG Slide 7 #
59 95:EGtr2 D # **	119 AcGtr Fngr C #	179 Yangchin	239 EG Fx Menu # *
60 EG Phs Menu2 # *	120 Ac.Guitar A	180 Yang Qin 2 A	240 EG Rake 1 #

Waveform List (2)

No.	Name
241	EG Rake 2
242	EG Mute
243	BzkiChd Menu *
244	Bouzki Chd 1
245	Bouzki Chd 2
246	Bouzki Chd 3
247	Sitar Gliss
248	GuZhengArpUp
249	GuZhengArpDn
250	Baby Bass ff
251	6Str Bass A
252	6Str Bass B
253	6Str Bass C
254	FingerdBs 2A
255	FingerdBs 2B
256	FingerdBs 2C
257	Pick Bass 2
258	6StBs Mute A
259	6StBs Mute B
260	6StBs Mute C
261	Tub Bass
262	Guitarron
263	GuitarronOct
264	Baby Bass Nz
265	Violin 2 A
266	Violin 2 B
267	Violin 2 C
268	Fiddle 1 A
269	Fiddle 1 B
270	Fiddle 1 C
271	Fiddle 2 A
272	Fiddle 2 B
273	Fiddle 2 C
274	Fdl Pizz 1 A
275	Fdl Pizz 1 B
276	Fdl Pizz 1 C
277	Fdl Stac 1 A
278	Fdl Stac 1 B
279	Fdl Stac 1 C
280	Erhu
281	Er Hu 2 A
282	Er Hu 2 B
283	Er Hu 2 C
284	Esraj 1
285	Esraj 2
286	Kemanche
287	FiddleFxMenu *
288	Fdl 5th 1
289	Fdl 5th 2
290	Fdl Riff 6
291	Fdl Riff 8
292	Er Hu Phrase
293	Trumpets f A
294	Trumpets f B
295	Trumpets f C
296	Tp Ambient A
297	Tp Ambient B
298	Tp Ambient C
299	SoloTp Vib1A
300	SoloTp Vib1B

No.	Name
301	SoloTp Vib1C
302	SoloTp Vib2A
303	SoloTp Vib2B
304	SoloTp Vib2C
305	Tp RomanticA
306	Tp RomanticB
307	Tp RomanticC
308	Tp Vib MariA
309	Tp Vib MariB
310	Tp Vib MariC
311	Tp Shake A
312	Tp Shake B
313	Tp Shake C
314	Tp Grwah A
315	Tp Grwah B
316	Tp Grwah C
317	MuteTp 2 A
318	MuteTp 2 B
319	MuteTp 2 C
320	Tbns ff A
321	Tbns ff B
322	Tbns ff C
323	Fat Tbns A
324	Fat Tbns B
325	Fat Tbns C
326	Tbn Accent A
327	Tbn Accent B
328	Tbn Accent C
329	Trombone3mfA
330	Trombone3mfB
331	Trombone3mfC
332	Trombone3 fA
333	Trombone3 fB
334	Trombone3 fC
335	Tbn Alto A
336	Tbn Alto B
337	Tbn Alto C
338	Tuba f A
339	Tuba f B
340	Tuba f C
341	2Tp+Tbn A
342	2Tp+Tbn B
343	2Tp+Tbn C
344	2Tp+TbAltTnA
345	2Tp+TbAltTnB
346	2Tp+TbAltTnC
347	Sect Fall A
348	Sect Fall B
349	Sect Fall C
350	Sect Stact A
351	Sect Stact B
352	Sect Stact C
353	SectChd 13th
354	SectChd m9
355	SectChd Mj9
356	IndFlute L A
357	IndFlute L B
358	IndFlute L C
359	IndFlute H A
360	IndFlute H B

No.	Name
361	IndFlute H C
362	Bang Di A
363	Bang Di B
364	Bang Di C
365	BangDi Vib A
366	BangDi Vib B
367	BangDi Vib C
368	Qu Di A
369	Qu Di B
370	Qu Di C
371	Qu Di Vib A
372	Qu Di Vib B
373	Qu Di Vib C
374	Zampona 1
375	Zampo Attack
376	Zampo Trem A
377	Zampo Trem B
378	Zampo Trem C
379	Sicu Pipe
380	Quena
381	Ocarina
382	Kawala A
383	Kawala B
384	Kawala C
385	Shakuhachi 2
386	Shaku Attack
387	Shaku Ornam
388	Hunt Pipe
389	Hunt Noise
390	Bagpipes 1
391	Bagpipes 2
392	Bagpipes 3
393	Bagpipes 4
394	Hichiriki
395	Hichiriki Lp
396	Sheng A
397	Sheng B
398	Sheng C
399	Suona A
400	Suona B
401	Suona C
402	Shahnai
403	Mizmar
404	Mizmar Lp
405	Piri
406	Piri Lp
407	Conch Shell1
408	Conch Shell2
409	Didge MENU *
410	Didgeridoo 1
411	Didgeridoo 2
412	Didgeridoo 3
413	Accrd ff OpA
414	Accrd ff OpB
415	Accrd ff OpC
416	Accrd Cls A
417	Accrd Cls B
418	Accrd Cls C
419	Musette 4 A
420	Musette 4 B
421	Musette 4 C
422	D.AccordionA
423	D.AccordionB
424	D.AccordionC
425	Harmonica2 A
426	Harmonica2 B
427	Harmonica2 C
428	Harmonica3 A
429	Harmonica3 B
430	Harmonica3 C
431	Harmonica4 A
432	Harmonica4 B
433	Harmonica4 C
434	Voice MENU 1 *
435	Yoh Tribe
436	How Tribe
437	Hey Brazil
438	Yyooh Dude
439	ZaghruLoop
440	ZaghruStop
441	Bull Scream
442	Voice MENU 2 *
443	Sabor!
444	Arriba!
445	Ole!
446	Uno!
447	Dos!
448	Tres!
449	Quatro!
450	Grito-Hahaha
451	Grito-Ahaha!
452	Grito-Haahai
453	Grito-Rrrrr!
454	Voice MENU 3 *
455	Tiquitito!
456	Grito-Oa Oa!
457	Grito-Eh Eh!
458	Ama ya ahi!
459	Fuego!
460	SambaBateria
461	AsiaGng MENU *
462	Asian Gong 1
463	Asian Gong 2
464	Asian Gong 3
465	Asian Gong 4
466	Asian Gong 5
467	Asian Gong 6
468	Asian Gong 7
469	REV Gong 5
470	REV Gong 7
471	Gong MENU *
472	Gamelan Gong
473	Kempur
474	Kajar
475	Kelontuk
476	Kelontuk Mt
477	Kelontuk Sid
478	Kemong
479	Ceng Ceng
480	Kopyak Op

Waveform List (3)

No.	Name	No.	Name	No.	Name	No.	Name
481	Kopyak Mt	541	Sarna Bell	601	Dhol 1	661	iYooth
482	Kane	542	Wind Bell	602	Dhol 2	662	Taiko
483	Kane Side	543	Blossom Bell	603	Dhol 3	663	Wadaiko
484	Korea MENU *	544	Agogo MENU *	604	Dhol 4	664	Wadaiko Rim
485	Ching Open	545	Agogo 2 Lo	605	Dhol 5	665	Sime Taiko
486	Ching Mute	546	Agogo 2 Hi	606	Udu Pot MENU *	666	Shimedaiko 2
487	Kwaengwari p	547	Agogo 3 Lo	607	Udu Pot1 Lo	667	Buk
488	Kwaengwari f	548	Agogo 3 Hi	608	Udu Pot1 Hi	668	Buk Rim
489	KwaengwariMt	549	AggoCwblMenu *	609	Udu Pot1 Slp	669	Tsuzumi Lo
490	Bonang	550	BongoBell Op	610	Udu Pot1 Acc	670	Tsuzumi Hi
491	Spokes	551	BongoBell Mt	611	Udu Pot2 Lng	671	Tsuzumi 2 p
492	Satellite Dr	552	MamboBell Op	612	Udu Pot2 Sht	672	Tsuzumi 2 mf
493	Atarigane	553	MamboBell Mt	613	Udu Pot2 Mut	673	Tsuzumi 2 Hi
494	China MENU *	554	Cowbell 1	614	Kendang MENU *	674	Mokugyo 1
495	Xiao Bo	555	Cowbell 2	615	Wadon 1	675	Mokugyo 2
496	Nao Bo	556	Cowbell 3	616	Wadon 2	676	Ohkawa
497	Shou Luo 1	557	VDrum Cowbell	617	Wadon 3	677	Ohkawa 2
498	Shou Luo 2	558	Cowbell Op 1	618	Wadon 4	678	Hyoshigi
499	HuYinLuoL Op	559	Cowbell Mt 1	619	Wadon 5	679	Hyoshigi 2
500	HuYinLuoL Mt	560	Cowbell Op 2	620	Wadon 6	680	Clapstick
501	HuYinLuoH Op	561	Cowbell Mt 2	621	Wadon 7	681	VDrum Woodblk
502	HuYinLuoH Mt	562	TablaByMENU1 *	622	Bebarongan 1	682	Boomerang
503	Ban Gu 1	563	TablaBayA 1	623	Bebarongan 2	683	Changgo
504	Ban Gu 2	564	TablaBayA 2	624	Bebarongan 3	684	Tang Gu Op
505	Ban Gu 3	565	TablaBayA 3	625	Pelegongan 1	685	Tang Gu Mt
506	Gender	566	TablaBayA 4	626	Pelegongan 2	686	Shu Gu
507	Saron	567	TablaBayA 5	627	Pelegongan 3	687	Shu Gu Rim
508	Jegogean A	568	TablaBayA 6	628	TalkingDr Up	688	Shu Ban 1
509	Jegogean B	569	TablaBayA 7	629	TalkingDr Dn	689	Shu Ban 2
510	Jegogean C	570	TablaBayA 8	630	AfroDrm MENU *	690	Ban Gu 4
511	Jublag A	571	TablaByMENU2 *	631	AfroDrum Op1	691	ChinaPrcMENU *
512	Jublag B	572	TablaBayAStd	632	AfroDrum Op2	692	Gu Roll
513	Jublag C	573	TablaBayAgin	633	AfroDrum Flm	693	Gu Hi
514	Pemade A	574	TablaBayA Ge	634	AfroDrum Rat	694	Rot Drum
515	Pemade B	575	TablaBayA Ka	635	Tablah MENU *	695	Log Drum 2
516	Pemade C	576	TablaBayA Na	636	Tablah Bend	696	Slit Drum
517	Reyong A	577	TablaBayA Tin	637	Tablah Dom	697	Bongo MENU 1 *
518	Reyong B	578	TablaBayA Tun	638	Tablah Tak	698	Bongo 1 Lo
519	Reyong C	579	TablaBayA Te	639	Tablah Rim	699	Bongo 1 Hi
520	Reyong Sid A	580	TablaBayA Ti	640	Tablah Roll	700	Bongo 2 Lo
521	Reyong Sid B	581	Dholak MENU1 *	641	Doira Dun	701	Bongo 2 Hi
522	Reyong Sid C	582	Dholak 1	642	Doira Tik	702	Bongo MENU 2 *
523	Steel Dr 2	583	Dholak 2	643	Doholla MENU *	703	Bongo LoOp f
524	Kalimba 1	584	Dholak 3	644	Doholla Dom	704	Bongo Lo Hrd
525	Kalimba 2	585	Dholak 4	645	Doholla Sak	705	Bongo Lo Sft
526	Kalimba 3	586	Dholak 5	646	Doholla Tak	706	Bongo LoOpf
527	Kalimba Glis	587	Dholak 6	647	Doholla Roll	707	Bongo LoSlap
528	Kalim Glis Lp	588	Dholak 7	648	Doholla Stop	708	Bongo Hi Hrd
529	Balaphone 1	589	Dholak 8	649	Rek MENU *	709	Bongo HiOp f
530	Balaphone 2	590	Dholak 9	650	Rek Dom	710	BongoHiSlap1
531	AsiaCym MENU *	591	Dholak MENU2 *	651	Rek Tek	711	BongoHiSlap2
532	Chenchen Ptn	592	Dholak Ga	652	Rek Open	712	Conga Menu *
533	Chenchen Opn	593	Dholak Ta	653	Rek Trill	713	CongaLoOp f
534	Chenchen Cls	594	Dholak Tun	654	Bendir 1	714	CongaLoOp mf
535	BaliCym Opn	595	Dholak Na	655	Bendir 2	715	Conga Lo Mt
536	BaliCym Cls	596	Madal MENU *	656	Dawul	716	Conga Slap
537	Finger Cym	597	Madal Da	657	JapanPrcMENU *	717	Conga Hi Op
538	Ramacymbal	598	Madal Din	658	Japan MENU *	718	Conga Hi Mt
539	Sagat Open	599	Madal Ta	659	Ho	719	Conga Thumb
540	Sagat Close	600	Dhol MENU *	660	Yoh	720	Conga Link

Waveform List (4)

No.	Name	No.	Name	No.	Name	No.	Name
721	Conga Roll	771	VDrum Claves	821	PandeiroOpen	871	Dixie HH Cls
722	Timbale MENU *	772	Cuica 2	822	PandeiroMute	872	Dixie HH Hlf
723	Timbale Lo	773	Cuica 3	823	PandeiroHit	873	Dixie HH Opn
724	Timbale Hi	774	Cuica Lo 1	824	PandeiroRim		
725	Timbale Side	775	Cuica Lo 2	825	PandeiroCrsh		
726	TimbalesMenu *	776	Cuica Hi 1	826	PandeiroRoll		
727	Timbles LoOp	777	Cuica Hi 2	827	TamborimMENU *		
728	Timbles LoMt	778	MrcsShkrMenu *	828	Tamborim Opn		
729	Timbles HiOp	779	Maracas 2	829	Tamborim Mut		
730	Timbles HiMt	780	MaracasUpDwn	830	Tamborim Slp		
731	TimbalesHand	781	VDrum Maracas	831	TamborimOpen		
732	Timbales Rim	782	Shaker MENU *	832	TamborimRim		
733	TmbSideStick	783	Shaker Ptn	833	TamborimMute		
734	TimbalesFil1	784	Shaker 1	834	TamborimRoll		
735	TimbalesFil2	785	Shaker 2	835	Tambrin Hit		
736	TimbalesFil3	786	Shaker Long	836	TambrinShake		
737	TimbalesFil4	787	Shaker Short	837	R8 Tamb		
738	Surdo MENU 1 *	788	Angklung 2	838	Others Menu *		
739	Surdo Open L	789	Rainstick	839	ApitoHiShort		
740	Surdo Open H	790	Guiro Long	840	ApitoLoShort		
741	Surdo Mute	791	Guiro Short	841	SambaWhistle		
742	Surdo Rim	792	Guiro Menu *	842	Quijada		
743	Surdo MENU 2 *	793	Quide Long	843	Chekere 3		
744	Surdo Hard	794	Quide Short	844	CajonClpMenu *		
745	Surdo Open1	795	Guiro Long2	845	Cajon Lo		
746	Surdo Open2	796	Guiro Short2	846	Cajon Hi		
747	Surdo Mute2	797	RecoRecoLng	847	Cajon Rol Hi		
748	Surdo Rim 2	798	RecoRecoSht	848	Cajon Rol Lo		
749	Surdo Soft	799	MtlGuiroLng	849	Afro Feet 1		
750	Caixa MENU 1 *	800	MtlGuiroSht	850	Afro Feet 2		
751	Caixa Open1	801	CbsCxGnzMenu *	851	Afro Clap		
752	Caixa Open2	802	Real Cabasa1	852	Hand Clap 2		
753	Caixa Roll	803	Real Cabasa2	853	Claps Real		
754	Caixa Mute	804	Cabasa Roll	854	FingerSnaps4		
755	Caixa MENU 2 *	805	VDrumCabasaUp	855	BomboBbnMenu *		
756	Caixa Open3	806	VDrumCabasDwn	856	SoftSet Menu *		
757	Caixa Mute2	807	Caxixi	857	HardSet Menu *		
758	Caixa Roll2	808	Ganza Soft	858	Fat BD		
759	Caixa Rim	809	Ganza Hard	859	Room Kick 2		
760	Rpnq&RpqMenu *	810	Chekere 1	860	Maple Kick		
761	RepiniqueHrd	811	Chekere 2	861	Warm Kick		
762	RepiniqueSft	812	PandeiroMENU *	862	Maple Lo Snr		
763	Repinique1	813	PandeiroL Lo	863	MapleSoft SN		
764	Repinique2	814	PandeiroL Hi	864	NaturlHardSN		
765	Repique Open	815	PandeiroL Sp	865	NaturlRimSht		
766	Repique Rim	816	PandeiroL Rm	866	Cross Stick2		
767	Repique Roll	817	PandeiroS Op	867	StudioLo Tom		
768	Clv&CucaMenu *	818	PandeiroS Sp	868	StudioMidTom		
769	Clave!	819	PandeiroS Rm	869	StudioHi Tom		
770	Claves Lo 2	820	PandTambMenu *	870	Dixie HH Pdl		

*: These are menu waveforms. Include multiple waveforms assigned to keys individually.

**: These are the phrase loop waveforms. The numbers included in the wave name represent the recommended tempo (B.P.M.). And these waveforms can be synchronized to a device such as a sequencer.

#: This waveform was selected from the CD-ROM "Whole Lotta Country" from Sampleheads.

When you create a Patch using the waveforms stored in the Expansion Board, observe the following points:

- * If you make a Patch with a single voice and then later play it in a chord, the sound may be distorted with certain settings for the Effects and TVA. If this happens, adjust the level of the Effects and TVA.
- * This product uses waveforms of the SR-JV80 series. For this reason, the upper end of the keyboard may not sound because of key range restrictions.

* : メニュー・ウェーブフォームです。複数のウェーブフォームが、各キーに割り当てられています。

**: フレーズ・ループのウェーブフォームです。ウェーブ・ネームに付いている数字は推奨テンポ(B.P.M.)です。また、これらのウェーブフォームはシーケンサー等との同期が可能です。

: このウェーブフォームは Sampleheads 社 CD-ROM 「WHOLE Lotta Country」からセレクトされています。

このエクスパンション・ボードに収められているウェーブフォームを使ってパッチを作るときには、次の点に注意してください。

- ※ 単音でパッチを作ったとき、エフェクトやTVAの設定状態によって、その音を和音で演奏すると音が歪む場合があります。このようなときは、エフェクトやTVAのレベルを調整してください。
- ※ 本製品のウェーブフォームは SR-JV80 シリーズのウェーブフォームを使用しているため、上鍵域で発音の制限があり発音しない部分があります。

Waveform List (1) (By Region 地域別)

India (インド)

No. Name

156 Sitar A
157 Sitar B
158 Sitar C
159 Sitar 2 A
160 Sitar 2 B
161 Sitar 2 C
247 Sitar Gliss
162 SitarDrone
155 Sitar/Drone
170 Santur 2 A
171 Santur 2 B
172 Santur 2 C
173 Santur Trm A
174 Santur Trm B
175 Santur Trm C
163 Tambura A
164 Tambura B
165 Tambura C
166 TamburaDrone
284 Esraj 1
285 Esraj 2
402 Shahnai
356 IndFlute L A
357 IndFlute L B
358 IndFlute L C
359 IndFlute H A
360 IndFlute H B
361 IndFlute H C
541 Sarna Bell
11 118:TablaByP
571 TablaBYMENU2
572 TablaBayoSld
573 TablaBayGin
574 TablaBay Ge
575 TablaBay Ka
576 TablaBay Na
577 TablaBayTin
578 TablaBayTun
579 TablaBay Te
580 TablaBay Ti
562 TablaByMENU1
563 TablaBay 1
564 TablaBay 2
565 TablaBay 3
566 TablaBay 4
567 TablaBay 5
568 TablaBay 6
569 TablaBay 7
570 TablaBay 8
606 Udu Pot MENU
607 Udu Pot1 Lo
608 Udu Pot1 Hi
609 Udu Pot1 Slp
610 Udu Pot1 Acc
611 Udu Pot2 Lng
612 Udu Pot2 Sht
613 Udu Pot2 Mut
12 92:DholakPh
591 Dholak MENU1
592 Dholak Ga
593 Dholak Ta
594 Dholak Tun

Japan (日本)

No. Name

595 Dholak Na
581 Dholak MENU2
582 Dholak 1
583 Dholak 2
584 Dholak 3
585 Dholak 4
586 Dholak 5
587 Dholak 6
588 Dholak 7
589 Dholak 8
590 Dholak 9
13 120:Dhol Ph
600 Dhol MENU
601 Dhol 1
602 Dhol 2
603 Dhol 3
604 Dhol 4
605 Dhol 5
596 Madal MENU
597 Madal Da
598 Madal Din
599 Madal Ta

Middle East (中近東)

No. Name

152 Oud A
153 Oud B
154 Oud C
286 Kemanche
382 Kawala A
383 Kawala B
384 Kawala C
403 Mizmar
404 Mizmar Lp
404 Mizmar Lp
539 Sagat Open
540 Sagat Close
635 Tablah MENU
636 Tablah Bend
637 Tablah Dom
638 Tablah Tak
639 Tablah Rim
640 Tablah Roll
641 Doira Dun
642 Doira Tik
643 Doholla MENU
644 Doholla Dom
645 Doholla Sak
646 Doholla Tak
647 Doholla Roll
648 Doholla Stop
649 Rek MENU
650 Rek Dom
651 Rek Tek
652 Rek Open
653 Rek Trill
654 Bendir 1
655 Bendir 2
656 Dawul
439 ZaghrutaLoop
440 ZaghrutaStop
3 Morocco Ens

Korea (韓国)

No. Name

194 Kayakeum
405 Piri
406 Piri Lp
484 Korea MENU
485 Ching Open
486 Ching Mute
487 Kwaengwari p
488 Kwaengwari f
489 KwaengwariMt
667 Buk
668 Buk Rim
683 Changgo
8 78:Korea Ph
2 Korean Ens

China (中国)

No. Name

178 Yuehchin
179 Yangchin
280 Erhu
461 AsiaGng MENU
462 Asian Gong 1
463 Asian Gong 2
464 Asian Gong 3
465 Asian Gong 4
466 Asian Gong 5
467 Asian Gong 6
468 Asian Gong 7
469 REV Gong 5
470 REV Gong 7
531 AsiaCym MENU
503 Ban Gu 1
504 Ban Gu 2
505 Ban Gu 3
691 ChinaPrcMENU
692 Gu Roll
693 Gu Hi
198 Pi Pa A
199 Pi Pa B
200 Pi Pa C
186 Chung Ruan A
187 Chung Ruan B
188 Chung Ruan C
189 Gu Zheng A
190 Gu Zheng B
191 Gu Zheng C
180 Yang Qin 2 A
181 Yang Qin 2 B
182 Yang Qin 2 C
183 YangQinTrm A
184 YangQinTrm B
185 YangQinTrm C
281 Er Hu 2 A
282 Er Hu 2 B
283 Er Hu 2 C
362 Bang Di A
363 Bang Di B
364 Bang Di C
365 BangDi Vib A
366 BangDi Vib B
367 BangDi Vib C
368 Qu Di A
369 Qu Di B
370 Qu Di C
371 Qu Di Vib A
372 Qu Di Vib B
373 Qu Di Vib C
396 Sheng A
397 Sheng B
398 Sheng C
399 Suona A
400 Suona B
401 Suona C
494 China MENU
495 Xiao Bo
496 Nao Bo
497 Shou Luo 1
498 Shou Luo 2
499 HuYinLuoL Op

Waveform List (2) (By Region 地域別)

500 HuYinLuoL Mt
501 HuYinLuoH Op
502 HuYinLuoH Mt
684 Tang Gu Op
685 Tang Gu Mt
686 Shu Gu
687 Shu Gu Rim
687 Shu Gu Rim
688 Shu Ban 1
689 Shu Ban 2
292 Er Hu Phrase
248 GuZhengArpUp
249 GuZhengArpDn
9 118:ChinaPh1
10 132:ChinaPh2

Europe (ヨーロッパ)

No. Name
167 Zither A
168 Zither B
169 Zither C
381 Ocarina
390 Bagpipes 1
391 Bagpipes 2
392 Bagpipes 3
393 Bagpipes 4

North America (北米)

No. Name
176 HmrDulcimer

South America (南米)

No. Name
150 Bandolim
151 Cavaquinho
212 Oct Harp
374 Zampona 1
375 Zampo Attack
376 Zampo Trem A
377 Zampo Trem B
378 Zampo Trem C
379 Sicu Pipe
380 Quena
523 Steel Dr 2
207 BerimbauMENU
208 Berimbau Opn
209 Berimbau Up
210 Berimbau Dn
211 Berimbau Mut
789 Rainstick
437 Hey Brazil
45 Samba MENU
460 SambaBateria
812 PandeiroMENU
813 PandeiroL Lo
814 PandeiroL Hi

815 PandeiroL Sp
816 PandeiroL Rm
817 PandeiroS Op
818 PandeiroS Sp
819 PandeiroS Rm
827 TamborimMENU
828 Tamborim Opn
829 Tamborim Mut
830 Tamborim Slp
738 Surdo MENU 1
743 Surdo MENU 2
739 Surdo Open L
740 Surdo Open H
741 Surdo Mute
747 Surdo Mute2
742 Surdo Rim
748 Surdo Rim 2
750 Caixa MENU 1
755 Caixa MENU 2
751 Caixa Open1
752 Caixa Open2
753 Caixa Roll
758 Caixa Roll2
754 Caixa Mute
757 Caixa Mute2
544 Agogo MENU
545 Agogo 2 Lo
546 Agogo 2 Hi
547 Agogo 3 Lo
548 Agogo 3 Hi
554 Cowbell 1
555 Cowbell 2
556 Cowbell 3
772 Cuica 2
773 Cuica 3
782 Shaker MENU
783 Shaker Ptn
784 Shaker 1
785 Shaker 2

Africa (アフリカ)

No. Name
213 Afro Harp
388 Hunt Pipe
389 Hunt Noise
524 Kalimba 1
525 Kalimba 2
526 Kalimba 3
527 Kalimba Glis
528 Kalim Gls Lp
529 Balaphone 1
530 Balaphone 2
695 Log Drum 2
696 Slit Drum
628 TalkingDr Up
629 TalkingDr Dn
630 AfroDrm MENU
631 AfroDrum Op1
632 AfroDrum Op2
633 AfroDrum Flm
634 AfroDrum Rat
177 Afro Zither
849 Afro Feet 1
850 Afro Feet 2
851 Afro Clap
435 Yoh Tribe
436 How Tribe
4 African Ens

Others (その他)

No. Name
543 Blossom Bell
491 Spokes
694 Rot Drum
434 Voice MENU 1
442 Voice MENU 2
454 Voice MENU 3
441 Bull Scream
407 Conch Shell1
408 Conch Shell2
1 World Tour

Southeast Asia (東南アジア)

No. Name
490 Bonang
506 Gender
507 Saron
537 Finger Cym
538 Ramacymbal
532 Chenchen Ptn
533 Chenchen Opn
534 Chenchen Cls
535 BaliCym Opn
536 BaliCym Cls
788 Angklung 2
214 JawHarp MENU
215 Jaw Harp Opn
216 Jaw Harp Wow

Australia (オーストラリア)

No. Name
680 Clapstick
682 Boomerang
409 Didge MENU
410 Didgeridoo 1
411 Didgeridoo 2
412 Didgeridoo 3

Menu Waveform (1)

45 Samba MENU

Key Wave# WaveName

C 4	Samba Phr1	*
D 4	Samba Phr2	*
E 4	Samba Phr3	*

46 BnjoPhs Menu

Key Wave# WaveName

C 4 47	120:Bnjo G
D 4 48	120:Bnjo A
E 4 49	120:Bnjo B
F 4 50	120:Bnjo Crm
G 4 51	120:Bnjo Crm+
A 4 52	120:Bnjo G-C
B 4 53	120:BnjoG-C+

54 EG Phs Menu1

Key Wave# WaveName

C 4 55	95:EGTr1 G
D 4 56	95:EGTr1 C
E 4 57	95:EGTr1 D
F 4 58	95:EGTr2 G
G 4 59	95:EGTr2 D

60 EG Phs Menu2

Key Wave# WaveName

C 4 61	140:EGTr3 G+
D 4 62	140:EGTr3 G
E 4 63	140:EGTr3 C+
F 4 64	140:EGTr3 C
G 4 65	140:EGTr3 D+
A 4 66	140:EGTr3 D

67 PdSteelMenu

Key Wave# WaveName

C 4 68	120:PdSt1 C
D 4 69	120:PdSt1 D
E 4 70	120:PdSt1 G
F 4 71	140:PdSt2 D
G 4 72	140:PdSt2 D+
A 4 73	140:PdSt2 G
B 4 74	140:PdSt2 G+

201 Biwa MENU

Key Wave# WaveName

C 4 202	Biwa 1
D 4 203	Biwa 2
E 4 204	Biwa 3

207 BerimbauMENU

Key Wave# WaveName

C 4 208	Berimbau Opn
D 4 209	Berimbau Up
E 4 210	Berimbau Dn
F 4 211	Berimbau Mut

214 JawHarp MENU

Key Wave# WaveName

C 4 215	Jaw Harp Opn
D 4 216	Jaw Harp Wow
E 4	Reverse ? *

222 EG Bend Menu

Key Wave# WaveName

C 4 223	EG C Bend 1
D 4 224	EG C Bend 2
E 4 225	EG D Bend 1
F 4 226	EG D Bend 2
G 4 227	EG D Bend 3
A 4 228	EG E Bend 1
B 4 229	EG E Bend 2
C 5 230	EG E Bend 3

231 EG SlideMenu

Key Wave# WaveName

C 4 232	EG Slide 1
D 4 233	EG Slide 2
E 4 234	EG Slide 3
F 4 235	EG Slide 4
G 4 236	EG Slide 5
A 4 237	EG Slide 6
B 4 238	EG Slide 7

239 EG Fx Menu

Key Wave# WaveName

C 4 240	EG Rake 1
D 4 241	EG Rake 2
E 4 242	EG Mute

243 BzkiChd Menu

Key Wave# WaveName

C 4 244	Bouzki Chd 1
D 4 244	Bouzki Chd 1
E 4 245	Bouzki Chd 2
F 4 245	Bouzki Chd 2
G 4 246	Bouzki Chd 3
A 4 246	Bouzki Chd 3

287 FiddleFxMenu

Key Wave# WaveName

C 4 288	Fdl 5th 1
D 4 289	Fdl 5th 2
E 4 290	Fdl Riff 6
F 4 291	Fdl Riff 8

409 Didge MENU

Key Wave# WaveName

C 4 410	Didgeridoo 1
D 4 411	Didgeridoo 2
E 4 412	Didgeridoo 3
F 4	Didgeridoo 4 *
G 4	Didgeridoo 5 *
A 4	Didgeridoo 6 *

434 Voice MENU 1

Key Wave# WaveName

C 4 435	Yoh Tribe
D 4 436	How Tribe
E 4 437	Hey Brazil
F 4 438	Yooo Dude
G 4 439	ZaghruTaLoop
A 4 440	ZaghruTaStop
B 4 441	Bull Scream

442 Voice MENU 2

Key Wave# WaveName

C 4 443	Sabor!
D 4 444	Arriba!
E 4 445	Ole!
F 4 446	Uno!
G 4 447	Dos!
A 4 448	Tres!
B 4 449	Quatro!
C 5 450	Grito-Hahaha
D 5 451	Grito-Ahaha!
E 5 452	Grito-Haahai
F 5 453	Grito-Rrrrr!

454 Voice MENU 3

Key Wave# WaveName

C 4 455	Tiquitito!
D 4 456	Grito-Oa Oa!
E 4 457	Grito-Eh Eh!
F 4 458	Ama ya ahi!
G 4 459	Fuego!

461 AsiaGng MENU

Key Wave# WaveName

C 4 462	Asian Gong 1
D 4 463	Asian Gong 2
E 4 464	Asian Gong 3
F 4 465	Asian Gong 4
G 4 466	Asian Gong 5
A 4 467	Asian Gong 6
B 4 468	Asian Gong 7
C 5	REV Gong 4 *
D 5	REV Gong 5 *
E 5	REV Gong 6 *
F 5	REV Gong 7 *

471 Gong MENU

Key Wave# WaveName

C 4 472	Gamelan Gong
D 4 473	Kempur
E 4 474	Kajar
F 4 475	Kelontuk
G 4 476	Kelontuk Mt
A 4 477	Kelontuk Sid
B 4 478	Kemong
C 5 479	Ceng Ceng
D 5 480	Kopyak Op
E 5 481	Kopyak Mt
F 5 6	122:GamelnP1
G 5 7	78:GamelnP2

484 Korea MENU

Key Wave# WaveName

C 4 667	Buk
D 4 668	Buk Rim
E 4 683	Chango
F 4 485	Ching Open
G 4 486	Ching Mute
A 4 487	Kwaengwari p
B 4 488	Kwaengwari f
C 5 489	KwaengwariMt

494 China MENU

Key Wave# WaveName

C 4 684	Tang Gu Op
D 4 685	Tang Gu Mt
E 4 686	Shu Gu
F 4 687	Shu Gu Rim
G 4 688	Shu Ban 1
A 4 689	Shu Ban 2
B 4 690	Ban Gu 4
C 5 495	Xiao Bo
D 5 496	Nao Bo
E 5 497	Shou Luo 1
F 5 498	Shou Luo 2
G 5 499	HuYinLuoL Op
A 5 500	HuYinLuoL Mt
B 5 501	HuYinLuoH Op
C 6 502	HuYinLuoH Mt
D 6 10	132:ChinaPh2

531 AsiaCym MENU

Key Wave# WaveName

C 4 532	Chenchen Ptn
D 4 533	Chenchen Opn
E 4 534	Chenchen Cls
F 4 535	BaliCym Opn
G 4 536	BaliCym Cls

544 Agogo MENU

Key Wave# WaveName

C 4 545	Agogo 2 Lo
D 4 546	Agogo 2 Hi
E 4 547	Agogo 3 Lo
F 4 548	Agogo 3 Hi
G 4 554	Cowbell 1
A 4 555	Cowbell 2
B 4 556	Cowbell 3

562 TablaByMENU1

Key Wave# WaveName

C 4 563</

Menu Waveform (2)

571 TablaByMENU2

Key Wave# WaveName

C 4	TablaBayaP 1	*
D 4	TablaBayaP 2	*
E 4	TablaBayaP 3	*
F 4	TablaBayaP 4	*
G 4	TablaBayaP 5	*
A 4	572	TablaBayaSld
B 4	573	TablaBayaGin
C 5	574	TablaBaya Ge
D 5	575	TablaBaya Ka
E 5	576	TablaBaya Na
F 5	577	TablaBayaTin
G 5	578	TablaBayaTun
A 5	579	TablaBaya Te
B 5	580	TablaBaya Ti

581 Dholak MENU1

Key Wave# WaveName

C 4	582	Dholak 1
D 4	583	Dholak 2
E 4	584	Dholak 3
F 4	585	Dholak 4
G 4	586	Dholak 5
A 4	587	Dholak 6
B 4	588	Dholak 7
C 5	589	Dholak 8
D 5	590	Dholak 9
E 5	12	92:DholakPh

591 Dholak MENU2

Key Wave# WaveName

C 4	592	Dholak Ga
D 4	593	Dholak Ta
E 4	594	Dholak Tun
F 4	595	Dholak Na
G 4		Dholak Ga 2 *

596 Madal MENU

Key Wave# WaveName

C 4	597	Madal Da
D 4	598	Madal Din
E 4	599	Madal Ta

600 Dhol MENU

Key Wave# WaveName

C 4	601	Dhol 1
D 4	602	Dhol 2
E 4	603	Dhol 3
F 4	604	Dhol 4
G 4	605	Dhol 5
A 4	13	120:Dhol Ph

606 Udu Pot MENU

Key Wave# WaveName

C 4		Udu Pot Phr1 *
D 4		Udu Pot Phr2 *
E 4		Udu Pot Phr3 *
F 4	607	Udu Pot1 Lo
G 4	608	Udu Pot1 Hi
A 4	609	Udu Pot1 Slp
B 4	610	Udu Pot1 Acc
C 5	611	Udu Pot2 Lng
D 5	612	Udu Pot2 Sht
E 5	613	Udu Pot2 Mut

614 Kendang MENU

Key Wave# WaveName

C 4	615	Wadon 1
D 4	616	Wadon 2
E 4	617	Wadon 3
F 4	618	Wadon 4
G 4	619	Wadon 5
A 4	620	Wadon 6
B 4	621	Wadon 7
C 5	622	Bebarongan 1
D 5	623	Bebarongan 2
E 5	624	Bebarongan 3
F 5	625	Peleongan 1
G 5	626	Peleongan 2
A 5	627	Peleongan 3

630 AfroDrm MENU

Key Wave# WaveName

C 4	631	AfroDrum Op1
D 4	632	AfroDrum Op2
E 4	633	AfroDrum Flm
F 4	634	AfroDrum Rat

635 Tablah MENU

Key Wave# WaveName

C 4		Tablah Phr1 *
D 4		Tablah Phr2 *
E 4		Tablah Phr3 *
F 4		Tablah Phr4 *
G 4	636	Tablah Bend
A 4	637	Tablah Dom
B 4	638	Tablah Tak
C 5	639	Tablah Rim
D 5	640	Tablah Roll

643 Doholla MENU

Key Wave# WaveName

C 4	644	Doholla Dom
D 4	645	Doholla Sak
E 4	646	Doholla Tak
F 4	647	Doholla Roll
G 4	648	Doholla Stop

649 Rek MENU

Key Wave# WaveName

C 4	650	Rek Dom
D 4	651	Rek Tek
E 4	652	Rek Open
F 4	653	Rek Trill

657 JapanPrcMENU

Key Wave# WaveName

C 4	662	Taiko
D 4	665	Sime Taiko
E 4	669	Tsuzumi Lo
F 4	670	Tsuzumi Hi
G 4	676	Ohkawa
A 4	678	Hyoshigi
B 4	493	Atarigane
C 5	438	Yyoo Dude

658 Japan MENU

Key Wave# WaveName

C 4	663	Wadaiko
D 4	664	Wadaiko Rim
E 4	666	Shimedaiko 2
F 4	671	Tsuzumi 2 p
G 4	672	Tsuzumi 2 mf
A 4	673	Tsuzumi 2 Hi
B 4	677	Ohkawa 2
C 5	674	Mokugyo 1
D 5	675	Mokugyo 2
E 5	679	Hyoshigi 2
F 5	482	Kane
G 5	483	Kane Side
A 5	542	Wind Bell
B 5	659	Ho
C 6	660	Yoh
D 6	661	iYoh

726 TimbalesMenu

Key Wave# WaveName

C 4	727	Timbales LoOp
D 4	728	Timbales LoMt
E 4	729	Timbales HiOp
F 4	730	Timbales HiMt
G 4	731	TimbalesHand
A 4	732	Timbales Rim
B 4	733	TmbSideStick
C 5	734	TimbalesFil1
D 5	735	TimbalesFil2
E 5	736	TimbalesFil3
F 5	737	TimbalesFil4

738 Surdo MENU 1

Key Wave# WaveName

C 4	739	Surdo Open L
D 4	740	Surdo Open H
E 4	741	Surdo Mute
F 4	742	Surdo Rim

750 Caixa MENU 1

Key Wave# WaveName

C 4	751	Caixa Open1
D 4	752	Caixa Open2
E 4	753	Caixa Roll
F 4	754	Caixa Mute

755 Caixa MENU 2

Key Wave# WaveName

C 4	756	Caixa Open3
D 4	757	Caixa Mute2
E 4	758	Caixa Roll2
F 4	759	Caixa Rim

768 Clv&CucaMenu

Key Wave# WaveName

C 4	769	Clave!
D 4	770	Claves Lo 2
E 4	774	Cuica Lo 1
F 4	775	Cuica Lo 2
G 4	776	Cuica Hi 1
A 4	777	Cuica Hi 2

778 MrcsShkrMenu

Key Wave# WaveName

C 4	779	Maracas 2
D 4	780	MaracasUpDwn
E 4	786	Shaker Long
F 4	787	Shaker Short
G 4		Shaker Lite *

Menu Waveform (3)

782 Shaker MENU

Key Wave# WaveName

C 4	783	Shaker Ptn
D 4	784	Shaker 1
E 4	785	Shaker 2

792 Guiro Menu

Key Wave# WaveName

C 4	793	Quide Long
D 4	794	Quide Short
E 4	795	Guiro Long2
F 4	796	Guiro Short2
G 4	797	RecoRecoLng
A 4	798	RecoRecoSht
B 4	799	MtlGuiroLng
C 5	800	MtlGuiroSht
D 5		MtlGuiroAtc *
E 5		MtlGuiroMut *

801 CbsCxGnzMenu

Key Wave# WaveName

C 4	802	Real Cabasa1
D 4	803	Real Cabasa2
E 4	804	Cabasa Roll
F 4	807	Caxixi
G 4	808	Ganza Soft
A 4	809	Ganza Hard

812 PandeiroMENU

Key Wave# WaveName

C 4	813	PandeiroL Lo
D 4	814	PandeiroL Hi
E 4	815	PandeiroL Sp
F 4	816	PandeiroL Rm
G 4	817	PandeiroS Op
A 4	818	PandeiroS Sp
B 4	819	PandeiroS Rm

820 PandTambMenu

Key Wave# WaveName

C 4	821	PandeiroOpen
D 4	822	PandeiroMute
E 4	823	PandeiroHit
F 4	824	PandeiroRim
G 4	825	PandeiroCrsh
A 4	826	PandeiroRoll
B 4	831	TamborimOpen
C 5	832	TamborimRim
D 5	833	TamborimMute
E 5	834	TamborimRoll
F 5	835	Tambrin Hit
G 5	836	TambrinShake

827 TamborimMENU

Key Wave# WaveName

C 4	828	Tamborim Opn
D 4	829	Tamborim Mut
E 4	830	Tamborim Slp

838 Others Menu

Key Wave# WaveName

C 4	839	ApitoHiShort
D 4	840	ApitoLoShort
E 4	842	Quijada
F 4	843	Chekere 3

844 CajonClpMenu

Key Wave# WaveName

C 4	845	Cajon Lo
D 4	846	Cajon Hi
E 4	847	Cajon Rol Hi
F 4	848	Cajon Rol Lo
G 4	852	Hand Clap 2

855 BomboBbnMenu

Key Wave# WaveName

C 4		Bombo Open *
D 4		Bombo Mute *
E 4		Bombo Rol *
F 4		Bubans 1 *
G 4		Bubans Rol *

856 SoftSet Menu

Key Wave# WaveName

C 2	745	Surdo Open1
D 2	757	Caixa Mute2
E 2	822	PandeiroMute
F 2	762	RepiniqueSft
C 4	706	Bongo LoOpmf
D 4	714	CongaLoOp mf
E 4	730	Timbres HiMt
F 4	550	BongoBell Op
G 4	802	Real Cabasa1
A 4	786	Shaker Long
B 4	808	Ganza Soft
C 5	775	Cuica Lo 2
D 5	795	Guiro Long2

857 HardSet Menu

Key Wave# WaveName

C 2	746	Surdo Open2
D 2	756	Caixa Open3
E 2	821	PandeiroOpen
F 2	761	RepiniqueHrd
C 4	704	Bongo Lo Hrd
D 4	713	CongaLoOp f
E 4	729	Timbres HiOp
F 4	552	MamboBell Op
G 4	803	Real Cabasa2
A 4	787	Shaker Short
B 4	809	Ganza Hard
C 5	774	Cuica Lo 1
D 5	793	Quide Long

* Used only in the menu waveforms.

* このウェーブフォームはメニュー・ウェーブフォームのみで使用しています。

About the New Format

Expansion boards SRX-01-04 could only hold a maximum of 128 Patches. In order to make it possible to provide an even greater variety of sounds, a new format (implemented originally on the SRX-05) is now being employed. This new format is capable of handling more than 128 Patches.

If you are using one of the five models listed below, and are still using an older version of the system, you may need to upgrade its system to enable it to support the new SRX format. Check the system program version of your instrument; if your current version is the same as, or older than the corresponding one listed below, use the system update program on the included CD-ROM to upgrade to the latest version before using the SRX-09.

- Fantom (FA-76): Update required for versions up to Ver. 1.12
- XV-5080: Update required for versions up to Ver. 1.24
- XV-3080: Update required for versions up to Ver. 1.08
- XV-88: Update required for versions up to Ver. 1.07
- RD-700: Update required for versions up to Ver. 1.04

For instructions on checking the system program version for each instrument, and upgrading the software, refer to the html files for the relevant instrument included on the CD-ROM.

About the Included CD-ROM

The included CD-ROM features:

- System update programs compatible with new-format SRX expansion boards (for Fantom (FA-76), XV-5080, XV-3080, XV-88, and RD-700)
- Data Reproducing the SR-JV's Original Patches and Rhythm Sets (Compatible models: Fantom (FA-76), XV-5080, XV-5050, XV-3080, XV-88, XV-2020)
- SRX-01-09 demo songs
- BPM Conversion Table

For more detailed information on each file, refer to index_e.html on the CD-ROM.

- * *Take proper care of the included CD-ROM; it will not be reissued.*
- * *The system programs on the included CD-ROM are the latest versions, as of September, 2002. For information regarding newer versions than those on this disk, you should contact the nearest Roland Service Center.*

新フォーマットについて

エクスパンション・ボード SRX-01 ~ 04 は、最大 128 パッチを収録していました。SRX-05 以降は、より多彩な音色をお客様に供給する為に、128 以上のパッチを扱えるよう、新フォーマットを採用しています。

これにより、以下の 5 機種において、現在お使いのバージョンによっては、新フォーマットに対応するためにバージョン・アップしていただく必要があります。システム・プログラム・バージョンをご確認の上、下記のバージョン、もしくはそれより古いバージョンの場合は、付属 CD-ROM に収録のシステム・アップデート・プログラムを使用して、製品をバージョン・アップしてから SRX-09 をお使いください。

- Fantom (FA-76) : Ver 1.12 まではアップデートが必要
- XV-5080 : Ver 1.24 まではアップデートが必要
- XV-3080 : Ver 1.08 まではアップデートが必要
- XV-88 : Ver 1.07 まではアップデートが必要
- RD-700 : Ver 1.04 まではアップデートが必要

各機種のシステム・プログラム・バージョンの確認方法、およびバージョン・アップ方法は、付属 CD-ROM に収録の、各機種別ファイルを参照してください。

付属 CD-ROM について

付属 CD-ROM には

- SRX エクスパンション・ボード新フォーマット対応用システム・アップデート・プログラム
(Fantom (FA-76)、XV-5080、XV-3080、XV-88、RD-700)
- SR-JV オリジナル Patch / Rhythm Set 再現データ
(対応機種: Fantom (FA-76)、XV-5080、XV-5050、XV-3080、XV-88、XV-2020)
- SRX-01 ~ 09 デモ・ソング
- BPM 変換テーブル

が収録されています。各ファイルの詳しい内容は、CD-ROM 内の index_j.html 参照してください。

- ※ 付属 CD-ROM は再発行しませんので、大切にお使いください。
- ※ 付属 CD-ROM に収録の各システム・プログラムは、2002 年 9 月時点での最新のものです。収録バージョンより新しいプログラムに関しては、もよりのローランド・サービスにお問い合わせください。



ローランド製品保証書

[持込修理]

お客様	ご芳名	様
	〒	□

取扱販売店名・住所・□

保証期間

お買い上げ日

年 月 日より

本体は一年間

ただし、ソフトウェア、付属品、消耗部品は除く

太枠内に記入または捺印の無い場合は、必ず販売店発行の領収書またはそのお買上げ年月日・販売店等を証明するものを保証書に添付願います。記入もしくは添付の無い場合は無効となりますので、ご注意ください。

型名 SRX-09 "World Collection"

●本保証書は、本書記載内容で無料修理をさせていただくことを約束するものです。

●保証期間中に故障が発生した場合は、製品と本書をご持参ご提示の上、お買上げの販売店にご依頼ください。

●ご転居・ご贈答品などの場合で、お買上げ販売店に修理を依頼することができない場合は、ローランドサービスステーションにお問い合わせください。

●本書は再発行いたしません。所定事項の記入および内容をよくお読みの上、大切に保存してください。



ローランド株式会社

本社工場 〒431-1304 浜松市細江町中川2036-1
電話 (053) 523-0230

保証規定

- 保証期間内において、取扱説明書・本体貼付ラベルなどの注意書に従った正常なご使用状態で発生した故障については、第3項に示す場合を除き、無料修理いたします。
- 保証期間内に無料修理をお受けになる場合は、お買上げの販売店・又は最寄りのローランドサービスステーションにご依頼のうえ、修理の際に本書をご提示ください。お客様のご事情により出張修理を依頼された場合、保証期間中であっても出張料金を申し受けます。
- 保証期間内でも、次の場合には有料修理となります。
 - (イ) 本書のご提示が無い場合。
 - (ロ) 本書にお買上げ年月日・販売店名の記入が無い場合、または字句を書き換えられた場合。
 - (ハ) ご使用上の誤り、又は当社の指定者以外の手により修理・改造された場合。
- 本製品に異常がなく、他の部分、他の機器に異常があり、点検及び改善した場合。
- お買上げ後の輸送、移動、落下等による故障や損傷および使用中に生じたキズ・汚れなどの外観上の変化。
- 地震、落雷、風水害、その他の天災地変、火災、公害、ガス、異常電圧による故障や損傷。
- 消耗部品（例：電池など）の取り替えを要する場合、および消耗部品の摩耗や劣化に起因する故障や損傷。

This warranty is valid only in Japan.

修理メモ

※ 本保証書は以上の保証規定により無料修理をお約束するものです。従ってこの保証書によってお客様の法律上の権利を制限するものではありません。

※ 本製品の補修用性能部品（製品の機能を維持するために必要な部品）の最低保有期間は製造打切後6年です。この部品保有期間を修理可能の期間とさせていただきます。保有期間経過後も、故障内容によっては修理可能の場合がありますので、ローランドサービスステーションまでお問い合わせください。

※ 修理の際、交換した部品を再生、再利用、製品の品質向上等の目的で回収させていただくことがありますので、ご協力願います。

Copyright © 2002 ROLAND CORPORATION

All rights reserved. No part of this publication may be reproduced in any form without the written permission of ROLAND CORPORATION.

© 2002 ローランド株式会社 本書の一部、もしくは全部を無断で複写・転載することを禁じます。



03122789

'05-10-5N