

# Waves API 550

## User Manual



**WAVES**

# TABLE OF CONTENTS

<b>CHAPTER 1 – INTRODUCTION.....</b>	<b>3</b>
1.1 WELCOME.....	3
1.2 PRODUCT OVERVIEW .....	4
1.3 COMPONENTS.....	5
<b>CHAPTER 2 – QUICKSTART GUIDE .....</b>	<b>6</b>
<b>CHAPTER 3 – CONTROLS AND INTERFACE.....</b>	<b>7</b>
3.1 EQ SECTION.....	8
3.2 OUTPUT SECTION.....	12
<b>CHAPTER 4 – THE WAVESYSTEM .....</b>	<b>14</b>
4.1 THE WAVESYSTEM TOOLBAR .....	14
<i>Toolbar Functions</i> .....	14
4.2 PRESET HANDLING .....	14
<i>Preset Types</i> .....	14
<i>Loading Presets and Setups</i> .....	15
<i>Saving Presets and Setups</i> .....	15
<i>Deleting Presets</i> .....	16
<i>A/B Comparison and Copying</i> .....	16
4.3 INTERFACE CONTROLS .....	16
<i>Toggle Buttons</i> .....	16
<i>Value Window Buttons</i> .....	17
<i>Sliders</i> .....	17
<i>Hover Box</i> .....	17
<i>Multiple Selection of Controls</i> .....	17
<i>TAB Functions</i> .....	18
<b>APPENDIX A – 550A CONTROLS.....</b>	<b>19</b>
<b>APPENDIX B – 550B CONTROLS.....</b>	<b>19</b>

# Chapter 1 – Introduction

## 1.1 Welcome

Thank you for choosing Waves! In order to get the most out of your Waves processor, please take the time to read through this manual.

In conjunction, we also suggest that you become familiar with [www.wavesupport.net](http://www.wavesupport.net). There you will find an extensive **Answer Base**, the latest **Tech Specs**, detailed **Installation** guides, new **Software Updates**, and current information on **Authorization** and **Registration**.

By signing up at [www.wavesupport.net](http://www.wavesupport.net), you will receive personalized information on your registered products, reminders when updates are available, and information on your authorization status.

## 1.2 Product Overview



The Waves API 550 consists of the API 550A, a 3-Band parametric equalizer with 5 fixed cutoff points per band and the API 550B, a 4-Band parametric equalizer with 7 fixed cutoff points per band.

Modeled on the late 1960's legend, the API 550A EQ delivers a sound that has been a hallmark of high end studios for decades. It provides reciprocal equalization at 15 points in 5 steps of boost divided into three overlapping ranges. The high and low frequency ranges are individually selectable as either peaking or shelving, and a band-pass filter can be inserted independently of all other settings.

Featuring four overlapped EQ bands, the API 550B features 7 switchable filter frequencies spanning up to 5 octaves per band. "Proportional Q" automatically widens the filter bandwidth at lower settings and narrows it at higher settings. It even lets you undo previous processing, affect or even reverse tonal modifications. With its vast range of tonal possibilities, the API 550B is an exceptionally versatile EQ.

## 1.3 Components

WaveShell technology enables us to split Waves processors into smaller plug-ins, which we call **components**. Having a choice of components for a particular processor gives you the flexibility to choose the configuration best suited to your material.

The API 550 has four component processors:

**API 550A Stereo** – A 3-Band stereo equalizer

**API 550A Mono** – A 3-Band mono equalizer


**API 550B Stereo** – A 4-Band stereo equalizer

**API 550B Mono** – A 4-Band mono equalizer

## **Chapter 2 – Quickstart Guide**

Approach the Waves API 550 as you would any conventional EQ. Since the API 550 features “Proportional Q,” which intuitively widens the filter bandwidth at lower settings and narrows it at higher settings, feel free to push the API 550 harder than you normally would other equalizers. The API 550 will deliver smooth, natural, and musical sound even at the most extreme settings.

# Chapter 3 – Controls and Interface



### 3.1 EQ Section



### API 550A Controls

#### Low Band Gain

##### Range

-12dB to +12dB (2-3dB steps)

##### Default

0dB

#### Low Band Frequency

##### Filter types

Shelf, Bell

##### Default

Shelf

##### Cutoff points

50Hz, 100Hz, 200Hz, 300Hz, 400Hz

##### Default

50Hz

#### Mid Band Gain

##### Range

-12dB to +12dB (2-3dB steps)

##### Default

0dB

### **Mid Band Frequency**

#### **Range**

.4kHz, .8kHz, 1.5kHz, 3kHz, 5kHz

#### **Default**

1.5kHz

#### **Filter types**

Bell

### **High Band Gain**

#### **Range**

-12dB to +12dB (2-3dB steps)

#### **Default**

0dB

### **High Band Frequency**

#### **Range**

5kHz, 7kHz, 10kHz, 12.5kHz, 15kHz

#### **Default**

7kHz

### **Bandpass Filter**

Applies a 50Hz-15kHz bandpass filter to the entire signal

#### **Range**

50Hz-15kHz

#### **Default**

Off

#### **Filter types**

Shelf, Bell

#### **Cutoff points**

5kHz, 7kHz, 10kHz, 12.5kHz, 15kHz

### **Low Shelf/Bell Selector**

#### **Range**

Shelf or Bell

#### **Default**

Shelf

### **High Shelf/Bell Selector**

#### **Range**

Shelf or Bell

#### **Default**

Shelf

## API 550B Controls

### Low Band Gain

#### Range

-12dB to +12dB (2-3dB steps)

#### Default

0dB

### Low Band Frequency

#### Range

30Hz, 40Hz, 50Hz, 100Hz, 200Hz, 300Hz, 400Hz

#### Default

50Hz

#### Filter types

Shelf, Bell

#### Cutoff points

30Hz, 40Hz, 50Hz, 100Hz, 200Hz, 300Hz, 400Hz

### Low Mid Band Gain

#### Range

-12dB to +12dB (2-3dB steps)

#### Default

0dB

### Low Mid Band Frequency

#### Range

75Hz, 150Hz, 180Hz, 240Hz, 500Hz, 700Hz, 1kHz

#### Default

500Hz

#### Filter types

Bell

#### Cutoff points

75Hz, 150Hz, 180Hz, 240Hz, 500Hz, 700Hz, 1kHz

### High Mid Band Gain

#### Range

-12dB to +12dB (2-3dB steps)

#### Default

0dB

## **High Mid Band Frequency**

### **Range**

0.8kHz, 1.5kHz, 3kHz, 5kHz, 8kHz, 10kHz, 12.5kHz

### **Default**

5kHz

### **Filter types**

Bell

### **Cutoff points**

0.8kHz, 1.5kHz, 3kHz, 5kHz, 8kHz, 10kHz, 12.5kHz

## **High Band Gain**

### **Range**

-12dB to 12dB (2-3dB steps)

### **Default**

Off

## **High Band Frequency**

### **Range**

2.5kHz, 5kHz, 7kHz, 10kHz, 12.5kHz, 15kHz, 20kHz

### **Default**

10kHz

### **Filter types**

Shelf, Bell

### **Cutoff points**

2.5kHz, 5kHz, 7kHz, 10kHz, 12.5kHz, 15kHz, 20kHz

## **Low Shelf/Bell Selector**

### **Range**

Shelf or Bell

### **Default**

Shelf

## **High Shelf/Bell Selector**

### **Range**

Shelf or Bell

### **Default**

Shelf

## **In**

Turns the EQ On/Off but leaves the Analog modeling.

### **Range**

On/Off

### **Default**

On

## 3.2 Output Section



The Output section, which is identical on both the API 550A and API 550B, consists of controls for Polarity (Phase Inversion) Analog Modeling, Output Level, and Trim.

### Pol (Polarity)

Shifts the phase by 180 degrees.

#### Range

0deg-180deg

#### Default

0deg

### Analog

Turns the Analog modeling on and off.

#### Range

On/Off

#### Default

On

## **Output**

Controls the output level.

### **Range**

-18dB to +18dB (in 0.1dB steps)

### **Default**

0dB

## **Trim**

Displays the maximum peak level of the output signal and its distance from nominal gain (-0.1dBfs).

### **Range**

-inf to 0dB

### **Default**

-inf

## **Meters**



The API 550 meters display output level in dBFS. The LED located between the two meters lights up when output signal is clipping.

# Chapter 4 – The WaveSystem

## 4.1 The WaveSystem Toolbar



All Waves processors feature the WaveSystem toolbar which takes care of most administrative functions you will encounter while working with your Waves software. The features of the WaveSystem toolbar are the same on practically all Waves processors, so familiarity with its features will be helpful whichever processor you are using.

### Toolbar Functions

<b>Undo</b>	Undoes the last 32 actions.
<b>Redo</b>	Redoes the last 32 undone actions.
<b>Setup A/B</b>	Toggles between two presets. This is useful for close comparison of different parameter settings
<b>Copy A-&gt;B</b>	Copies the current settings to the second preset register
<b>Load</b>	Recalls presets from file
<b>Save</b>	Saves presets in the Waves file formats
<b>?</b>	Opens the manual for the processor you are using

## 4.2 Preset Handling

### Preset Types

**Factory Presets** are permanent presets in the Load menu. Factory presets cannot be over-written or deleted. When applicable, different component plug-ins may have different factory presets.

**User Presets** are your favorite settings of the plug-in saved as a preset in the Load menu, under ‘User Presets’. User Presets can be over-written and deleted.

**Setup Files** may contain more than one preset. For example, a single file can contain all the presets for a session. When you open a Setup File, all its setups become part of your Load pop-up menu for fast access. This can be particularly useful with multiple instances of a plug-in in a single session. By saving all the settings you create into a single Setup File, they can all be quickly available for every instance of that plug-in.

## Loading Presets and Setups



**Click-and-hold** on the Load button to see the Load pop-up menu. The menu is divided into four sections. If a section is not currently available it will not appear in the Load pop-up menu.

- Open Preset File...** Select to open any setup or preset file, whether from the Library or your own creations.
- 'Filename.xps':** Displays any currently loaded Setup File and its presets.
- Factory Presets:** Displays the default Factory Presets.
- User Presets:** Displays any loaded User Presets.

## Saving Presets and Setups



Click-and-hold on the Save button to see the Save pop-up menu. Four options are available. If an option is not currently available it will be grayed out and inaccessible.

- Save to New File...** Select this to start a new Setup file. There are two prompts - first for the setup filename, then for the preset name. You must provide a name for both the setup file and the preset. Click OK (ENTER) to complete the save. It is a good idea to create a folder in which to save several setup files for a project.
- Save 'File Name' – "Preset Name"** Overwrites the settings of the loaded preset (whether a User Preset or a preset from a Setup File) with the current settings. If a Setup File is currently loaded, the name of the Setup File is displayed followed by the name of the preset itself. If a User Preset is loaded, its name is displayed.
- Save to 'File Name' As...** Saves the current settings as a new preset into the Setup file that is open (if one is not open, the option is grayed out). You will be prompted to give the preset a name.
- Put into Preset Menu As...** Save the current settings into a User Preset that will always be in your Load menu (until deleted). You will be prompted to give this preset a name. User Presets are stored in the plug-in's preference file.

## **Deleting Presets**

You may delete User Presets and presets within a Setup File. Factory Presets and Setup Library files cannot be deleted or overwritten.

1. Hold the Command (Mac)/Control (PC) key down.
2. Click-and-hold the Load button to see the pop-up menu.
3. While still holding the Command/Control key, select the preset or setup to delete.
4. A confirmation box will appear, allowing you to cancel or 'OK' the deletion.

## **A/B Comparison and Copying**

The Setup A/Setup B button may be clicked to compare two settings. If you load a preset in the Setup B position, this will not affect the preset loaded into the Setup A position, and vice-versa.

If you want to slightly modify the settings in Setup A, you can copy them to Setup B by clicking on the Copy to B button, then alter Setup A and compare with the original Setup B.

The name of the current setup will be shown in the title bar (on platforms which support it), and will switch as you change from Setup A to Setup B.

Note: an asterisk will be added to the preset name when a change is made to the preset -

## **4.3 Interface Controls**

**Controls can be in one of three states:**

- **Not Selected** where the control is not the target of any user entry
- **Selected** where the control is the target of mouse control entry only
- **Selected and Active** where the control is the target for both mouse and keyboard entry

## **Toggle Buttons**

Toggle buttons display the state of a control, and allow switching between two or more states. **Single-click** to change the control's state. Some toggle buttons have a text display which updates with the current setting, and others (bypass, solo, or monitoring toggles) illuminate when the control is active.

Some processors have **link buttons** between a pair of toggle buttons, allowing click-and-drag adjustment while retaining the offset between the controls.

## **Value Window Buttons**

Value windows display the value of a control and allow **click-and-drag** adjustment, or **direct control via the keyboard**.

- **Using the mouse**, click-and-drag on the value window to adjust. Some value windows support left/right, some up/down (as you hover over a button, arrows will appear to let you know which direction of movement that button supports).
- **Using the arrow keys**, click once with mouse to select the button, and then use up/down – left/right (depending on the direction supported by that button) to move in the smallest incremental steps across the button's range (holding down the arrow keys will move faster through the range).
- **Using key entry**, double click on the button to open the value window, and directly enter the value from your keyboard. If you enter an out of range number, the button stays selected but remains at the current setting (system beeps? If system sounds are on?)

Some processors have **link buttons** between a pair of value windows, allowing click-and-drag adjustment while retaining the offset between the controls.

## **Sliders**

Click on the slider itself or anywhere within the sliders track. The numerical value of the slider settings is displayed in a hover window above the slider path.

## **Hover Box**

Hovering boxes will appear and display the control value when hovering with the mouse over the control.

## **Multiple Selection of Controls**

One of the most powerful features of the WaveSystem is the ability to select and adjust many controls at the same time. Using the mouse, simply drag-select the desired group of button or graphic controls by clicking and holding at a point outside the controls and forming a rectangle to include the controls you wish to adjust. Alternatively, you can hold down Shift while clicking the mouse on any control you wish to link. This second method is useful when you want to select two (or more) controls that are separated on the GUI by other controls you do not wish to select.

## **TAB Functions**

TAB moves the 'selected' status to the next control, with shift-TAB moving in the reverse direction.

Additionally, the Mac has an option-TAB function for 'down' movement and shift-option-TAB for 'up' movement where applicable.

If you have several Value Window Buttons selected, TAB functions will take you through the selected controls only.

## Appendix A – 550A Controls

Control	Range	Default
<b>Low Band Gain</b>	-12dB to 12dB (2-3dB's steps)	0dB
<b>Low Band Frequency</b>	50Hz,100Hz,200Hz,300Hz,400Hz	50Hz
<b>Mid Band Gain</b>	-12dB to 12dB(2-3dB's steps)	0dB
<b>Mid Band Frequency</b>	.4kHz,.8kHz,1.5kHz,3kHz,5kHz.	1.5kHz
<b>High Band Gain</b>	-12dB to 12dB(2-3dB's steps)	0dB
<b>High Band Frequency</b>	5kHz,7kHz,10kHz,12.5kHz,15kHz.	7kHz
<b>Filter</b>	Bandpass 50Hz-15kHz	Off
<b>Low shelf/bell selector</b>	Shelf or Bell	Shelf
<b>High shelf/bell selector</b>	Shelf or Bell	Shelf
<b>Output</b>	-18dB to 18dB	0dB
<b>Trim</b>	-inf to 0dB	-inf
<b>Analog</b>	On/Off	On
<b>Phase</b>	0deg- 180deg	0deg

## Appendix B – 550B Controls

Control	Range	Default
<b>Low Band Gain</b>	-12dB to 12dB(2-3dB's steps)	0dB
<b>Low Band Frequency</b>	30Hz,40Hz,50Hz,100Hz,200Hz,300Hz,400Hz	50Hz
<b>Low Mid Band Gain</b>	-12dB to 12dB(2-3dB's steps)	0dB
<b>Low Mid Band Frequency</b>	75Hz,150Hz,180Hz,240Hz,500Hz,700Hz,1kHz.	500Hz
<b>High Mid Band Gain</b>	-12dB to 12dB(2-3dB's steps)	0dB
<b>High Mid Band Frequency</b>	0.8kHz,1.5kHz,3kHz,5kHz,8kHz,10kHz,12.5kHz.	5kHz
<b>High Band Gain</b>	-12dB to 12dB(2-3dB's steps)	Off
<b>High Band Frequency</b>	2.5kHz,5kHz,7kHz,10kHz,12.5kHz,15kHz,20kHz.	10kHz
<b>Low shelf/bell selector</b>	Shelf or Bell	Shelf
<b>High shelf/bell selector</b>	Shelf or Bell	Shelf
<b>Output</b>	-18dB to 18dB	0dB
<b>Trim</b>	-inf to 0dB	-inf
<b>Analog</b>	On/Off	On
<b>Phase</b>	0deg- 180deg	0deg

