
Spectrum 1 **INSTRUCTIONS**



Please read these instructions carefully for proper operating procedures for the BOSS SP-1.

BEFORE USING SP-1

- When operating SP-1 from AC line, use BOSS AC Adaptor for SP-1.
- Avoid using SP-1 in very dusty location or under high temperature or humidity conditions.




CAUTION: The output sound may be distorted at a limited frequency range which is strument and amplifier to proper position to avoid such trouble. determined by Spectrum control to create a peak. Set level controls of in-

OPERATING SP-1



panel as illustrated. After connecting all cords required, set all knobs on the

- N Tread the pedal to check battery. If check lamp lights, battery is live.
- * If lamp does not light, which means dead battery, replace with a new battery.



Turn Spectrum knob to proper position

Tread pedal to set the unit in the state that sound is effected.




SPECTRUM

umes of Normal and Effect modes. Turn Balance knob to proper position to obtain well-balanced vol-

NAME AND FUNCTIONS

especially efficient when sound by emphasizing a limused at high frequencies. sound spectrum. The emited frequency range of the perfectly new effect unit; it BOSS Spectrum SP-1 is a Also it will give you a unique tinuously variable between phasis frequency can be conadds variety to the original tone, used with a bass guitar. 500Hz and 5KHz. It is



SPECTRUM

comes higher when turned clockwise (O) The frequency to be emphasized can be continuously changed from 500Hz to and lower when turned counterclockwise 5KHz by this knob. The frequency be

BALANCE
This knob controls volume balance of clockwise to boost Normal volume. wise to boost Effect volume and counter Normal and Effect modes, Turn clock

* The total volume is constant without regard to Balance control setting posi-

INPUT JACK

electric guitar and other electronic instruments. This input jack receives output from

OUTPUT JACK

This jack feeds signal to amplifier.

a BOSS AC Adaptor (DC9V) to this jack battery (9V) and from AC line, Connect AC ADAPTOR JACK
SP-1 operates both from self-contained

> PEDAL SWITCH performance.

circuit, guaranteeing stable long-time and the battery is disconnected from the

This is a changeover switch for Normal or Effect. By use of FET ELECTRONIC employed even in studio recording. eliminated and OD-1 can be satisfactorily size effect units, pop noise is perfectly SWITCH, first in these kinds of small


CHECK LAMP

lamp lets you confirm the changeover lights if battery is normal. Thus this While pedal is trod down, this lamp also battery state. between Effect and Normal modes, and

battery with a new one. If the indicator fails to light, replace the

ful not to lose it. screw from the pedal. If you do, be care to open the casing. Do not remove off the When replacing battery, loosen this screw

CAUTIONS FOR REPLACING AND HANDLING BATTERY



REPLACING BATTERY. USE ONE 9-VOLT BATTERY.

- Loosen the screw of pedal to open it and take out battery from its housing.
- Replace the battery by a fresh one and put it into position.
- Set coil spring onto the projection on the rear of the pedal and shut the cover (pedal). Finally, insert the screw into the pedal guide and tighten it.

At this time, be careful not to catch the battery strap in the cover or coil spring.


remo

CAUTIONS

- When you don't use for a long period, remove the battery to prevent current leakage and leaking out of sticky substance.
- If battery voltage drops, effect becomes inferior or no sound is produced. To present that, replace the battery a little
- Be sure to keep the battery snapped by connector into the housing, when using AC adaptor, too.
- * Even if AC Adaptor cord comes out during performance, operations immediately changes to battery, causing no trouble in continued performance.
- Power is switched on while a plug is put into input jack. When you do not use, keep the plug off the jack.

AC ADAPTOR (OPTION)

When you operate SP-1 from AC line, use AC Adaptor for SP-1.



SPECIFICATIONS

Weight 400g	Dimensions	Output load impedance (Input impedance	S/N ratio	Jack			Others	Control	Current draw		Power
100g	70(W) x 55(H) x 125(D)mm	Over 600Ω	220ΚΩ	Over 80dB	Input, Output, AC Adaptor	(also for confirmation of Normal/Effect changeover)	Battery Check Lamp	Normal/Effect Changeover Switch,	Spectrum (500Hz - 5KHz continuous), Balance	DC9V, 3.5mA	AC Adaptor	Battery 9V (1)

^{*}Specifications are subject to change without notice.



Printed in Japan '78 Dec. B-3

リンパクトツリーズのインツケーターがおちりました。

チェックインジケーターは、バッテリーチェックだけでなく、エフェクトインジケーターとしても動作します。エフェクト 市時にはインジケーターが点灯したままになり、ノーマル時にはインジケーターが、が消えます。使用中インジケーターが、暗くなったり点灯しなくなった場合は、電池が消耗していますので早めに新しい電池と交換して下さい。

NOTICE:

There has been a change in the LED indicators of the Boss compact series pedals.

Instead of being merely a battery checker which lights only when the pedal is depressed, the LED now goes on whenever the effect is on; therefore, the ON/OFF status of the effect can be seen at a glance. If the LED is dim when the effect is on, or does not light at all, this is an indication that the battery needs replacing

